Power Windows

Component Location Index

PASSENGER'S SWITCH
Test, page 16-46
Replacement, page 16-46

DRIVER'S SWITCH
Input Test, page 16-44
Test, page 16-45
Replacement, page 16-46

PASSENGER'S MOTOR
Test, page 16-47

DRIVER'S MOTOR
Test, page 16-47

POWER WINDOW RELAY
Test, page 16-43

DASH RELAY HOLDER