
## Headliner



## Replacement -

- 1. Remove:
  - Sun visors and holders.
  - Rearview mirror assembly (page 14-43).
  - Front pillar trim (page 14-36).
  - Quarter window trim panel (page 14-36).
  - Dome light.
  - Roof trim.
- 2. Remove the clips and rear roof trim, then remove the headliner.



3. Assemble the headliner in the reverse order of disassembly.

## NOTE:

- When installing the headliner inside the passenger cabin, be careful not to fold or bend it. Also, be careful not to scratch the body.
- Check that the two sides of the headliner are securely attached to the trim.