## **Test**




## - Evaporator Sensor -

Dip the evaporator sensor into a pan filled with ice water, and check for continuity between the terminals.

Cut off 1.5--0.5°C (35-33°F) Cut in 2.5-5°C (36-41°F)

If cut off or cut in temperature is too low or too high, replace the thermo switch.



## Relay

NOTE: All A/C system relays are similar.

- 1. Check for continuity between terminals ② and ④.
- Connect a 12 V battery across terminals ② and ④.
   There should be continuity between terminals ① and ③.

