
Brake Pad

Inspection/Replacement (cont'd) -


- Apply MOLYKOTE M77 or equivalent to both surfaces of the shim and back of the pads.
- 9. Install the brake pads.

NOTE: Apply MOLYKOTE M77 or equivalent between the shims and pads.

10. Install the brake pad shims correctly.



- 11. Push in the piston so that the caliper will fit over the pads.
- 12. Pivot the caliper down into position, then install the caliper bolt and tighten it.




- 13. Connect the brake hose to the knuckle.
- 14. Depress the brake pedal several times to make sure the brakes work, then road-test.

Brake Caliper


Disassembly -

CAUTION:

- Before reassembling, check that all parts are free of dust and other foreign particles.
- Replace parts with new ones whenever specified to do so.
- Use only clean brake fluid.
- Make sure no dirt or other foreign matter is allowed to contaminate the brake fluid.
- Do not mix different brands of brake fluid as they may not be compatible.
- Do not spill brake fluid on the car, it may damage the paint; if brake fluid does contact the paint, wash it off immediately with water.
- Remove the banjo bolt and disconnect the brake hose from the caliper.
- 2. Remove the caliper bolts, then remove the caliper.



33 N·m (3.3 kg-m, 24 lb-ft)
3. Remove the pad spring from the caliper body.






 Place a wooden block or shop rag in the caliper opposite the piston, then carefully remove the piston from the caliper by applying air pressure through the brake line hole.

WARNING

- Do not place your fingers in front of the piston.
- Do not use high air pressure; use an OSHAapproved 30 PSI nozzle.



5. Remove the piston boot and piston seal.


CAUTION: Take care not to damage the cylinder.



Reassembly -

CAUTION:

- Before reassembling, check that all parts are free of dust and other foreign particles.
- Replace parts with new ones whenever specified to do so.
- Use only clean brake fluid.
- Make sure no dirt or other foreign matter is allowed to contaminate the brake fluid.
- Do not mix different brands of brake fluid as they may not be compatible.
- Do not spill brake fluid on the car; it may damage the paint, if brake fluid does contact the paint; wash it off immediately with water.
- Clean the piston and caliper bore with brake fluid and inspect for wear or damage.
- Apply silicone grease to a new piston seal, then install the piston seal in the cylinder groove.
- Apply silicone grease to a new piston boot, then install the piston boot.



 Lubricate the caliper cylinder and piston with brake fluid, then install the piston in the cylinder with the dished end facing in.



- 5. Reinstall the caliper in the reverse order of removal.
- Fill the brake reservoir up and bleed the brake system (page 13-11).