
System Description


Vacuum Connections:

[KX, KS, KZ model (4WS)]






Control Box



System Description


Vacuum Connections (cont'd)

[KF, KG, KW, KB model (4WS)]






[KE model (4WS)]



System Description

Vacuum Connections (cont'd)

[KX, KS, KZ model (4WS)]



- 1) MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR
- ② EACV

- © VACUUM SWITCH


 © CRANKING LEAK SOLENOID VALVE

 © IDLE BOOST THROTTLE CONTROLLER
- 6 A/C IDLE BOOST SOLENOID VALVE
- TALLED VALVE A
- **8** AIR BLEED VALVE B
- **9 AIR CONTROL DIAPHRAGM**
- 10 INTAKE AIR TEMPERATURE (TA) SENSOR
- **(1) AIR LEAK SOLENOID VALVE**
- 12 INNER VENT SOLENOID VALVE
- (13) AIR VENT CUT-OFF SOLENOID VALVE
- (4) CANISTER
- (§) TWO-WAY VALVE
- **16 CHOKE OPENER**
- **M** VACUUM PISTON CONTROL VALVE
- **(8) THROTTLE CONTROLLER**
- 19 THERMOWAX VALVE
- **② SILENCER**

- **②1 AIR SUCTION VALVE**
- **② AIR SUCTION CONTROL SOLENOID VALVE**
- **3 THERMOVALVE**
- **WACUUM PISTON CONTROL SOLENOID VALVE**
- **(35)** CHECK VALVE C
- **®** AIR CHAMBER
- T EGR VALVE
- **® EGR CONTROL VALVE**
- **39 AIR FILTER**
- **30 PURGE CUT-OFF SOLENOID VALVE**
- **31 AIR JET CONTROLLER**
- **32 CATALYTIC CONVERTER**
- 39 CHECK VALVE A
 39 CHECK VALVE C
- 35 AIR BLEED VALVE C
- **® IDLE BOOST SOLENOID VALVE**



[KF, KG, KW, KB, KE model (4WS)]



- ① CRANKING LEAK SOLENOID VALVE ② AIR BLEED VALVE A
- 3 AIR CONTROL DIAPHRAGM
 4 AIR BLEED VALVE B
- **⑤ CANISTER**
- **® THERMOWAX VALVE**
- ① ANTI-AFTERBURN VALVE
- **8 THERMOVALVE**
- **9 THROTTLE CONTROLLER CONTROL VALVE**
- **10 THROTTLE CONTROLLER**

- **(11) CHECK VALVE C**
- 12 CHECK VALVE A
- **13 INNER VENT SOLENOID VALVE**
- (I) AIR VENT CUT-OFF SOLENOID VALVE
- **(15) A/C IDLE BOOST SOLENOID VALVE**
- (6) IDLE BOOST SOLENOID VALVE
- (17) CHOKE OPENER
- ® THERMOVALVE
- **19 IDLE BOOST THROTTLE CONTROLLER**