## Upper Arm/Stabilizer/Radius Rod/Lower Arm



Index/Inspection -

## **CAUTION:**

- The radius rod bushings can easily be incorrectly installed; the thick radius rod bushing should be installed in the front position.
- R or L mark is stamped on the rear end of the radius arm to prevent incorrect installation.

