Front Bumper

Replacement

- 1. Remove the side marker lights and front turn signal lights.
- 2. Remove the fog lights or lids.
- 3. Remove the 2 bumper lower mount bolts and the 4 bumper mount bolts.
- 4. Disconnect the headlight washer hose.
- 5. Remove the bumper by sliding it forward.

If necessary:

- 6. Remove the bumper brackets by removing the bracket mount botis.
- 7. Remove the screws, then remove the mud guards.

