

Tailpipe Emissions

Inspection

NOTE: It is not possible to use a CO meter to adjust the idle mixture; the effect of the catalytic converter prevents accurate tracking of such small changes in air-fuel ratio.

WWARNING Do not smoke during this procedure. Keep any open flame away from your work area.

- 1. Follow steps the propane enrichment method.
- Warm up and calibrate the CO meter according to the meter manufacturer's instructions.
- Check idle CO with the headlights, heater blower, rear window defogger, cooling fan, and air conditioner off.

Specified CO %:

KS, KX, KZ model: 0.1% maximum Except KS, KX, KZ model: 1.0±1.0%

Catalytic Converter

Carbureted Engine: KX, KS, KZ Fuel-Injected Engine: KX, KS, KZ, KQ

Inspection

If excessive exhaust system back-pressure is suspected, remove the catalytic converter from the car and make a visual check for plugging, melting or cracking of the catalyst. Replace the catalytic converter if more than 50% of the visible area is damaged or plugged.

NOTE: Tighten each nut in the sequence shown below.

