
Steering Gearbox


-Overhaul (2WS) –

- 1. Install the boots so that the angle of the pinion shaft center line is as shown.
- 2. Install new boot bands on the boot and bend both sets of locking tabs.


NOTE: LR Drive shown, RH Drive is symmetly.




<GEAR HOUSING SIDE> View from the left side.



<CYLINDER SIDE>
View from the right side.



3. Lightly tap on the doubled-over portions to reduce their height.



- 4. Install the air transfer tube.
- After assembling, slide the rack right and left to be certain that the boots are not deformed or twisted.