## **Rear Bumper**



## Replacement

- 1. Disconnect the two license light wire connectors.
- 2. Remove the 3 bumper mount screws on each side at the corner edge of the bumper.
- 3. Remove the 2 bumper lower mount nuts from under the trunk floor.
- 4. Remove the 2 bumper upper mount nuts from the trunk area.
- 5. Remove the bumper by sliding it to the rear.

NOTE: Do not damage the threads of the bumper bolts.

## If necessary:

6. Remove the screws and nuts, then remove the rear under spoiler.

