

Replacement -WARNING Do not smoke while working on fuel system. Keep any open flame away from your work area. Drain fuel in to an approved container. THROTTLE CONTROLLER FRONT BRACKET THERMOWAX VALVE PRIMARY ŚLOW MIXTURE CUT-OFF SOLENOID VALVE REAR BRACKET LEFT CARBURETOR **IDLE BOOST** THROTTLE CONTROLLER IDLE BOOST THROTTLE CONTROLLER [KX, KS, KZ **FUEL VAPOR PIPE** (4WS)] ීම **CROSSOVER PIPE** THROTTLE ANGLE SENSOR (A/T) PRIMARY SLOW MIXTURE CUT-OFF SOLENOID VALVE [KX, KS, KZ model and KY, KT, KF, KG, KW, KE, KB (A/T) model only] RIGHT CARBURETOR AIR VENT CUT-OFF SOLENOID VALVE