





IoT Product Development 1-Day Workshop INSTALLATION REQUIREMENTS

1) Register an Account at the Tool Vendor Websites:

- Zentri: Sign-Up for a Zentri DMS Account (Required!) https://dms.zentri.com/signup/
- **IBM Bluemix**: Sign-up for your own IBM Bluemix account (*Recommended*) https://console.ng.bluemix.net/registration/
- Avnet: Sign-Up to CloudConnectKits to access downloads and support forums (Recommended) http://cloudconnectkits.org/user/register/
- Cypress: Sign-up to WICED Wi-Fi community forum (Optional / Recommended) https://community.cypress.com/community/wiced-wifi

2) Download and Install ZentriOS SDK Development Tools:

ZentriOS SDK: Download and install the Zentri Development Tool (Required!)
 http://resources.zentri.com/zentrios sdk/ZentriOS SDK Installer.exe

3) Download and Install JRE (Java Runtime Environment)


- JRE must be present on your computer to run Zentri's Eclipse IDE
 Download and Installation of a recent version JRE 8 is recommended (Required!)
 - 32bit Windows: use 32bit JRE (x86)
 - 64bit Windows: use 64bit JRE (x64)

Oracle JRE Download site:

http://www.oracle.com/technetwork/java/javase/downloads/jre8-downloads-2133155.html

- JRE path <u>must</u> be present in your Windows path! eg.
 C:\ProgramData\Oracle\Java\javapath
- <u>Tip</u>: To check the JRE executables can be found,
 Open a cmd window then enter:
 where java*

(This lists the executables referenced by java path)









Manual Installation of USB Drivers (Not normally required!)

In some rare cases the Windows USB drivers require further attention after the ZentriOS SDK installation. (This will be apparent when after plugging-in the board, it is not recognized by the SDK software)

If this is the case with your installation, re-install these USB drivers manually as follows:

With the board unplugged from the USB, using **Windows File Explorer** go to: ...\ZentriOS_SDK\tools\drivers\ATG002

Double-click **dpinst64.exe** to run the Device Driver Install Wizard (Use **dpinst32.exe** instead if your computer has an older 32 bit Windows installation)

Once the driver installation has completed, again plug-in the BCM4343W IoT Starter Kit board

Use Windows Device Manager to check the USB COM port and USB JTAG port are now reported correctly...

