QUANTIZATION CODE FIGURES

Example:

 $Signal(t) = 0.5sin(200\pi t)$

 $F_s = 4000 \; Hz$

8000 Samples

3 Bits

-2.5 V to +2.5 V





