

Software Installation

- Work Instruction

Revision History				
Rev	ECO	Changes	Author	
1	N/A	Initial release	DSK	

Template: QMS-40-003-TEM, Rev.001 Page 1 of 3



Table of Contents

1	Scope	2
	References	
3	Installation of software on the Allen-Bradley CompactLogix 5370 PLC	2
4	Installation of software on the Allen-Bradley PanelView 800 4" TFT touch screen	3
1	Scope	

The present document provides instructions on how to install the required software on the AAU Pandemic Ventilator

2 References

- Ref 1. RI001-40-002-BIN PLC (Executable)
 Ref 2. RI001-40-004-BIN HMI (Executable)
- 3 Installation of software on the Allen-Bradley CompactLogix 5370 PLC
 - 1) Power off PLC.
 - 2) Take SD card from PLC (see figure below).
 - 3) Download contents of RI001-40-002-BIN PLC (Executable) [Ref 1] to folder "Logix" on SD card of PLC.
 - 4) Insert SD card in PLC where indicated in figure below.
 - 5) Power on device and installation starts automatically.





- 4 Installation of software on the Allen-Bradley PanelView 800 4" TFT touch screen
 - 6) Power off PLC and screen.
 - 7) Download contents of RI001-40-004-BIN HMI (Executable) [Ref 2] to USB stick (Must be FAT formatted).
 - 8) Insert USB as indicated in figure below.
 - 9) Power on device and installation starts automatically.





USB memory stick

Template: QMS-40-003-TEM, Rev.001 Page 3 of 3