Labels: US, 2016 ELECTRICAL Canada, TO CURRENT Mexico IC CIRCUIT BUS® BE / DIAGRAM CE SERIES CIRCUIT MANUAL DIAGRAMS - / 0000020182 March Revision 2024 7 / MY 2016 - 2024 IC BUS® BE / CE SERIES and ELECTRIC CE BUS SERIES CIRCUIT DIAGRAMS / IC Bus, LLC 2701 Navistar Drive, Lisle, IL 60532 USA / 2024 Navistar, Inc. All rights reserved. All marks are trademarks of their respective owners. ©

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS / 38 38 39 40 41 42 43 44 45 46 47 48

TABLE OF CONTENTS

TABLE OF CONTENTS

2. INSTRUCTIONS AND CHARTS (CHAPTER 2). 1
2.1. ABBREVIATIONS, P. 1. 1
2.2. ACRONYMS, P. 2. 2
2.3. CIRCUIT DIAGRAM INSTRUCTIONS, P. 3. 3
2.4. CIRCUIT NUMBER IDENTIFICATION AND COLOR, P. 4. 4
2.5. CIRCUIT NUMBER IDENTIFICATION AND COLOR (CONT.), P. 5. 5
2.6. CIRCUIT NUMBER IDENTIFICATION AND COLOR (CONT.), P. 6. 6
2.7. CIRCUIT NUMBER IDENTIFICATION AND COLOR (CONT.), P. 7. 7
2.8. CIRCUIT NAME COMPOSITION, P. 8. 8
2.9. CIRCUIT / INSULATION COLOR, P. 9. 9
2.10. LAMP BULB CHART, P. 10. 10
2.11. RELAY FUNCTION AND WIRING GUIDE, P. 11. 11
2.12. SCHEMATIC SYMBOL CHART, P. 12. 12
2.13. SCHEMATIC SYMBOL CHART (CONT.), P. 13. 13
2.14. SCHEMATIC SYMBOL CHART (CONT.), P. 14. 14
2.15. SCHEMATIC SYMBOL CHART (CONT.), P. 15. 15
2.16. SCHEMATIC SYMBOL CHART (CONT.), P. 16. 16
2.17. SCHEMATIC SYMBOL CHART (CONT.), P. 17. 17
2.18. SCHEMATIC SYMBOL CHART

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 3.12. 3.13. 3.14. 3.15. 3.16. 3.17. 3.18. 3.19. 3.20. 3.21. 3.22. 3.23. 3.24. 3.25. 3.26. 3.27. 3.28. / 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 / 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 3.62. 3.63. 3.64. 3.65. 3.66. 3.67. / 104 105 106 107 108 109 / 3.68. 3.69. 3.70. 3.71. 3.72. 3.73.

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

3.62. ZERO VOLT REFERENCE SPLICE (CONT.), P. 59. 99
3.63. ZERO VOLT REFERENCE SPLICE (CONT.), P. 60. 100
3.64. ENGINE GROUND W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 61. 101
3.65. ENGINE GROUND W/ F 2018 PROPANE ENGINE, P. 62. 102
3.66. ENGINE GROUND W/ F 2018 GASOLINE ENGINE, P. 63. 103
3.67. BATTERY ECM POSITIVE / NEGATIVE CONN W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 64. 104
3.68. BATTERY ECM POSITIVE / NEGATIVE CONN W/ F 2018 PROPANE ENGINE, P. 65. 105
3.69. BATTERY ECM POSITIVE / NEGATIVE CONN W/ F 2018 GASOLINE ENGINE, P. 66. 106
3.70. DC POWER EFFECTS, P. 67. 107
3.71. DC POWER EFFECTS W/ 2017 ISB DIESEL ENGINE, P. 67A. 108
3.72. BATTERY ISOLATOR, P. 68. 109
3.73. J1939 DATALINK W/ 500K W/ LCT / WTEC XMSN W/ 2017 ISB / 2021 B6.7 DIESEL & F-2018 PROPANE / GASOLINE ENGINE, P. 69. 110
3.74. J1939 DATALINK W/ 500K W/ LCT / BENDIX ABS-8 W/ 2017 ISB / 2021 B6.7 DIESEL & F-2018 PROPANE / GASOLINE ENGINE, P. 70. 111
3.75. J1939 DATALINK WITH 500K WITH LCT / ABS 8 / ZONAR WITH F 2017 ISB / 2021 B6.7 DIESEL & F 2018 PROPANE / GASOLINE ENGINE, P. 71. 112
3.76. J1939 DATALINK WITH 500K WITH LCT / WINGMAN / ZONAR WITH F 2017 ISB / 2021 B6.7 DIESEL & F 2018 PROPANE / GASOLINE ENGINE, P. 72. 113
3.77. J1939 DATALINK WITH 500K WITH BENDIX FUSION WITH 2017 ISB / 2021 B6.7 DIESEL & F 2018 PROPANE / GASOLINE ENGINE, P. 73. 114
3.78. J1939 DATALINK W/ 500K W/ LCT / BENDIX WINGMAN W/ 2017 IBS / 2021 B6.7 DIESEL & F-2018 PROPANE / GASOLINE ENGINE, P. 74. . . . . .

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 138 139 140 141 142 143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159 160 161 162 163 164 165 166 167 168

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

3.92. J1939 DATALINK WITH 500K W/ EATON PROCISION XMSN W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 88. 129
3.93. J1939 DATALINK WITH PUBLIC CAN WITHOUT ENHANCED VCM FUNCTION W/ F-2018 PROPANE ENGINE, P. 89. 130
3.94. J1939 DATALINK WITH PUBLIC CAN WITH ENHANCED VCM FUNCTION W/ F-2018 PROPANE ENGINE, P. 90. 131
3.95. J1939 DATALINK WITH PUBLIC CAN WITHOUT PAM W/ F-2018 GASOLINE ENGINE, P. 91. 132
3.96. J1939 DATALINK W/ 500K W/ ENHANCED VCM FUNCTIONS W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 92. 133
3.97. DRIVER INTERFACE UNIT W/ 2017 ISB / 2021 B6.7 DIESEL & W/ 2018 PROPANE / GASOLINE ENGINE, P. 93. 134
3.98. BATTERY FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE / GASOLINE ENGINE, P. 94. 135
3.99. ACCESSORY FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE / GASOLINE ENGINE, P. 94A. 136
3.100. IGNITION FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE / GASOLINE ENGINE, P. 94B. 137
3.101. IGNITION FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE / GASOLINE ENGINE (CONT.), P. 94C. 138
3.102. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL, P. 94D. 139
3.103. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94E. 140
3.104. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94F. 141
3.105.

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 174 175 / 179 180 / 186 187 / 189 190 / 193 194 195 196

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

3.132. J1708 DATALINK COMPLETE W/ WTEC XMSN W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE, P. 96. 169
3.133. J1708 DATALINK COMPLETE W/ WTEC XMSN W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE (CONT.), P. 96A. 170
3.134. J1939 DATALINK COMPLETE W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE, P. 96B. 171
3.135. J1939 DATALINK BASIC W/ LCT OR EATON XMSN W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE, P. 96C. 172
3.136. J1939 DATALINK BASIC W/ WTEC XMSN W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE, P. 96D. 173
3.137. J1939 DATALINK BASIC W/ LCT OR EATON & W/ WTEC XMSN W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE, P. 96E. 174
3.138. J1939 DATALINK W/ 500K W/ 2017 ISB DIESEL ENGINE, P. 96F. 175
3.139. J1939 DATALINK W/ 500K W/ LCT XMSN OR E-PRO W/ 2017 ISB DIESEL ENGINE, P. 96G. 176
3.140. J1939 DATALINK W/ 500K W/ LCT XMSN OR E-PRO & W/ ZONAR W/ 2017 ISB DIESEL ENGINE, P. 96H. 177
3.141. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX WINGMAN W/ 2017 ISB DIESEL ENGINE, P. 96J. 178
3.142. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX WINGMAN & ZONAR W/ 2017 ISB DIESEL ENGINE, P. 96K. 179
3.143. J1939 DATALINK W/ 500K W/ LCT XMSN & ABS-8 W/ 2017 ISB DIESEL ENGINE, P. 96L. . . 180
3.144. J1939 DATALINK W/ 500K W/ LCT XMSN & ABS-8 & ZONAR W/ 2017 ISB DIESEL ENGINE, P. 96M. . . . . .

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 204 205 206 / 207 208 209 210 211 / 4.2. 4.3. 4.4. 4.5. 4.6. / 212 213 214 215 216 / 4.7. 4.8. 4.9. 4.10. / 217 218 219 220 221 222 223 224 / 5.2. 5.3. 5.4. 5.5. 5.6. 5.7. 5.8. 5.9. / 226 227 228 229 / 5.11. 5.12. 5.13. 5.14.

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 237 237 238 239 240 241 242 / 243 244 245 246 247 248 249 250 251 252 253 254 255 256 257 258 259 / 6.8. 6.9. 6.10. 6.11. 6.12. 6.13. 6.14. 6.15. 6.16. 6.17. 6.18. 6.19. 6.20. 6.21. 6.22. 6.23. 6.24. / 261 261 262 263 264 265 266 267 268 269

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 7.10. 7.11. 7.12. 7.13. 7.14. 7.15. 7.16. 7.17. 7.18. 7.19. 7.20. 7.21. 7.22. 7.23. 7.24. / 270 271 272 273 274 275 276 277 278 279 280 281 282 283 / 284 285 286 287 / 7.25. 7.26. 7.27. 7.28. / 288 289 / 7.29. 7.30. / 291 292 293 294 295 296 297 298 299 300 301 302 303 304 / 7.32. 7.33. 7.34. 7.35. 7.36. 7.37. 7.38. 7.39. 7.40. 7.41. 7.42. 7.43. 7.44. 7.45.

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 312 313 / 7.53. 7.54. / 315 316 317 318 / 7.56. 7.57. 7.58. 7.59. / 324 325 326 327 / 7.65. 7.66. 7.67. 7.68. / 329 330 331 332 333 334 335 336 337 338 339 / 7.70. 7.71. 7.72. 7.73. 7.74. 7.75. 7.76. 7.77. 7.78. 7.79. 7.80. / 340 341 342 343 344 / 7.81. 7.82. 7.83. 7.84. 7.85.

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / BRAKE MONITORING EFFECTS, P. 70..... / 348 348 349 350 351 352 353 354 355 356 357 358 359 360 361 362 363 364 365 366 367 368 369 / 370 371 372 373 374 375 376 377 378 379 380 381 382 383 384 385 386 387 388 389 390 391 392 393 394 / 8.24. 8.25. 8.26. 8.27. 8.28. 8.29. 8.30. 8.31. 8.32. 8.33. 8.34. 8.35. 8.36. 8.37. 8.38. 8.39. 8.40. 8.41. 8.42. 8.43. 8.44. 8.45. 8.46. 8.47.

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 8.48. 8.49. 8.50. / 395 396 / 398 399 400 / 8.52. 8.53. 8.54. / 401 402 403 404 / 8.55. 8.56. 8.57. 8.58. / 407 408 409 / 8.61. 8.62. 8.63. / 411 412 413 414 415 / 8.65. 8.66. 8.67. 8.68. / 416 416 417 418 419 420 421 422 / 423 424 425 426 427 428 429 / 9.9. 9.10. 9.11. 9.12. 9.13. 9.14. / 430 430 431 432

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 10.4. 10.5. 10.6. 10.7. / 433 434 435 436 / 437 437 / 440 441 / 11.5. 11.6. / 443 444 445 446 447 448 449 450 451 452 / 453 454 455 / 456 456 457 458 459 460 461 462 / 464 465

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

10.4. MOTORIZED MIRROR (CONT.), P. 4. 433
10.5. HEATED MIRROR - LEFT AND RIGHT OVERHEAD, P. 5. 434
10.6. HEATED CROSSVIEW MIRRORS, P. 6.. 435
10.7. HEATED AND MOTORIZED MIRROR WITH LOWER MOUNT, P. 7.. 436
11. ENGINE AND ENGINE SYSTEM (CHAPTER 11).. 437
11.1. ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 1. 437
11.2. ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 2. 438
11.3. ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 3. 439
11.4. ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 4. 440
11.5. DEF AND AFTERTREATMENT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 5. 441
11.6. DEF AND AFTERTREATMENT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 6. 442
11.7. DEF AND AFTERTREATMENT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 7. 443
11.8. FAN WIRING WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 8.. 444
11.9. FREON COMPRESSOR WIRING WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 9. 445
11.10. ELECTRONIC ENGINE CONTROL WITH F-2018 PROPANE ENGINE, P. 10.. 446
11.11. ELECTRONIC ENGINE CONTROL WITH F-2018 PROPANE ENGINE (CONT.), P. 11. 447
11.12. FREON COMPRESSOR WIRING WITH F-2018 PROPANE ENGINE, P. 12. 448
11.13. ELECTRONIC ENGINE CONTROL WITH F-2018 GASOLINE ENGINE, P. 13. 449
11.14. ELECTRONIC EN

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 473 474 / 478 479 480 / 481 482 / 484 485 / 489 490 / 493 494 495 / 13.2. 13.3. 13.4.

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

12.14. 1 / 2 / 3000 ALLISON XMSN GEN5 (WTEC / LCT) WITH BCM GEN4 WITH 2017 ISB DIESEL ENGINE, P. 10A. 469
12.15. 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 11. 470
12.16. 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 12. 471
12.17. 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 12A. 472
12.18. 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 13. 473
12.19. EATON PROCISION XMSN WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 14. 474
12.20. EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017 ISB DIESEL ENGINE, P. 15. 475
12.21. EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017 ISB DIESEL ENGINE (CONT.), P. 15A. 476
12.22. EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017 ISB DIESEL ENGINE (CONT.) , P. 15B. 477
12.23. EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017 ISB DIESEL ENGINE (CONT.), P. 15C. 478
12.24. J1939 EATON PROCISION XMSN WITH 250K, P. 15D. 479
12.25. J1939 WITH 500K EATON PROCISION XMSN WITH 4100, P. 15E. 480
12.26. EATON PROCISION TRANSMISSION WITH PUSH BUTTON WITH 2017 ISB DIESEL ENGINE, P. 15F. . . . .

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 497 498 / 13.6. 13.7. / 499 500 501 502 / 508 509 510 511 / 512 513 514 515 516 517 518 519 / 520 521 522 / 526 527 528

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

13.5. PARK BRAKE SIGNAL WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE, P. 4. 497
13.6. PARK BRAKE SIGNAL WITH 2017 ISB & 2018 PROPANE / GASOLINE ENGINE, P. 4A. 498
13.7. AIR SOLENOID EFFECTS WITH 4 PACK WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE, P. 5. 499
13.8. WINDSHIELD WIPER EFFECTS WITH CE BUS WIPER MOTOR WIRING, P. 6. 500
13.9. WINDSHIELD WIPER EFFECTS WITH CE BUS WIPER MOTOR WIRING (CONT.), P. 7. 501
13.10. REMOTE HAZARD SWITCH EFFECTS W/ TILTING & TELESCOPING, P. 8. 502
13.11. WINDSHIELD WIPER EFFECTS W/ WIPER MOTOR WIRING WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE, P. 8A. 503
13.12. WINDSHIELD WIPER EFFECTS W/ WIPER MOTOR WIRING WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE (CONT.), P. 8B. 504
13.13. REMOTE HAZARD SWITCH EFFECTS W/ TILTING & TELESCOPING WITH 2017 ISB DIESEL & 2018 PROPANE / GASOLINE ENGINE, P. 8C. 505
13.14. REMOTE HAZARD SWITCH EFFECTS W/ TILTING & TELESCOPING WITH 2017 ISB DIESEL & 2018 PROPANE / GASOLINE ENGINE (CONT.), P. 8D. 506
13.15. AIR HORN EFFECTS WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE, P. 9. 507
13.16. AIR HORN EFFECTS WITH 2017 ISB DIESEL & 2018 PROPANE / GASOLINE ENGINE, P. 9A. 508
13.17. TRACTION AIDS EFFECTS WITH TRACTION CHAIN, P. 10. 509
13.18. TIRE WINCH EFFECTS, P. 11. 510
13.19. FIRE SUPPRESSION SYSTEM WITH JOMARR VTS12 AND PRESSURE SWITCH, P. 12. . . 511
13.20. FIRE SUPPRESSION WITH INDICATOR WITHOUT BUZZER ON 2017 ISB DIESEL ENGINE, P. 12. . . . . .

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 533 534 535 / 541 542 543 / 547 548 / 552 553

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

13.39. BENDIX ABS-8 WITH EC 80, GEN 4 BC AND ATC WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 30. 531
13.40. BENDIX ABS-8 WITH EC 80,GEN 4 BC AND STABILITY CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 31. 532
13.41. BENDIX ABS-8 WITH EC 80, GEN 4 BC, FUSION & WINGMAN WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 32. 533
13.42. HYDRAULIC BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 33. 534
13.43. HYDRAULIC BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 34. 535
13.44. HYDRAULIC BRAKE WITH AIR COMPRESSOR V8 AND L MEGA BRACKET WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 35. 536
13.45. HYDRAULIC BRAKE WITH AIR COMPRESSOR V8 AND L MEGA BRACKET WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 36. 537
13.46. HYDROMAX HYDRAULIC BRAKES WITH MANUAL PARK BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 37. 538
13.47. HYDROMAX HYDRAULIC BRAKES WITH WABCO MK25 AND STABILITY CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 38. 539
13.48. HYDROMAX HYDRAULIC BRAKES WITH WABCO MK25 AND STABILITY CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 39. 540
13.49. HYDROMAX HYDRAULIC BRAKES WITH WABCO MK25 AND STABILITY CONTROL WITH 2017 ISB DIESEL ENGINE, P. 39A. 541
13.50. BENDIX ABS-6 WITHOUT ATC WITH F-2018 PROPANE / GASOLINE ENGINE, P. 40. 542
13.51. BENDIX ABS-6 WITH ATC WITH F-2018 PROPANE / GASOLINE ENGINE, P. 41. 543
13.52. BENDIX ABS-6 WITH PARK BRAKE BUZZER WITH F-2018 PROPANE / GASOLINE ENGINE, P. 42. 544
13.53. BENDIX ABS-8, WITH EC 80, GEN 4 BC AND ATC WITH F-2018 PROPANE / GASOLINE ENGINE, P. 43

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 568 569 570 571 / 574 575 576 / 578 579 580 / 581 581 582 583 584 585 586 587 588 589 590 591 592

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

13.67. BENDIX ABS 6 WITH 2017 ISB DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE (CONT.), P. 53C. .. . .

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 593 594 595 596 597 598 / 600 601 602 603 604 605 606 607 / 610 611 612 / 614 615 / 15.3. 15.4. / 621 622

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

14.13. KICK OUT WINDOW WITH 3 IN RED LIGHT SECT 7 TO 13 RIGHT BODY, P. 11. 593
14.14. KICK OUT WINDOWS - ANY SECT 4 TO 6 LEFT BODY, P. 12. 594
14.15. KICK OUT WINDOWS - ANY SECT 7 TO 9 LEFT BODY, P. 13. 595
14.16. KICK OUT WINDOWS - ANY SECT 10 TO 12 LEFT BODY, P. 14. 596
14.17. ROOF HATCHES WITH ALARM SECTION 1 TO 11 LEFT BODY, P. 15. 597
14.18. ROOF HATCHES WITH ALARM SECTION 11 TO 13 LEFT BODY, P. 16. 598
14.19. ROOF HATCHES WITH ALARM AND STARTER INTERLOCK SECT 1 TO 4 AND 9 TO 12 LEFT BODY, P. 17. 599
14.20. ROOF HATCHES WITH ALARM AND STARTER INTERLOCK SECT 5 TO 8 AND 13 LEFT BODY, P. 18. 600
14.21. LEFT SIDE EMERGENCY DOOR, P. 19. 601
14.22. LEFT SIDE EMERGENCY DOOR (CONT.), P. 19A. 602
14.23. RIGHT SIDE EMERGENCY EXIT DOOR WITH ACCESSORY FEED, P. 20. 603
14.24. RIGHT SIDE EMERGENCY EXIT DOOR WITH ACCESSORY FEED (CONT.), P. 21. 604
14.25. RIGHT SIDE EMERGENCY EXIT DOOR, P. 22. 605
14.26. RIGHT SIDE EMERGENCY EXIT DOOR (CONT.), P. 23. 606
14.27. RIGHT SIDE EMERGENCY EXIT DOOR (CONT.), P. 24. 607
14.28. RIGHT SIDE EMERGENCY DOOR WITH 3 IN RED LIGHT TIED TO CLEARANCE LIGHT WITHOUT KICK OUT WINDOW, P. 25. 608
14.29. RIGHT SIDE EMERGENCY DOOR WITH 3 IN RED LIGHT TIED TO CLEARANCE LIGHT WITH KICK OUT WINDOW, P. 26. 609
14.30. RIGHT SIDE EMERGENCY DOOR WITH 3IN RED LIGHT TIED TO IGNITION SECT 7 TO 8, P. 27. . . . . .

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 635 636 637 638 639 640 641 642 643 644 / 647 648 649 650 651 652

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

15.14. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 4 TO 5, P. 14. 626
15.15. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 4 TO 5, 5 TO 6, P. 15. 627
15.16. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 6 TO 7, P. 16. 628
15.17. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 7 TO 8, P. 17. 629
15.18. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 8 TO 9, P. 18. 630
15.19. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 9 TO 10, P. 19. 631
15.20. SINGLE LEFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 10 TO 11, P. 20. 632
15.21. SINGLE LEFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 11 TO 12, P. 21. 633
15.22. SINGLE LEFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 12 TO 13, P. 22. 634
15.23. 48 INCH ALTERNATE ENTRANCE DOOR INTERLOCK TO BRAKE AND XMSN IN SECTION 7 TO 8, 8 TO 9, P. 23. 635
15.24. PUPIL WARNING LIGHTS ACTIVATED BY LIFT DOOR OPEN, P. 24. 636
15.25. LIFT DOOR WITH STARTER INTERLOCK, P. 25. . . . . .

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 657 658 659 / 16.6. 16.7. 16.8. / 660 661 662 663 664 / 665 666 667 668 669 / 672 673 674 675 676 / 679 680 681 682 683 684 685 686 687 688 689 690 691 692 693 694 695 / 696 696

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

16.5. PANEL MOUNTED DOOR CONTROLS - WITH 2 POSITION TOGGLE SWITCH WITH AMBER CANCEL WITH RRX, MASTER SWITCH, P. 5. 657
16.6. PANEL MOUNTED DOOR CONTROLS - WITH LEFT SIDE REDUNDANT DOOR, P. 6. 658
16.7. PANEL MOUNTED DOOR CONTROLS - WITH RIGHT SIDE REDUNDANT DOOR, P. 7. 659
16.8. FRONT ENTRANCE DOOR - WITH MANUAL DOOR CONTROL WITHOUT AIR / ELECTRIC DOOR, P. 8. 660
16.9. FRONT ENTRANCE DOOR - WITH AIR DOOR, P. 9. 661
16.10. FRONT ENTRANCE DOOR - WITH AIR DOOR (CONT.), P. 9A. 662
16.11. FRONT ENTRANCE DOOR - WITH AIR DOOR WITH LOW SIDE DRIVER, P. 10. 663
16.12. FRONT ENTRANCE DOOR - WITH AIR DOOR WITH LOW SIDE DRIVER (CONT.), P. 10A. . . 664
16.13. FRONT ENTRANCE DOOR - WITH AIR DOOR WITHOUT STEP-WELL LIGHT RELAY, P. 11. 665
16.14. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR, P. 12. 666
16.15. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR (CONT.), P. 12A. 667
16.16. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH LOW SIDE DRIVER, P. 13. 668
16.17. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH KEY OFF SWITCH, P. 14. 669
16.18. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH KEY OFF SWITCH (CONT.), P. 15. 670
16.19. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH RELEASE STARTER INTERLOCK, P. 16. 671
16.20. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH SINGLE CYCLE FLASHER CANCEL, P. 17. 672
16.21. VANDAL LOCKS ON RIGHT WITH AIR DOOR WITH ZONAR, P. 18. 673
16.22. VANDAL LOCKS ON RIGHT WITH ELECTRIC DOOR WITH ZONAR, P. 19. 674
16.23. VANDAL LOCKS ON RIGHT WITH

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 17.2. 17.3. 17.4. 17.5. / 697 698 699 / 700 701 702 703 704 705 706 707 708 709 710 711 712 713 714 715 716 717 718 719 720 721 722 723 724 725 726 / 727 728 729 730 731 732 733 734 735 / 736 736 737 738 739 740 741 742 743

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 744 745 746 747 748 749 750 751 752 753 754 755 756 / 769 770 771 772 773 774 775 776

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

18.9. THEFT MATE PREWIRE SYSTEM, P. 5.. 744
18.10. THEFT MATE PREWIRE SYSTEM (CONT.), P. 5A. 745
18.11. THEFT MATE PREWIRE SYSTEM (CONT.), P. 6. 746
18.12. THEFT MATE PREWIRE SYSTEM (CONT.), P. 7. 747
18.13. THEFT MATE PREWIRE SYSTEM (CONT.), P. 7A. 748
18.14. THEFT MATE PREWIRE SYSTEM WITH SNOOZE, P. 8. 749
18.15. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 9. 750
18.16. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 10. 751
18.17. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 11. 752
18.18. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 12. 753
18.19. CHILD CHECK MATE SYSTEM, P. 13.. 754
18.20. CHILD CHECK MATE SYSTEM (CONT.), P. 13A.. 755
18.21. CHILD CHECK MATE SYSTEM WITH PTI DEACTIVATION SWITCH IN LIGHT BAR, P. 14.. . 756
18.22. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR AND WITH LIFT, P. 15.. .. ..

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 779 780 781 782 783 784 785 786 787 788 789 790 791 792 793 794 795 796 / 799 800 801 802 803 804 805 806 807 808 / 813 814 / 815 816 / 817 817

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

18.44. CHILD CHECKMATE / THEFT MATE SYSTEM WITH EMERGENCY EXIT ACT WITH DOME LIGHT (CONT.), P. 36 779
18.45. LEAVE NO STUDENT BEHIND WITH BATTERY FEED BUZZ, P. 37. 780
18.46. LEAVE NO STUDENT BEHIND WITH BATTERY FEED BUZZ (CONT.), P. 37A. 781
18.47. POST TRIP INSPECTION EFFECTS WITHOUT CRS, P. 38. 782
18.48. POST TRIP INSPECTION EFFECTS WITHOUT CRS (CONT.), P. 38A. 783
18.49. POST TRIP INSPECTION EFFECTS WITH SNOOZE, P. 39. 784
18.50. POST TRIP INSPECTION EFFECTS WITH SNOOZE (CONT.), P. 39A. 785
18.51. CHILD SAFETY ALARM, P. 40. 786
18.52. CHILD SAFETY ALARM (CONT.), P. 40A. 787
18.53. THEFT MATE PREWIRE SYSTEM WITH SNOOZE, P. 41. 788
18.54. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 41A. 789
18.55. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 41B. 790
18.56. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 41C. 791
18.57. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 41D. 792
18.58. CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT, P. 42. 793
18.59. CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT (CONT.), P. 42A. 794
18.60. CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT (CONT.), P. 42B. 795
18.61. CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT (CONT.), P. 42C. 796
18.62. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACT WITHOUT LIFT, P. 43. 797
18.63. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACT WITHOUT LIFT (CONT.), P. 43A. 798
18.64. CHILD CHECKMATE SYSTEM WITH ENTRA

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 860 861 862 863 864 865

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

19.2. BOOSTER PUMP W/ FRONT MOUNTED HEATER W/ TIMER IN ELECTRICAL PANEL OR OVERHEAD DRIVER COMPARTMENT, P. 2. 818
19.3. BOOSTER PUMP W/ FR MOUNTED HEATER W/ SMART TIMER, P. 3. 819
19.4. BOOSTER PUMP W/ FR MOUNTED HEATER W/ TIMER RIGHT DRIVER, P. 4. 820
19.5. BOOSTER PUMP W/ FR MOUNTED HEATER W/ WHITE TIMER, P. 5. 821
19.6. BOOSTER PUMP W/ ACTIVATED BY HEATER SWITCH, P. 6. 822
19.7. BOOSTER PUMP W/ COOLANT HEATER WIRED SEPARATELY W/ TIMER, P. 7. 823
19.8. BOOSTER PUMP W/ COOLANT HEATER W/ TIMER AND LOW VOLTAGE DISC, P. 8. 824
19.9. BOOSTER PUMP W/ ESPAR HEATER W/ TIMER PREWIRE, P. 9. 825
19.10. BOOSTER PUMP WITH 2010 HIGH OUTPUT, P. 10. 826
19.11. BOOSTER PUMP ACTIVATED BY DRIVER HEATER SWITCH, P. 11. 827
19.12. ESPAR COOLANT HEATER W/ ESPAR 7-DAY TIMER / WHITE TIMER W/ DIESEL, P. 12. . . 828
19.13. ESPAR COOLANT HEATER W/ ESPAR W/ MULTIMAX TIMER W/ DIESEL, P. 13. 829
19.14. ESPAR COOLANT HEATER W/ RSM TANK AND W/ 12 KW RSM TANK, P. 14. 830
19.15. ESPAR COOLANT HEATER W/ AUXILIARY AND RSM FUEL TANK, P. 15. 831
19.16. COOLANT HEATER EFFECTS, P. 16. 832
19.17. COOLANT HEATER EFFECTS (CONT.), P. 17. 833
19.18. COOLANT HEATER EFFECTS (CONT.), P. 18. 834
19.19. COOLANT HEATER EFFECTS (CONT.), P. 19. 835
19.20. COOLANT HEATER EFFECTS (CONT.), P. 20. 836
19.21. LEFT FRONT PASSENGER HEATER, P. 21. 837
19.22. LEFT REAR PASSENGER HEATER, P. 22. 838
19.23. RIGHT FRONT PASSENGER HEATER, P. 23. 839
19.24. RIGHT REAR PASSENGER HEATER, P

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 866 867 / 869 870 871 872 873 874 875 876 877 878 879 / 881 881 882 883 884 885 886 887 888 889 890 891 892 893 894 895 896 897 898 899 900 901 902 903 904 905 906 907 908 909 910 911

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

19.50. DUAL A/C COMPRESSOR DISABLE #1 AND #2, P. 50. 866
19.51. AIR COMPRESSOR, P. 51. .. . .

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.)

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

20.32. CONNECTOR COMPOSITES %(1030), %(1031), %(1031), P. 18A. 912
20.33. CONNECTOR COMPOSITES %(1033B), %(1043A), %(1044A), %(1051), P. 19. 913
20.34. CONNECTOR COMPOSITES %(1052), @(1053), @(1053), %(1060), P. 20. 914
20.35. CONNECTOR COMPOSITES %(1060A), @(1062), %(1099), %(1099A), P. 21. 915
20.36. CONNECTOR COMPOSITES %(1099C), %(1099D), %(1100), P. 22.. 916
20.37. CONNECTOR COMPOSITES @(1100), @(1100), %(1101), P. 23. 917
20.38. CONNECTOR COMPOSITES %(1101), %(1104), %(1104A), %(1104B), %(1105M), P. 24. . . . 918
20.39. CONNECTOR COMPOSITES %(1109), %(1109A), @(1135), P. 25. 919
20.40. CONNECTOR COMPOSITES @(1135A), @(1136), @(1136A), P. 26. 920
20.41. CONNECTOR COMPOSITES %(1137), P. 26A. 921
20.42. CONNECTOR COMPOSITES %(1138), %(1139), P. 27. 922
20.43. CONNECTOR COMPOSITES %(1140), %(1145), %(1145), ##(1146), P. 28. 923
20.44. CONNECTOR COMPOSITES %(1146A), %(1146B), %(1147), P. 29. 924
20.45. CONNECTOR COMPOSITES %(1232), *(1233), P. 30.. 925
20.46. CONNECTOR COMPOSITES *(1234), P. 30A.. 926
20.47. CONNECTOR COMPOSITES %(1300), %(1301), %(1301), P. 31. 927
20.48. CONNECTOR COMPOSITES %(1302), %(1349), %(1350), P. 32. 928
20.49. CONNECTOR COMPOSITES %(1350), %(1351), P. 32A. 929
20.50. CONNECTOR COMPOSITES %(1401), %(1402), %(1403), P. 32B. 930
20.51. CONNECTOR COMPOSITES %(1404), #(1500), #(1501), P. 33. 931
20.52. CONNECTOR COMPOSITES #(1505), P. 33A. 932
20.53. CONNECTOR COMPOSITES %(1531), %(1555), %(1556), P. 34. 933
20.54. CONNECTOR COMPOSITES *@(1600), P. 35.. . .. .

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 963 964 965 966 967 968 969 970 971 972 973 974 975 976 977 978 979 980 981 982 983 984 985 986 987 988 989 990 991 992 993 994 995 996 997 998 999 / 1000 1000 1001 1002 1003 1004 1005 1006 1007 1008 1009 1010 1011

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.)

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

21.13. CONNECTOR COMPOSITES *(4017), *(4018), *(4019), P. 12. . .. .
1012
21.14. CONNECTOR COMPOSITES *(4034), *(4036), *(4037), P. 13. . .. .
1013
21.15. CONNECTOR COMPOSITES *(4037), *(4038), #(4039), P. 14. . . . . .
. . 1014
21.16. CONNECTOR COMPOSITES *(4040), &(4041), *(4041), P. 15. . .. .
1015
21.17. CONNECTOR COMPOSITES !(4041), @(4041), *(4041A), P. 16.. .. ..
1016
21.18. CONNECTOR COMPOSITES *(4043), P. 17. . . ..
.. . . 1017
21.19. CONNECTOR COMPOSITES *(4045), &(4046), P. 18. . . . . .
. 1018
21.20. CONNECTOR COMPOSITES *(4046), &(4049), P. 19. . . . . .
. 1019
21.21. CONNECTOR COMPOSITES &(4049A), &(4050), &(4050A), P. 20. . . . . .
1020
21.22. CONNECTOR COMPOSITES !(4052), *(4087), &(4101), P. 21. . . . . .
. . 1021
21.23. CONNECTOR COMPOSITES *(4101), *(4103), &(4103), P. 22. . .. .
1022
21.24. CONNECTOR COMPOSITES *(4104), &(4104), *(4106), P. 23. . .. .
1023
21.25. CONNECTOR COMPOSITES &(4106), *(4107), P. 24. . . . . .
. 1024
21.26. CONNECTOR COMPOSITES *(4108), *(4109), P. 25. .. . .
. .. 1025
21.27. CONNECTOR COMPOSITES *(4109), *(4110), *(4111), *(4111M), P. 26. . . . . .
1026
21.28. CONNECTOR COMPOSITES *(4112), *(4113), *(4114), *(4115), P. 27. . . . . .
1027
21.29. CONNECTOR COMPOSITES *(4116), #(4117), @(4301), P. 28. .. . .
1028
21.30. CONNECTOR COMPOSITES #(4200), #(4201), #(4202), P. 28A.. .. . .
1029
21.31. CONNECTOR COMPOSITES #(4203), #(4208), P. 28B. . . . . .
. 1030
21.32. CONNECTOR COMPOSITES #(4301E), P.

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 1063 1064 1065 1066 1067 1068 1069 1070 1071 / 1104 1105 1106 1107 1108 1109 1110

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

21.64. CONNECTOR COMPOSITES *(7604M), *(7605M), #(7606M), *(7607M), P. 56. 1063
21.65. CONNECTOR COMPOSITES *(7607M), *(7801M), P. 57. 1064
21.66. CONNECTOR COMPOSITES @(7801M), @(7803), P. 58. 1065
21.67. CONNECTOR COMPOSITES *(7803), *(7808), *(7809), P. 59.. 1066
21.68. CONNECTOR COMPOSITES *(7905A), *(8003A), P. 60. 1067
21.69. CONNECTOR COMPOSITES @(8003E), *(8004A), @(8004E), P. 61. 1068
21.70. CONNECTOR COMPOSITES @(8310), @(8310A), @(8310E), P. 62. 1069
21.71. CONNECTOR COMPOSITES @(8331), #(8585), #(8585A), @(8601), P. 63. 1070
21.72. CONNECTOR COMPOSITES @(8903), #(8904), P. 64. 1071
22. CONNECTOR COMPOSITE (9001-9996) (CHAPTER 22). 1072
22.1. CONNECTOR COMPOSITES *(9001), @(9003), *(9004), *(9004A), P. 1.. 1072
22.2. CONNECTOR COMPOSITES *(9005), *(9006), P. 2. 1073
22.3. CONNECTOR COMPOSITES *(9006), *(9007), *(9007A), P. 3. 1074
22.4. CONNECTOR COMPOSITES *(9008), *(9009), *(9100), P. 4. 1075
22.5. CONNECTOR COMPOSITES @(9100), P. 5. 1076
22.6. CONNECTOR COMPOSITES *(9100A), *(9100B), *(9101), P. 6.. 1077
22.7. CONNECTOR COMPOSITES *(9101), *(9101A), *(9101B), #(9101E), P. 7. 1078
22.8. CONNECTOR COMPOSITES *(9120), *(9123), *(9125), *(912

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 1111 1112 1113 1114 1115 1116 1117 1118 1119 1120 1121 1122 1123 1124 1125 1126 / 1127 1127 1128 1129 1130 1131 1132 1133 1134 1135 1136 1137 1138 1139 1140 / 1141 1142 1143 1144 1145 1146 1147 1148 1149 / 1150 1151 1152 1153 1154 1155 1156 1157

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 1158 1159 1160 1161 1162 1163 1164 1165 1166 1167 1168 1169 1170 1171 1172 1173 1174 1175 1176 1177 1178 1179 1180 1181 1182 / 1183 1183 1184 1185 1186 1187 1188 1189 1190 1191 1192 1193 1194 1195 1196 1197 1198 1199 1200 1201 1202 1203 1204 1205 1206

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.)

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

24.25. CONNECTOR COMPOSITES @@10309, P. 14. 1207
24.26. CONNECTOR COMPOSITES @@10309, P. 14A. 1208
24.27. CONNECTOR COMPOSITES @@10309, P. 14B. 1209
24.28. CONNECTOR COMPOSITES @@10309, P. 14C. 1210
24.29. CONNECTOR COMPOSITES @@10309, P. 14D. 1211
24.30. CONNECTOR COMPOSITES @10310, P. 15. 1212
24.31. CONNECTOR COMPOSITES @@10310, P. 15A. 1213
24.32. CONNECTOR COMPOSITES @@10310, P. 15B. 1214
24.33. CONNECTOR COMPOSITES @@10310, P. 15C. 1215
24.34. CONNECTOR COMPOSITES @@10311, P. 16. 1216
24.35. CONNECTOR COMPOSITES @@10311, P. 17. 1217
24.36. CONNECTOR COMPOSITES @@10311, P. 18. 1218
24.37. CONNECTOR COMPOSITES @@10311, P. 19. 1219
24.38. CONNECTOR COMPOSITES @@10311, P. 20. 1220
24.39. CONNECTOR COMPOSITES @@@10311, P. 20A.. 1221
24.40. CONNECTOR COMPOSITES @@@10311, P. 20B.. 1222
24.41. CONNECTOR COMPOSITES @@@10311, P. 20C. 1223
24.42. CONNECTOR COMPOSITES @@@10311, P. 20D. 1224
24.43. CONNECTOR COMPOSITES @@@10311, P. 20E.. 1225

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 1258 1259 1260 1261 1262 1263 1264 1265 1266 1267 1268 1269 1270 1271 1272 1273 1274 1275 1276 1277 1278 1279 1280 1281 1282 / 1283 1284 1285 1286 1287 1288 1289 1290 / 1291 1291 / 1294 1295 / 25.5. 25.6. / 1297 1298 1299 1300

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 1301 1302 1303 / 1304 1305 1306 1307 1308 1309 1310 1311 1312 / 1313 1314 1315 1316 1317 1318 1319 1320 1321 1322 1323 1324 1325 1326 1327 1328 1329 1330 1331 1332 1333 1334 / 1335 1336 1337 1338 1339 1340 1341 1342 1343 1344 1345 / 1346 1346

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.)

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

26.2. CONNECTOR COMPOSITES @10757, &10757A, &10757B, P. 2. 1347
26.3. CONNECTOR COMPOSITES *10758, *10758A, &10759, P. 3.. 1348
26.4. CONNECTOR COMPOSITES &10760, *10760A, &10761, P. 4. 1349
26.5. CONNECTOR COMPOSITES &10761A, &10762, @10763, P. 5. 1350
26.6. CONNECTOR COMPOSITES @10765B, @10765C, @10765D, P. 6. 1351
26.7. CONNECTOR COMPOSITES @10767, @10768, %10769C, P. 7. 1352
26.8. CONNECTOR COMPOSITES !10769D, @10769E, &10769F, @10769G, P. 8. 1353
26.9. CONNECTOR COMPOSITES @10770C, @10770D, @10770E, @10770F, P. 9. 1354
26.10. CONNECTOR COMPOSITES @10770G @10771A, P. 10. 1355
26.11. CONNECTOR COMPOSITES @10771B, @10771C, @10771D, P. 11. 1356
26.12. CONNECTOR COMPOSITES @10771E, @10771F, @10771G, P. 12. 1357
26.13. CONNECTOR COMPOSITES @10771H, @10771J, @10771K, P. 13. 1358
26.14. CONNECTOR COMPOSITES %10771L, @10771M, P. 14.. 1359
26.15. CONNECTOR COMPOSITES @10772A, @10772B, @10772C, P. 15. 1360
26.16. CONNECTOR COMPOSITES &10772D, &10772E, &10772F, P. 16. 1361
26.17. CONNECTOR COMPOSITES !10772G, !10772H, !10772G, P. 17. 1362
26.18. CONNECTOR COMPOSITES !10772K, !10772L, !10772M, P. 18. 1363
26.19. CONNECTOR COMPOSITES &10773A, &10773B, !10773C, P. 19. 1364
26.20. CONNECTOR COMPOSITES !10773D, &10773E, &10773F, !10773G, P. 20. 1365
26.21. CONNECTOR COMPOSITES !10773H, !10773J, !10773K, P. 21. . . . . .

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 1398 1399 1400 1401 1402 1403 1404 1405 1406 1407 1408 1409 1410 1411 1412 1413 1414 1415 1416 1417 1418 1419 1420 / 1421 1421 1422 1423 1424 1425 1426 1427 1428 1429 1430 1431 1432 1433 1434 1435 1436 1437 1438 1439 1440 1441 1442 1443 1444 1445 1446

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 1493 1493 1494 1495

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

27.27. VCU BACKUP LIGHTS SIGNAL WITH PB10E00, P. 26. 1447
27.28. PANEL LIGHTS SWITCH WITH PB10E00, P. 27. 1448
27.29. VEHICLE CONTROL UNIT (VCU) WITH PB10E00, P. 28. 1449
27.30. SCU MODULE WITH PB10E00, P. 29.. .. . .

Labels: TABLE OF CONTENTS / TABLE OF CONTENTS (CONT.) / 1496 1497 1498 1499 1500 1501 1502 1503 1504 1505 1506 1507 1508 1509 1510 1511 1512 1513 1514 1515 1516 1517 1518 1519 1520 1521

TABLE OF CONTENTS

TABLE OF CONTENTS (CONT.)

28.4. CONNECTOR COMPOSITE 1653, 1653A, P. 4.. 1496
28.5. CONNECTOR COMPOSITE 1700E, P. 5. 1497
28.6. CONNECTOR COMPOSITE 1701, P. 6. 1498
28.7. CONNECTOR COMPOSITE 1825, 1826, 1855, P. 7. 1499
28.8. CONNECTOR COMPOSITE 4015, 4041, 4210, 4212, 4215, P. 8. 1500
28.9. CONNECTOR COMPOSITE 4220, 4221, 4222, 4905, P. 9.. 1501
28.10. CONNECTOR COMPOSITE 6020, 6022, 6023A, 6023B, P. 10. 1502
28.11. CONNECTOR COMPOSITE 6025, P. 11.. 1503
28.12. CONNECTOR COMPOSITE 6027, 6028, 6030, P. 12. 1504
28.13. CONNECTOR COMPOSITE 6035, 6036, 6038, 6041, P. 13. 1505
28.14. CONNECTOR COMPOSITE 6042, 6050, 6055, P. 14. 1506
28.15. CONNECTOR COMPOSITE 6055, 6057, 6058, 6060, P. 15. 1507
28.16. CONNECTOR COMPOSITE 6071, 6072, 6073, 6074, P. 16. 1508
28.17. CONNECTOR COMPOSITE 6075, 6076, 6078, 6079, P. 17. 1509
28.18. CONNECTOR COMPOSITE 6081, 6082, 6083, P. 18. 1510
28.19. CONNECTOR COMPOSITE 6084, 6085, 6086, P. 19. 1511
28.20. CONNECTOR COMPOSITE 6090, 6091, P. 20. 1512
28.21. CONNECTOR COMPOSITE 6092, 6093, 6094, P. 21. 1513
28.22. CONNECTOR COMPOSITE 6095, 6096A, 6096

Labels: TABLE OF CONTENTS

TABLE OF CONTENTS

Figure 1 ABBREVIATIONS

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / INSTRUCTIONS AND CHARTS (CHAPTER 2) / 2.1. ABBREVIATIONS, P. 1 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090653 NO. 95885P 20OCT20 / CHAPTER 2 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / Figure 1

Figure 2 ACRONYMS

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.2. ACRONYMS, P. 2 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090653 95885P 20OCT20 / CHAPTER 2 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / Figure 2

2.3. CIRCUIT DIAGRAM INSTRUCTIONS, P. 3
Figure 3 CIRCUIT DIAGRAM INSTRUCTIONS

Components: BODY CONTROLLER (1602); KEY SWITCH (1101M)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.3. CIRCUIT DIAGRAM INSTRUCTIONS, P. 3 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090653 95885P 20OCT20 / CHAPTER 2 CIRCUIT DIAGRAM INSTRUCTIONS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / F1 A B 20A F2 B A 20A / SUFFIX BEGINNING WITH G INDICATES A GROUND CIRCUIT / NOTE: FOR CIRCUIT DESCRIPTION OTHER THAN GROUNDS NEITHER THE LETTER "G" NOR THE COLOR WHITE SHALL BE USED / A SWITCH, MECHANICAL / A128 BUSSED CONTACT / LOCATION INDIVIDUAL GROUND CIRCUIT NUMBER / SINGLE IN-LINE CONNECTORS DISPLAYED AS SHOWN BELOW WITH R/D NUMBER / 87A 85 RELAY - SUPPRESSED / A (12) / E - SWITCHES, RELAYS AND COMPONENTS INDICATE EXTERNAL WIRE CONNECTIONS AND / OR INTERNAL CONNECTIONS OR CONTACTS. EXTERNAL WIRE A12 A12A CONNECTIONS C IGN OFF / D - MULTIPLE CIRCUIT NUMBERS ON A LINE INDICATE ONE CIRCUIT DISTRIBUTING CURRENT TO TWO CIRCUITS. / R32-G R32-GA R32-GB / COMMON GROUND CIRCUIT NUMBER / SUFFIX BEGINNING WITH G INDICATES A GROUND CIRCUIT / B S / PRINTED CIRCUIT IN INSTRUMENT CLUSTER / LOCATION IN FUSE / CIRCUIT BREAKER CONNECTION / FUSE RATING / WIRE CONNECTION F18 A B 20A A F19 B 20A / Figure 3 / CIRCUIT DIAGRAM INSTRUCTIONS

Table: / WIRE COLOR 20A

LOCATION	FUSE	RATING
FUSE / CIRCUIT	A F2 B	
CONNECTION	20A	

2.4. CIRCUIT NUMBER IDENTIFICATION AND COLOR, P. 4
Figure 4 CIRCUIT NUMBER IDENTIFICATION AND COLOR

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.4. CIRCUIT NUMBER IDENTIFICATION AND COLOR, P. 4 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090653 95885P 10NOV20 / CHAPTER 2 CIRCUIT NUMBER IDENTIFICATION AND COLOR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CIRCUIT NUMBER 1 2 3 3 4 5 5 6 7 8 9 10 11 12 13 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 / COLOR LTBL RD DKBL GY / YL GN GY RD / GY WH WH LTBL PK BK RD RD / PK PK GY LTGN TN TN TN GY TN TN TN TN TN TN TN TN TN TN TN TN GY GY GY TN GY / Figure 4 / CIRCUIT NUMBER IDENTIFICATION AND COLOR

2.5. CIRCUIT NUMBER IDENTIFICATION AND COLOR (CONT.), P. 5
Figure 5 CIRCUIT NUMBER IDENTIFICATION AND COLOR (CONT.)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.5. CIRCUIT NUMBER IDENTIFICATION AND COLOR (CONT.), P. 5 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090653 NO. 95885P 20OCT20 / CHAPTER 2 CIRCUIT NUMBER IDENTIFICATION AND COLOR (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CIRCUIT NUMBER 43 44 45 46 47 48 49 50 51 52 53 54 55 56 56 57 57 58 59 60 61 62 63 64 65 66 67 68 69 70 70 71 71 72 73 74 75 76 77 78 79 80 81 82 83 / Figure 5 / CIRCUIT NUMBER IDENTIFICATION AND COLOR (CONT.)

Figure 6 CIRCUIT NUMBER IDENTIFICATION AND COLOR (CONT.)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.6. CIRCUIT NUMBER IDENTIFICATION AND COLOR (CONT.), P. 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090653 NO. 95885P 20OCT20 / CHAPTER 2 CIRCUIT NUMBER IDENTIFICATION AND COLOR (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / Figure 6 / CIRCUIT NUMBER IDENTIFICATION AND COLOR (CONT.)

Figure 7 CIRCUIT NUMBER IDENTIFICATION AND COLOR (CONT.)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.7. CIRCUIT NUMBER IDENTIFICATION AND COLOR (CONT.), P. 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090653 NO. 95885P 20OCT20 / CHAPTER 2 CIRCUIT NUMBER IDENTIFICATION AND COLOR (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / Figure 7 / CIRCUIT NUMBER IDENTIFICATION AND COLOR (CONT.)

2.8. CIRCUIT NAME COMPOSITION, P. 8
Figure 8 CIRCUIT NAME COMPOSITION

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.8. CIRCUIT / COMPOSITION, P. 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS PART NO. RELEASE NO. AE08090653 95885P 20OCT20 / CHAPTER 2 / MJV0488 22SEP21 REVISED DESC. OF K AND N / B B / HARNESS LOCATIONS-BUS LOCATIONS PREFIX LETTER A B C D E F G H I J K L M N O P Q R S T U V W X Y Z / Figure 8

2.9. CIRCUIT / INSULATION COLOR, P. 9
Figure 9 CIRCUIT / INSULATION COLOR

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.9. CIRCUIT / INSULATION COLOR, P. 9 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090653 95885P 20OCT20 / CHAPTER 2 / CIRCUIT/INSULATION COLOR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GENERAL COLORS BY SYSTEM / GENERAL COLORS BY GROUND / RED PINK LIGHT BLUE YELLOW DARK BLUE BROWN ORANGE ORANGE GRAY TAN LIGHT GREEN VIOLET BLACK / CABLE COLOR / WHITE PER SYSTEM'S DESIGNATED COLOR WHITE BLACK WHITE GRAY / Figure 9 / CIRCUIT / INSULATION COLOR

2.10. LAMP BULB CHART, P. 10
Figure 10 LAMP BULB CHART

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.10. LAMP BULB CHART, P. 10 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090653 95885P 20OCT20 / CHAPTER CHAPTER 2 2 / LAMP BULB CHART / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / BULB APPLICATION / Figure 10 / LAMP BULB CHART

Figure 11 RELAY FUNCTION AND WIRING GUIDE

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.11. RELAY FUNCTION AND WIRING GUIDE, P. 11 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090653 95885P 20OCT20 / RELAY FUNCTION AND WIRING GUIDE / CHAPTER 2 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 85 87 / MICRO - 280 (1) / RELAY VIEWED FROM INSERTION END MINIATURE - ISO (1) / 2 4 1 / 30 86 / MINIATURE - 280 (1) / MICRO - ISO (1) ENERGIZING COIL / NORMALLY CLOSED CONTACT ENERGIZING COIL / RELAY SCHEMATIC / 86 87A / ENERGIZING COIL NORMALLY CLOSED CONTACT NORMALLY OPEN CONTACT / COMMON CONTACT ENERGIZING COIL / NORMALLY OPEN CONTACT / MICRO - 4 PIN (1) / MINI MICRO - 4 PIN (2) / COMMON CONTACT / NOTES : 1. RELAY CONTAINS A 680 OHM SUPPRESSION RESISTOR 2. RELAY CONTAINS A 1000 OHM SUPPRESSION RESISTOR / Figure 11 / RELAY FUNCTION AND WIRING GUIDE

2.12. SCHEMATIC SYMBOL CHART, P. 12
Figure 12 SCHEMATIC SYMBOL CHART

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.12. SCHEMATIC SYMBOL CHART, P. 12 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090653 95885P 20OCT20 / SCHEMATIC SYMBOL CHART / CHAPTER 2 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / DIODE, LIGHT EMITTING / CIRCUIT BREAKER / FAN SOLENOID / AIR DRYER / CIGAR LIGHTER / FEMALE TERMINAL / BLUNT CUT CIRCUIT / Figure 12 / SCHEMATIC SYMBOL CHART

Figure 13 SCHEMATIC SYMBOL CHART (CONT.)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.13. SCHEMATIC SYMBOL CHART (CONT.), P. 13 / CHAPTER 2 SCHEMATIC SYMBOL CHART (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090653 NO. 95885P 20OCT20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FUSIBLE LINK / GROUND W/ STUD / GROUND N/ STUD / KEY SWITCH / LIGHT W/ SWITCH / LIGHT, DOUBLE FILAMENT / LIGHT, SINGLE FILAMENT / HOLDER, FUSE W/ BUSBAR / S B / OFF IGN D C / KEY SWITCH, COMPLEX / S S S S I A I A I A I A OFF OFF OFF OFF / FUSES W/ BUSBAR / Figure 13 / SCHEMATIC SYMBOL CHART (CONT.)

Figure 14 SCHEMATIC SYMBOL CHART (CONT.)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.14. SCHEMATIC SYMBOL CHART (CONT.), P. 14 / CHAPTER 2 SCHEMATIC SYMBOL CHART (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090653 NO. 95885P 20OCT20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / RELAY, FIVE TERMINAL / RELAY, FOUR TERMINAL / PASS THRU CONNECTION / PRESSURE SWITCH / SENDER - FUEL, OIL, TEMP, WATER / SENSOR, PRESSURE. ABS 6 / RELAY, LATCHING / SENSOR, MAGNETIC / SENSOR, YAW / SOLENOID W/ DIODE / MALE TERMINAL / Figure 14 / SCHEMATIC SYMBOL CHART (CONT.)

2.15. SCHEMATIC SYMBOL CHART (CONT.), P. 15
Figure 15 SCHEMATIC SYMBOL CHART (CONT.)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.15. SCHEMATIC SYMBOL CHART (CONT.), P. 15 / CHAPTER 2 SCHEMATIC SYMBOL CHART (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090653 NO. 95885P 20OCT20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SWITCH, MECHANICAL (NORMALLY OPEN) / START MOTOR W/ TOCP / SWITCH, MECHANICAL (NORMALLY CLOSED) / VALVE, ETHER BOTTLE / SWITCH, PUSH BUTTON / VALVE, MODULATOR / TERMINATING RESISTOR / 120 OHMS / M B / Figure 15 / SCHEMATIC SYMBOL CHART (CONT.)

2.16. SCHEMATIC SYMBOL CHART (CONT.), P. 16
Figure 16 SCHEMATIC SYMBOL CHART (CONT.)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.16. SCHEMATIC SYMBOL CHART (CONT.), P. 16 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090653 NO. 95885P 20OCT20 / CHAPTER 2 SCHEMATIC SYMBOL CHART (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 3 2 1 / SYMBOL SYMBOL SYMBOL / RED + - BLACK / 16 BLU 69 OR 16 RED 40 / DC OUTLET / BLK BLK SC SC / 1 1 2 2 / SC SC / TO CIRCUIT BREAKER / CLOSED TO LIFT / AIR REGULATOR AND SOLENOID / - + + / HEATED WIPER BLADES / AIR DUMP VALVE / FOOT SWITCH FOR AIR HORN / AIR REGULATOR / 16 RED 40 / BLACK BLACK / BACK-UP ALARM / MASTER DISCONNECT / REVERSING KEY SWITCH CENTER POSITION "OFF" / LIFT SOLENOID / MASTER DISCONNECT / AIR SUPPLY LINE / AIR DOOR CYLINDER / 1 2 / 1 2 / Figure 16 / SCHEMATIC SYMBOL CHART (CONT.)

2.17. SCHEMATIC SYMBOL CHART (CONT.), P. 17
Figure 17 SCHEMATIC SYMBOL CHART (CONT.)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.17. SCHEMATIC SYMBOL CHART (CONT.), P. 17 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090653 NO. 95885P 20OCT20 / CHAPTER 2 SCHEMATIC SYMBOL CHART (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SYMBOL SYMBOL SYMBOL / RIGHT TRACTION SANDER / R AMBER I/P R RED I/P L AMBER I/P L RED I/P R AMBER O/P R RED O/P L AMBER O/P L RED O/P AMBER INDICATOR RED INDICATOR +VE -VE / PILOT LIGHT RELAY / AIR HORN SOLENOID / DUAL ELECT SOLENOID W/ AIR REGULATOR / RESISTOR BLOCK / LEFT TRACTION SANDER / Figure 17 / SCHEMATIC SYMBOL CHART (CONT.)

2.18. SCHEMATIC SYMBOL CHART (CONT.), P. 18
Figure 18 SCHEMATIC SYMBOL CHART (CONT.)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.18. SCHEMATIC SYMBOL CHART (CONT.), P. 18 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090653 NO. 95885P 20OCT20 / CHAPTER 2 SCHEMATIC SYMBOL CHART (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CHILD CHECK MATE / STOP ARM OV SW ERRIDE ITCH DOOR SW ITC H MASTER SW ITC H N.S. JUMPER GROUND SW STA ITC RT H MANUAL JUMPER RIGHT AMBER AMBER LEFT RIGHT RED LEFT RED / 20 20 20 20 / SC RED SC ORANGE / BLK RED WHT / SYMBOL ORANGE - HIGH SPEED RED LOW SPEED - BLACK - GROUND SC BLACK / ORANGE +12V BLACK - GROUND ORANGE / CHECK-MATE INC SYSTEMS CHILD / ELECTRONIC EIGHT LAMP SCHOOL BUS FLASHER / SPECIALTIES, EL ECTRONIC MODEL B-1 INC. LIGHTING / STEP / DEFROST HEATER MOTOR / BOOSTER PUMP MOTOR / check! and / DRIVER'S HEATER MOTOR / ELECTRONIC LIGHTING SPECIALTIES, INC. / 1 2 3 / THROTTLE IDLE / ACCELERATOR POSITION SENSOR / Figure 18 / SCHEMATIC SYMBOL CHART (CONT.)

2.19. SCHEMATIC SYMBOL CHART (CONT.), P. 19
Figure 19 SCHEMATIC SYMBOL CHART (CONT.)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.19. SCHEMATIC SYMBOL CHART (CONT.), P. 19 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090653 NO. 95885P 20OCT20 / CHAPTER 2 SCHEMATIC SYMBOL CHART (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / NC NC _2 _2 NO NO _3 _3 NO NC _3 _1 / NO NC _3 _1 NO NC _3 _1 NO NO _3 _3 / NC NO _2 _4 NC NO _4 _2 NO NC _4 _4 / NO _3 NC _2 _2 NC _2 / NO _4 NC _1 / SYMBOL SYMBOL SYMBOL / NO _4 NO _3 / ORANGE - HIGH SPEED RED - LOW SPEED MOTOR FRAME-GROUND / NC _2 / NC NC _1 _1 NO NO _4 _4 NC NO _4 _2 / PANEL DIMMER / NO _3 NC _2 / SYMBOL R / NC _1 / 16BK 40 / RHEOSTAT CONTROLLER / SC SC / OR RD BK / NO _3 / RED GRA BLK / BLUE YELLOW BLACK / 3-POSITION ROTARY AIR DOOR SWITCH / 16BK 40 / 1 2 3 / NO _4 / NC _3 / 2-POSITION ROTARY AIR DOOR SWITCH / 1 2 3 / 3-POSITION ELECTRIC ENTRANCE DOOR SWITCH / FRONT / REAR POWER VENT / MANUAL DOOR SWITCH / 2-POSITION ELECTRIC ENTRANCE DOOR SWITCH / DOME LIGHT RHEOSTAT / NO _4 / NO _4 / RIGHT SIDE / 3-POSITION DOOR SWITCH IN L DRIVER'S SWITCH PANEL / C...O CARLING K301-27 / Figure 19 / SCHEMATIC SYMBOL CHART (CONT.)

2.20. SCHEMATIC SYMBOL CHART (CONT.), P. 20
Figure 20 SCHEMATIC SYMBOL CHART (CONT.)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.20. SCHEMATIC SYMBOL CHART (CONT.), P. 20 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090653 NO. 95885P 20OCT20 / CHAPTER 2 SCHEMATIC SYMBOL CHART (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 3-POSITION DOOR SWITCH IN L DRIVER'S SWITCH PANEL / A A / REAR ROW DOME LIGHTS (43) 8 / STOP and check! / LIFT DOOR SWITCH / ROCKER SWITCH / B B / RIGHT CONVEX MIRROR MOTOR / DEACTIVATION SWITCH / ELECTRIC DOOR CONTROL LIMIT SWITCHING / LEFT CONVEX MIRROR MOTOR / MOTORIZED HEATED MIRROR / HEATER-CONVEX MIRROR / HEATER-FLAT MIRROR / RIGHT SIDE / LEFT SIDE / SC SC / Figure 20 / SCHEMATIC SYMBOL CHART (CONT.)

Figure 21 CE BUS LAYOUT (CONT.)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.21. CE BUS LAYOUT (CONT.), P. 21 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090653 NO. 95885P 20OCT20 / CE BUS LAYOUT / CHAPTER 2 / BOW SECT 1 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / NOTE - WINDOW LOCATIONS ARE SUBJECT TO MOVING BASED ON FEATURE CODES ORDERED. / Figure 21 / CE BUS LAYOUT (CONT.)

Figure 22 CE BUS LAYOUT (CONT.)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.22. CE BUS LAYOUT (CONT.), P. 22 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090653 NO. 95885P 20OCT20 / CE BUS LAYOUT (CONT.) / CHAPTER 2 / RIGHT BODY HARNESS / REAR CAP HARNESS / FRONT CAP ENTRANCE DOOR HARNESS / PLATFORM HARNESS / LEFT BODY REAR CAP HARNESS / LEFT BODY HARNESS / ELECTRICAL PANEL FR CAP HARNESS / FRONT CAP HARNESS / ELECTRICAL PANEL HARNESS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CE BUS LEFT VIEW / CE BUS RIGHT VIEW / Figure 22 / CE BUS LAYOUT (CONT.)

Figure 23 CE BUS LAYOUT (CONT.)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.23. CE BUS LAYOUT (CONT.), P. 23 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090653 NO. 95885P 20OCT20 / CE BUS LAYOUT (CONT.) / CHAPTER 2 / MJV0488 10JUN21 INITIAL PRODUCTION RELEASE. / CE BUS FRONT VIEW / CE BUS REAR VIEW / Figure 23 / CE BUS LAYOUT (CONT.)

2.24. FUSE GRAPHIC - PLATFORM AND ELECTRICAL PANEL - 4214351C1 (CONT.), P. 24
Figure 24 FUSE GRAPHIC - PLATFORM AND ELECTRICAL PANEL - 4214351C1 (CONT.)

Relay map: Relay block B1 position R1: CROSSING GATE; Relay block B1 position R2: STARTER INTERLOCK; Relay block B1 position R3: MIN TIMER; Relay block B1 position R4: CHILD CHECK; Relay block B1 position R5: DOME LIGHTS; Relay block B1 position R6: CHILD MONITOR; Relay block B11 position R1: CL LIGHTS; Relay block B11 position R2: B/U LIGHTS; Relay block B11 position R3: PUPIL WARNING LIGHTS; Relay block B11 position R4: A/C; Relay block B11 position R5: CHILD MONITOR; Relay block B11 position R6: PARK BRAKE; Relay block B2 position R1: REAR ROW DOME; Relay block B2 position R2: REAR DOME; Relay block B2 position R3: FRONT DOME; Relay block B2 position R4: BOOSTER PUMP; Relay block B2 position R5: BOOSTER PUMP; Relay block B2 position R6: FLASHER SYSTEM; Relay block B4 position R1: LIFT LIGHT; Relay block B4 position R2: FLASHER SYSTEM; Relay block B4 position R3: AED; Relay block B4 position R4: LIFT INTLK; Relay block B4 position R5: LIFT INTLK; Relay block B4 position R6: AED VANDAL LOCK; Relay block B5 position R1: STOP ARM; Relay block B5 position R2: CHILD CHECK MATE; Relay block B5 position R3: TEMP SENSOR; Relay block B5 position R4: BUZZER; Relay block B5 position R5: CHILD SAFETY ALARM; Relay block B5 position R6: CHILD SAFETY ALARM; Relay block B8 position R1: DOOR CONTROL; Relay block B8 position R2: DOOR CONTROL; Relay block B8 position R3: STEP LIGHT; Relay block B8 position R4: PTI; Relay block B8 position R5: PTI; Relay block B8 position R6: PTI
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.24. FUSE GRAPHIC - PLATFORM AND ELECTRICAL PANEL - 4214351C1 (CONT.), P. 24 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090653 95885P 20OCT20 / CHAPTER 2 FUSE GRAPHIC-PLATFORM AND ELECTRICAL PANEL-4214351C1 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / R3 AED / VANDAL LOCK R6 AED / INTERLOCK STARTER LIGHTS DOME R2 R5 / CROSSING CHILD CHECK GATE R1 R4 / LIFT LIGHT LIFT INTLK R1 R4 / MONITOR MIN TIMER CHILD R3 R6 2 / LIGHT STEP PTI R3 R6 / FLASHER SYSTEM LIFT INTLK R2 R5 / WARNING LIGHTS BRAKE PUPIL PARK R6 R3 / LIGHTS MONITOR CHILD B/U R2 R5 / LIGHTS A/C R1 CL R4 / ROW BOOSTER DOME PUMP R1 R4 REAR / BOOSTER REAR DOME PUMP R2 R5 / FLASHER FRONT SYSTEM DOME R3 R6 / BUZZER STOP R1 ARM R4 / CHECK CHILD MATE CHILD SAFETY ALARM R2 R5 / SENSOR CHILD SAFETY ALARM TEMP R6 R3 / CONTROL DOOR PTI R1 R4 / CONTROL DOOR R2 PTI R5 / M L K J / T P R N / D B A C / H G F E / T P R N / H G F E / M L K J / D B C A / 1 4 / 1 4 / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 24 / FUSE GRAPHIC - PLATFORM AND ELECTRICAL PANEL - 4214351C1 (CONT.)

2.25. FUSE GRAPHIC - PLATFORM AND ELECTRICAL PANEL - 4214351C1 (CONT.), P. 25
Figure 25 FUSE GRAPHIC - PLATFORM AND ELECTRICAL PANEL - 4214351C1 (CONT.)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.25. FUSE GRAPHIC - PLATFORM AND ELECTRICAL PANEL - 4214351C1 (CONT.), P. 25 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090653 NO. 95885P 20OCT20 / CHAPTER 2 FUSE GRAPHIC-PLATFORM AND ELECTRICAL PANEL-4214351C1(CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / R1 STEP WARMER / R4 R1 EMRCY FOG EXIT LIGHT / R3 BACK UP LIGHT D C B A CHECK 4 / R6 BACK UP LIGHT / R2 AUTO DRAIN VALVE / R5 R2 PARK SHIFT BRAKE INHIBIT ALARM / R3 SEAT BELT ALARM / R4 WIPER HI-LO / R6 PARK BRAKE ZVR / R5 R2 AIR THERMAL PARK OVER BRAKE CRANK INTLK / R1 WHEEL CHAIR LIFT / R3 HYD PARK BRAKE WHEEL CHAIR / R4 DUAL A/C COMP CTRL / R5 ECON MODE / R1 WIPER POWER / E D C B A / STARTER RELAY ALTN FUEL / IGN POWER / IGN POWER / 40 37 40 37 X W V U X W V U / H G F E / D C B A / M L K J / T R P N / H G F E / M L K J / T R P N / K J H G F / 1 4 / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 25 / FUSE GRAPHIC - PLATFORM AND ELECTRICAL PANEL - 4214351C1 (CONT.)

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
10301-B12	B12-A	15	BAT	LIFT INTERLOCK
10301-B12	B12-B	NOTE 1	BAT	ELEC ENTR DOOR/AIR/DOOR VANDAL LOCK
10301-B12	B12-C	5	BAT	REVERSE MOTION SENSOR
10301-B12	B12-D	5	BAT	DDR SYSTEM
10301-B12	B12-E	7.5	BAT	LUGGAGE BOX LIGHT
10301-B12	B12-F	5	BAT	RADIO MEMORY
10301-B12	B12-G	NOTE 2	NS3	R FRONT HEATER SW
10301-B12	B12-H	7.5	NS3	FRONT POWER VENT
10301-B12	B12-J	NOTE 3	IGN	DOME LT TIMER RELAY/PTI
10301-B12	B12-K	NOTE 4	IGN	ALTERNATE ENTRANCE DOOR/PTI/AC NOISE
10301-B12	B12-L	7.5	IGN	ENTRANCE DOOR
10301-B12	B12-M	5	IGN	LIQUID SPRING SUSPENSION/ EV NOISE GEN
10301-B12	B12-N	-	-	-
10301-B12	B12-P	-	-	-
10301-B12	B12-R	-	-	-
10301-B12	B12-T	NOTE 5	NS4	DEFOG FAN RIGHT SW/ CENTER BLOWER SW
10301-B12	B12-U	NOTE 6	NS3	R REAR HEATER SW
10301-B12	B12-V	7.5	NS3	REAR POWER VENT
10301-B12	B12-W	15A/25A	NS2	LT REAR PASSENGER HEATER
10301-B12	B12-X	7.5	NS2	RADIO POWER

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
10302-B9	B9-A	NOTE 7	BAT	POST TRIP INSPECTION
10302-B9	B9-B	NOTE 8	BAT	POST TRIP INSPECTION
10302-B9	B9-C	20	BAT	AUDIO & VIDEO PREWIRE
10302-B9	B9-D	5	BAT	LIQUID SPRING SUSPENSION
10302-B9	B9-E	7.5	ACC1	EMERGENCY EXIT ALARM
10302-B9	B9-F	5	ACC1	FRONT CLUSTER LIGHT
10302-B9	B9-G	NOTE 9	ACC1	POST TRIP INSPECTION
10302-B9	B9-H	15	BAT	THEFTMATE
10302-B9	B9-J	NOTE 10	ACC1	TRAC SANDERS/AUDIO & VIDEO PREWIRE
10302-B9	B9-K	NOTE 11	ACC1	PWL/PEDESTRIAN LIGHT
10302-B9	B9-L	25	NS1	DRIVERS HEATER
10302-B9	B9-M	20	NS1	STEPWELL FLOOR HEATER
10302-B9	B9-N	10	ACC2	MOTORIZED MIRRORS
10302-B9	B9-P	NOTE 12	ACC2	LIGHT MONITOR
10302-B9	B9-R	7.5	ACC2	STEP LIGHT
10302-B9	B9-T	-	-	-
10302-B9	B9-U	5	ACC2	DOME LIGHT OPTIONS
10302-B9	B9-V	NOTE 13	BAT /IGN	DOME LIGHT
10302-B9	B9-W	15	BAT	PTI / DOME LIGHT OPTIONS
10302-B9	B9-X	3A/10A	BAT	HAZARD LIGHT

2.27. FUSE GRAPHIC - PLATFORM AND ELECTRICAL PANEL - 4214351C1 (CONT.), P. 27 | Figure 27 FUSE GRAPHIC - PLATFORM AND ELECTRICAL PANEL - 4214351C1 (CONT.) | printed page 27

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
10303-B6	B6-A	15	BAT	DC OUTLET
10303-B6	B6-B	NOTE 14	BAT	BOOSTER PUMP/FUEL FIRED HEATER
10303-B6	B6-C	10	BAT	CLEARANCE LIGHT
10303-B6	B6-D	5	GND -	LIQUID SPRING SUSPENSION
10303-B6	B6-E	NOTE 15	BAT	DVR /BOOSTER PUMP/AUDIO & VIDEO
10303-B6	B6-F	NOTE 16	BAT	STOP ARM/ CROSSING GATE/PWL
10303-B6	B6-G	15	BAT	B/U LIGHT - ACT BY EMERGENCY EXIT
10303-B6	B6-H	25A/15A	NS1	L FRONT PASSENGER HEATER
10303-B6	B6-J	DIODE	-	EMERGENCY EXIT ALARMS
10303-B6	B6-K	DIODE	-	FLASHER SYSTEM MASTER SWITCH
10303-B6	B6-L	20	ACC2	AUDIO AND VIDEO PREWIRE
10303-B6	B6-M	5	ACC2	DRIVERS DOME LIGHT
10303-B6	B6-N	NOTE 17	-	ENGINE COMP LT/CHILD MONITOR
10303-B6	B6-P	NOTE 18	-	ENGINE COMP LT/ELE PANEL COMP LT
10303-B6	B6-R	7.5	BAT	EMERGENCY EXIT ALARMS (BATTERY)
10303-B6	B6-T	5	BAT	AED VANDAL LOCK / EMERGENCY DOOR
10303-B6	B6-U	DIODE	-	REAR DOOR ACTIVATED OPTIONS
10303-B6	B6-V	15	MD3	DOME LIGHT FEED
10303-B6	B6-W	NOTE 19	MD3	HEATED SEAT/ CHILD SAFETY ALARM
10303-B6	B6-X	15	MD3	AIR SEAT

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
10304-B3	B3-A	DIODE	-	HAZARD LIGHTS
10304-B3	B3-B	20	NS4	AUDIO AND VIDEO PREWIRE
10304-B3	B3-C	DIODE	-	CHILD MONITOR SYSTEM
10304-B3	B3-D	DIODE	-	CHILD MONITOR SYSTEM
10304-B3	B3-E	7.5	ACC1	STROBE LIGHT
10304-B3	B3-F	5	ACC1	DOME LIGHT TIMER RELAY
10304-B3	B3-G	NOTE 20	MD1	BOOSTER PUMP
10304-B3	B3-H	20	MD1	TWO-WAY RADIO TERMINAL STRIP
10304-B3	B3-J	15A/20A	MD2	DOME LIGHT FEED
10304-B3	B3-K	NOTE 21	MD2	DDR / VIDEO SYSTEM TERMINAL STRIP
10304-B3	B3-L	-	-	-
10304-B3	B3-M	7.5/10A	MD3	DESTINATION SIGN
10304-B3	B3-N	DIODE	-	HAZARD LIGHTS
10304-B3	B3-P	DIODE	-	SEE CIRCUIT DIAGRAM
10304-B3	B3-R	5	NS2	AIR CONDITIONING
10304-B3	B3-T	NOTE 22	NS2	DEFOG FAN SW / CENTER BLOWER SW
10304-B3	B3-U	15	MD2	HEATED MIRRORS
10304-B3	B3-V	15	MD2	TRACTION SANDERS
10304-B3	B3-W	25	MD1	STEP WARMER
10304-B3	B3-X	DIODE	-	REAR DOOR ACTIVATED OPTIONS

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
10305-A1	A1-A	3	IGN	LOCKING COMPARTMENT
10305-A1	A1-B	3	IGN	BUZZER ISOLATION RELAY
10305-A1	A1-C	3	IGN	FUEL FIRED HEATER TIMER
10305-A1	A1-D	3	IGN	STOP-ARM / CROSSING GATE CANCEL
10305-A1	A1-E	3	IGN	STARTER INTERLOCK
10305-A1	A1-F	3	ACC2	PTI - LEAVE NO STUDENT BEHIND
10305-A1	A1-G	3	ACC2	BATTERY ISOLATOR
10305-A1	A1-H	3	ACC2	ENGINE COMAPRTMENT TEMP SENSOR
10305-A1	A1-J	3	ACC1	EMERGENCY EXIT LIGHTS
10305-A1	A1-K	3	MD1	AIR HORN
10305-A1	R1	-	-	STEP WARMER RELAY

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
10308-B11	R1	-	-	CL LIGHTS RELAY
10308-B11	R2	-	-	BACK UP LIGHTS RELAY
10308-B11	R3	-	-	PUPIL WARNING LIGHTS RELAY
10308-B11	R4	-	-	A/C RELAY
10308-B11	R5	-	-	CHILD MONITOR RELAY
10308-B11	R6	-	-	PARK BRAKE RELAY

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
10309-B8	R1	-	-	DOOR CONTROL RELAY
10309-B8	R2	-	-	DOOR CONTROL RELAY
10309-B8	R3	-	-	STEP LIGHT RELAY
10309-B8	R4	-	-	PTI RELAY
10309-B8	R5	-	-	PTI RELAY
10309-B8	R6	-	-	PTI RELAY

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
10310-B5	R1	-	-	STOP ARM RELAY
10310-B5	R2	-	-	CHILD CHECKMATE RELAY
10310-B5	R3	-	-	TEMP SENSOR RELAY
10310-B5	R4	-	-	BUZZER RELAY
10310-B5	R5	-	-	CHILD SAFETY ALARM RELAY
10310-B5	R6	-	-	CHILD SAFETY ALARM RELAY

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
10311-B2	R1	-	-	REAR ROW DOME LIGHT RELAY
10311-B2	R2	-	-	REAR DOME LIGHT RELAY
10311-B2	R3	-	-	FRONT DOME LIGHT RELAY
10311-B2	R4	-	-	BOOSTER PUMP RELAY
10311-B2	R5	-	-	BOOSTER PUMP RELAY
10311-B2	R6	-	-	FLASHER SYSTEM RELAY

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
10312-B4	R1	-	-	LIFT LIGHT RELAY
10312-B4	R2	-	-	FLASHER SYSTEM RELAY
10312-B4	R3	-	-	AED RELAY
10312-B4	R4	-	-	LIFT INTLK RELAY
10312-B4	R5	-	-	LIFT INTLK RELAY
10312-B4	R6	-	-	AED VANDAL LOCK RELAY

2.29. FUSE GRAPHIC - PLATFORM AND ELECTRICAL PANEL - 4214351C1 (CONT.), P. 29 | Figure 29 FUSE GRAPHIC - PLATFORM AND ELECTRICAL PANEL - 4214351C1 (CONT.) | printed page 29

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
10313-B1	R1	-	-	CROSSING GATE RELAY
10313-B1	R2	-	-	STARTER INTERLOCK RELAY
10313-B1	R3	-	-	2 MIN TIMER RELAY
10313-B1	R4	-	-	CHILD CHECK RELAY
10313-B1	R5	-	-	DOME LIGHTS RELAY
10313-B1	R6	-	-	CHILD MONITOR RELAY

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
10314-B10	R1	-	-	NS1 RELAY
10314-B10	R2	-	-	NS2 RELAY

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
10315-B7	R1	-	-	NS3 RELAY
10315-B7	R2	-	-	NS4 RELAY

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
10316-A4	R1	-	-	MD1 RELAY
10316-A4	R2	-	-	MD2 RELAY

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
10317-A7	R1	-	-	MD3 RELAY
10317-A7	R2	-	-	IGNITION RELAY

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
10318-A10	R1	-	-	ACC1 RELAY
10318-A10	R2	-	-	ACC2 RELAY

2.30. FUSE GRAPHIC - PLATFORM AND ELECTRICAL PANEL - 4214351C1 (CONT.), P. 30 | Figure 30 FUSE GRAPHIC - PLATFORM AND ELECTRICAL PANEL - 4214351C1 (CONT.) | printed page 30

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
1014-A6	A6-A	10	BAT	CROSSIGN GATE / AMMETER
1014-A6	A6-B	10	BAT	STOP LIGHTS
1014-A6	A6-C	5	BAT	N2 COMMUNICATIONS MODULE
1014-A6	A6-D	15	BAT	INSTRUMENT CLUSTER
1014-A6	A6-E	5	BAT	HYDRAULIC BRAKE/ EV HEADLAMP
1014-A6	A6-F	3	BAT	ZONAR PREWIRE
1014-A6	A6-G	20	BAT	COOLANT HEATER
1014-A6	A6-H	10	BAT	KEY SWITCH
1014-A6	A6-J	30	BAT	IGN RELAY #1
1014-A6	A6-K	10	BAT	DIAGNOSTIC CONNECTOR
1014-A6	A6-L	30	BAT	IGN RELAY #2
1014-A6	A6-M	10	BAT	WTEC SHIFT SELECTOR/ EV GSM
1014-A6	A6-N	10	BAT	BENDIX ABS FUSION DIESEL
1014-A6	A6-P	15	BAT	FOG LIGHTS
1014-A6	A6-R	10	BAT	FAN / SHUTTER
1014-A6	A6-T	10	BAT	BENDIX ABS FUSION GAS
1014-A6	A6-U	-	-	-
1014-A6	A6-V	-	-	-
1014-A6	A6-W	-	-	-
1014-A6	A6-X	-	-	-

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
1016-A6	A3-A	5	IGN	AIR PARK BRAKE INTERLOCK
1016-A6	A3-B	5	IGN	ABS CONTROLLER
1016-A6	A3-C	-	-	-
1016-A6	A3-D	-	-	-
1016-A6	A3-E	10	IGN	XMSN CONTROL MODULE/ EV GSM
1016-A6	A3-F	5	IGN	XMSN SHIFTER LCT
1016-A6	A3-G	5	IGN	BODY BUILDER CONNECTOR
1016-A6	A3-H	10	IGN	WINDSHIELD WASHER PUMP
1016-A6	A3-J	5	IGN	ACCELERATOR PEDAL
1016-A6	A3-K	5	IGN	ENGINE ELECTRONICS/ EV ELECTRONICS
1016-A6	A3-L	5	IGN	AUTO DRAIN VALVE
1016-A6	A3-M	10	IGN	BACK-UP LIGHTS
1016-A6	A3-N	10	IGN	AIR DRYER, DRAIN VALVE, FUEL
1016-A6	A3-P	5	IGN	INSTRUMENT CLUSTER
1016-A6	A3-R	NOTE 23	-	IGN ANTILOCK BRAKE SYSTEM
1016-A6	A3-T	3	IGN	ZONAR PREWIRE
1016-A6	A3-U	5	ACC	SAAR POSITION SENSOR
1016-A6	A3-V	10	ACC	BODY BUILDER CONN / NEC GPS
1016-A6	A3-W	5	ACC	SWITCH PACK / SYSTEM CONTROLLER
1016-A6	A3-X	5	BAT	PANEL LIGHTS

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
1017 -A2	A2-F1	-	-	-
1017 -A2	A2-F2	-	-	-
1017 -A2	A2-F3	-	-	-
1017 -A2	A2-F4	-	-	-
1017 -A2	A2-F5	-	-	-
1017 -A2	A2-F6	-	-	-
1017 -A2	A2-F7	-	-	-
1017 -A2	A2-F8	-	-	-
1017 -A2	A2-F9	30	BAT	GAS/PROPANE STARTER FUSE

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
1010 -A12	R1	-	-	WHEEL CHAIR LIFT RELAY
1010 -A12	R2	-	-	THERMAL OVER CRANK/EV PEDAL FWD
1010 -A12	R3	-	-	HYD PB/ WHEEL CHAIR/ EV PEDAL RR
1010 -A12	R4	-	-	DUAL A/C COMP CONTROL RELAY
1010 -A12	R5	-	-	AIR PARK BRAKE INTRLINK RELAY
1010 -A12	R6	-	-	BACK UP LIGHT RELAY

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
1011 -A11	R1	-	-	WIPER POWER RELAY
1011 -A11	R2	-	-	SHIFT INHIBIT RELAY
1011 -A11	R3	-	-	SEAT BELT ALRAM RELAY
1011 -A11	R4	-	-	WIPER HI-LOW RELAY
1011 -A11	R5	-	-	PARK BRAKE ALARM RELAY
1011 -A11	R6	-	-	PARK BRAKE ZVR RELAY

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
1012 -A9	R1	-	-	FOG LIGHT RELAY
1012 -A9	R2	-	-	AUTO DRAIN VALVE RELAY
1012 -A9	R3	-	-	BACK UP LIGHT RELAY
1012 -A9	R4	-	-	EMERGENCY EXIT RELAY
1012 -A9	R5	-	-	ECONOMY MODE RELAY
1012 -A9	R6	-	-	PTI RELAY

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
1013 -A8	R1	-	-	IGN POWER RELAY 1
1013 -A8	R2	-	-	IGN POWER RELAY 2

R/D	FUSE/RELAY	RATING(A)	CONNECTED	DESCRIPTION
1015 -A5	R1	-	-	STARTER ALT FUEL RELAY
1015 -A5	R2	-	-	-

2.32. FUSE GRAPHIC - PLATFORM AND ELECTRICAL PANEL - 4214351C1 (CONT.), P. 32 | Figure 32 FUSE GRAPHIC - PLATFORM AND ELECTRICAL PANEL - 4214351C1 (CONT.) | printed page 32

Table: INC. PANEL-4214351C1(CONT.)

BREAKERS	NOTES	CURRENT RATING	DESCRIPTION
1		7.5A	MANUAL DOOR VANDAL LOCK
1		10A	AIR DOOR VANDAL LOCK
1		15A	ELECTRIC ENTRANCE DOOR
2		15A	RF 50K BTU SINGLE SW
2		25A	RF WALL HEATER SWITCH 2/RF PASSENGER
3		3A	PTI - THEFMATE
3		5A	DOME LIGHT TIMER RELAY
4		3A	PTI CHECKMATE/ ALT ENTRANCE DOOR AIR
4		5A	A/C NOISE SUPRESSION
4		7.5A	ALT ENTRANCE DOOR ELECTRIC
5		7.5A	DEFOG FAN RIGHT SWITCH
5		15A	DEFOG FAN RIGHT SWITCH X2
5		20A	CENTER BLOWER RIGHT SWITCH
6		15A	RR 50K BTU SINGLE SW
6		25A	RR WALL HEATER SWITCH 2/RR PASSENGER
7		3A	3A PTI - CHECKMATE
7		5A	5A PTI - THEFTMATE
7		10A	10A PTI - CRS
7		15A	15A CHK-MATE ACTIVATED BY BRKS OR PWL
8		3A	3A PTI - CHECKMATE DEACTIVATE
8		10A	10A PTI - THEFTMATE
8		15A	15A PTI - CRS-HEADLIGHTS
9		3A	PTI - THEFTMATE/PTI-CHECKMATE
9		5A	PTI - CRS
10		3A	TRACTION SANDERS
10		20A	AUDIO AND VIDEO PREWIRE
11		3A	PUPIL WARNING LIGHTS
11		20A	PEDESTRIAN LIGHTS
12		3A	INDICATOR LIGHT MONITOR
12		7.5A	LIGHT MONITOR
13		5A	DOME LIGHTS ACTIVATED BY TIMER
13		15A	DOME LIGHTS (BATTERY)
13		20A	DOME LIGHT FEED (IGNITION)
14		2/5/7.5/10A	BOOSTER PUMP
14		15/20A	FUEL FIRED HEATER TIMER
15		5A	DVR SYSTEM
15		15A	BOOSTER PUMP
15		20A	AUDIO AND VIDEO PREWIRE
16		7.5A	STOP ARM/CROSSING GATE
16		15A	PUPIL WARNING LIGHTS RED & BLUE
17		3A	ENGINE COMPARTMENT LIGHT
17		15A	CHILD MONITOR SYSTEM
18		3A	ENGINE COMPARTMENT LIGHT
18		7.5A	ELECTRICAL PANEL COMPARTMENT LIGHT
19		7.5A	HEATED SEAT/CHILD SAFETY ALARM
19		20A	AUDIO AND VIDEO PREWIRE
20		15/10/7.5A	BOOSTER PUMP
21		3A	PREWIRE DVR
21		7.5A	DDR
21		20A	VIDEO SYSTEM TERMINAL STRIP
22		7.5A	DEFOG FAN LEFT SWITCH
22		15A	DEFOG FAN (X2) LEFT SWITCH
22		20A	CENTER BLOWER LEFT SWITCH
23		5A	HYD BRAKES/ BENDIX AIR
23		10A	WABCO AIR
23		10A	PARKING BRAKE BUZZER N/BENDIX
23		30A	PARKING BRAKE BUZZER W/BENDIX

Legend: NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. ; CHK DATE ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; MJV0488 19AUG21 CHAPTER NUMBER 2 B 96259J ; RELEASE NO. DATE ; WAS 20.

2.33. PRODUCT GRAPHIC - BUS BODY ELECTRICAL PANEL HARNESS, P. 33
Figure 33 PRODUCT GRAPHIC - BUS BODY ELECTRICAL PANEL HARNESS

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.33. PRODUCT GRAPHIC - BUS BODY ELECTRICAL PANEL HARNESS, P. 33 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090653 95885P 26NOV20 / CHAPTER 2 PRODUCT GRAPHIC-BUS BODY ELECTRICAL PANEL HARNESS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FUSE BLOCK ELEC PANEL / F26 F27 F29 F30 F32 F33 F35 F36 / F14 F15 F17 F18 F20 F21 F23 F24 / F2 F3 F5 F6 F8 F9 F11 F12 / D61 #10306 D64 D67 D70 / STEP WARMER / F38 F39 F41 F42 F44 F45 F47 F48 / F50 F51 F53 F54 F56 F57 F59 F60 / F62 F63 F65 F66 F68 F69 F71 F72 / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / Figure 33 / PRODUCT GRAPHIC - BUS BODY ELECTRICAL PANEL HARNESS

2.34. PRODUCT GRAPHIC - FUSE BLOCK PLATFORM HARNESS, P. 34
Figure 34 PRODUCT GRAPHIC - FUSE BLOCK PLATFORM HARNESS

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.34. PRODUCT GRAPHIC - FUSE BLOCK PLATFORM HARNESS, P. 34 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090653 95885P 26NOV20 / CHAPTER 2 PRODUCT GRAPHIC- FUSE BLOCK PLATFORM HARNESS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / IGN IGN BACK-UP STOP WIPER WIPER #2 #1 LIGHT LIGHT SPEED POWER RELAY RELAY RELAY RELAY RELAY RELAY / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / PART - 4165878C1 / Figure 34 / PRODUCT GRAPHIC - FUSE BLOCK PLATFORM HARNESS

2.35. TERMINAL / HEAT SHRINK (HST) INFORMATION, P. 35
Figure 35 TERMINAL / HEAT SHRINK (HST) INFORMATION

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.35. TERMINAL / HEAT SHRINK (HST) INFORMATION, P. 35 / CHAPTER 2 TERMINAL/HEAT SHRINK(HST) INFORMATION / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090653 NO. 95885P 10NOV20 / NOTE - REFER CHAPTER 2_08 FOR PREFIX LOCATION IDENTIFICATION/INFORMATION. / MJV0488 13SEP21 ADDED TERMINAL PART NUMBERS. / TERMINAL NOTE / PREFIX FOR HARNESS INDENTIFICATION / TERMINAL NO. / Figure 35 / TERMINAL / HEAT SHRINK (HST) INFORMATION

Figure 36 TERMINAL / HEAT SHRINK (HST) INFORMATION (CONT.)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.36. TERMINAL / HEAT SHRINK (HST) INFORMATION (CONT.), P. 36 / CHAPTER 2 TERMINAL/HEAT SHRINK(HST) INFORMATION / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090653 NO. 95885P 17MAY21 / NOTE - REFER CHAPTER 2_08 FOR PREFIX LOCATION IDENTIFICATION/INFORMATION. / MJV0488 13SEP21 ADDED TERMINAL PART NUMBERS. / TERMINAL NOTE / TERMINAL NO. / Figure 36 / TERMINAL / HEAT SHRINK (HST) INFORMATION (CONT.)

2.37. HIGH / LOW VOLTAGE LINE SPECIFICATION, P. 37
Figure 37 HIGH / LOW VOLTAGE LINE SPECIFICATION

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 2.37. HIGH / LOW VOLTAGE LINE SPECIFICATION, P. 37 / CHAPTER 2 HIGH/LOW VOLTAGE LINE SPECIFICATION / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090653 96429Y 09FEB22 / NOTE - THICKNESS OF LINES INDICATES THE HIGH VOLTAGE AND LOW VOLTAGE CONNECTIONS. / SR NO. / LOW VOLTAGE / HIGH VOLTAGE / - UPDATED HV CABLE FOR LINE THICKNESS. / Figure 37 / HIGH / LOW VOLTAGE LINE SPECIFICATION

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 78 | printed page 38 | section
12 VOLT POWER DISTRIBUTION AND DATALINK (CHAPTER 3)
Figure 38 BATTERY FEED PLATFORM

Components: ALARM (1109A); ALARM RELAY (1011-R5); CAB FEED (4000); FEED STUD (1000); FOG LIGHT RELAY (1012-R1); FUSE BLOCK (1014-A6); HEADLAMP SWITCH (1142); IGNITION POWER RELAY 2 (1013-R2); INSTRUMENT CLUSTER (1500); PLATFORM/ELEC PANEL (1702); PLATFORM/ENGINE (1701); PLATFORM/FWD CHASSIS (1700); POWER RELAY 1 (1013-R1); VALVE RELAY (1012-R2); ZONAR V3-POWER (1349)
Wires (circuit gauge+color): A14 4RD; A14A 6RD; A14C 6RD; A14CA 12RD; A14CB 12RD; A14CC 12RD; A14D 6RD; A14DA 12RD; A14DB 12RD; A14EA 12RD; A14EB 12RD; A14EC 12RD; A14FA 12RD; A14FB 12RD; A14HB 18RD; A14KA 12RD; A14TS 20RD; A152W 18GY; A28 18TN; A39D 14OR; A74 12LTGN; A74D 14LTGN; A74H 12LTGN; A75 12LTGN; A75 12RD; A79A 16RD; A79B 16RD; A79C 16RD; A90C 18GY
See also sheets: CH13_02, CH13_34, CH13_52, CH13_55, CH17_31, CH19_12, CH19_13, CH19_17, CH19_18, CH27_23, CH27_25, CH2_24, CH3_04, CH5_01, CH5_12, CH7_61
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12 VOLT POWER DISTRIBUTION AND DATALINK (CHAPTER 3) / 3.1. BATTERY FEED PLATFORM, P. 1 / BATTERY FEED - PLATFORM / CHAPTER 3 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 96275E 10AUG21 / MJV0488 22SEP21 ADDED 1507 TO FUSE B B A6-D.ADDED CIR A14HB. / A79A 16RD / A6-E A14EB 12RD 9 13 / FUSE BLOCK (1014-A6) A6-B A14CB 12RD 6 2 / A39D 14OR / BATTTERY FEED STUD (1000) / A14 4RD / A14D 6RD / A14C 6RD / A79C 16RD / A79B 16RD / A6-F A14EC 12RD 10 14 A6-D A14CC 12RD 4 8 / A14TS 20RD / A28 18TN / A6-L A14FA 12RD 19 23 / A14EA 12RD / IGNITION POWER RELAY 2 (1013-R2) CH3_04 / A6-G A14DA 12RD 15 11 / ^A74D 14LTGN @A74H 12LTGN %A75 12RD *A75 12LTGN #A74 12LTGN / PLATFORM/FWD CHASSIS (1700) CH19_17 CH19_18 / A6-J A14DB 12RD 17 21 / A14CA 12RD / IGNITION POWER RELAY 1 (1013-R1) CH3_04 / A6-N A14FB 12RD 29 25 / A152W 18GY / PLATFORM/ELEC PANEL (1702) CH13_55 / A6-P A14KA 12RD 26 30 / A64A 16YL A64B 16YL / FOG LIGHT RELAY (1012-R1) CH7_61 / A14A 6RD / CAB FEED (4000) / A90C 18GY / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / A14HB 18RD / Figure 38 / BATTERY FEED PLATFORM

3.2. BATTERY FEED PLATFORM (CONT.), P. 2
Figure 39 BATTERY FEED PLATFORM (CONT.)

Components: CLUSTER (1500); CONNECTOR (1651); ELEC PANEL (1702); ENG/PLATFORM (1701); EV SHIFT SELECTOR (1855); FUSE BLOCK (1014-A6); FUSE BLOCK (1016-A3); FWD CHASSIS (1700); K BAUD (1651); KEY SW (1100); N2 MODULE (2513); PANEL LT SPLICE (1002A); PLATFORM/ENG (1701); PLATFORM/FWD CHASSIS (1700); RELAY 1 (1013-R1); SHIFT INHIBIT RELAY (1011-R2); SHIFT SELECTOR (1850); SW PACK (1101)
Wires (circuit gauge+color): A119 16GY; A119A 16GY; A119AC 18GY; A13AA 12PK; A13AF 12PK; A14BA 18RD; A15 16RD; A152W 18GY; A15A 18RD; A15B 16RD; A23 16TN; A26 18TN; A26B 18TN; A59 16GY; A62 16DKBL; A62AN 18DKBL; A62DM 18DKBL; A62Z 16DKBL; A62ZA 18DKBL; A92B 18TN
See also sheets: CH12_02, CH12_03, CH13_55, CH27_11, CH27_40, CH2_24, CH3_03, CH3_04, CH3_27, CH3_92, CH4_01, CH5_01, CH5_08, CH5_09, CH8_24, CH8_25, CH8_53, CH9_09, CH9_11
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.2. BATTERY FEED PLATFORM (CONT.), P. 2 / CHAPTER 3 BATTERY FEED - PLATFORM (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 96275E 10AUG21 / MJV0488 22SEP21 ADDED CIRCUIT A98A AND A92B. / A119A 16GY / FUSE BLOCK (1014-A6) A6-A 1 5 / PLATFORM/ FWD CHASSIS (1700) CH9_11 PLATFORM/ENG (1701) CH5_09 / A119AC 18GY / A26B 18TN / A6-K 22 18 / *A98A 18VT DIAGNOSTIC CONNECTOR 500K BAUD (1651) CH3_92 SHIFT SELECTOR (1850) CH12_03 / A98 18VT / A6-H 16 12 / A15B 16RD / PLATFORM/FWD CHASSIS (1700) CH9_09,10 N2 MODULE (2513) CH3_27 SHIFT INHIBIT RELAY (1011-R2) CH12_02 KEY SW (1100) CH3_03,04 CH4_01,02,04 / A6-M 24 20 / A#170A 18PK / *A92B 18TN PLATFORM/ENG (1701) 18 @A23 16TN @A59 16GY / A6-R 27 31 / A6-T 28 32 / A152W 18GY / PLATFORM/ ELEC PANEL (1702) CH13_55 / A13AA 12PK / IGN PWR RELAY 1 (1013-R1) CH3_04 / ENG/PLATFORM (1701) 1 @A97Z 12VT / A62Z 16DKBL / FUSE BLOCK (1016-A3) A3-X 36 40 / A62AN 18DKBL / PLATFORM/ ELEC PANEL (1702) CH8_24 SW PACK (1101) CH8_53 PANEL LT SPLICE (1002A) CH8_25 @ W/BASE W/GEN 5 W/2017/2021-ISB/B6.7-DIESEL ENGINE / A62 16DKBL / INSTRUMENT CLUSTER (1500) CH5_01 / A26 18TN A26B 18TN A119 16GY / PLATFORM/ENG (1701) CH5_08,10 / A6-C 3 7 / A14BA 18RD / A15A 18RD A15 16RD / A15 16RD / A13AF 12PK / A62DM 18DKBL / A119 16GY / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / DIAGNOSTIC CONNECTOR AND EV DIAGONOSTIC CONNECTOR (1651)(1652) CH3_92, CH27_11 / EV SHIFT SELECTOR (1855) CH27_40 / A62ZA 18DKBL / Figure 39 / BATTERY FEED PLATFORM (CONT.)

3.3. ACCESSORY FEED PLATFORM, P. 3
Figure 40 ACCESSORY FEED PLATFORM

Components: BODY CONTROLLER (1600); BODY CONTROLLER (1606); DIODE ASSY CONN (1010F); ELEC PANEL (1703); EMERGENCY EXIT RELAY (1012-R4); FUSE A6-H (1014); FUSE BLOCK (1016-A3); FWD CHASSIS (1700); KEY SWITCH (1100); PARK BRK ZVR RELAY (1011-R6); PTI RELAY (1012-R6); SWITCH PACK (1101); WHEEL CHAIR LIFT RELAY (1010-R1); ZVR RELAYS (1009)
Wires (circuit gauge+color): A117C 18GY; A12 16GY; A125H 18GY; A12A 16LTBL; A12AA 16LTBL; A12C 18LTBL; A12D 18GY; A12E 16GY; A12EB 16LTBL; A148 16GY; A148B 16LTBL; A149D 18GY; A15 16RD; A15B 16RD; A44M 16GY; A79P 16PK
See also sheets: CH13_04, CH13_52, CH14_02, CH15_08, CH18_38, CH2_24, CH3_02, CH3_30, CH8_53
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.3. ACCESSORY FEED PLATFORM, P. 3 / CHAPTER 3 ACCESSORY FEED - PLATFORM / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A12AA 16LTBL A12A 16LTBL / A3-V 34 38 / FUSE BLOCK (1016-A3) A3-U 33 37 / KEY SWITCH (1100) BATT / OFF IGN C / J3-RED BODY CONTROLLER (1600) / 16RD 16RD A15 A15 / FUSE A6-H (1014) CH3_02 / %A149D 18GY *A12D 18GY / PLATFORM/ ELEC PANEL (1703) CH3_30 / A3-W 39 / A12C 18LTBL / SWITCH PACK (1101) CH8_53 / A44M 16GY / PLATFORM/ FWD CHASSIS (1700) CH13_04 / A12EB 16LTBL / RELAY ZVR SPLICE DIODE ASSY CONN (1010F) A B / A12EB 16LTBL / %A148B 16LTBL / %A148 16GY / *A12 16GY / J1-18 WAY BODY CONTROLLER (1606) / A15B 16RD / % W/2017/2021 ISB/B6.7 DIESEL ENG * W/F-2018-PROP/GAS-ENG / COILS SIGNAL ZVR RELAYS (1009) A / A89CD 18VT / A79P 16PK / A117C 18GY A125H 18GY / *A12E 16GY / Figure 40 / ACCESSORY FEED PLATFORM

3.4. IGNITION FEED PLATFORM, P. 4
Figure 41 IGNITION FEED PLATFORM

Components: BODY CONTROLLER (1600); FUSE A3-A (1016); FUSE A3-E (1016); FUSE A3-G (1016); FUSE A6-H (1014); FUSE A6-J (1014); FUSE A6-L (1014); FUSE A6-T (1014); GROUND (4037A); KEY SWITCH (1100); RELAY 2 (1013-R2); RELAY R1 (1013-R1)
Wires (circuit gauge+color): A11-GZ 8WH; A13-G 18WH; A13-GA 18WH; A13A 16PK; A13AA 12PK; A13AC 12PK; A13AD 12PK; A13AD 18GY; A13AE 12PK; A13AF 12PK; A13AN 16GY; A13B 16PK; A13BA 12PK; A148AN 16GY; A149AD 18GY; A14CA 12RD; A14EA 12RD; A15 16RD; A15B 16RD
See also sheets: CH2_24, CH3_01, CH3_02, CH3_05
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.4. IGNITION FEED PLATFORM, P. 4 / CHAPTER 3 / IGNITION FEED - PLATFORM / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / IGNITION POWER RELAY R1 (1013-R1) 86 / J3 RED BODY CONTROLLER (1600) / % W/GEN 5 W/2017/2021 ISB/B6.7 DIESEL ENG * W/GEN 5 W/F-2018-PROP/GAS-ENG / A15 16RD A15 16RD / KEY SWITCH (1100) BATT / OFF IGN C / J3-RED BODY CONTROLLER (1600) / FUSE A6-H (1014) CH3_02 / %A149AD 18GY *A13AD 18GY / A15B 16RD / A13AA 12PK / FUSE A3-A (1016) CH3_05 FUSE A3-G (1016) CH3_05 FUSE A6-T (1014) CH3_02 / A14CA 12RD / FUSE A6-J (1014) CH3_01 / GROUND (4037A) / A11-GZ 8WH / %A148AN 16GY *A13AN 16GY / A13A 16PK / IGNITION POWER RELAY 2 (1013-R2) 86 30 / A13-GA 18WH / A13B 16PK / A13BA 12PK / A13AE 12PK / FUSE A3-E (1016) CH3_05 / A14EA 12RD / FUSE A6-L (1014) CH3_01 / A13-G 18WH / A13AC 12PK / A13AD 12PK / *A13AF 12PK / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 41 / IGNITION FEED PLATFORM

3.5. IGNITION FEED PLATFORM (CONT.), P. 5
Figure 42 IGNITION FEED PLATFORM (CONT.)

Components: ABS-8 CONN X1 (9543); FUSE BLOCK (1016-A3); IGNITION SPLICE PACK (1014A); INTERLOCK RELAY (1010-R5); PLATFORM/ELEC PANEL (1702); PLATFORM/ENG (1701); PLATFORM/ENGINE (1701); PLATFORM/FWD CHASSIS (1700); PLATORM/ENG (1701); PWR RELAY 1 (1013-R1); PWR RELAY 2 (1013-R2); SELECTOR (1855); SHIFT SELECTOR (1850)
Wires (circuit gauge+color): A13AA 12PK; A13AB 18PK; A13AC 12PK; A13AD 12PK; A13AE 12PK; A13BA 12PK; A13BB 12PK; A13BC 12PK; A13D 18PK; A13DA 18PK; A44K 18GY; A90E 18GY; A92B 18GY; A92C 18TN; A94BA 18GY; A94BJ 10GY; A94BJ 18GY; A94BK 12GY; A94Y 18GY
See also sheets: CH11_01, CH12_03, CH12_10, CH12_12, CH12_15, CH13_22, CH13_26, CH13_30, CH13_33, CH13_42, CH13_54, CH15_11, CH27_40, CH2_24, CH3_04, CH3_21, CH3_28, CH4_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.5. IGNITION FEED PLATFORM (CONT.), P. 5 / CHAPTER 3 IGNITION FEED - PLATFORM (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 96275E 10AUG21 / MJV0488 22SEP21 ADDED CIR A92C. / A13AB 18PK / FUSE BLOCK (1016-A3) A3-A A13AC 12PK 1 5 / A3-G A13AD 12PK 15 11 / PLATFORM/ELEC PANEL (1702) CH3_21 / A44AB 16VT / AIR PARK BRAKE INTERLOCK RELAY (1010-R5) CH15_11 PLATORM/ENG (1701) CH13_54 / A13AA 12PK / A13AB 18PK A13D 18PK *A92C 18TN / IGNITION SPLICE PACK (1014A) EV SHIFT CH3_28 SELECTOR (1855) CH27_40 / A3-R A13BC 12PK 31 27 / A94BJ 18GY / A94Y 18GY / A94BJ 10GY / A44K 18GY / A13DA 18PK / A3-E A13AE 12PK 9 13 / A#163AA 18YL / A13BA 12PK / A92B 18GY / A3-K A13BB 12PK 22 18 / A97UA 18VT / A94BK 12GY / IGNITION PWR RELAY 1 (1013-R1) CH3_04 / IGNITION PWR RELAY 2 (1013-R2) CH3_04 / A#163 18YL A#163A 18YL / A#163 18YL / A94BA 18GY / A90E 18GY / *W/PB10E00 NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 42 / IGNITION FEED PLATFORM (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 83 | printed page 43 | section 3.6
3.6. IGNITION FEED PLATFORM (CONT.), P. 6
Figure 43 IGNITION FEED PLATFORM (CONT.)

Components: ACCEL POSITION (1804); AUTO DRAIN VALVE RELAY (1012-R2); BACK-UP LT RELAY (1010-R6); CLUSTER (1500); CONTROL SOLENOID (1828); DRIVER INTERFACE UNIT (9548); DRIVR INTERFACE UNIT (9548); ELEC PANEL (1702); FUSE BLOCK (1016-A3); FWD CHASSIS (1700); PLATFORM/ENG (1701); PLATFORM/VCU (1701); PLATORM/FWD CHASSIS (1700); REGEN SW (9266); ZONAR V3 POWER (1349)
Wires (circuit gauge+color): A13BF 18PK; A13E 18PK; A13EE 18PK; A13F 18PK; A13FD 18PK; A13FV 18PK; A13TS 20PK; A152S 18RD; A152V 18GY; A152X 18GY; A152Y 18RD; A28A 18TN; A39A 16GY; A71 16OR; A71A 18OR; A71AB 16OR; A87A 18GY; A92 18TN; A95C 18PK; A95CA 18PK
See also sheets: CH11_01, CH12_05, CH13_01, CH13_02, CH13_07, CH13_20, CH13_32, CH13_50, CH13_55, CH17_31, CH27_23, CH27_42, CH2_24, CH3_93, CH5_01, CH7_02, CH7_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.6. IGNITION FEED PLATFORM (CONT.), P. 6 / CHAPTER 3 IGNITION FEED - PLATFORM (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 96275E 10AUG21 / MJV0488 22SEP21 ADDED 1507 TO FUSE A3-P. / A13TS 20PK / A3-B 2 6 / A3-T 32 28 / REGEN SW (9266) CH13_20 INSTRUMENT CLUSTER (1500)/(1507) CH5_01 CH27_23 ZONAR V3 POWER (1349) CH17_31 / FUSE BLOCK (1016-A3) A152Y 18RD A13EE 18PK / A152V 18GY A152V 18GY A152X 18GY A152X 18GY A13F 18PK A13E 18PK / A152S 18RD A13E 18PK A13FV 18PK / A3-F 14 10 A3-H 16 12 A3-J 17 21 A3-L 23 19 A3-M 24 20 / A92 18TN / SHIFT LEVEL CONTROL SOLENOID (1828) CH12_05 PLATORM/FWD CHASSIS (1700) CH13_07 ACCEL POSITION (1804) CH11_01 AUTO DRAIN VALVE RELAY (1012-R2) CH13_02 / A87A 18GY / A99F 18VT / A39A 16GY / A71 16OR / A71A 18OR A71 16OR A71 16OR A71AB 16OR / BACK-UP LT RELAY (1010-R6) CH7_02 / A13BF 18PK A13FD 18PK A95CA 18PK / A3-N 25 29 / A13BF 18PK / A95C 18PK / PLATFORM/ENG (1701) CH13_01 PLATFORM/VCU (1701) CH27_42 / A28A 18TN / A3-P 26 30 / BACK-UP LT RELAY (1010-R6) CH7_03 / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / A152Y 18RD / Figure 43 / IGNITION FEED PLATFORM (CONT.)

3.7. BATTERY FEED - ELECTRICAL PANEL, P. 7
Figure 44 BATTERY FEED - ELECTRICAL PANEL

Components: AED RELAY (10312-R3); DESTINATION SIGN (10267A); DOME LT PWR (10201); DOOR CONTROL RELAY (10309); ELEC PANEL/PLATFORM (1702); FUSE BLOCK (10301-B12); FUSE BLOCK (10304-B3); HTD MIRROR (10293); HTD MIRROR TIMER (10295); LUGGAGE BOX LT (10268); NS3 RELAY (10315-R1); R FR HTR SW (10245A); R RR HTR2 (10246A); R RR HTR2 (10246B)
Wires (circuit gauge+color): B118D 12BK; B118DE 12BK; B118E 14BK; B120J 16LTGN; B120J 18LTGN; B133A 18LTGN; B134 16OR; B134 16RD; B135A 16OR; B14 4BK; B14A 6BK; B14CD 12BK; B14D 12BK; B14E 12BK; B14L 12BK; B14S 12BK; B14T 14BK; B14U 12PK; B63A 12DKBL; B75AJ 12LTGN; B75AM 12LTGN; B75R 12LTGN; B75X 12LTGN; B78A 18LTGN; B78D 18LTGN
See also sheets: CH10_01, CH16_08, CH16_12, CH16_13, CH16_18, CH19_23, CH19_24, CH2_24, CH3_20, CH7_07, CH7_09, CH7_64, CH8_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.7. BATTERY FEED - ELECTRICAL PANEL, P. 7 / CHAPTER 3 BATTERY FEED - ELECTRICAL PANEL / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B75R 12LTGN B75AM 12LTGN B75X 12LTGN B75AJ 12LTGN B133A 18LTGN / B12-G B14D 12BK 11 15 B118D 12BK B12-U B14E 12BK 33 37 B118E 14BK B14L B12-B 12BK 2 6 / B3-J 17 21 B3-U B14T 14BK 33 37 / FUSE BLOCK (10301-B12) B12-E B14CD 12BK 9 13 / DOME LT PWR (10201) CH8_35 HTD MIRROR (10293) CH10_01 HTD MIRROR TIMER (10295) CH10_01 AED RELAY (10312-R3) CH7_09 DESTINATION SIGN (10267A) CH7_07.08 / B134 16RD / B3-M B14U 12PK 20 24 / B135A 16OR / PWR STUD (0PWR) B14 4BK / B63A 12DKBL / FUSE BLOCK (10304-B3) / B14S 12BK / B14A 6BK / B120J 16LTGN / B78D 18LTGN / B134 16OR / B118DE 12BK / NS3 RELAY (10315-R1) CH3_20 / B120J 18LTGN / B78A 18LTGN / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / B120J 16LTGN / Figure 44 / BATTERY FEED - ELECTRICAL PANEL

3.8. BATTERY FEED - ELECTRICAL PANEL (CONT.), P. 8
Figure 45 BATTERY FEED - ELECTRICAL PANEL (CONT.)

Components: ASSERT (11338); BLOCK (10302-B9); DOME LT RELAY (10313_R5); DRIVERS HEATER (10229); FUSE B6-H (10303); LT RELAY (10311-R1); LT RELAY (10311-R2); LT RELAY (10311-R3); MIN TIMER RELAY (10313_R3); NS1 RELAY (10314-R1); PTI RELAY (10309-R4); RELAY (10310-R2); TIMER RELAY (10397)
Wires (circuit gauge+color): B118A 12BK; B118AB 10BK; B118B 14BK; B125H 16GY; B125J 16GY; B125K 16GY; B125S 16GY; B14 4BK; B14A 6BK; B14CA 14RD; B14H 14BK; B14H 14RD; B14HH 16BK; B14W 10BK; B14WW 12BK; B63A 16DKBL; B63B 16DKBL; B63E 16DKBL; B63K 16DKBL; B63L 16DKBL; B63M 16DKBL; B63MA 16DKBL; B63MB 16DKBL; B63MC 16DKBL; B63MD 16DKBL; B63MJ 18DKBL; B63MK 16DKBL; B63MV 16DKBL; B63N 16DKBL; B63R 16DKBL; B75 12LTGN; B85 16GY
See also sheets: CH18_02, CH18_07, CH18_10, CH18_23, CH18_24, CH18_36, CH19_11, CH2_24, CH3_09, CH3_21, CH8_08, CH8_09, CH8_15, CH8_17, CH8_18, CH8_19, CH8_21
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.8. BATTERY FEED - ELECTRICAL PANEL (CONT.), P. 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / CHAPTER 3 BATTERY FEED - ELECTRICAL PANEL (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B9-W 35 39 / B14H 14RD B14H 14RD B85 16GY B14CA 14RD B63M 16DKBL B63M 16DKBL / FUSE BLOCK (10302-B9) / B63MJ 18DKBL B63MC 16DKBL B63MA 16DKBL B63MK 16DKBL B63MV 16DKBL B63MB 16DKBL B63MD 16DKBL / FRONT DOME LT RELAY (10311-R3) CH8_18 CH8_21 / B63L 16DKBL / B63MB 16DKBL B63MA 16DKBL B63K 16DKBL B63R 16DKBL B63N 16DKBL B63M 16DKBL B63B 16DKBL B63E 16DKBL B125H 16GY / DOME LT RELAY (10313_R5) CH8_17 / 2 MIN TIMER RELAY (10313_R3) CH8_09 / B63A 16DKBL / B9-H 16 12 / B125K 16GY / B125J 16GY / REAR ROW DOME LT RELAY (10311-R1) CH8_08 REAR DOME LT RELAY (10311-R2) CH18_07 CHILD CHECKMATE RELAY (10310-R2) CH18_36 DRIVERS HEATER (10229) CH19_11 / B9-L 19 23 / B75 12LTGN / REAR DOME LT RELAY (10311-R2) CH8_18 CH8_19 CH8_21 / B125S 16GY / PWR STUD (0PWR) / B14H 14BK / B14A 6BK / B14 4BK / B14HH 16BK / B14WW 12BK B118A 12BK / B14W 10BK B118AB 10BK B118B 14BK / NS1 RELAY (10314-R1) CH3_21 FUSE B6-H (10303) CH3_09 / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / B63M 16DKBL / B63M 16DKBL / Figure 45 / BATTERY FEED - ELECTRICAL PANEL (CONT.)

3.9. BATTERY FEED - ELECTRICAL PANEL (CONT.), P. 9
Figure 46 BATTERY FEED - ELECTRICAL PANEL (CONT.)

Components: ACCESSORY 2 (10261A); ALARM MODULE (11627); ALARM RELAY (10310-R6); BOOSTER PUMP RELAY (10311-R4); BOOSTER PUMP RELAY (10311-R5); BUTTON (11631); CONVECTION HTR (10253); ELEC PANEL/PLATFORM (1702); FUSE B9-L (10302); FUSE BLOCK (10303-B6); HEATED AIR SEAT (10358); HEATED AIR SEAT (10368); LFR HTR (10243A); PLATFORM (1702); TIMER COMMON (11621); TIMER POWER IN (11619); TIMER PREWIRE (1053); WEBASTO HTR (10101); WEBASTO SMART TIMER (11623A)
Wires (circuit gauge+color): B105 16LTGN; B105A 16LTGN; B118B 14BK; B125A 18GY; B125T 18GY; B12RB 14LTGN; B14 4BK; B14A 6BK; B14K 10BK; B14KK 12BK; B14V 10BK; B14VV 12BK; B14Y 14BK; B74 14LTGN; B74 16LTGN; B74A 12LTGN; B74A 12RD; B74A 18LTGN; B74B 14LTGN; B74B 16RD; B74C 16LTGN; B74C 18RD; B74D 16RD; B74E 18RD; B74K 16LTGN; B74K 16RD; B74L 16LTGN; B74L 16RD; B74M 16LTGN; B74P 14LTGN; B74P 16RD; B74S 14LTGN; B74U 14LTGN; B74U 16RD; B75AL 12LTGN
See also sheets: CH17_28, CH18_40, CH19_01, CH19_02, CH19_03, CH19_04, CH19_05, CH19_07, CH19_08, CH19_09, CH19_19, CH19_21, CH19_34, CH19_36, CH27_51, CH2_24, CH3_08
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.9. BATTERY FEED - ELECTRICAL PANEL (CONT.), P. 9 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 96275E 10AUG21 / CHAPTER 3 BATTERY FEED - ELECTRICAL PANEL (CONT.) / MJV0488 30SEP21 ADDED CHAPTER 27 TO FUSE B. / FUSE BLOCK (10303-B6) B6-B B14KK 12BK 2 6 / B74 16LTGN B74C 16LTGN B74P 16RD B74A 12RD B74A 12LTGN B74B 14LTGN / B6-W 35 39 / BOOSTER PUMP RELAY (10311-R4) CH19_02,03 CH19_01,05 / BOOSTER PUMP RELAY (10311-R5) CH19_02,03 CH19_01 CH19_05 / B74B 16RD / B74K 16LTGN B74U 14LTGN B74L 16LTGN / B74 14LTGN / POWER STUD (0PWR) B14 4BK / B14K 10BK / B14VV 12BK / B14V 10BK / B14A 6BK / B74B 16RD / B74B 14LTGN / B74B 14LTGN / B74B 14LTGN / Figure 46 / BATTERY FEED - ELECTRICAL PANEL (CONT.)

3.10. BATTERY FEED - ELECTRICAL PANEL (CONT.), P. 10
Figure 47 BATTERY FEED - ELECTRICAL PANEL (CONT.)

Components: ACCESSORY 2 (10261A); AIR HORN (10285); AIR HORN SW (10286); BOOSTER PUMP (10255); ELEC COMP LT SW (10342); FAN SW (1135/1135A); FAN SW (1136/1136A); FOOT SW (8313); FUSE BLOCK (10301-B12); FUSE BLOCK (10303-B6); FUSE BLOCK (10304-B3); FUSE BLOCK (10305-A1); HTR SW (10244A); NS2 RELAY (10314-R2); NS4 RELAY (10315-R2); PLATFORM (1702); SEALED ENG (11500); STEP WARMER RELAY (10305-R1); STOP ARM PWR (10359); TEMP SENSOR RELAY (10310-R3)
Wires (circuit gauge+color): A100A 18GY; A76AA 14LTGN; A76AB 14LTGN; B100A 18GY; B118C 12BK; B118CH 12BK; B118F 12BK; B118FK 12BK; B118H 12BK; B118K 10BK; B119 16GY; B12RB 14LTGN; B132A 12GY; B14 4BK; B14AA 10BK; B14AC 12BK; B14B 6BK; B14BB 6BK; B14C 14BK; B14F 12BK; B14M 10BK; B14MM 12BK; B14P 12PK; B14R 14BK; B14RR 16BK; B14X 10BK; B14XX 12BK; B14Z 12BK; B74AB 12LTGN; B75P 12LTGN; B76C 14LTGN; B76D 14LTGN; B89 14OR; B89H 14OR
See also sheets: CH13_09, CH17_28, CH19_01, CH19_22, CH19_26, CH19_33, CH2_24, CH3_20, CH3_21, CH6_09, CH8_03, CH8_04, CH9_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.10. BATTERY FEED - ELECTRICAL PANEL (CONT.), P. 10 / CHAPTER 3 BATTERY FEED - ELECTRICAL PANEL (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC B74AB WAS B74A IN FUSE B3-G(10304). / B75P 12LTGN / FUSE BLOCK (10305-A1) A1-K B14RR 16BK 20 10 / B3-T B14C 14BK 28 32 B118C 12BK B3-G B14P 12PK 11 15 15 B3-W B14R 14BK 35 39 / FUSE BLOCK (10301-B12) B12-T B14F 12BK 28 32 B118F 12BK B12-W B14Z 12BK 35 39 B118H 12BK / B3-B B14AA B14AC 10BK 12BK 2 6 B118FK 12BK / L REAR HTR SW (10244A) CH19_22 / FUSE BLOCK B119 (10303-B6) 16GY B6-F B14MM B89 12BK 14OR 10 14 B14MM 12BK / ACCESSORY 2 (10261A) CH17_28 / B74AB 12LTGN / STOP ARM PWR (10359) CH9_01 TEMP SENSOR RELAY (10310-R3) CH6_09 ELEC COMP LT SW (10342) CH8_04 ELEC PANEL SEALED ENG (11500) CH8_03 / B136 16YL B121 18YL / B6-P B14XX 12BK 30 26 B14XX 12BK FUSE BLOCK (10304-B3) / ELEC PANEL/ PLATFORM (1702) 2 B76D A76AA 14LTGN 14LTGN / B132A 12GY / BOOSTER PUMP (10255) CH19_01,02,03,04,05, 06,07,08,09 STEP WARMER RELAY (10305-R1) CH19_33 / B76C 14LTGN / PWR STUD (0PWR) B14 4BK / R DEFOG FAN SW (1136/1136A) CH19_26,27 / B12RB 14LTGN ELEC PANEL/ PLATFORM (1702) 3 A76AB 14LTGN / AIR HORN FOOT SW (8313) CH13_09 AIR HORN (10285) CH13_09 AIR HORN SW (10286) CH13_09 / B89H 14OR / B14M 10BK B14M 10BK / ELEC PANEL/ PLATFORM (1702) 45 / B100A 18GY B100A 18GY / A100A 18GY / B118K 10BK / B118CH 12BK / NS4 RELAY (10315-R2) CH3_21 / B14B 6BK / B14BB 6BK / B14X 10BK B14X 10BK / NS2 RELAY (10314-R2) CH3_20 / L DEFOG FAN SW (1135/1135A) CH19_26,27 / B100A 18GY / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 47 / BATTERY FEED - ELECTRICAL PANEL (CONT.)

3.11. BATTERY FEED - ELECTRICAL PANEL (CONT.), P. 11
Figure 48 BATTERY FEED - ELECTRICAL PANEL (CONT.)

Components: ELEC PANEL/ L BODY (10401A/B); FUSE BLOCK (10302-B9); MD2 RELAY (10316-R2); PTI RELAY (10309-R4); PTI RELAY (10309-R5); PTI RELAY (10309-R6)
Wires (circuit gauge+color): B125A 18GY; B125F 18GY; B14 4BK; B14B 6BK; B14BB 6BK; B14BC 14RD; B14MD2 8BK; B14N 12BK; B14X 14RD; B53 16GY; B85X 14GY; B85X 14RD
See also sheets: CH18_02, CH18_07, CH18_10, CH18_14, CH18_16, CH18_20, CH18_24, CH18_29, CH18_34, CH2_24, CH3_20
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.11. BATTERY FEED - ELECTRICAL PANEL (CONT.), P. 11 / CHAPTER 3 BATTERY FEED - ELECTRICAL PANEL (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FUSE BLOCK (10302-B9) B9-B 6 2 / B125F 18GY / PWR STUD (0PWR) B14 4BK / B14N 12BK / MD2 RELAY (10316-R2) CH3_20 / B14B 6BK / B14BB 6BK / B14B 6BK / B14MD2 8BK / B125A 18GY / B53 16GY / B14X 14RD B85X 14RD / B85X 14GY B14BC 14RD / B14N 12BK / B14 4BK / B125F 18GY / B85X 14GY / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 48 / BATTERY FEED - ELECTRICAL PANEL (CONT.)

3.12. BATTERY FEED - ELECTRICAL PANEL (CONT.), P. 12
Figure 49 BATTERY FEED - ELECTRICAL PANEL (CONT.)

Components: BATT FEED (11505); CA 2018 CHECK MATE (10339); CCM/TM POWER SPLICE BLOCK (11503); CHILD CHECK MATE MODULE (10212); CHILD MONITER (11642); CHILD MONITER RELAY (10308-R5); CHILD SAFETY ALARM RELAY (10310-R6); ELEC PANEL/FR CAP (10000); ELEC PANEL/SEALED ENG (11500); FUSE BLOCK (10301-B12); FUSE BLOCK (10302-B9); L INTLK RELAY (10312-R4); L LT RELAY (10312-R1); L SPLICE (10370); PLATFORM (1702); PTI RELAY (10309-R4); RADIO (10259); THEF MATE RED DOT (11642A); THEFT MATE RED DOT (11642A)
Wires (circuit gauge+color): B122D 16GY; B122E 16GY; B122F 16GY; B122H 18GY; B122J 16GY; B125E 18GY; B125H 16GY; B137 16LTBL; B14 18RD; B14AB 18RD; B14CMA 18RD; B14CMB 18RD; B14SE 16RD; B44 18GY; B71H 18LTBL; B86B 16LTGN
See also sheets: CH15_01, CH15_06, CH17_01, CH17_02, CH17_27, CH18_01, CH18_02, CH18_05, CH18_09, CH18_11, CH18_13, CH18_18, CH18_20, CH18_24, CH18_25, CH18_26, CH18_33, CH18_36, CH2_24, CH7_04, CH7_43
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.12. BATTERY FEED - ELECTRICAL PANEL (CONT.), P. 12 / CHAPTER 3 BATTERY FEED - ELECTRICAL PANEL (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B12-C 3 7 B12-D 4 8 / B12-A 1 5 / B71H 18LTBL / B14SE 16RD / B122E 16GY / FUSE BLOCK (10301-B12) / B12-F 10 14 / B86B 16LTGN / B137 16LTBL / B44 18GY / B122H 18GY / B122F 16GY / B122J 16GY B122D 16GY / B86B 16LTGN FUSE BLOCK (10302-B9) B9-A 1 5 / B14CMB 18RD B14 18RD B14CMA 18RD / B14AB 18RD / B125H 16GY / B125E 18GY / B14 18RD / PTI RELAY (10309-R4) CH18_02 CHILD MONITER (11642) CH18_01 / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 49 / BATTERY FEED - ELECTRICAL PANEL (CONT.)

3.13. BATTERY FEED - ELECTRICAL PANEL (CONT.), P. 13
Figure 50 BATTERY FEED - ELECTRICAL PANEL (CONT.)

Components: ACCESSORY 4 (10263B); BATTERY RH (10215A); BATTERY RH (10215B); DOME LT POWER (10201); DOME LT TIMER RELAY (10397); ELEC PANEL/PLATFORM (1702); ELEC PANEL/SEALED ENG (11500); FIRE SUPPRESSION SYSTEM (10384); FUSE BLOCK (10302-B9); HAZARD LIGHT SW (10256); HAZARD LIGHT SW (10256B); MIN TIMER RELAY (10313-R3); RHEOSTAT DIMMER (10376)
Wires (circuit gauge+color): B144 18GY; B144B 18GY; B14LS 18RD; B14UB 14RD; B60 18OR; B60BH 18OR; B63A 12DKBL; B63AA 16DKBL; B63AAH 12DKBL; B63AH 12DKBL; B63AL 12DKBL; B63B 16DKBL; B63RA 12DKBL; B63RB 12DKBL
See also sheets: CH13_12, CH13_15, CH17_28, CH2_24, CH7_65, CH8_07, CH8_10, CH8_17, CH8_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.13. BATTERY FEED - ELECTRICAL PANEL (CONT.), P. 13 / CHAPTER 3 BATTERY FEED - ELECTRICAL PANEL (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B9-C 3 7 / B9-X 36 40 / FIRE SUPPRESSION SYSTEM (10384) CH13_12 ACCESSORY 4 (10263B) CH17_28 ELEC PANEL/SEALED ENG (11500) CH13_12 / B60BH 18OR / 2 MIN TIMER RELAY (10313-R3) CH8_10 DOME LT TIMER RELAY (10397) CH8_17 HAZARD LIGHT SW (10256B) CH7_65 HAZARD LIGHT SW (10256) CH7_65 / B144B 18GY B14UB 14RD / FUSE BLOCK (10302-B9) / B9-V 34 38 / B63AH 12DKBL / BATTERY RH (10215A) CH8_07 BATTERY RH (10215B) CH8_07 RHEOSTAT DIMMER (10376) CH8_07 DOME LT POWER (10201) CH8_35 / B60 18OR / B63A 12DKBL B63AAH 12DKBL / B144 18GY / B14LS 18RD / B63AL 12DKBL B63A 12DKBL / ELEC PANEL/PLATFORM (1702) CH13_15 / B9-D 4 8 / B63B 16DKBL / B63RA 12DKBL / B63RB 12DKBL / B63AA 16DKBL / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 50 / BATTERY FEED - ELECTRICAL PANEL (CONT.)

3.14. BATTERY FEED - ELECTRICAL PANEL (CONT.), P. 14
Figure 51 BATTERY FEED - ELECTRICAL PANEL (CONT.)

Components: A/C RELAY (10308-R4); ACCESSORY 3 (10262B); BACK UP LIGHT RELAY (10308-R2); BOOSTER PUMP RELAY (10311-R4); CL LIGHTS RELAY (10308-R1); DC POWER SOURCE (10375/10375A); DRIVERS ALARM (10299); ELEC PANEL/L BODY (10400A/B); ELEC PANEL/PLATFORM (1702); ELEC PANEL/SEALED ENG (11500); FUSE BLOCK (10303-B6); IN SW PANEL (10375B); SEON POWER (11643); SEON POWER (11653); STEP LIGHT RELAY (10309-R3)
Wires (circuit gauge+color): B131A 16DKBL; B131B 16DKBL; B133L 18LTGN; B14 16RD; B14AH 16RD; B14J 18RD; B14UA 14RD; B14W 18RD; B58 16BN; B71C 16LTBL; B71D 16LTBL; B74 12RD; B84 16LTGN
See also sheets: CH14_01, CH14_19, CH16_21, CH17_28, CH17_29, CH19_08, CH2_24, CH3_67, CH7_05, CH7_66, CH7_67, CH8_03, CH8_23
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.14. BATTERY FEED - ELECTRICAL PANEL (CONT.), P. 14 / CHAPTER 3 BATTERY FEED - ELECTRICAL PANEL (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B6-C 3 7 / B6-A 1 5 / B6-E 9 13 / DC POWER SOURCE (10375/10375A) CH3_67 DC PWR OUTLET IN SW PANEL (10375B) CH3_67 CL LIGHTS RELAY (10308-R1) CH7_66 / B84 16LTGN B84 16LTGN B84 16LTGN B58 16BN / B14UA 14RD / ACCESSORY 3 (10262B) CH17_28 BOOSTER PUMP RELAY (10311-R4) CH19_08 SEON POWER (11643) CH17_29 SEON POWER (11653) CH17_29 / FUSE BLOCK (10303-B6) / B6-G 11 15 / B71C 16LTBL / BACK UP LIGHT RELAY (10308-R2) CH7_05 STEP LIGHT RELAY (10309-R3) CH8_23 / B74 12RD / B131A 16DKBL / B14AH 16RD / B14 16RD / B6-R 27 31 / DRIVERS ALARM (10299) CH14_01 ELEC PANEL/L BODY (10400A/B) CH14_19 ELEC PANEL/SEALED ENG (11500) CH8_03 / B14J 18RD / B14W 18RD / B121 18YL / A/C RELAY (10308-R4) CH7_67 / B6-T 28 32 / B131A 16DKBL B131B 16DKBL / B71D 16LTBL / ELEC PANEL/PLATFORM (1702) CH16_21 / B133L 18LTGN / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 51 / BATTERY FEED - ELECTRICAL PANEL (CONT.)

3.15. ACCESSORY FEED - ELECTRICAL PANEL, P. 15
Figure 52 ACCESSORY FEED - ELECTRICAL PANEL

Components: ACC 1 RELAY (10318-R1); ACC 2 RELAY (10318-R2); ACCESSORY 2 (10261B); ACCESSORY 4 (10263A); DOME LT MONITER (10397); ELEC PANEL/FR CAP (10000); ELEC PANEL/L BODY (10400A/B); FUSE BLOCK (10302-B9); FUSE BLOCK (10303-B6); FUSE BLOCK (10304-B3); FUSE BLOCK (10305-A1); LT MONITER PWR (1079); PEDESTRIAN LT RELAY (10282); STROBE LT LATCH RELAY (10300); STROBE LT SW (10270); TEMP SENSOR RELAY (10310-R3)
Wires (circuit gauge+color): B127 16BK; B127A 16BK; B127A 16OR; B127B 16OR; B128 16LTBL; B12H 12BK; B12HK 12BK; B12HL 10BK; B12HM 16BK; B12K 12BK; B12KL 12BK; B12KM 10BK; B12L 14BK; B12MG 14BK; B12N 12BK; B12RD 14LTGN; B12UB 14LTBL; B143 18DKBL; B41B 18TN; B41H 18TN; B58J 16BN; B63A 16DKBL
See also sheets: CH14_19, CH17_28, CH2_24, CH3_24, CH5_04, CH6_03, CH6_11, CH7_10, CH7_11, CH7_14, CH7_62, CH8_05, CH8_17
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.15. ACCESSORY FEED - ELECTRICAL PANEL, P. 15 / CHAPTER 3 ACCESSORY FEED - ELECTRICAL PANEL / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / MJV0488 19NOV21 CIRC B12MG WAS B12M AT FUSE A1-H(10305). / FUSE BLOCK (10304-B3) B3-E 9 13 / FUSE BLOCK (10302-B9) B9-F 10 14 B9-K 18 22 / B12L 14BK / B58J 16BN / ELEC PANEL/FR CAP (10000) CH8_05 PEDESTRIAN LT RELAY (10282) CH7_62 LT MONITER PWR (1079) CH6_11 / STROBE LT SW (10270) CH7_11,12,13,17 STROBE LT SW (10270) CH7_14 STROBE LT LATCH RELAY (10300) CH7_14 / B12H 12BK / B127A 16OR / ACC 1 RELAY (10318-R1) CH3_24 / B12HL 10BK / B127 16BK / B127A 16BK B127A 16OR B127B 16OR / ELEC PANEL/L BODY (10400A/B) CH7_10 / B12HK 12BK / B139 16YL / B128 16LTBL / B12HM 16BK / FUSE BLOCK (10305-A1) A1-J 19 9 A1-H 8 18 / B143 18DKBL / ELEC PANEL/L BODY (10400A/B) CH14_19 / B12MG 14BK / B41B 18TN / TEMP SENSOR RELAY (10310-R3) CH5_04 / B41H 18TN / B12K 12BK / B63A 16DKBL / B9-U 33 37 / LT MONITER PWR (1079) CH6_11 ELEC PANEL/FR CAP (10000) CH6_03 DOME LT MONITER (10397) CH8_17 / FUSE BLOCK (10302-B9) B9-P 26 30 / B12KL 12BK / B12KM 10BK / B128 16LTBL B128 16LTBL / B12RD 14LTGN B12UB 14LTBL / ACCESSORY 4 (10263A) CH17_28 ACCESSORY 2 (10261B) CH17_28 / FUSE BLOCK (10303-B6) B6-L 19 23 / B12N 12BK / ACC 2 RELAY (10318-R2) CH3_24 / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 52 / ACCESSORY FEED - ELECTRICAL PANEL

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 93 | printed page 53 | section 3.16
3.16. ACCESSORY FEED - ELECTRICAL PANEL (CONT.), P. 16
Figure 53 ACCESSORY FEED - ELECTRICAL PANEL (CONT.)

Components: ACCESSORY 1 (10260B); ACCESSORY 3 (10262A); CA 2018 CHECK MATE VL (11340); CHECK MATE MODULE (10212); CHILD CHECKMATE RELAY (10310-R2); CHILD MONITER (11642); CHILD MONITER DOOR SW O/P (11641); DIODE B6-J (10303); DRIVER MIRROR SW (10353/10354); DRIVERS ALARM (10299); ELEC PANEL/L BODY (10400A/B); ELEC PANEL/PLATFORM (1702); FUSE BLOCK (10302-B9); RELAY COIL (10364); STEP LT RELAY (10309-R3); THEFT MATE SIG VIO DOT (11648)
Wires (circuit gauge+color): B12 18LTBL; B125 18GY; B125C 18GY; B12A 18LTBL; B12AC 18LTBL; B12B 18LTBL; B12C 18LTBL; B12J 18LTBL; B12RC 14LTGN; B12UA 14LTBL; B12W 18LTBL; B12X 18LTBL; B131A 16DKBL; B78A 18LTGN
See also sheets: CH10_02, CH14_01, CH14_28, CH16_08, CH17_28, CH18_01, CH18_06, CH18_12, CH18_13, CH18_18, CH18_21, CH2_24, CH3_29
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.16. ACCESSORY FEED - ELECTRICAL PANEL (CONT.), P. 16 / CHAPTER 3 ACCESSORY FEED - ELECTRICAL PANEL (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B12A 18LTBL FUSE BLOCK B12A (10302-B9) 18LTBL B12A 18LTBL B9-E B12A 18LTBL 9 13 B12W 18LTBL B12C 18LTBL / B9-J 17 21 / B12RC 14LTGN B12UA 14LTBL B78A 18LTGN B131A 16DKBL / B9-G 11 15 / B125 18GY / B12 18LTBL B125 18GY B125C 18GY B12A 18LTBL B12AC 18LTBL B12A 18LTBL / B9-N 25 29 B9-R 27 31 / ACCESSORY SPLICE RELAY COIL (10364) CH3_29 / DRIVERS ALARM (10299) CH14_01 / ELEC PANEL/L BODY (10400A/B) CH14_28 / DIODE B6-J (10303) CH14_28 / ELEC PANEL/PLATFORM (1702) CH14_28 / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 53 / ACCESSORY FEED - ELECTRICAL PANEL (CONT.)

3.17. ACCESSORY FEED - ELECTRICAL PANEL (CONT.), P. 17
Figure 54 ACCESSORY FEED - ELECTRICAL PANEL (CONT.)

Components: CHILD CHECK MATE RELAY (10310-R2); ELEC PANEL/SEALED ENG (11500); FUSE BLOCK (10303-B3); FUSE BLOCK (10303-B6); FUSE BLOCK (10304-B3); FUSE BLOCK (10305-A1); MIN TIMER RELAY (10313-R3); OVERHEAD LIGHT (11645); PTI RELAY (10309-R4); RR DOME LT RELAY (10311-R2); RR ROW DOME LT RELAY (10311-R1); SEALED ENG (11500)
Wires (circuit gauge+color): B125E 18GY; B125M 16GY; B12A 18LTBL; B14 14RD; B140 18TN; B14CA 14RD; B14DM 14RD; B63A 16DKBL; B63E 14RD; B63N 16DKBL
See also sheets: CH18_03, CH18_04, CH18_08, CH18_15, CH18_19, CH18_31, CH18_37, CH2_24, CH3_68, CH8_03, CH8_10, CH8_12, CH8_15
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.17. ACCESSORY FEED - ELECTRICAL PANEL (CONT.), P. 17 / CHAPTER 3 ACCESSORY FEED - ELECTRICAL PANEL (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B6-M 20 24 / B63A 16DKBL / FUSE BLOCK (10303-B6) / RED DRIVERS OVERHEAD LIGHT (11645) CH8_12 / B3-F 10 14 / B12A 18LTBL / FUSE BLOCK (10304-B3) / 2 MIN TIMER RELAY (10313-R3) CH8_15,16 / A1-F 16 6 A1-G 17 7 / B125E 18GY / FUSE BLOCK (10305-A1) / PTI RELAY (10309-R4) CH18_37 / B140 18TN / ELEC PANEL/ SEALED ENG (11500) CH3_68 / B6-N 25 29 / B63N 16DKBL / FUSE BLOCK (10303-B3) / RR ROW DOME LT RELAY (10311-R1) CH18_04 / B14CA 14RD / B14DM 14RD / B63E 14RD / B14CA 14RD / B14 14RD / B121 18YL / B125M 16GY / RR DOME LT RELAY (10311-R2) CH18_08 / RR DOME LT RELAY (10311-R2) CH18_15 / RR DOME LT RELAY (10311-R2) CH18_19 / CHILD CHECK MATE RELAY (10310-R2) CH18_31 / RR DOME LT RELAY (10311-R2) CH18_03 / ELEC PANEL/SEALED ENG (11500) CH8_03 / 2 MIN TIMER RELAY (10313-R3) CH8_10 / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 54 / ACCESSORY FEED - ELECTRICAL PANEL (CONT.)

3.18. IGNITION FEED - ELECTRICAL PANEL, P. 18
Figure 55 IGNITION FEED - ELECTRICAL PANEL

Components: AED RELAY (10312-R3); ALTERNATE ENTRNCE DOOR (10203); BATT FEED (11506); CA 2018 CHECKMATE (10339); CHILD MONITER (11642); COMPARTMENT (10398); ELEC PANEL/FR CAP (10000-D2); ELEC PANEL/L BODY (10401A/B); ELEC PANEL/SEALED ENG (11500); FUSE BLOCK (10301-B12); FUSE BLOCK (10305-A1); LEFT & ELECTRIC AED (10203A); PLATFORM (1703); RELAY (10317-R2); THEFT MATE RED DOT (11642A)
Wires (circuit gauge+color): B120AA 18LTGN; B120AB 16LTGN; B120AB 18LTGN; B120AD 18LTGN; B120AL 16LTGN; B13 18PK; B133P 18LTGN; B133R 18LTGN; B13A 18PK; B13AA 18PK; B13D 12BK; B13DC 12BK; B13DE 12BK; B13E 12BK; B13SE 16PK; B74N 16LTGN; B77A 18LTGN
See also sheets: CH16_22, CH16_23, CH18_11, CH18_18, CH18_26, CH19_01, CH19_39, CH19_40, CH2_24, CH3_21, CH7_43
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.18. IGNITION FEED - ELECTRICAL PANEL, P. 18 / CHAPTER 3 IGNITION FEED - ELECTRICAL PANEL / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B13 18PK B77A 18LTGN / FUSE BLOCK (10305-A1) A1-C B13DC 12BK 13 3 / FUSE BLOCK (10301-B12) B12-K 22 18 / THEFT MATE RED DOT (11642A) CH18_11,27 CA 2018 CHECKMATE (10339) CH18_18,22 ELEC PANEL/SEALED ENG (11500) CH19_39 CHILD MONITER (11642) CH18_26 / B13D 12BK / B74N 16LTGN B13SE 16PK / IGNITION RELAY (10317-R2) CH3_21 / B13DE 12BK / B13AA 18PK / B120AD 18LTGN / ALTERNATE ENTRNCE DOOR (10203) CH16_22 ELEC PANEL/L BODY (10401A/B) CH16_22 LEFT & ELECTRIC AED (10203A) CH16_23 AED RELAY (10312-R3) CH16_23 / B120AA 18LTGN / B120AL 16LTGN / B13E 12BK / A1-A 11 1 / B133R 18LTGN / B133P 18LTGN / B120AB 18LTGN / B120AA 18LTGN / B120AB 16LTGN / B13A 18PK / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 55 / IGNITION FEED - ELECTRICAL PANEL

3.19. IGNITION FEED - ELECTRICAL PANEL (CONT.), P. 19
Figure 56 IGNITION FEED - ELECTRICAL PANEL (CONT.)

Components: AED VANDAL LOCK RELAY (10312-R6); BUZZER RELAY (10310-R4); ELEC PANEL/FR CAP (10000); ELEC PANEL/PLATFORM (1702); FUSE BLOCK (10301-B12); FUSE BLOCK (10305-A1); MIN TIMER RELAY (10313-R3); MODULE (14516); STARTER INTLK RELAY (10313-R2); STOP ARM X-GATE CANCEL (10241); THEFT MATE RED DOT (11642A)
Wires (circuit gauge+color): B117H 18LTGN; B119L 18GY; B120N 18LTGN; B125HA 18GY; B133U 18LTGN; B13A 18PK; B13AZ 18PK; B13LS 18PK; B17C 18LTGN
See also sheets: CH13_15, CH15_25, CH16_13, CH16_25, CH16_26, CH18_05, CH19_40, CH27_68, CH2_24, CH8_15, CH9_04
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.19. IGNITION FEED - ELECTRICAL PANEL (CONT.), P. 19 / CHAPTER 3 IGNITION FEED - ELECTRICAL PANEL (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 96275E 10AUG21 / MJV0488 19NOV21 CIRC B125HA WAS B125H AT FUSE B12-J(10301). / B12-J 17 21 / FUSE BLOCK (10305-A1) A1-B 12 2 A1-D 14 4 A1-E 15 5 / 2 MIN TIMER RELAY (10313-R3) CH8_15,16 THEFT MATE RED DOT (11642A) CH18_05,34 ELEC PANEL/PLATFORM (1702) CH16_25 ELEC PANEL/FR CAP (10000) CH16_13 / B133U 18LTGN B17C 18LTGN / BUZZER RELAY (10310-R4) CH16_26 STOP ARM X-GATE CANCEL (10241) CH9_04 AED VANDAL LOCK RELAY (10312-R6) CH19_40 STARTER INTLK RELAY (10313-R2) CH15_25 / B13A 18PK / FUSE BLOCK (10301-B12) / B125HA 18GY / ELEC PANEL/PLATFORM (1702) CH13_15 NOISE GENERATOR MODULE (14516) CH27_68 / B12-L 19 23 / B120N 18LTGN / B13LS 18PK / B12-M 20 24 / B119L 18GY / B117H 18LTGN / B120N 18LTGN / *B13AZ 18PK / Figure 56 / IGNITION FEED - ELECTRICAL PANEL (CONT.)

3.20. BODY CIRCUIT - NOISE SUPPRESSION, P. 20
Figure 57 BODY CIRCUIT - NOISE SUPPRESSION

Components: B12-G (10301); FUSE B3-J (10304); FUSE B3-T (10304); MD2 RELAY (10316_R2); MSTR DISC SW (10257); NS SW (10264); NS3 RELAY (10315-R1); RELAY (10308-R5); RELAY (10314-R2); RELAY COIL (10369); SPLICE (10335B)
Wires (circuit gauge+color): B11-GAA 18WH; B11-GAB 18WH; B11-GAD 18WH; B11-GAE 18WH; B11-GAF 18WH; B118CH 12BK; B118DE 12BK; B118L 18LTBL; B118LA 18LTBL; B118M 18LTBL; B118N 18LTBL; B12CD 12BK; B12N 18LTBL; B12P 18LTBL; B12S 18LTBL; B12T 18LTBL; B12U 18LTBL; B14 4BK; B14A 6BK; B14B 6BK; B14MD2 8BK; B14NS2 8BK; B14NS3 8BK
See also sheets: CH2_24, CH3_07, CH3_10, CH3_11, CH3_21, CH3_22, CH3_24, CH3_25, CH3_30, CH3_37
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.20. BODY CIRCUIT - NOISE SUPPRESSION, P. 20 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / CHAPTER 3 BODY CIRCUIT - NOISE SUPPRESSION / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 30 NS3 RELAY (10315-R1) / MD2 RELAY (10316_R2) / B14B 6BK B14A 6BK / B14 4BK / FEED STUD (OPWR) / FUSE B12-G (10301) CH3_07 / FUSE B3-J (10304) CH3_25 / B118CH 12BK / FUSE B3-T (10304) CH3_10 / 30 NS2 RELAY (10314-R2) / GROUND SPLICE (10335B) CH3_37 / B11-GAB 18WH / B14MD2 8BK / B118DE 12BK / B14NS3 8BK / B12P 18LTBL / B12CD 12BK / CHILD MONITER RELAY (10308-R5) CH3_22 / B14NS2 8BK / B11-GAD 18WH / B118L 18LTBL / #B12N 18LTBL / B11-GAA 18WH / B11-GAF 18WH / PWR STUD (0PWR) CH3_11 / &B12N 18LTBL / #B118M 18LTBL / #B118N 18LTBL / B12S 18LTBL / @B118N 18LTBL %B12U 18LTBL / NS SW (10264) CH3_21 / ACC SPLICE RELAY COIL (10369) CH3_30 MSTR DISC SW (10257) CH3_24 / GROUND SPLICE (10335B) CH3_37 / B11-GAD 18WH / B118L 18LTBL / @B118M 18LTBL / *B118N 18LTBL *B118M 18LTBL / %B12T 18LTBL / B11-GAE 18WH / B118LA 18LTBL / ACC SPLICE RELAY COIL (10369) CH3_30 / MSTR DISC SW (10257) CH3_24 / & W/MSTR DISC SW W/NS SW # W/NS SW W/LOW VOLTAGE MDL * W/1 ABATMENT ADAPTER % W/MSTR DISC SW N/NS SW @ W/IGN MSTR DISC SW N/NS SW / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 57 / BODY CIRCUIT - NOISE SUPPRESSION

3.21. BODY CIRCUIT - NOISE SUPPRESSION (CONT.), P. 21
Figure 58 BODY CIRCUIT - NOISE SUPPRESSION (CONT.)

Components: A3-G (1016); B9-L (10302); COIL (10369); DISC SW (10257); FUSE B12-K (10301); FUSE B3-B (10304); FUSE B3-G (10304); NS1 RELAY (10314-R1); NS2 RELAY (10314-R2); PLATFORM (1702); REALY COIL (10369); RELAY (10308-R5); RELAY (10315-R2); RELAY (10316-R1); RELAY (10317-R2); RELAY COIL (10369); SPLICE (10335B); SPLICE (11633); SW ILLUM (10366); SWITCH (10264)
Wires (circuit gauge+color): A13AB 18PK; A13DA 18PK; B11-GAA 18WH; B11-GAD 18WH; B11-GAG 16WH; B11-GAH 16WH; B11-GAR 16WH; B11-GAZ 18WH; B118AB 10BK; B118K 10BK; B118L 18LTBL; B118LA 18LTBL; B118M 18LTBL; B118P 16BK; B118P 16LTBL; B118R 16LTBL; B118T 16LTBL; B12AB 12BK; B12M 16LTBL; B12N 18LTBL; B12S 18LTBL; B12T 16LTBL; B12V 16LTBL; B12W 16LTBL; B13AB 16PK; B13DE 12BK; B14 4BK; B14A 6BK; B14B 6BK; B14IGN 8BK; B14MD1 8BK; B14NS1 8BK; B14NS4 8BK; B62-G 18WH; B62-GBF 18WH; B62BF 18DKBL
See also sheets: CH2_24, CH3_05, CH3_08, CH3_10, CH3_18, CH3_20, CH3_22, CH3_24, CH3_25, CH3_30, CH3_37, CH3_38, CH8_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.21. BODY CIRCUIT - NOISE SUPPRESSION (CONT.), P. 21 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 3 BODY CIRCUIT - NOISE SUPPRESSION (CONT.) NOISE SUPPRESSION SWITCH (10264) 2 / MJV0488 19NOV21 CIRC B11-GAZ & B B11-GAR WERE B11-GAH & A11-GAL. / FUSE B3-B (10304) CH3_10 / B11-GAG 16WH / B118AB 10BK / IGNITION RELAY (10317-R2) B13DE 12BK B11-GAR B11-GAZ 16WH 18WH / *B118P 16LTBL / MD1 RELAY (10316-R1) / B14NS4 8BK / &B12S 18LTBL *B118L 18LTBL &B118L 18LTBL B118R 16LTBL &B62-G 18WH B62-GBF 18WH &B62BF 18DKBL / NS4 RELAY (10315-R2) / FUSE B3-G (10304) CH3_25 / B11-GAA 18WH / B14MD1 8BK / B12AB 12BK / B118K 10BK / PRIMARY SW ILLUM (10366) CH8_24 / FUSE B12-K (10301) CH3_18 GROUND SPLICE (10335B) CH3_38 MASTER DISC SW (10257) CH3_24 ACC SPLICE RELAY COIL (10369) CH3_30 / FUSE B9-L (10302) CH3_08 / %B118L 18LTBL / @B12S 18LTBL / CHILD MONITER RELAY (10308-R5) CH3_22 ACC SPLICE RELAY COIL (10369) CH3_30 MASTER DISC SW (10257) CH3_24 *B118R 16LTBL B14A 6BK / B14NS1 8BK / B14 4BK / MASTER DISC SW (10257) CH3_24 ACC SPLICE REALY COIL (10369) CH3_30 / PWR STUD (0PWR) / B14B 6BK / %B118P 16BK @B12V 16LTBL / &B118LA 18LTBL / NOISE ABAT SPLICE (11633) CH3_22 / B12S 18LTBL / &B118T 16LTBL / %B118R 16LTBL 16LTBL @B12W / B11-GAD 18WH / B11-GAH 16WH / &B118P 16LTBL / &B12T 16LTBL B12M 16LTBL #B12T 16LTBL / NS2 RELAY (10314-R2) CH3_20 / A13DA 18PK / FUSE A3-G (1016) CH3_05 / NS1 RELAY (10314-R1) / B12N 18LTBL / Figure 58 / BODY CIRCUIT - NOISE SUPPRESSION (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 99 | printed page 59 | section 3.22
3.22. BODY CIRCUIT - NOISE SUPPRESSION (CONT.), P. 22
Figure 59 BODY CIRCUIT - NOISE SUPPRESSION (CONT.)

Components: ABATMENT (11634); ABATMENT (11635); CONTROLLER (1601); NOISE SUPP SW (10264); NS1 RELAY (10314-R1); NS2 RELAY (10314-R2); PLATFORM/ENG (1702); SUPRESION SW (10264)
Wires (circuit gauge+color): A12AY 18GY; B118-GA 14WH; B118L 18LTBL; B118LA 18LTBL; B118R 16LTBL; B118S 16LTBL; B118T 16LTBL; B12SA 18LTBL
See also sheets: CH3_20, CH3_21
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.22. BODY CIRCUIT - NOISE SUPPRESSION (CONT.), P. 22 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / CHAPTER 3 BODY CIRCUIT - NOISE SUPPRESSION (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / NOISE ABATMENT (11634) / B118R 16LTBL / NOISE SUPRESION SW (10264) CH3_21,94U / NOISE ABATMENT (11635) / B118S 16LTBL / B118T 16LTBL / NOISE ABATMENT SPLICE @(11633) / B118LA 18LTBL / B118L 18LTBL / B118-GA 14WH / GND STUD (31) / CHILD MONITER RELAY 87A #(10308-R5) / NS2 RELAY (10314-R2) CH3_20 NS1 RELAY (10314-R1) CH3_21 / NOISE SUPP SW (10264) CH3_21 / PLATFORM/ENG (1702) 71 B12SA 18LTBL / A12AY 18GY / J4-BLUE BODY CONTROLLER (1601) / @ W/CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK # W/CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK / Figure 59 / BODY CIRCUIT - NOISE SUPPRESSION (CONT.)

3.23. BODY CIRCUIT - NOISE SUPPRESSION (CONT.), P. 23
Figure 60 BODY CIRCUIT - NOISE SUPPRESSION (CONT.)

Components: FR POWER VENT SW (10226); FUSE BLOCK (10301-B12); FUSE BLOCK (10302-B9); FUSE BLOCK (10304-B3); PLATFORM (1702); RADIO (10259); RADIO/PA2 CHANNEL (1301); RR POWER VENT SW (10227); SEALED ENG (11500)
Wires (circuit gauge+color): B132A 12GY; B76A 16LTGN; B76B 16LTGN; B77A 18LTGN; B86A 16LTGN; B86D 16LTGN
See also sheets: CH17_01, CH17_02, CH19_35, CH19_39, CH19_41, CH2_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.23. BODY CIRCUIT - NOISE SUPPRESSION (CONT.), P. 23 / CHAPTER 3 BODY CIRCUIT - NOISE SUPPRESSION (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B12-H 16 12 / B76A 16LTGN / FUSE BLOCK (10301-B12) / ELEC PANEL/ PLATFORM (1702) 36 B86A B86D 16LTGN 16LTGN / FR POWER VENT SW (10226) CH19_41 / B12-X 36 40 / FUSE BLOCK (10304-B3) / B3-R 27 31 / B77A 18LTGN / ELEC PANEL/ SEALED ENG (11500) CH19_39 / B12-V 34 38 / B76B 16LTGN / RR POWER VENT SW (10227) CH19_41 / B86A 16LTGN / RADIO (10259) CH17_02 / FUSE BLOCK (10302-B9) / B9-M 20 24 / B132A 12GY / STEPWEL HTR SW L(10258) CH19_35 / RADIO/PA2 CHANNEL (1301) CH17_01 / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 60 / BODY CIRCUIT - NOISE SUPPRESSION (CONT.)

3.24. BODY CIRCUIT - MASTER DISCONNECT, P. 24
Figure 61 BODY CIRCUIT - MASTER DISCONNECT

Components: DISC SW (10257); FUSE B12-F (10302); FUSE B6-W (10303); FUSE B9-P (10302); MD1 RELAY (10316-R1); MD2 RELAY (10316-R2); MD3 RELAY (10317-R1); NS SW (10264); NS1/NS2 RELAY (10314-R1/R2); RELAY (10318-R1); RELAY (10318-R2); RELAY COIL (10369); SPLICE (10330); SPLICE (10335B)
Wires (circuit gauge+color): B11-GAA 18WH; B11-GAC 16WH; B11-GAJ 18WH; B11-GAK 16WH; B11-GAZ 18WH; B12EF 10BK; B12F 12BK; B12HL 10BK; B12KM 10BK; B12M 16LTBL; B12MD 18LTBL; B12N 18LTBL; B12P 18LTBL; B12R 16LTBL; B12S 18LTBL; B12T 16LTBL; B13BC 16PK; B13BZ 18PK; B13C 16PK; B14 4BK; B14A 6BK; B14AC1 8BK; B14AC2 8BK; B14B 6BK; B14MD3 8BK; B62-GAW 18WH; B62AW 18DKBL
See also sheets: CH2_24, CH3_15, CH3_20, CH3_21, CH3_25, CH3_30, CH3_37, CH3_38, CH8_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.24. BODY CIRCUIT - MASTER DISCONNECT, P. 24 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / CHAPTER 3 BODY CIRCUIT - MASTER DISCONNECT / MJV0488 19NOV21 CIRC B11-GAZ,B13BZ WERE B11-GAH, B13B. / B14MD3 8BK / 30 ACC 1 RELAY (10318-R1) / MASTER DISC SW (10257) 2 / B11-GAK 16WH GROUND SPLICE (10335B) CH3_37 / B12T 16LTBL B12M 16LTBL B62-GAW 18WH B62AW 18DKBL B14 4BK / B12KM 10BK / # W/NS SW W/LOW VTG MDL @ W/NS SW / #B12N 18LTBL B12R 16LTBL B12R 16LTBL / B12HL 10BK / B12S 18LTBL B12N 18LTBL B12P B12N 18LTBL 18LTBL / ACC SPLICE RELAY COIL (10369) CH3_30 NS SW (10264) CH3_21 NS1/NS2 RELAY (10314-R1/R2) CH3_21/20 / B14A 6BK / B12MD 18LTBL @B12S 18LTBL / FUSE B6-W (10303) CH3_25 / B13BC 16PK / PWR STUD (0PWR) / B12EF 10BK / FUSE B12-F (10302) CH3_15 / MD3 RELAY (10317-R1) / B14AC1 8BK / B11-GAA 18WH / B14AC2 8BK / B13C 16PK / ACCESSORY SPLICE RELAY COIL (10369) CH3_30 / FUSE B9-P (10302) CH3_15 / B14B 6BK / SW ILLUM SPLICE (10330) CH8_31 / B13BZ 18PK / B11-GAZ 18WH / B11-GAC 16WH / GROUND SPLICE (10335B) CH3_38 / B11-GAJ 18WH / MD2 RELAY (10316-R2) CH3_20 / MD1 RELAY (10316-R1) CH3_21 / ACCESSORY SPLICE RELAY COIL (10369) CH3_30 / ACC 2 RELAY (10318-R2) / B12F 12BK / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 61 / BODY CIRCUIT - MASTER DISCONNECT

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 102 | printed page 62 | section 3.25
3.25. BODY CIRCUIT - MASTER DISCONNECT (CONT.), P. 25
Figure 62 BODY CIRCUIT - MASTER DISCONNECT (CONT.)

Components: ACCESSORY 2 (10261A); AED RELAY (10312-R3); AIR HORN (10285); AIR HORN (10286); ALARM RELAY (10310-R6); BOOSTER PUMP (10255); CSA MODULE (11627); DESTINATION SIGN (10267A); DOME LT PWR (10201); FOOT SW (8313); FUSE BLOCK (10303-B6); FUSE BLOCK (10304-B3); FUSE BLOCK (10305-A1); HEATED AIR SEAT (10358); HEATED AIR SEAT (10368); HTD MIRROR (10293); HTD MIRROR TIMER (10295); MD1 RELAY (10316-R1); MD2 RELAY (10316-R2); MD3 RELAY (10317-R1); PLATFORM (1702); STEP WARMER RELAY (10305-R1)
Wires (circuit gauge+color): A100A 18GY; B100A 18GY; B105 16LTGN; B105A 16LTGN; B125A 18GY; B125T 18GY; B12A 12BK; B12AB 12BK; B12B 14BK; B12BB 16BK; B12C 12BK; B12CD 12BK; B12D 14BK; B12E 12BK; B12EF 10BK; B12F 12BK; B12RB 14LTGN; B132A 12GY; B134 16OR; B134 16RD; B63A 12DKBL; B74AB 12LTGN; B78A 18LTGN; B78D 18LTGN
See also sheets: CH10_01, CH13_09, CH17_28, CH18_40, CH19_01, CH19_33, CH19_36, CH2_24, CH3_20, CH3_21, CH3_24, CH7_07, CH7_09, CH8_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.25. BODY CIRCUIT - MASTER DISCONNECT (CONT.), P. 25 / CHAPTER 3 BODY CIRCUIT - MASTER DISCONNECT (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC B74AB WAS B74A IN FUSE B3-G(10304). / B105A 16LTGN / FUSE BLOCK (10305-A1) A1-K B12BB 16BK 20 10 / B12C B3-J 12BK 21 17 B3-U B12D 14BK 33 37 / B3-G 11 15 B3-W B12B 14BK 35 39 / FUSE BLOCK (10303-B6) B6-W B12F 12BK 39 35 / BOOSTER PUMP (10255) CH19_01 STEP WARMER RELAY (10305-R1) CH19_33 / B63A 12DKBL / B12RB 14LTGN / B78A 18LTGN / DOME LT PWR (10201) CH8_35 HTD MIRROR (10293) CH10_01 HTD MIRROR TIMER (10295) CH10_01 AED RELAY (10312-R3) CH7_09 DESTINATION SIGN (10267A) CH7_07,08 / B132A 12GY / B74AB 12LTGN / AIR HORN FOOT SW (8313) CH13_09 AIR HORN (10285) CH13_09 AIR HORN (10286) CH13_09 / B100A 18GY FUSE BLOCK (10304-B3) / ELEC PANEL/ PLATFORM (1702) 45 / B100A 18GY / A100A 18GY / B12A 12BK / B12AB 12BK / MD1 RELAY (10316-R1) CH3_21 / B100A 18GY / B3-M B12E 12BK 20 24 / B134 16RD / B78D 18LTGN / B105 16LTGN B125A 18GY B125T 18GY / B12CD 12BK / B12EF 10BK / MD2 RELAY (10316-R2) CH3_20 / MD3 RELAY (10317-R1) CH3_24 / B134 16OR / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 62 / BODY CIRCUIT - MASTER DISCONNECT (CONT.)

3.26. BODY CIRCUIT - MASTER DISCONNECT (CONT.), P. 26
Figure 63 BODY CIRCUIT - MASTER DISCONNECT (CONT.)

Components: ACCESSORY 1 (10260A); AIR SEAT (10391); FR CAP (10000); FUSE BLOCK (10303-B6); FUSE BLOCK (10304-B3); HTD AIR SEAT (10358); PLATFORM (1702); SEON POWER (11643); SEON POWER (11653); STD FR DOME LT (10230); TRACTION CHAIN (10265)
Wires (circuit gauge+color): B105 16LTGN; B105 16WH; B10LA 18WH; B10LB 18WH; B12RA 14LTGN; B13 18PK; B137 16LTBL; B137A 16LTBL; B137B 14LTBL; B138A 16GY; B13K 18PK; B63AM 16DKBL; B86U 14LTGN
See also sheets: CH13_10, CH13_15, CH17_27, CH17_28, CH17_29, CH19_36, CH2_24, CH8_14
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.26. BODY CIRCUIT - MASTER DISCONNECT (CONT.), P. 26 / CHAPTER 3 BODY CIRCUIT - MASTER DISCONNECT (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B6-V 34 38 B6-X 36 40 / STD FR DOME LT (10230) CH8_14 AIR SEAT (10391) CH19_36 SELF CONTAINED HTD AIR SEAT (10358) CH19_36 / B63AM 16DKBL / FUSE BLOCK (10303-B6) / B105 16LTGN / B10LB 18WH / ELEC PANEL/ PLATFORM (1702) CH13_15 / B6-D 4 8 / B10LA 18WH / FUSE BLOCK (10304-B3) B3-H 12 16 / B86U 14LTGN / B12RA 14LTGN / 2 WAY RADIO (+) (10260) CH17_27 / ELEC PANEL/ FR CAP (10000) CH17_27 / B137A 16LTBL B137 16LTBL / B137B 14LTBL / B3-K 18 22 / B86U 14LTGN / VIDEO SYSTEM (+) (10262) CH17_27 / SEON POWER (11643) CH17_29 / B13K 18PK / B138A 16GY / B3-V 34 38 / TRACTION CHAIN (10265) CH13_10 / B105 16WH / ACCESSORY 1 (10260A) CH17_28 / B13 18PK / SEON POWER (11653) CH17_29 / NOTE: REFER SHEETS CH2_24 TO 34 FOR FUSE AND RELAY RATINGS & SPECIFICATIONS. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 63 / BODY CIRCUIT - MASTER DISCONNECT (CONT.)

3.27. N2 COMMUNICATIONS MODULE EFFECTS W/ CUMMINS CONNECTIVITY, P. 27
Figure 64 N2 COMMUNICATIONS MODULE EFFECTS W/ CUMMINS CONNECTIVITY

Components: CONTROLLER (1602); ECM CONN (6022); FUSE A6-C (1014); K BODY (1935F); K BODY (1935M); N2 MODULE (2513); N2 TERM RESISTOR (1939); PLATFORM/ENG (1701)
Wires (circuit gauge+color): A14BA 18RD; A180-G 18WH
See also sheets: CH3_02, CH3_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.27. N2 COMMUNICATIONS MODULE EFFECTS W/ CUMMINS CONNECTIVITY, P. 27 / CHAPTER 3 N2 COMMUNICATIONS MODULE EFFECTS W/CUMMINS CONNECTIVITY / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5N(+) 18YL / J5-TAN BODY CONTROLLER (1602) / J1939 - F5 / J1939 + 6 / J1939 - 2 / A5B(+) A5B(-) 18YL 18GN / J1939 + F6 / N2 MODULE (2513) / A5N(-) 18GN / A5M(+) 18YL / J1939 RESISTOR 250K BODY (1935M) A / A5C(+) 18YL / A5C(-) 18GN / A5M(-) 18GN / 1 GND / A14BA 18RD / A180-G 18WH / A5A(+) 18YL / A5A(-) 18GN / J1939 RESISTOR 250K BODY (1935F) A / GROUND SPLICE PACK #4 (1003) CH3_31 / J1939 + 7 / 3 J1939 - / A5N2A(+) 18YL A5N2A(-) 18GN / PLATFORM/ENG (1701) 24 A5N2B(+) 18YL A5N2B(-) 18GN / N2 TERM RESISTOR (1939) B / A5N2C(-) 20GN / A5N2C(+) 20YL / CUMMINS ECM CONN (6022) 3 J1939 + / KN2(+) 18YL KN2(-) 18GN / 10 J1939 - / OHMS 120 / 120 OHMS / FUSE A6-C (1014) CH3_02 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 64 / N2 COMMUNICATIONS MODULE EFFECTS W/ CUMMINS CONNECTIVITY

3.28. N2 COMMUNICATIONS MODULE EFFECTS W/ 2017 ISB DIESEL & F-2018
Figure 65 N2 COMMUNICATIONS MODULE EFFECTS W/ 2017 ISB DIESEL & F-2018 PROPANE /

Components: CONTROLLER (1602); FUSE F6 (1011); K BODY (1935F); K BODY (1935M); N2 MODULE (2513)
Wires (circuit gauge+color): A14BA 18RD; A180-G 18WH
See also sheets: CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.28. N2 COMMUNICATIONS MODULE EFFECTS W/ 2017 ISB DIESEL & F-2018 PROPANE / GAS ENGINE, P. 27A / CHAPTER 3 N2 COMMUNICATIONS MODULE EFFECTS W/2017-ISB-DIESEL & F-2018 PROP/GAS-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 27MAR21 / MJV0488 10JUN21 INITIAL PRODUCTION RELEASE. / A5N(+) 18YL / J5- TAN BODY CONTROLLER (1602) / J1939 - F5 / J1939 + 6 / 2 J1939 - / A5B(+) A5B(-) 18YL 18GN / J1939 + F6 / N2 MODULE (2513) / A5N(-) 18GN / A5M(+) 18YL / J1939 RESISTOR 250K BODY (1935M) / A5C(+) 18YL / A5C(-) 18GN / A5M(-) 18GN / GND 1 / A14BA 18RD / A180-G 18WH / A5A(+) 18YL / A5A(-) 18GN / J1939 RESISTOR 250K BODY (1935F) A / GROUND SPLICE PACK #4 (1003) CH3_95A / OHMS 120 / OHMS 120 / FUSE F6 (1011) CH3_94 / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 65 / N2 COMMUNICATIONS MODULE EFFECTS W/ 2017 ISB DIESEL & F-2018 PROPANE / GAS ENGINE

3.29. IGNITION SPLICE PACK (5 AMP MAX), P. 28
Figure 66 IGNITION SPLICE PACK (5 AMP MAX)

Components: CANCEL SW (1140); ESPAR CLNT HTR W/TIMER (9996); FUSE A3-G (1016); SWITCH (1137); SWITCH (1139)
Wires (circuit gauge+color): A119M 18GY; A13D 18PK; A13DA 18PK; A74B 18LTGN; A89A 18OR; A89F 18PK
See also sheets: CH19_12, CH3_05, CH6_19, CH6_22, CH9_05
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.29. IGNITION SPLICE PACK (5 AMP MAX), P. 28 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / CHAPTER 3 IGNITION SPLICE PACK (5 AMP MAX) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / IGNITION SPLICE PACK (5AMP MAX) (1014A) A / RED OVERRIDE SWITCH (1139) CH6_22 / A119M 18GY / RH STOP ARM CANCEL SW (1140) CH9_05 / FUSE A3-G (1016) CH3_05 / A13D 18PK / A89A 18OR / A89F 18PK / RH MASTER FLASHER SWITCH (1137) CH6_19 / A74B 18LTGN / ESPAR CLNT HTR W/TIMER (9996) CH19_12 / A13DA 18PK / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 66 / IGNITION SPLICE PACK (5 AMP MAX)

3.30. IGNITION SPLICE PACK W/ 2017 ISB DIESEL & F-2018 PROPANE / GAS-ENGINE, P. 28A
Figure 67 IGNITION SPLICE PACK W/ 2017 ISB DIESEL & F-2018 PROPANE / GAS-ENGINE

Components: CROSSING GATE CANCEL SW (1140); ESPAR CLNT HTR W/TIMER (9996); FIRE SUPPRESSION SYSTEM (1099C); FUSE F14 (1011); IGNITION SPLICE (1014); MASTER FLASHER (1137); SWITCH (1139); WEBASTO CLNT HTR W/TIMER (9997)
Wires (circuit gauge+color): A119M 18GY; A13D 18PK; A144D 16GY; A74B 18LTGN; A74D 18LTGN; A89A 18OR; A89F 18PK
See also sheets: CH19_12, CH19_57, CH6_19, CH6_22, CH9_05
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.30. IGNITION SPLICE PACK W/ 2017 ISB DIESEL & F-2018 PROPANE / GAS-ENGINE, P. 28A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / CHAPTER 3 IGNITION SPLICE PACK W/2017-ISB-DIESEL & F-2018-PROP/GAS-ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / IGNITION SPLICE (1014) A / RED OVERRIDE SWITCH (1139) CH6_22 / A119M 18GY / RIGHT STOP ARM/ CROSSING GATE CANCEL SW (1140) CH9_05 / FIRE SUPPRESSION SYSTEM (1099C) CH13_12A / FUSE F14 (1011) CH3_94B / A13D 18PK / A89A 18OR / A89F 18PK / RIGHT MASTER FLASHER (1137) CH6_19 / @A144D 16GY / @A74B 18LTGN / @A74D 18LTGN / ESPAR CLNT HTR W/TIMER (9996) CH19_12 / WEBASTO CLNT HTR W/TIMER (9997) CH19_57 / @ W/2017-ISB-DIESEL ENG ONLY / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 67 / IGNITION SPLICE PACK W/ 2017 ISB DIESEL & F-2018 PROPANE / GAS-ENGINE

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 108 | printed page 68 | section 3.31
3.31. ACCESSORY SPLICE RELAY COILS, P. 29
Figure 68 ACCESSORY SPLICE RELAY COILS

Components: AED RELAY (10310); AED RELAY (10312-R3); AIR COMPRESSOR RELAY (10308); ALARM RELAY (10310-R6); ELEC PANEL/PLATFORM (1702); FLASHER OVERRIDE (10238); HEATER SW (10228); LIFT SWITCH (10281); MASTER FLASHER (10236); RELAY COIL (10364)
Wires (circuit gauge+color): B12 18LTBL; B120A 16LTBL; B120A 18LTGN; B120B 16LTBL; B120C 16LTBL; B123F 18LTGN; B123J 18LTGN; B12A 18LTBL; B12C 18LTGN; B12W 18LTBL; B12X 18LTBL; B132B 18GY; B62BN 18DKBL
See also sheets: CH15_03, CH16_03, CH16_04, CH16_08, CH19_33, CH19_51, CH3_16, CH6_15, CH6_21
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.31. ACCESSORY SPLICE RELAY COILS, P. 29 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / CHAPTER 3 ACCESSORY SPLICE RELAY COILS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B132B 18GY / ELEC PANEL/PLATFORM (1702) CH16_08,27 / #B12W 18LTBL *B12X 18LTBL / ACCESSORY SPLICE RELAY COIL (10364) A / B123F 18LTGN / B123J 18LTGN / MASTER FLASHER (10236) CH6_15,17 / B12C 18LTGN / FUSE B9-E ##(10302) CH3_16 FUSE F49 %%(10305) CH3_94L / B12A 18LTBL / B62BN 18DKBL %%B12 18LTBL %B120A 18LTGN / @B120A 16LTBL / B120C 16LTBL B120B 16LTBL / AED RELAY (10310) CH16_4A,34 / %%B120A 18LTGN %%B120A 16LTBL / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 68 / ACCESSORY SPLICE RELAY COILS

3.32. ACCESSORY SPLICE RELAY COILS (CONT.), P. 30
Figure 69 ACCESSORY SPLICE RELAY COILS (CONT.)

Components: ACC1 RELAY (10318-R1); ACC2 RELAY (10318-R2); AED VANDAL LOCK RELAY (10312-R6); FUSE A3-V (1016); LIFT INTLK RELAY (10312-R4); LIFT INTLK RELAY (10312-R4,R5); LIFT INTLK RELAY (10312-R5); MD1 RELAY (10316-R1); MD2 RELAY (10316-R2); MD3 RELAY (10317-R1); PLATFORM (1703); RELAY (10311-R6); RELAY 2 (10314-R1); RELAY 2 (10314-R2); RELAY 3 (10315-R1); RELAY 4 (10315-R2); RELAY COILS (10369); SWITCH (10257); SWITCH (10264)
Wires (circuit gauge+color): A12A 16LTBL; A12AA 16LTBL; B118L 18LTBL; B118M 18LTBL; B118N 18LTBL; B118P 16PK; B118R 16LTBL; B123L 18LTGN; B123R 18LTGN; B123T 18LTGN; B12MD 18LTBL; B12N 18LTBL; B12P 18LTBL; B12R 16LTBL; B12S 18LTBL; B12T 16LTBL; B12Y 16LTBL; B12Z 16LTBL; B13 18PK; B13A 18PK; B13B 18PK; B13BC 18PK; B13BZ 18PK; B13C 16PK; B13H 18PK
See also sheets: CH03_20, CH03_21, CH06_16, CH06_17, CH15_01, CH15_06, CH16_05, CH16_14, CH3_03, CH3_20, CH3_21, CH3_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.32. ACCESSORY SPLICE RELAY COILS (CONT.), P. 30 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / CHAPTER 3 ACCESSORY SPLICE RELAY COILS (CONT.) ELEC PANEL/ PLATFORM (1703) A12AA 16LTBL A2 A12A 16LTBL / MJV0488 19NOV21 CIRC B13BZ WAS B13B IN CAV C AT R/D 10369. / ACCESSORY SPLICE RELAY COILS (10369) A / B118L 18LTBL / B12MD 18LTBL / B12Y 16LTBL @B13 18PK %B13 18PK / B13BZ 18PK / B12N 18LTBL / *B13 18PK / #B123L 18LTGN / FLASHER SYSTEM RELAY (10311-R6) CH06_16,17, CH16_05 / B13H 18PK / B123R 18LTGN / B13A 18PK B13B 18PK / B13C 16PK B13BC 18PK / B12P 18LTBL B12T 16LTBL B12R 16LTBL / B12S 18LTBL / B118M 18LTBL / B118N 18LTBL B118P 16PK / B118R 16LTBL / B123T 18LTGN / B12Z 16LTBL / Figure 69 / ACCESSORY SPLICE RELAY COILS (CONT.)

3.33. ACCESSORY SPLICE RELAY COILS (CONT.), P. 30A
Figure 70 ACCESSORY SPLICE RELAY COILS (CONT.)

Components: ACCESSORY RELAY 1 (10322); AED VANDAL LOCK RELAY (10310); FLASHER SYSTEM RELAY (10311); FUSE F11 (1011); LIFT INTERLOCK RELAY (10312); PLATFORM (1703); RELAY (10311); RELAY 1 (10314); RELAY 1 (10318); RELAY COILS (10369); SWITCH (10257); SWITCH (10264); WEBASTO (11630)
Wires (circuit gauge+color): A12A 16LTBL; B118L 18LTBL; B123L 18LTGN; B12MD 18LTBL; B12N 18LTBL; B12S 18LTBL; B12Y 16LTBL; B12Z 16LTBL; B13 18PK; B13B 18PK; B13H 18PK; B74L 18PK
See also sheets: CH15_34, CH16_35, CH19_61, CH6_23, CH6_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.33. ACCESSORY SPLICE RELAY COILS (CONT.), P. 30A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / CHAPTER 3 ACCESSORY SPLICE RELAY COILS (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ACCESSORY SPLICE RELAY COILS (10369) A / MASTER DISCONNECT RELAY 1 (10318) CH3_94S / B118L 18LTBL / B12MD 18LTBL / NOISE SUPPRESSION RELAY 1 (10314) CH3_94U / LIFT INTERLOCK RELAY (10312) CH15_34 / B12Y 16LTBL / B13B 18PK / B12N 18LTBL / MASTER DISCONNECT SWITCH (10257) CH3_94S / ACCESSORY RELAY 1 (10322) CH3_94R / B13 B13 18PK 18PK / NOISE SUPPRESSION SWITCH (10264) CH3_94U / B12S 18LTBL / B74L 18PK / 7-DAY TIMER WEBASTO (11630) CH19_61 FLASHER SYSTEM RELAY (10311) CH6_23,24 FLASHER SYSTEM RELAY (10311) CH6_24 AED VANDAL LOCK RELAY (10310) CH16_35 / ELEC PANEL/ PLATFORM (1703) A2 / A12A 16LTBL / FUSE F11 (1011) CH3_94A LIFT INTERLOCK RELAY (10312) CH15_34,35 / B123L 18LTGN / B13H 18PK B12Z 16LTBL / B13 18PK / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 70 / ACCESSORY SPLICE RELAY COILS (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 111 | printed page 71 | section 3.34
3.34. BODY GROUND PLATFORM, P. 31
Figure 71 BODY GROUND PLATFORM

Components: AIR PARK BRAKE CCM (9556); CLUSTER WARNING LIGHTS (1555); DIGITAL LED CLOCK (4500); ENGINE COMPARTMENT INDICATOR (1062); J6-18WAY BODY CONTROLLER (1606); JOMARR FIRE SUPPR INDICATIONS (1099A); N2 MODULE (2513); PLATFORM/ELEC PANEL (1702); PLATFORM/ENGINE (1701); PROTECTION RELAY (1010-R2); SPLICE PACK GROUND (4037Z); SPLICE PACK GROUND (4037ZC); STEPWELL HEATER (1913); VANDAL LOCK STARTER INTERLOCK (1146B); WEBASTO SMART TIMER (8331); ZONAR V3 PREWIRE (1349)
Wires (circuit gauge+color): A101-G 16WH; A10LS 18WH; A11-G 12WH; A11-GA 12WH; A11-GTS 20WH; A132A-G 14WH; A133-GA 16WH; A144-GA 18WH; A17CC 18WH; A180-G 18WH; A26-G 18WH; A41A-G 18WH; A44-G 16WH; A62-GL 18WH; A74-G 16WH; A74-GA 16WH; A88-G 18WH; A94-GE 18WH
See also sheets: CH13_12, CH13_15, CH13_56, CH13_60, CH16_19, CH17_31, CH18_39, CH19_17, CH19_18, CH19_35, CH3_27, CH4_01, CH5_04, CH5_09, CH7_43, CH8_27
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.34. BODY GROUND PLATFORM, P. 31 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / CHAPTER 3 / BODY GROUND - PLATFORM / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / VANDAL LOCK STARTER INTERLOCK (1146B) CH16_19 AMMETER PANEL LIGHT (52) CH8_27 / AIR PARK BRAKE CCM (9556) CH18_39 CLUSTER WARNING LIGHTS (1555) CH13_56 WEBASTO SMART TIMER (8331) CH19_18 CH19_17,20 STEPWELL HEATER (1913) CH19_35 / GROUND SPLICE #2 (1004) A / A62-GL 18WH A26-G 18WH A41A-G 18WH A11-GTS 20WH / AMMETER PANNEL LT (52) CH8_27 PLATFORM/ENGINE (1701) CH5_09 ENGINE COMPARTMENT INDICATOR (1062) CH5_04 ZONAR V3 PREWIRE (1349) CH17_31 / GROUND SPLICE PACK #4 (1003) / A11-GA 12WH / A10LS 18WH A101-G 16WH A44-G 16WH A94-GE 18WH A74-G 16WH A74-GA 16WH A132A-G 14WH A133-GA 16WH A62-GL 18WH / A88-G 18WH A11-G 12WH / SPLICE PACK GROUND (4037ZC) / A144-GA 18WH / JOMARR FIRE SUPPR INDICATIONS (1099A) CH13_12 THERMAL OVER CRANK PROTECTION RELAY (1010-R2) CH4_01 / A17CC 18WH / N2 MODULE (2513) CH3_27 PLATFORM/ELEC PANEL (1702) CH13_15 J6-18WAY BODY CONTROLLER (1606) CH13_60 / A180-G 18WH / DIGITAL LED CLOCK (4500) CH7_43 / SPLICE PACK GROUND (4037Z) / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 71 / BODY GROUND PLATFORM

3.35. BODY GROUND PLATFORM (CONT.), P. 32
Figure 72 BODY GROUND PLATFORM (CONT.)

Components: AUTO XMSN PANEL LT (1501); CLOCK SPRING (1832); CLUSTER WARNING LT (1555); DEFOG FAN SW (1135); DEFOG FAN SW (1135A); DEFOG FAN SW (1136); DEFOG FAN SW (1136A); ECONOMY MODE RELAY (1012-R5); GROUND SPLICE (1003A); NEXT GEN PARK BRAKE SW FOR WHEELCHAIR (9267A); PARK BRAKE SW (1105M); PLATFORM (1700); RADIO/PA-2 CHANNEL (1301); SHIFT SELECTOR (1850); STUD (4037A); SW AND PANEL LT (1830); VANDAL LOCK KEYSW (1146); VANDAL SOLENOID (1147); WIPER MOTER (4046)
Wires (circuit gauge+color): A11-GE 20WH; A11-GH 12WH; A11-GZ 8WH; A133-G 18WH; A133B-G 18WH; A62-GC 18WH; A62-GE 18WH; A62E-G 18WH; A62F-G 18WH; A62G-G 18WH; A82-GA 16WH; A86-G 18WH; A90-G 18WH; A90B-G 18WH; A90C-G 18WH; A90D-G 18WH; A92-G 18WH; A94-GE 18WH
See also sheets: CH12_01, CH12_03, CH12_04, CH13_06, CH13_34, CH13_56, CH13_57, CH16_15, CH16_20, CH17_01, CH19_26, CH19_27, CH8_51
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.35. BODY GROUND PLATFORM (CONT.), P. 32 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. GROUND SPLICE (1003A) A / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / CHAPTER 3 BODY GROUND - PLATFORM (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A82-GA 16WH / A11-GZ 8WH WIPER MOTER (4046) CH13_06 SHIFT SELECTOR (1850) CH12_03 / A62-GC 18WH A86-G 18WH / *A62E-G 18WH #A62F-G 18WH %%A62E-G 18WH / %A92-G 18WH A11-GE 20WH / A62-GE 18WH / @A#169A 18GY / **A90D-G 18WH / A133B-G 18WH / L HAND DEFOG FAN SW (1135A) CH19_27 R HAND DEFOG FAN SW (1136) CH19_27 / A133-G 18WH / BODY GROUND STUD (4037A) / A11-GH 12WH / #A62G-G 18WH / #A62E-G 18WH / FWD CHASSIS/ PLATFORM (1700) CH13_34 HYDRAULIC PARK BRAKE SW (1105M) CH13_34 / **A90B-G 18WH / **A90C-G 18WH / ##A94-GE 18WH / &&A90-G 18WH / CLUSTER WARNING LT (1555) CH13_56 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 72 / BODY GROUND PLATFORM (CONT.)

3.36. BODY GROUND PLATFORM (CONT.), P. 33
Figure 73 BODY GROUND PLATFORM (CONT.)

Components: AIR PARK BRAKE SOLENOID (1012A-B); CONTROLRELAY (1010-R4); DAY TIMER (9996); ESPAR MULTI MAX TIMER (1053); GROUND SPLICE (1003B); INDICATORS (1060); INDICATORS (1060A); INTRLINK RELAY (1010-R5); PLATFORM/ELEC PANEL (1703); PLATFORM/ENG (1701); REGEN SW (9266); STARTER ALTERNATOR FUEL RELAY (1015-R1); STUD (4037ZD)
Wires (circuit gauge+color): A10-GA 18WH; A11-GG 12WH; A11-GL 18WH; A44-GB 18WH; A44-GC 18WH; A44-GD 18WH; A44C-G 18WH; A74-GA 16WH; A74-GA 18WH; A74-GB 18WH; A74-GC 18WH; A77A 18WH; A77B 18WH; A77H 18WH; A89RK-G 18WH
See also sheets: CH11_19, CH13_20, CH13_54, CH15_08, CH15_11, CH19_12, CH19_13, CH4_03, CH6_10, CH6_11
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.36. BODY GROUND PLATFORM (CONT.), P. 33 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / CHAPTER 3 BODY GROUND - PLATFORM (CONT.) / MJV0488 19NOV21 ADDED CIRC A77H IN CAV F. / RED/AMBER INDICATORS (1060) CH6_10 RED/AMBER INDICATORS (1060A) CH6_11 / A89RK-G 18WH / A11-GG 12WH / BODY GROUND STUD (4037ZD) / GROUND SPLICE (1003B) / A89RK-G 18WH / A44C-G 18WH / A10-GA 18WH / PLATFORM/ELEC PANEL (1703) CH15_08,09,11 STARTER ALTERNATOR FUEL RELAY (1015-R1) CH4_03,04 / %A44C-G 18WH / PLATFORM/ENG (1701) CH13_54,CH15_08,09 / &A44-GC 18WH / #A74-GC 18WH / *A74-GA 16WH / @A44-GC 18WH A11-GL 18WH A77A 18WH A77B 18WH #A74-GA 18WH #A74-GB 18WH / &A44-GD 18WH / &A44-GB 18WH / AIR PARK BRAKE SOLENOID (1012A-B) CH15_11 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / A77H 18WH / Figure 73 / BODY GROUND PLATFORM (CONT.)

3.37. BODY GROUND ELECTRICAL PANEL, P. 34
Figure 74 BODY GROUND ELECTRICAL PANEL

Components: ALARM RELAY (10310-R6); CHILD MONITOR (11642-2); CROSSING GATE (10219A); CROSSING GATE (10219B); DRIVER DOME LT (10207); ELEC COMPARTMENT LT (10341); GROUND (1090); GROUND SPLICE (10334); HEATED MIRROR (10295); LT DROP (11646); PTI CONTROL RELAY (10309-R6); REAR STOP ARM (10475B/10475A); STOP ARM (10221); STOP ARM RELAY (10310-R1); STOP ARM SOLENOID (10219); STROBE LT INDICATOR (10395); TEMP SENSOR RELAY (10310-R3)
Wires (circuit gauge+color): B11-GAP 12WH; B119-GB 18WH; B119-GC 18WH; B119-GE 16WH; B119-GN 16WH; B119-GN 18WH; B11GD 16WH; B11GE 18WH; B11GF 16WH; B127-GA 16WH; B128-G 16WH; B136-GA 16WH; B63-GA 16WH; B63-GAB 16WH; B63-GAC 14WH; B63-GAD 14WH; B78-GE 18WH; B89G 16WH; B89GA 16WH; B89GG 16WH
See also sheets: CH10_01, CH18_25, CH18_26, CH6_09, CH6_11, CH7_17, CH8_04, CH8_11, CH8_12, CH9_01, CH9_02, CH9_06, CH9_07, CH9_08
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.37. BODY GROUND ELECTRICAL PANEL, P. 34 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. GROUND SPLICE (10334) A / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / CHAPTER 3 BODY GROUND - ELECTRICAL PANEL / MJV0488 19NOV21 CIRC B11-GAP WAS B11-GA IN CAV A. / B119-GE 16WH %B119-GN 16WH / *%B136-GA 16WH *&B63-GA 16WH B128-G 16WH / B78-GE 18WH / B11-GAP 12WH B127-GA 16WH / #B119-GB 18WH / &B119-GC 18WH / GROUND (17) / **B63-GAB 16WH ##B63-GAC 14WH / DRIVER DOME LT (10207) CH8_11 / *B89GG 16WH / *B89G 16WH / *B89GA 16WH / @B119-GN 18WH / B63-GAB 16WH B63-GAD 14WH / B11GF 16WH / B11GE 18WH / B11GD 16WH / Figure 74 / BODY GROUND ELECTRICAL PANEL

3.38. BODY GROUND ELECTRICAL PANEL (CONT.), P. 35
Figure 75 BODY GROUND ELECTRICAL PANEL (CONT.)

Components: AC RELAY (10308-R4); BOOSTER PUMP RELAY (10311-R4); BOOSTER PUMP RELAY (10311-R5); CL LT RELAY (10308-R1); COOLANT HTR PUSH BUTTON (11631); ELEC PANEL/PLATFORM (1703); ESPAR MULTIMAX TIMER PREWIRE (1053); GROUND SPLICE (10335A); STEP WARMER RELAY (10305-R1); TIMER GROUND (11620); TIMER GROUND (11625)
Wires (circuit gauge+color): B11-GBY 16WH; B132-GC 18WH; B58-GF 18WH; B74-G 16WH; B74-G 18WH; B74-GA 16WH; B74-GA 18WH; B74-GB 14WH; B74-GB 16WH; B74-GB 18WH; B74-GC 16WH; B74-GC 18WH; B74-GF 18WH; B74-GT 16WH; B74E 18LTGN; B74F-G 18WH; B74N-G 14WH; B74R-G 18WH; B74T-G 18WH; B77-G 18WH
See also sheets: CH19_01, CH19_02, CH19_04, CH19_05, CH19_06, CH19_08, CH19_09, CH19_17, CH19_33, CH19_38, CH7_66
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.38. BODY GROUND ELECTRICAL PANEL (CONT.), P. 35 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / CHAPTER 3 BODY GROUND - ELECTRICAL PANEL (CONT.) / MJV0488 19NOV21 CIRC B11-GBY WAS B11-GB IN CAV A. / B11-GBY 16WH B58-GF 18WH B77-G 18WH B74-GB 18WH / GROUND SPLICE (10335A) A B C / CL LT RELAY (10308-R1) CH7_66 AC RELAY (10308-R4) CH19_38 BOOSTER PUMP RELAY (10311-R5) CH19_09 / B132-GC 18WH / OGND (18) / B74-G 18WH / B74-GA 18WH / B74E 18LTGN B74-GT 16WH B74-G 16WH / B74-G 18WH / B74F-G 18WH B74R-G 18WH B74-GC 18WH B74-GA 18WH B74-GB 18WH B74F-G 18WH B74T-G 18WH B74-GA 16WH / B74-GF 18WH B74-GC 18WH / B74-GA 16WH B74-GB 16WH B74N-G 14WH B74-GC 16WH / B74-GB 14WH / B74-GB 18WH / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / B74-G 18WH / B74-G 18WH / Figure 75 / BODY GROUND ELECTRICAL PANEL (CONT.)

3.39. BODY GROUND ELECTRICAL PANEL (CONT.), P. 36
Figure 76 BODY GROUND ELECTRICAL PANEL (CONT.)

Components: DOME LT TIMER REALY (10397); DOME LT TIMER RELAY (10397-85); ELEC PANEL/L BODY (10401A/B); ELEC PANEL/PLATFORM (1702/1702); FLASH LT INDICATOR (10371); FR DOME LT RELAY (10311-R3); GROUND SPLICE (10335A); INCH LIFT INDICATOR (1051); INCH LIFT INDICATOR (9555); LIFT INTERLOCK RELAY (10312-R4); LIFT INTERLOCK RELAY (10312-R4,R5); LIFT INTERLOCK RELAY (10312-R5); REAR ROW DOME LT RELAY (10311-R1); RR DOME LT RELAY (10311-R2); RR DOME LT RELAY (10311-R3); RR ROW DOME LT RELAY (10311-R1)
Wires (circuit gauge+color): A122B 18GY; A122B-G 16WH; B11-G 16WH; B11-G 18WH; B11-GA 16WH; B11-GA 18WH; B11-GB 16WH; B11-GB 18WH; B11-GC 16WH; B11-GD 16WH; B11-GJ 16WH; B122 18GY; B122-G 18WH; B122-GA 18WH; B122-GB 18WH; B122P 18PK; B13A 18PK; B63-G 16WH; B63-GA 16WH; B63-GB 16WH; B63-GE 14WH; B63-GF 16WH
See also sheets: CH15_01, CH15_06, CH5_05, CH8_14, CH8_15, CH8_16, CH8_17, CH8_18, CH8_20, CH8_21
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.39. BODY GROUND ELECTRICAL PANEL (CONT.), P. 36 / CHAPTER 3 BODY GROUND - ELECTRICAL PANEL (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B122 18GY / B122-GB 18WH / B11-G 18WH / A122B 18GY A122B-G 16WH / ELEC PANEL/PLATFORM (1702/1702) 15 / B11-GD 16WH / B63-G 16WH B63-GB 16WH / B63-GE 14WH B63-GF 16WH B63-GA 16WH B11-GA 16WH B11-GC 16WH B11-GD 16WH B11-G 16WH B11-GA 16WH / GROUND SPLICE (10335A) F / B11-GA 18WH B11-GB 18WH B11-GC 16WH B11-GJ 16WH B11-GB 16WH B11-GA 16WH B11-GA 18WH B11-G 18WH / B11-GB 18WH / B122-G 18WH B122-G 18WH / B122-G 18WH B122-GA 18WH / B13A 18PK B122P 18PK / B11-GB 16WH / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / B11-GB 16WH / Figure 76 / BODY GROUND ELECTRICAL PANEL (CONT.)

3.40. BODY GROUND ELECTRICAL PANEL (CONT.), P. 37
Figure 77 BODY GROUND ELECTRICAL PANEL (CONT.)

Components: AMBER CANCEL (11760); AMBER CANCEL (11770); BUZZER RELAY (10310-R4); DOOR CONTROL RELAY (10309-R1); DOOR CONTROL RELAY 2 (10309-R2); DOOR LT RELAY (10309-R1); DOOR SW OPEN SIGNAL (11600C); GROUND SPLICE (10335B); MD1 RELAY (10316-R1); MD2 RELAY (10316-R2); MD3 RELAY (10317-R1); NS1 RELAY (10314-R1); NS2 RELAY (10314-R2); NS3 RELAY (10315-R1); NS4 RELAY (10315-R2); STEP LT RELAY (10309-R3)
Wires (circuit gauge+color): B11-G 18WH; B11-GAA 18WH; B11-GAB 18WH; B11-GAC 16WH; B11-GAD 16WH; B11-GAD 18WH; B11-GAE 18WH; B11-GAF 18WH; B11-GAG 16WH; B11-GAH 16WH; B11-GK 16WH; B117-GL 18WH; B120-G 18WH; B120-GK 18WH; B120-GL 18WH; B120-GM 18WH; B120-GS 18WH; B120-GT 18WH; B120-GW 18WH
See also sheets: CH16_03, CH16_04, CH16_05, CH16_08, CH16_09, CH16_11, CH16_12, CH16_26, CH3_20, CH3_21, CH3_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.40. BODY GROUND ELECTRICAL PANEL (CONT.), P. 37 / CHAPTER 3 BODY GROUND - ELECTRICAL PANEL (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. GROUND SPLICE (10335B) A / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B120-GK 18WH / B117-GL 18WH B120-G 18WH B11-G 18WH B120-G 18WH B11-GAA 18WH / B11-GK 16WH / 0GND (18) / B11-GAB 18WH B11-GAC 16WH B11-GAD 16WH / B120-GS 18WH B120-GL 18WH B120-GT 18WH B120-GW 18WH B120-GS 18WH B120-GL 18WH B120-GM 18WH / B11-GAD 18WH / B11-GAE 18WH B11-GAH 16WH / B11-GAF 18WH B11-GAG 16WH / NS3 RELAY (10315-R1) CH3_20 NS4 RELAY (10315-R2) CH3_21 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 77 / BODY GROUND ELECTRICAL PANEL (CONT.)

3.41. BODY GROUND ELECTRICAL PANEL (CONT.), P. 38
Figure 78 BODY GROUND ELECTRICAL PANEL (CONT.)

Components: ACC1 RELAY (10318-R1); ACC2 RELAY (10318-R2); CCM/TM GND SPLICE BLOCK (11502); CHECK MATE MODULE (10212); ELEC PANEL/L BODY (10401A/B); ENG TEMP SENSOR RELAY (10310-R3); FR DOME LT RELAY (10311-R3); IGN RELAY (10317-R2); REAR DOME LT REALY (10311-R2); SPLICE (10335B); THEFT MATE RED DOT (11642A)
Wires (circuit gauge+color): B11-GAJ 18WH; B11-GAK 16WH; B11-GAR 16WH; B11-GAZ 18WH; B125-G 18WH; B125-GK 18WH; B125-GL 18WH; B125-GM 18WH; B125A 18GY; B125B 18GY; B41-GC 18WH
See also sheets: CH18_01, CH18_04, CH18_05, CH18_13, CH18_32, CH18_37, CH3_21, CH3_24, CH5_04
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.41. BODY GROUND ELECTRICAL PANEL (CONT.), P. 38 / CHAPTER 3 BODY GROUND - ELECTRICAL PANEL (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC B11-GAZ & B B11-GAR WERE B11-GAH & A11-GAL. / B11-GAZ 18WH / B41-GC 18WH B125-GL 18WH / B125-G 18WH / CCM/TM GND SPLICE BLOCK (11502) CH18_32 CHECK MATE MODULE (10212) CH18_13 / B125-G B125-G 18WH 18WH / ELEC PANEL/L BODY (10401A/B) CH18_01 ELEC PANEL/L BODY (10401A/B) CH18_37 / *B125B 18GY / * W/PTI-CRS & W/PTI-LEAVE NO STUDENT BEHIND / &B125A 18GY / B125-G 18WH / THEFT MATE RED DOT (11642A) CH18_05 / B125-GM 18WH / B125-GK 18WH / B11-GAK 16WH / B11-GAJ 18WH / B11-GAR 16WH / REAR DOME LT REALY (10311-R2) CH18_04 / GROUND SPLICE (10335B) / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 78 / BODY GROUND ELECTRICAL PANEL (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 119 | printed page 79 | section 3.42
3.42. BODY GROUND ELECTRICAL PANEL (CONT.), P. 39
Figure 79 BODY GROUND ELECTRICAL PANEL (CONT.)

Components: AIR SEAT (10391); CA 2018 CHECKMATE (10339); CA 2018 CHECKMATE (11339); CHILD CHECK RELAY (10313-R4); CHILD CHECKMATE RELAY (10310-R2); CHILD MONITOR (11642); CHILD MONITOR RELAY (10308-R5); COM/TM GND SPLICE BLOCK (11502); GROUND SPLICE (10336); HEATED AIR SEAT (10358); HEATED AIR SEAT (10368); INPOWER HAZARD ASSERT (11338); INPOWER HAZZARD ASSERT (11338); PTI RELAY (10309-R4); PTI RELAY (10309-R5); PTI RELAY (10309-R6); REAR ROW DOME LT RELAY (10311-R1); THEFTMATE RED DOT (11642A); TWO MIN TIMER NC RELAY (11303)
Wires (circuit gauge+color): B105-G 16WH; B11-GCX 10WH; B11GA 16WH; B11GB 16WH; B11GC 16WH; B11GCC 16WH; B12-G 18WH; B125-G 18WH; B125-GA 10WH; B125-GA 14WH; B125-GA 16WH; B125-GD 18WH; B125-GE 14WH; B125-GE 18WH; B125-GL 14WH; B125-GM 18WH; B53-GHA 18WH; B53-GHB 18WH; B53B-G 18WH; B53C-G 18WH; B60-G 16WH; B60-G 18WH; B85-GH 18WH; B85A-G 18WH
See also sheets: CH18_01, CH18_09, CH18_10, CH18_11, CH18_16, CH18_17, CH18_18, CH18_22, CH18_23, CH18_25, CH18_32, CH19_36, CH8_10
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.42. BODY GROUND ELECTRICAL PANEL (CONT.), P. 39 / CHAPTER 3 BODY GROUND - ELECTRICAL PANEL (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. GROUND SPLICE (10336) A / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC B11-GCX WAS B11-GC IN CAV A. / B105-G 16WH B125-GD 18WH B125-GA 16WH / 0GND (10) / B11-GCX 10WH / B105-G 16WH / B105-G 16WH / B125-GA 16WH / B125-GA 14WH / B125-GA 10WH / B11GA 16WH / REAR ROW DOME LT RELAY (10311-R1) CH18_25 / Figure 79 / BODY GROUND ELECTRICAL PANEL (CONT.)

3.43. BODY GROUND ELECTRICAL PANEL (CONT.), P. 40
Figure 80 BODY GROUND ELECTRICAL PANEL (CONT.)

Components: AED RELAY (10312-R3); AED RELAY (11312-R3); AED VANDAL LOCK RELAY (10312-R6); CHILD SAFETY ALARM MODULE (11627); CHILD SAFETY ALARM RELAY (10310-R5); CROSSING GATE RELAY (10313-R1); ELEC PANEL/SEALED ENGINE (11500); FLASHER SYSTEM RELAY (10312-R2); MASTER WARN CANCEL (10236A); OVER HEAD LOCKING COMPARTMENT (10398); PARK BRAKE RELAY (10308-R6); PEDESTRIAN LIGHT RELAY (10282); SPLICE (10336); TEMP SENSOR RELAY (11310-R3)
Wires (circuit gauge+color): B119-G 16WH; B120-GD 18WH; B120-GE 18WH; B120-GF 18WH; B120-GG 18WH; B120-GK 18WH; B123-GK 18WH; B125-GS 18WH; B125-GT 18WH; B125-GU 18WH; B125-GV 18WH; B125-GW 18WH; B125U-G 18WH; B133-GR 18WH; B134-G 16WH; B139-G 16WH; B44-G 18WH; B44-GA 18WH; B44-GB 18WH
See also sheets: CH13_04, CH16_23, CH18_40, CH19_40, CH6_16, CH6_17, CH7_09, CH7_62, CH9_06
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.43. BODY GROUND ELECTRICAL PANEL (CONT.), P. 40 / CHAPTER 3 BODY GROUND - ELECTRICAL PANEL (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B133-GR 18WH B44-G 18WH / B119-G 16WH B139-G 16WH / B125-GS 18WH / OVER HEAD LOCKING COMPARTMENT (10398) CH19_40 / CHILD SAFETY ALARM RELAY (10310-R5) CH18_40 / B120-GD 18WH / B134-G 16WH B123-GK 18WH B123-GK 18WH B125U-G 18WH / B125-GT 18WH B125-GU 18WH / B44-GA 18WH B44-GB 18WH / B120-GG 18WH / B120-GF 18WH B120-GE 18WH / B120-GK 18WH / GROUND SPLICE (10336) / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 80 / BODY GROUND ELECTRICAL PANEL (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 121 | printed page 81 | section 3.44
3.44. BODY GROUND ELECTRICAL PANEL (CONT.), P. 41
Figure 81 BODY GROUND ELECTRICAL PANEL (CONT.)

Components: AIR HORN (10285); AIR HORN PULL SW (10287); DIMMER UNIT (10372); DOOR CONTROL (10047); FIRE SUPPRESION SYSTEM (10383); FIRE SUPPRESION SYSTEM (10385); FR CAP (10000); GROUND SPLICE (10337); INPOWER STROBE MODULE (10500); MIRROR SW (10353/10354); PRIMARY SW ILLUM (10336); RADIO (10259); STROBE LT LATCH RELAY (10300); STROBE LT RELAY (10308-R2); TEMP SENSOR BUZZER (10390)
Wires (circuit gauge+color): B100-G 16GY; B100-G 18WH; B11-GDM 12WH; B120-GC 18WH; B127-G 16WH; B144-G 18WH; B144-GA 18WH; B144-GF 18WH; B144-GG 18WH; B41-GK 18WH; B62-G 18WH; B62-GAN 18WH; B78-G 18WH; B78-GC 20WH; B78-GD 20WH; B86-G 16WH; C120-G 16WH
See also sheets: CH10_02, CH13_09, CH13_12, CH16_09, CH17_02, CH5_04, CH7_12, CH7_13, CH7_14, CH8_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.44. BODY GROUND ELECTRICAL PANEL (CONT.), P. 41 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / CHAPTER 3 BODY GROUND - ELECTRICAL PANEL (CONT.) / MJV0488 19NOV21 CIRC B11-GDM WAS B11-GD IN CAV A. / B41-GK 18WH / B86-G 16WH B62-GAN 18WH / B11-GDM 12WH B100-G 18WH / GROUND SPLICE (10337) / AIR HORN (10285) CH13_09 AIR HORN PULL SW (10287) CH13_09 FIRE SUPPRESION SYSTEM (10385) CH13_12 FIRE SUPPRESION SYSTEM (10383) CH13_12 / B144-G 18WH / B127-G 16WH B127-G 16WH / 0GND (17) / B78-GC 20WH B78-GD 20WH / B62-G 18WH / ENG COMPARTMENT TEMP SENSOR BUZZER (10390) CH5_04 / B120-GC 18WH / ELEC PANEL/ FR CAP (10000) B1 / C120-G 16WH / FR CAP/ ENTRANCE DOOR CONTROL (10047) CH16_09,10,11 / MIRROR SW (10353/10354) CH10_02 / B78-G 18WH / B127-G 16WH / B100-G 16GY / B144-GF 18WH B144-GA 18WH B144-GG 18WH / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 81 / BODY GROUND ELECTRICAL PANEL (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 122 | printed page 82 | section 3.45
3.45. BODY GROUND ELECTRICAL PANEL (CONT.), P. 42
Figure 82 BODY GROUND ELECTRICAL PANEL (CONT.)

Components: DC POWER (10375A); DC POWER OUTLET 10 SW PANEL (10375B); DC POWER SOURCE (10375); DRIVERS FAN (10284); ELEC PANEL/FR CAP (10000); SPLICE PACK (10360B)
Wires (circuit gauge+color): B76-G 14WH; B76-GA 14WH; B76-GC 14WH; B76-GD 14WH; B76-GE 14WH; B76-GF 14WH; B76D-G 14WH; B84-G 16WH; B84-GA 18WH; B84-GB 16WH
See also sheets: CH19_28, CH19_29, CH19_31, CH3_67
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.45. BODY GROUND ELECTRICAL PANEL (CONT.), P. 42 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / CHAPTER 3 BODY GROUND - ELECTRICAL PANEL (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B84-GA 18WH B84-G 16WH B84-G 16WH B84-GB 16WH B76-GC 14WH B76-GA 14WH B76-GC 14WH / B76-GD 14WH B76D-G 14WH / 0 GND SPLICE PACK (10360B) / DC POWER SOURCE (10375) CH3_67 DC POWER OUTLET 10 SW PANEL (10375B) CH3_67 DC POWER (10375A) CH3_67 / ELEC PANEL/FR CAP (10000) CH19_29,30 / B76-GE 14WH B76-GF 14WH / DRIVERS FAN (10284) CH19_28 ELEC PANEL/FR CAP (10000) CH19_31,32 DRIVERS FAN (10284) CH19_28 / B76-G 14WH / 0GND (13) / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 82 / BODY GROUND ELECTRICAL PANEL (CONT.)

3.46. BODY GROUND FRONT CAP, P. 43
Figure 83 BODY GROUND FRONT CAP

Components: CAMERA (10035); COMPT (10039); CONNECTOR (1979B2); DRIVERS DOME LT (10072); DUMP VALVE (10041); ELEC PANEL (10000); GROUND CIRCUIT (10009); L AMBER RED WARN LT (10075); L RED WARN LT (10076); R AMBER WARN LT (10077); R RED WARN LT (10078); SAFETY COMPT (10050); STARTER INTERLOCK (10043); STARTER INTERLOCK (11143); VANDAL LOCK SW (10086)
Wires (circuit gauge+color): B11-GF 12WH; C11-GA 12WH; C11-GB 16WH; C11COG 20WH; C120-GC 18WH; C133-G 16WH; C133-GA 16WH; C133-GB 16WH; C133-GC 16WH; C137-G 16WH; C63-G 18WH; C89-G 16WH; C89-GA 18WH; C89-GB 18WH; C89-GC 18WH; C89-GD 18WH
See also sheets: CH13_64, CH14_29, CH15_30, CH16_24, CH17_27, CH19_40, CH6_07
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.46. BODY GROUND FRONT CAP, P. 43 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / CHAPTER 3 / BODY GROUND - FRONT CAP / MJV0488 19NOV21 ADDED CIRC C11COG IN CAV B OF R/D 10009. / FR CAP/ ELEC PANEL (10000) A4 / GROUND CIRCUIT (10009) A / CAMERA (10035) CH17_27 STARTER INTERLOCK VANDAL LOCK SW (10086) CH14_29 SAFETY COMPT (10039) CH19_40 / C137-G 16WH / C120-GC 18WH / C11-GA 12WH / B11-GF 12WH / GROUND STUD @(0GND) CH3_95D 0 GND %(19) / C133-G 16WH / C133-GC 16WH / C133-GA 16WH / C133-GB 16WH C133-GB 16WH / C63-G 18WH / C89-G 16WH / C89-GA 18WH / C89-GB 18WH / C89-GC 18WH / C89-GD 18WH / C11-GB 16WH / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / @ W/CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK % W/CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK / C11COG 20WH / Figure 83 / BODY GROUND FRONT CAP

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 124 | printed page 84 | section 3.47
3.47. BODY GROUND FRONT CAP (CONT.), P. 44
Figure 84 BODY GROUND FRONT CAP (CONT.)

Components: CLUSTER LT (10020/10021/10022); CORNER MARKER LT (10016/10018); DESTINATION SIGN (10036); DESTINATION SIGN (10037); FR CAP/ELEC PANEL (10000); GROUND CIRCUITS (10010); HEATED MIRROR (10023); L MOTORIZED MIRROR (10070); LED PEDESTRIAN LT (10046A); LIFT DOOR INDICATOR (1033B); LIFT INDICATOR LT (10033A); LT MONITOR CONN D (10025D/10026D); MOTORIZED MIRROR (10048); PEDESTRIAN LT (10046); POST TRIP COMM (10045/10045A); R HTD MIRROR (10024); RED PWL LEFT FRONT (10028); RED PWL RIGHT FRONT (10030); RED PWL RIGHT FRONT (10031); RED/AMBER PWL RIGHT/LEFT FRONT (10029/10031); SECOND CORNER MARKER LT (10017); SECOND CORNER MARKER LT (10019)
Wires (circuit gauge+color): B11-GE 12WH; C11-G 12WH; C11-GA 12WH; C122-G 16WH; C122G 16WH; C125-G 16WH; C128-G 16WH; C134-G 16WH; C139-GB 14WH; C139-GB 16WH; C58-G 18WH; C58-GB 18WH; C58-GC 18WH; C58-GD 18WH; C58-GE 18WH; C58-GF 18WH; C58-GH 18WH; C58-GJ 18WH; C78-G 18WH; C78-GA 18WH; C78-GB 18WH; C78-GL 18WH; C78-GR 18WH; C89-G 16WH; C89-GA 16WH; C89-GB 16WH; C89-GC 16WH; C89-GD 16WH
See also sheets: CH10_03, CH10_04, CH10_05, CH15_29, CH18_06, CH18_09, CH18_50, CH6_03, CH6_04, CH7_07, CH7_46, CH7_62, CH8_05
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.47. BODY GROUND FRONT CAP (CONT.), P. 44 / CHAPTER 3 BODY GROUND - FRONT CAP (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. GROUND CIRCUITS (10010) B / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 ADDED CHAPTER B CH7_62A,B2B,CH18_50. / H J K / C11-GA 12WH / C125-G 16WH C128-G 16WH / C78-GR 18WH C122-G 16WH C122G 16WH C139-GB 14WH C139-GB 16WH C58-GH 18WH C58-GJ 18WH C134-G 16WH C134-G 16WH FR CAP/ELEC PANEL (10000) A3 C11-G 12WH / C89-G 16WH / CLUSTER LT (10020/10021/10022) CH8_05 / CORNER MARKER LT (10016/10018) CH7_46 / C78-G 18WH C78-G 18WH / B11-GE 12WH / C78-GA 18WH C78-GB 18WH C78-GL 18WH C78-GR 18WH / GROUND STUD @(0GND) CH3_95D / C89-GA 16WH C89-GC 16WH C89-GB 16WH C89-GD 16WH / C58-G 18WH / 0 GND %(19) / Figure 84 / BODY GROUND FRONT CAP (CONT.)

3.48. BODY GROUND REAR CAP, P. 45
Figure 85 BODY GROUND REAR CAP

Components: ADDITIONAL L STOP/TAIL LT (10105A); ADDITIONAL R STOP/TAIL LT (10126A); AMBER WARNING LT (10113); GROUND SPLICE (10161); L BODY/ELEC PANEL (10400/10400A/B); L DIRECTIONAL LT (10101); L DUAL CORNER MARKER LT (10157); L LICENSE LT (10105); L STOP/TAIL LICENSE LT (10104); L STOP/TAIL LT (10102); LOWER L WARM LT (10172); LOWER R WARM LT (10173); PTI STOP REAR SW (10513/10513A); R AMBER WARNING LT (10118); R BACKUP LT (10126); R DUAL CORNER MARKER LT (10156); R RED WARNING LT (10117); REAR CAP/L BODY (10406); REAR DOOR SW BOX (10177); RED WARNING LT (10112); SPLICE (10160); STROBE LT (10109/10109A)
Wires (circuit gauge+color): B11-GJ 10WH; D11-G 10WH; D11-GA 10WH; D11-GB 10WH; D11-GD 16WH; D11-GG 16WH; D125-G 16WH; D127-G 16WH; D56-G 16WH; D58-G 16WH; D58-GA 16WH; D58-GC 16WH; D58-GD 16WH; D58-GE 16WH; D58-GH 16WH; D58-GK 16WH; D58-GL 16WH; D58-GM 16WH; D68-G 16WH; D68-GA 16WH; D68-GB 16WH; D68-GD 16WH; D68-GE 16WH; D68G 16WH; D68GA 16WH; D68GB 16WH; D68L-G 16WH; D89-G 16WH; D89-GA 16WH; D89-GB 16WH; D89-GC 16WH; D89LA-G 16WH; D89LR-G 16WH; D89RA-G 16WH; D89RR-G 16WH; E11-G 10WH
See also sheets: CH14_24, CH18_14, CH3_46, CH6_08, CH6_13, CH7_10, CH7_18, CH7_19, CH7_47, CH7_49
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.48. BODY GROUND REAR CAP, P. 45 / BODY GROUND - REAR CAP / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / CHAPTER 3 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / L REAR CAP GROUND SPLICE (10160) A / D11-GA 10WH / D11-GD 16WH / REAR CAP/L BODY (10406) D3 D11-G 10WH / D56-G 16WH D68-GA 16WH D68L-G 16WH D58-GC 16WH D58-GD 16WH D58-GE 16WH D58-GH 16WH D58-GK 16WH D58-GL 16WH D58-GM 16WH / D58-G 16WH / E F / D127-G 16WH D89-G 16WH / D89LA-G 16WH D89LR-G 16WH D89RA-G 16WH D89RR-G 16WH D89-GA 16WH D89-GB 16WH / D89-GC 16WH / H J / D11-GG 16WH %D68-GB 16WH D68-GE 16WH / % L LICENSE PLATE LT # L & R LICENSE PLATE LT * W/VEHICLES N/0508108 - NOT MTA FUSE BLOCK & W/VEHICLES W/0508108 - MTA FUSE BLOCK / D58-GA 16WH / CLUSTER/MARKER LT (10114/10115/ 10116/10119/10108) CH7_47,48,49,50,51 / D125-G 16WH / GROUND STUD *(0GND) CH3_95D 0 GND &(11/12) / L BODY/ELEC PANEL (10400/10400A/B) A3 E11-G B11-GJ 10WH 10WH R REAR CAP D11-GB GROUND SPLICE 10WH (10161) CH3_46 / L DIRECTIONAL LT (10101) CH7_18 L STOP/TAIL LICENSE LT (10104) CH7_19 L STOP/TAIL LT (10102) CH7_18 / D68-G 16WH D68G 16WH / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 85 / BODY GROUND REAR CAP

3.49. BODY GROUND REAR CAP (CONT.), P. 46
Figure 86 BODY GROUND REAR CAP (CONT.)

Components: DESTINATION SIGN (10143); DESTINATION SIGN (10144); DRIVERS ALERT SIGN (10128); EMERGENCY EXIT LT (10142); EMERGENCY EXIT LT (10142A); GROUND SPLICE (10161); L BACKUP LT (10103); L REAR CAP GROUND SPLICE (10160); LOWER L BACKUP LT (10174); LOWER R BACKUP LT (10175); R BACKUP LT (10122); R DIRECTIONAL LT (10124); R REAR MARKER LT (10183); R STOP/TAIL LICENSE LT (10125); R STOP/TAIL LT (10123)
Wires (circuit gauge+color): D11-GA 10WH; D11-GB 10WH; D11-GE 16WH; D11-GF 16WH; D134-G 16WH; D143-G 16WH; D57-G 16WH; D58-GL 16BN; D58-GL 16WH; D58-GN 16WH; D68-GC 16WH; D68R-G 16WH; D71-G 16WH; D71L-G 16WH; D71R-G 16WH
See also sheets: CH14_20, CH3_45, CH6_13, CH7_01, CH7_07, CH7_18, CH7_19, CH7_48, CH7_50, CH7_51
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.49. BODY GROUND REAR CAP (CONT.), P. 46 / CHAPTER 3 BODY GROUND - REAR CAP (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / R REAR CAP GROUND SPLICE (10161) A / D11-GE 16WH / D11-GB 10WH / @D71-G 16WH / %D71-G 16WH / *D134-G 16WH #D134-G 16WH ^D58-GN 16WH / L REAR CAP GROUND SPLICE (10160) CH3_45 / R DIRECTIONAL LT (10124) CH7_18 R STOP/TAIL LICENSE LT (10125) CH7_19 / D11-GF 16WH / D57-G 16WH D68-GC 16WH / D68R-G 16WH / D11-GA 10WH / DRIVERS ALERT SIGN (10128) CH6_13,14 L BACKUP LT (10103) CH7_01 / &D143-G 16WH / R STOP/TAIL LT (10123) CH7_18 / D58-GL 16WH D58-GL 16BN / R REAR MARKER LT (10183) CH7_51 / D71L-G 16WH / D71R-G 16WH / D71L-G 16WH / D71R-G 16WH / R BACKUP LT (10122) CH7_01 / LOWER L BACKUP LT (10174) CH7_01 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 86 / BODY GROUND REAR CAP (CONT.)

3.50. BODY GROUND SEALED ENGINE, P. 47
Figure 87 BODY GROUND SEALED ENGINE

Components: AIR COMPRESSOR (11518); BLOCK (11507); BOOSTER PUMP (11502); BOOSTER PUMP (11524); BOOSTER PUMP (11535); BOTTOM STEP HTR (11528); HIGH OUTPUT BE (11537); HIGH OUTPUT CE (11536); SECOND STEP HTR (11529); SPLICE BLOCK (11509); SPLICE BLOCK CAP (11509); TIRE WINCH (11520); TRACTION SANDERS (11514)
Wires (circuit gauge+color): Y11-G 12WH; Y11-G 8WH; Y11-GA 16WH; Y11-GB 16WH; Y11-GC 16WH; Y11-GD 16WH; Y11-GE 16WH; Y115-G 10WH; Y132-G 12WH; Y132-GA 12WH; Y132-GB 12WH; Y138-G 12WH; Y146-G 12WH; Y74-G 12WH
See also sheets: CH13_10, CH13_11, CH19_01, CH19_02, CH19_10, CH19_33, CH19_37, CH3_48, CH3_49
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.50. BODY GROUND SEALED ENGINE, P. 47 / CHAPTER 3 BODY GROUND - SEALED ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SEALED ENG GROUND (0GND) / Y138-G 12WH / Y74-G 12WH / Y115-G 10WH / Y132-G 12WH Y132-G 12WH / %Y11-G 8WH / Y132-GB 12WH / Y11-GB 16WH Y11-GC 16WH / Y11-GD 16WH Y11-GE 16WH Y11-GA 16WH Y11-GB 16WH / Y146-G 12WH / Y132-GA 12WH / BOTTOM STEP HTR (11528) CH19_33 / GROUND/POWER SPLICE BLOCK (11509) CH3_49 / GROUND SPLICE BLOCK (11507) CH3_48 / SECOND STEP HTR (11529) CH19_33 / @Y11-G 12WH / Y11-GA 16WH / GROUND/POWER SPLICE BLOCK CAP (11509) CH3_49 / Y74-G 12WH / Y74-G 12WH / Y74-G 12WH / Y74-G 12WH / % W/OPTIONAL FEATURE @ N/OPTIONAL FEATURE / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 87 / BODY GROUND SEALED ENGINE

3.51. BODY GROUND SEALED ENGINE (CONT.), P. 48
Figure 88 BODY GROUND SEALED ENGINE (CONT.)

Components: AED STEP LT (11517); BACKUP ALARM (11516); BATTERY ISOLATOR (11521); ENG COMPARTMENT LT (11505); GROUND SPLICE BLOCK (11507); L HTD COVER MIRROR (11519); LUGGAGE BOX LT (11511); REVERSE MOTION SENSOR (11515); TRACTION CHAIN (11513)
Wires (circuit gauge+color): Y11-G 8WH; Y11-GC 16WH; Y11-GD 16WH; Y11-GE 16WH; Y121-GA 16WH; Y131-GD 16WH; Y135-G 16WH; Y138-G 16WH; Y140-G 18WH; Y71-G 16WH; Y78-GA 16WH
See also sheets: CH10_06, CH13_10, CH16_22, CH3_47, CH3_68, CH7_04, CH7_64, CH8_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.51. BODY GROUND SEALED ENGINE (CONT.), P. 48 / CHAPTER 3 BODY GROUND - SEALED ENGINE (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE BLOCK (11507) A / Y135-G 16WH / Y11-GE 16WH / Y78-GA 16WH / LUGGAGE BOX LT (11511) CH7_64 / Y11-GC 16WH / BATTERY ISOLATOR (11521) CH3_68 / Y138-G 16WH / Y131-GD 16WH / TRACTION CHAIN (11513) CH13_10 / Y140-G 18WH / ENG COMPARTMENT LT (11505) CH8_03 / Y121-GA 16WH / Y71-G 16WH / Y71-G 16WH / Y11-GD 16WH / L HTD COVER MIRROR (11519) CH10_06 / AED STEP LT (11517) CH16_22,23 REVERSE MOTION SENSOR (11515) CH7_04 BACKUP ALARM (11516) CH7_04 / Y11-G 8WH / SEALED ENG GROUND (0GND) CH3_47 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 88 / BODY GROUND SEALED ENGINE (CONT.)

3.52. BODY GROUND SEALED ENGINE (CONT.), P. 49
Figure 89 BODY GROUND SEALED ENGINE (CONT.)

Components: AFT STEP LT (11530); FWD STEP LT (11526); PWR SPLICE (11509); SEALED ENG/ELEC PANEL (11500); SKIRT LT (1531)
Wires (circuit gauge+color): Y11-G 12WH; Y11-G 8WH; Y11-GA 16WH; Y11-GB 16WH; Y131 16DKBL; Y131-GA 16WH; Y131-GB 16WH; Y131-GC 16WH; Y131A 16DKBL; Y131B 16DKBL; Y131C 16DKBL
See also sheets: CH3_47, CH8_22
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.52. BODY GROUND SEALED ENGINE (CONT.), P. 49 / CHAPTER 3 BODY GROUND - SEALED ENGINE (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND/ PWR SPLICE (11509) A / Y131A 16DKBL / Y131B 16DKBL / Y131 16DKBL / Y11-GA 16WH Y11-GB 16WH / Y131C 16DKBL / Y131-GC 16WH / Y131-GB 16WH / Y131-GA 16WH / AFT STEP LT (11530) CH8_22 / *Y11-G 12WH #Y11-G 8WH / SEALED ENG/ELEC PANEL (11500) CH8_22,23A / * N/OPTIONAL FEATURE # W/OPTIONAL FEATURE / SEALED ENG GROUND (0GND) CH3_47 / FWD STEP LT (11526) CH8_22 / SKIRT LT (1531) CH8_22 / FWD STEP LT (11526) CH8_22 / AFT STEP LT (11530) CH8_22 / SKIRT LT (1531) CH8_22 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 89 / BODY GROUND SEALED ENGINE (CONT.)

3.53. BODY GROUND CHASSIS W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 50
Figure 90 BODY GROUND CHASSIS W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: AIR DRYER (9257); AIR PARK BRAKE - SAAR (9777M); AIR TANK (9009); DRAIN VALVE (9526/9526A); ESPAR COOLANT HTR W/RMS TANK (9005); ESPAR HTR FUEL PUMP (9001); FWD CHASSIS/HOOD HARNESS (8003A); GATE (4301); GROUND (9737); GROUND SPLICE (6740); HALDEX DRAIN VALVE (9527A/9527); HORN (8310/8310A); HYDRAULIC PUMP MOTOR 1 (9510); INTERCONNECT (9513M/F); L FOG LT (4302/4302A); R FOG LT (4303/4303A); SUPPLY VALVE (9506); W/AF FUEL TANK (9006)
Wires (circuit gauge+color): M11-G 10WH; M11-G 14WH; M11-GA 12WH; M11-GB 12WH; M11-GC 12WH; M11-GD 12WH; M39B-G 14WH; M39C-G 14WH; M39D-G 14WH; M44-GB 18WH; M64-G 14WH; M64A-G 14WH; M64B-G 14WH; M75-G 10WH; M75-GA 10WH; M75-GB 18WH; M75-GC 10WH; M75-GD 10WH; M75-GE 18WH; M85-GA 16WH; M89-G 16WH; M90A-G 12WH; M90AA-G 12WH; M90E-G 18WH; R44-GB 18WH
See also sheets: CH13_01, CH13_02, CH13_04, CH13_34, CH18_13, CH19_14, CH19_15, CH19_16, CH7_57, CH7_61, CH9_09
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.53. BODY GROUND CHASSIS W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 50 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 3 BODY GROUND - CHASSIS W/2017/2021 ISB/B6.7 DIESEL ENG M11-GC 12WH M11-GB 12WH M85-GA 16WH M11-GD 12WH / M39C-G 14WH M39B-G 14WH M39D-G 14WH FWD/REAR CHASSIS INTERCONNECT (9513M/F) R44-GB 18WH / W/RMS FUEL TANK M75-GB 18WH M75-GA 10WH M75-GE 18WH M75-GD 10WH M75-GB 18WH M75-G 10WH / UPPER DASH GROUND (2GA) M75-G 10WH / ESPAR HTR FUEL PUMP (9001) CH19_14 ESPAR COOLANT HTR W/RMS TANK (9005) CH19_14 / GROUND SPLICE (6740) A / M11-GA 12WH / W/AF FUEL TANK M75-GC 10WH / FWD CHASSIS/HOOD HARNESS (8003A) CH7_57,58 HORN (8310/8310A) CH18_13 / M89-G 16WH / RADIATOR GROUND (9737) / CROSSING GATE (4301) CH9_09 / M11-G 10WH M11-G 14WH / M75-GA 10WH / M90AA-G 12WH M90E-G 18WH M64A-G 14WH M64B-G 14WH / HYDRAULIC PUMP MOTOR 1 (9510) CH13_34 SUPPLY VALVE (9506) CH13_34 L FOG LT (4302/4302A) CH7_61 R FOG LT (4303/4303A) CH7_61 / M90A-G 12WH / M64-G 14WH / M44-GB 18WH / AIR PARK BRAKE - SAAR (9777M) CH13_04,4A / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 90 / BODY GROUND CHASSIS W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE

3.54. BODY GROUND CHASSIS W/ F-2018 PROPANE / GASOLINE ENGINE, P. 51
Figure 91 BODY GROUND CHASSIS W/ F-2018 PROPANE / GASOLINE ENGINE

Components: AIR DRYER (9257); BENDIX DRAIN VALVE (9526/9526A); CROSSING GATE (4301); GROUND (9737); GROUND SPLICE (6740); HALDEX DRAIN VALVE (9527/9527A); HARNESS (8003A); INTERCONNECT (9100); L FOG LT (4302); R FOG LT (4303)
Wires (circuit gauge+color): M11-G 10WH; M11-GA 10WH; M11-GB 12WH; M11-GC 12WH; M11-GD 12WH; M11-GE 4WH; M148-G 10WH; M148-GA 6WH; M148-GB 10WH; M37-G 10WH; M37GA 6WH; M37GB 10WH; M39B-G 14WH; M39C-G 14WH; M39D-G 14WH; M64-G 14WH; M64A-G 14WH; M64B-G 14WH; M89-G 16WH
See also sheets: CH13_01, CH13_02, CH5_13, CH5_16, CH7_59, CH7_61, CH9_10
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.54. BODY GROUND CHASSIS W/ F-2018 PROPANE / GASOLINE ENGINE, P. 51 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / CHAPTER 3 BODY GROUND - CHASSIS W/F-2018-PROPANE/ GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / M39C-G 14WH M39B-G 14WH / UPPER DASH GROUND (2GA) / GROUND SPLICE (6740) / M64A-G 14WH M64B-G 14WH / M64-G 14WH / M39D-G 14WH / M11-GA 10WH / M89-G 16WH / M11-G 10WH / M11-GE 4WH / M148-GA 6WH M37GA 6WH / M148-G 10WH M37GB 10WH / M11-GB 12WH M11-GD 12WH / M148-GB 10WH M37-G 10WH / M11-GC 12WH / FWD/HOOD HARNESS (8003A) CH7_59 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 91 / BODY GROUND CHASSIS W/ F-2018 PROPANE / GASOLINE ENGINE

3.55. BODY GROUND RIGHT BODY, P. 52
Figure 92 BODY GROUND RIGHT BODY

Components: AFT ENTR DOOR (10712); AFT ENTR DOOR (10837); AFT REAR WHL PKT (10838); AIR DOOR SOLENOID (10769C/D/E/F/G); CMB LT FWD RR WHL PKT CE (10781); DOME LT SECT 3 (10758); FWD RR WHL PKT (10708/10708A/10708B); GROUND SPLICE (10701); GUARD DOME LT SECT 1 (10768); INTERMEDIATE MARKER LT (10710/10710A); INTERMEDIATE MARKER LT MIDSHIP (10710); L BODY/ELEC PANEL (10400/10400A/B); OVER REAR WHL PKT (10706/10706A/10706B); R BODY/RR CAP (10700); RR CAP/L BODY (10406); RR WHL PKT CE (10707/10707A/10707B); SIDE DIR LT FWD REAR WHL PKT (10705); SIDE DIR LT FWD RR WHL PKT (10779/10779B); SIDE DIR LT FWD RR WHL PKT CE (10779A); SIDE DIR LT OVER REAR WHL PKT (10780); SIDE DIRECTIONAL LT (10807A/10807B); SIDE DIRECTIONAL LT AFT ENT DOOR (10711); SIDE DIRECTIONAL LT MIDSHIP (10709/10709A); SIDE DIRECTIONAL MARKER LT MIDSHIP (10808)
Wires (circuit gauge+color): B11-GJ 10WH; D11-G 10WH; D11-GF 12WH; E11-G 10WH; F11-GA 16WH; F11-GF 12WH; F120-G 18WH; F57-G 18WH; F57-GB 18WH; F57-GC 18WH; F57-GD 18WH; F57-GE 18WH; F57-GF 18WH; F57-GH 18WH; F58-GA 18WH; F58-GB 18WH; F58-GC 18WH; F58-GD 18WH; F58-GE 18WH; F58-GH 18WH; F58-GJ 18WH; F63-G 12WH; F63-G 16WH; F63-GA 16WH; F63-GF 16WH; F63-GK 16WH
See also sheets: CH16_24, CH7_37, CH7_38, CH7_39, CH7_40, CH7_53, CH8_01, CH8_08, CH8_37, CH8_39, CH8_41, CH8_42, CH8_50, CH8_54, CH8_55
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.55. BODY GROUND RIGHT BODY, P. 52 / CHAPTER 3 BODY GROUND - RIGHT BODY / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. GROUND SPLICE (10701) A / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / C D / F11-GA 16WH / 0 GND (11/12) / SIDE DIRECTIONAL LT (10807A/10807B) CH7_37 / G H / J K / Figure 92 / BODY GROUND RIGHT BODY

3.56. BODY GROUND RIGHT BODY (CONT.), P. 53
Figure 93 BODY GROUND RIGHT BODY (CONT.)

Components: ACTIVITY DOMME LT (10765); ELEC PANEL (10400/10400A/B); EMERGENCY EXIT LT SPLICE (10714); KICK OUT WINDOW SPLICE (10713); PASSENGER PULL CORD (10836); R BODY/REAR CAP (10700); REAR CAP/L BODY (10406); SIDE EMERGENCY DOOR LT (10771); SIDE EMERGENCY DOOR LT (10773); SIDE EMERGENCY DOOR LT (10773G); SPLICE (10702)
Wires (circuit gauge+color): B11-GJ 10WH; D11-G 10WH; D11-GF 12WH; E11-G 10WH; F11-G 12WH; F11-GB 16WH; F11-GF 12WH; F12-G 18WH; F126-G 18WH; F130-G 18WH; F130-GA 18WH; F130-GB 18WH; F130-GC 18WH; F130-GD 18WH; F141-G 16WH; F143-G 18WH; F143-GR 18WH; F143-GS 18WH; F143-GT 18WH; F143-GU 18WH; F143-GV 18WH; F143-GW 18WH; F143-GX 18WH; F143-GY 18WH; F143-GZ 18WH; F143GAA 18WH; F143GAB 18WH; F143GAL 18WH; F143GAM 18WH; F63-GX 16WH
See also sheets: CH13_14, CH14_08, CH14_10, CH14_23, CH14_25, CH14_27, CH8_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.56. BODY GROUND RIGHT BODY (CONT.), P. 53 / CHAPTER 3 BODY GROUND - RIGHT BODY (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (10702) / KICK OUT WINDOW SPLICE (10713) CH14_08,09 / F11-GB 16WH / F11-GF 12WH / L BODY/ REAR CAP/L BODY ELEC PANEL (10406) (10400/10400A/B) D3 A3 D11-G E11-G B11-GJ 10WH 10WH 10WH / SIDE EMERGENCY DOOR LT (10771) CH14_23 / F63-GX 16WH F143-G 18WH / F141-G 16WH / F12-G 18WH / 0 GND (11/12) / R BODY/REAR CAP (10700) A3 / D11-GF 12WH / W/12,13 WDO / SIDE EMERGENCY DOOR LT (10773) CH14_25 / PASSENGER PULL CORD (10836) CH13_14 / Figure 93 / BODY GROUND RIGHT BODY (CONT.)

3.57. BODY GROUND LEFT BODY, P. 54
Figure 94 BODY GROUND LEFT BODY

Components: AFT ENTR DOOR (10518); ELEC PANEL (10400/10400A/B); LT FWD (10412); LT FWD (10412/10412A/10412B); SIDE DIR LIGHTOVER RR WHEEL PKT (10413/10413A/10413B); SIDE DIR LT FWD REAR WHL PKT CE (10506A/10506B); SIDE DIR LT FWD RR WHL PKT CE (10506); SIDE DIR LT OVER REAR WHL PKT (10511); SIDE DIR LT OVER REAR WHL PKT (10511A/10511B); SIDE DIRECTIONAL LT (10410); SIDE DIRECTIONAL/MARKER LT (10416); SIDE DIRECTIONAL/MARKER LT (10512); SIDE MARKER LT (10417/10417A); SIDE MARKER LT (10417B); SIDE MARKER LT (10512); SPLICE (10419)
Wires (circuit gauge+color): B11-GH 10WH; E11-GA 10WH; E56-G 18WH; E56-GA 18WH; E56-GB 18WH; E56-GC 18WH; E56-GD 18WH; E56-GE 18WH; E56-GF 18WH; E56-GG 18WH; E56-GH 18WH; E56-GJ 18WH; E58-GB 18WH; E58-GH 18WH
See also sheets: CH7_35, CH7_36, CH7_41, CH7_42
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.57. BODY GROUND LEFT BODY, P. 54 / CHAPTER 3 / BODY GROUND - LEFT BODY / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / E56-G 18WH E56-GE 18WH E56-GF 18WH E58-GB 18WH E58-GH 18WH / L BODY/ ELEC PANEL (10400/10400A/B) D3 / GROUND SPLICE (10419) A / GROUND STUD @(0GND) CH3_95D 0 GND %(11/12) / SIDE DIRECTIONAL LT (10410) CH7_36 SIDE DIRECTIONAL/MARKER LT (10416) CH7_41 SIDE DIRECTIONAL/MARKER LT (10512) CH7_41 / SIDE DIRFCTIONAL LT FWD (10412) CH7_35 / E11-GA 10WH / B11-GH 10WH / E56-GB 18WH / SIDE MARKER LT AFT ENTR DOOR (10518) CH7_42 / SIDE DIR LT FWD REAR WHL PKT CE (10506A/10506B) CH7_36 / SIDE DIR LT OVER REAR WHL PKT (10511A/10511B) CH7_36 SIDE DIR LT OVER REAR WHL PKT (10511) CH7_35 SIDE MARKER LT (10512) CH7_41 / SIDE DIRFCTIONAL LT FWD (10412/10412A/10412B) CH7_35 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / @ W/CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK % W/CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK / Figure 94 / BODY GROUND LEFT BODY

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 135 | printed page 95 | section 3.58
3.58. BODY GROUND LEFT BODY (CONT.), P. 55
Figure 95 BODY GROUND LEFT BODY (CONT.)

Components: BUZZER GROUND (10349); GROUND SPLICE (10482); KICKOUT WINDOW SPLICE (10421); LT SPLICE (10423); MARKER LT (10418/10418A); ROOF HATCH SPLICE (10472); SED LT (10454A/B/C/D/E/F/G/H); SIDE EMERGENCY DOOR (10456A/B/C/D/E/F/G/H); SPLICE (10419); SPLICE REAR K/O WDO (10514)
Wires (circuit gauge+color): E11-GC 12WH; E126-GA 18WH; E126-GD 18WH; E129-GA 18WH; E130-GA 18WH; E141-G 16WH; E143-GA 18WH; E143-GV 18WH; E58-GA 18WH; E58-GB 18WH
See also sheets: CH14_05, CH14_13, CH14_15, CH14_19, CH3_57, CH7_52
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.58. BODY GROUND LEFT BODY (CONT.), P. 55 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / CHAPTER 3 BODY GROUND - LEFT BODY (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (10419) E / E143-GA 18WH / SIDE EMERGENCY DOOR (10456A/B/C/D/E/F/G/H) CH14_19 ROOF HATCH SPLICE (10472) CH14_15,16 / E130-GA 18WH *E141-G 16WH / SPLICE REAR K/O WDO (10514) CH14_13 KICKOUT WINDOW SPLICE (10421) CH14_ EMERGENCY EXIT LT SPLICE (10423) CH14_05,06,07 SED LT (10454A/B/C/D/E/F/G/H) CH14_19 / E143-GV 18WH / E129-GA 18WH / E11-GC 12WH / GROUND SPLICE (10482) CH3_57 / E126-GD 18WH E126-GA 18WH / PULL CORD BUZZER GROUND (10349) / E58-GA 18WH E58-GB 18WH / INTERMEDIATE MARKER LT (10418/10418A) CH7_52 / * W/9 WDO / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 95 / BODY GROUND LEFT BODY (CONT.)

3.59. BODY GROUND LEFT BODY (CONT.), P. 56
Figure 96 BODY GROUND LEFT BODY (CONT.)

Components: ELEC PANEL (10401/10401A/B); GROUND SPLICE (10473); ROOF HATCH (10457-10464); ROOF HATCH (10459-10469); STROBE LT (10474A/B/C); STROBE LT (10474A/B/C/D/E/F/G/H/J/K/L/M/N); STROBE LT (10474D/E/F/G/H/J/K/L/M/N)
Wires (circuit gauge+color): B11-GG 12WH; E11-GB1 12WH; E11-GB2 16WH; E127-GA 18WH; E127-GB 18WH; E76-GA 16WH; E76-GB 16WH
See also sheets: CH19_41, CH7_10, CH7_15
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.59. BODY GROUND LEFT BODY (CONT.), P. 56 / CHAPTER 3 BODY GROUND - LEFT BODY (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (10473) A / E11-GB2 16WH / E76-GA 16WH / E76-GB 16WH / E127-GA 18WH / E127-GB 18WH / E127-GB 18WH / ROOF HATCH (10457-10464) CH19_41 / STROBE LT (10474A/B/C/D/E/F/G/H/J/K/L/M/N) CH7_10,11,12,13,14 / L BODY/ ELEC PANEL (10401/10401A/B) A3 / GROUND STUD @(0GND) CH3_95D 0 GND %(14/15) / B11-GG 12WH / E127-GA 18WH / STROBE LT (10474D/E/F/G/H/J/K/L/M/N) CH7_15,16 / STROBE LT (10474A/B/C) CH7_15,16 / E11-GB1 12WH / ROOF HATCH (10459-10469) CH19_41 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / @ W/CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK % W/CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK / Figure 96 / BODY GROUND LEFT BODY (CONT.)

3.60. BODY GROUND LEFT BODY (CONT.), P. 57
Figure 97 BODY GROUND LEFT BODY (CONT.)

Components: ACTIVITY LT (10491B); ACTIVITY LT (10491E/C/D); AFT RR WHL PKT (10519); ALTERNATE ENTRANCE DOOR (10479); DOME LT GUARD (10492); DOME LT SECT 1 (10483); DOME LT SECT 3 (10484); DOME LT SECT 5 (10485); GROUND SPLICE (10419); GROUND SPLICE (10482); INTERMEDIATE MARKER LT (10418); L BODY/SED TRANSITION (10801C); L BODY/SED TRANSITION (10801C/E); SIDE DIR LT MIDSHIP (10411); SIDE DIR LT MIDSHIP (10411A); SIDE MARKER LT AFT ENT DOOR (10518); WHL PKT (10414)
Wires (circuit gauge+color): E11-GC 12WH; E120-GA 18WH; E131-G 16WH; E56-GA 18WH; E56-GC 18WH; E56-GD 18WH; E58-GA 18WH; E58-GB 18WH; E58-GC 18WH; E58-GF 18WH; E58-GJ 18WH; E63-GA 16WH; E63-GAE 18WH; E63-GAF 18WH; E63-GC 16WH; E63-GD 16WH; E63-GF 16WH; E63-GH 16WH; E63-GN 16WH; E63-GW 16WH
See also sheets: CH16_22, CH3_55, CH7_35, CH7_36, CH7_42, CH7_52, CH7_67, CH8_01, CH8_02, CH8_37, CH8_39, CH8_40, CH8_49
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.60. BODY GROUND LEFT BODY (CONT.), P. 57 / CHAPTER 3 BODY GROUND - LEFT BODY (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (10482) A / D E / E11-GC 12WH E63-GW 16WH E63-GAE 18WH E131-G 16WH E63-GAF 18WH E58-GF 18WH *E120-GA 18WH E131-G 16WH E131-G 16WH **E120-GA 18WH @E63-GF 16WH / E63-GA 16WH / E63-GN 16WH / #E63-GC 16WH / % W/10 WINDOW @ W/9 WINDOW # W/6 WINDOW * W/12 WINDOW ** W/7,8,9,10,11,13 WDO / #E63-GD 16WH #E63-GH 16WH %E56-GD 18WH E56-GC 18WH E58-GA 18WH E56-GC 18WH E58-GJ 18WH E58-GB 18WH E58-GC 18WH E56-GA 18WH / SIDE DIR LT MIDSHIP (10411) CH7_36 INTERMEDIATE MARKER LT (10418) CH7_52 SIDE DIR LT MIDSHIP (10411A) CH7_35 / SIDE MKR LT AFT RR WHL PKT (10519) CH7_42 / #E63-GA 16WH / SIDE DIR LT AFT RR WHL PKT (10414) CH7_36 NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 97 / BODY GROUND LEFT BODY (CONT.)

3.61. ZERO VOLT REFERENCE SPLICE, P. 58
Figure 98 ZERO VOLT REFERENCE SPLICE

Components: AIR PARK BRAKE SW (1104); AIR PARK BRAKE SW (1813); BODY CONTROLLER (1602); BRAKE SW (1814); CLOCK SPRING (1809); CLOCK SPRING (1832); EMERGENCY EXIT RELAY (1012-R4); MANUAL HYD PARK BRAKE SW (9267/9267A); PARK BRAKE ZVR RELAY (1011-R6); PLATFORM/ELEC PANEL (1702/1702); PLATFORM/FWD CHASSIS (1700); PRIMARY AIR PRESSURE SENSOR (1811); PRIMARY AIR PRESSURE SENSOR (1811A); PTI RELAY (1012-R6); REFERENCE (1005); SEAT BELT ALARM (1109); SEAT BELT ALARM RELAY (1011-R3); SECONDARY AIR PRESSURE SENSOR (1812); SECONDARY AIR PRESSURE SENSOR (1812A); STOP LT 1 PRESSURE SW (1023A); STOP LT 1 PRESSURE SW (1823); STOP LT 2 PRESSURE SW (1024A); STOP LT 2 PRESSURE SW (1824); TURN SIGNAL SW (1810); WHEEL CHAIR LIFT RELAY (1010-R1); ZERO VOLT REF SPLICE (1005A); ZVR SPLICE (1035OA); ZVR SPLICE (1035OB)
Wires (circuit gauge+color): A125J 18GY; A9A 16GY; A9AA 18GY; A9B 16GY; A9B 18GY; A9BB 16GY; A9BB 18GY; A9C 18GY; A9CA 18GY; A9D 16GY; A9FA 18GY; A9H 18GY; A9HA 18GY; A9HA 20TN; A9J 18GY; A9K 18GY; A9S 18GY; A9VC 18GY; A9VE 18GY; A9VF 18GY; A9VG 16GY; A9VH 16GY; A9VL 14GY; A9VL 18GY; B9L 16GY; B9M 16GY; B9N 16GY
See also sheets: CH13_03, CH13_04, CH13_07, CH13_34, CH13_51, CH13_52, CH13_53, CH13_57, CH14_02, CH15_08, CH18_38, CH3_59, CH3_60, CH5_11, CH5_12, CH8_51, CH8_52
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.61. ZERO VOLT / SPLICE, P. 58 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / CHAPTER CHAPTER 3 3 SPLICE / ZERO VOLT / MJV0488 19NOV21 CIRC A9AA WAS A9A IN CAV B AT R/D 1005. / A9C 18GY A9AA 18GY A9VL 18GY A9K 18GY A9K 18GY @A9A 16GY A9BB 18GY A125J 18GY A9CA 18GY / J5 - TAN BODY CONTROLLER (1602) / ZVR SPLICE (1035OA) CH3_60 ZVR SPLICE (1035OB) CH3_60 EMERGENCY EXIT RELAY (1012-R4) CH14_02 / D E / ZERO VOLT (1005) A / A9D 16GY / E5 ZVR 2 / A9VF 18GY A9HA 20TN A9HA 18GY / A9J 18GY / A9VL 14GY / A9H 18GY / A9S 18GY / A9B 18GY / A9BB 16GY A9B 16GY A9VG 16GY A9VH 16GY A9VC 18GY A9VE 18GY A9VG 16GY A9VH 16GY A9VC 18GY A9VE 18GY / A9FA 18GY NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / B9M 16GY B9N 16GY / A9VL 14GY / Figure 98 / ZERO VOLT

3.62. ZERO VOLT REFERENCE SPLICE (CONT.), P. 59
Figure 99 ZERO VOLT REFERENCE SPLICE (CONT.)

Components: DOOR CONTROL SW (3201); FLASHER START SW (1138); FLASHER SW (1137); RED OVERRIDE SW (1139); REDUNDANT DOOR SW (3203); REFERENCE SPLICE (1005A); ZVR SPLICE (1005)
Wires (circuit gauge+color): A9A 16GY; A9W 18GY; A9X 18GY; A9Y 18GY; A9Z 18GY
See also sheets: CH16_02, CH16_07, CH3_58, CH6_19, CH6_20, CH6_22
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.62. ZERO VOLT / SPLICE (CONT.), P. 59 / ZERO VOLT / SPLICE (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / CHAPTER 3 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ZERO VOLT SPLICE (1005A) / A9W 18GY / A9Y 18GY / A9Z 18GY / A9X 18GY / REDUNDANT DOOR SW (3203) CH16_07 FLASHER START SW (1138) CH6_20 DOOR CONTROL SW (3201) CH16_02 / ZVR SPLICE (1005) CH3_58,95M / RED OVERRIDE SW (1139) CH6_22 / A9A 16GY / R MASTER FLASHER SW (1137) CH6_19 / A9W 18GY / Figure 99 / ZERO VOLT / SPLICE (CONT.)

Figure 100 ZERO VOLT REFERENCE SPLICE (CONT.)

Components: A/C RELAY (10308-R4); ALARM RELAY (10310-R6); ALTERNATE ENTRANCE DOOR (10203); BOOSTER PUMP RELAY (10311-R5); CHILD SAFETY ALARM RELAY (10310-R6); DOOR CONTROL RELAY 1 (10309-R1); DOOR CONTROL SW (10200); DOOR SW ZERO VOLT REF (11600A); ELEC PANEL/PLATFORM (1702); FLASHER CANCEL (10239); FLASHER OVERRIDE (10238); FLASHER START SW (10237); FLASHER SYSTEM RELAY (10311-R6); FR CAP/ELEC PANEL (10001); HAZARD LT SW (10256B); LDW DISABLE/ENABLE (10283); MASTER FLASHER (10236); POS TOGGLE WITH AMBER CANCEL (11770); PWL RELAY (10308-R3); REDUNDANT DOOR SW (10365); ZERO VOLT REFERENCE (1005); ZVR SPLICE (10350A); ZVR SPLICE (10350B)
Wires (circuit gauge+color): A9D 16GY; B123A 18LTGN; B123B 18GY; B152-G 18WH; B60BA 18OR; B67-GA 18WH; B77D 18LTGN; B9A 18GY; B9B 18GY; B9C 18GY; B9D 18GY; B9E 18GY; B9F 18LTGN; B9H 18GY; B9J 18LTGN; B9K 18GY; B9L 16GY; B9M 16GY; B9N 16GY; B9P 18GY; B9S 18GY
See also sheets: CH13_55, CH15_24, CH16_01, CH16_03, CH16_04, CH16_05, CH16_06, CH16_08, CH16_22, CH18_40, CH19_38, CH3_58, CH6_15, CH6_16, CH6_17, CH6_18, CH6_20, CH6_21, CH7_65
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.63. ZERO VOLT / SPLICE (CONT.), P. 60 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / CHAPTER 3 SPLICE (CONT.) / ZERO VOLT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B A / B9B 18GY B9A 18GY B9D 18GY B9C 18GY B9C 18GY / B9B 18GA B9A 18GY B67-GA 18WH B152-G 18WH B9P 18GY B9N 16GY ELEC PANEL/PLATFORM (1702) 1 A9D 16GY B77D 18LTGN / B60BA 18OR B9K 18GY B9H 18GY B9E 18GY / B9L 16GY / B9F 18LTGN B9J 18LTGN B9H 18GY B123B 18GY B123A 18LTGN B9S 18GY B9S 18GY / ZVR SPLICE (10350B) F / Figure 100 / ZERO VOLT / SPLICE (CONT.)

3.64. ENGINE GROUND W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 61
Figure 101 ENGINE GROUND W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: AMMETER SENSE (6334); AMP AMMETER SENSOR (6335); FAN CLUTCH (6406M); FREON COMPRESSOR (6200); FREON COMPRESSOR (6202); FUEL HTR RELAY (4007); GROUND SPLICE (6704M); IGN FAN RELAY (4014); LOW HYD FLUID LEVEL (4034); PAM MODULE (4087); RELAY (4016)
Wires (circuit gauge+color): K10-GA 12WH; K10-GAB 18WH; K10-GB 16WH; K23-G 18WH; K23-G1 20TN; K23-G2 18WH; K26-G 18WH; K77A-G 16WH; K90-G 18GY; K97-GFA 18WH
See also sheets: CH11_08, CH11_09, CH13_01, CH13_19, CH13_34, CH5_08, CH5_10
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.64. ENGINE GROUND W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 61 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / CHAPTER 3 ENGINE GROUND - W/2017/2021 ISB/B6.7 DIESEL ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (6704M) A / K90-G 18GY K77A-G 16WH K77A-G 16WH K10-GB 16WH / UPPER GROUND STUD (2G) AIR DRYER/DV2 VALVE RELAY (4016) CH13_01 / K26-G 18WH K26-G 18WH / K97-GFA 18WH / K10-GAB 18WH / K10-GA 12WH / K23-G 18WH / FAN CLUTCH (6406M) CH11_08 / K26-G 18WH / K23-G2 18WH / IGN FAN RELAY (4014) CH11_08 / K23-G1 20TN / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 101 / ENGINE GROUND W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE

3.65. ENGINE GROUND W/ F 2018 PROPANE ENGINE, P. 62
Figure 102 ENGINE GROUND W/ F 2018 PROPANE ENGINE

Components: DV2 VALVE RELAY (4015); FUEL PUMP RELAY (4103); RELAY (4101); TCM NEUTRAL RELAY (4009); VALVE RELAY (4011); VALVE RELAY (4016)
Wires (circuit gauge+color): K10-GA 18WH; K10-GAB 14WH; K10-GB 18WH; K10-GC 10WH; K10-GD 10WH; K10C-G 18WH; K10D-G 18WH; K10E-G 18WH
See also sheets: CH13_01, CH4_02, CH5_17
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.65. ENGINE GROUND W/ F 2018 PROPANE ENGINE, P. 62 / CHAPTER 3 ENGINE GROUND - W/F-2018-PROPANE-ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K10-GC 10WH / UPPER GROUND STUD (3G) / K10-GAB 14WH / K10-GA 18WH / K10C-G 18WH / K10-GB 18WH / K10-GD 10WH / K10D-G 18WH / K10D-G 18WH / K10E-G 18WH / K10E-G 18WH / K10C-G 18WH / FUEL SUPPLY VALVE RELAY (4011) CH5_17 / FUEL RETURN VALVE RELAY (4016) CH5_17 / FUEL PUMP RELAY (4103) CH5_17 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 102 / ENGINE GROUND W/ F 2018 PROPANE ENGINE

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 143 | printed page 103 | section 3.66
3.66. ENGINE GROUND W/ F 2018 GASOLINE ENGINE, P. 63
Figure 103 ENGINE GROUND W/ F 2018 GASOLINE ENGINE

Components: DV2 VALVE RELAY (4015); RELAY (4103)
Wires (circuit gauge+color): K10-GAB 14WH; K10-GC 10WH; K10-GD 10WH; K10E-G 18WH
See also sheets: CH13_01, CH5_15
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.66. ENGINE GROUND W/ F 2018 GASOLINE ENGINE, P. 63 / CHAPTER 3 ENGINE GROUND - W/F-2018-GASOLINE-ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K10-GC 10WH / FUEL PUMP RELAY (4103) CH5_15 / UPPER GROUND STUD (3G) / K10-GAB 14WH / AIR DRYER/ DV2 VALVE RELAY (4015) CH13_01 / K10-GD 10WH / K10E-G 18WH / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 103 / ENGINE GROUND W/ F 2018 GASOLINE ENGINE

3.67. BATTERY ECM POSITIVE / NEGATIVE CONN W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 64
Figure 104 BATTERY ECM POSITIVE / NEGATIVE CONN W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: CROSSOVER (6022); DEF PUMP RELAY (4103); ECM CONN (6021); GEN4 TCM (7150); INTERCONNECT KEY A (6365); INTERCONNECT KEY B (6366); MODULE HTR FUSE (4108); NEGATIVE CONN (9260); NTERCONNECTION KEY A (6365B); POSITIVE CONN (9261); TCM VEHICLE UPPER (7105); TRNAS MODULE 1 (1232); VEHICLE UPPER (7105)
Wires (circuit gauge+color): K10-GC 16WH; K10-GD 16WH; K14 16RD; K14AA 16RD; K14E 12RD; K92A109 10WH; K92A110 10RD; K95-GG 10WH; K95-GG 12WH; K95-GH 14WH; K95-GH1 18WH; K95-GH2 18TN; K95-GHA 18WH; K95-GJ 14WH; K95-GK 14WH; K95-GK 18WH
See also sheets: CH11_01, CH11_02, CH11_06, CH11_07, CH12_10, CH12_12, CH12_15
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.67. BATTERY ECM POSITIVE / NEGATIVE CONN W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 64 / CHAPTER 3 BATTERY ECM POSITIVE / NEGATIVE CONN W/2017/2021 ISB/B6.7 DIESEL-ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K97 K97 10VT 10VT / BATTERY ECM POSITIVE CONN (9261) / *K14AA 16RD K92A110 10RD / K92#109 18GY K92#169 18GY K92#109 18GY K92#169 18GY / K95-GHA 18WH K95-GJ 14WH K95-GJ K95-GJ 14WH 14WH K95-GK 18WH / K95-GG 12WH K95-GG 10WH / K10-GD 16WH K10-GC 16WH K92A109 10WH / POWERTRAIN/DEF INTERCONNECT KEY B (6366) CH11_07 EATON PROCISSION TRANSMISSION VEHICLE UPPER (7105) CH12_15 / BATTERY ECM NEGATIVE CONN (9260) / K95-GH 14WH / K95-GK 14WH K95-GH1 18WH K95-GH2 18TN / GEN4 TCM (7150) CH12_10 / K97FA 10VT / K97FBA 16VT K97FBB 16VT K97FAC 16VT K97FAB 16VT K97FAA 16VT / ECM CONN (6021) CH11_01 / K14E 12RD #K14 16RD / K92#110 18PK K92#170 18PK K92#110 18PK K92#170 18PK / K97FB 10VT / TRNAS MODULE 1 (1232) CH12_12 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / # W/CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK * W/CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK / Figure 104 / BATTERY ECM POSITIVE / NEGATIVE CONN W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE

3.68. BATTERY ECM POSITIVE / NEGATIVE CONN W/ F 2018 PROPANE ENGINE, P. 65
Figure 105 BATTERY ECM POSITIVE / NEGATIVE CONN W/ F 2018 PROPANE ENGINE

Components: AC COMPRESSOR (6200); CONNECTOR (6021); ECM FUSE (4108); GEN 5 TCM (7150); GEN5 TCM (7150); INTERCONNECTION (6200A); NEGATIVE CONN (9260); POSITIVE CONN (9261); POWERTRAIN RELAY (4007)
Wires (circuit gauge+color): K77H-G 16WH; K77HA-G 10WH; K77HB-G 16WH; K77HC-G 16WH; K92A109 10WH; K92A110 10RD; K97 10RD; K97-G 12WH; K97KA 12RD; K97P 6RD; K97PE 10RD
See also sheets: CH11_11, CH11_12, CH11_16, CH12_18
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.68. BATTERY ECM POSITIVE / NEGATIVE CONN W/ F 2018 PROPANE ENGINE, P. 65 / CHAPTER 3 BATTERY ECM POSITIVE / NEGATIVE CONN W/F-2018-PROP-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / MJV0488 19NOV21 ADDED CIRC K77HA-G, B K77HB-G,K77HC-G AT R/D 9260. / BATTERY ECM POSITIVE CONN (9261) / GEN 5 TCM (7150) CH12_18 / K97-G 12WH / K92#109 18GY / K92A109 10WH / AC COMPRESSOR (6200) CH11_12 / BATTERY ECM NEGATIVE CONN (9260) / GEN5 TCM (7150) CH12_18 / VEHICLE INTERFACE CONNECTOR (6021) CH11_11 / K97P 6RD / K97KA 12RD / POWERTRAIN RELAY (4007) CH11_11 / K92A110 10RD / K92#170 18PK / K77H-G 16WH / K97 10RD / K97PE 10RD / ECM FUSE (4108) CH11_11 / K92#110 18PK / K92#169 18GY / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / K77HA-G 10WH / K77HB-G 16WH / K77HC-G 16WH / AC COMPRESSOR INTERCONNECTION (6200A) CH11_16 / Figure 105 / BATTERY ECM POSITIVE / NEGATIVE CONN W/ F 2018 PROPANE ENGINE

3.69. BATTERY ECM POSITIVE / NEGATIVE CONN W/ F 2018 GASOLINE ENGINE, P. 66
Figure 106 BATTERY ECM POSITIVE / NEGATIVE CONN W/ F 2018 GASOLINE ENGINE

Components: AC COMPRESSOR (6200); CONNECTOR (6021); ECM FUSE (6108); ECM NEGATIVE (9260); ECM POSITIVE (9261); GEN 5 TCM (7150); GEN5 TCM (7150); INTERCONNECTION (6200A); POWERTRAIN RELAY (4007)
Wires (circuit gauge+color): K77H-G 16WH; K77HA-G 10WH; K77HB-G 16WH; K77HC-G 16WH; K92A109 10WH; K92A110 10RD; K97 10RD; K97-G 12WH; K97KA 12RD; K97P 6RD; K97PE 10RD
See also sheets: CH11_14, CH11_15, CH11_16, CH12_21
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.69. BATTERY ECM POSITIVE / NEGATIVE CONN W/ F 2018 GASOLINE ENGINE, P. 66 / CHAPTER 3 BATTERY ECM POSITIVE / NEGATIVE CONN W/F-2018-GAS-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / MJV0488 19NOV21 ADDED CIRC K77HA-G, B K77HB-G,K77HC-G AT R/D 9260. / ECM POSITIVE (9261) / GEN 5 TCM (7150) CH12_21 / K97-G 12WH / K92#109 18GY / K92A109 10WH / VEHICLE INTERFACE CONNECTOR (6021) CH11_14 AC COMPRESSOR (6200) CH11_15 / ECM NEGATIVE (9260) / GEN5 TCM (7150) CH12_21 / K97P 6RD / K97KA 12RD / POWERTRAIN RELAY (4007) CH11_14 / K92A110 10RD / K92#170 18PK / K77H-G 16WH / K97 10RD / K97PE 10RD / ECM FUSE (6108) CH11_14 / K92#110 18PK / K92#169 18GY / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / K77HA-G 10WH / K77HB-G 16WH / K77HC-G 16WH / AC COMPRESSOR INTERCONNECTION (6200A) CH11_16 / Figure 106 / BATTERY ECM POSITIVE / NEGATIVE CONN W/ F 2018 GASOLINE ENGINE

3.70. DC POWER EFFECTS, P. 67
Figure 107 DC POWER EFFECTS

Components: DC POWER (10375A); DC POWER SOURCE (10375); FUSE B6-A (10303); IN SWITCH PANEL (10375B); SPLICE PACK (10360B)
Wires (circuit gauge+color): B84 16LTGN; B84-G 16WH; B84-GA 16WH; B84-GB 16WH; B84A 16LTGN; B84B 16LTGN
See also sheets: CH3_14, CH3_42
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.70. DC POWER EFFECTS, P. 67 / CHAPTER 3 / DC POWER EFFECTS / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 0 GND SPLICE PACK (10360B) CH3_42 / %B84-GA 16WH @B84-G 16WH / %B84A 16LTGN / @B84 16LTGN %B84 16LTGN / %B84B 16LTGN %B84-GB 16WH / DC POWER SOURCE (10375) / DC POWER (10375A) / DC POWER OUTLET IN SWITCH PANEL (10375B) / *B84-G 16WH / *B84 16LTGN / * W/DC PWR SOURCE IN SW PANEL @ W/DC PWR SOURCE LOCATED IN DASH % W/2DC PWR SOURCE LOCATED IN DASH & OVHD / FUSE B6-A (10303) CH3_14 / FUSE B6-A (10303) CH3_14 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 107 / DC POWER EFFECTS

3.71. DC POWER EFFECTS W/ 2017 ISB DIESEL ENGINE, P. 67A
Figure 108 DC POWER EFFECTS W/ 2017 ISB DIESEL ENGINE

Components: DC POWER (10375A); DC POWER SOURCE (10375); ELEC PANEL (1702); FUSE 28 (10303); FUSE F71 (10306); IN SW PANEL (10375B); SOURCE (1908)
Wires (circuit gauge+color): A84-G 16WH; A84A 16LTGN; B84 16LTGN; B84-G 16WH; B84-GA 16WH; B84-GB 16WH; B84A 16LTGN; B84B 16LTGN
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.71. DC POWER EFFECTS W/ 2017 ISB DIESEL ENGINE, P. 67A / CHAPTER 3 DC POWER EFFECTS W/2017-ISB-DIESEL-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND STUD (OGND) / %B84-GA 16WH @B84-G 16WH / %B84A 16LTGN / DC POWER SOURCE (1908) / @B84 16LTGN B84 16LTGN / B84B 16LTGN B84-GB 16WH / A84A 16LTGN / DC POWER SOURCE (10375) / A84-G 16WH / PLATFORM/ ELEC PANEL (1702) 43 / GND SPLICE PACK#2 (1004) CH3_95A / FUSE 28 (10303) CH3_94G / DC POWER (10375A) / DC POWER OUTLET IN SW PANEL (10375B) / *B84-G 16WH / *B84 16LTGN / FUSE F71 (10306) CH3_94N / @ W/SINGLE DC OUTLET % W/DUAL DC OUTLET * W/SW PANEL / Figure 108 / DC POWER EFFECTS W/ 2017 ISB DIESEL ENGINE

3.72. BATTERY ISOLATOR, P. 68
Figure 109 BATTERY ISOLATOR

Components: ENGINE (11500); FUSE A1-G (10305); FUSE F66 (10306); GROUND SPLICE (11507)
Wires (circuit gauge+color): B140 18TN; Y140 18TN; Y140-G 18WH
See also sheets: CH3_17, CH3_48
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.72. BATTERY ISOLATOR, P. 68 / CHAPTER 3 / BATTERY ISOLATOR / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / BATTERY ISOLATOR #(11521) / %B140 18TN / Y140 18TN / ELEC PANEL/ @B140 SEALED 18TN ENGINE (11500) D2 / Y140-G 18WH / GROUND SPLICE (11507) CH3_48 / FUSE F66 (10306) CH3_94N FUSE A1-G (10305) CH3_17 / Figure 109 / BATTERY ISOLATOR

3.73. J1939 DATALINK W/ 500K W/ LCT / WTEC XMSN W/ 2017 ISB / 2021 B6.7 DIESEL
Figure 110 J1939 DATALINK W/ 500K W/ LCT / WTEC XMSN W/ 2017 ISB / 2021 B6.7 DIESEL & F-2018

Components: BODY CONTROLLER (1602); INSTRUMENT CLUSTER (1505); K BAUD (1651); PLATFORM/ENG (1701); RESISTOR (1657M); RESISTOR (7801M)
See also sheets: CH3_86, CH3_90
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.73. J1939 DATALINK W/ 500K W/ LCT / WTEC XMSN W/ 2017 ISB / 2021 B6.7 DIESEL & F-2018 PROPANE / GASOLINE ENGINE, P. 69 / CHAPTER 3 J1939 DATALINK W/500K W/LCT/WTEC XMSN W/2017/2021 ISB/B6.7 DIESEL & F-2018-PROPANE/GASOLINE ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / INSTRUMENT CLUSTER (1505) J1939(+) J1939(-) 12 11 / A5BS(+) 18YL / @K5F(-) 20GN @K5F(+) 20YL %K5A(-) 20GN %K5A(+) 20YL J5-TAN BODY CONTROLLER (1602) F2 J1939 - / A5BJ(-) 18GN A5BJ(+) 18YL / F3 J1939 + / H J1939(-) / J J1939(+) / DIAGNOSTIC CONN 500K BAUD (1651) / 120 OHMS / J1939 TERMINATING RESISTOR (1657M) / PLATFORM/ENG (1701) / A5BT(-) 18GN / A5BP(+) 18YL / A5BR(-) 18GN / A5BN(-) 18GN A5BM(+) 18YL / A5BA(+) 18YL A5BB(-) 18GN / B5BC(+) 18YL / B5BD(-) 18GN / A5BE(+) 18YL / A5BF(-) 18GN / J1939 TERM RESISTOR (7801M) CH3_86,87,88 J1939 TERM RESISTOR (7801M) CH3_90,91 / @ W/2017/2021 ISB/B6.7 DIESEL ENGINE % W/F-2018-PROPANE/GASOLINE ENGINE / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 110 / J1939 DATALINK W/ 500K W/ LCT / WTEC XMSN W/ 2017 ISB / 2021 B6.7 DIESEL & F-2018 PROPANE / GASOLINE ENGINE

3.74. J1939 DATALINK W/ 500K W/ LCT / BENDIX ABS-8 W/ 2017 ISB / 2021 B6.7
Figure 111 J1939 DATALINK W/ 500K W/ LCT / BENDIX ABS-8 W/ 2017 ISB / 2021 B6.7 DIESEL &

Components: BODY CONTROLLER (1606); CONN X1 (9543); CONNECTOR (6021); ECM CONN (6021); ENGINE (1701); FWD CHASSIS (1700); K BAUD (1651); RESISTOR (1657); RESISTOR (7801M)
See also sheets: CH13_25, CH13_32, CH13_50, CH3_86, CH3_88, CH3_89
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.74. J1939 DATALINK W/ 500K W/ LCT / BENDIX ABS-8 W/ 2017 ISB / 2021 B6.7 DIESEL & F-2018 PROPANE / GASOLINE ENGINE, P. 70 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / CHAPTER 3 J1939 DATALINK W/500K W/LCT/BENDIX ABS-8 W/2017/2021 ISB/B6.7 DIESEL & F-2018-PROP/GAS-ENG / MJV0488 19NOV21 CIRC A5MA(+),A5MA(-) B 96289K WERE A5MG(+),A5MG(-) AT R/D 1651. / J6-18WAY BODY CONTROLLER (1606) / A5H(+) 18YL A5H(-) 18GN / A5S(-) 18GN / A5S(+) 18YL / 7 J1939 - / BENDIX AIR ABS-8 CONN X1 (9543) / A5F(+) 18YL A5F(-) 18GN / A5R(-) 18GN / A5R(+) 18YL / J1939 + 8 / J1939 - G / J1939 + H / PLATFORM/ FWD CHASSIS (1700) / A5AC(+) 18YL A5AC(-) 18GN / A5V(-) 18GN / A5V(+) 18YL / J1939 - D / J1939 + C / DIAGNOSTIC CONN 500K BAUD (1651) / A5MA(+) 18YL A5MA(-) 18GN / PLATFORM/ ENGINE (1701) / *K5A(-) 18GN / *K5A(+) 18YL / %K5B(-) 18GN %K5B(+) 18YL %K5G(-) 18GN %K5G(+) 18YL / VEHICLE INTERFACE CONNECTOR (6021) CH3_89,90,91 / ECM CONN (6021) CH3_88 / ECM CONN (6021) CH3_86,87 / % W/2017/2021 ISB/B6.7 DIESEL ENG * W/F-2018-PROP/GAS-ENG / M5E(+) 18YL M5E(-) 18GN / M5A(+) 18YL M5A(-) 18GN / M5(+) 18YL M5(-) 18GN / M5A(+) 18YL M5A(-) 18GN / J1939 TERM RESISTOR (7801M) CH13_25,28, 35,36,38, 42,47,48 / J1939 TERM RESISTOR (7801M) CH13_32 / J1939 TERM RESISTOR (1657) CH13_32,50 / J1939 TERM RESISTOR (1657) CH13_50 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 111 / J1939 DATALINK W/ 500K W/ LCT / BENDIX ABS-8 W/ 2017 ISB / 2021 B6.7 DIESEL & F-2018 PROPANE / GASOLINE ENGINE

3.75. J1939 DATALINK WITH 500K WITH LCT / ABS 8 / ZONAR WITH F 2017 ISB / 2021
Figure 112 J1939 DATALINK WITH 500K WITH LCT / ABS 8 / ZONAR WITH F 2017 ISB / 2021 B6.7

Components: BODY CONTROLLER (1606); CONN X1 (9543); CONNECTOR (6021); DATALINK (1350); ECM CONN (6021); ENGINE (1701); FWD CHASSIS (1700); K BAUD (1651); RESISTOR (1657); RESISTOR (7801M)
See also sheets: CH13_25, CH13_32, CH13_50, CH3_86, CH3_88, CH3_89
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.75. J1939 DATALINK WITH 500K WITH LCT / ABS 8 / ZONAR WITH F 2017 ISB / 2021 B6.7 DIESEL & F 2018 PROPANE / GASOLINE ENGINE, P. 71 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC A5MA(+),A5MA(-) B 96289K WERE A5MP(+),A5MP(-) AT R/D 1651. / J6-18WAY BODY CONTROLLER (1606) / A5H(+) 18YL A5H(-) 18GN / A5S(-) 18GN / A5S(+) 18YL / 7 J1939 - / BENDIX AIR ABS-8 CONN X1 (9543) 8 J1939 + / A5F(+) 18YL A5F(-) 18GN / A5Y(-) 18GN / A5Y(+) 18YL / J1939 - G / J1939 + H / A5AC(+) 18YL A5AC(-) 18GN / A5W(-) 18GN / A5W(+) 18YL / J1939 - 6 / J1939 + 1 / ZONAR V3 DATALINK (1350) / A5J(+) 20YL A5J(-) 20GN / PLATFORM/ ENGINE (1701) / *K5A(-) 18GN / *K5A(+) 18YL / %K5B(-) 18GN %K5B(+) 18YL %K5G(-) 18GN %K5G(+) 18YL / VEHICLE INTERFACE CONNECTOR (6021) CH3_89,90,91 / ECM CONN (6021) CH3_88 / ECM CONN (6021) CH3_86,87 / % W/2017/2021 ISB/B6.7 DIESEL ENG * W/F-2018-PROP/GAS-ENG / DIAGNOSTIC CONNECTOR 500K BAUD (1651) J1939 + C / J1939 - D / A5MA(+) 18YL A5MA(-) 18GN / A5R(-) 18GN / A5R(+) 18YL / PLATFORM/ FWD CHASSIS (1700) / M5E(+) 18YL M5E(-) 18GN / M5A(+) 18YL M5A(-) 18GN / M5(+) 18YL M5(-) 18GN / M5A(+) 18YL M5A(-) 18GN / J1939 TERM RESISTOR (7801M) CH13_25,28, 35,36,38, 42,47,48 / J1939 TERM RESISTOR (7801M) CH13_32 / J1939 TERM RESISTOR (1657) CH13_32,50 / J1939 TERM RESISTOR (1657) CH13_50 / Figure 112 / J1939 DATALINK WITH 500K WITH LCT / ABS 8 / ZONAR WITH F 2017 ISB / 2021 B6.7 DIESEL & F 2018 PROPANE / GASOLINE ENGINE

3.76. J1939 DATALINK WITH 500K WITH LCT / WINGMAN / ZONAR WITH F 2017 ISB /
Figure 113 J1939 DATALINK WITH 500K WITH LCT / WINGMAN / ZONAR WITH F 2017 ISB / 2021 B6.7

Components: BODY CONTROLLER (1606); CONN X1 (9543); CONNECTOR (6021); DATALINK (1350); ECM CONN (6021); FWD CHASSIS (1700); K BAUD (1651); PLATFORM/ENGINE (1701); RESISTOR (1657); RESISTOR (7801M); UNIT (9548)
See also sheets: CH13_25, CH13_32, CH13_50, CH3_86, CH3_88, CH3_89
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.76. J1939 DATALINK WITH 500K WITH LCT / WINGMAN / ZONAR WITH F 2017 ISB / 2021 B6.7 DIESEL & F 2018 PROPANE / GASOLINE ENGINE, P. 72 / CHAPTER 3 J1939 DATALINK W/500K W/LCT/WINGMAN/ZONAR W/2017/2021 ISB/B6.7 DIESEL & F-2018-PROP/GAS-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC A5MA(+),A5MA(-) B 96289K WERE A5MW(+),A5MW(-) AT R/D 1651. / J6-18WAY BODY CONTROLLER (1606) J1939 + H / A5H(+) 18YL A5H(-) 18GN / A5S(-) 18GN / A5S(+) 18YL / 7 J1939 - / BENDIX AIR ABS-8 CONN X1 (9543) / A5F(+) 18YL A5F(-) 18GN / A5ABF(-) 18GN / A5ABF(+) 18YL / A5R(-) 18GN / A5R(+) 18YL / J1939 + 8 / J1939 - G / A5AC(+) 18YL A5AC(-) 18GN / A5W(-) 18GN / A5W(+) 18YL / J1939 + 1 / ZONAR V3 DATALINK (1350) 6 J1939 - / A5J(-) 20GN A5J(+) 20YL / DRIVER INTERFACE UNIT (9548) J1939 - 6 / J1939 + 7 / A5L(-) 18GN A5L(+) 18YL / J1939 + C / DIAGNOSTIC CONN 500K BAUD (1651) J1939 - D / A5MA(-) 18GN A5MA(+) 18YL / PLATFORM/ENGINE (1701) / A5AA(-) 18GN / A5AA(+) 18YL / *K5A(-) 18GN / *K5A(+) 18YL / %K5B(-) 18GN %K5B(+) 18YL %K5G(-) 18GN %K5G(+) 18YL / VEHICLE INTERFACE CONNECTOR (6021) CH3_89,90,91 NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / ECM CONN (6021) CH3_88 / ECM CONN (6021) CH3_86,87 / % W/2017/2021 ISB/B6.7 DIESEL ENG * W/F-2018-PROP/GAS-ENG / PLATFORM/ FWD CHASSIS (1700) / M5E(+) 18YL M5E(-) 18GN / M5A(+) 18YL M5A(-) 18GN / M5(+) 18YL M5(-) 18GN / M5A(+) 18YL M5A(-) 18GN / J1939 TERM RESISTOR (7801M) CH13_25,28, 35,36,38, 42,47,48 / J1939 TERM RESISTOR (7801M) CH13_32 / J1939 TERM RESISTOR (1657) CH13_32,50 / J1939 TERM RESISTOR (1657) CH13_50 / Figure 113 / J1939 DATALINK WITH 500K WITH LCT / WINGMAN / ZONAR WITH F 2017 ISB / 2021 B6.7 DIESEL & F 2018 PROPANE / GASOLINE ENGINE

3.77. J1939 DATALINK WITH 500K WITH BENDIX FUSION WITH 2017 ISB / 2021 B6.7
Figure 114 J1939 DATALINK WITH 500K WITH BENDIX FUSION WITH 2017 ISB / 2021 B6.7 DIESEL & F

Components: BODY CONTROLLER (1606); CONN X1 (9543); CONNECTOR (6021); ECM CONN (6021); ELEC PANEL/FR CAP (10001); ENGINE (1701); FWD CHASSIS (1700); K BAUD (1651); PANEL (1703/@1703C/%1703); RESISTOR (1657); RESISTOR (7801M); UNIT (9548)
See also sheets: CH13_25, CH13_50, CH13_55, CH3_86, CH3_88, CH3_89
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.77. J1939 DATALINK WITH 500K WITH BENDIX FUSION WITH 2017 ISB / 2021 B6.7 DIESEL & F 2018 PROPANE / GASOLINE ENGINE, P. 73 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC A5MA(+),A5MA(-) B 96289K WERE A5MT(+),A5MT(-) AT R/D 1651. / A5H(+) 18YL A5H(-) 18GN / A5P(-) 18GN / A5P(+) 18YL / 7 J1939 - / BENDIX AIR ABS-8 CONN X1 (9543) J1939 + 8 / A5F(+) 18YL A5F(-) 18GN / A5R(-) 18GN / A5R(+) 18YL / J1939 - G / J1939 + H / A5AC(+) 18YL A5AC(-) 18GN / A5Z(-) 18GN / A5Z(+) 18YL / PLATFORM/ELECTRICAL PANEL (1703/@1703C/%1703) A13 / A5NE(-) 18GN A5NE(+) 18YL / @A5AK(+) 18YL @A5AK(-) 18LTGN / J1939 - 6 / J1939 + 7 / A5L(-) 18GN A5L(+) 18YL / DRIVER INTERFACE UNIT (9548) / J1939 + C / J1939 - D / DIAGNOSTIC CONN 500K BAUD (1651) / A5MA(-) 18GN A5MA(+) 18YL / PLATFORM/ ENGINE 46 (1701) / A5AA(-) 18GN / A5AA(+) 18YL / %K5B(-) 18GN %K5B(+) 18YL %K5G(-) 18GN %K5G(+) 18YL / *K5A(-) 18GN / *K5A(+) 18YL / VEHICLE INTERFACE CONNECTOR (6021) CH3_89,90,91 / ECM CONN (6021) CH3_88 / ECM CONN (6021) CH3_86,87 / % W/2017/2021 ISB/B6.7 DIESEL ENG * W/F-2018-PROP/GAS-ENG NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / PLATFORM/ FWD CHASSIS (1700) / M5E(+) 18YL M5E(-) 18GN / M5(+) 18YL M5(-) 18GN / M5A(+) 18YL M5A(-) 18GN / J1939 TERM RESISTOR (7801M) CH13_25,28, 35,36,38, 42,47,48 / J1939 TERM RESISTOR (1657) CH13_50 / J1939 TERM RESISTOR (1657) CH13_50 / %B5(+) %B5(-) %B5A(+) %B5A(-) 18YL 18GN 18YL 18GN / ELEC PANEL/FR CAP (10001) CH13_55 / Figure 114 / J1939 DATALINK WITH 500K WITH BENDIX FUSION WITH 2017 ISB / 2021 B6.7 DIESEL & F 2018 PROPANE / GASOLINE ENGINE

3.78. J1939 DATALINK W/ 500K W/ LCT / BENDIX WINGMAN W/ 2017 IBS / 2021 B6.7
Figure 115 J1939 DATALINK W/ 500K W/ LCT / BENDIX WINGMAN W/ 2017 IBS / 2021 B6.7 DIESEL &

Components: BODY CONTROLLER (1606); CONN X1 (9543); CONNECTOR (6021); ECM CONN (6021); ENGINE (1701); FWD CHASSIS (1700); K BAUD (1651); RESISTOR (1657); RESISTOR (7801M); UNIT (9548)
See also sheets: CH13_25, CH13_50, CH3_86, CH3_88, CH3_89
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.78. J1939 DATALINK W/ 500K W/ LCT / BENDIX WINGMAN W/ 2017 IBS / 2021 B6.7 DIESEL & F-2018 PROPANE / GASOLINE ENGINE, P. 74 / CHAPTER 3 J1939 DATALINK W/500K W/LCT/BENDIX WINGMAN W/2017/2021 ISB/B6.7 DIESEL & F-2018-PROP/GAS-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC A5MA(+),A5MA(-) B 96289K WERE A5MR(+),A5MR(-) AT R/D 1651. / J6-18WAY BODY CONTROLLER (1606) / A5H(+) 18YL A5H(-) 18GN / A5S(-) 18GN / A5S(+) 18YL / 7 J1939 - / BENDIX AIR ABS-8 CONN X1 (9543) / A5F(+) 18YL A5F(-) 18GN / A5R(-) 18GN / A5R(+) 18YL / 8 J1939 + / J1939 - G / J1939 + H / A5AC(+) 18YL A5AC(-) 18GN / A5AD(-) 18GN / A5AD(+) 18YL / J1939 - 6 / J1939 + 7 / A5L(-) 18GN A5L(+) 18YL / DRIVER INTERFACE UNIT (9548) / J1939 + C / J1939 - D / DIAGNOSTIC CONN 500K BAUD (1651) / A5MA(-) 18GN A5MA(+) 18YL / PLATFORM/ ENGINE (1701) / A5AA(-) 18GN / A5AA(+) 18YL / *K5A(+) 18YL / %K5B(-) 18GN %K5B(+) 18YL %K5G(-) 18GN %K5G(+) 18YL / VEHICLE INTERFACE CONNECTOR (6021) CH3_89,90,91 / ECM CONN (6021) CH3_88 / ECM CONN (6021) CH3_86,87 / *K5A(-) 18GN / M5E(+) 18YL M5E(-) 18GN / J1939 TERM RESISTOR (1657) CH13_50 / M5(+) 18YL M5(-) 18GN / M5A(+) 18YL M5A(-) 18GN / J1939 TERM RESISTOR (1657) CH13_50 / J1939 TERM RESISTOR (7801M) CH13_25,28, 35,36,38, 42,47,48 / PLATFORM/ FWD CHASSIS (1700) / % W/2017/2021 ISB/B6.7 DIESEL ENG * W/F-2018-PROP/GAS-ENG / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 115 / J1939 DATALINK W/ 500K W/ LCT / BENDIX WINGMAN W/ 2017 IBS / 2021 B6.7 DIESEL & F-2018 PROPANE / GASOLINE ENGINE

3.79. J1939 DATALINK W/ 500K W/ LCT / FUSION / ZONAR W/ 2017 IBS / 2021 B6.7
Figure 116 J1939 DATALINK W/ 500K W/ LCT / FUSION / ZONAR W/ 2017 IBS / 2021 B6.7 DIESEL &

Components: BODY CONTROLLER (1606); CONN X1 (9543); CONNECTOR (6021); DATALINK (1350); ECM CONN (6021); ELEC PANEL/FR CAP (10001); ENGINE (1701); FWD CHASSIS (1700); K BAUD (1651); PANEL (1703/@1703C/%1703); RESISTOR (1657); RESISTOR (7801M); UNIT (9548)
See also sheets: CH13_25, CH13_50, CH13_55, CH3_86, CH3_88, CH3_89
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.79. J1939 DATALINK W/ 500K W/ LCT / FUSION / ZONAR W/ 2017 IBS / 2021 B6.7 DIESEL & F-2018 PROPANE / GASOLINE ENGINE, P. 75 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC A5MA(+),A5MA(-) B 96289K WERE A5MZ(+),A5MZ(-) AT R/D 1651. / A5H(+) 18YL A5H(-) 18GN / A5P(-) 18GN / A5P(+) 18YL / 7 J1939 - / BENDIX AIR ABS-8 CONN X1 (9543) / A5F(+) 18YL A5F(-) 18GN / A5AB(-) 18GN / A5AB(+) 18YL / A5R(-) 18GN PLATFORM/ ENGINE 46 (1701) %K5B(-) 18GN %K5B(+) 18YL %K5G(-) 18GN %K5G(+) 18YL / A5R(+) 18YL / 8 J1939 + / J1939 - G / J1939 + H / A5AC(+) 18YL A5AC(-) 18GN / A5W(-) 18GN / A5W(+) 18YL / PLATFORM/ELECTRICAL PANEL (1703/@1703C/%1703) A13 / A5NE(-) 18GN A5NE(+) 18YL / J1939 + 1 / ZONAR V3 DATALINK (1350) / J1939 - 6 / A5J(-) 20GN A5J(+) 20YL / J1939 - 6 / J1939 + 7 / A5L(-) 18GN A5L(+) 18YL / DRIVER INTERFACE UNIT (9548) / J1939 + C / DIAGNOSTIC CONN 500K BAUD (1651) D J1939 - / A5MA(-) 18GN A5MA(+) 18YL / A5AA(-) 18GN / A5AA(+) 18YL / ECM CONN (6021) CH3_88 / *K5A(+) 18YL / *K5A(-) 18GN / VEHICLE INTERFACE CONNECTOR (6021) CH3_89,90,91 NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / % W/2017/2021 ISB/B6.7 DIESEL ENG * W/F-2018-PROP/GAS-ENG / ECM CONN (6021) CH3_86,87 / @A5AK(+) 18YL @A5AK(-) 18LTGN / M5E(+) 18YL M5E(-) 18GN / J1939 TERM RESISTOR (1657) CH13_50 / M5(+) 18YL M5(-) 18GN / M5A(+) 18YL M5A(-) 18GN / J1939 TERM RESISTOR (1657) CH13_50 / J1939 TERM RESISTOR (7801M) CH13_25,28, 35,36,38, 42,47,48 / PLATFORM/ FWD CHASSIS (1700) / %B5(+) %B5(-) %B5A(-) %B5A(+) 18YL 18GN 18YL 18GN / ELEC PANEL/FR CAP (10001) CH13_55 / Figure 116 / J1939 DATALINK W/ 500K W/ LCT / FUSION / ZONAR W/ 2017 IBS / 2021 B6.7 DIESEL & F-2018 PROPANE / GASOLINE ENGINE

3.80. J1939 DATALINK W/ 500K W/ LCT OR E-PRO W/ 2017 IBS / 2021 B6.7 DIESEL &
Figure 117 J1939 DATALINK W/ 500K W/ LCT OR E-PRO W/ 2017 IBS / 2021 B6.7 DIESEL & F-2018

Components: BODY CONTROLLER (1606); CONNECTOR (6021); ECM CONN (6021); FWD CHASSIS (1700); K BAUD (1651); PLATFORM/ENGINE (1701); RESISTOR (1657); RESISTOR (7801M)
See also sheets: CH13_25, CH13_50, CH3_86, CH3_88, CH3_89
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.80. J1939 DATALINK W/ 500K W/ LCT OR E-PRO W/ 2017 IBS / 2021 B6.7 DIESEL & F-2018 PROPANE / GASOLINE ENGINE, P. 76 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / CHAPTER 3 J1939 DATALINK W/500K W/LCT OR E-PRO W/2017/2021 ISB/B6.7 DIESEL & F-2018-PROP/GAS-ENG / MJV0488 19NOV21 CIRC A5MA(+),A5MA(-) B 96289K WERE A5ML(+),A5ML(-) AT R/D 1651. / J6-18WAY BODY CONTROLLER (1606) / A5H(+) 18YL A5H(-) 18GN / A5R(-) 18GN / A5R(+) 18YL / D J1939 - / DIAGNOSTIC CONN 500K BAUD (1651) C J1939 + / A5MA(+) 18YL A5MA(-) 18GN / A5U(-) 18GN / A5U(+) 18YL / J1939 - G / J1939 + H / PLATFORM/ FWD CHASSIS 31 (1700) / A5V(+) 18YL A5V(-) 18GN / PLATFORM/ENGINE (1701) %K5B(+) 18YL %K5B(-) 18GN %K5G(-) 18GN %K5G(+) 18YL / ECM CONN (6021) CH3_86,87 / VEHICLE INTERFACE CONNECTOR (6021) CH3_89,90,91 / ECM CONN (6021) CH3_88 / % W/2017/2021 ISB/B6.7 DIESEL ENG * W/F-2018-PROP/GAS-ENG / *K5A(+) 18YL / *K5A(-) 18GN / M5A(+) 18YL / M5(-) 18GN / M5(+) 18YL / M5E(+) 18YL / M5E(-) 18GN / M5A(-) 18GN / J1939 TERM RESISTOR (7801M) CH13_25,28, 35,36,38, 42,47,48 / J1939 TERM RESISTOR (1657) CH13_50 / J1939 TERM RESISTOR (1657) CH13_50 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 117 / J1939 DATALINK W/ 500K W/ LCT OR E-PRO W/ 2017 IBS / 2021 B6.7 DIESEL & F-2018 PROPANE / GASOLINE ENGINE

3.81. J1939 DATALINK W/ 500K W/ LCT OR E-PRO W/ ZONAR W/ 2017 IBS / 2021 B6.7
Figure 118 J1939 DATALINK W/ 500K W/ LCT OR E-PRO W/ ZONAR W/ 2017 IBS / 2021 B6.7 DIESEL &

Components: BODY CONTROLLER (1606); CONNECTOR (6021); DATALINK (1350); ECM CONN (6021); ENGINE (1701); FWD CHASSIS (1700); K BAUD (1651); RESISTOR (1657); RESISTOR (7801M)
See also sheets: CH13_25, CH13_50, CH3_86, CH3_88, CH3_89
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.81. J1939 DATALINK W/ 500K W/ LCT OR E-PRO W/ ZONAR W/ 2017 IBS / 2021 B6.7 DIESEL & F-2018 PROPANE / GASOLINE ENGINE, P. 77 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / CHAPTER 3 J1939 DATALINK W/500K W/LCT OR E-PRO W/ZONAR W/2017/2021 ISB/B6.7 DIESEL & F-2018-PROP/GAS-ENG / MJV0488 19NOV21 CIRC A5MA(+),A5MA(-) B 96289K WERE B5MF(+),B5MF(-) AT R/D 1651. / J6-18WAY BODY CONTROLLER (1606) / A5H(+) 18YL A5H(-) 18GN / A5Y(-) 18GN / A5Y(+) 18YL / 6 J1939 - / ZONAR V3 DATALINK (1350) / A5J(+) 20YL A5J(-) 20GN / 1 J1939 + / J1939 - G / J1939 + H / PLATFORM/ ENGINE (1701) %K5B(+) 18YL %K5B(-) 18GN %K5G(-) 18GN %K5G(+) 18YL / A5W(+) 18YL A5W(-) 18GN / A5U(-) 18YL / A5U(+) 18GN / PLATFORM/ FWD CHASSIS (1700) 31 / C J1939 + / A5MA(-) 18GN A5MA(+) 18YL / D J1939 - / DIAGNOSTIC CONN 500K BAUD (1651) / A5R(-) 18GN / A5R(+) 18YL / *K5A(-) 18GN / % W/2017/2021 ISB/B6.7 DIESEL ENG * W/F-2018-PROP/GAS-ENG / ECM CONN (6021) CH3_86,87 / VEHICLE INTERFACE CONNECTOR (6021) CH3_89,90,91 / ECM CONN (6021) CH3_88 / *K5A(+) 18YL / M5(+) 18YL / J1939 TERM RESISTOR (1657) CH13_50 / M5E(+) 18YL / M5A(-) 18GN / J1939 TERM RESISTOR (1657) CH13_50 / M5E(-) 18GN / M5A(+) 18YL / J1939 TERM RESISTOR (7801M) CH13_25,28, 35,36,38, 42,47,48 / M5(-) 18GN / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 118 / J1939 DATALINK W/ 500K W/ LCT OR E-PRO W/ ZONAR W/ 2017 IBS / 2021 B6.7 DIESEL & F-2018 PROPANE / GASOLINE ENGINE

3.82. J1939 DATALINK WITH 500K WITH WTEC W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE, P. 78
Figure 119 J1939 DATALINK WITH 500K WITH WTEC W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE

Components: CONTROLLER (1606); ECM CONN (6021); ENGINE (1701); FWD CHASSIS (1700); K BAUD (1651); RESISTOR (1657); RESISTOR (7801M); SELECTOR (1850)
See also sheets: CH13_25, CH13_50, CH3_86, CH3_88
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.82. J1939 DATALINK WITH 500K WITH WTEC W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE, P. 78 / CHAPTER CHAPTER 3 3 J1939 DATALINK W/500K W/WTEC W/2017/2021 ISB/B6.7 DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC A5MA(+),A5MA(-) B 96289K WERE B5MP(+),B5MP(-) AT R/D 1651. / J6-18WAY BODY CONTROLLER (1606) J1939 + H / A5H(+) 18YL A5H(-) 18GN / A5R(-) 18GN / A5R(+) 18YL / J1939 - G / A5U(+) 18YL A5U(-) 18GN / A5Z(-) 18GN / A5Z(+) 18YL / 15 J1939 - / J1939 + 8 / A5K(-) 18GN A5K(+) 18YL / SHIFT SELECTOR (1850) / J1939 + C / DIAGNOSTIC CONN 500K BAUD (1651) D J1939 - / A5MA(-) 18GN A5MA(+) 18YL / PLATFORM/ ENGINE (1701) / A5AAX(-) 18GN / A5AAX(+) 18YL / K5B(-) 18GN K5B(+) 18YL / ECM CONN (6021) CH3_88 NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / K5G(-) 18GN / K5G(+) 18YL / ECM CONN (6021) CH3_86,87 / M5E(+) 18YL M5E(-) 18GN / J1939 TERM RESISTOR (1657) CH13_50 / M5(+) 18YL M5(-) 18GN / M5A(+) 18YL M5A(-) 18GN / J1939 TERM RESISTOR (1657) CH13_50 / J1939 TERM RESISTOR (7801M) CH13_25,28, 35,36,38, 42,47,48 / PLATFORM/ FWD CHASSIS (1700) / Figure 119 / J1939 DATALINK WITH 500K WITH WTEC W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 160 | printed page 120 | section 3.83
3.83. J1939 DATALINK WITH 500K WITH WTEC W/ ZONAR W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE, P. 79
Figure 120 J1939 DATALINK WITH 500K WITH WTEC W/ ZONAR W/ 2017 IBS / 2021 B6.7 DIESEL

Components: BODY CONTROLLER (1606); DATALINK (1350); ECM CONN (6021); FWD CHASSIS (1700); K BAUD (1651); PLATFORM/ENGINE (1701); RESISTOR (1657); RESISTOR (7801M); SELECTOR (1850)
See also sheets: CH13_25, CH13_50, CH3_86, CH3_88
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.83. J1939 DATALINK WITH 500K WITH WTEC W/ ZONAR W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE, P. 79 / CHAPTER CHAPTER 3 3 J1939 DATALINK W/500K W/WTEC W/ZONAR W/2017/2021 ISB/B6.7 DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC A5MA(+),A5MA(-) B 96289K WERE A5MD(+),A5MD(-) AT R/D 1651. / J6-18WAY BODY CONTROLLER (1606) / A5H(+) 18YL A5H(-) 18GN / A5ABZ(-) 18GN / A5ABZ(+) 18YL / A5R(-) 18GN / A5R(+) 18YL / J1939 - G / J1939 + H / A5U(+) 18YL A5U(-) 18GN / A5W(-) 18GN / A5W(+) 18YL / J1939 + 1 / ZONAR V3 DATALINK (1350) / J1939 - 6 / A5J(-) 20GN A5J(+) 20YL / SHIFT SELECTOR (1850) J1939 - 15 / J1939 + 8 / A5K(-) 18GN A5K(+) 18YL / J1939 + C / J1939 - D / DIAGNOSTIC CONN 500K BAUD (1651) / A5MA(-) 18GN A5MA(+) 18YL / PLATFORM/ENGINE (1701) / A5AAZY(-) 18GN / A5AAZY(+) 18YL / K5G(-) 18GN / ECM CONN (6021) CH3_86,87 / ECM CONN (6021) CH3_88 NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / K5B(-) 18GN K5B(+) 18YL / K5G(+) 18YL / J1939 TERM RESISTOR (7801M) CH13_25,28, 35,36,38, 42,47,48 / M5(+) 18YL M5(-) 18GN / J1939 TERM RESISTOR (1657) CH13_50 / M5A(+) 18YL M5A(-) 18GN / J1939 TERM RESISTOR (1657) CH13_50 / M5E(+) 18YL M5E(-) 18GN / PLATFORM/ FWD CHASSIS (1700) / Figure 120 / J1939 DATALINK WITH 500K WITH WTEC W/ ZONAR W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE

3.84. J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX ABS 8 W/ 2017 IBS / 2021
Figure 121 J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX ABS 8 W/ 2017 IBS / 2021 B6.7

Components: BODY CONTROLLER (1606); CONN X1 (9543); ECM CONN (6021); ENGINE (1701); FWD CHASSIS (1700); K BAUD (1651); RESISTOR (1657); RESISTOR (7801M); SHIFT SELECTOR (1850)
See also sheets: CH13_25, CH13_32, CH13_50, CH3_86, CH3_88
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.84. J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX ABS 8 W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE, P. 80 / CHAPTER CHAPTER 3 3 J1939 DATALINK W/500K W/WTEC W/BENDIX ABS-8 W/2017/2021 ISB/B6.7 DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC A5MA(+),A5MA(-) B 96289K WERE A5MK(+),A5MK(-) AT R/D 1651. / J6-18WAY BODY CONTROLLER (1606) / A5H(+) 18YL A5H(-) 18GN / A5S(-) 18GN / A5S(+) 18YL / 7 J1939 - / BENDIX AIR ABS-8 CONN X1 (9543) / A5F(+) 18YL A5F(-) 18GN / A5R(-) 18GN / A5R(+) 18YL / 8 J1939 + / J1939 - G / J1939 + H / A5AC(+) 18YL A5AC(-) 18GN / A5Z(-) 18GN / A5Z(+) 18YL / J1939 - 15 / J1939 + 8 / A5K(-) 18GN A5K(+) 18YL / SHIFT SELECTOR (1850) / J1939 + C / J1939 - D / DIAGNOSTIC CONN 500K BAUD (1651) / A5MA(-) 18GN A5MA(+) 18YL / PLATFORM/ ENGINE (1701) / A5AAA(-) 18GN / A5AAA(+) 18YL / K5B(-) 18GN K5B(+) 18YL / K5G(-) 18GN K5G(+) 18YL / ECM CONN (6021) CH3_88 / ECM CONN (6021) CH3_86,87 / M5E(+) 18YL M5E(-) 18GN / J1939 TERM RESISTOR (1657) CH13_50 / J1939 TERM RESISTOR (7801M) CH13_32 / M5A(+) 18YL M5A(-) 18GN / M5(+) 18YL M5(-) 18GN / M5A(+) 18YL M5A(-) 18GN / J1939 TERM RESISTOR (1657) CH13_32,50 / J1939 TERM RESISTOR (7801M) CH13_25,28, 35,36,38, 42,47,48 / PLATFORM/ FWD CHASSIS (1700) / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 121 / J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX ABS 8 W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE

3.85. J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX WINGMAN W/ 2017 IBS /
Figure 122 J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX WINGMAN W/ 2017 IBS / 2021

Components: BODY CONTROLLER (1606); CONN X1 (9543); ECM CONN (6021); ENGINE (1701); FWD CHASSIS (1700); K BAUD (1651); RESISTOR (1657); RESISTOR (7801M); SELECTOR (1850); UNIT (9548)
See also sheets: CH13_25, CH13_32, CH13_50, CH3_86, CH3_88
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.85. J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX WINGMAN W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE, P. 81 / CHAPTER CHAPTER 3 3 J1939 DATALINK W/500K W/WTEC W/BENDIX WINGMAN W/2017/2021 ISB/B6.7 DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC A5MA(+),A5MA(-) B 96289K WERE A5MP(+),A5MP(-) AT R/D 1651. / J6-18WAY BODY CONTROLLER (1606) / A5H(+) 18YL A5H(-) 18GN / A5S(-) 18GN / A5S(+) 18YL / 7 J1939 - / BENDIX AIR ABS-8 CONN X1 (9543) / A5F(+) 18YL A5F(-) 18GN / A5AB(-) 18GN / A5AB(+) 18YL / A5R(-) 18GN / A5R(+) 18YL / 8 J1939 + / J1939 - G / J1939 + H / A5AC(+) 18YL A5AC(-) 18GN / A5Z(-) 18GN / A5Z(+) 18YL / J1939 + 8 / SHIFT SELECTOR (1850) J1939 - 15 / A5K(-) 18GN A5K(+) 18YL / 6 J1939 - / J1939 + 7 / A5L(-) 18GN A5L(+) 18YL / DRIVER INTERFACE UNIT (9548) / J1939 + C / J1939 - D / DIAGNOSTIC CONN 500K BAUD (1651) / A5MA(-) 18GN A5MA(+) 18YL / PLATFORM/ ENGINE (1701) / A5AA(-) 18GN / A5AA(+) 18YL / K5G(-) 18GN / ECM CONN (6021) CH3_86,87 / ECM CONN (6021) CH3_88 NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / K5B(-) 18GN K5B(+) 18YL / K5G(+) 18YL / J1939 TERM RESISTOR (7801M) CH13_25,28, 35,36,38, 42,47,48 / M5(+) 18YL M5(-) 18GN / J1939 TERM RESISTOR (1657) CH13_50 / M5A(+) 18YL M5A(-) 18GN / J1939 TERM RESISTOR (1657) CH13_32,50 / J1939 TERM RESISTOR (7801M) CH13_32 / M5E(+) 18YL M5E(-) 18GN / PLATFORM/ FWD CHASSIS (1700) / M5A(+) 18YL M5A(-) 18GN / Figure 122 / J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX WINGMAN W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE

3.86. J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX ABS 8 W/ ZONAR W/ 2017
Figure 123 J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX ABS 8 W/ ZONAR W/ 2017 IBS /

Components: BODY CONTROLLER (1606); CONN X1 (9543); DATALINK (1350); ECM CONN (6021); FWD CHASSIS (1700); K BAUD (1651); PLATFORM/ENGINE (1701); RESISTOR (1657); RESISTOR (7801M); SHIFT SELECTOR (1850)
See also sheets: CH13_25, CH13_32, CH13_50, CH3_86, CH3_88
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.86. J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX ABS 8 W/ ZONAR W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE, P. 82 / CHAPTER CHAPTER 3 3 J1939 DATALINK W/500K W/WTEC W/BENDIX ABS-8 W/ZONAR W/2017/2021 ISB/B6.7 DIESEL ENG BENDIX AIR ABS-8 CONN X1 (9543) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. J6-18WAY BODY CONTROLLER (1606) / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC A5MA(+),A5MA(-) B 96289K WERE A5MR(+),A5MR(-) AT R/D 1651. / A5H(+) 18YL A5H(-) 18GN / A5S(-) 18GN / A5S(+) 18YL / 7 J1939 - / A5F(+) 18YL A5F(-) 18GN / A5AB(-) 18GN / A5AB(+) 18YL / A5R(-) 18GN / A5R(+) 18YL / 8 J1939 + / J1939 - G / J1939 + H / A5AC(+) 18YL A5AC(-) 18GN / A5W(-) 18GN / A5W(+) 18YL / J1939 + 1 / ZONAR V3 DATALINK (1350) / J1939 - 6 / A5J(-) 20GN A5J(+) 20YL / J1939 - 15 / J1939 + 8 / A5K(-) 18GN A5K(+) 18YL / SHIFT SELECTOR (1850) / J1939 + C / DIAGNOSTIC CONN 500K BAUD (1651) D J1939 - / A5MA(-) 18GN A5MA(+) 18YL / PLATFORM/ENGINE (1701) / A5AA(-) 18GN / A5AA(+) 18YL / K5G(-) 18GN / ECM CONN (6021) CH3_86,87 / ECM CONN (6021) CH3_88 / K5B(-) 18GN K5B(+) 18YL / K5G(+) 18YL / J1939 TERM RESISTOR (7801M) CH13_25,28, 35,36,38, 42,47,48 / PLATFORM/ FWD CHASSIS (1700) / M5A(+) 18YL M5A(-) 18GN / M5A(+) 18YL M5A(-) 18GN / M5(+) 18YL M5(-) 18GN / M5E(+) 18YL M5E(-) 18GN / J1939 TERM RESISTOR (1657) CH13_50 / J1939 TERM RESISTOR (7801M) CH13_32 / J1939 TERM RESISTOR (1657) CH13_32,50 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 123 / J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX ABS 8 W/ ZONAR W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE

3.87. J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX WINGMAN W/ ZONAR W/
Figure 124 J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX WINGMAN W/ ZONAR W/ 2017 IBS /

Components: BODY CONTROLLER (1606); CONN X1 (9543); DATALINK (1350); ECM CONN (6021); FWD CHASSIS (1700); K BAUD (1651); PLATFORM/ENGINE (1701); RESISTOR (1657); RESISTOR (7801M); SELECTOR (1850); UNIT (9548)
See also sheets: CH13_25, CH13_32, CH13_50, CH3_86, CH3_88
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.87. J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX WINGMAN W/ ZONAR W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE, P. 83 / CHAPTER CHAPTER 3 3 J1939 DATALINK W/500K W/WTEC W/BENDIX WINGMAN W/ZONAR W/2017/2021 ISB/B6.7 DIESEL ENG BENDIX AIR ABS-8 CONN X1 (9543) 8 J1939 + / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC A5MA(+),A5MA(-) B 96289K WERE A5MF(+),A5MF(-) AT R/D 1651. / A5H(+) 18YL A5H(-) 18GN / A5S(-) 18GN / A5S(+) 18YL / 7 J1939 - / A5F(+) 18YL A5F(-) 18GN / A5AB(-) 18GN / A5AB(+) 18YL / A5R(-) 18GN / A5R(+) 18YL / J1939 - G / A5AC(+) 18YL A5AC(-) 18GN / A5W(-) 18GN / A5W(+) 18YL / J1939 + 1 / ZONAR V3 DATALINK (1350) 6 J1939 - / A5J(-) 20GN A5J(+) 20YL / SHIFT SELECTOR (1850) J1939 - 15 / J1939 + 8 / A5K(-) 18GN A5K(+) 18YL / DRIVER INTERFACE UNIT (9548) J1939 - 6 / J1939 + 7 / A5L(-) 18GN A5L(+) 18YL / PLATFORM/ENGINE (1701) / A5AN(-) 18GN / A5AN(+) 18YL / A5AJ(-) 18GN / A5AJ(+) 18YL / DIAGNOSTIC CONN 500K BAUD (1651) J1939 - D / J1939 + C / A5MA(-) 18GN A5MA(+) 18YL / K5B(-) 18GN K5B(+) 18YL / K5G(-) 18GN / K5G(+) 18YL / ECM CONN (6021) CH3_86,87 / ECM CONN (6021) CH3_88 NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / J1939 TERM RESISTOR (7801M) CH13_25,28, 35,36,38, 42,47,48 / M5(+) 18YL M5(-) 18GN / J1939 TERM RESISTOR (7801M) CH13_32 / M5A(+) 18YL M5A(-) 18GN / J1939 TERM RESISTOR (1657) CH13_32,50 / M5E(+) 18YL M5E(-) 18GN / PLATFORM/ FWD CHASSIS (1700) / J1939 TERM RESISTOR (1657) CH13_50 / M5A(+) 18YL M5A(-) 18GN / Figure 124 / J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX WINGMAN W/ ZONAR W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE

3.88. J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX FUSION W/ ZONAR W/
Figure 125 J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX FUSION W/ ZONAR W/ 2017 IBS /

Components: BODY CONTROLLER (1606); CONN 500K BAUD (1651); CONN X1 (9543); DATALINK (1350); ECM CONN (6021); ELEC PANEL/FR CAP (10001); ENGINE (1701); FWD CHASSIS (1700); PANEL (1703/@1703C/%1703); RESISTOR (1657); RESISTOR (7801M); SELECTOR (1850); UNIT (9548)
See also sheets: CH13_25, CH13_50, CH13_55, CH3_86, CH3_88
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.88. J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX FUSION W/ ZONAR W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE, P. 84 / CHAPTER CHAPTER 3 3 J1939 DATALINK W/500K W/WTEC W/BENDIX FUSION W/ZONAR W/2017/2021 ISB/B6.7 DIESEL ENG BENDIX AIR ABS-8 CONN X1 (9543) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. J6-18WAY BODY CONTROLLER (1606) / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC A5MA(+),A5MA(-) B 96289K WERE A5MK(+),A5MK(-) AT R/D 1651. / A5H(+) 18YL A5H(-) 18GN / J1939 - 7 / A5F(+) 18YL A5F(-) 18GN / A5AB(-) 18GN / A5AB(+) 18YL / A5MA(-) 18GN A5MA(+) 18YL A5R(-) 18GN / A5R(+) 18YL / 8 J1939 + / J1939 - G / J1939 + H / A5AC(+) 18YL A5AC(-) 18GN / A5W(-) 18GN / A5W(+) 18YL / J1939 + 1 / ZONAR V3 DATALINK (1350) J1939 - 6 / A5J(-) 20GN A5J(+) 20YL / SHIFT SELECTOR (1850) J1939 - 15 / J1939 + 8 / A5K(-) 18GN A5K(+) 18YL / DRIVER INTERFACE UNIT (9548) J1939 - 6 / J1939 + 7 / A5L(-) 18GN A5L(+) 18YL / PLATFORM/ ENGINE (1701) / A5AN(-) 18GN / A5AN(+) 18YL / A5AJ(-) 18GN / A5AJ(+) 18YL / DIAGNOSTIC CONN 500K BAUD (1651) J1939 - D / J1939 + C / A5P(-) 18GN / A5P(+) 18YL / PLATFORM/ELECTRICAL PANEL (1703/@1703C/%1703) A13 / A5NE(-) 18GN A5NE(+) 18YL / ECM CONN (6021) CH3_86,87 / K5G(-) 18GN / K5B(-) 18GN K5B(+) 18YL / K5G(+) 18YL / ECM CONN (6021) CH3_88 NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / M5A(+) 18YL M5A(-) 18GN / @A5AK(+) 18YL @A5AK(-) 18LTGN / PLATFORM/ FWD CHASSIS (1700) / M5E(+) 18YL M5E(-) 18GN / %B5(+) %B5A(+) %B5(-) %B5A(-) 18YL 18GN 18GN 18YL / M5(+) 18YL M5(-) 18GN / J1939 TERM RESISTOR (7801M) CH13_25,28, 35,36,38, 42,47,48 / J1939 TERM RESISTOR (1657) CH13_50 / J1939 TERM RESISTOR (1657) CH13_50 / ELEC PANEL/FR CAP (10001) CH13_55 / Figure 125 / J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX FUSION W/ ZONAR W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE

3.89. J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX FUSION W/ 2017 IBS /
Figure 126 J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX FUSION W/ 2017 IBS / 2021 B6.7

Components: BODY CONTROLLER (1606); CONN X1 (9543); ECM CONN (6021); ELEC PANEL/FR CAP (10001); ENGINE (1701); FWD CHASSIS (1700); K BAUD (1651); PANEL (1703/@1703C/%1703); RESISTOR (1657); RESISTOR (7801M); SELECTOR (1850); UNIT (9548)
See also sheets: CH13_25, CH13_50, CH13_55, CH3_86, CH3_88
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.89. J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX FUSION W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE, P. 85 / CHAPTER CHAPTER 3 3 J1939 DATALINK W/500K W/WTEC W/BENDIX FUSION W/2017/2021 ISB/B6.7 DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC A5MA(+),A5MA(-) B 96289K WERE A5MK(+),A5MK(-) AT R/D 1651. / J6-18WAY BODY CONTROLLER (1606) / A5H(+) 18YL A5H(-) 18GN / A5P(-) 18GN / A5P(+) 18YL / 7 J1939 - / BENDIX AIR ABS-8 CONN X1 (9543) / A5F(+) 18YL A5F(-) 18GN / A5AB(-) 18GN / A5AB(+) 18YL / A5R(-) 18GN / A5R(+) 18YL / 8 J1939 + / J1939 - G / J1939 + H / A5AC(+) 18YL A5AC(-) 18GN / A5W(-) 18GN / A5W(+) 18YL / PLATFORM/ELECTRICAL PANEL (1703/@1703C/%1703) A13 / A5NE(-) 18GN A5NE(+) 18YL / J1939 + 8 / SHIFT SELECTOR (1850) / J1939 - 15 / A5K(-) 18GN A5K(+) 18YL / J1939 - 6 / J1939 + 7 / A5L(-) 18GN A5L(+) 18YL / DRIVER INTERFACE UNIT (9548) / J1939 + C / D J1939 - / DIAGNOSTIC CONN 500K BAUD (1651) / A5MA(-) 18GN A5MA(+) 18YL / PLATFORM/ ENGINE (1701) / A5AA(-) 18GN / A5AA(+) 18YL / ECM CONN (6021) CH3_86,87 / K5G(-) 18GN / K5B(-) 18GN K5B(+) 18YL / K5G(+) 18YL / ECM CONN (6021) CH3_88 / @A5AK(+) 18YL @A5AK(-) 18LTGN / M5E(+) 18YL M5E(-) 18GN / J1939 TERM RESISTOR (1657) CH13_50 / M5(+) 18YL M5(-) 18GN / M5A(+) 18YL M5A(-) 18GN / J1939 TERM RESISTOR (1657) CH13_50 / J1939 TERM RESISTOR (7801M) CH13_25,28, 35,36,38, 42,47,48 / PLATFORM/ FWD CHASSIS (1700) / %B5A(-) %B5A(+) %B5A(-) %B5A(+) 18GN 18YL 18GN 18YL / ELEC PANEL/FR CAP (10001) CH13_55 / Figure 126 / J1939 DATALINK WITH 500K WITH WTEC W/ BENDIX FUSION W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE

3.90. J1939 DATALINK WITH 500K WITH ALLISON XMSN W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE, P. 86
Figure 127 J1939 DATALINK WITH 500K WITH ALLISON XMSN W/ 2017 IBS / 2021 B6.7 DIESEL

Components: CLUSTER (1505); CONN 500K BAUD (1651); ECM CONN (6021); ENG/PLATFORM (1701/1701); GEN4 TCM (7150); PAM MODULE (4087); RESISTOR (7801M); RESISTOR (7803)
See also sheets: CH13_62, CH3_69, CH3_70, CH3_96
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.90. J1939 DATALINK WITH 500K WITH ALLISON XMSN W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE, P. 86 / CHAPTER 3 J1939 DATALINK W/500K W/ALLISON XMSN W/2017/2021 ISB/B6.7 DIESEL-ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / OHMS 120 A / K5(+) 18YL / J1939 TERMINATING RESISTOR (7803) / K5(-) 18GN / K5E(+) 18YL / K5B(+) 18YL / K5E(-) 18GN / K5B(-) 18GN / K5C(-) 20GN / ENG/PLATFORM (1701/1701) 45 / J1939 + 6 / J1939 - 27 / GEN4 TCM (7150) / K5#106 18YL K5#127 18GN / K5C(+) 20YL / 22 J1939 + / J1939 - 46 / ECM CONN (6021) / OHMS 120 A / J1939 TERMINATING RESISTOR (7801M) / @K5F(+) 20YL / PAM MODULE (4087) 7 J1939 + / 8 J1939 - / K5L(+) 18YL K5L(-) 18GN / %K5J(+) 18YL / %K5F(+) 20YL / %K5J(-) 18GN / %K5F(-) 20GN / @K5F(-) 20GN / *A5R(+) 18YL / *A5R(+) 18GN / A5BJ(+) 18YL / A5J(-) 18GN / INSTRUMENT CLUSTER (1505) CH3_69 / #A5A(-) 18GN / #A5A(+) 18YL / Figure 127 / J1939 DATALINK WITH 500K WITH ALLISON XMSN W/ 2017 IBS / 2021 B6.7 DIESEL ENGINE

3.91. J1939 DATALINK W/ 500K W/ ALLISON XMSN W/ PTO W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 87
Figure 128 J1939 DATALINK W/ 500K W/ ALLISON XMSN W/ PTO W/ 2017 ISB / 2021 B6.7 DIESEL

Components: CLUSTER (1505); CONN 500K BAUD (1651); ECM CONN (6021); MODULE-2 (1233); MODULE-3 (1234); PLATFORM/ENG (1701); RESISTER (7801M); RESISTER (7803)
See also sheets: CH13_62, CH3_69, CH3_70, CH3_96
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.91. J1939 DATALINK W/ 500K W/ ALLISON XMSN W/ PTO W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 87 / CHAPTER CHAPTER 3 3 J1939 DATALINK W/500K W/ALLISON XMSN W/PTO W/2017/2021 ISB/B6.7 DIESEL ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K5(+) 18YL / K5(-) 18GN / K5#106 18YL / K5#127 18GN / J1939+ 46 / J1939- 22 / ECM CONN (6021) / K5C(+) 20YL K5C(-) 20GN / TRANS MODULE-3 16 (1234) / TRANS MODULE-2 (1233) / J1939 TERMINATING RESISTER (7803) B / OHMS 120 / J1939 TERMINATING RESISTER (7801M) A / OHMS 120 / @K5B(+) 18YL / @K5B(-) 18GN / */@K5F(+) 20YL / */@K5F(-) 20GN / PLATFORM/ENG (1701) 45 / #A5R(+) 18YL / #A5R(+) 18GN / A5BJ(+) 18YL / A5J(-) 18GN / INSTRUMENT DIAGNOSTIC CLUSTER CONN 500K BAUD (1505) (1651) CH13_62, CH3_70,71,72,73, CH3_96,96C,96D 74,75,76,77,78,79, 80,81,82,83,84,85 / INSTRUMENT CLUSTER (1505) CH3_69 / # W/CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK * W/CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK @ N/PAM 250K / %A5A(+) 18YL / %A5A(-) 18GN / #K5A(+) 20YL / #K5A(-) 20GN / Figure 128 / J1939 DATALINK W/ 500K W/ ALLISON XMSN W/ PTO W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE

3.92. J1939 DATALINK WITH 500K W/ EATON PROCISION XMSN W/ 2017 ISB / 2021
Figure 129 J1939 DATALINK WITH 500K W/ EATON PROCISION XMSN W/ 2017 ISB / 2021 B6.7

Components: CLUSTER (1505); CONN 500K BAUD (1651); CONNECTOR (6021); ENG/PLATFORM (1701/1701); PAM MODULE (4087); RESISTOR (7801M); RESISTOR (7803); UPPER (7105)
See also sheets: CH3_69, CH3_70
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.92. J1939 DATALINK WITH 500K W/ EATON PROCISION XMSN W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 88 / CHAPTER 3 J1939 DATALINK W/500K W/EATON PROCISION XMSN W/2017/2021 ISB/B6.7 DIESEL ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / OHMS 120 A / K5B(+) K5B(-) 18YL 18GN / J1939 TERMINATING RESISTOR (7803) / K5C(+) K5C(-) 18YL 18GN / K5G(+) K5G(-) 18YL 18GN / K5D(+) 20YL K5D(-) 20GN / J1939+ 11 J1939- 12 / EPS VEHICLE UPPER (7105) / K5A(+) 18YL K5A(-) 18GN / ECM CONNECTOR (6021) J1939+ 22 / 46 J1939- / ENG/PLATFORM (1701/1701) / OHMS 120 A / J1939 TERMINATING RESISTOR (7801M) / @K5F(+) 20YL / 8 J1939 - / PAM MODULE (4087) / 7 J1939 + / K5L(+) 18YL K5L(-) 18GN / %K5J(+) 18YL / %K5F(+) 20YL / %K5J(-) 18GN / %K5F(-) 20GN / @K5F(-) 20GN / @ N/PAM 250K % W/PAM 250K / A5R(+) A5R(+) 18YL 18GN / A5BJ(+) 18YL / A5J(-) 18GN / DIAGNOSTIC CONN 500K BAUD (1651) CH3_70,71,72,73, 74,75,76,77,78,79, 80,81,82,83,84,85 / INSTRUMENT CLUSTER (1505) CH3_69 / Figure 129 / J1939 DATALINK WITH 500K W/ EATON PROCISION XMSN W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE

3.93. J1939 DATALINK WITH PUBLIC CAN WITHOUT ENHANCED VCM FUNCTION W/
Figure 130 J1939 DATALINK WITH PUBLIC CAN WITHOUT ENHANCED VCM FUNCTION W/ F-2018

Components: CONN 500K BAUD (1651); CONNECTOR (6021); GEN 5 TCM (7150); PLATFORM (1701); RESISTER (7803)
See also sheets: CH3_70
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.93. J1939 DATALINK WITH PUBLIC CAN WITHOUT ENHANCED VCM FUNCTION W/ F-2018 PROPANE ENGINE, P. 89 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / CHAPTER 3 J1939 DATALINK W/PUBLIC CAN N/ENHANCED VCM FUNCTION W/F-2018-PROP-ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ENGINE/ PLATFORM (1701) / VEHICLE INTERFACE CONNECTOR (6021) - + J1939 J1939 C12 C11 / K5B(-) K5B(+) 18GN 18YL / K5D(+) 18YL / K5D(-) 18GN / GEN 5 TCM (7150) / K5A(-) K5A(+) 18GN 18YL / K5#108 18GN / K5#128 18YL / 28 J1939 + / J1939 TERMINATING RESISTER (7803) B / K5E(-) 18GN / K5E(+) 18YL / OHMS 120 / J1939 - / A5R(-) A5R(+) 18GN 18YL / DIAGNOSTIC CONN 500K BAUD (1651) CH3_70,71,72,73, 74,75,76,77 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 130 / J1939 DATALINK WITH PUBLIC CAN WITHOUT ENHANCED VCM FUNCTION W/ F-2018 PROPANE ENGINE

3.94. J1939 DATALINK WITH PUBLIC CAN WITH ENHANCED VCM FUNCTION W/
Figure 131 J1939 DATALINK WITH PUBLIC CAN WITH ENHANCED VCM FUNCTION W/ F-2018

Components: CLUSTER (1505); CONN 500K BAUD (1651); CONNECTOR (6021); ENGINE (1701); GEN 5 TCM (7150); RESISTER (7801M); RESISTER (7803)
See also sheets: CH3_69, CH3_70
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.94. J1939 DATALINK WITH PUBLIC CAN WITH ENHANCED VCM FUNCTION W/ F-2018 PROPANE ENGINE, P. 90 / CHAPTER 3 J1939 DATALINK W/PUBLIC CAN W/ENHANCED VCM FUNCTION W/F-2018-PROP-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC K5C(-)&K5C(+) B 96289K WERE K5A(+)&K5A(-) AT R/D 7801M. / PLATFORM/ ENGINE (1701) / K5A(+) 18YL / K5A(-) 18GN / K5D(+) 18YL / K5D(-) 18GN / K5E(+) 18YL / K5E(-) 18GN / C12 J1939 - / 27 J1939 - / C11 J1939 + / VEHICLE INTERFACE CONNECTOR (6021) / GEN 5 TCM (7150) / J1939 TERMINATING RESISTER (7803) / K5#106 18YL K5#127 18GN / K5B(+) 18YL K5B(-) 18GN / 120 OHMS / J1939 + / OHMS 120 / J1939 TERMINATING RESISTER (7801M) B / K5C(-) 20GN / K5C(+) 20YL / A5R(+) 18YL / A5R(-) 18GN / A5A(+) 18YL / A5A(-) 18GN / DIAGNOSTIC CONN 500K BAUD ISTRUMENT (1651) CLUSTER CH3_70,71,72, (1505) 73,74,75,76,77 CH3_69 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 131 / J1939 DATALINK WITH PUBLIC CAN WITH ENHANCED VCM FUNCTION W/ F-2018 PROPANE ENGINE

3.95. J1939 DATALINK WITH PUBLIC CAN WITHOUT PAM W/ F-2018 GASOLINE ENGINE, P. 91
Figure 132 J1939 DATALINK WITH PUBLIC CAN WITHOUT PAM W/ F-2018 GASOLINE ENGINE

Components: CLUSTER (1505); CONNECTOR (6021); GEN5 TCM (7150); K BAUD (1651); PLATFORM (1701); RESISTOR (7801M); RESISTOR (7803)
See also sheets: CH3_69, CH3_70
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.95. J1939 DATALINK WITH PUBLIC CAN WITHOUT PAM W/ F-2018 GASOLINE ENGINE, P. 91 / CHAPTER 3 J1939 DATALINK W/PUBLIC CAN N/PAM W/F-2018-GAS-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30DEC20 / MJV0488 19NOV21 CIRC K5C(-) & K5C(+) B 96289K WERE K5A(+) & K5A(-) AT R/D 7801M. / DIAGNOSTIC CONNECTOR 500K BAUD (1651) CH3_70,71,72, 73,74,75,76,77 / A5R(+) 18YL / A5R(-) 18GN / K5A(+) 18YL / K5A(-) 18GN / J1939 - 27 / J1939 + 6 / K5#106 18YL K5#127 18GN / K5D(-) 18GN / K5D(+) 18YL / K5B(+) 18YL / J1939 - C12 / K5B(-) 18GN / C11 J1939 + / K5E(-) 18GN / K5E(+) 18YL / GEN5 TCM (7150) / VEHICLE INTERFACE CONNECTOR (6021) / 120 OHMS / J1939 TERMINATING RESISTOR (7803) / A5BJ(-) 18GN / K5C(-) 20GN / J1939 TERMINATING RESISTOR (7801M) / K5C(+) 20YL / 120 OHMS / A5BJ(+) 18YL / ELEC PANEL/ PLATFORM (1701) / INSTRUMENT CLUSTER (1505) CH3_69 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 132 / J1939 DATALINK WITH PUBLIC CAN WITHOUT PAM W/ F-2018 GASOLINE ENGINE

3.96. J1939 DATALINK W/ 500K W/ ENHANCED VCM FUNCTIONS W/ 2017 ISB / 2021
Figure 133 J1939 DATALINK W/ 500K W/ ENHANCED VCM FUNCTIONS W/ 2017 ISB / 2021 B6.7

Components: FUSE A6-K (1014); FUSE F9 (1011); FWD CHASSIS (1700); GND STUD (4037A)
Wires (circuit gauge+color): A11-GZ 8WH; A98-G 16WH; M3CA 18GY; M3CB 18GY
See also sheets: CH3_02, CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.96. J1939 DATALINK W/ 500K W/ ENHANCED VCM FUNCTIONS W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 92 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 31DEC20 / CHAPTER 3 J1939 DATALINK W/500K W/ENHANCED VCM FUNCTIONS W/2017/2021 ISB/B6.7 DIESEL & F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / DIAGNOSTIC CONN 500K BAUD %%(1651) / A3(+) 18DKBL A3(-) 18GY / 26 J1939 - / FUSE F9 (1011) CH3_94 FUSE A6-K (1014) CH3_02 FULL POWER BRAKE CONTROLLER %%(9511) 31 J1939 + / @M3C(+) 18DKBL @M3C(-) 18GY / J1939 - G / J1939 + F / PLATFORM/ FWD CHASSIS (1700) 39 / 9 J1939 - / WABCO AIR ABS CONN %%(4906) J1939 + 4 / A98-G 16WH / GROUND A / A11-GZ 8WH / GND STUD (4037A) / ##A98 18VT &A98 18VT / %M3C(+) 18DKBL %M3C(-) 18GY / 5 J1939 + / 1 J1939 - / BENDIX AIR ABS-6 CONN %%(9538) J1939 + 5 / 1 J1939 - / #M3CA 18GY #M3CB 18GY / BENDIX AIR ABS-6 CONN %%(9538) / *M3C(+) 18DKBL *M3C(-) 18GY / N/GPS PRE-WIRE / Figure 133 / J1939 DATALINK W/ 500K W/ ENHANCED VCM FUNCTIONS W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE

3.97. DRIVER INTERFACE UNIT W/ 2017 ISB / 2021 B6.7 DIESEL & W/ 2018 PROPANE / GASOLINE ENGINE, P. 93
Figure 134 DRIVER INTERFACE UNIT W/ 2017 ISB / 2021 B6.7 DIESEL & W/ 2018 PROPANE

Components: FUSE A3-B (1016); FUSE F16 (1011); INTERFACE UNIT (9548)
Wires (circuit gauge+color): A13EE 18PK; A152-G 18WH; A152-GA 18WH; A152S 18RD; A152V 18GY; A152Y 18RD; A94-GB 12WH; A94-GD 12WH
See also sheets: CH3_06, CH3_95
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.97. DRIVER INTERFACE UNIT W/ 2017 ISB / 2021 B6.7 DIESEL & W/ 2018 PROPANE / GASOLINE ENGINE, P. 93 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 21JAN21 / CHAPTER 3 DRIVER INTERFACE UNIT W/2017/2021 ISB/B6.7 DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / DRIVER INTERFACE UNIT (9548) / #A152V 18GY / A152-G 18WH / GROUND 5 / FUSE A3-B (1016) CH3_06 / #A152Y 18RD / A94-GB 12WH / #A13EE 18PK / #A152S 18RD / A152-GA 18WH / A94-GD 12WH / GROUND STUD #(4037ZB) GROUND STUD %(4037Z) CH3_95 / % W/CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK # W/CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK / %A152Y 18RD / %A152V 18GY / FUSE F16 (1011) CH3_94B / %A152S 18RD / Figure 134 / DRIVER INTERFACE UNIT W/ 2017 ISB / 2021 B6.7 DIESEL & W/ 2018 PROPANE / GASOLINE ENGINE

3.98. BATTERY FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE / GASOLINE ENGINE, P. 94
Figure 135 BATTERY FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE / GASOLINE

Components: A AMMETER SENSOR (6335); AMMETER SENSE (6334); AUTO DRAIN RELAY W/0508095 (1018B); CROSSING GATE (4301); DECU J1 CONN (1826); DECU J2 CONN (1827); DIAGNOSTIC CONN (1650); ELEC PANEL/PLATFORM (1702); ENG (1701/1701); FOG LIGHT RELAY (1017); FUSE BLOCK (1011); FUSE F34 (1011); FWD CHASSIS (1700); GATE RELAY (1027); INSTRUMENT GAUGE CLUSTER (1500); KEY SW (1100); MEGA FUSE (4000); N2 MODULE (2513); PAM MODULE (4087); PARK BRAKE NOT SET ALARM (9999); PHMI DISPLAY CONN (1829); PLATFORM/ENG (1701); PLATFORM/ENG (1701-20); SEAT BELT ALARM (1109A); SHIFT SELECTOR (1850); STOP LIGHT RELAY (1011-R3); STUD (1000); ZONAR V3 POWER (1349)
Wires (circuit gauge+color): A119 16GY; A119A 16GY; A119B 16GY; A119D 16GY; A13AA 12PK; A13AG 14PK; A13AJ 14PK; A14 4RD; A144KC 14RD; A14A 6RD; A14B 10RD; A14BA 18RD; A14C 10RD; A14CA 12RD; A14D 10RD; A14E 10RD; A14EA 12RD; A14F 10RD; A14G 10RD; A14H 10RD; A14K 10RD; A14L 10RD; A14TS 20RD; A15 16RD; A152W 18GY; A15A 18RD; A26 16GY; A26 18TN; A26B 18TN; A28 18TN; A39D 14OR; A44KB 14RD; A44KB1 14RD; A44KB2 14RD; A70 18OR; A70BB 14OR; A74 10LTGN; A74D 14LTGN; A74H 10LTGN; A75 10LTGN; A75 10RD; A79A 16RD; A79B 16RD; A79C 16RD; A90C 18GY; K26 18TN; K26C 18TN
See also sheets: CH12_03, CH13_34, CH13_68, CH13_69, CH15_33, CH17_38, CH19_56, CH19_58, CH19_59, CH3_92, CH4_07, CH5_01, CH5_08, CH5_09, CH5_10, CH7_70, CH9_09, CH9_10
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.98. BATTERY FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE / GASOLINE ENGINE, P. 94 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0488 19NOV21 ADDED CIRC &A26 IN FUSE F4(1011). / BATTERY FEED STUD (1000) / A F7 B 10A F8 A B 30A F9 B A 10A / F6 B A 5A F2 A B 15A / F10 A B 30A A F30 B 10A F33 A B 15A A F27 B 10A / A14D 10RD / F32 A B 20A / A F4 B 10A / A14E 10RD / F5 A B 10A / A F3 B 5A A F13 A14K B 10RD 3A / %A90C 18GY A14TS 20RD %A74D 14LTGN %A75 10LTGN %A75 10RD %A74H 10LTGN %A74 10LTGN A15 16RD / A14A 6RD / A14H 10RD A14F 10RD / A14B 10RD / A14G 10RD / A14C 10RD / A14 4RD / FUSE BLOCK (1011) / A MEGA FUSE (4000) / 400A AMMETER SENSOR (6335) CH5_10 AMMETER SENSE (6334) CH5_08 PAM MODULE (4087) CH5_10A / %A14L 10RD / % W/2017-ISB-DIESEL ENG ONLY & W/F-2018-PROPANE/GASOLINE-ENG / DECU J2 CONN (1827) CH13_69 / DECU J1 CONN (1826) CH13_68 PHMI DISPLAY CONN (1829) CH13_69 / A119D 16GY &A26 16GY / A119B 16GY / CROSSING GATE RELAY (1027)CH5_10B PLATFORM/ENG (1701)CH5_09 / Figure 135 / BATTERY FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE / GASOLINE ENGINE

3.99. ACCESSORY FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE /
Figure 136 ACCESSORY FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE / GASOLINE

Components: BLOCK (1011); BODY CONTROLLER (1600); BODY CONTROLLER (1606); DIODE ASSY CONN (1010F); ELEC PANEL (1703/1703); EMERGENCY EXIT RELAY (1020); FUSE F7 (1011); KEY SWITCH (1100); PARK BRAKE ZVR SIGNAL (9998); PLATFORM (1700); PTI RELAY (1021); RELAY COILS (10369); SWITCH PACK (1101); WHEEL CHAIR LIFT RELAY (1019); ZVR RELAYS (1009)
Wires (circuit gauge+color): A117C 18GY; A12 16GY; A12 16LTBL; A125H 18GY; A12A 16LTBL; A12B 16LTBL; A12B 18LTBL; A12C 18LTBL; A12D 18GY; A12D 18LTBL; A12E 18LTBL; A148 16GY; A148A 16LTBL; A149D 18GY; A15 16RD; A44M 16GY; A79P 16PK; B12Y 16LTBL
See also sheets: CH15_32, CH3_94, CH8_53
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.99. ACCESSORY FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE / GASOLINE ENGINE, P. 94A / CHAPTER 3 ACCESSORY FEED - PLATFORM W/2017-ISB-DIESEL & F-2018-PROP/GAS-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PLATFORM/ ELEC PANEL (1703/1703) A2 A12A B12Y 16LTBL 16LTBL / A117C 18GY / FUSE BLOCK (1011) F12 A B 5A @(A148) %(A12) @(A12) F11 A B 10A / PARK BRAKE ZVR SIGNAL (9998) CH13_53B EMERGENCY EXIT RELAY (1020) CH14_2A WHEEL CHAIR LIFT RELAY (1019) CH15_32,33 PTI RELAY (1021) CH18_38A / A12C 18LTBL / COIL SIGNAL ZVR RELAYS (1009) A / OFF IGN C / J3-RED BODY CONTROLLER (1600) W/ENHANCED VCM FUNCTIONS @A149D 18GY / ACCESSORY SPLICE RELAY COILS (10369) CH3_30A / ACC SWITCH A1 INPUT / A89CD 18VT / 16RD A15 / KEY SWITCH (1100) / FUSE F7 (1011) CH3_94 / SWITCH PACK (1101) CH8_53 / @A148 16GY %A12 16GY / D D / A79P 16PK / J6-18 WAY BODY CONTROLLER (1606) / %A12D 18GY / #A12D 18LTBL / A125H 18GY / A12E 18LTBL / A12B 18LTBL / RELAY ZVR SPLICE DIODE ASSY CONN (1010F) B A / F15 B A 5A / A44M 16GY / FWD CHASSIS /PLATFORM (1700) CH13_4A / 16LTBL #A12 / 16LTBL @A148A 16LTBL 16LTBL %A12B @A12B / Figure 136 / ACCESSORY FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE / GASOLINE ENGINE

3.100. IGNITION FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE /
Figure 137 IGNITION FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE / GASOLINE ENGINE

Components: AIR PARK BRAKE RELAY (1013); BODY CONTROLLER (1600); BODY CONTROLLER (1606); CONTROLLER (1600); DRIVER INTERFACE UNIT (9548); FUSE BLOCK (1011); FUSE F10 (1011); FUSE F18 (1011); FUSE F27 (1011); FUSE F7 (1011); FUSE F8 (1011); IGN SPLICE PACK (1014); KEY SW (1100); PLATFORM/ ELEC PANEL (1702); PLATFORM/ELEC PANEL (1702); PLATFORM/ENG (1701); PLATFORM/FWD CHASSIS (1700); PWR INPUT (1404); STUD (4037A); WASHER/PUMP (4500)
Wires (circuit gauge+color): A11-GZ 8WH; A12-G 18WH; A12-GA 18WH; A13-G 18WH; A13-GA 18WH; A13AA 12PK; A13AB 18PK; A13AC 16PK; A13AC 18PK; A13AD 16PK; A13AD 18GY; A13AF 16PK; A13AF 18PK; A13AG 14PK; A13AG 18PK; A13AH 16PK; A13AJ 14PK; A13AJ 16PK; A13AK 14PK; A13AK 18PK; A13AL 14PK; A13AN 16GY; A13AN 16PK; A13B 16PK; A13BA 12PK; A13D 18PK; A13E 18PK; A13F 18PK; A148AN 16GY; A149AD 18GY; A14CA 12RD; A14EA 12RD; A15 16RD; A152S 18RD; A152V 18GY; A152X 18GY; A152Y 18RD; A44 18GY; A44KA 14PK; A59B 18GY; A87A 18GY
See also sheets: CH13_32, CH13_63, CH13_68, CH3_93, CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.100. IGNITION FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE / GASOLINE ENGINE, P. 94B / CHAPTER 3 IGNITION FEED - PLATFORM W/2017-ISB-DIESEL & F-2018-ROPANE/GASOLINE ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30MAR21 / MJV0488 19NOV21 ADDED CIRC A44/16VT B 96289K & REMOVED CIRC A89B IN FUSE F1(1011). / F16 A B 10A / S B / F28 A B 5A A F1 B 10A / 85 A / @A148AN 16GY A13AA 12PK %A13AG 18PK @A13AG 14PK / F14 A B 5A / OFF IGN ACC C / IGNITION RELAY #1 E B (1011-R5) 86 30 / A87A 18GY A59B 18GY A13D 18PK A13AB 18PK A13E 18PK A13AD 16PK / PLATFORM/ENG (1701) CH13_54A AIR PARK BRAKE RELAY (1013) CH13_63 PLATFORM/ENG (1701) CH13_54A / KEY SW (1100) BATT / FUSE BLOCK (1011) F34 A B 10A @F35 A B 10A / @A13AF 18PK @A13AJ 16PK %A13AC 16PK / C A12-G 18WH / 87A D / A FUSE F7 A15 (1011) CH3_94 16RD W/ENHANCED VCM FUNCTION J3-RED BODY CONTROLLER (1600) A16 J6-18 WAY BODY CONTROLLER (1606) B / IGNITION RELAY #2 (1011-R6) E B 86 30 / @A13AD 18GY %A149AD 18GY / A152Y 18RD / A152V 18GY A152X 18GY A13F 18PK A152S 18RD A44KA 14PK / 85 A / A13BA 12PK / C A12-GA 18WH / 87A D / FUSE F18 (1011) CH3_94C / A13B 16PK / A14EA 12RD A13-GA 18WH A13-G 18WH / FUSE F10 (1011) CH3_94 / GROUND STUD (4037A) FUSE F8 (1011) CH3_94 / A14CA 12RD / A11-GZ 8WH / %A13AN 16GY / W/BODY CONTROLLER A13AN 16PK / %A13AF 16PK / %A13AJ 14PK / FUSE F27 (1011) CH3_94 / Figure 137 / IGNITION FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE / GASOLINE ENGINE

3.101. IGNITION FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE /
Figure 138 IGNITION FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE / GASOLINE

Components: ARENS SHIFT SELECTOR A (7808); BACKUP LT CHECK RELAY (1016); BENDIX AIR ABS8 CONNECTOR XI (9543); CLUSTER (1500); FUSE BLOCK (1011); INSTRUMENT CLUSTER (1500); PLATFORM/ENG (1701); PLATFORM/ENG (1702); PLATFORM/FWD CHASSIS (1700); POSITION SENSER (1804); REGEN SW (9266); SHIFT SELECTOR (1850); SHIFTER LEVEL CONTROL SOLENOID (1828); SW PACK (1101); VALVE RELAY W/0508095 (1018); VALVE RELAY W/0508095 (1018B); ZONAR V3 PREWIRE (1349)
Wires (circuit gauge+color): A13AE 12PK; A13BA 12PK; A13BB 12PK; A13BC 12PK; A13BF 18PK; A13F 18PK; A13TS 20PK; A28A 18TN; A39A 16GY; A62 16DKBL; A62A 18DKBL; A62D 18DKBL; A62Z 16DKBL; A71 16OR; A71A 18OR; A90E 18GY; A92 18GY; A92 18TN; A94BA 18GY; A94BJ 10GY; A94BJ 18GY; A94Y 18GY; A95C 18PK
See also sheets: CH11_01, CH12_03, CH12_05, CH12_23, CH12_24, CH13_01, CH13_20, CH13_22, CH13_26, CH13_30, CH13_33, CH13_42, CH17_38, CH4_08, CH5_01, CH8_24, CH8_53
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.101. IGNITION FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE / GASOLINE ENGINE (CONT.), P. 94C / CHAPTER 3 IGNITION FEED - PLATFORM W/2017-ISB-DIESEL & F-2018-PROPANE/GASOLINE ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090654 NO. RELEASE NO. 95885P 30MAR21 / MJV0488 19NOV21 REMOVED CIRC A44 FROM FUSE F24(1011). / A28A 18TN A94BJ 18GY A94BA 18GY @A94BJ 10GY A90E 18GY A94Y 18GY A13TS 20PK / F25 A B 5A/10A F29 A B 5A / F24 A B 5A / IGNITION RELAY #2 R6 (1011) CH3_94B / F22 A B 5A / FUSE BLOCK (1011) F26 A B 10A F20 A B 10A / A13AE 12PK / A13BC 12PK / F21 A B / F17 A 5A B F18 A B 5A F19 A B 5A / REGEN SW (9266) CH13_20 / A95C 18PK / F23 A B 10A / A62Z 16DKBL A62A 18DKBL A71 16OR A71A 18OR A92 18TN @A#163A 18PK @A92 18GY @A#163 18YL @A#163 18PK @A#163A 18YL %A92#163 18YL A97UA 18VT / A13BA 12PK / @A13BF 18PK %A13F 18PK / A13BB 12PK / @A99F 18VT / PLATFORM/ENG (1701) CH13_01 PLATFORM/ENG (1701) CH13_01 / A39A 16GY / A39A 16GY / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / INSTRUMENT CLUSTER (1500) CH5_01 / A62 16DKBL / Figure 138 / IGNITION FEED PLATFORM W/ 2017 ISB DIESEL & W/ 2018 PROPANE / GASOLINE ENGINE (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 179 | printed page 139 | section 3.102
3.102. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL, P. 94D
Figure 139 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL

Components: CONVECTION HTR SW (10253); FUSE BLOCK (10301); LF HTR SW (10243A); LR HTR SW (10244A); PLATFORM (1702); R FR HTR SW (10245A); RADIO (10259); RELAY 1 (10314); RELAY 2 (10315); RELAY 3 (10316); RELAY1 (10314); RELAY4 (10317); RF HTR SW (10245A); RR HTR 2 SW (10246B); RR HTR SW (10246A); S HTR SW (10229); SEALED ENG (11500); STEPWELL HTR SW (10258); VENT SW (10226); VENT SW (10227)
Wires (circuit gauge+color): B118A 10BK; B118B 14BK; B118C 12BK; B118D 12BK; B118E 14BK; B118F 12BK; B118H 12BK; B118J 12BK; B132A 12GY; B14 4BK; B14A 6BK; B14B 6BK; B14C 14BK; B14CJ 14BK; B14D 12BK; B14E 12BK; B14F 12BK; B14W 10BK; B14Y 14BK; B14Z 12BK; B74A 18LTGN; B75 12LTGN; B75AJ 12LTGN; B75AL 12LTGN; B75AM 12LTGN; B75P 12LTGN; B75R 12LTGN; B75X 12LTGN; B76A 16LTGN; B76B 16LTGN; B76C 14LTGN; B76D 14LTGN; B77A 18LTGN; B86A 16LTGN
See also sheets: CH17_01, CH17_02, CH19_11, CH19_21, CH19_22, CH19_23, CH19_24, CH19_26, CH19_34, CH19_35, CH19_41, CH19_53
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.102. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL, P. 94D / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 29MAR21 / CHAPTER 3 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL / MJV0488 19NOV21 ADDED CIRC B75R IN FUSE F3 & F5(10301). / RR HTR SW (10246A) CH19_24 FR PWR VENT SW (10226) CH19_41 ELEC PANEL/ SEALED ENG (11500) CH19_53 / F7 B3 25A C3 / NOISE SUPPRESSION RELAY1 (10314) CH3_94U / B118A 10BK B14W 10BK B14Y 14BK / B118C 12BK B14C 14BK B118J 12BK / FUSE BLOCK (10301) F1 B1 A1 25A C1 F2 F1 E1 20A F3# G1 H1 / F8 E3 F3 7.5A / B132A 12GY B75R 12LTGN B75AL 12LTGN / B76A 16LTGN / B14F 12BK B118F 12BK B14Z 12BK / NOISE SUPPRESSION RELAY 1 (10314) CH3_94U B14A 6BK B14B 6BK / B76D 14LTGN B75R 12LTGN B75P 12LTGN / B118D 12BK B14D 12BK / B118B 14BK / G4 F12 H4 7.5A B4 A4 F10 25A C4 / NOISE SUPPRESSION RELAY 2 (10315) CH3_94U / B14E 12BK / B14 4BK / B76B 16LTGN / B75 12LTGN / B75R 12LTGN / F11 E4 F4 7.5A / ELEC PANEL/ PLATFORM (1702) CH19_26,27 RR HTR SW (10246A) CH19_24 / F9 G3 H3 J3 5A / NOISE SUPPRESSION RELAY4 (10317) CH3_94U NOISE SUPPRESSION RELAY 2 (10315) CH3_94U / A2 F4* B2 / POWER STUD (0PWR) / RF HTR SW (10245A) CH19_23 / NOISE SUPPRESSION RELAY 3 (10316) CH3_94U / F6 H2 G2 7.5A / B74A 18LTGN / B118E 14BK / B118H 12BK / E2 F5 F2 25A / B75AM 12LTGN / B75AJ 12LTGN / B76C 14LTGN B75AM 12LTGN B75X 12LTGN / B86A 16LTGN / ELEC PANEL/ PLATFORM (1702) CH17_01 / B86A 16LTGN / B14CJ 14BK / B77A 18LTGN / Figure 139 / BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 180 | printed page 140 | section 3.103
3.103. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94E
Figure 140 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

Components: ACCESORY 1 (10260A); ACCESSORY 3 (10262A); ACCESSORY 4 (10263A); AIR HORN (10285); AIR HORN (10286); BOOSTER PUMP SW (10255); DOME LT PWR (10201); ELEC PANEL/PLATFORM (1702); FR CAP (10000); FUSE BLOCK (10302); RELAY 1 (10318); RELAY 2 (10319); SEON PWR (11643); SEON PWR (11653); STEP WARMER RELAY (10312)
Wires (circuit gauge+color): B100A 18GY; B12A 12BK; B12B 14BK; B12BJ 14BK; B12C 12BK; B12RA 14LTGN; B12RC 14LTBL; B12RD 14LTBL; B13 18PK; B132A 12GY; B137 16LTBL; B137A 16LTBL; B137B 14LTBL; B13K 18PK; B14 4BK; B14A 6BK; B14B 6BK; B14P 12BK; B14R 14BK; B14RJ 14BK; B14S 12BK; B63A 12DKBL; B74A 12LTGN; B86U 14LTGN
See also sheets: CH17_34, CH17_36, CH17_37, CH17_40, CH19_42, CH19_48
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.103. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94E / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / CHAPTER 3 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.) / MJV0488 19NOV21 ADDED CIRC B12RC & B 96289K B12RD IN FUSE F18 & F15 RESPECTIVELY. / B14P 12BK / F13 A1 B1 25A / F14 F1 E1 15A / B86U 14LTGN B12RA 14LTGN B12RD 14LTBL B132A 12GY / FUSE BLOCK (10302) / B74A 12LTGN / B12B 14BK B14R 14BK / MASTER DISCONNECT RELAY 1 (10318) CH3_94S / B12A 12BK / MASTER DISCONNECT RELAY 1 (10318) CH3_94S / F15 H1 G1 20A / B100A 18GY / B12BJ 14BK B14RJ 14BK / B100A 18GY / B100A 18GY / A2 3A F17 E2 F2 15A / ELEC PANEL/PLATFORM (1702) CH13_9A DOME LT PWR (10201) CH8_36A VIDEO SYSTEM (+) (10262) CH17_34 ELEC PANEL/ FR CAP (10000) CH17_34 / B12C 12BK / B14B 6BK / MASTER DISCONNECT RELAY 2 (10319) CH3_94S / B63A 12DKBL B137B 14LTBL B137A 16LTBL B137 16LTBL / F18** H2 / B14 4BK / PWR STUD (OPWR) / ** 7.5A - DDR/DVR CAMERA SYSTEM 20A - VIDEO SYSTEM TERMINAL STRIP / B14A 6BK / 7.5A / 20A / B14S 12BK / B86U 14LTGN B13K 18PK B13 18PK / TWO WAY RADIO+ (10260) CH17_34 SEON PWR (11643) CH17_37 SEON PWR (11653) CH17_37 ACCESSORY 3 (10262A) CH17_40 / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / B12RC 14LTBL / Figure 140 / BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

3.104. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94F
Figure 141 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

Components: ACCESORY 2 (10261A); ACCESSORY 2 (10261A); AED RELAY (10310); AIR COMPRESSOR RELAY (10308); AIR SEAT (10391); ALARM MODULE (11627); ALARM RELAY (10308); BACK UP RELAY (10308); DESTINATION SIGN (10267A); FUSE BLOCK (10302); FUSE F78 (10307); HEATED AIR SEAT (10358); HEATED AIR SEAT (10368); HEATED MIRROR (10293); HEATED MIRROR (10295); LYTX CAMERA PREWIRE (14602); PWR AND GROUND (14520); RELAY 2 (10319); RELAY 3 (10320); TRACTION CHAIN (10265)
Wires (circuit gauge+color): B105 16LTGN; B105 16WH; B105A 16LTGN; B125A 18GY; B125T 18GY; B12D 14BK; B12DJ 14BK; B12E 12BK; B12F 10BK; B12FJ 10BK; B12RB 14LTBL; B12RB 14LTGN; B134 16OR; B134 16RD; B137A 16LTBL; B137B 16LTBL; B137C 16LTBL; B138A 16GY; B13K 18PK; B14 4BK; B146A 12GY; B14A 6BK; B14T 14BK; B14TJ 14BK; B14U 12BK; B14V 10BK; B14VJ 10BK; B78A 18LTGN; B78D 18LTGN
See also sheets: CH10_01, CH13_10, CH17_36, CH17_39, CH17_40, CH19_51, CH19_54, CH7_07, CH7_68
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.104. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94F / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / CHAPTER 3 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.) / MJV0488 19NOV21 ADDED CIRC B12RB IN FUSE F24(10302). / B14 4BK / PWR STUD (0PWR) / B12D 14BK B12DJ 14BK B14TJ 14BK / F19 A3 B3 10A / B78D 18LTGN / B78A 18LTGN / B14T 14BK / MASTER DISCONNECT RELAY 2 (10319) CH3_94S / F21 G3 H3 15A F20 E3 F3 15A / MASTER DISCONNECT RELAY 3 (10320) CH3_94S / B12E 12BK / B14U 12BK / B146A 12GY / B14V 10BK B12F 10BK B12FJ 10BK B14VJ 10BK / F23 E4 F4 15A F24 G4 H4 7.5A / %F22 A4 B4 / B12RB 14LTBL B13K 18PK B138A 16GY / FUSE F78 (10307) CH3_94P / B14A 6BK / HEATED MIRROR (10293) CH10_01 / B125T 18GY / B125A 18GY / B105 16LTGN B105 16WH / B134 16RD B134 16OR / B105A 16LTGN / B105 16LTGN B12RB 14LTGN / FUSE BLOCK (10302) / B137A B137B 16LTBL 16LTBL B137C 16LTBL / % 7.5A - TRACTION CHAINS 20A - TRACTION SANDER NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 141 / BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

3.105. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94G
Figure 142 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

Components: BATTERY (10215A/B); DC PWR (10375A); DC PWR SOURCE (10375); DOME LT POWER (10201); DOME LT PWR (10201); DOME LT TIMER (10397); DOME LT TIMER RELAY (10397); FR DOME LT RELAY (10311); FUSE BLOCK (10303); HAZARD LT SW (10256); HAZARD LT SW (10256B); INPOWER HAZARD ASSERT (11338); MIN TIMER RELAY (10311); PTI HORN RELAY (10311); PTI RELAY (10309); PTI RELAY (10309-C3); R ROW DOME LT RELAY (10311); REAR DOME LT RELAY (10311); RHEOSTAT DIMMER (10376)
Wires (circuit gauge+color): B125J 16GY; B125L 16GY; B14 4BK; B14A 6BK; B14CA 14RD; B14CZ 14RD; B14H 14BK; B14H 14RD; B14K 14RD; B14M 16RD; B14P 16RD; B14XA 16RD; B60 18OR; B63A 12DKBL; B63A 16DKBL; B63AA 16DKBL; B63AH 12DKBL; B63AL 12DKBL; B63B 16DKBL; B63L 16DKBL; B63M 16DKBL; B63RA 12DKBL; B63RB 12DKBL; B84 16LTGN; B84A 16LTGN; B84B 16LTGN; B85 16GY
See also sheets: CH18_23, CH18_44, CH18_51, CH18_54, CH7_65, CH8_07
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.105. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94G / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 28MAR21 / CHAPTER 3 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.) / MJV0488 19NOV21 ADDED CIRC B125L & B125J IN FUSE F26(10303). / FUSE BLOCK (10303) F25 A1 B1 15A (B14H) E1 F26 F1 15A / B14A 6BK / B14 4BK / BATTERY FEED STUD (OPWR) / B60 18OR B60BH 180R B84 16LTGN B84 16LTGN / G1 F27 H1 3A A2 F28 B2 15A / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / B14H 14BK / B63AH 12DKBL / B84A 16LTGN B84B 16LTGN / B14H 14RD / B14H 14RD / B14H 14RD / Figure 142 / BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 183 | printed page 143 | section 3.106
3.106. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94H
Figure 143 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

Components: BATTERY FEED (11505); BOOSTER PUMP RELAY (10311); CLEARANCE LT RELAY (10308); DOOR CONTROL RELAY 1 (10309); ELEC PANEL/FR CAP (10000); ELEC PANEL/PLATFORM (1702); ELEC PANEL/SEALED ENG (11500); FUSE BLOCK (10303); HTR CLNT PUSH BUTTON (11631); LIFT LT RELAY (10312); LIFT SPLICE (10370); LUGGAGE BOX LT (10268); PLATFORM/ELEC PANEL (1702); RADIO (10259); TIMER COMMON (11621); TIMER PWR IN (11619); WEBASTO HTR (10101)
Wires (circuit gauge+color): B120J 16LTGN; B120J 18LTGN; B122E 16GY; B12C 16LTGN; B133A 18LTGN; B135A 16OR; B137 16LTBL; B14 4BK; B14A 6BK; B14AF 16RD; B14K 10BK; B14L 12BK; B14LJ 12BK; B14SE 16RD; B14UB 14RD; B44 18GY; B58 16BN; B71H 18LTBL; B74 14LTGN; B74A 12LTGN; B74A 12RD; B74B 14LTGN; B74B 16RD; B74C 16LTGN; B74C 18RD; B74D 16RD; B74E 18RD; B74P 16RD; B86B 16LTGN
See also sheets: CH15_34, CH16_15, CH16_18, CH16_30, CH16_35, CH17_01, CH17_34, CH17_40, CH19_07, CH19_42, CH19_44, CH19_47, CH19_57, CH19_61, CH19_62, CH7_04, CH7_64
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.106. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94H / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / CHAPTER 3 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.) / MJV0488 19NOV21 ADDED CIRC B14UB IN FUSE F34(10303). / B14L 12BK / B14A 6BK / B14 4BK / BATTERY FEED STUD (0PWR) / (B14K) C2 F30 G2 H2 10A F31 A3 15A B3 / B44 18GY B120J 16LTGN B12C 16LTGN B133A 18LTGN B14AF 16RD B120J 18LTGN B71H 18LTBL B137 16LTBL B14SE 16RD B135A 16OR B14UB 14RD B86B 16LTGN B86B 16LTGN / B74A 12RD B74A 12LTGN B74P 16RD B74C 16LTGN B58 16BN B122E 16GY / #F32 E3 F3 / (B14L) C3 F33 G3 H3 5A F36 H4 G4 5A / B14LJ 12BK / F34 A4 B4 7.5A C4 E4 F35 F4 5A / FUSE BLOCK (10303) / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / F29 F2 E2 15A / B14K 10BK / B14A 6BK / BATTERY FEED STUD (OPWR) / B14 4BK / # 7.5A - MANUAL DOOR 10A - AIR DOOR VANDAL LOCK 15A - ELECTRIC DOOR / Figure 143 / BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

3.107. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94J
Figure 144 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

Components: ALARM RELAY (10308); BACKUP LT RELAY (10308); BATTERY 1 (10262B); BOOSTER PUMP RELAY (10311); BUS SCAN MODULE (10211); CA 2018 CHECKMATE (10339); CCM/TM PWR SPLICE BLOCK (11503); CHECK MATE MODULE (10212); CHILD MONITOR (11642A); ELEC PANEL/PLATFORM (1702); FUSE BLOCK (10304); FUSE F40 (10304); LYTX CAMERA PREWIRE (14602); PTI RELAY (10309); SEON PWR (11643); SEON PWR (11653); STEP LT RELAY (10309); STEP WARMER RELAY (10312); STOP ARM PWR (10359); STOP ARM RELAY (10310); TEMP SENSOR RELAY (10310); THEFT MATE RED DOT (11642A)
Wires (circuit gauge+color): B119 16GY; B125C 18GY; B125D 16GY; B125D 18GY; B125E 18GY; B125H 16GY; B131A 16DKBL; B14 16RD; B14 18RD; B14 4BK; B14A 18RD; B14AA 18RD; B14AH 16RD; B14B 18RD; B14B 6BK; B14CMA 18RD; B14CMB 18RD; B14EE 18RD; B14F 18RD; B14HA 18RD; B14HB 18RD; B14L 18RD; B14M 10BK; B14UA 14RD; B14X 18RD; B53G 18RD; B53H 18RD; B71C 16LTBL; B74 12RD; B89 14OR; B89H 14OR; B89HH 14OR
See also sheets: CH17_36, CH17_37, CH17_39, CH18_43, CH18_46, CH19_47, CH6_09
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.107. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94J / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 3 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.) B14AH 16RD B14 16RD B14UA 14RD B74 12RD B14AH 16RD B119 16GY / MJV0488 19NOV21 ADDED CIRC (B14N) IN FUSE F40 (10304). / FUSE BLOCK (10304) F37 A1 B1 25/5A (B14M) F38 E1 F1 7.5/ C1 15A F39 G1 H1 15A / F40 A2 B2 / B125C 18GY B125E 18GY B14CMA 18RD B125D 18GY B125H 16GY / B14M 10BK / B14B 6BK / B14 4BK / BATTERY PWR STUD (OPWR) / B71C 16LTBL B131A 16DKBL B125E 18GY B125D 18GY B14AA 18RD B14 18RD / B125D 16GY / B89HH 14OR B89H 14OR / B89 14OR / B14A 18RD B14F 18RD B14HA 18RD B14HB 18RD B14X 18RD B14A 18RD B14EE 18RD B14HA 18RD B14HB 18RD B14L 18RD B14A 18RD B14B 18RD B53G 18RD B53H 18RD / B14 18RD / B14 18RD / B14 18RD / B14CMB 18RD / FUSE F40 (10304) CH3_94K / Figure 144 / BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

3.108. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94K
Figure 145 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

Components: ALTERNATE ENTRANCE DOOR (10203); ALTERNATE ENTRANCE DOOR RELAY (10310); BATTERY 1 (10262B); BATTERY 2 (10263B); CA 2018 CHECKMATE (10339); CHILD MONITOR (11642); ELEC PANEL/FR CAP (10000); ELEC PANEL/L BODY (10401A/B); ELEC PANEL/PLATFORM (1702); ELEC PANEL/PLATFORM (1703); ELEC PANEL/SEALED ENG (11500); FIRE SUPPRESSION SYSTEM (10384); FUSE BLOCK (10304); FUSE F40 (10304); IGN RELAY (10321); L AED ELECTRIC (10203A); MIN TIMER RELAY (10311); PTI RELAY (10309); PTIRELAY (10309); SPECIAL EQUIP IGN FEED (11506); STARTER INTERLOCK RELAY (10310); STOP ARM CROSSING GATE CANCEL (10241); THEFT MATE RED DOT (11642A); THEFT MATE RED DOT (11642A)
Wires (circuit gauge+color): B119L 18GY; B120AA 18LTGN; B120AB 16LTGN; B120AB 18LTGN; B120N 18LTGN; B125A 18GY; B125F 18GY; B125H 18GY; B125H 18PK; B13 18PK; B133U 18LTGN; B13A 18PK; B13AA 18PK; B13D 12PK; B13DJ 12BK; B13LS 18PK; B13SE 16PK; B14 4BK; B144 18GY; B144B 18GY; B14B 6BK; B14BA 14RD; B14C 14RD; B14FX 14RD; B14HL 14RD; B14HR 14RD; B14LS 18RD; B14N 12BK; B14UA 14RD; B14UB 14RD; B14X 14RD; B17C 18LTGN; B17C 18PK; B53 16GY; B53A 14RD; B53B 14RD; B74N 16LTGN; B77A 18LTGN; B85X 14GY; B85X 14RD
See also sheets: CH13_12, CH13_15, CH15_37, CH16_22, CH16_26, CH16_31, CH17_36, CH17_40, CH18_43, CH18_44, CH18_45, CH18_48, CH18_49, CH18_54, CH19_42, CH19_53, CH19_55, CH9_04
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.108. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94K / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / CHAPTER 3 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.) / MJV0488 19NOV21 ADDED CIRC B125H/18PK B AT FUSE F48(10304). / F43 A3 B3 3A (B13D) F44 E3 F3 7.5A / F99 D3 C3 5A F45 H3 G3 7.5A C4 / G4 F48 H4 3/5A A4 F46 B4 3A / IGN RELAY (10321) CH3_94R / B13D 12PK / B13DJ 12BK / FUSE BLOCK (10304) / B14N 12BK / F98 D2 C2 5A F42 H2 G2 10A / F41 E2 F2 / B85X 14GY / B85X 14RD / B14HR 14RD B14HL 14RD B53B 14RD B53A 14RD B14FX 14RD B14C 14RD / B14X 14RD / BATTERY PWR STUD (OPWR) / B14 4BK FUSE F40 (10304) CH3_94J / B14B 6BK / Figure 145 / BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

3.109. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94L
Figure 146 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

Components: BUS SCAN MODULE (10211); CHECK MATE MODULE (10212); CHECKMATE VL (11340); CHILD MONITOR (11642); DRIVERS ALARM (10299); ELEC PANEL/FR CAP (10000); ELEC PANEL/L BODY (10400A); ELEC PANEL/L BODY (10400A/B); ELEC PANEL/LEFT BODY (10400A/B); ELEC PANEL/PLATFORM (1702); FUSE BLOCK (10305); FUSE F52 (10305); PLATFORM (1702); PTI RELAY (10310); RELAY 1 (10322); RELAY COIL (10364); SW OUTPUT (11641); VIO DOT (11648)
Wires (circuit gauge+color): B12 18LTBL; B125 18GY; B125C 18GY; B12A 18LTBL; B12AA 18LTBL; B12C 18LTBL; B12H 10BK; B12HJ 10BK; B12J 18LTBL; B12W 18LTBL; B12X 18LTBL; B143 18DKBL; B58J 16BN
See also sheets: CH14_28, CH18_06, CH18_21, CH18_46, CH18_50, CH3_29, CH8_05
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.109. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94L / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / CHAPTER 3 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.) / MJV0488 19NOV21 ADDED CHAPTER B 96289K CH18_50 FOR CIRC B125C. / FUSE BLOCK (10305) A1 F49 B1 7.5A / ELEC PANEL/FR CAP (10000) CH8_05 / ACCESSORY RELAY 1 (10322) CH3_94R / F50 E1 E1 F1 7.5A C1 F51 H1 G1 7.5A / B12A 18LTBL / B12H 10BK / B58J 16BN / B12HJ 10BK / B143 18DKBL / F54 H2 G2 / B125 18GY / B125 18GY B125C 18GY / &B12C 18LTBL / &B12W 18LTBL / B125 18GY / B12 18LTBL / B12C 18LTBL B12J 18LTBL B12W 18LTBL B12X 18LTBL / ELEC PANEL/PLATFORM (1702) CH14_28 ELEC PANEL/LEFT BODY (10400A/B) CH14_19A DRIVERS ALARM (10299) CH14_1A ACCESSORY SPLICE RELAY COIL (10364) CH3_29 / B12A 18LTBL / B12A 18LTBL / B12 18LTBL / PTI RELAY (10310) CH18_42C / & W/ALARM ON W/EMERGENCY EXIT / B12AA 18LTBL / FUSE F52 (10305) CH3_94M / Figure 146 / BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 187 | printed page 147 | section 3.110
3.110. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94M
Figure 147 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

Components: ACCESORY 1 (10260A); ACCESORY 1 (10260B); ACCESORY 3 (10262A); DIODE D70 (10306); DOME LT TIMER (10397); DRIVER MIRROR SW (10353); ELEC PANEL (11500); ELEC PANEL (1703); ELEC PANEL/FR CAP (10000); ENG TEMP SENSOR RELAY (10310); FUSE BLOCK (10305); FUSE F54 (10305); HAZARD LT SW (10256B); LT MONITOR POWER (1079); MIRROR SW (10354); PEDESTRIAN LT (10344); PEDESTRIAN LT RELAY (10282); RELAY 2 (10323); STEP WELL LT RELAY (10309); TEMP SENSOR (10224)
Wires (circuit gauge+color): B128 16LTBL; B12K 10BK; B12KJ 10BK; B12RA 14LTBL; B12RC 14LTGN; B12UA 14LTBL; B131A 16DKBL; B41 18TN; B41B 18TN; B41E 18TN; B41H 18TN; B60BB 18OR; B60BC 18OR; B60BD 18OR; B63A 16DKBL; B78A 18LTGN; B78B 20LTGN; B78C 20LTGN
See also sheets: CH10_02, CH17_36, CH17_40, CH6_03, CH6_11, CH7_65
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.110. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94M / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / CHAPTER 3 BODY CIRCUIT-BATTERY FEED ELECTRICAL PANEL (CONT.) / MJV0488 19NOV21 ADDED CIRC B12RA IN FUSE F52(10305). / F53 E2 20A F2 / B139 16YL / PEDESTRIAN LT (10344) CH7_62A / F59 E4 F4 3A C2 F52 A2 B2 / B139 16YL / B128 16LTBL / PEDESTRIAN LT RELAY (10282) CH7_62A,62B / B12UA 14LTBL / B12RC 14LTGN / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / B78A 18LTGN / C3 F57 G3 H3 7.5A C4 F60 G4 H4 3A / B128 16LTBL B128 16LTBL / B12K 10BK / B12KJ 10BK / FUSE BLOCK (10305) F55 A3 B3 7.5A F56 F3 E3 10A / B60BC 18OR / F58 A4 B4 10A / B41B 18TN / B131A 16DKBL / B60BB 18OR / B60BD 18OR / PLATFORM/ ELEC PANEL (1703) CH13_8D ACCESSORY RELAY 2 (10323) CH3_94R / B60BE 180R / B63A 16DKBL B12RA 14LTBL / B41 18TN / B41E 18TN / FUSE F54 (10305) CH3_94L / B41H 18TN / LT MONITOR POWER (1079) CH6_11 / B78B 20LTGN B78C 20LTGN / Figure 147 / BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

3.111. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94N
Figure 148 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

Components: ACCESORY 2 (10261B); ACCESORY 4 (10263A); BUZZER RELAY (10310); DC PWR OUTLET IN SW PANEL (10375B); ELEC PANEL/FR CAP (10000); ELEC PANEL/L BODY (10400A); ELEC PANEL/L BODY (10400B); ELEC PANEL/SEALED ENG (11500); FUSE BLOCK (10306); IGNITION RELAY (10321); MIN TIMER RELAY (10311); OVERHEAD LOCKING COMPT (10398); OVERHEAD LT (11645); PLATFORM (1702); PTI ISOLATION RELAY (10309); RELAY 1 (10322); RELAY 2 (10323); STROBE LT LATCH RELAY (10300); STROBE LT SW (10270)
Wires (circuit gauge+color): B10LA 18WH; B10LB 18WH; B117H 18LTGN; B125E 18GY; B127 16BK; B127A 16BK; B127A 16OR; B127B 16OR; B12A 18LTBL; B12L 14BK; B12M 14BK; B12MJ 14BK; B12RD 14LTGN; B12UB 14LTBL; B133P 18LTGN; B133R 18LTGN; B13E 12BK; B140 18TN; B63A 16DKBL; B84 16LTGN
See also sheets: CH13_15, CH17_36, CH19_55, CH3_68, CH7_11, CH7_14, CH7_15, CH8_12
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.111. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94N / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / CHAPTER 3 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FUSE BLOCK (10306) / B12M 14BK / F66 H2 G2 3A / F63 H1 G1 3A F65 E2 F2 / B140 18TN / ELEC PANEL/SEALED ENG (11500) CH3_68 / F62 E1 F1 7.5A / B127A 16OR / B12MJ 14BK / B127B 16OR / B127A 16OR / B12L 14BK / B12A 18LTBL / F69 G3 H3 / F68 E3 F3 / F72 G4 H4 3A / B117H 18LTGN / E4F71 F4 3A / IGNITION RELAY (10321) CH3_94R / ACCESSORY RELAY 1 (10322) CH3_94R / B13E 12BK / ACCESSORY RELAY 2 (10323) CH3_94R / B125E 18GY / B133R 18LTGN B133P 18LTGN / B63A 16DKBL / B127 16BK / B127A 16BK / B12RD 14LTGN B12UB 14LTBL / B84 16LTGN / ELEC PANEL/ PLATFORM (1702) CH13_15 / B10LB 18WH / F105 C1 5A D1 / B10LA 18WH / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 148 / BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 189 | printed page 149 | section 3.112
3.112. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94P
Figure 149 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

Components: ACCESORY 2 (10261A); AIR COMPRESSOR RELAY (10308); DRIVERS ALARM (10299); ELEC PANEL/L BODY (10400A/B); ELEC PANEL/PLATFORM (1702); FUSE BLOCK (10302); FUSE BLOCK (10307); FUSE F80 (10307); LT SW (10342); RELAY 4 (10317); SEALED ENG (11500); STD/FR DOME LT (10230)
Wires (circuit gauge+color): B118K 10BK; B12FJ 10BK; B12RB 14LTGN; B131A 16DKBL; B131B 16DKBL; B133L 18LTGN; B14 4BK; B14AA 10BK; B14B 6BK; B14J 18RD; B14VJ 10BK; B14W 18RD; B14XJ 10BK; B63AM 16DKBL
See also sheets: CH16_29, CH17_36, CH8_03, CH8_04, CH8_09
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.112. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94P / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30MAR21 / CHAPTER 3 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FUSE BLOCK (10307) / B14AA 10BK B118K 10BK / B14 B14B 4BK 6BK NOISE SUPPRESSION RELAY 4 (10317) CH3_94U / BATTERY PWR STUD (0PWR) / F81 H3 G3 3A / B136 16YL / ENG COMPT LT SW (10342) CH8_04 ELEC PANEL/ SEALED ENG (11500) CH8_03 ELEC PANEL/PLATFORM (1702) CH16_29 / F74 F1 E1 / F75 H1 G1 F77 E2 F2 F78 G2 H2 / B14VJ 10BK B12FJ 10BK (B14X) / FUSE BLOCK (10302) CH3_94F / G4 F84 H4 10A / B133L 18LTGN / B14XJ 10BK / F83 E4 F4 7.5A / B121 18YL B14W 18RD / ELEC PANEL/ SEALED ENG (11500) CH8_03 DRIVERS ALARM (10299) CH14_1A ELEC PANEL/L BODY (10400A/B) CH14_19A / B14J 18RD / B63AM 16DKBL / STD/FR DOME LT (10230) CH8_09 / B12RB 14LTGN / ACCESORY 2 (10261A) CH17_36 / B131A 16DKBL B131B 16DKBL / AIR COMPRESSOR RELAY (10308) CH7_67A / B121 18YL / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / FUSE F80 (10307) CH3_94Q / Figure 149 / BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 190 | printed page 150 | section 3.113
3.113. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94Q
Figure 150 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

Components: FR DOME LT RELAY (10311); FUSE BLOCK (10307); FUSE F81 (10307); R ROW DOME RELAY (10311); REAR DOME LT RELAY (10311); REAR DOME RELAY (10311)
Wires (circuit gauge+color): A14E 14RD; B125M 16GY; B14 4BK; B14B 6BK; B14CA 14RD; B14DA 18RD; B14FA 18RD; B14G 14RD; B14X 10BK; B63D 16DKBL; B63N 16DKBL
See also sheets: CH18_53
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.113. BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.), P. 94Q / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30MAR21 / CHAPTER 3 BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.) / MJV0488 19NOV21 ADDED CIRC B63D IN FUSE F80(10307). / B14X 10BK / F80 F3 / B63N 16DKBL B125M 16GY B14CA 14RD / B14DA 18RD / A14E 14RD / B14FA 18RD / B14G 14RD / B14B 6BK / B14 4BK / BATTERY PWR STUD (0PWR) / FUSE F81 (10307) CH3_94P / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / FUSE BLOCK (10307) / B63D 16DKBL / Figure 150 / BODY CIRCUIT - BATTERY FEED ELECTRICAL PANEL (CONT.)

3.114. BODY CIRCUIT - ACCESSORY AND IGNITION FEED ELECTRICAL PANEL, P. 94R
Figure 151 BODY CIRCUIT - ACCESSORY AND IGNITION FEED ELECTRICAL PANEL

Components: ELEC PANEL/PLATFORM (1702); FUSE F14 (1011); FUSE F44 (10304); FUSE F50 (10305); FUSE F56 (10305); FUSE F62 (10306); FUSE F65 (10306); FUSE F71 (10306); RELAY (10321); RELAY 1 (10322); RELAY 2 (10323); RELAY COIL (10369); SPLICE (10335B)
Wires (circuit gauge+color): A13AB 18PK; B11-GAH 18WH; B11-GAJ 18WH; B11-GAK 16WH; B12H 10BK; B12K 10BK; B12L 14BK; B12M 14BK; B13A 16PK; B13B 18PK; B13C 16PK; B13D 12BK; B13E 12BK; B14 4BK; B14A 6BK; B14AC1 8BK; B14AC2 8PK; B14B 6BK; B14IGN 8BK
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.114. BODY CIRCUIT - ACCESSORY AND IGNITION FEED ELECTRICAL PANEL, P. 94R / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / CHAPTER 3 BODY CIRCUIT - ACC AND IGN FEED ELECTRICAL PANEL / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 30 ACCESSORY RELAY 2 (10323) / B12K 10BK B12M 14BK / 30 ACCESSORY RELAY 1 (10322) / FUSE F44 (10304) CH3_94K FUSE F71 (10306) CH3_94N / B13D 12BK B13E 12BK / FUSE F14 (1011) CH3_94B B14B 6BK / 85 B11-GAH 18WH / B13A 16PK / B14 4BK / PWR FEED STUD (0PWR) / FUSE F56 (10305) CH3_94M FUSE F65 (10306) CH3_94N / FUSE F50 (10305) CH3_94L FUSE F62 (10306) CH3_94N / 30 IGNITION RELAY (10321) / GROUND SPLICE (10335B) CH3_95H / B12H 10BK B12L 14BK B11-GAK 16WH / B14AC1 8BK / B14A 6BK / B14AC2 8PK / ELEC PANEL/PLATFORM (1702) 62 / B13B 18PK / B11-GAJ 18WH B13C 16PK / A13AB 18PK B14IGN 8BK / ACCESSORY SPLICE RELAY COIL (10369) CH3_30A / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 151 / BODY CIRCUIT - ACCESSORY AND IGNITION FEED ELECTRICAL PANEL

3.115. BODY CIRCUIT - MASTER DISCONNECT, P. 94S
Figure 152 BODY CIRCUIT - MASTER DISCONNECT

Components: DISCONNECT SW (10257); FUSE F13 (10302); FUSE F14 (10302); FUSE F17 (10302); FUSE F19 (10302); FUSE F20 (10302); FUSE F23 (10302); GROUND SPLICE (10335B); NOISE SUPPRESSION SW (10264); RELAY 1 (10314); RELAY 1 (10318); RELAY 2 (10319); RELAY 3 (10320); RELAY COIL (10369); SPLICE (10330)
Wires (circuit gauge+color): B11-GAA 18WH; B11-GAB 18WH; B11-GAC 16WH; B12A 12BK; B12B 14BK; B12C 12BK; B12D 14BK; B12E 12BK; B12F 10BK; B12MD 18LTBL; B12N 18LTBL; B12P 18LTBL; B12R 16LTBL; B12S 18LTBL; B14 4BK; B14A 6BK; B14B 6BK; B14MD1 8BK; B14MD2 8BK; B14MD3 8BK; B62-GAW 18WH; B62AW 18DKBL
See also sheets: CH8_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.115. BODY CIRCUIT - MASTER DISCONNECT, P. 94S / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 29MAR21 / CHAPTER 3 BODY CIRCUIT - MASTER DISCONNECT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B14MD3 8BK / 30 MASTER DISCONNECT RELAY 1 (10318) / MASTER DISCONNECT SW (10257) 2 / B11-GAB 18WH / B62-GAW 18WH B62AW 18DKBL PWR STUD (0PWR) / B12C 12BK B12D 14BK B11-GAC 16WH / B12A 12BK B12B 14BK / B14 4BK / @ W/NOISE SUPRESSION / B12R 16LTBL / B12E 12BK B12F 10BK / FUSE F14 (10302) CH3_94E FUSE F13 (10302) CH3_94E GROUND SPLICE (10335B) CH3_95H B14MD2 B14B 8BK 6BK / B12S 18LTBL B12N 18LTBL / ACCESSORY SPLICE RELAY COIL (10369) CH3_30A NOISE SUPPRESSION SW (10264) CH3_94U NOISE SUPPRESSION RELAY 1 (10314) CH3_94U / B14A 6BK / B12MD 18LTBL @B12S 18LTBL / FUSE F20 (10302) CH3_94F FUSE F23 (10302) CH3_94F / B12N 18LTBL / MASTER DISCONNECT RELAY 3 (10320) / B11-GAA 18WH / B14MD1 8BK / MASTER DISCONNECT RELAY 2 (10319) / 18LTBL B12P / ACCESSORY SPLICE RELAY COIL (10369) CH3_30A / SW ILLUM SPLICE (10330) CH8_31 / FUSE F17 (10302) CH3_94E FUSE F19 (10302) CH3_94F / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 152 / BODY CIRCUIT - MASTER DISCONNECT

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 193 | printed page 153 | section 3.116
3.116. BODY CIRCUIT - NOISE SUPPRESSION, P. 94U
Figure 153 BODY CIRCUIT - NOISE SUPPRESSION

Components: FUSE F10 (10301); FUSE F2 (10301); FUSE F3 (10301); FUSE F4 (10301); FUSE F5 (10301); FUSE F7 (10301); FUSE F75 (10307); FUSE F9 (10301); MASTER DISCONN SW (10257); MASTER DISCONN SWITCH (10257); REALY COILS (10369); RELAY (10312); RELAY 1 (10314); RELAY 2 (10315); RELAY 3 (10316); RELAY 4 (10317); RELAY COILS (10369); SPLICE (10335B); SPLICE (11633); STEP WARMER RELAY (10312); SUPPRESSION SW (10264); SW ILLUM (10366)
Wires (circuit gauge+color): B11-GAD 18WH; B11-GAE 18WH; B11-GAF 18WH; B11-GAG 16WH; B118A 10BK; B118B 14BK; B118C 12BK; B118D 12BK; B118E 14BK; B118F 12BK; B118H 12BK; B118K 10BK; B118L 18LTBL; B118LA 18LTBL; B118M 18LTBL; B118N 18LTBL; B118P 16BK; B118P 16LTBL; B118R 16LTBL; B12S 18LTBL; B12T 18LTBL; B12U 18LTBL; B12V 16LTBL; B14 4BK; B14A 6BK; B14B 6BK; B14NS1 8BK; B14NS2 8BK; B14NS3 8BK; B14NS4 8BK; B62-G 18WH; B62-GBF 18WH; B62BF 18DKBL
See also sheets: CH3_22, CH8_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.116. BODY CIRCUIT - NOISE SUPPRESSION, P. 94U / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 29MAR21 / CHAPTER 3 BODY CIRCUIT - NOISE SUPPRESSION / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FUSE F9 (10301) CH3_94D FUSE F5 (10301) CH3_94D / B11-GAE 18WH / B118A 10BK / B118B 14BK / &B118N 18LTBL B12U 18LTBL / B118C 12BK B118H 12BK B11-GAF 18WH / NOISE SUPPRESSION RELAY 4 (10317) FUSE F4 (10301) CH3_94D FUSE F75 (10307) CH3_94P / NOISE SUPPRESSION RELAY 3 (10316) / FUSE F2 (10301) CH3_94D FUSE F3 (10301) CH3_94D B14NS2 8BK / 30 NOISE SUPPRESSION RELAY 1 (10314) / NOISE SUPPRESSION SW (10264) 2 / % NOISE SUPPRESSION SW OUTPUT * NOISE SUPPRESSION IGN ACTIVATED # N/NOISE SUPPRESSION & W/LOW VOLTAGE MODULE / *B118P 16BK #B12V 16LTBL &B118P 16LTBL / B12S 18LTBL &B12S 18LTBL *B118L 18LTBL B118R 16LTBL &B62-G 18WH B62-GBF 18WH &B62BF 18DKBL / B14NS4 8BK / NOISE SUPPRESSION RELAY 2 (10315) / FUSE F7 (10301) CH3_94D FUSE F10 (10301) CH3_94D / B14NS3 8BK / B118D 12BK B118E 14BK B11-GAG 16WH NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / B118F 12BK B118K 10BK / PRIMARY SW ILLUM (10366) CH8_24 / 18LTBL B12T / %B118L 18LTBL / B12S 18LTBL / STEP WARMER RELAY (10312) CH3_94V ACCESSORY SPLICE RELAY COILS (10369) B14 4BK CH3_30A MASTER DISCONN SW (10257) CH3_94S / B14NS1 8BK / B14A 6BK / GROUND SPLICE (10335B) CH3_95H / B11-GAD 18WH / B14B 6BK / &B118M 18LTBL / &B118L 18LTBL / B118LA 18LTBL / Figure 153 / BODY CIRCUIT - NOISE SUPPRESSION

3.117. BODY CIRCUIT - NOISE SUPPRESSION (CONT.), P. 94V
Figure 154 BODY CIRCUIT - NOISE SUPPRESSION (CONT.)

Components: BODY CONTROLLER (1601); ELEC PANEL/PLATFORM (1702); RELAY (10312); RELAY 1 (10314); SWITCH (10264)
Wires (circuit gauge+color): A12A 18GY; B118-GA 14WH; B118L 18LTBL; B118LA 18LTBL; B12SA 18LTBL
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.117. BODY CIRCUIT - NOISE SUPPRESSION (CONT.), P. 94V / CHAPTER 3 BODY CIRCUIT - NOISE SUPPRESSION (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 19NOV21 ADDED CIRC A12A IN R/D 1702 FOR DIESEL ENG. / 85 F1 / H2 86 / F2 30 / 87A G1 / STEP WARMER RELAY (10312) / B118L 18LTBL / B118-GA 14WH / B118LA 18LTBL / NOISE SUPPRESSION RELAY 1 (10314) CH3_94U / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / NOISE SUPRESSION SWITCH (10264) CH3_94U / GROUND STUD (1GND) / % W/F-2018-PROPANE/GASOLINE ENGINE # W/F-2017-ISB-DIESEL ENGINE / B12SA 18LTBL / ELEC PANEL/PLATFORM (1702) 71 / %A12A 18GY #A12A 18GY / J4-TAN BLUE BODY CONTROLLER (1601) / Figure 154 / BODY CIRCUIT - NOISE SUPPRESSION (CONT.)

3.118. BODY GROUND PLATFORM, P. 95
Figure 155 BODY GROUND PLATFORM

Components: AIR PARK BRAKE CCM (9556); AIR PARK BRAKE SW (1104); AIR PARK BRAKE SW (1104A); CONN X1 (9543); CONNECTOR X1 (9543); DRIVERS INTERFACE UNIT (9548); GROUND SPLICE (1003); GROUND SPLICE (1003B); PANEL LT SPLICE (1002B); PLATFORM/FWD CHASSIS (1700); STUD (4037Z)
Wires (circuit gauge+color): A11-G 12WH; A11-GA 12WH; A11-GG 12WH; A11-GK 16WH; A152-G 18WH; A152-GA 18WH; A44-G 18WH; A67-G 18WH; A67-GA 18WH; A79-G 14WH; A79L-G 16WH; A79M-G 14WH; A79P-G 16WH; A94-G 12WH; A94-GA 12WH; A94-GB 12WH; A94-GC 12WH; A94-GD 12WH
See also sheets: CH13_30, CH13_32, CH13_66, CH3_93, CH8_26
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.118. BODY GROUND PLATFORM, P. 95 / CHAPTER 3 / BODY GROUND - PLATFORM / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 29MAR21 / MJV0488 19NOV21 ADDED CHAPTER B 96289K CH13_66,67 FOR CIRC A67-GA. / A11-G 12WH / SPLICE PACK GROUND STUD (4037Z) / A11-GA 12WH / A11-GG 12WH / A94-G 12WH / A11-GK 16WH / A79-G 14WH / @A94-GD 12WH / A79M-G 14WH A79P-G 16WH A79L-G 16WH / A152-GA 18WH / A67-GA 18WH / A94-GC 12WH / A152-G 18WH / A67-G 18WH / A94-GA 12WH / @A94-GB 12WH / A79P-G 16WH / A79L-G 16WH / A79M-G 14WH / @A79-G 14WH / @A44-G 18WH / Figure 155 / BODY GROUND PLATFORM

3.119. BODY GROUND PLATFORM (CONT.), P. 95A
Figure 156 BODY GROUND PLATFORM (CONT.)

Components: AIR PARK BRAKE CCM (9556); AUTO DRAIN VALVE RELAY (1018); CLUSTER WARNING LT (1555); DC PWR SOURCE (1908); DECU J2 CONN (1827); ENG COMPT INDICATOR (1062); FIRE SUPPRESSION INDICATION (1099); GROUND SPLICE (1003); GROUND STUD (4037Z); J6-18WAY BODY CONTROLLER (1606); JOMARR FIRE SUPPR INDICATIONS (1099A); N2 MODULE (2513); PLATFORM/ELEC PANEL (1702); PLATFORM/ENG (1701); PROTECTION RELAY (2016); PWR INPUT (1404); STEPWELL HTR (1913); VANDAL LOCK STARTER INTERLOCK (1146B); VCR PWR (1052); WEBASTO SMART TIMER (8331); ZONAR V3 PREWIRE (1349)
Wires (circuit gauge+color): A101-G 16WH; A10LS 18WH; A11-G 12WH; A11-GA 12WH; A11-GTS 20WH; A132A-G 14WH; A133-GA 16WH; A137A-G 18WH; A144-G 18WH; A144-GA 18WH; A17CC 18WH; A180-G 18WH; A26-G 18WH; A39C 16GY; A41A-G 18WH; A44-G 16WH; A44K-GA 14WH; A59-G 18WH; A62-GL 18WH; A74-G 16WH; A74-GA 16WH; A84-G 16WH; A94-GE 18WH
See also sheets: CH13_12, CH13_15, CH13_56, CH13_60, CH13_69, CH16_19, CH17_35, CH17_38, CH19_35, CH19_63, CH3_95, CH4_07, CH5_09, CH8_27
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.119. BODY GROUND PLATFORM (CONT.), P. 95A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. GROUND SPLICE (1003) K J H G F / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / CHAPTER 3 / BODY GROUND - PLATFORM (CONT.) / MJV0488 19NOV21 ADDED CIRC A44K-GA IN CAV F OF R/D 1003. / E C B D / GND SPLICE PACK#2 (1004) A / *A11-GA 12WH *A62-GL 18WH A84-G 16WH *A26-G 18WH A41A-G 18WH *A11-GTS 20WH / A180-G 18WH A10LS 18WH *A101-G 16WH A44-G 16WH *A94-GE 18WH A44K-GA 14WH A74-G 16WH A74-GA 16WH *A132A-G 14WH *A133-GA 16WH A62-GL 18WH *A11-G 12WH / A137A-G 18WH / SPLICE PACK GROUND STUD (4037Z) CH3_95 / A59-G 18WH / *A39C 16GY / *A144-GA 18WH / *A144-G 18WH A17CC 18WH / Figure 156 / BODY GROUND PLATFORM (CONT.)

3.120. BODY GROUND PLATFORM (CONT.), P. 95B
Figure 157 BODY GROUND PLATFORM (CONT.)

Components: AUTO XMSN PANEL LT (1501); CLOCK SPRING (1832); CLUSTER WARNING LT (1555); DEFOG FAN SW (1135); DEFOG FAN SW (1135A); DEFOG FAN SW (1136); DEFOG FAN SW (1136A); ECONOMY MODE SW RELAY (1015); GROUND SPLICE (1003A); HYD PARK BRAKE SW (9267A); PARK BRAKE (1105M); PLATFORM (1700); RADIO/PA 2 CHANNEL (1301); RADIO/PA 4 CHANNEL (1300); SHIFT SELECTOR (1850); STUD (4037A); SW AND PANEL LT (1830); VANDAL LOCK KEY SW (1146); VANDAL SOLENOID (1147); WIPER MOTER (4046)
Wires (circuit gauge+color): A11-GE 20WH; A11-GH 12WH; A11-GZ 8WH; A133-G 18WH; A133B-G 18WH; A62-GC 18WH; A62-GE 18WH; A62E-G 18WH; A62F-G 18WH; A62G-G 18WH; A82-GA 16WH; A86-G 18WH; A90-G 18WH; A90B-G 18WH; A90C-G 18WH; A90D-G 18WH; A92-G 18WH; A94-GE 18WH
See also sheets: CH12_03, CH12_04, CH13_34, CH13_56, CH13_57, CH16_15, CH16_28, CH17_01, CH17_33, CH19_26, CH19_27, CH8_51
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.120. BODY GROUND PLATFORM (CONT.), P. 95B / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. GROUND SPLICE (1003A) A / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / CHAPTER 3 BODY GROUND - PLATFORM (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A82-GA 16WH / A11-GZ 8WH WIPER MOTER (4046) CH13_8A SHIFT SELECTOR (1850) CH12_03 / A62-GC 18WH &A86-G 18WH / *A62E-G 18WH #A62F-G 18WH %A62E-G 18WH / A92-G 18WH A11-GE 20WH / A62-GE 18WH / A#169A 18GY / @A86-G 18WH **A90D-G 18WH / A133B-G 18WH / L HAND DEFOG FAN SW (1135A) CH19_27 R HAND DEFOG FAN SW (1136) CH19_27 / A133-G 18WH / BODY GROUND STUD (4037A) / A11-GH 12WH / #A62G-G 18WH / #A62E-G 18WH / FORWARD CHASSIS/ PLATFORM (1700) CH13_34 HYDRAULIC PARK BRAKE (1105M) CH13_34 / **A90B-G 18WH / **A90C-G 18WH / ##A94-GE 18WH / &&A90-G 18WH / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 157 / BODY GROUND PLATFORM (CONT.)

3.121. BODY GROUND PLATFORM (CONT.), P. 95C
Figure 158 BODY GROUND PLATFORM (CONT.)

Components: AUX HAZARD RELAY (1022); BRAKE SOLENOID (1031); DAY W/TIMER (9996); DECU J1 CONN (1826); DUAL AC RELAY (1027A); ESPAR MULTI MAX TIMER (1053); GROUND (4037Z); GROUND SPLICE (1003B); HEATED WIPERS (4501); INDICATORS (1060); INDICATORS (1060A); INTERLOCK RELAY (1013); PHMI DISPLAY CONN (1829); PLATFORM/ELEC PANEL (1703); PLATFORM/ENG (1701); REGEN SW (9266); STOP LT RELAY (1011)
Wires (circuit gauge+color): A10-GA 18WH; A11-GG 12WH; A11-GL 18WH; A44-GC 18WH; A44C-G 18WH; A44K-G 14WH; A44K-G1 14WH; A44K-G2 14WH; A56-G 16OR; A74-GA 16WH; A74-GA 18WH; A74-GB 18WH; A74-GC 18WH; A77-GB 18WH; A77H 18WH; A82-GW 16WH; A89RK-G 18WH; B44-GB 18GY; B44-GD 18GY
See also sheets: CH11_18, CH13_20, CH13_61, CH13_63, CH13_68, CH13_69, CH15_33, CH19_12, CH19_50, CH19_56, CH3_95, CH4_10, CH6_10, CH6_11
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.121. BODY GROUND PLATFORM (CONT.), P. 95C / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. GROUND SPLICE (1003B) / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / CHAPTER 3 BODY GROUND - PLATFORM (CONT.) / MJV0488 19NOV21 ADDED CIRC A44K-G, B 96289K A44K-G1,A44K-G2 IN CAV F AT R/D 1003B. / RED/AMBER INDICATORS (1060) CH6_10 RED/AMBER INDICATORS (1060A) CH6_11 PLATFORM/ELEC PANEL (1703) CH15_33 STOP LT RELAY (1011) CH4_10 REGEN SW (9266) CH13_20 / A89RK-G 18WH / A11-GG 12WH / SPLICE PACK GROUND (4037Z) CH3_95 / A89RK-G 18WH / A44C-G 18WH / A10-GA 18WH @A11-GL 18WH / A44C-G 18WH / A44-GC 18WH / @A82-GW 16WH A56-G 16OR @A77-GB 18WH @A74-GC 18WH / @A74-GA 16WH @A44K-G 14WH / A74-GA A74-GA 18WH 18WH A74-GB 18WH / B44-GD 18GY / B44-GB 18GY / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / A44K-G1 14WH A44K-G2 14WH / #A77H 18WH / Figure 158 / BODY GROUND PLATFORM (CONT.)

3.122. BODY GROUND ELECTRICAL PANEL, P. 95D
Figure 159 BODY GROUND ELECTRICAL PANEL

Components: DC POWER (10375A); DC POWER SOURCE (10375); DRIVERS FAN (10284); DRIVERS HTR (10367); ELEC PANEL/FR CAP (10000); ELEC PANEL/L BODY (10400A/B); ELEC PANEL/L BODY (10401A/B); GROUND SPLICE (10334); GROUND SPLICE (10335A); GROUND SPLICE (10335B); GROUND SPLICE (10336); GROUND SPLICE (10337); IN SW PANEL (10375B)
Wires (circuit gauge+color): B11-GA 12WH; B11-GB 16WH; B11-GC 10WH; B11-GD 12WH; B11-GE 12WH; B11-GF 12WH; B11-GG 12WH; B11-GH 10WH; B11-GJ 10WH; B11-GK 16WH; B75-G 12WH; B76-GA 14WH; B76-GC 14WH; B76-GD 14WH; B76-GE 14WH; B76-GF 14WH; B76D-G 14WH; B84-G 16WH; B84-GA 16WH; B84-GB 16WH
See also sheets: CH19_11, CH19_29, CH19_31, CH19_49, CH3_43, CH3_44, CH3_45, CH3_54, CH3_56
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.122. BODY GROUND ELECTRICAL PANEL, P. 95D / CHAPTER 3 BODY GROUND - ELEC PANEL / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 29MAR21 / MJV0488 10JUN21 INITIAL PRODUCTION RELEASE. / B11-GA 12WH B11-GD 12WH B11-GB 16WH / B11-GK 16WH / B11-GC 10WH / B75-G 12WH / B84-GB 16WH B11-GG 12WH / GROUND STUD (OGND) / B11-GJ 10WH B11-GH 10WH B84-G 16WH / B84-GA 16WH / B76-GC 14WH B76-GD 14WH B76-GA 14WH / B76-GC 14WH / *B76-GF 14WH #B76-GE 14WH / B11-GE 12WH / B11-GF 12WH / B84-G 16WH / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / B76D-G 14WH / Figure 159 / BODY GROUND ELECTRICAL PANEL

3.123. BODY GROUND ELECTRICAL PANEL (CONT.), P. 95E
Figure 160 BODY GROUND ELECTRICAL PANEL (CONT.)

Components: AED VANDAL LOCK RELAY (10310); CONVECTION HEATER (10254); ELEC PANEL/FR CAP (10000); GROUND (10215G); L AUX HTR (10247); L REAR AUX HTR (10248); R FR AUX HTR (10249); R REAR AUX HTR (10250); SEON POWER (11643); SEON POWER (11653); STEP WARMER RELAY (10312); WEBASTO HTR (10101); WEBASTO SMART TEMP (14510); WEBASTO SMART TIMER (11623A); WEBASTO SMART TIMER (11632); WEBASTO TEMP SMART TIMER (14510A)
Wires (circuit gauge+color): B11 16WH; B11-GZ 16WH; B118-GA 14WH; B120-GV 16WH; B137-GB 14WH; B63-GRA 12WH; B74-G 16WH; B74-G 18WH; B74-GA 12WH; B74-GA 16WH; B74A-G 12WH; B75-GA 12WH; B75-GB 12WH; B75-GC 12WH; B75-GD 12WH; B86-GU 14WH; B9T-G 16GY
See also sheets: CH16_35, CH17_34, CH17_37, CH19_21, CH19_22, CH19_23, CH19_24, CH19_34, CH19_43, CH19_61, CH19_63, CH19_64, CH8_07
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.123. BODY GROUND ELECTRICAL PANEL (CONT.), P. 95E / CHAPTER 3 BODY GROUND - ELEC PANEL (CONT) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B75-GB 12WH B120-GV 16WH / B75-GA 12WH / B75-GC 12WH / GROUND STUD (1GND) / B74-GA 16WH B86-GU 14WH / B137-GB 14WH / B75-GA 12WH B75-GD 12WH B118-GA 14WH B11-GZ 16WH B74-GA 16WH / B74-G 16WH B74A-G 12WH B74-GA 12WH / B9T-G 16GY / B74-G 18WH / B63-GRA 12WH / B11 16WH B74-G 16WH / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 160 / BODY GROUND ELECTRICAL PANEL (CONT.)

3.124. BODY GROUND ELECTRICAL PANEL (CONT.), P. 95F
Figure 161 BODY GROUND ELECTRICAL PANEL (CONT.)

Components: AND GROUND (14520); BACK UP RELAY (10308); CHILD MONITOR (11642); CHILD SAFETY ALM RELAY (10308); CROSSING GATE (10219B); DRIVER DOME LT (10207); ELECTRICAL COMPT LT (10341); GROUND SPLICE (10334); GROUND SPLICE (1090); HEATED MIRROR (10295); PTI CONTROL RELAY (10309); REAR STOP ARM (10475B/10475A); RED DRIVERS DOME LT DROP (11646); STOP ARM (10221); STOP ARM RELAY (10310); STOP ARM SOLENOID (10219); STOP ARM SOLENOID 2 (10219A); STROBE LT INDICATOR (10395); STROBE LT INTENSITY (10242); TEMP SENSOR RELAY (10310); TO DIST UNIT POWER 7 GROUND (14521)
Wires (circuit gauge+color): B11-GA 12WH; B11-GD 16WH; B11-GE 18WH; B11-GF 16WH; B119-GB 18WH; B119-GC 18WH; B119-GE 16WH; B119-GG 18WH; B119-GN 16WH; B119-GN 18WH; B127-GA 16WH; B128-G 16WH; B136-GA 16WH; B137-GA 16WH; B137-GA 18WH; B137-GB 16WH; B137-GC 16WH; B137-GK 16WH; B63-GA 16WH; B63-GAB 16WH; B63-GAC 14WH; B78-GE 18WH; B89G 16WH; B89GA 16WH; B89GG 16WH
See also sheets: CH10_01, CH6_09, CH6_11, CH7_17, CH7_68, CH7_69, CH8_04, CH8_12, CH9_02, CH9_07, CH9_08, CH9_12
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.124. BODY GROUND ELECTRICAL PANEL (CONT.), P. 95F / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. GROUND SPLICE (10334) A / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 14APR21 / CHAPTER 3 BODY GROUND - ELEC PANEL (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B119-GE 16WH %B119-GN 16WH @B119-GN 18WH **B63-GAB 16WH B63-GAC 14WH B78-GE 18WH *%B136-GA 16WH *&B63-GA 16WH B119-GG 18WH / B11-GA 12WH B127-GA 16WH / #B119-GB 18WH &B119-GC 18WH *B89GA *B89GG 16WH 16WH *B89G 16WH / GROUND STUD (OGND) CH3_95D / B128-G 16WH / B137-GC 16WH / B137-GB 16WH B137-GA 16WH B137-GB 16WH B137-GA 18WH B137-GK 16WH / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / B11-GE 18WH B11-GF 16WH / B11-GD 16WH / B137-GC 16WH / Figure 161 / BODY GROUND ELECTRICAL PANEL (CONT.)

3.125. BODY GROUND ELECTRICAL PANEL (CONT.), P. 95G
Figure 162 BODY GROUND ELECTRICAL PANEL (CONT.)

Components: AC RELAY (10308); AED VANDAL LOCK RELAY (10310); BOOSTER PUMP RELAY (10311); BOOSTER PUMP RELAY (10311-A3); CLNT HTR PUSH-BUTTON (11631); DAY TIMER WEBASTO (11630); DOME LT TIMER REALY (10397); DOME LT TIMER RELAY (10397); ELEC PANEL/L BODY (10401A/B); ELEC PANEL/PLATFORM (1702/1702); ELEC PANEL/PLATFORM (1703); ESPAR MULTIMAX TIMER PREWIRE (1053); FLASH LT INDICATOR (10371); GROUND SPLICE (10335A); INCH LIFT INDICATOR (1051); INCH LIFT INDICATOR (9555); LIFT INTERLOCK RELAY (10312); REAR DOME LT RELAY (10311); REAR ROW DOME LT RELAY (10311); RELAY (10308); STEP WARMER RELAY (10312); TIMER 2 (11620A); TIMER GROUND (11620)
Wires (circuit gauge+color): A122B 18GY; A122B-G 16WH; B11-G 16WH; B11-G 18WH; B11-GA 16WH; B11-GBY 16WH; B122 18GY; B122-G 18WH; B122-GA 18WH; B122-GB 18WH; B122-GC 18WH; B132-GC 18WH; B58-GF 18WH; B63-G 16WH; B63-GA 16WH; B63-GB 16WH; B63-GE 14WH; B63-GF 16WH; B74-G 16WH; B74-G 18WH; B74-GA 16WH; B74-GA 18WH; B74-GB 14WH; B74-GB 18WH; B74-GC 18WH; B74-GT 16WH; B74E 18LTGN; B74F 18WH; B74H 18WH; B74J 18WH; B77-G 18WH
See also sheets: CH15_31, CH15_34, CH15_40, CH18_54, CH19_09, CH19_42, CH19_43, CH19_44, CH19_45, CH19_46, CH19_47, CH19_48, CH19_52, CH19_61, CH19_62, CH5_05
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.125. BODY GROUND ELECTRICAL PANEL (CONT.), P. 95G / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. GROUND SPLICE (10335A) A B C / CHAPTER 3 BODY GROUND - ELEC PANEL (CONT.) / MJV0488 19NOV21 ADDED CIRC B122-GC & B 96289K B11-G IN CAV K & F AT R/D 10335A. / B74E 18LTGN B74E 18LTGN B74-G 18WH B74-GT 16WH B74-G 16WH / H J / E F / B122 18GY / B11-GBY 16WH B58-GF 18WH B77-G 18WH B74F 18WH / B132-GC 18WH B11-G 18WH B11-G 16WH B11-GA 16WH B63-G 16WH B63-GB 16WH / GROUND STUD (OGND) CH3_95D / B74H 18WH B74J 18WH / B63-GE 14WH B63-GF 16WH B63-GA 16WH ELEC PANEL/PLATFORM (1702/1702) B11-G 18WH 15 A122B 18GY A122B-G 16WH / B74-GB 14WH B74-GB 18WH B74-GB 18WH B74-GC 18WH B74-GA 18WH B74-GA 16WH B74-G 18WH B74-GA 18WH / B74-G 18WH / B74-GB 18WH / Figure 162 / BODY GROUND ELECTRICAL PANEL (CONT.)

3.126. BODY GROUND ELECTRICAL PANEL (CONT.), P. 95H
Figure 163 BODY GROUND ELECTRICAL PANEL (CONT.)

Components: AIR COMPRESSOR RELAY (10308); BUS SCAN MODULE (10211); BUS SCAN PILOT LT (10325); BUZZER RELAY (10310); CCM/TM GROUND SPLICE BLOCK (11502); CHECK MATE MODULE (10212); CHILD SAFETY ALARM RELAY (10308); DOOR CONTROL RELAY (10309); DOOR SW OPEN SIGNAL (11600C); ELEC PANEL/L BODY (10401A/B); ENG TEMP SENSOR RELAY (10310); GROUND SPLICE (10335B); IGN RELAY (10321); MASTER DISCCONNECT RELAY 1 (10318); NOISE SUPPRESSION RELAY 1 (10314); POSN TOGGLE W/AMBER CANCEL (11770); REAR DOME LT RELAY (10311); RR DOME LT RELAY (10311); STEP LT RELAY (10309); THEFT MATE RED DOT (11642A); W/AMBER CANCEL (11760)
Wires (circuit gauge+color): B11-G 18WH; B11-GAA 18WH; B11-GAD 18WH; B11-GAH 18WH; B11-GK 16WH; B117-GL 18WH; B120-G 18WH; B120-GK 18WH; B125-G 16WH; B125-G 18WH; B125-GA 18WH; B125-GB 16WH; B125-GL 18WH; B125A 18GY; B125B 18GY; B146-G 18WH; B41-GC 18WH; B63GA 18WH; B9P 18GY
See also sheets: CH16_34, CH16_35, CH18_46, CH18_47, CH18_53, CH19_51
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.126. BODY GROUND ELECTRICAL PANEL (CONT.), P. 95H / CHAPTER 3 BODY GROUND - ELEC PANEL (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. GROUND SPLICE (10335B) A / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 19NOV21 ADDED CIRC B63GA IN CAV J AT R/D 10335B. / B120-GK 18WH B9P 18GY B117-GL 18WH B120-G 18WH B120-G 18WH / B146-G 18WH B11-G 18WH / B11-GAA 18WH / B11-GAD 18WH B11-GAH 18WH / B11-GK 16WH B120-GK 18WH / B41-GC 18WH B125-G 16WH / B125-G 18WH B125-GL 18WH B125-G B125-G 18WH 18WH B125-G 18WH B63GA 18WH *B125B 18GY &B125A 18GY / B125-GB 16WH B125-GA 18WH / B125B 18GY / Figure 163 / BODY GROUND ELECTRICAL PANEL (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 204 | printed page 164 | section 3.127
3.127. BODY GROUND ELECTRICAL PANEL (CONT.), P. 95J
Figure 164 BODY GROUND ELECTRICAL PANEL (CONT.)

Components: AIR SEAT (10391); CA 2018 CHECKMATE (10339); CCM/TM GROUND SPLICE BLOCK (11502); CHILD MONITOR (11642); GROUND SPLICE (10336); HEATED AIR SEAT (10358); HEATED AIR SEAT (10368); INPOWER HAZARD ASSERT (11338); OVHD/OVER LOCKING COMPT (10398); PED LT RELAY (10310); PTI RELAY (10309); PTI RELAY (10309-A3); STEP WARMER RELAY (10312); THEFT MATE RED DOT (11642A)
Wires (circuit gauge+color): B105-G 16WH; B11-GC 10WH; B12-G 18WH; B125-G 18WH; B125-GA 10WH; B125-GA 14WH; B125-GA 16WH; B125-GD 18WH; B125-GE 18WH; B125-GL 14WH; B125-GM 18WH; B133-GR 18WH; B53-GHA 18WH; B53-GHB 18WH; B53B-G 18WH; B53C-G 18WH; B60-G 16WH; B85-GH 18WH; B85A-G 18WH
See also sheets: CH18_23, CH18_48, CH19_54, CH19_55
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.127. BODY GROUND ELECTRICAL PANEL (CONT.), P. 95J / CHAPTER 3 BODY GROUND - ELECTRICAL PANEL (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (10336) A / B C / B105-G 16WH B105-G 16WH B105-G 16WH B125-GD 18WH B125-GA 16WH / GROUND STUD (0GND) CH3_95D / B11-GC 10WH / PTI RELAY (10309) CH18_42A PED LT RELAY (10310) CH18_42C / B125-GA 10WH / B53-GHA 18WH B12-G 18WH / B125-GL 14WH B125-GM 18WH B53-GHB 18WH B85-GH 18WH B60-G 16WH B125-G 18WH B125-GE 18WH B53B-G 18WH B53C-G 18WH B60-G 16WH B85A-G 18WH B125-G 18WH B60-G 16WH / B125-GA 16WH / B125-GA 14WH / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / B133-GR 18WH / OVHD/OVER LOCKING COMPT (10398) CH19_55 / Figure 164 / BODY GROUND ELECTRICAL PANEL (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 205 | printed page 165 | section 3.128
3.128. BODY GROUND ELECTRICAL PANEL (CONT.), P. 95K
Figure 165 BODY GROUND ELECTRICAL PANEL (CONT.)

Components: AED RELAY (10310); ALTERNATE ENTRANCE DOOR RELAY (10310); CHILD SAFETY ALARM MODULE (11627); CHILD SAFETY ALARM RELAY (10308); CROSSING GATE RELAY (10307); ELEC PANEL/SEALED ENG (11500); MASTER WARN CANCEL (10236A); PARK BRAKE RELAY (10308); PEDESTRIAN LT RELAY (10310); PEDESTRIAN LT TIMER (10282); SPLICE (10336); SYSTEM RELAY (10312)
Wires (circuit gauge+color): B119-G 16WH; B120-GD 18WH; B123-GK 18WH; B125-GS 18WH; B125-GT 18WH; B125-GU 18WH; B125U-G 18WH; B134-G 16WH; B139-G 16WH; B44-G 18WH
See also sheets: CH16_31, CH6_23, CH6_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.128. BODY GROUND ELECTRICAL PANEL (CONT.), P. 95K / CHAPTER 3 BODY GROUND - ELECTRICAL PANEL (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 19NOV21 ADDED CHAPTER B 96289K CH7_62B FOR CIRC B139-G. / GROUND SPLICE (10336) E / B44-G 18WH / B139-G 16WH / B139-G 16WH / B125-GS 18WH / PARK BRAKE RELAY (10308) CH13_4A / CHILD SAFETY ALARM MODULE (11627) CH18_40A / PEDESTRIAN LT RELAY (10310) CH7_62A / CHILD SAFETY ALARM RELAY (10308) CH18_40A / B120-GD 18WH B134-G 16WH / B125-GT 18WH / B125-GU 18WH / PEDESTRIAN LT TIMER (10282) CH7_62A,62B / B119-G 16WH / CROSSING GATE RELAY (10307) CH9_6A / B123-GK 18WH / B125U-G 18WH / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / B123-GK 18WH / Figure 165 / BODY GROUND ELECTRICAL PANEL (CONT.)

3.129. BODY GROUND ELECTRICAL PANEL (CONT.), P. 95L
Figure 166 BODY GROUND ELECTRICAL PANEL (CONT.)

Components: AIR HORN (10285); AIR HORN PULL SW (10287); DIMMER UNIT (10372); DOOR CONTROL (10047); DRIVERS MIRROR (10355); FIRE SUPPRESION SYSTEM (10383); FIRE SUPPRESION SYSTEM (10385); FR CAP (10000); GROUND SPLICE (10337); ILLUM SPLICE (10366); MIRROR SW (10353/10354); MODULE (10500); RADIO (10259); STROBE LT LATCH RELAY (10300); STROBE LT RELAY (10308); TEMP SENSOR BUZZER (10390)
Wires (circuit gauge+color): B100-G 16GY; B100-G 18WH; B11-GD 12WH; B120-GC 18WH; B127-G 16WH; B144-G 18WH; B144-GA 18WH; B144-GF 18WH; B144-GG 18WH; B41-GK 18WH; B62-G 18WH; B62-GAN 18WH; B78-G 18WH; B78-GA 18WH; B78-GC 20WH; B78-GD 20WH; B86-G 16WH; C120-G 16WH
See also sheets: CH10_02, CH10_07, CH13_12, CH17_02, CH7_13, CH7_14, CH8_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.129. BODY GROUND ELECTRICAL PANEL (CONT.), P. 95L / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. GROUND SPLICE (10337) A / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / CHAPTER 3 BODY GROUND - ELEC PANEL (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B41-GK 18WH / B86-G 16WH B62-GAN 18WH / B11-GD 12WH B100-G 18WH B100-G 16GY B144-G 18WH / AIR HORN (10285) CH13_9A AIR HORN PULL SW (10287) CH13_9A FIRE SUPPRESION SYSTEM (10385) CH13_12 / B127-G 16WH B127-G 16WH / GROUND STUD (0GND) CH3_95D / B78-GA 18WH B78-GC 20WH B78-GD 20WH / B62-G 18WH / B120-GC 18WH / ELEC PANEL/ FR CAP (10000) B1 / C120-G 16WH / FR CAP/ENT DOOR CONTROL (10047) CH16_9A,10A DRIVERS MIRROR (10355) CH10_07 MIRROR SW (10353/10354) CH10_02 / B78-G 18WH / B127-G 16WH / B144-GF B144-GF 18WH 18WH B144-GA 18WH B144-GG 18WH / FIRE SUPPRESION SYSTEM (10383) CH13_12 / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 166 / BODY GROUND ELECTRICAL PANEL (CONT.)

3.130. ZERO VOLT REFERENCE SPLICE, P. 95M
Figure 167 ZERO VOLT REFERENCE SPLICE

Components: AIR PARK BRAKE SW (1104); AIR PARK BRAKE SW (1104B); AIR PARK BRAKE SW (1813); AUX HAZARD RELAY (1022); BRAKE SW (1814); CLOCK SPRING (1809); CLOCK SPRING (1832); CONTROLLER (1602); EMERGENCY EXIT RELAY (1020); INSPECTION RELAY (1021); MANUAL HYD PARK BRAKE SW (9267); MANUAL NEXT GEN HYD PARK BRAKE SW (9267A); PARK BRAKE ZVR SIGNAL RELAY (9998); PLATFORM/ELEC PANEL (1702/1702); PLATFORM/FWD CHASSIS (1700); PRIMARY AIR PRESSURE SENSOR (1811A/1811); REFERENCE (1005); SEAT BELT ALARM (1109); SECONDARY AIR PRESSURE SENSOR (1812A/1812); STOP LT 1 PRESSURE SW (1023A/1823); STOP LT 2 PRESSURE SW (1024A/1824); TURN SIGNAL SW (1810); WHEEL CHAIR LIFT RELAY (1019); ZVR SPLICE (1005A); ZVR SPLICE (1035OA)
Wires (circuit gauge+color): A125J 18GY; A9A 16GY; A9AA 18GY; A9B 16GY; A9B 18GY; A9BB 16GY; A9BB 18GY; A9C 18GY; A9CA 18GY; A9D 16GY; A9FA 18GY; A9H 18GY; A9HA 18GY; A9HA 20TN; A9J 18GY; A9K 18GY; A9S 18GY; A9T 18GY; A9U 18GY; A9VC 18GY; A9VE 18GY; A9VF 18GY; A9VG 16GY; A9VH 16GY; A9VL 14GY; A9VL 18GY; B9L 16GY
See also sheets: CH13_03, CH13_34, CH13_57, CH15_32, CH3_59, CH5_11, CH8_51, CH8_52
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.130. ZERO VOLT / SPLICE, P. 95M / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30MAR21 / CHAPTER CHAPTER 3 3 SPLICE / ZERO VOLT / MJV0488 19NOV21 ADDED R/D 1104B & CIRC A9VL, A9B IN CAV B. / A9C 18GY A9AA 18GY A9VL 18GY A9VL 18GY A9K 18GY A9K 18GY %A9K 18GY A9A 16GY A9BB 18GY A125J 18GY / J5 - TAN BODY CONTROLLER (1602) ZERO VOLT (1005) A / D E / A9T 18GY A9U 18GY A9S 18GY / A9D 16GY A9FA 18GY / ZVR 2 / A9VF 18GY A9HA 20TN / A9CA 18GY / A9J 18GY / A9VL 14GY / A9H 18GY / A9B 18GY A9B 18GY / A9BB 16GY A9B 16GY A9VG 16GY A9VH 16GY / A9VC 18GY A9VE 18GY / A9HA 18GY / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 167 / ZERO VOLT

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 208 | printed page 168 | section 3.131
3.131. ZERO VOLT REFERENCE SPLICE (CONT.), P. 95N
Figure 168 ZERO VOLT REFERENCE SPLICE (CONT.)

Components: AC RELAY (10308); ALARM RELAY (10308); ALTERNATE ENTRANCE DOOR (10203); DOOR CONTROL RELAY 1 (10309); DOOR CONTROL SW (10200); DOOR SW ZERO VOLT REF (11600A); ELEC PANEL/PLATFORM (1702); ELEC PANEL/PLATFORM (1702/1702); ENABLE (10283); FLASHER CANCEL (10239); FLASHER OVERRIDE (10238); FLASHER START SW (10237); FLASHER SYSTEM RELAY (10311); FR CAP/ELEC PANEL (10001); HAZARD LT SW (10256B); MASTER FLASHER (10236); PWL RELAY (10308); REDUNDANT DOOR SW (10365); W/AMBER CANCEL (11770); ZERO VOLT REFERENCE (1005); ZVR SPLICE (10350A); ZVR SPLICE (10350B)
Wires (circuit gauge+color): A9D 16GY; B123A 18LTGN; B123B 18GY; B152-G 18WH; B60BA 18OR; B67-GA 18WH; B77D 18LTGN; B9A 18GY; B9B 18GY; B9C 18GY; B9D 18GY; B9E 18GY; B9F 18LTGN; B9H 18GY; B9J 18LTGN; B9K 18GY; B9L 16GY; B9M 16GY; B9N 16GY; B9P 18GY; B9S 18GY
See also sheets: CH13_65, CH15_36, CH16_01, CH16_06, CH16_22, CH16_27, CH16_32, CH16_34, CH19_52, CH6_15, CH6_18, CH6_20, CH6_21, CH6_23, CH7_65
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.131. ZERO VOLT / SPLICE (CONT.), P. 95N / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30MAR21 / CHAPTER 3 SPLICE (CONT.) / ZERO VOLT / MJV0488 19NOV21 ADDED CIRC B67-GA IN CAV D OF R/D 10350A. / B C / G H / B67-GA 18WH B152-G 18WH B9P 18GY / B9L 16GY / ZVR SPLICE (10350B) F / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / B9B 18GY B9A 18GY / Figure 168 / ZERO VOLT / SPLICE (CONT.)

3.132. J1708 DATALINK COMPLETE W/ WTEC XMSN W/ BODY CONTROLLER W/
Figure 169 J1708 DATALINK COMPLETE W/ WTEC XMSN W/ BODY CONTROLLER W/ 2017 ISB

Components: ENGINE/PLATFORM (1701); INSTRUMENT CLUSTER (1505); J1939 SPLICE (1029)
See also sheets: CH3_86
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.132. J1708 DATALINK COMPLETE W/ WTEC XMSN W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE, P. 96 / CHAPTER 3 J1708 DATALINK COMPLETE W/WTEC XMSN W/BODY CONTROLLER W/2017-ISB-DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / INSTRUMENT CLUSTER (1505) (+) (-) CAN CAN 12 11 / A5D(+) 18YL / J1939 SPLICE (1029) / A5AL(+) A5AM(-) 18YL 18GN / A5B(-) 18GN / A5D(-) 18GN / J1939 SPLICE (1029) / A5A(-) 18GN A5A(+) 18YL / A5B(+) 18YL / ENGINE/PLATFORM (1701) CH3_86,87 / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 169 / J1708 DATALINK COMPLETE W/ WTEC XMSN W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE

3.133. J1708 DATALINK COMPLETE W/ WTEC XMSN W/ BODY CONTROLLER W/
Figure 170 J1708 DATALINK COMPLETE W/ WTEC XMSN W/ BODY CONTROLLER W/ 2017 ISB

Components: ABS6 CONTROLLER (9538); BRAKE CONTROLLER (9511); CONNECTOR (1650); CONTROLLER X1 (4906); ENGINE (1701); FORWARD CHASSIS (1700)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.133. J1708 DATALINK COMPLETE W/ WTEC XMSN W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE (CONT.), P. 96A / CHAPTER 3 J1708 DATALINK COMPLETE W/WTEC XMSN W/BODY CONTROLLER W/2017-ISB-DIESEL ENG (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. J1708 PUBLIC (+) (1660) A / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090654 NO. RELEASE NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / # W/HYD BRAKE & W/WABCO AIR BRAKE * W/BENDIX AIR BRAKE / A3BA(-) 18GY A3AA(-) 18GY A3C(-) 18GY / 26 31 - + J1708 J1708 FULL POWER BRAKE CONTROLLER (9511) NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / J1708 + 5 / J1708 PUBLIC (-) (1661) / #M3C- 18DKBL 18GY #M3C+ / PLATFORM/ ENGINE (1701) / A3AA(+) 18DKBL / DIAGNOSTIC CONNECTOR (1650) / *M3C- 18GY *M3C+ 18DKBL / A3C(+) 18DKBL / PLATFORM/ FORWARD CHASSIS (1700) / A3BA(+) 18DKBL / J1708 - 1 / BENDIX AIR ABS6 CONTROLLER (9538) / WABCO AIR ABS CONTROLLER X1 (4906) / &M3C+ 18DKBL / J1708 + 4 / &M3C- 18GY / J1708 - 9 / Figure 170 / J1708 DATALINK COMPLETE W/ WTEC XMSN W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE (CONT.)

3.134. J1939 DATALINK COMPLETE W/ BODY CONTROLLER W/ 2017 ISB DIESEL
Figure 171 J1939 DATALINK COMPLETE W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE

Components: ADAPTER (1029); BODY CONTROLLER (1602); CONNECTOR (1650); DIAGNOSTIC CONNECTOR (1650); FUSE F9 (1011); GROUND STUD (4037A); J1939 ADAPTER (1029); RESISTOR (1657M); SELECTOR (1850)
Wires (circuit gauge+color): A11-GZ 8WH; A98-G 16WH
See also sheets: CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.134. J1939 DATALINK COMPLETE W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE, P. 96B / CHAPTER 3 J1939 DATA LINK COMPLETE W/BODY CONTROLLER W/2017-ISB-DIESEL ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5BK(-) A5BJ(+) 18GN 18YL / A5AH(-) A5AG(+) 18GN 18YL / A5MM(-) A5MN(+) 18GN 18YL A5BD(-) 18GN / A5BC(+) 18YL / STUD (4037A) GROUND / A98 18VT / A5BK(-) A5BJ(+) 18GN 18YL / J5-TAN BODY CONTROLLER (1602) LINK LINK - + J1939 J1939 DATA DATA F2 F3 / A5AF(-) A5AE(+) A11-GZ 18YL 18GN 8WH F9 CH3_94 (1011) FUSE / A5BA(+) 18YL / A5BB(-) 18GN / (-) J1939 15 / A OHMS 120 / J1939 ADAPTER (1029) A / A5MP(-) A5MR(+) 18GN 18YL / A5BC(+) 18YL / J1939 ADAPTER (1029) / DIAGNOSTIC CONNECTOR (1650) C / A5BD(-) 18GN / DATALINK COMPLETE W/LCT TRANSMISSION / A5AE(+) 18YL / A5AF(-) 18GN / (+) J1939 8 / TERMINATING RESISTOR (1657M) / A5AH(-) A5AG(+) 18GN 18YL / TERMINATING RESISTOR (1657M) / A98-G 16WH 18VT A98 / DATALINK COMPLETE W/WTEC TRANSMISSION / J5-TAN BODY CONTROLLER (1602) LINK LINK - + J1939 J1939 DATA DATA F2 F3 / A5BB(-) 18GN / A5BA(+) 18YL / A98-G 16WH / A OHMS 120 / DIAGNOSTIC CONNECTOR (1650) / SHIFT SELECTOR (1850) / GROUND STUD (4037A) / FUSE F9 (1011) CH3_94 / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / A11-GZ 8WH / Figure 171 / J1939 DATALINK COMPLETE W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE

3.135. J1939 DATALINK BASIC W/ LCT OR EATON XMSN W/ BODY CONTROLLER W/
Figure 172 J1939 DATALINK BASIC W/ LCT OR EATON XMSN W/ BODY CONTROLLER W/ 2017

Components: BODY CONTROLLER (1602); DIAGNOSTIC CONNECTOR (1650); ENGINE/PLATFORM (1701); INSTRUMENT CLUSTER (1505); TERMINATING RESISTOR (1657M)
See also sheets: CH3_86
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.135. J1939 DATALINK BASIC W/ LCT OR EATON XMSN W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE, P. 96C / CHAPTER 3 J1939 DATALINK BASIC W/LCT OR EATON XMSN W/BODY CONTROLLER W/2017-ISB-DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / INSTRUMENT CLUSTER (1505) (+) (-) CAN CAN 12 11 / J5-TAN BODY CONTROLLER (1602) LINK LINK - + J1939 J1939 DATA DATA F2 F3 / A5AL(+) A5AM(-) 18YL 18GN / DIAGNOSTIC CONNECTOR (1650) / A 120 OHMS / A5A(+) 18YL / A5A(-) 18GN / A5AH(-) A5AG(+) 18GN 18YL / A5BA(+) 18YL / ENGINE/PLATFORM (1701) CH3_86.87 / A5BC(+) 18YL / A5AE(+) A5AF(-) 18YL 18GN / A5BK(-) A5BJ(+) 18GN 18YL / TERMINATING RESISTOR (1657M) / A5BD(-) 18GN / A5BB(-) 18GN / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 172 / J1939 DATALINK BASIC W/ LCT OR EATON XMSN W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE

3.136. J1939 DATALINK BASIC W/ WTEC XMSN W/ BODY CONTROLLER W/ 2017 ISB
Figure 173 J1939 DATALINK BASIC W/ WTEC XMSN W/ BODY CONTROLLER W/ 2017 ISB DIESEL

Components: BODY CONTROLLER (1602); CONNECTOR (1650); ENGINE/PLATFORM (1701); INSTRUMENT CLUSTER (1505); RESISTOR (1657M); WTEC SHIFT SELECTOR (1850)
See also sheets: CH3_86
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.136. J1939 DATALINK BASIC W/ WTEC XMSN W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE, P. 96D / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / INSTRUMENT CLUSTER (1505) (+) (-) CAN CAN 12 11 / A5BK(-) A5BJ(+) 18GN 18YL / A5BD(-) 18GN / A5AE(+) 18YL / J5-TAN BODY CONTROLLER (1602) LINK LINK - + J1939 J1939 DATA DATA F2 F3 / A5A(+) 18YL / (+) J1939 8 / A5AH(-) A5AG(+) 18GN 18YL / (-) J1939 15 / DIAGNOSTIC CONNECTOR (1650) / A5A(-) 18GN / A5MM(-) A5MN(+) 18GN 18YL / A5BB(-) 18GN / A OHMS 120 / A5AF(-) 18GN / A5AL(+) A5AM(-) 18YL 18GN / WTEC SHIFT SELECTOR (1850) / A5BC(+) 18YL / ENGINE/PLATFORM (1701) CH3_86,87 / A5MP(-) A5MR(+) 18GN 18YL / TERMINATING RESISTOR (1657M) / A5BA(+) 18YL / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 173 / J1939 DATALINK BASIC W/ WTEC XMSN W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE

3.137. J1939 DATALINK BASIC W/ LCT OR EATON & W/ WTEC XMSN W/ BODY
Figure 174 J1939 DATALINK BASIC W/ LCT OR EATON & W/ WTEC XMSN W/ BODY CONTROLLER

Components: ABS6 CONTROLLER (9538); BRAKE CONTROLLER (9511); CONNECTOR (1650); CONTROLLER X1 (4906); FORWARD CHASSIS (1700); PLATFORM/ENGINE (1701)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.137. J1939 DATALINK BASIC W/ LCT OR EATON & W/ WTEC XMSN W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE, P. 96E / CHAPTER 3 J1939 DATALINK BASIC W/LCT OR EATON & W/WTEC XMSN W/BODY CONTROLLER W/2017-ISB-DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / *M3C+ 18DKBL *M3C- 18GY / DIAGNOSTIC CONNECTOR (1650) / 31 + J1939 / J1939 - G / PLATFORM/ENGINE (1701) 36 / * W/BENDIX AIR ABS6 & W/WABCO AIR ABS # W/HYD BRAKE / #M3C- #M3C+ 18DKBL 18GY / J1939 + 5 / PLATFORM/ FORWARD CHASSIS (1700) / A3A(-) 18GY / J1939 - 1 / 18DKBL A3(+) A3(-) 18GY / F J1939 + / A3B(-) A3B(-) 18GY 18GY / BENDIX AIR ABS6 CONTROLLER (9538) / 26 - J1939 / A3A(+) 18DKBL / A3B(+) 18DKBL / FULL POWER BRAKE CONTROLLER (9511) / WABCO AIR ABS CONTROLLER X1 (4906) / 9 J1939 - / 4 J1939 + / &M3C+ 18DKBL / &M3C- 18GY / A3(+) 18DKBL A3(-) 18GY / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 174 / J1939 DATALINK BASIC W/ LCT OR EATON & W/ WTEC XMSN W/ BODY CONTROLLER W/ 2017 ISB DIESEL ENGINE

3.138. J1939 DATALINK W/ 500K W/ 2017 ISB DIESEL ENGINE, P. 96F
Figure 175 J1939 DATALINK W/ 500K W/ 2017 ISB DIESEL ENGINE

Components: BODY CONTROLLER (1606); CONNECTOR X1 (9543); DATALINK (1350); ENGINE/PLATFORM (1701); FR CAP (10001); INTERFACE UNIT (9548); K BAUD (1651); PLATFORM/ELEC PANEL (1703); SHIFT SELECTOR (1850); TCM (7150)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.138. J1939 DATALINK W/ 500K W/ 2017 ISB DIESEL ENGINE, P. 96F / CHAPTER 3 J1939 DATALINK W/500K W/2017-ISB-DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5W(+) 18YL A5W(-) 18GN / @A5J(+) 20YL @A5J(-) 20GN / J1939 + 1 / J1939 - 6 / ZONAR V3 DATALINK (1350) / A5AC(+) 18YL A5AC(-) 18GN / A5F(+) 18YL A5F(-) 18GN / K5B(+) 18YL K5B(-) 18GN BENDIX AIR ABS-8 CONNECTOR X1 (9543) / PLATFORM/ELEC PANEL (1703) A14 A5P(-) B5A(-) 18GN 18GN A5P(+) B5A(+) 18YL 18YL / A5H(+) 18YL A5H(-) 18GN / J6-18 WAY BODY CONTROLLER (1606) / J1939 + H / A5AB(-) 18GN A5AB(+) 18YL / A5AA(-) 18GN A5AA(+) 18YL / A5M(-) 18GN A5M(+) 18YL / DRIVERS INTERFACE UNIT (9548) / A5R(+) 18YL A5R(-) 18GN / SHIFT SELECTOR (1850) / DIAGNOSTIC CONNECTOR 500K BAUD (1651) / ENGINE/PLATFORM (1701) 45 / J1939 + 8 / *A5K(-) 18GN / J1939 - 15 / *A5K(+) 18YL / A5L(-) 18GN / A5L(+) 18YL / J1939 + 7 / J1939 - 6 / @ W/LCT & FUSION & ZONAR # W/WTEC & BENDIX FUSION / GEN4 TCM (7150) CH3_96Y / J1939 - / J1939 + / J1939 - / J1939 - / J1939 + / ELEC PANEL/ FR CAP (10001) CH13_55A / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 175 / J1939 DATALINK W/ 500K W/ 2017 ISB DIESEL ENGINE

3.139. J1939 DATALINK W/ 500K W/ LCT XMSN OR E-PRO W/ 2017 ISB DIESEL
Figure 176 J1939 DATALINK W/ 500K W/ LCT XMSN OR E-PRO W/ 2017 ISB DIESEL ENGINE

Components: BODY CONTROLLER (1606); CONNECTOR (6021); ENGINE/PLATFORM (1701); K BAUD (1651); PLATFORM/FWD CHASSIS (1700); WINGMAN (8903)
See also sheets: CH13_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.139. J1939 DATALINK W/ 500K W/ LCT XMSN OR E-PRO W/ 2017 ISB DIESEL ENGINE, P. 96G / CHAPTER 3 J1939 DATALINK W/500K W/LCT XMSN OR E-PRO W/2017-ISB-DIESEL-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5V(-) 18GN A5V(+) 18YL / A5M(-) 18GN A5M(+) 18YL / C J1939 + / D J1939 - / DIAGNOSTIC CONNECTOR 500K BAUD (1651) / K5B(+) 18YL K5B(-) 18GN / ENGINE/PLATFORM (1701) 45 / J6-18 WAY BODY CONTROLLER (1606) / A5H(+) 18YL A5H(-) 18GN / A5U(+) 18YL A5U(-) 18GN / PLATFORM/FWD CHASSIS (1700) 30 / BENDIX WINGMAN (8903) CH13_32 / M5A(+) 18YL M5A(-) 18GN / A5R(+) 18YL A5R(-) 18GN / VEHICLE INTERFACE CONNECTOR (6021) CH3_96Y / K5G(+) 18YL K5G(-) 18GN / VEHICLE INTERFACE CONNECTOR (6021) CH3_96Z / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 176 / J1939 DATALINK W/ 500K W/ LCT XMSN OR E-PRO W/ 2017 ISB DIESEL ENGINE

3.140. J1939 DATALINK W/ 500K W/ LCT XMSN OR E-PRO & W/ ZONAR W/ 2017 ISB
Figure 177 J1939 DATALINK W/ 500K W/ LCT XMSN OR E-PRO & W/ ZONAR W/ 2017 ISB DIESEL

Components: BODY CONTROLLER (1606); DATALINK (1350); ECM CONN (6021); ENGINE/PLATFORM (1701); K BAUD (1651); PLATFORM/FWD CHASSIS (1700); WINGMAN (8903)
See also sheets: CH13_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.140. J1939 DATALINK W/ 500K W/ LCT XMSN OR E-PRO & W/ ZONAR W/ 2017 ISB DIESEL ENGINE, P. 96H / CHAPTER 3 J1939 DATALINK W/500K W/LCT XMSN OR E-PRO & W/ZONAR W/2017-ISB-DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5W(+) 18YL A5W(-) 18GN / A5J(+) 20YL A5J(-) 20GN / ZONAR V3 DATALINK (1350) 1 J1939 + / J1939 - 6 / A5H(+) 18YL A5H(-) 18GN / J6-18WAY BODY CONTROLLER (1606) H J1939 + / G J1939 - / A5Y(-) 18GN A5Y(+) 18YL / A5M(+) 18YL / C J1939 + / DIAGNOSTIC CONNECTOR 500K BAUD (1651) D J1939 - / A5M(-) 18GN / PLATFORM/FWD CHASSIS (1700) / 31 31 / 30 30 / A5U(-) 18GN A5U(+) 18YL / BENDIX WINGMAN (8903) CH13_32 / M5A(-) 18GN M5A(+) 18YL / A5R(-) 18GN / A5R(+) 18YL / ENGINE/PLATFORM (1701) 45 / K5B(+) 18YL / ECM CONN (6021) CH3_96Y / K5B(-) 18GN / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / K5G(-) 18GN / K5G(+) 18YL / ECM CONN (6021) CH3_96Z / Figure 177 / J1939 DATALINK W/ 500K W/ LCT XMSN OR E-PRO & W/ ZONAR W/ 2017 ISB DIESEL ENGINE

3.141. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX WINGMAN W/ 2017 ISB
Figure 178 J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX WINGMAN W/ 2017 ISB DIESEL

Components: BODY CONTROLLER (1606); CONNECTOR X1 (9543); ECM CONN (6021); ENGINE/PLATFORM (1701); FWD CHASSIS/PLATFORM (1700); INTERFACE UNIT (9548); K BAUD (1651); WINGMAN (8903)
See also sheets: CH13_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.141. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX WINGMAN W/ 2017 ISB DIESEL ENGINE, P. 96J / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / BENDIX AIR ABS-8 CONNECTOR X1 (9543) / A5H(+) 18YL A5H(-) 18GN / J6-18WAY BODY CONTROLLER (1606) / FWD CHASSIS/PLATFORM (1700) 30 / A5AD(-) 18GN A5AD(+) 18YL / A5L(-) 18GN A5L(+) 18YL / DRIVERS INTERFACE UNIT (9548) / A5AA(+) 18YL / A5AA(-) 18GN / A5M(+) 18YL A5M(-) 18GN / K5B(+) 18YL K5G(-) 18GN K5G(+) 18YL DIAGNOSTIC CONNECTOR 500K BAUD (1651) / A5AC(-) 18GN A5AC(+) 18YL / A5F(-) 18GN A5F(+) 18YL / A5S(+) 18YL / A5S(-) 18GN / A5R(+) 18YL / A5R(-) 18GN / ENGINE/PLATFORM (1701) 46 / K5B(-) 18GN / ECM CONN (6021) CH3_96Y / J1939 + / J1939 - / M5A(+) 18YL / M5A(-) 18GN / BENDIX WINGMAN (8903) CH13_32 / J1939 + / J1939 - / J1939 - / J1939 + / J1939 - / J1939 + / ECM CONN (6021) CH3_96Z / Figure 178 / J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX WINGMAN W/ 2017 ISB DIESEL ENGINE

3.142. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX WINGMAN & ZONAR W/
Figure 179 J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX WINGMAN & ZONAR W/ 2017 ISB

Components: BODY CONTROLLER (1606); CONNECTOR X1 (9543); DATALINK (1350); ECM CONN (6021); ENGINE/PLATFORM (1701); FWD CHASSIS/PLATFORM (1700); INTERFACE UNIT (9548); K BAUD (1651); WINGMAN (8903)
See also sheets: CH13_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.142. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX WINGMAN & ZONAR W/ 2017 ISB DIESEL ENGINE, P. 96K / CHAPTER 3 J1939 DATALINK W/500K W/LCT XMSN W/BENDIX WINGMAN & ZONAR W/2017-ISB-DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5W(+) 18YL A5W(-) 18GN / A5J(+) 20YL A5J(-) 20GN / J1939 + 1 / J1939 - 6 / ZONAR V3 DATALINK (1350) / BENDIX AIR ABS-8 CONNECTOR X1 (9543) / A5H(+) 18YL A5H(-) 18GN / J6-18WAY BODY CONTROLLER (1606) / FWD CHASSIS/PLATFORM (1700) 30 / A5AB(-) 18GN A5AB(+) 18YL / A5L(-) 18GN A5L(+) 18YL / DRIVERS INTERFACE UNIT (9548) / A5AA(+) 18YL / A5AA(-) 18GN / A5M(+) 18YL A5M(-) 18GN / K5B(+) 18YL K5G(-) 18GN K5G(+) 18YL DIAGNOSTIC CONNECTOR 500K BAUD (1651) / A5AC(-) 18GN A5AC(+) 18YL / A5F(-) 18GN A5F(+) 18YL / A5S(+) 18YL / A5S(-) 18GN / A5R(+) 18YL / A5R(-) 18GN / ENGINE/PLATFORM (1701) 46 / K5B(-) 18GN / ECM CONN (6021) CH3_96Y / J1939 + / J1939 - / M5A(+) 18YL / M5A(-) 18GN / J1939 + / J1939 - / J1939 - / J1939 + / J1939 - / J1939 + / BENDIX WINGMAN (8903) CH13_32 / ECM CONN (6021) CH3_96Z / Figure 179 / J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX WINGMAN & ZONAR W/ 2017 ISB DIESEL ENGINE

3.143. J1939 DATALINK W/ 500K W/ LCT XMSN & ABS-8 W/ 2017 ISB DIESEL ENGINE, P. 96L
Figure 180 J1939 DATALINK W/ 500K W/ LCT XMSN & ABS-8 W/ 2017 ISB DIESEL ENGINE

Components: BODY CONTROLLER (1606); CONNECTOR X1 (9543); ECM CONN (6021); ENGINE/PLATFORM (1701); K BAUD (1651); PLATFORM/FWD CHASSIS (1700); WINGMAN (8903)
See also sheets: CH13_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.143. J1939 DATALINK W/ 500K W/ LCT XMSN & ABS-8 W/ 2017 ISB DIESEL ENGINE, P. 96L / CHAPTER 3 J1939 DATALINK W/500K W/LCT XMSN & ABS-8 W/2017-ISB-DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30MAR21 / MJV0488 10JUN21 INITIAL PRODUCTION RELEASE. / PLATFORM/FWD CHASSIS (1700) 30 / DIAGNOSTIC CONNECTOR 500K BAUD (1651) D J1939 - / A5V(-) 18GN A5V(+) 18YL / J6-18WAY BODY CONTROLLER (1606) H J1939 + / A5H(+) 18YL A5H(-) 18GN / C J1939 + / A5S(+) 18YL A5S(-) 18GN / A5M(-) 18GN A5M(+) 18YL / A5AC(-) 18GN / A5AC(+) 18YL / A5F(+) 18YL / A5F(-) 18GN / BENDIX AIR ABS-8 CONNECTOR X1 (9543) / M5A(-) 18GN / M5A(+) 18YL / BENDIX WINGMAN (8903) CH13_32 / J1939 - / J1939 + / J1939 - / ENGINE/PLATFORM (1701) 45 K5B(+) 18YL / K5B(-) 18GN / ECM CONN (6021) CH3_96Y / A5R(+) 18YL / A5R(-) 18GN / ECM CONN (6021) CH3_96Z / K5G(+) 18YL / K5G(-) 18GN / Figure 180 / J1939 DATALINK W/ 500K W/ LCT XMSN & ABS-8 W/ 2017 ISB DIESEL ENGINE

3.144. J1939 DATALINK W/ 500K W/ LCT XMSN & ABS-8 & ZONAR W/ 2017 ISB
Figure 181 J1939 DATALINK W/ 500K W/ LCT XMSN & ABS-8 & ZONAR W/ 2017 ISB DIESEL ENGINE

Components: BODY CONTROLLER (1606); CONNECTOR X1 (9543); DATALINK (1350); ECM CONN (6021); ENGINE/PLATFORM (1701); K BAUD (1651); PLATFORM/FWD CHASSIS (1700); WINGMAN (8903)
See also sheets: CH13_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.144. J1939 DATALINK W/ 500K W/ LCT XMSN & ABS-8 & ZONAR W/ 2017 ISB DIESEL ENGINE, P. 96M / CHAPTER 3 J1939 DATALINK W/500K W/LCT XMSN & ABS-8 & ZONAR W/2017-ISB-DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PLATFORM/FWD CHASSIS (1700) 30 / DIAGNOSTIC CONNECTOR 500K BAUD (1651) D J1939 - / A5Y(-) 18GN A5Y(+) 18YL / J1939 - 6 / A5J(+) 20YL A5J(-) 20GN / J6-18WAY BODY CONTROLLER (1606) H J1939 + / A5H(+) 18YL A5H(-) 18GN / C J1939 + / J1939 + 1 / A5W(+) 18YL A5W(-) 18GN / A5S(+) 18YL A5S(-) 18GN / A5M(-) 18GN A5M(+) 18YL / ZONAR V3 DATALINK (1350) / A5AC(-) 18GN / A5AC(+) 18YL / A5F(+) 18YL / A5F(-) 18GN / BENDIX AIR ABS-8 CONNECTOR X1 (9543) / M5A(-) 18GN / M5A(+) 18YL / J1939 - / J1939 + / J1939 - / ENGINE/PLATFORM (1701) 45 K5B(+) 18YL / K5B(-) 18GN K5G(+) 18YL K5G(-) 18GN / ECM CONN (6021) CH3_96Y / A5R(+) 18YL / A5R(-) 18GN / BENDIX WINGMAN (8903) CH13_32 / ECM CONN (6021) CH3_96Z / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 181 / J1939 DATALINK W/ 500K W/ LCT XMSN & ABS-8 & ZONAR W/ 2017 ISB DIESEL ENGINE

3.145. J1939 DATALINK W/ 500K W/ LCT XMSN & BENDIX FUSION W/ 2017 ISB
Figure 182 J1939 DATALINK W/ 500K W/ LCT XMSN & BENDIX FUSION W/ 2017 ISB DIESEL ENGINE

Components: BODY CONTROLLER (1606); CONNECTOR X1 (9543); ECM CONN (6021); FR CAP (10001); INTERFACE UNIT (9548); K BAUD (1651); PLATFORM (1701); PLATFORM/ELEC PANEL (1703)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.145. J1939 DATALINK W/ 500K W/ LCT XMSN & BENDIX FUSION W/ 2017 ISB DIESEL ENGINE, P. 96N / CHAPTER 3 J1939 DATALINK W/500K W/LCT XMSN & BENDIX FUSION W/2017-ISB-DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5AC(+) 18YL A5AC(-) 18GN / A5F(+) 18YL A5F(-) 18GN / K5G(+) 18YL K5G(-) 18GN K5B(+) 18YL K5B(-) 18GN BENDIX AIR ABS-8 CONNECTOR X1 (9543) / PLATFORM/ELEC PANEL (1703) A14 A5P(-) B5A(-) 18GN 18GN A5P(+) B5A(+) 18YL 18YL / A5H(+) 18YL A5H(-) 18GN / J6-18 WAY BODY CONTROLLER (1606) / J1939 + H / A5Z(-) 18GN A5Z(+) 18YL / A5AA(-) 18GN A5AA(+) 18YL / A5M(-) 18GN A5M(+) 18YL / DRIVERS INTERFACE UNIT (9548) / ENGINE/ PLATFORM (1701) 45 A5R(+) 18YL A5R(-) 18GN / DIAGNOSTIC CONNECTOR 500K BAUD (1651) / A5L(-) 18GN / A5L(+) 18YL / J1939 + 7 / J1939 - 6 / @ W/LCT & FUSION & ZONAR # W/WTEC & BENDIX FUSION / ECM CONN (6021) CH3_96Y / J1939 - / J1939 + / J1939 - / J1939 - / J1939 + / ELEC PANEL/ FR CAP (10001) CH13_55A / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / ECM CONN (6021) CH3_96Z / Figure 182 / J1939 DATALINK W/ 500K W/ LCT XMSN & BENDIX FUSION W/ 2017 ISB DIESEL ENGINE

3.146. J1939 DATALINK W/ 500K W/ WTEC XMSN W/ BENDIX WINGMAN W/ 2017 ISB
Figure 183 J1939 DATALINK W/ 500K W/ WTEC XMSN W/ BENDIX WINGMAN W/ 2017 ISB DIESEL

Components: BODY CONTROLLER (1606); CONNECTOR X1 (9543); ECM CONN (6021); ENGINE/PLATFORM (1701); INTERFACE UNIT (9548); K BAUD (1651); PLATFORM/FWD CHASSIS (1700); SHIFT SELECTOR (1850); WINGMAN (8903)
See also sheets: CH13_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.146. J1939 DATALINK W/ 500K W/ WTEC XMSN W/ BENDIX WINGMAN W/ 2017 ISB DIESEL ENGINE, P. 96P / CHAPTER 3 J1939 DATALINK W/500K W/WTEC XMSN W/BENDIX WINGMAN W/2017-ISB-DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5AC(+) 18YL A5AC(-) 18GN / A5F(+) 18YL A5F(-) 18GN / BENDIX AIR ABS-8 CONNECTOR X1 (9543) / A5H(+) 18YL A5H(-) 18GN / J6-18WAY BODY CONTROLLER (1606) / J1939 - G / J1939 + H / A5K(+) 18YL A5Z(-) 18GN A5Z(+) 18YL / A5AB(-) 18GN A5AB(+) 18YL / A5L(-) 18GN A5L(+) 18YL / DRIVERS INTERFACE UNIT (9548) / A5K(-) 18GN / 8 J1939 + / J1939 - 15 / SHIFT SELECTOR (1850) / A5AA(+) 18YL / A5AA(-) 18GN / A5M(+) 18YL A5M(-) 18GN / K5B(+) 18YL K5G(-) ECM CONN 18GN (6021) K5G(+) CH3_96Z 18YL DIAGNOSTIC CONNECTOR 500K BAUD (1651) / A5R(+) 18YL / A5R(-) 18GN / ENGINE/PLATFORM (1701) 46 / K5B(-) 18GN / ECM CONN (6021) CH3_96Y / A5S(-) 18GN A5S(+) 18YL / PLATFORM/FWD CHASSIS (1700) 31 / M5A(-) 18GN M5A(+) 18YL / BENDIX WINGMAN (8903) CH13_32 / J1939 + / J1939 - / J1939 - / J1939 + / J1939 + / J1939 - / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 183 / J1939 DATALINK W/ 500K W/ WTEC XMSN W/ BENDIX WINGMAN W/ 2017 ISB DIESEL ENGINE

3.147. J1939 DATALINK W/ 500K W/ WTEC XMSN W/ BENDIX WINGMAN & ZONAR W/
Figure 184 J1939 DATALINK W/ 500K W/ WTEC XMSN W/ BENDIX WINGMAN & ZONAR W/ 2017

Components: CONNECTOR X1 (9543); CONTROLLER (1606); DATALINK (1350); ECM CONN (6021); ENGINE/PLATFORM (1701); INTERFACE UNIT (9548); K BAUD (1651); PLATFORM/FWD CHASSIS (1700); SELECTOR (1850); WINGMAN (8903)
See also sheets: CH13_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.147. J1939 DATALINK W/ 500K W/ WTEC XMSN W/ BENDIX WINGMAN & ZONAR W/ 2017 ISB DIESEL ENGINE, P. 96Q / CHAPTER 3 J1939 DATALINK W/500K W/WTEC XMSN W/BENDIX WINGMAN & ZONAR W/2017-ISB-DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5W(+) 18YL A5W(-) 18GN / A5J(+) 20YL A5J(-) 20GN / J1939 + 1 / 6 J1939 - / ZONAR V3 DATALINK (1350) / A5AC(+) 18YL A5AC(-) 18GN / A5F(+) 18YL A5F(-) 18GN / 8 J1939 + / 7 J1939 - / BENDIX AIR ABS-8 CONNECTOR X1 (9543) / A5S(-) 18GN A5S(+) 18YL / A5H(+) 18YL A5H(-) 18GN / J6-18WAY BODY CONTROLLER (1606) / J1939 + H / PLATFORM/FWD CHASSIS (1700) 31 M5A(-) 18GN M5A(+) 18YL / A5AB(-) 18GN A5AB(+) 18YL / A5AN(-) 18GN A5AN(+) 18YL / A5L(-) 18GN A5L(+) 18YL / DRIVERS INTERFACE UNIT (9548) / J1939 + 7 / 6 J1939 - / A5K(-) 18GN / A5K(+) 18YL / J1939 + 8 / J1939 - 15 / SHIFT SELECTOR (1850) / A5AJ(+) 18YL / A5AJ(-) 18GN / A5M(+) 18YL A5M(-) 18GN / K5B(-) 18GN K5B(+) 18YL K5G(-) 18GN K5G(+) 18YL DIAGNOSTIC CONNECTOR 500K BAUD (1651) / J1939 - D / J1939 + C / A5R(-) 18GN A5R(+) 18YL / ENGINE/PLATFORM (1701) 46 / ECM CONN (6021) CH3_96Y / J1939 - / BENDIX WINGMAN (8903) CH13_32 / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / ECM CONN (6021) CH3_96Z / Figure 184 / J1939 DATALINK W/ 500K W/ WTEC XMSN W/ BENDIX WINGMAN & ZONAR W/ 2017 ISB DIESEL ENGINE

3.148. J1939 DATALINK W/ 500K W/ WTEC XMSN & ABS-8 W/ 2017-ISB-DIESEL
Figure 185 J1939 DATALINK W/ 500K W/ WTEC XMSN & ABS-8 W/ 2017-ISB-DIESEL ENGINE

Components: BODY CONTROLLER (1606); CONNECTOR X1 (9543); ECM CONN (6021); ENGINE/PLATFORM (1701); K BAUD (1651); PLATFORM/FWD CHASSIS (1700); SHIFT SELECTOR (1850); WINGMAN (8903)
See also sheets: CH13_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.148. J1939 DATALINK W/ 500K W/ WTEC XMSN & ABS-8 W/ 2017-ISB-DIESEL ENGINE, P. 96R / CHAPTER 3 J1939 DATALINK W/500K W/WTEC XMSN & ABS-8 W/2017-ISB-DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5AC(+) 18YL A5AC(-) 18GN / A5F(+) 18YL A5F(-) 18GN / 8 J1939 + / 7 J1939 - / BENDIX AIR ABS-8 CONNECTOR X1 (9543) / A5S(-) 18GN A5S(+) 18YL / A5H(+) 18YL A5H(-) 18GN / J6-18WAY BODY CONTROLLER (1606) / J1939 - G / J1939 + H / PLATFORM/FWD CHASSIS (1700) 31 / A5Z(-) 18YL A5Z(+) 18YL / A5AA(-) 18GN A5AA(+) 18YL / A5K(-) 18GN / A5K(+) 18YL / J1939 + 8 / J1939 - 15 / SHIFT SELECTOR (1850) / A5M(-) 18GN A5M(+) 18YL / DIAGNOSTIC CONNECTOR 500K BAUD (1651) / J1939 - D / C J1939 + / A5R(+) 18YL / A5R(-) 18GN / ENGINE/PLATFORM (1701) 45 / K5B(+) 18YL / K5B(-) 18GN K5G(+) 18YL K5G(-) 18GN / ECM CONN (6021) CH3_96Y / M5A(-) 18GN M5A(+) 18YL / BENDIX WINGMAN (8903) CH13_32 / ECM CONN (6021) CH3_96Z / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 185 / J1939 DATALINK W/ 500K W/ WTEC XMSN & ABS-8 W/ 2017-ISB-DIESEL ENGINE

3.149. J1939 DATALINK W/ 500K W/ WTEC XMSN & ABS-8 & ZONAR W/
Figure 186 J1939 DATALINK W/ 500K W/ WTEC XMSN & ABS-8 & ZONAR W/ 2017-ISB-DIESEL ENGINE

Components: BODY CONTROLLER (1606); CONNECTOR X1 (9543); DATALINK (1350); ECM CONN (6021); K BAUD (1651); PLATFORM (1701); PLATFORM/FWD CHASSIS (1700); SHIFT SELECTOR (1850); WINGMAN (8903)
See also sheets: CH13_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.149. J1939 DATALINK W/ 500K W/ WTEC XMSN & ABS-8 & ZONAR W/ 2017-ISB-DIESEL ENGINE, P. 96S / CHAPTER 3 J1939 DATALINK W/500K W/WTEC XMSN & ABS-8 & ZONAR W/2017-ISB-DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5W(+) 18YL A5W(-) 18GN / A5J(+) 20YL A5J(-) 20GN / ZONAR V3 DATALINK (1350) / A5AC(+) 18YL A5AC(-) 18GN / A5F(+) 18YL A5F(-) 18GN / BENDIX AIR ABS-8 CONNECTOR X1 (9543) / PLATFORM/FWD CHASSIS (1700) 31 A5S(-) M5A(-) 18GN 18GN A5S(+) M5A(+) 18YL 18YL / A5H(+) 18YL A5H(-) 18GN / J6-18WAY BODY CONTROLLER (1606) / A5AB(-) 18GN A5AB(+) 18YL / A5AA(-) 18GN A5AA(+) 18YL / A5M(-) 18GN A5M(+) 18YL / SHIFT SELECTOR (1850) / DIAGNOSTIC CONNECTOR 500K BAUD (1651) / A5K(-) 18GN / A5K(+) 18YL / J1939 - 15 / ENGINE/ PLATFORM (1701) 45 A5R(+) 18YL A5R(-) 18GN / ECM CONN (6021) CH3_96Y / K5G(+) 18YL K5G(-) 18GN K5B(+) 18YL K5B(-) 18GN / J1939 + / BENDIX WINGMAN (8903) CH13_32 / J1939 - / J1939 - / J1939 - / J1939 - / J1939 + / J1939 + / J1939 + / J1939 + / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / ECM CONN (6021) CH3_96Z / Figure 186 / J1939 DATALINK W/ 500K W/ WTEC XMSN & ABS-8 & ZONAR W/ 2017-ISB-DIESEL ENGINE

3.150. J1939 DATALINK W/ 500K W/ WTEC XMSN W/ 2017-ISB-DIESEL ENGINE, P. 96U
Figure 187 J1939 DATALINK W/ 500K W/ WTEC XMSN W/ 2017-ISB-DIESEL ENGINE

Components: BODY CONTROLLER (1606); ECM CONN (6021); ENGINE/PLATFORM (1701); K BAUD (1651); PLATFORM/FWD CHASSIS (1700); SHIFT SELECTOR (1850); WINGMAN (8903)
See also sheets: CH13_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.150. J1939 DATALINK W/ 500K W/ WTEC XMSN W/ 2017-ISB-DIESEL ENGINE, P. 96U / CHAPTER 3 J1939 DATALINK W/500K W/WTEC XMSN W/2017-ISB-DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5Z(+) 18YL A5Z(-) 18GN / A5H(+) 18YL A5H(-) 18GN / J1939 - 15 / A5M(-) 18GN A5M(+) 18YL / A5K(+) 18YL A5K(-) 18GN / A5AA(-) 18GN A5AA(+) 18YL / J1939 + 8 / G J1939 - / DIAGNOSTIC CONNECTOR 500K BAUD (1651) / J6-18WAY BODY CONTROLLER (1606) / SHIFT SELECTOR (1850) / A5U(-) 18GN A5U(+) 18YL / PLATFORM/FWD CHASSIS (1700) / 30 30 / BENDIX WINGMAN (8903) CH13_32 / 31 31 / M5A(-) 18GN M5A(+) 18YL / J1939 - / J1939 + / J1939 + / ENGINE/PLATFORM (1701) 45 / A5R(+) 18YL / A5R(-) 18GN / ECM CONN (6021) CH3_96Y / K5B(+) 18YL / K5B(-) 18GN K5G(+) 18YL K5G(-) 18GN / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / ECM CONN (6021) CH3_96Z / Figure 187 / J1939 DATALINK W/ 500K W/ WTEC XMSN W/ 2017-ISB-DIESEL ENGINE

3.151. J1939 DATALINK W/ 500K W/ WTEC XMSN & W/ ZONAR W/ 2017-ISB-DIESEL
Figure 188 J1939 DATALINK W/ 500K W/ WTEC XMSN & W/ ZONAR W/ 2017-ISB-DIESEL ENGINE

Components: BODY CONTROLLER (1606); DATALINK (1350); ECM CONN (6021); ENGINE/PLATFORM (1701); K BAUD (1651); PLATFORM/FWD CHASSIS (1700); SHIFT SELECTOR (1850); WINGMAN (8903)
See also sheets: CH13_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.151. J1939 DATALINK W/ 500K W/ WTEC XMSN & W/ ZONAR W/ 2017-ISB-DIESEL ENGINE, P. 96V / CHAPTER 3 J1939 DATALINK W/500K W/WTEC XMSN & W/ZONAR W/2017-ISB-DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5W(+) 18YL A5W(-) 18GN / A5J(+) 20YL A5J(-) 20GN / J1939 + 1 / J1939 - 6 / ZONAR V3 DATALINK (1350) / A5U(-) 18GN A5U(+) 18YL / A5H(+) 18YL A5H(-) 18GN / J6-18WAY BODY CONTROLLER (1606) / PLATFORM/FWD CHASSIS (1700) 31 / A5AB(-) 18GN A5AB(+) 18YL / A5AA(-) 18GN A5AA(+) 18YL / A5M(-) 18GN A5M(+) 18YL / J1939 - D / SHIFT SELECTOR (1850) / DIAGNOSTIC CONNECTOR 500K BAUD (1651) / A5K(-) 18GN / A5K(+) 18YL / J1939 + 8 / 15 J1939 - / M5A(-) 18GN M5A(+) 18YL / BENDIX WINGMAN (8903) CH13_32 / ENGINE/PLATFORM (1701) 45 / A5R(+) 18YL A5R(-) 18GN / ECM CONN (6021) CH3_96Y / K5B(+) 18YL K5B(-) 18GN K5G(+) 18YL K5G(-) 18GN / J1939 + / J1939 - / J1939 + / ECM CONN (6021) CH3_96Z / Figure 188 / J1939 DATALINK W/ 500K W/ WTEC XMSN & W/ ZONAR W/ 2017-ISB-DIESEL ENGINE

3.152. J1939 DATALINK W/ 500K W/ WTEC XMSN FUSION & ZONAR W/
Figure 189 J1939 DATALINK W/ 500K W/ WTEC XMSN FUSION & ZONAR W/ 2017-ISB-DIESEL ENGINE

Components: BODY CONTROLLER (1606); CONNECTOR X1 (9543); DATALINK (1350); ECM CONN (6021); FR CAP (10001); INTERFACE UNIT (9548); K BAUD (1651); PLATFORM (1701); PLATFORM/ELEC PANEL (1703); SHIFT SELECTOR (1850)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.152. J1939 DATALINK W/ 500K W/ WTEC XMSN FUSION & ZONAR W/ 2017-ISB-DIESEL ENGINE, P. 96W / CHAPTER 3 J1939 DATALINK W/500K W/WTEC XMSN FUSION & ZONAR W/2017-ISB-DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5W(+) 18YL A5W(-) 18GN / A5J(+) 20YL A5J(-) 20GN / J1939 + 1 / J1939 - 6 / ZONAR V3 DATALINK (1350) / A5AC(+) 18YL A5AC(-) 18GN / A5F(+) 18YL A5F(-) 18GN / K5G(+) 18YL K5G(-) 18GN K5B(+) 18YL K5B(-) 18GN BENDIX AIR ABS-8 CONNECTOR X1 (9543) / PLATFORM/ELEC PANEL (1703) A14 A5P(-) B5A(-) 18GN 18GN A5P(+) B5A(+) 18YL 18YL / A5H(+) 18YL A5H(-) 18GN / J6-18 WAY BODY CONTROLLER (1606) / J1939 + H / A5AB(-) 18GN A5AB(+) 18YL / A5M(-) 18GN A5M(+) 18YL / DRIVERS INTERFACE UNIT (9548) / A5R(+) 18YL A5R(-) 18GN / DIAGNOSTIC CONNECTOR 500K BAUD (1651) / ENGINE/ PLATFORM (1701) 45 / A5L(-) 18GN / A5L(+) 18YL / J1939 + 7 / J1939 - 6 / J1939 - / J1939 + / J1939 - / J1939 - / J1939 + / ELEC PANEL/ FR CAP (10001) CH13_55A / SHIFT SELECTOR (1850) / J1939 + 8 / J1939 - 15 / A5K(-) 18GN / A5K(+) 18YL / A5AN(-) 18GN A5AN(+) 18YL / A5AJ(-) A5AJ(+) 18GN 18YL / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / ECM CONN (6021) CH3_96Y / ECM CONN (6021) CH3_96Z / Figure 189 / J1939 DATALINK W/ 500K W/ WTEC XMSN FUSION & ZONAR W/ 2017-ISB-DIESEL ENGINE

3.153. J1939 DATALINK W/ 500K W/ ALLISON XMSN W/ 2017-ISB-DIESEL ENGINE, P. 96Y
Figure 190 J1939 DATALINK W/ 500K W/ ALLISON XMSN W/ 2017-ISB-DIESEL ENGINE

Components: CLUSTER (1505); ECM CONN (6021); GEN4 TCM (7150); K BAUD (1651); PLATFORM (1701/1701); RESISTOR (7803)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.153. J1939 DATALINK W/ 500K W/ ALLISON XMSN W/ 2017-ISB-DIESEL ENGINE, P. 96Y / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / OHMS 120 A / K5(+) K5(-) 18YL 18GN / J1939 TERMINATING RESISTOR (7803) / K5E(+) K5E(-) 18YL 18GN / K5B(+) K5B(-) 18YL 18GN / K5C(-) 20GN / ENGINE/ PLATFORM (1701/1701) / J1939 + 6 / J1939 - 27 / GEN4 TCM (7150) / K5#106 18YL K5#127 18GN / K5C(+) 20YL / 22 J1939 + / J1939 - 46 / ECM CONN (6021) / A5R(+) A5R(-) 18YL 18GN / DIAGNOSTIC CONN INSTRUMENT 500K BAUD CLUSTER (1651) (1505) CH3_96F,96G,96H,96J, CH3_97A 96K,96L,96M,96N,96P, 96Q,96R,96S,96U,96V,96W / A5A(-) 18GN / A5A(+) 18YL / Figure 190 / J1939 DATALINK W/ 500K W/ ALLISON XMSN W/ 2017-ISB-DIESEL ENGINE

3.154. J1939 DATALINK W/ 500K W/ EATON PROCISION XMSN W/ 2017-ISB-DIESEL
Figure 191 J1939 DATALINK W/ 500K W/ EATON PROCISION XMSN W/ 2017-ISB-DIESEL ENGINE

Components: CONNECTOR (6021); ENGINE/PLATFORM (1701/1701); K BAUD (1651); RESISTOR (7803); VEHICLE UPPER (7105)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.154. J1939 DATALINK W/ 500K W/ EATON PROCISION XMSN W/ 2017-ISB-DIESEL ENGINE, P. 96Z / CHAPTER 3 J1939 DATALINK W/500K W/EATON PROCISION XMSN W/2017-ISB-DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 29MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / OHMS 120 A / K5B(+) K5B(-) 18YL 18GN / J1939 TERMINATING RESISTOR (7803) / K5C(+) K5C(-) 18YL 18GN / K5G(+) K5G(-) 18YL 18GN / K5D(+) 20YL K5D(-) 20GN / J1939+ 11 12 J1939- / EPS VEHICLE UPPER (7105) / K5A(+) 18YL K5A(-) 18GN / ECM CONNECTOR (6021) J1939+ 22 / J1939- 46 / ENGINE/PLATFORM (1701/1701) / 45 46 A5R(+) A5R(-) 18YL 18GN / DIAGNOSTIC CONN 500K BAUD (1651) CH3_96G,96H,96J,96K, 96L,96M,96N,96P,96Q, 96R,96S,96U,96V,96W / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 191 / J1939 DATALINK W/ 500K W/ EATON PROCISION XMSN W/ 2017-ISB-DIESEL ENGINE

3.155. J1939 DATALINK W/ 500K W/ ENHANCED VCM FEATURES W/ 2017-ISB-DIESEL ENGINE, P. 97
Figure 192 J1939 DATALINK W/ 500K W/ ENHANCED VCM FEATURES W/ 2017-ISB-DIESEL ENGINE

Components: CLUSTER (1505); CONNECTOR (1651); CONTROLLER (1602); PAM MODULE (4087); PLATFORM/ENG (1701/1701); RESISTOR (1657M); RESISTOR (7801M)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.155. J1939 DATALINK W/ 500K W/ ENHANCED VCM FEATURES W/ 2017-ISB-DIESEL ENGINE, P. 97 / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J5-TAN BODY CONTROLLER (1602) / A5BN(-) 18GN / A5BM(+) 18YL / A5B(+) 18YL / A5B(-) 18GN / PLATFORM/ENG (1701/1701) / A5BA(+) 18YL / A5BB(-) 18GN / F2 J1939 - / F3 J1939 + / %K5A(+) 20YL / %K5A(-) 20GN / @K5A(-) 20GN / @K5A(+) 20YL / A5BP(+) 18YL / A5BR(-) 18GN / A5BT(-) 18GN A5BS(+) 18YL / J1939 + 12 / J1939 - 11 / INSTRUMENT CLUSTER (1505) / J1939 TERMINATING RESISTOR (1657M) C / OHMS 120 / A5BC(+) A5BD(-) 18YL 18GN / H + J1939 / J - J1939 / DIAGNOSTIC CONNECTOR (1651) / A5BE(+) 18YL / A5BF(-) 18GN / @ N/PAN TERMINATING RESISTOR % W/PAM J1939 (250K) / J1939 TERMINATING RESISTOR (7801M) CH5_10A / PAM MODULE (4087) CH5_10A / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 192 / J1939 DATALINK W/ 500K W/ ENHANCED VCM FEATURES W/ 2017-ISB-DIESEL ENGINE

3.156. J1939 DATALINK W/ 250K W/ LCT XMSN W/ 2017-ISB-DIESEL &
Figure 193 J1939 DATALINK W/ 250K W/ LCT XMSN W/ 2017-ISB-DIESEL & F-2018-PROPANE /

Components: CLUSTER (1505); CONN (9538); CONNECTOR (1650); CONNECTOR (6021); CONTROLLER (1602); ECM CONN (6021); ENG (1701); FUSE F9 (1011); J1939 SPLICE (1029A); PLATFORM (1700); RESISTER (7801M); STUD (4037A)
Wires (circuit gauge+color): A11-GZ 8WH; A98-G 16WH; M3CA 18GY; M3CB 18GY
See also sheets: CH13_42, CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.156. J1939 DATALINK W/ 250K W/ LCT XMSN W/ 2017-ISB-DIESEL & F-2018-PROPANE / GAS-ENGINE, P. 97A / CHAPTER 3 J1939 DATALINK W/250K W/LCT XMSN W/2017-ISB- DIESEL & F-2018-PROPANE/GASOLINE ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / (-) CAN 11 / BODY CONTROLLER (1602) / A5AL(+) A5AL(-) 18YL 18GN / DIAGNOSTIC CONNECTOR (1650) D CAN (-) C CAN (+) F / (+) CAN 12 / (-) CAN F2 / A5AH(-) A5AH(+) 18GN 18YL J1939 SPLICE (1029A) H A5TS(+) 20YL A5TS(-) 20GN A5BC(-) 18GN A5BC(+) 18YL A5B(-) 18GN / INSTRUMENT CLUSTER (1505) / A5BJ(-) A5BJ(+) 18GN 18YL / (+) CAN F3 / @A5AG(+) 18YL %A5E(+) 18YL A5BD(+) 18YL A5BD(-) 18GN / A5BA(-) 18GN A5BA(+) 18YL / PLATFORM/ 45 45 ENG (1701) / #K5A(+) #K5A(-) 18YL 18GN / VEHICLE INTERFACE ECM CONN CONNECTOR (6021) (6021) CH3_96Y CH3_97D,97C / A5A(+) A5A(-) 18YL 18GN / A5B(+) 18YL / M C D J / FWD CHASSIS/ PLATFORM (1700) 31 / @A5AG(-) 18GN / %A5E(-) 18GN / M5E(-) 18GN M5E(+) 18YL / BENDIX AIR ABS-6 CONN (9538) CH13_42 GROUND STUD (4037A) FUSE F9 (1011) CH3_94 / (+) CAN 1 / (-) CAN 6 / ZONAR V3 DATALINK #(1350) / M3CA 18GY M3CB 18GY A11-GZ 8WH / J1939 TERMINATING RESISTER (7801M) CH13_49A / (+) CAN 8 / (-) CAN 15 / SHIFT SELECTOR &(1850) / &K5B(+) 18YL / &K5B(-) 18GN / Figure 193 / J1939 DATALINK W/ 250K W/ LCT XMSN W/ 2017-ISB-DIESEL & F-2018-PROPANE / GAS-ENGINE

3.157. J1939 DATALINK W/ 250K W/ LCT XMSN W/ F-2018-PROPANE / GAS-ENGINE, P. 97B
Figure 194 J1939 DATALINK W/ 250K W/ LCT XMSN W/ F-2018-PROPANE / GAS-ENGINE

Components: BODY CONTROLLER (1602); CONN (1651); INSTRUMENT CLUSTER (1505); PLATFORM (1701); RESISTER (1657M); RESISTER (7801M)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.157. J1939 DATALINK W/ 250K W/ LCT XMSN W/ F-2018-PROPANE / GAS-ENGINE, P. 97B / CHAPTER 3 J1939 DATALINK W/250K W/LCT XMSN W/F-2018-PROP/GAS-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5AL(+) A5AL(-) 18YL 18GN / A5BC(-) 18GN / J1939 TERMINATING RESISTER (7801M) CH3_97C,97D / ENGINE/ PLATFORM 72 (1701) / A5A(+) A5A(-) 18YL 18GN / A5BA(-) 18GN / K5A(+) K5A(-) 20YL 20GN / A5BA(+) 18YL / A5BC(+) 18YL / INSTRUMENT CLUSTER (1505) + - J1939 J1939 / J1939 TERMINATING RESISTER (1657M) / 120 OHMS / A5BJ(-) A5BJ(+) 18GN 18YL / J5-TAN BODY CONTROLLER (1602) - + J1939 J1939 / A5AD(-) A5AD(+) 18GN 18YL / DIAGNOSTIC CONN (1651) - + J1939 J1939 / A5AG(-) A5AG(+) 18YL 18YL / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 194 / J1939 DATALINK W/ 250K W/ LCT XMSN W/ F-2018-PROPANE / GAS-ENGINE

3.158. J1939 DATALINK W/ 250K W/ LCT XMSN W/ F-2018-PROPANE-ENGINE, P. 97C
Figure 195 J1939 DATALINK W/ 250K W/ LCT XMSN W/ F-2018-PROPANE-ENGINE

Components: CLUSTER (1505); CONNECTOR (6021); GEN 5 TCM (7150); K BAUD (1651); PLATFORM (1701); RESISTER (7801M); RESISTER (7803)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.158. J1939 DATALINK W/ 250K W/ LCT XMSN W/ F-2018-PROPANE-ENGINE, P. 97C / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30MAR21 / CHAPTER 3 J1939 DATALINK W/250K W/LCT XMSN W/F-2018-PROP-ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ENGINE/ PLATFORM 46 (1701) / A5A(-) A5A(+) 18GN 18YL / VEHICLE INTERFACE CONNECTOR (6021) - + J1939 J1939 C12 C11 / K5B(-) K5B(+) 18GN 18YL / K5D(+) 18YL / K5D(-) 18GN / GEN 5 TCM (7150) / K5A(-) K5A(+) 18GN 18YL / @K5#108 18GN / @K5#128 18YL / J1939 + 28 / INSTUMENT CLUSTER (1505) CH3_97A / J1939 TERMINATING RESISTER (7803) B / K5E(-) 18GN / K5E(+) 18YL / 120 OHMS / J1939 - / W/AIR AND HYDRAULIC BRAKE / #K5#106 18YL / #K5#127 18GN / 27 J1939 - / J1939 + / J1939 TERMINATING RESISTER (7801M) A / OHMS 120 / K5A(+) 20YL / K5A(-) 20GN / A5A(+) A5A(-) 18YL 18GN / INSTUMENT CLUSTER (1505) CH3_97B / @ N/ENHANCED VCM FUNTION # W/ENHANCED VCM FUCTION / A5R(-) A5R(+) 18GN 18YL / DIAGNOSTIC CONNECTOR BAUD (1651) CH3_97E,97F,97G, 97H,97J,97K,97L,97M 500K NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 195 / J1939 DATALINK W/ 250K W/ LCT XMSN W/ F-2018-PROPANE-ENGINE

3.159. J1939 DATALINK W/ 250K W/ LCT XMSN W/ F-2018-GAS-ENGINE, P. 97D
Figure 196 J1939 DATALINK W/ 250K W/ LCT XMSN W/ F-2018-GAS-ENGINE

Components: CLUSTER (1505); CONNECTOR (6021); ENGINE (1701); GEN 5 TCM (7150); K BAUD (1651); RESISTER (7801M); RESISTER (7803)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.159. J1939 DATALINK W/ 250K W/ LCT XMSN W/ F-2018-GAS-ENGINE, P. 97D / CHAPTER 3 J1939 DATALINK W/250K W/LCT XMSN W/F-2018-GAS-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 95885P 30MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PLATFORM/ ENGINE (1701) / A5A(+) A5A(-) A5A(+) A5A(-) 18YL 18YL 18GN 18GN / K5A(+) K5A(-) 18YL 18GN / K5D(+) K5D(-) 18YL 18GN / K5E(+) K5E(-) 18YL 18GN / C12 J1939 - / 27 J1939 - / C11 J1939 + / VEHICLE INTERFACE CONNECTOR (6021) / GEN 5 TCM (7150) / J1939 TERMINATING RESISTER (7803) / K5#106 18YL K5#127 18GN / K5B(+) 18YL K5B(-) 18GN / 120 OHMS / J1939 + / OHMS 120 / J1939 TERMINATING RESISTER (7801M) B / K5A(-) 20GN / K5A(+) 20YL / INSTRUMENT CLUSTER CH3_97A (1505) / A5R(+) A5R(-) 18YL 18GN / 97H,97J,97K,97L,97M CH3_97E,97F,97G, DIAGNOSTIC CONNECTOR BAUD (1651) 500K / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / INSTRUMENT CLUSTER CH3_97B (1505) / Figure 196 / J1939 DATALINK W/ 250K W/ LCT XMSN W/ F-2018-GAS-ENGINE

3.160. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX FUSION W/
Figure 197 J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX FUSION W/ F-2018-PROPANE /

Components: BODY CONTROLLER (1606); CONNECTOR (6021); CONNECTOR X1 (9543); FR CAP (10001); FWD CHASSIS/PLATFORM (1700); INTERFACE UNIT (9548); K BUAD (1651); PLATFORM/ENGINE (1701); WINGMAN (8903)
See also sheets: CH13_50
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.160. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX FUSION W/ F-2018-PROPANE / GAS-ENGINE, P. 97E / CHAPTER 3 J1939 DATALINK W/500K W/LCT XMSN W/BENDIX FUSION W/F-2018-PROP/GAS-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5Z(+) 18YL A5Z(-) 18GN / A5L(+) 18YL A5L(-) 18GN / J1939 + 7 / J1939 - 6 / DRIVERS INTERFACE UNIT (9548) / A5AC(+) 18YL A5AC(-) 18GN / A5F(+) 18YL A5F(-) 18GN / 8 J1939 + / 7 J1939 - / BENDIX AIR ABS-8 CONNECTOR X1 (9543) / A5H(+) 18YL A5H(-) 18GN / J6-18WAY BODY CONTROLLER (1606) J1939 + H / G J1939 - / A5AA(-) 18GN A5AA(+) 18YL / A5M(-) 18GN A5M(+) 18YL / DIAGNOSTIC CONNECTOR 500K BUAD (1651) D J1939 - / C J1939 + / PLATFORM/ENGINE (1701) 46 A5R(+) K5A(+) 18YL 18YL A5R(-) K5A(-) 18GN 18GN / B5A(-) 18GN B5A(+) 18YL / A5P(+) A5P(-) PLATFORM/ 18YL 18GN ELEC PANEL (1703/*1703C/ %1703) A14 / ELEC PANEL/ FR CAP (10001) CH13_55A / *A5AK(+) *A5AK(-) 18LTGN 18YL / FWD CHASSIS/PLATFORM (1700) 31 M5A(+) 18YL / A5N(-) 18GN / M5A(-) 18GN / BENDIX WINGMAN (8903) CH13_50 / A5N(+) 18YL / VEHICLE INTERFACE CONNECTOR (6021) CH3_97C,97D / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / B5(+) 18YL / B5(-) 18GN / ELEC PANEL/ FR CAP (10001) CH13_55A / Figure 197 / J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX FUSION W/ F-2018-PROPANE / GAS-ENGINE

3.161. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX FUSION & ZONAR W/
Figure 198 J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX FUSION & ZONAR W/

Components: CONNECTOR (6021); CONNECTOR X1 (9543); CONTROLLER (1606); DATALINK (1350); FR CAP (10001); FWD CHASSIS/PLATFORM (1700); K BUAD (1651); PLATFORM/ENG (1701); UNIT (9548); WINGMAN (8903)
See also sheets: CH13_50
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.161. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX FUSION & ZONAR W/ F-2018-PROPANE / GAS-ENGINE, P. 97F / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30MAR21 / MJV0488 10JUN21 INITIAL PRODUCTION RELEASE. / A5L(+) 18YL A5L(-) 18GN A5AB(-) A5AB(+) 18GN 18YL / J1939 + 7 / J1939 - 6 / DRIVERS INTERFACE UNIT (9548) / A5AC(-) 18GN A5AC(+) 18YL / A5F(-) 18GN A5F(+) 18YL / J1939 + 8 / 7 J1939 - / BENDIX AIR ABS-8 CONNECTOR X1 (9543) / A5H(-) 18GN A5H(+) 18YL / J6-18 WAY BODY CONTROLLER (1606) J1939 - G / J1939 + H / A5AA(-) 18GN A5AA(+) 18YL / A5M(-) 18GN A5M(+) 18YL / DIAGNOSTIC CONNECTOR 500K BUAD (1651) / C J1939 + / D J1939 - / PLATFORM/ENG (1701) 46 A5R(+) K5A(+) 18YL 18YL A5R(-) K5A(-) 18GN 18GN / B5A(-) 18GN B5A(+) 18YL / A5P(+) A5P(-) PLATFORM/ 18YL 18GN ELEC PANEL (1703/*1703C/ %1703) A14 / ELEC PANEL/ FR CAP (10001) CH13_55A / *A5AK(+) *A5AK(-) 18LTGN 18YL / FWD CHASSIS/PLATFORM (1700) 31 M5A(+) 18YL / A5N(-) 18GN / M5A(-) 18GN / BENDIX WINGMAN (8903) CH13_50 / A5N(+) 18YL / VEHICLE INTERFACE CONNECTOR (6021) CH3_97C,97D / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / B5(+) 18YL / B5(-) 18GN / ELEC PANEL/ FR CAP (10001) CH13_55A / A5J(-) 20GN A5J(+) 20YL / ZONAR V3 DATALINK (1350) J1939 - 6 / J1939 + 1 / A5W(-) 18GN A5W(+) 18YL / Figure 198 / J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX FUSION & ZONAR W/ F-2018-PROPANE / GAS-ENGINE

3.162. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX WINGMAN W/
Figure 199 J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX WINGMAN W/ F-2018-PROPANE /

Components: BODY CONTROLLER (1606); CONNECTOR (6021); CONNECTOR X1 (9543); FWD CHASSIS/PLATFORM (1700); K BUAD (1651); PLATFORM/ENG (1701); UNIT (9548); WINGMAN (8903)
See also sheets: CH13_50
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.162. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX WINGMAN W/ F-2018-PROPANE / GAS-ENGINE, P. 97G / CHAPTER 3 J1939 DATALINK W/500K W/LCT XMSN W/BENDIX WINGMAN W/F-2018-PROPANE/GASOLINE ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5L(+) 18YL A5L(-) 18GN / A5AD(+) 18YL A5AD(-) 18GN / J1939 + 7 / J1939 - 6 / DRIVERS INTERFACE UNIT (9548) / A5AC(+) 18YL A5AC(-) 18GN / A5F(+) 18YL A5F(-) 18GN / J1939 + 8 / 7 J1939 - / BENDIX AIR ABS-8 CONNECTOR X1 (9543) / A5H(+) 18YL A5H(-) 18GN / J6-18WAY BODY CONTROLLER (1606) J1939 + H / J1939 - G / A5AA(-) 18GN A5AA(+) 18YL / A5M(-) 18GN A5M(+) 18YL / DIAGNOSTIC CONNECTOR 500K BUAD (1651) D J1939 - / C J1939 + / PLATFORM/ENG (1701) 45 A5R(+) 18YL A5R(-) 18GN / K5A(+) 18YL K5A(-) 18GN / A5S(+) 18YL / FWD CHASSIS/PLATFORM (1700) 30 M5A(+) 18YL / A5S(-) 18GN / BENDIX WINGMAN (8903) CH13_50 / M5A(-) 18GN / VEHICLE INTERFACE CONNECTOR (6021) CH3_97C,97D / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 199 / J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX WINGMAN W/ F-2018-PROPANE / GAS-ENGINE

3.163. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX WINGMAN & ZONAR W/
Figure 200 J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX WINGMAN & ZONAR W/

Components: BODY CONTROLLER (1606); CONNECTOR (6021); CONNECTOR X1 (9543); DATALINK (1350); ENGINE/PLATFORM (1701); FWD CHASSIS/PLATFORM (1700); INTERFACE UNIT (9548); K BAUD (1651); WINGMAN (8903)
See also sheets: CH13_50
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.163. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX WINGMAN & ZONAR W/ F-2018-PROPANE / GAS-ENGINE, P. 97H / CHAPTER 3 J1939 DATALINK W/500K W/LCT XMSN W/BENDIX WINGMAN & ZONAR W/F-2018-PROP/GAS-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5W(+) 18YL A5W(-) 18GN / A5J(+) 20YL A5J(-) 20GN / J1939 + 1 / J1939 - 6 / ZONAR V3 DATALINK (1350) / BENDIX AIR ABS-8 CONNECTOR X1 (9543) / A5H(+) 18YL A5H(-) 18GN / J6-18WAY BODY CONTROLLER (1606) / FWD CHASSIS/PLATFORM (1700) 30 / A5AB(-) 18GN A5AB(+) 18YL / A5L(-) 18GN A5L(+) 18YL / DRIVERS INTERFACE UNIT (9548) / A5AA(+) 18YL / A5AA(-) 18GN / A5M(+) 18YL A5M(-) 18GN / DIAGNOSTIC CONNECTOR 500K BAUD (1651) / A5AC(-) 18GN A5AC(+) 18YL / A5F(-) 18GN A5F(+) 18YL / A5S(+) 18YL / A5S(-) 18GN / A5R(+) 18YL / A5R(-) 18GN / ENGINE/PLATFORM (1701) 46 / K5A(+) 18YL / K5A(-) 18GN / J1939 + / J1939 - / M5A(+) 18YL / M5A(-) 18GN / BENDIX WINGMAN (8903) CH13_50 / J1939 + / J1939 - / J1939 - / J1939 + / J1939 - / J1939 + / VEHICLE INTERFACE CONNECTOR (6021) CH3_97C,97D / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 200 / J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX WINGMAN & ZONAR W/ F-2018-PROPANE / GAS-ENGINE

3.164. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX ABS-8 W/ F-2018-PROPANE
Figure 201 J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX ABS-8 W/ F-2018-PROPANE /

Components: BODY CONTROLLER (1606); CONNECTOR (6021); CONNECTOR X1 (9543); ENGINE/PLATFORM (1701); K BAUD (1651); PLATFORM/FWD CHASSIS (1700); WINGMAN (8903)
See also sheets: CH13_50
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.164. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX ABS-8 W/ F-2018-PROPANE / GAS-ENGINE, P. 97J / CHAPTER 3 J1939 DATALINK W/500K W/LCT XMSN W/BENDIX ABS-8 W/F-2018-PROP/GAS-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30MAR21 / MJV0488 10JUN21 INITIAL PRODUCTION RELEASE. / A5V(+) 18YL A5V(-) 18GN / A5AC(+) 18YL A5AC(-) 18GN / A5F(+) 18YL A5F(-) 18GN / BENDIX AIR ABS-8 CONNECTOR X1 (9543) / PLATFORM/FWD CHASSIS (1700) 31 A5S(-) M5A(-) 18GN 18GN A5S(+) M5A(+) 18YL 18YL / A5H(+) 18YL A5H(-) 18GN / J6-18WAY BODY CONTROLLER (1606) / A5M(-) 18GN A5M(+) 18YL / C J1939 + / DIAGNOSTIC CONNECTOR 500K BAUD (1651) / A5R(+) 18YL A5R(-) 18GN / ENGINE/PLATFORM (1701) 45 / VEHICLE INTERFACE CONNECTOR (6021) CH3_97C,97D / K5A(+) 18YL K5A(-) 18GN / BENDIX WINGMAN (8903) CH13_50 / J1939 - / J1939 - / J1939 - / J1939 + / J1939 + / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 201 / J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX ABS-8 W/ F-2018-PROPANE / GAS-ENGINE

3.165. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX ABS-8 & ZONAR W/
Figure 202 J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX ABS-8 & ZONAR W/ F-2018-PROPANE

Components: BODY CONTROLLER (1606); CONNECTOR (6021); CONNECTOR X1 (9543); DATA LINK (1350); ENGINE/PLATFORM (1701); FWD CHASSIS/PLATFORM (1700); K BAUD (1651); WINGMAN (8903)
See also sheets: CH13_50
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.165. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX ABS-8 & ZONAR W/ F-2018-PROPANE / GAS-ENGINE, P. 97K / CHAPTER 3 J1939 DATALINK W/500K W/LCT XMSN W/BENDIX ABS-8 & ZONAR W/F-2018-PROP/GAS-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30MAR21 / MJV0488 10JUN21 INITIAL PRODUCTION RELEASE. / A5W(+) 18YL A5W(-) 18GN / A5J(+) 20YL A5J(-) 20GN / J1939 + 1 / J1939 - 6 / ZONAR V3 DATA LINK (1350) / BENDIX AIR ABS-8 CONNECTOR X1 (9543) / A5H(+) 18YL A5H(-) 18GN / J6-18WAY BODY CONTROLLER (1606) / FWD CHASSIS/PLATFORM (1700) 30 / A5Y(-) 18GN A5Y(+) 18YL / A5M(-) 18GN A5M(+) 18YL / DIAGNOSTIC 500K BAUD (1651) / A5AC(-) 18GN A5AC(+) 18YL / A5F(-) 18GN A5F(+) 18YL / A5S(+) 18YL / A5S(-) 18GN / A5R(+) 18YL / A5R(-) 18GN / ENGINE/PLATFORM (1701) 46 / K5A(+) 18YL / K5A(-) 18GN / M5A(+) 18YL / M5A(-) 18GN / BENDIX WINGMAN (8903) CH13_50 / J1939 + / J1939 - / J1939 - / J1939 + / J1939 - / J1939 + / VEHICLE INTERFACE CONNECTOR (6021) CH3_97C,97D / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 202 / J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX ABS-8 & ZONAR W/ F-2018-PROPANE / GAS-ENGINE

3.166. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX ABS-6 W/ F-2018-PROPANE
Figure 203 J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX ABS-6 W/ F-2018-PROPANE /

Components: BODY CONTROLLER (1606); CONNECTOR (6021); ENGINE/PLATFORM (1701); K BAUD (1651); PLATFORM/FWD CHASSIS (1700); WINGMAN (8903)
See also sheets: CH13_50
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.166. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX ABS-6 W/ F-2018-PROPANE / GAS-ENGINE, P. 97L / CHAPTER 3 J1939 DATALINK W/500K W/LCT XMSN W/BENDIX ABS-6 W/F-2018-PROP/GAS-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5V(+) 18YL A5V(-) 18GN / A5H(+) 18YL A5H(-) 18GN / J6-18WAY BODY CONTROLLER (1606) H J1939 + / G J1939 - / A5M(+) 18YL / C J1939 + / DIAGNOSTIC CONNECTOR 500K BAUD (1651) D J1939 - / A5M(-) 18GN / PLATFORM/FWD CHASSIS (1700) / 31 31 / 30 30 / A5U(-) 18GN A5U(+) 18YL / BENDIX WINGMAN (8903) CH13_50 / M5A(-) 18GN M5A(+) 18YL / A5R(-) 18GN / A5R(+) 18YL / ENGINE/PLATFORM (1701) 45 K5A(+) 18YL / VEHICLE INTERFACE CONNECTOR (6021) CH3_97C,97D / K5A(-) 18GN / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 203 / J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX ABS-6 W/ F-2018-PROPANE / GAS-ENGINE

3.167. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX ABS-6 & ZONAR W/
Figure 204 J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX ABS-6 & ZONAR W/ F-2018-PROPANE

Components: BODY CONTROLLER (1606); CONNECTOR (6021); DATA LINK (1350); FWD CHASSIS/PLATFORM (1700); K BAUD (1651); PLATFORM/ENGINE (1701); WINGMAN (8903)
See also sheets: CH13_50
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.167. J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX ABS-6 & ZONAR W/ F-2018-PROPANE / GAS-ENGINE, P. 97M / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090654 NO. 95885P 30MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5Y(+) 18YL A5Y(-) 18GN / A5J(+) 18YL A5J(-) 18GN / J1939 + 1 / J1939 - 6 / ZONAR V3 DATA LINK (1350) / A5M(+) 18YL A5M(-) 18GN / D J1939 - / C J1939 + / A5W(-) 18GN A5W(+) 18YL / A5H(+) 18YL / H J1939 + / J6-18 WAY BODY CONTROLLER (1606) G J1939 - / A5H(-) 18GN / PLATFORM/ENGINE (1701) 46 K5A(-) 18GN K5A(+) 18YL / A5R(-) 18GN A5R(+) 18YL / VEHICLE INTERFACE CONNECTOR (6021) CH3_97C,97D / A5U(-) 18GN / A5U(+) 18YL / FWD CHASSIS/PLATFORM (1700) 30 / M5A(+) 18YL / BENDIX WINGMAN (8903) CH13_50 / M5A(-) 18GN / DIAGNOSTIC CONNECTOR 500K BAUD (1651) / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 204 / J1939 DATALINK W/ 500K W/ LCT XMSN W/ BENDIX ABS-6 & ZONAR W/ F-2018-PROPANE / GAS-ENGINE

3.168. 500K ISB DATALINK BASIC W/ 0508095 AND W/ INTELLIPARK, P. 97N
Figure 205 500K ISB DATALINK BASIC W/ 0508095 AND W/ INTELLIPARK

Components: CLUSTER (1505); CONNECTOR (1651); CONTROLLER (1602); ENGINE (1701); RESISTOR (1657M); RESISTOR (7801M)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.168. 500K ISB DATALINK BASIC W/ 0508095 AND W/ INTELLIPARK, P. 97N / CHAPTER 3 500K ISB DATALINK BASIC W/0508095 AND W/INTELLIPARK / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 96289K 07OCT21 / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / INSTRUMENT CLUSTER (1505) + J1939 12 / 120 OHMS / BODY CONTROLLER (1602) + - J1939 J1939 F3 F2 A5BM(+) A5BT(-) 18YL 18GN A5BP(+) 18YL / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / - J1939 11 / A5BS(+) 18YL / A5BY(+) 18YL / A5BJ(-) 18GN / A5B(+) 18YL / A5B(-) 18GN / PLATFORM/ ENGINE (1701) / K5C(+) 20YL / K5C(-) 20GN / TERMINATING RESISTOR (7801M) / A5BN(-) 18GN / A5BR(-) 18GN / A5BG(+) 18YL / A5BK(-) 18GN / A5CB 18YL / A5C(-) 18GN / A5BC(+) 18YL A5BE(+) 18YL / DIAGNOSTIC CONNECTOR (1651) + - J1939 J1939 J H / A5BD(-) 18GN / A5BA(+) 18YL / A5BF(-) 18GN A5BB(-) 18GN / 120 OHMS / J1939 TERMINATING RESISTOR (1657M) / Figure 205 / 500K ISB DATALINK BASIC W/ 0508095 AND W/ INTELLIPARK

3.169. J1939 DATA LINK W/ INTELLIPARK WIRING W/ F-2017-ISB-ENGINE, P. 97P
Figure 206 J1939 DATA LINK W/ INTELLIPARK WIRING W/ F-2017-ISB-ENGINE

Components: CLUSTER (1505); CONNECTOR (1826); CONNECTOR (1827); CONNECTOR (1829); CONTROLLER (1602); K BAUD (1651); PLATFORM/ENG (1701); RESISTOR (1657M); RESISTOR (7801M)
See also sheets: CH13_69
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 3.169. J1939 DATA LINK W/ INTELLIPARK WIRING W/ F-2017-ISB-ENGINE, P. 97P / CHAPTER 3 J1939 DATA LINK W/INTELLIPARK WIRING W/F-2017-ISB-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090654 96289K 11OCT21 / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / DIAGNOSTIC CONN 500K BAUD (1651) + - J1939 J1939 H J / A5BC(+) 18YL / A5BD(-) 18GN / A5BA(+) 18YL / A5BB(-) 18GN / 120 OHMS / J1939 TERMINATING RESISTOR (1657M) NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / 11 J1939 - / 12 J1939 + / PLATFORM/ENG (1701) A5B(-) 18GN A5B(+) 18YL / 13 J1939(-) / 15 J1939(+) / DECU J1 CONNECTOR (1826) / A5BY(+) A5BJ(-) 18YL 18GN / A5BT(-) 18GN A5BS(+) 18YL / A5BH(+) 18YL A5BL(-) 18GN / B5CC(+) B5CA(-) 18YL 18GN / A5BP(+) A5BR(-) 18YL 18GN / K5F(-) 20GN K5F(+) 20YL / J1939 TERMINATING RESISTOR (7801M) B / 120 OHMS / A5BW(-) 18GN A5BZ(+) 18YL / PHMI DISPLAY CONNECTOR (1829) CH13_69 / INSTRUMENT CLUSTER (1505) / F3 J1939 + / J5-TAN BODY CONTROLLER (1602) F2 J1939 - / A5BN(-) 18GN A5BM(+) 18YL / A5BG(+) A5BK(-) 18YL 18GN / DECU J2 CONNECTOR (1827) CH13_69 / A5CB(+) 18YL A5C(-) 18GN / A5BE(+) 18YL A5BF(-) 18GN / Figure 206 / J1939 DATA LINK W/ INTELLIPARK WIRING W/ F-2017-ISB-ENGINE

Figure 207 CHARGING AND CRANKING - W/ ENHANCED VCM FUNCTION W/ 2017 ISB / 2021 B6.7

Components: BODY CONTROLLER (1606); FUSE A6-H (1014); GND (6311); INTERRUPT (1008M/1008F); KEY SWITCH (1100); MAG SW (6306); PLATFORM/ENGINE (1701/1701); RELAY (1010-R2); RELAY (10313-R2); SPLICE PACK (1004); STARTER INTERRUPT (1008M/F); SWITCH RELAY (4009)
Wires (circuit gauge+color): A149A 18GY; A15 16RD; A17 16PK; A17B 16PK; A17C 18LTGN; A17CA 18LTGN; A17CB 18BK; A17CC 18WH; B17 18LTGN; B17B 18LTGN; K17B 16PK; K17B 18GY; K17BA 16PK; K2-GB 1WH; K2B 1RD; K2BA-FL 6TN
See also sheets: CH12_15, CH15_25, CH3_02, CH3_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / CHARGING AND CRANKING SYSTEM (CHAPTER 4) / 4.1. CHARGING AND CRANKING - W/ ENHANCED VCM FUNCTION W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 1 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090655 NO. RELEASE NO. 95885P 18DEC20 / CHAPTER 4 CHARGING AND CRANKING - W/ENHANCED VCM FUNCTION W/2017/2021 ISB/B6.7 DIESEL ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ALTERNATOR ALTERNATOR POWER STARTER/ R %(6108/6105) ALTERNATOR *(6110) GROUND %(6107) *(6109) / K2B 1RD / K2-GB 1WH / KEY SWITCH (1100) BATT BATT / FRAME GROUND / OFF OFF IGN C / S S / PLATFORM/ENGINE (1701/1701) 26 &K17B 18GY &K17BA 16PK *K17B 16PK / STARTER POWER %(6313) B S / K2BA-FL 6TN / FUSE A6-H (1014) CH3_02 / STARTER INTERRUPT (1008M/1008F) A A17B A17B 16PK 16PK / A15 16RD / STARTER MAG SW (6306) / * W/BCM 4 GEN ALLISION W/2021 & W/BCM 4 GEN EATON W/2021 NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. % W/1 GAUGE CHARGE / J6-18 WAY BODY CONTROLLER (1606) / A149A 18GY A17 16PK A92#141 18GY / A17CB 18BK / A17CC 18WH / GROUND SPLICE PACK (1004) CH3_31 / S T / 18LTGN A17C / THERMAL OVERCRANK PROTECTION RELAY (1010-R2) / TCM NEUTRAL SWITCH RELAY (4009) CH12_15 / B17 18LTGN STARTER INTERRUPT (1008M/F) 87A A / B17B 18LTGN / STARTER GND (6311) / A17CA 18LTGN / STARTER INTERLOCK RELAY (10313-R2) CH15_25 / Figure 207 / CHARGING AND CRANKING - W/ ENHANCED VCM FUNCTION W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE

4.2. CHARGING AND CRANKING - W/ F-2018-PROPANE-ENGINE, P. 2
Figure 208 CHARGING AND CRANKING - W/ F-2018-PROPANE-ENGINE

Components: BODY CONTROLLER (1601); CONTROLLER (1606); ECM CONTROL RELAY (4116); ENGINE/PLATFORM (1701/1701); FUSE A3-K (1016); FUSE A6-H (1014); FUSE STUD (4000B); GEN 5 TCM (7150); INTERFACE CONN (6021); INTERRUPT (1008M/F); KEY POWER (4104); KEY SWITCH (1100); PLATFORM/ENGINE (1701/1701); RELAY (4003); RELAY (4101); STARTER ALT FUEL RELAY (1015-R1); STARTER FUSE (4106); STARTER INTERLOCK RELAY (10313-R2); STARTER INTERRUPT (1008F/M); SWITCH (4009)
Wires (circuit gauge+color): A15 16RD; A17B 16PK; A17BC 16PK; A17L 16PK; A97RB 18TN; B17 18LTGN; K10-GA 18WH; K10-GB 18WH; K10-GC 10WH; K17B 12PK; K17B 14PK; K17BZ 12RD; K17RA 18RD; K17RC 14RD; K17RD 16RD; K17RD2 14RD; K17SA 12RD; K17SB 12RD; K17SC 12RD; K17SE 18RD; K17UA 18PK; K17UB 14PK; K17UC 14PK; K17UE 14PK; K17UF 18PK; K17UG 12PK; K17UH 12PK
See also sheets: CH15_25, CH3_02, CH3_05, CH3_62, CH4_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 4.2. CHARGING AND CRANKING - W/ F-2018-PROPANE-ENGINE, P. 2 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090655 95885P 18DEC20 / CHAPTER 4 CHARGING AND CRANKING - W/F-2018-PROP-ENG / - MJV0488 - 19NOV21 ADDED CIRC K17UH IN R/D 6021. / GEN 5 TCM (7150) NEUTRAL 41 START / S B / OFF IGN D C / 16RD A15 / STARTER INTERRUPT (1008M/F) A / KEY SWITCH (1100) / STARTER INTERRUPT (1008F/M) A B17 18LTGN PLATFORM/ENGINE (1701/1701) 19 A17B K17B 16PK 14PK K17BZ 12RD K17B 12PK / TCM NEUTRAL SWITCH (4009) / K92#141 18GY / (1014) CH3_02 A6-H FUSE / K10-GC 10WH / UPPER GROUND STUD (3G) CH3_62 / SWITCHED CRANK RELAY (4101) / K17SB 12RD / STARTER FUSE (4106) / B A / UPPER MEGA FUSE STUD (4000B) / K17SA 12RD / K17UE 14PK / KEY POWER (4104) / K17UC 14PK / K17RD2 14RD 1 30 / K17UB 14PK ENGINE/PLATFORM (1701/1701) 21 / K17UA 18PK / K97RB 18VT ECM CONTROL RELAY (4116) NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / A97UA 18VT / FUSE A3-K (1016) CH3_05 J4-TAN BLUE BODY CONTROLLER (1601) HYD BRK E8 / E1 AIR ABS / VEHICLE BODY INTERFACE CONN (6021) / K17UG 12PK / K17UF 18PK / START RELAY (4003) / K10-GA 18WH / A97RB 18TN A97RB 18TN / A17BC 16PK / J6-18 WAY BODY CONTROLLER (1606) / 2 86 / 87A 3 / 85 5 / K17RD 16RD / K17RA 18RD / K17RC 14RD / 85 5 / K17SC 12RD 2 86 / 87A 3 / 1 30 / 2 86 / 1 30 / 85 5 / 87A 3 / 85 5 K17SE 18RD / 2 86 / 87A 3 / 1 30 / K10-GB 18WH / A17L 16PK / STARTER ALT FUEL RELAY (1015-R1) CH4_03 / STARTER INTERLOCK RELAY (10313-R2) CH15_25 / K17UH 12PK / Figure 208 / CHARGING AND CRANKING - W/ F-2018-PROPANE-ENGINE

4.3. CHARGING AND CRANKING - W/ F-2018-PROPANE-ENGINE (CONT.), P. 3
Figure 209 CHARGING AND CRANKING - W/ F-2018-PROPANE-ENGINE (CONT.)

Components: BODY CONTROLLER (1606); ENGINE (1701); FEED (1027); FUEL RELAY (1015_R1); FUSE A2-F9 (1017)
Wires (circuit gauge+color): A10-GA 18WH; A17A 12RD; A17BZ 12RD; A17DG 10RD; A17SE 18RD
See also sheets: CH4_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 4.3. CHARGING AND CRANKING - W/ F-2018-PROPANE-ENGINE (CONT.), P. 3 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090655 NO. 95885P 18DEC20 / CHAPTER 4 CHARGING AND CRANKING - W/F-2018-PROP-ENG (CONT.) / - MJV0488 - 09JUN21 INITIAL PRODUCTION RELEASE. / J6-18 WAY BODY CONTROLLER (1606) / STARTER ALT FUEL RELAY (1015_R1) / A17A 12RD / FUSE A2-F9 (1017) 18 17 / STARTER FEED (1027) / A17DG 10RD / A17BZ 12RD / PLATFORM/ ENGINE (1701) CH4_02 / A10-GA 18WH / A17SE 18RD / GROUND SPLICE#1 (1003B) CH3-33 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 209 / CHARGING AND CRANKING - W/ F-2018-PROPANE-ENGINE (CONT.)

4.4. CHARGING AND CRANKING - W/ F-2018-GAS-ENGINE, P. 4
Figure 210 CHARGING AND CRANKING - W/ F-2018-GAS-ENGINE

Components: BODY CONTROLLER (1606); FEED (1027); FUEL RELAY (1015-R1); FUSE A2-F9 (1017); FUSE A3-K (1016); FUSE A6-H (1014); INTERFACE CONN (6021); INTERRUPT (1008F/M); KEY POWER (4104); KEY SWITCH (1100); PLATFORM (1701/1701); RELAY (4003)
Wires (circuit gauge+color): A10-GA 18WH; A15 16RD; A17BC 16PK; A17BZ 12RD; A17L 16PK; A17SE 18RD; B17A 12RD; K17B 12PK; K17DG 10RD; K17RD 16PK; K17UA 18PK; K17UB 14PK; K17UC 14PK; K17UE 14PK; K17UF 18PK; K17UG 12PK; K17UH 12PK
See also sheets: CH3_02, CH3_05, CH3_33
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 4.4. CHARGING AND CRANKING - W/ F-2018-GAS-ENGINE, P. 4 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090655 95885P 18DEC20 / CHAPTER 4 CHARGING AND CRANKING - W/F-2018-GAS-ENG / - MJV0488 - 19NOV21 ADDED CIRC K17UH IN R/D 6021. / 1 30 / START RELAY 2 (4003) 86 / 85 5 / ENGINE/ PLATFORM (1701/1701) 1 / K17B 12PK / D1 C6 / VEHICLE BODY INTERFACE CONN (6021) / K17UE K17UG 12PK 14PK / K17UF 18PK / K17RD K17UH 16PK 12PK / FUSE A3-K (1016) CH3_05 KEY POWER (4104) A / K17UB 14PK K17UC 14PK / K17UA 18PK / A97UA 18VT / A17SE 18RD / J6-18 WAY BODY CONTROLLER (1606) / OFF IGN D C / KEY SWITCH (1100) BATT / FUSE A6-H (1014) CH3_02 / A15 16RD / A10-GA 18WH / A17BC 16PK STARTER INTERRUPT (1008F/M) / GROUND SPLICE #1 (1003B) CH3_33 / A17L 16PK / STARTER ALT FUEL RELAY (1015-R1) 85 / FUSE A2-F9 (1017) B17A K17DG 12RD 10RD 18 17 STARTER FEED (1027) / A17BZ 12RD / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 210 / CHARGING AND CRANKING - W/ F-2018-GAS-ENGINE

4.5. GRID HEATER CONNECTIONS W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 5
Figure 211 GRID HEATER CONNECTIONS W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: GRID HEATER (6560); SOLENOID GRID (1112); SOLENOID POWER (1111); STARTER POWER (6312); UPPER MEGA FUSE STUD (4000C); UPPER STUD (4025)
Wires (circuit gauge+color): K14F 1RD; K14LA 2RD; K14R-FL 6TN; K14T 2RD; K14V-FL 6TN
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 4.5. GRID HEATER CONNECTIONS W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 5 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090655 95885P 18DEC20 / CHAPTER 4 GRID HEATER CONNECTIONS W/2017/2021 ISB/B6.7 DIESEL ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K14LA 2RD / SOLENOID GRID (1112) / GRID HEATER (6560) / K14T 2RD / K14V-FL 6TN / GRID HTR PWR UPPER MEGA FUSE STUD (4000C) / K14R-FL 6TN / K14F 1RD / SOLENOID POWER (1111) / STARTER POWER (6312) / MEGA FUSE FEED UPPER STUD (4025) / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 211 / GRID HEATER CONNECTIONS W/ 2017 ISB / 2021 B6.7 DIESEL ENGINE

4.6. CAB FEED AND FRAME GROUND CONNECTIONS W/ F-2018-PROPANE / GAS-ENGINE, P. 6
Figure 212 CAB FEED AND FRAME GROUND CONNECTIONS W/ F-2018-PROPANE / GAS-ENGINE

Components: CAB FEED (4025); GROUND (6322); JUNCTION (2222); STUD (4005)
Wires (circuit gauge+color): K11-GL 2WH; K14F 1RD
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 4.6. CAB FEED AND FRAME GROUND CONNECTIONS W/ F-2018-PROPANE / GAS-ENGINE, P. 6 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090655 NO. 95885P 18DEC20 / - MJV0488 - 09JUN21 INITIAL PRODUCTION RELEASE. / LOWER GROUND STUD (4005) / K11-GL 2WH / FRAME GROUND (6322) / K14F 1RD / CAB FEED (4025) / BUS BAR JUNCTION (2222) / K14D-FL 8LT BL / K14E-FL 8LT BL / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 212 / CAB FEED AND FRAME GROUND CONNECTIONS W/ F-2018-PROPANE / GAS-ENGINE

4.7. CHARGING AND CRANKING - W/ 2017-ISB-DIESEL ENGINE, P. 7
Figure 213 CHARGING AND CRANKING - W/ 2017-ISB-DIESEL ENGINE

Components: BODY CONTROLLER (1606); FUSE F7 (1011); GROUND (6107/6106/6109); GROUND (6311); INTERLOCK (10310); INTERRUPT (1008M/1008F); KEY SW (1100); MAG SW (6306); PLATFORM/ENG (1701/1701); PWR (6108/6105/6110); RELAY (2016); STARTER INTERRUPT (1008F/1008M); STARTER PWR (6313); SW RELAY (4009)
Wires (circuit gauge+color): A149A 18GY; A15 16RD; A17 16PK; A17B 16PK; A17CA 18LTGN; A17CB 18BK; A17CC 18WH; B17 18LTGN; B17B 18LTGN; K17B 16PK; K17B 18GY; K17BA 16PK; K2-GB 1WH; K2B 1RD; K2BA-FL 6TN
See also sheets: CH15_37, CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 4.7. CHARGING AND CRANKING - W/ 2017-ISB-DIESEL ENGINE, P. 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090655 95885P 25FEB21 / CHAPTER 4 CHARGING AND CRANKING - W/2017-ISB-DIESEL- ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ALTERNATOR ALTERNATOR PWR R (6108/6105/6110) / K2B 1RD / K2-GB 1WH / KEY SW (1100) / FRAME GROUND / OFF OFF IGN C / S S / BATT BATT / PLATFORM/ENG (1701/1701) 26 *K17B 18GY &K17BA 16PK *K17B 16PK / B S / W/1 GAUGE CHARGE K2BA-FL 6TN / FUSE F7 (1011) CH3_94 / STARTER INTERRUPT (1008M/1008F) A A17B A17B 16PK 16PK / STARTER PWR (6313) / A15 16RD / STARTER/ ALTERNATOR GROUND (6107/6106/6109) / STARTER MAG SW (6306) / & W/ALLISON XMSN * W/EATON XMSN @ W/MUX FOR BC PROG ONLY % W/ENHANCED VCM FUNCTIONS NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / J6-18 WAY BODY CONTROLLER (1606) / %A149A 18GY %A17 16PK %A92#141 18GY / %A17CB 18BK / %A17CC 18WH / GROUND PLICE PACK #2 (1004) CH3_95A / S T / %A17CA 18LTGN / THERMAL OVERCRANK PROTECTION RELAY (2016) / TCM NEUTRAL SW RELAY (4009) CH12_15A / 5 30 / 1 86 / 85 2 / B17B 18LTGN STARTER INTERRUPT (1008F/1008M) A / B17 18LTGN / STARTER INTERLOCK (10310) CH15_37 / ALTERNATOR GROUND (6311) / @A17 16PK / Figure 213 / CHARGING AND CRANKING - W/ 2017-ISB-DIESEL ENGINE

4.8. CHARGING AND CRANKING - W/ F-2018-PROPANE-ENGINE, P. 8
Figure 214 CHARGING AND CRANKING - W/ F-2018-PROPANE-ENGINE

Components: BODY CONTROLLER (1601); CONTROLLER (1606); ENG/PLATFORM (1701/1701); FUSE F17-B (1011); FUSE F7-B (1011); FUSE STUD (4000B); GEN 5 TCM (7150); INTERFACE CONN (6021); INTERLOCK (10310); INTERRUPT (1008M/1008F); KEY PWR (4104); KEY SW (1100); PLATFORM/ENG (1701/1701); RELAY (1011-R3); RELAY (4003); RELAY (4101); RELAY (4116); STARTER FUSE (4106); TCM NEUTRAL SW (4009)
Wires (circuit gauge+color): A15 16RD; A17 16PK; A17B 12RD; A17B 16PK; A17SE 18RD; A97RB 18TN; B17 18LTGN; B17B 18LTGN; K10-GA 18WH; K10-GB 18WH; K10-GC 10WH; K17B 12PK; K17B 16PK; K17RA 18RD; K17RC 14RD; K17RD 16RD; K17RD2 14RD; K17SA 12RD; K17SB 12RD; K17SC 12RD; K17SE 18RD; K17UA 18PK; K17UB 14PK; K17UC 14PK; K17UE 14PK; K17UF 18PK; K17UG 12PK; K17UH 12PK
See also sheets: CH15_37, CH3_94, CH4_10
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 4.8. CHARGING AND CRANKING - W/ F-2018-PROPANE-ENGINE, P. 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 4 CHARGING AND CRANKING - W/F-2018-PROP-ENG / - MJV0488 - 19NOV21 ADDED CIRC K17UH IN R/D 6021. / C B / GEN 5 TCM (7150) NEUTRAL 41 START / S B / OFF IGN D C / 16RD A15 / STARTER INTERRUPT (1008M/1008F) A A17 B17B 16PK 18LTGN B17 18LTGN PLATFORM/ENG (1701/1701) 19 / STARTER INTERRUPT (1008M/1008F) A A17B 16PK / 1 30 / K92#141 18GY 2 86 / 87A 3 / 85 5 / KEY SW (1100) / 4 K17SE SWITCHED 18RD CRANK RELAY 1 (4101) 2 86 30 / TCM NEUTRAL SW (4009) / F7-B (1011) CH3_94 FUSE / K17B 12PK START RELAY 1 (4003) 2 30 86 / 85 5 / 87A 3 / 87A 3 / K10-GB 18WH / K10-GC 10WH / UPPER GROUND STUD (3G) / K17SB 12RD / STARTER FUSE (4106) / B A / UPPER MEGA FUSE STUD (4000B) / K17SA 12RD / 1 30 / 2 86 / 87A 3 K17RC 14RD / K17UB 14PK ENG/PLATFORM (1701/1701) 21 K17UA 18PK ECM CONTROL RELAY (4116) 85 5 / K17UE 14PK / KEY PWR (4104) / K17UC 14PK / K17RA 18RD / K17RD2 14RD / K97RB 18VT / A97UA 18VT / FUSE F17-B (1011) CH3_94C J4-TAN BLUE BODY CONTROLLER (1601) E8 HYD BRK / E1 AIR ABS / K17SC 12RD / K17UG 12PK / K17RD 16RD / K10-GA 18WH / *A97RB 18TN %A97RB 18TN / % W/HYDRAULIC BRAKES * W/AIR BRAKES / K17B 16PK / STARTER INTERLOCK (10310) CH15_37 / A17SE A17B 16PK 18RD / A17B 12RD / (1011-R3) LT RELAY CH4_10 STOP / K17UF 18PK / K17UH 12PK / Figure 214 / CHARGING AND CRANKING - W/ F-2018-PROPANE-ENGINE

4.9. CHARGING AND CRANKING - W/ F-2018-GAS-ENGINE, P. 9
Figure 215 CHARGING AND CRANKING - W/ F-2018-GAS-ENGINE

Components: CONTROLLER (1606); ENGINE/PLATFORM (1701/1701); FUSE F17-B (1011); FUSE F7-B (1011); INTERFACE CONN (6021); INTERLOCK (10310); INTERRUPT (1008M/1008F); KEY POWER (4104); KEY SWITCH (1100); RELAY (1011-R3); RELAY (4003); STARTER INTERRUPT (1008F/1008M)
Wires (circuit gauge+color): A15 16RD; A17 16PK; A17B 12RD; A17B 16PK; A17SE 18RD; B17 18LTGN; B17B 18LTGN; K17B 12PK; K17RD 16PK; K17UA 18PK; K17UB 14PK; K17UC 14PK; K17UE 14PK; K17UF 18PK; K17UG 12PK; K17UH 12PK
See also sheets: CH15_37, CH3_94, CH4_10
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 4.9. CHARGING AND CRANKING - W/ F-2018-GAS-ENGINE, P. 9 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090655 95885P 25FEB21 / CHAPTER 4 CHARGING AND CRANKING - W/F-2018-GAS-ENG / - MJV0488 - 19NOV21 ADDED CIRC K17UH IN R/D 6021. / STARTER INTERRUPT (1008M/1008F) A / 1 30 / START RELAY 2 (4003) 86 / 87A 3 / 85 5 / ENGINE/PLATFORM (1701/1701) 1 K17B A17B 12PK 12RD / D1 C6 / VEHICLE BODY INTERFACE CONN (6021) / K17UE K17UG 12PK 14PK / K17UF 18PK / K17RD K17UH 16PK 12PK / FUSE F17-B (1011) CH3_94C KEY POWER (4104) A / K17UB 14PK K17UC 14PK / K17UA 18PK / STOP LT RELAY (1011-R3) CH4_10 A97UA 18VT / J6-18 WAY BODY CONTROLLER (1606) / OFF IGN D C / KEY SWITCH (1100) BATT / FUSE F7-B (1011) CH3_94 / A15 16RD / A17 B17B 16PK 18LTGN STARTER INTERRUPT (1008F/1008M) A A17B B17 16PK 18LTGN / STARTER INTERLOCK (10310) CH15_37 / A17SE 18RD / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 215 / CHARGING AND CRANKING - W/ F-2018-GAS-ENGINE

4.10. CHARGING AND CRANKING - W/ F-2018-PROPANE / GAS-ENGINE, P. 10
Figure 216 CHARGING AND CRANKING - W/ F-2018-PROPANE / GAS-ENGINE

Components: CONN (1012); CONTROLLER (1606); FEED (1027); PLATFORM/ENG (1701); RELAY (1011-R3)
Wires (circuit gauge+color): A10-GA 18WH; A17 12RD; A17A 12RD; A17B 12RD; A17SE 18RD
See also sheets: CH4_08
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 4.10. CHARGING AND CRANKING - W/ F-2018-PROPANE / GAS-ENGINE, P. 10 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090655 95885P 31MAR21 / CHAPTER 4 CHARGING AND CRANKING-W/F-2018 PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A 86 / E 30 / 85 B / A17B 12RD / A10-GA 18WH / PLATFORM/ENG (1701) CH4_08,09 J6-18 WAY BODY CONTROLLER (1606) CH4_08,09 / GROUND SPLICE #1 (1003B) CH3-95C / A17SE 18RD / STARTER FUSE CONN (1012) B A 30A / A17A 12RD / A17 12RD / STARTER FEED (1027) / STOP LT RELAY (1011-R3) / W/ENHANCED VCM FUNCTION / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 216 / CHARGING AND CRANKING - W/ F-2018-PROPANE / GAS-ENGINE

Figure 217 INSTRUMENT GAUGE CLUSTER W/ 2017 ISB / 2021 B6.7 DIESEL & F-2018-PROPANE /

Components: AIR TEMP RESISTOR (1028); BODY CONTROLLER (1602); FUSE A3-P (1016); FUSE A3-X (1016); FUSE A6-D (1014); FUSE F2 (1011); FUSE F24 (1011); FUSE F26 (1011); GROUND (4037A); INSTRUMENT CLUSTER (1500); INSTRUMENT CLUSTER (1505); PLATFORM/FR CHASSIS (1700/1700); SENSOR (8601)
Wires (circuit gauge+color): A11-GZ 8WH; A110 18GY; A110AD 18GY; A28 18TN; A28-G 18WH; A28A 18TN; A41 18TN; A62 16DKBL; M110AD 18GY; M41 18TN
See also sheets: CH3_01, CH3_02, CH3_06, CH3_94, CH5_06
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / GAUGES AND WARNING LIGHTS (CHAPTER 5) / 5.1. INSTRUMENT GAUGE CLUSTER W/ 2017 ISB / 2021 B6.7 DIESEL & F-2018-PROPANE / GAS-ENGINE, P. 1 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. 95885P 18DEC20 / CHAPTER 5 INSTRUMENT GAUGE CLUSTER W/2017/2021 ISB/B6.7 DIESEL & F-2018-PROP/GAS-ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / @A28 18TN / FWD AMBIENT TEMP SENSOR (8601) CH5_06 AIR TEMP RESISTOR (1028) CH5_06 J5-TAN BODY CONTROLLER (1602) / HEADLIGHT E11 ENABLE / FUSE A6-D (1014) CH3_01 FUSE F2 (1011) CH3_94 / *A28-G 18WH / @A28A 18TN / INSTRUMENT CLUSTER (1505) / *A50 18YL / INSTRUMENT CLUSTER (1500) / HEADLIGHT 10 ENABLE / IGNITION IGNITION / ACCESSORY 4 / @A62 16DKBL / FUSE A3-P (1016) CH3_06 FUSE F24 (1011) CH3_94C FUSE A3-X (1016) CH3_02 FUSE F26 (1011) CH3_94C / *A110AD 18GY / M110AD 18GY / PLATFORM/FR CHASSIS (1700/1700) 32 / *A110 18GY / AIR TEMP RESISTOR (1028) CH5_06 / FWD AMBIENT TEMP SENSOR (8601) CH5_06 / A11-GZ 8WH / GROUND (4037A) / *A41 18TN / M41 18TN / PLATFORM/FR CHASSIS (1700/1700) 15 / *A41 18TN / OUTSIDE TEMP / %A28 18TN / %A28A 18TN / %A62 16DKBL / Figure 217 / INSTRUMENT GAUGE CLUSTER W/ 2017 ISB / 2021 B6.7 DIESEL & F-2018-PROPANE / GAS-ENGINE

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 258 | printed page 218 | section 5.2
5.2. FUEL GAUGES W/ 2017 / 2021 ISB / B6.7 DIESEL ENGINE, P. 2
Figure 218 FUEL GAUGES W/ 2017 / 2021 ISB / B6.7 DIESEL ENGINE

Components: BODY CONTROLLER (1600); BODY CONTROLLER (1602); FORWARD CHASSIS (1700/1700); INTERCONNECT (9100/9100A/B); INTERCONNECT (9513M / 9513F)
Wires (circuit gauge+color): A36 18TN; A9AAP 18GY; M36 18TN; M9D 18GY; R36 18BK; R9D 18WH
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.2. FUEL GAUGES W/ 2017 / 2021 ISB / B6.7 DIESEL ENGINE, P. 2 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090656 95885P 18DEC20 / CHAPTER 5 FUEL GAUGES W/2017/2021 ISB/B6.7 DIESEL ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FUEL LEVEL SENSOR INPUT / A36 18TN / #M36 18TN / FUEL LEVEL SENSOR INPUT / AIR REAR CHASSIS INTERCONNECT (9100/9100A/B) A / J3-RED BODY CONTROLLER (1600) / M36 18TN / *M36 18TN / PLATFORM / FORWARD CHASSIS (1700/1700) 58 / R9D 18WH FUEL GAUGE LEVEL SENSOR %(9101B) LOOMISE BUS LOCATION / @(9101) RIGHT SIDE MTD TANK B A / A9AAP 18GY / PLATFORM / FORWARD CHASSIS (1700/1700) 58 / ZERO VOLT (1) / HYD REAR CHASSIS INTERCONNECT (9513M / 9513F) / R36 A 18BK / J3-RED BODY CONTROLLER (1600) / AF FUEL SENDER @(9101) %(9101A) #(9101B) B / ZERO VOLT E3 (1) / A9AAP 18GY / J5-TAN BODY CONTROLLER (1602) / A36 18TN / J5-TAN BODY CONTROLLER (1602) / AF FUEL SENDER *(9101) &(9101B) ^(9101B) A R36 18BK / R9D 18WH / #M9D 18GY / *M9D 18GY / M9D 18GY / @ W/STANDARD FUEL SENDER % W/40 GAL FUEL SENDER # W/65 GAL FUEL SENDER * W/AFT MTD FUEL TANK W/AIR BRAKES / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 218 / FUEL GAUGES W/ 2017 / 2021 ISB / B6.7 DIESEL ENGINE

5.3. FUEL GAUGES W/ F-2018-PROPANE / GAS-ENG, P. 3
Figure 219 FUEL GAUGES W/ F-2018-PROPANE / GAS-ENG

Components: CONTROLLER (1602); FR CHASSIS (1700); INTERCONNECT (9100/9100); INTERCONNECT (9101); PLATFORM/CAP (1703/1703C)
Wires (circuit gauge+color): A171JPS 18GY; A171L 18TN; A171LA 18TN; A171M 18TN; A171MA 18TN; A171PS 18GY; A171PSJ 18GY; M148L 18TN; M148M 18TN; R148L 18TN; R148M 18TN
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.3. FUEL GAUGES W/ F-2018-PROPANE / GAS-ENG, P. 3 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090656 NO. 95885P 18DEC20 / CHAPTER 5 FUEL GAUGES W/F-2018-PROP/GAS-ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A171LA 18TN / A171MA 18TN / M148L 18TN / FWD/REAR FUEL SYSTEM INTERCONNECT (9100/9100) 12 / PLATFORM/ FR CHASSIS (1700) 53 / J5-TAN BODY CONTROLLER (1602) / FUEL SYSTEM INTERCONNECT (9101) / A171JPS 18GY / A171PSJ 18GY / A171PS 18GY / PLATFORM/CAP (1703/1703C) / A171L 18TN / A171M 18TN / M148M 18TN / R148L 18TN / R148M 18TN / A171MA 18TN / Figure 219 / FUEL GAUGES W/ F-2018-PROPANE / GAS-ENG

5.4. ENGINE COMPARTMENT TEMP INDICATOR, P. 4
Figure 220 ENGINE COMPARTMENT TEMP INDICATOR

Components: BUZZER (10390); ELEC PANEL (11500); FUSE A1-H (10305); GROUND SPLICE (10335B); INDICATOR (1062); PLATFORM (1702); SPLICE (10337); TEMP SENSOR (10224); TEMP SENSOR (11523); TEMP SENSOR RELAY (10310-R3)
Wires (circuit gauge+color): A41A 16TN; A41A-G 18WH; B41 18TN; B41-GC 18WH; B41-GK 18WH; B41A 18TN; B41B 18TN; B41C 18TN; B41D 18TN; B41E 18TN; B41F 18TN; B41H 18TN; B41J 18TN; B41K 18TN; B41L 18TN; B41M 18TN; Y41 18TN; Y41A 18TN
See also sheets: CH3_15, CH3_31, CH3_38, CH3_41
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.4. ENGINE COMPARTMENT TEMP INDICATOR, P. 4 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090656 95885P 18DEC20 / CHAPTER 5 ENGINE COMPARTMENT TEMP INDICATOR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 30 30 / B41J 18TN 87A / B41C 18TN / ENGINE COMPARTMENT INDICATOR (1062) 1A / TEMP SENSOR (10224) B / B41F 18TN / B41E 18TN / B41A 18TN / ENGINE COMP TEMP SENSOR (11523) A / Y41 18TN / Y41A 18TN / ENGINE COMP TEMP SENSOR SW / ENGINE COMP TEMP SENSOR BUZZER (10390) / 18TN B41 / B41-GC 18WH / GROUND SPLICE (10335B) CH3_38 / B41D 18TN / ELEC PANEL/ PLATFORM (1702) 49 B41L 18TN GND SPLICE PACK#2 (1004) CH3_31 / A41A 16TN A41A-G 18WH / GROUND SPLICE (10337) CH3_41 / B41K 18TN / B41-GK 18WH / TEMP SENSOR RELAY (10310-R3) / B41B 18TN / FUSE A1-H (10305) CH3_15 / B41H 18TN / TEMP SENSOR SW / SEALED ENGINE / ELEC PANEL (11500) / B41M 18TN / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 220 / ENGINE COMPARTMENT TEMP INDICATOR

5.5. ENGINE COMPARTMENT TEMP INDICATOR (CONT.), P. 4A
Figure 221 ENGINE COMPARTMENT TEMP INDICATOR (CONT.)

Components: BUZZER (10390); ELEC PANEL (11500); FUSE F60 (10305); GROUND SPLICE (10335B); INDICATOR (1062); PLATFORM (1702); SENSOR RELAY (10310); SPLICE (10337); TEMP SENSOR (10224); TEMP SENSOR (11523)
Wires (circuit gauge+color): A41A 16TN; A41A-G 18WH; B41 18TN; B41-GC 18WH; B41-GK 18WH; B41A 18TN; B41B 18TN; B41C 18TN; B41D 18TN; B41E 18TN; B41F 18TN; B41H 18TN; B41J 18TN; B41K 18TN; B41L 18TN; Y41 18TN; Y41A 18TN
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.5. ENGINE COMPARTMENT TEMP INDICATOR (CONT.), P. 4A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090656 NO. 95885P 29MAR21 / CHAPTER 5 ENGINE COMPARTMENT TEMP INDICATOR (CONT.) / MJV0488 10JUN21 INITIAL PRODUCTION RELEASE. / E2 30 30 / B41J 18TN 87A / ENGINE TEMP SENSOR RELAY (10310) 85 E1 / F2 86 / B41C 18TN / ENGINE COMPARTMENT INDICATOR (1062) 1A / TEMP SENSOR (10224) B / B41F 18TN / B41E 18TN / B41A 18TN / ENGINE COMP TEMP SENSOR (11523) A / Y41 18TN / Y41A 18TN / ENGINE COMP TEMP SENSOR SW / ENGINE COMP TEMP SENSOR BUZZER (10390) / 18TN B41 / B41-GC 18WH / GROUND SPLICE (10335B) CH3_95H / B41D 18TN / ELEC PANEL/ PLATFORM (1702) 49 B41L 18TN GND SPLICE PACK#2 (1004) CH3_95A / A41A 16TN A41A-G 18WH / GROUND SPLICE (10337) CH3_95L / B41K 18TN / B41-GK 18WH / B41B 18TN / FUSE F60 (10305) CH3_94M / B41H 18TN / TEMP SENSOR SW / SEALED ENGINE / ELEC PANEL (11500) / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 221 / ENGINE COMPARTMENT TEMP INDICATOR (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 262 | printed page 222 | section 5.6
5.6. LIFT DOOR INDICATOR EFFECTS, P. 5
Figure 222 LIFT DOOR INDICATOR EFFECTS

Components: ELE PANEL/L BODY (10401A/B); INDICATOR (10371); LIFT INDICATOR (1051); LIFT INDICATOR (9555); LIFT LT RELAY (10312); PLATFORM (1702); SPLICE (10335A); STEP WARMER RELAY (10312)
Wires (circuit gauge+color): A122A 16GY; A122A 18GY; A122B 18GY; A122B-G 16WH; B122 18GY; B122-GB 18WH; B122A 18GY; B122B 18GY; B122CA 18GY; B122N 16GY; B122V 16GY
See also sheets: CH15_02, CH15_31, CH15_40
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.6. LIFT DOOR INDICATOR EFFECTS, P. 5 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090656 95885P 19DEC20 / CHAPTER 5 LIFT DOOR INDICATOR EFFECTS / MJV0488 19NOV21 ADDED EFFECTS OF W/ON V BATT. / B122A 18GY / #A122B 18GY @A122B-G 16WH / 1/2 INCH LIFT INDICATOR (1051) 1A 1A / #A122A 18GY @A122A 16GY / *B122V 16GY / B122-GB 18WH / B122 18GY / ELEC PANEL/ PLATFORM (1702) 14 / GROUND SPLICE (10335A) CH3_95G / B122B 18GY / LIFT LT RELAY (10312)CH15_40 STEP WARMER RELAY (10312) CH15_40 LIFT LT RELAY (10312) CH15_31,34,35, ELE PANEL/L BODY (10401A/B) CH15_02,05,07 / 2 INCH RED OVAL LIFT INDICATOR (9555) A / B122N 16GY / FLASH LT INDICATOR (10371) / %B122V 16GY / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / &B122V 16GY &B122CA 18GY / Figure 222 / LIFT DOOR INDICATOR EFFECTS

5.7. TEMPERATURE DISPLAY, P. 6
Figure 223 TEMPERATURE DISPLAY

Components: CLUSTER CONNECTOR (1505); INSTRUMENT CLUSTER (1500); PLATFORM (1700); RESISTOR (1028); TEMP SENDER (8601)
Wires (circuit gauge+color): A110 18GY; A110AD 18GY; A41 18TN; M110AD 18GY; M41 18TN
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.7. TEMPERATURE DISPLAY, P. 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090656 95885P 19DEC20 / CHAPTER 5 / TEMPERATURE DISPLAY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A110AD 18GY A41 18TN / A110 18GY / OUTSIDE TEMP / FORWARD CHASSIS / PLATFORM (1700) 32 / INSTRUMENT CLUSTER (1500) / W/ AMBIENT TEMP RESISTOR AIR TEMP RESISTOR (1028) B / CLUSTER CONNECTOR (1505) / %M41 18TN / %M110AD 18GY / A41 18TN / FORWARD AMBIENT TEMP SENDER (8601) B / % W/2017/2021 ISB B6.7 DIESEL ENG AND F-2018-PROP/GAS-ENG / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 223 / TEMPERATURE DISPLAY

5.8. BODY BUILDER CONNECTIONS, P. 7
Figure 224 BODY BUILDER CONNECTIONS

Components: BODY CONTROLLER (1024); BODY CONTROLLER FEED (1605); CONN (1023); HARNESS (1701)
Wires (circuit gauge+color): A14AB 4RD; A47 18GY; A48 18GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.8. BODY BUILDER CONNECTIONS, P. 7 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090656 95885P 19DEC20 / CHAPTER 5 / BODY BUILDER CONNECTIONS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / BODY CONTROLLER FEED (1605) / A14AB 4RD / SPECIAL EQUIPMENT CONN (1023) / A47 18GY / A48 18GY / ENGINE/PLATFORM HARNESS (1701) / BODY CONTROLLER (1024) / W/2017/2021 ISB/B6.7 DIESEL & F-2018-PROP/GAS-ENG / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 224 / BODY BUILDER CONNECTIONS

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 265 | printed page 225 | section 5.9
5.9. PAM MODULE AND AMMETER CONNECTIONS W/ 2017 / 2021 ISB / B6.7 DIESEL ENG, P. 8
Figure 225 PAM MODULE AND AMMETER CONNECTIONS W/ 2017 / 2021 ISB / B6.7 DIESEL ENG

Components: AMMETER CONNECTION (6333); AMMETER CONNECTION (9262); ENGINE / PLATFORM (1701/1701); FUSE A6-A (1014); FUSE F4 (1011); PAM MODULE (4087); PLATFORM (1701/1701); SPLICE (6704M)
Wires (circuit gauge+color): A26 18RD; A26 18TN; A26A 18TN; A26B 18TN; K26 18TN; K26-G 18WH; K26A 16TN; K26B 16TN; K26C 18TN; K26D 18TN; K26E 18TN
See also sheets: CH3_02, CH3_61, CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.9. PAM MODULE AND AMMETER CONNECTIONS W/ 2017 / 2021 ISB / B6.7 DIESEL ENG, P. 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090656 NO. 95885P 19DEC20 / CHAPTER 5 PAM MODULE AND AMMETER CONNECTIONS W/2017/2021 ISB/B6.7 DIESEL ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A26 18TN / ENGINE / PLATFORM (1701/1701) 32 / *A26A 18TN %A26B 18TN @A26B 18TN / AMMETER(+) (50) + - AMMETER(-) (51) FUSE A6-A (1014) CH3_02 FUSE F4 (1011) CH3_94 GROUND SPLICE (6704M) CH3_61 / 11 AMMETER (-) / 12 12 / K26 18TN / B METER (-) / GROUND D / *K26D 18TN *K26C 18TN / METER (+) C / 10 AMMETER (+) / *A26 18RD / AMMETER SENSE *(6334) / *K26E 18TN / PAM MODULE (4087) / ENGINE / PLATFORM (1701/1701) 23 / K26-G 18WH / GROUND SPLICE (6704M) CH3_61 / K26A 16TN K26B 16TN / AMMETER CONNECTION (6333) / AMMETER CONNECTION (9262) / *K26-G 18WH / FUSE A6-A (1014) CH3_02 / NOTE: W/CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK / Figure 225 / PAM MODULE AND AMMETER CONNECTIONS W/ 2017 / 2021 ISB / B6.7 DIESEL ENG

5.10. CROSSING GATE AND AMMETER CONNECTIONS W/ F-2018-PROPANE / GAS-ENG, P. 9
Figure 226 CROSSING GATE AND AMMETER CONNECTIONS W/ F-2018-PROPANE / GAS-ENG

Components: AMMETER SENSE (6334); ENGINE / PLATFORM (1701); FUSE A6-A (1014); FUSE-F4 (1011)
Wires (circuit gauge+color): A119A 16GY; A26 16GY; A26 18RD; A26 18TN; A26-G 18WH; A26A 18TN; A26B 18TN; A26N 18TN; A26P 18TN; K26 18TN; K26-G 18WH; K26N 18TN; K26P 18TN
See also sheets: CH3_02, CH3_31, CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.10. CROSSING GATE AND AMMETER CONNECTIONS W/ F-2018-PROPANE / GAS-ENG, P. 9 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090656 NO. 95885P 19DEC20 / CHAPTER 5 CROSSING GATE AND AMMETER CONNECTIONS W/F-2018-PROP/GAS-ENG / MJV0488 19NOV21 UPDATED CIRC OF R/D 50, 51. / ENGINE / PLATFORM (1701) 32 / *K26-G 18WH / AMMETER SENSE (6334) / *K26 18TN / *K26P 18TN / *K26N 18TN / FUSE A6-A (1014) CH3_02 FUSE-F4 (1011) CH3_94 GROUND SPLICE#2 (1004) CH3_31,95A / AMMETER(+) (50) + - AMMETER(-) (51) / @A26 18RD %A26N 18TN %A26P 18TN / @A26A 18TN / @A26B 18TN / *A26-G 18WH / A119A 16GY / *K26-G 18WH / *K26N 18TN / AMMETER(-) (51) - + AMMETER(+) (50) / A119A 16GY / *K26P 18TN / ENGINE / PLATFORM (1701) 44 / @A26A 18TN %A26P 18TN %A26N 18TN @A26 18RD / AMMETER SENSE (6334) / *K26 18TN / @A26B 18TN / %A26 18TN *A26-G 18WH / %A119A 16GY #A26 16GY / %A26 18TN / %A119A 16GY #A26 16GY / Figure 226 / CROSSING GATE AND AMMETER CONNECTIONS W/ F-2018-PROPANE / GAS-ENG

5.11. AMMETER CONNECTION W/ 400A W/ 2017 / 2021 ISB / B6.7 DIESEL ENG, P. 10
Figure 227 AMMETER CONNECTION W/ 400A W/ 2017 / 2021 ISB / B6.7 DIESEL ENG

Components: AMMETER SENSOR (6335); ENGINE / PLATFORM (1701); FUSE A6-A (1014); FUSE F4 (1011); SPLICE (6704M)
Wires (circuit gauge+color): A26 18RD; A26A 18TN; A26B 18TN; K26 18TN; K26-G 18WH; K26N 18TN; K26P 18TN
See also sheets: CH3_02, CH3_61, CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.11. AMMETER CONNECTION W/ 400A W/ 2017 / 2021 ISB / B6.7 DIESEL ENG, P. 10 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090656 95885P 19DEC20 / CHAPTER 5 AMMETER CONNECTION W/400A W/2017/2021 ISB/B6.7 DIESEL ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / #K26-G 18WH / 400 AMP AMMETER SENSOR (6335) / ENGINE / PLATFORM (1701) 44 / #K26P 18TN #K26 18TN / #K26N 18TN / FUSE A6-A (1014) CH3_02 FUSE F4 (1011) CH3_94 GROUND SPLICE (6704M) CH3_61 / AMMETER(+) (50) / #A26 18RD @A26B 18TN / AMMETER(-) (51) / #A26A 18TN / - + / %A26B 18TN / Figure 227 / AMMETER CONNECTION W/ 400A W/ 2017 / 2021 ISB / B6.7 DIESEL ENG

5.12. PAM MODULE CONNECTIONS W/ 2017-ISB-DIESEL ENG, P. 10A
Figure 228 PAM MODULE CONNECTIONS W/ 2017-ISB-DIESEL ENG

Components: AMMETER CONN (6333); AMMETER CONN (9262); ENG/PLATFORM (1701); FUSE F4-B (1011); PAM MODULE (4087); SPLICE (6704M); TERMINATING RESISTOR (7801M)
Wires (circuit gauge+color): A26 18TN; K26 18TN; K26-G 18WH; K26A 16TN; K26B 16TN
See also sheets: CH3_61, CH3_94, CH3_97
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.12. PAM MODULE CONNECTIONS W/ 2017-ISB-DIESEL ENG, P. 10A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090656 95885P 29MAR21 / CHAPTER 5 PAM MODULE CONNECTIONS W/2017-ISB-DIESEL ENGINE / MJV0488 19NOV21 FUSE F4-B WAS FUSE F4 AT R/D 1011. / A26 18TN / 11 AMMETER (-) / J1939 (-) / GROUND 12 / K26 18TN / J1939 (+) / AMMETER (+) 10 / PAM MODULE (4087) / ENG/PLATFORM (1701) 23 / K26-G 18WH / K26A 16TN K26B 16TN / GROUND SPLICE (6704M) CH3_61 AMMETER CONN (6333) / AMMETER CONN (9262) / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / #K5C(+) 18YL #K5C(-) 18GN / #K5A(+) 20YL #K5A(-) 20GN / @K5A(+) 20YL / #K5B(+) 18YL / #K5B(-) 18GN / @K5A(-) 20GN / TERMINATING RESISTOR (7801M) / # W/ PAM MODULE @ N/ PAM MODULE / 120 OHMS / FUSE F4-B (1011) CH3_94 / ENG/PLATFORM (1701) CH3_97 / Figure 228 / PAM MODULE CONNECTIONS W/ 2017-ISB-DIESEL ENG

5.13. CROSSING GATE W/ 150A AMMETER N / PWL W/ 2017-ISB-DIESEL ENG, P. 10B
Figure 229 CROSSING GATE W/ 150A AMMETER N / PWL W/ 2017-ISB-DIESEL ENG

Components: CANCEL RELAY (1030); CONTROLLER (1601); CROSSING GATE DIODE (1031); ELEC PANEL (1702); FUSE F4-B (1011); GROUND (4037A); KEY SW (1146); PLATFORM (1700); RELAY (1027); SWITCH (10241)
Wires (circuit gauge+color): A119 16GY; A119-G 16WH; A119-GA 18WH; A119B 16GY; A119C 16GY; A119D 16GY; A119H 18GY; A119J 16GY; A119K 18GY; A119L 18GY; A120 18LTGN; A120A 18LTGN; A120B 18LTGN; A133B 16LTGN; B119M 18GY
See also sheets: CH16_15, CH2_35, CH3_94, CH9_04, CH9_09
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.13. CROSSING GATE W/ 150A AMMETER N / PWL W/ 2017-ISB-DIESEL ENG, P. 10B / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090656 96289K 10OCT21 / CHAPTER 5 CROSSING GATE W/150A AMMETER N/PWL W/2017-ISB-DIESEL ENG / - MJV0488 - 19NOV21 INITIAL PRODUCTION RELEASE. / 1 30 / 2 86 / 87A 5 / 85 3 / CROSSING GATE RELAY (1027) / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / A119-G 16WH / GROUND (4037A) CH2_35 / A119 16GY / A120 18LTGN / J4-BLUE BODY CONTROLLER (1601) / A119D 16GY / A119B 16GY / FUSE F4-B (1011) CH3_94 / A119C 16GY / FWD CHASSIS/ PLATFORM (1700) CH9_09 / 87A 4 5 / 2 86 / 1 30 / 85 3 / A119-GA 18WH / GROUND (4037A) CH2_35 / A119J 16GY / CROSSING GATE CANCEL RELAY (1030) / A119K 18GY / PLATFORM/ ELEC PANEL (1702) 56 A119L B119M 18GY 18GY / STOPARM CROSSING GATE CANCEL SWITCH (10241) CH9_04 / A119H 18GY CROSSING GATE DIODE (1031) A / FWD CHASSIS/ PLATFORM (1700) CH9_09 / A120A 18LTGN / A120B 18LTGN / A133B 16LTGN / VANDAL LOCK KEY SW (1146) CH16_15 / Figure 229 / CROSSING GATE W/ 150A AMMETER N / PWL W/ 2017-ISB-DIESEL ENG

5.14. SEAT BELT ALARM EFFECTS W/ 2017 / 2021 ISB / B6.7 DIESEL &
Figure 230 SEAT BELT ALARM EFFECTS W/ 2017 / 2021 ISB / B6.7 DIESEL & F-2018-PROPANE /

Components: ALARM (1109); CONTROLLER (1600); REFERENCE (1005)
Wires (circuit gauge+color): A79 18GY; A9BB 18GY
See also sheets: CH3_58
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.14. SEAT BELT ALARM EFFECTS W/ 2017 / 2021 ISB / B6.7 DIESEL & F-2018-PROPANE / GAS-ENG, P. 11 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090656 NO. 95885P 19DEC20 / CHAPTER 5 SEAT BELT ALARM EFFECTS W/2017/2021 ISB/B6.7 DIESEL & F-2018-PROP/GAS-ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SEAT BELT A3 ALARM I/P / SEAT BELT ALARM (1109) A / ZERO VOLT (1005) CH3_58,95M / J3-RED BODY CONTROLLER (1600) / A9BB 18GY / A79 18GY / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 230 / SEAT BELT ALARM EFFECTS W/ 2017 / 2021 ISB / B6.7 DIESEL & F-2018-PROPANE / GAS-ENG

5.15. SEAT BELT ALARM EFFECTS W/ 2017 / 2021 ISB / B6.7 DIESEL &
Figure 231 SEAT BELT ALARM EFFECTS W/ 2017 / 2021 ISB / B6.7 DIESEL & F-2018-PROPANE /

Components: ALARM (1109A); ALARM RELAY (1011-R3); ALARM RELAY (1011-R5); CONTROLLER (1600); FUSE A6-E (1014); REFERENCE (1005); SPLICE (4037ZA/B)
Wires (circuit gauge+color): A79 16GY; A79-G 12WH; A79-G 14WH; A79A 16RD; A79C 16RD; A79D 16GY; A79E 16GY; A79M-G 14WH; A9BB 16GY; A9VL 14GY
See also sheets: CH13_52, CH3_01, CH3_58
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.15. SEAT BELT ALARM EFFECTS W/ 2017 / 2021 ISB / B6.7 DIESEL & F-2018-PROPANE / GAS-ENG (CONT.), P. 12 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090656 NO. RELEASE NO. 95885P 19DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SEAT BELT ALARM RELAY (1011-R3) / A79E 16GY / A79A 16RD / A79C 16RD / A79D 16GY / FUSE A6-E (1014) CH3_01 / PARK BRAKE ALARM RELAY (1011-R5) CH13_52 / SEAT BELT ALARM (1109A) / ZERO VOLT (1005) CH3_58 / A9VL 14GY / A9BB 16GY / SEAT BELT ALARM INPUT / A79 16GY / J3-RED BODY CONTROLLER (1600) / A79M-G 14WH / GROUND SPLICE (4037ZA/B) / %A79-G 12WH @A79-G 14WH / @ W/PARK BRAKE BUZZER-ABS 8 % W/PARK BRAKE BUZZER-ABS 6 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 231 / SEAT BELT ALARM EFFECTS W/ 2017 / 2021 ISB / B6.7 DIESEL & F-2018-PROPANE / GAS-ENG (CONT.)

5.16. GASOLINE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/
Figure 232 GASOLINE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/ F-2018-GAS-ENG

Components: CONNECTOR (6022); FWD CHASSIS (1700); INTERCONNECT (9100); PLATFORM/ENG (1701); RELAY (4103); SPLICE (6740); VALVE RELAY (4011)
Wires (circuit gauge+color): A36CB 10TN; A36D 14TN; A37C 18TN; A37E 14TN; A37H 14TN; A37J 14TN; A37K 14TN; K36D 14TN; K36DB 16TN; K36E 14TN; K36EB 16TN; K37DS 12TN; K37ES 12RD; K37ET 10RD; K37H 14TN; K37HB 16TN; K37J 14TN; K37JB 16TN; K37K 14TN; K37KB 16TN; M11-GA 10WH; M11-GE 4WH; M36C 10RD; M36CA 6RD; M36CB 10RD; M36D 14TN; M37-G 10WH; M37C 12TN; M37E 14TN; M37GA 6WH; M37GB 10WH; M37H 12TN; M37J 12TN; M37K 12TN
See also sheets: CH3_51, CH5_14, CH5_15
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.16. GASOLINE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/ F-2018-GAS-ENG, P. 13 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090656 NO. 95885P 19DEC20 / CHAPTER 5 GASOLINE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/F-2018-GASOLINE-ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FUEL INTERFACE CONNECTOR (6022) / PLATFORM/ENG (1701) 36 / K36D 14TN K36E 14TN / K37H 14TN / K37DS 12TN / K37J 14TN K37K 14TN / K37ET 10RD / K36DB 16TN K36EB 16TN / K37HB 16TN / K37JB 16TN K37KB 16TN / K37ES 12RD / FUEL SUPPLY VALVE RELAY (4011) CH5_15 FUEL PUMP RELAY (4103) CH5_15 / PLATFORM/ FWD CHASSIS (1700) 68 / A36D 14TN A37E 14TN / A37H 14TN / A37C 18TN / A37J 14TN / A37K 14TN / A36CB 10TN / M36C 10RD / M36CA 6RD / M36CB 10RD / M37-G 10WH / M37GA 6WH / M37GB 10WH / M11-GE 4WH / M11-GA 10WH / M37C 12TN / M36D 14TN M37E 14TN / M37J 12TN / M37K 12TN / M37H 12TN / GROUND SPLICE (6740) CH3_51 / FWD GROUND (2GA) / REAR/FWD CHASSIS FUEL SYSTEM INTERCONNECT (9100) CH5_14 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 232 / GASOLINE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/ F-2018-GAS-ENG

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 273 | printed page 233 | section 5.17
5.17. GASOLINE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/
Figure 233 GASOLINE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/ F-2018-GAS-ENG (CONT.)

Components: CONNECTOR (9125); CONNECTOR (9127); FUEL SYSTEM INTERCONNECT (9100); GAS FUEL PUMP (9123); PLATFORM (1700); PRESSURE SENSOR (9120); SPLICE (9126)
Wires (circuit gauge+color): M36CB 10RD; M36D 14TN; M37C 12TN; M37E 14TN; M37GB 10WH; M37H 12TN; M37J 12TN; M37K 12TN; R36C 10TN; R36CA 6RD; R36CB 10TN; R36D 14TN; R37C 18TN; R37CA 12TN; R37E 14TN; R37G 10GY; R37GA 6GY; R37GB 16GY; R37GC 10GY; R37GD 6GY; R37GE 10GY; R37GG 10GY; R37GGA 6GY; R37GGB 10GY; R37H 16TN; R37J 16TN; R37K 16TN
See also sheets: CH5_13
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.17. GASOLINE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/ F-2018-GAS-ENG (CONT.), P. 14 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090656 NO. RELEASE NO. 95885P 19DEC20 / CHAPTER 5 GASOLINE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/F-2018-GAS-ENG (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / VENT VALVE CANNISTER CONNECTOR (9127) / GROUND SPLICE (9126) A / @ W/60 GA FUEL TANK % W/60 OR 100 GA FUEL TANK NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / %R37C 18TN / %R37GB 16GY / @R37G 10GY %R37G 10GY R37GC 10GY R37GG 10GY / R36CA 6RD / GAS FUEL PUMP (9123) / R37GGB 10GY R36CB 10TN / R37E 14TN / R36D 14TN / GAS FUEL SUPPLY PRESSURE SENSOR (9120) / R37H 16TN R37J 16TN R37K 16TN / VENT VALVE CANNISTER CONNECTOR (9125) A / @R37GB 16GY / @R37C 18TN / @R37GA 6GY / @R37CA 12TN / %R37GA 6GY / R37GGA 6GY / R37GD 6GY / R36C 10TN R37GE 10GY / %R37CA 12TN / FWD CHASSIS/ PLATFORM (1700) CH5_13 / M36D 14TN / M37E 14TN M36CB 10RD M37GB 10WH M37H 12TN M37J 12TN M37K 12TN / REAR/FWD CHASSIS FUEL SYSTEM INTERCONNECT (9100) / M37C 12TN / Figure 233 / GASOLINE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/ F-2018-GAS-ENG (CONT.)

5.18. GASOLINE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/
Figure 234 GASOLINE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/ F-2018-GAS-ENG (CONT.)

Components: CHASSIS (1700); CONNECTOR (6021); ECM FUSE (4108); ENGINE (1701); FUSE (4045); RELAY (4011); RELAY (4103)
Wires (circuit gauge+color): A36CB 10TN; A37C 18TN; K10-GC 10WH; K10-GD 10WH; K10D-G 18WH; K10E-G 18WH; K37A 12RD; K37B 12RD; K37D 14RD; K37DC 18TN; K37DS 12TN; K37E 14RD; K37EC 18TN; K37ES 12RD; K37ET 10RD; K97KB 12RD
See also sheets: CH11_13, CH11_14, CH3_63, CH5_13
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.18. GASOLINE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/ F-2018-GAS-ENG (CONT.), P. 15 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090656 NO. RELEASE NO. 95885P 19DEC20 / CHAPTER 5 GASOLINE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/F-2018-GAS-ENG (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PLATFORM/ ENGINE (1701) 69 / K37DS 12TN / FUEL PUMP RELAY (4103) / VEHICLE INTERFACE CONNECTOR (6021) CH11_13 / K37DC 18TN 1 30 / K10D-G 18WH / 85 5 K37D 14RD / K37EC 18TN / K37ES 12RD / K37ET 10RD / 87A 3 K10E-G 18WH / FUEL SUPPLY VALVE RELAY (4011) / K37E 14RD / UPPER MEGA FUSE STUD FUEL SYSTEM (@4000B/#4000E) FUSE (4045) K37A 12RD A B / K10-GC 10WH / UPPER GROUND STUD (3G) CH3_63 / A37C 18TN / A36CB 10TN / PLATFORM/ FORWARD CHASSIS (1700) CH5_13 / K37B 12RD / @ W/FREON COMPRESSOR WIRING # N/FREON COMPRESSOR WIRING / K10-GD 10WH / 1 30 / 2 86 / 85 5 / 2 86 / 87A 3 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / K97KB 12RD / ECM FUSE (4108) CH11_14 / Figure 234 / GASOLINE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/ F-2018-GAS-ENG (CONT.)

5.19. PROPANE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/
Figure 235 PROPANE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/ F-2018-PROPANE-ENG

Components: CHASSIS (1700); CHASSIS (9100/9100); CONNECTOR (6022); CONTROLLER (1602); FUEL PUMP RELAY (4103); FWD CHASSSIS (1700); GROUND SPLICE (6740); INTERCONNECT (9101); PLATFORM (1701); PLATFORM (1703C1/1703); VALVE RELAY (4011); VALVE RELAY (4016)
Wires (circuit gauge+color): A171JPS 18GY; A171L 18TN; A171LA 18TN; A171M 18TN; A171MA 18TN; A171PS 18GY; A171PSJ 18GY; A36CB 10TN; A36D 14TN; A37A 12TN; A37B 14TN; A37E 14TN; A37F 14TN; A37H 14TN; A37J 14TN; A37K 14TN; K36D 14TN; K36DB 16TN; K36E 14TN; K36EB 16TN; K37CS 14TN; K37DS 12TN; K37ET 10RD; K37F 14TN; K37FB 16TN; K37H 14TN; K37HB 16TN; K37J 14TN; K37JB 16TN; K37K 14TN; K37KB 16TN; M148-G 10WH; M148-GA 6WH; M148-GB 10WH; M148A 12TN; M148B 14TN; M148C 10RD; M148CA 6RD; M148CB 10RD; M148D 14TN; M148E 14TN; M148F 14TN; M148H 12TN; M148J 12TN; M148K 12TN; M148L 18TN; M148M 18TN; R148-G 10TN; R148-GA 6WH; R148-GB 10TN; R148A 12TN; R148B 14TN; R148C 10TN; R148CA 6RD; R148CB 10TN; R148D 14TN; R148E 14TN; R148F 14TN; R148H 12TN; R148J 12TN; R148K 12TN; R148L 18TN; R148M 18TN
See also sheets: CH3_51, CH5_17
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.19. PROPANE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/ F-2018-PROPANE-ENG, P. 16 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090656 NO. 95885P 20DEC20 / CHAPTER 5 PROPANE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/F-2018-PROP-ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FUEL SYSTEM INTERCONNECT (9101) / R148A 12TN / PLATFORM/FWD CHASSIS (1700) 71 / K37DS 12TN / R148B 14TN / R148D 14TN / R148E 14TN / R148F 14TN / R148H 12TN / R148J 12TN R148K 12TN / FWD/REAR CHASSIS (9100/9100) / ENGINE/ PLATFORM (1701) / M148A 12TN / M148B 14TN / M148D 14TN / M148E 14TN / M148F 14TN / M148H 12TN / M148J 12TN M148K 12TN / A37A 12TN / A37B 14TN / A36D 14TN / A37E 14TN / A37F 14TN / A37H 14TN / A37J 14TN A37K 14TN / K37CS 14TN / K36D 14TN / K36E 14TN / K37F 14TN / K37H 14TN / K37JB K37J 16TN 14TN K37KB K37K 16TN 14TN J5-TAN BODY CONTROLLER (1602) / FUEL SUPPLY VALVE RELAY (4011) CH5_17 / FUEL RETURN VALVE RELAY (4016) CH5_17 / R148CB 10TN / R148CA 6RD / R148C 10TN / M148C 10RD / M148CA 6RD / FWD/REAR CHASSIS (9100/9100) 1 / R148-G 10TN / R148-GA 6WH / R148-GB 10TN / M148-G 10WH / M148-GA 6WH / FUEL INTERFACE CONNECTOR (6022) / K36EB 16TN / K37FB 16TN / K37HB 16TN / K36DB 16TN / R148L 18TN / M148L 18TN / A171L 18TN / A171LA 18TN / R148M 18TN / M148M 18TN / A171M 18TN / A171MA 18TN / B14 A171JPS 18GY A171PS 18GY / ELEC PANEL/ PLATFORM (1703C1/1703) B15 A171PSJ 18GY / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 235 / PROPANE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/ F-2018-PROPANE-ENG

5.20. PROPANE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/
Figure 236 PROPANE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/ F-2018-PROPANE-ENG

Components: CHASSIS (1700); CONNECTOR (6021); ENGINE (1701); FUSE (4045); RELAY (4011); RELAY (4016); RELAY (4103)
Wires (circuit gauge+color): A36CB 10TN; A37A 12TN; A37B 14TN; K10-GC 10WH; K10-GD 10WH; K10C-G 18WH; K10D-G 18WH; K10E-G 18WH; K37A 12RD; K37B 12RD; K37C 14RD; K37CC 18TN; K37CS 14TN; K37D 14RD; K37DC 18TN; K37DS 12TN; K37E 14RD; K37EC 18TN; K37ES 12RD; K37ET 10RD
See also sheets: CH11_10, CH3_62, CH5_16
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 5.20. PROPANE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/ F-2018-PROPANE-ENG (CONT.), P. 17 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090656 NO. RELEASE NO. 95885P 20DEC20 / CHAPTER 5 PROPANE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/F-2018-PROP-ENG (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PLATFORM/ ENGINE (1701) 75 / K37DS 12TN / FUEL PUMP RELAY (4103) / VEHICLE INTERFACE CONNECTOR (6021) CH11_10 / K37DC 18TN / K10D-G 18WH / K37D 14RD / K37EC 18TN / K37ES 12RD / K10E-G 18WH / FUEL SUPPLY VALVE RELAY (4011) / K10C-G 18WH / K37C 14RD / FUEL RETURN VALVE RELAY (4016) / K37E 14RD / K37CC 18TN / K37A 12RD / UPPER MEGA FUSE STUD (@4000B/#4000E) / FUEL SYSTEM FUSE (4045) A B / K10-GC 10WH / UPPER GROUND STUD (3G) CH3_62 / A37A 12TN A37B 14TN A36CB 10TN / N/ENHANCED VCM FUNCTION @K10-GD 10WH / PLATFORM/ FORWARD CHASSIS (1700) CH5_16 / K37B 12RD / K37CS 14TN K37ET 10RD / @ N/ENHANCED VCM FUNCTION * W/ENHANCED VCM FUNCTION / #K10-GC 10WH ENHANCED VCM FUNCTION / 1 30 / 2 86 / 87A 3 / 85 5 / 1 30 / 87A 3 / 2 86 / 85 5 / 2 86 / 1 30 / 85 5 / 87A 3 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 236 / PROPANE FUEL TANK WITH AIR AND HYDRAULIC BRAKES W/ F-2018-PROPANE-ENG (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 277 | printed page 237 | section
PUPIL WARNING LIGHT ACTIVATION (CHAPTER 6)
Figure 237 PUPIL WARNING LIGHT CONTROLS WITH RED LIGHT

Components: FRONT CAP (10000); J1-12 WAY BODY CONTROLLER (1603); L RED INPUT (1080); LEFT BODY (10400A/B); LT SPLICE (11601); MODULE (10500); PLATFORM (1702); R RED INPUT (1082); REAR CAP (10406); RED WARNING LT (10112); RED WARNING LT (10117); SPLICE (10360R)
Wires (circuit gauge+color): A89LB 14OR; A89LF 14OR; A89RB 14OR; A89RF 14OR; B128LR 16OR; B128RR 16OR; B89AB 16OR; B89AC 16OR; B89E 16OR; B89F 16OR; B89G 16OR; B89H 16OR; B89LFR 16OR; B89LRR 16OR; B89N 16OR; B89P 16OR; B89R 16OR; B89RFR 16OR; B89RRR 16OR; B89S 16OR; B89T 16OR; B89U 16OR; D89LR-M 16OR; D89RR-M 16OR; E89LR-M 16OR; E89RR-M 16OR
See also sheets: CH6_06, CH6_08, CH6_11, CH6_13, CH7_13, CH9_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / PUPIL WARNING LIGHT ACTIVATION (CHAPTER 6) / 6.1. PUPIL WARNING LIGHT CONTROLS WITH RED LIGHT, P. 1 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090657 NO. 95885P 20DEC20 / CHAPTER 6 PUPIL WARNING LIGHT CONTROLS W/RED LIGHT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / RED PWL SPLICE (10360R) A M B L K / F E D / J H G / ELEC PANEL/ PLATFORM 7 (1702) / %B128LR 16OR B89LFR 16OR B89RFR 16OR / B89T 16OR B89P 16OR / B89S 16OR B89N 16OR / B89LRR 16OR @B89AC 16OR B89U 16OR B89RRR 16OR @B89AB 16OR B89R 16OR / B89E 16OR / B89G 16OR / B89H 16OR / B89F 16OR / ELEC PANEL/ LEFT BODY (10400A/B) / J1-12 WAY BODY CONTROLLER (1603) / L RIGHT REAR RED PWL J LEFT REAR RED PWL H LEFT FRONT RED PWL F RIGHT FRONT RED PWL / A89RB 14OR A89LB 14OR A89LF 14OR A89RF 14OR / STOP ARM WARNING LT SPLICE (11601) CH9_02 / LEFT BODY/ REAR CAP (10406) C4 D89LR-M 16OR C6 D89RR-M 16OR / E89LR-M E89RR-M 16OR 16OR / B89E 16OR / INPOWER STROBE MODULE (10500) CH7_13 / L RED INPUT (1080) CH6_11 ELEC PANEL/ FRONT CAP (10000) CH6_06 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / RED WARNING LT (10112) CH6_08 RED WARNING LT (10117) CH6_08 / R RED INPUT (1082) CH6_11 / %B128RR 16OR / ELEC PANEL/ LEFT BODY (10400A/B) CH6_13,14 / @ W/DRIVER ALERT SIGN % W/SW PANEL INDICATOR / Figure 237 / PUPIL WARNING LIGHT CONTROLS WITH RED LIGHT

6.2. PUPIL WARNING LIGHT CONTROLS WITH AMBER LIGHT, P. 2
Figure 238 PUPIL WARNING LIGHT CONTROLS WITH AMBER LIGHT

Components: ALARM MODULE (11627); ELEC PANEL/FRONT CAP (10000); INDICATOR (1060); INPUT (1087); J1-12 WAY BODY CONTROLLER (1603); J2-10 WAY BODY CONTROLLER (1604); L AMBER INPUT (1085); LEFT BODY (10400A/B); LIGHT (10113); LIGHT (10118); MODULE (10500); PLATFORM (1702); REAR CAP (10406); SPLICE (10360A)
Wires (circuit gauge+color): A89JJ 14OR; A89SS 14OR; A89YY 14OR; A89ZX 18OR; A89ZY 14OR; A89ZZ 14OR; B119S 18GY; B128LA 16OR; B128RA 16OR; B89A 16OR; B89AA 16OR; B89AD 16OR; B89B 16OR; B89C 16OR; B89D 16OR; B89F 16OR; B89J 16OR; B89K 16OR; B89L 16OR; B89LFA 16OR; B89LRA 16OR; B89M 16OR; B89RFA 16OR; B89RRA 16OR; D89LA-M 16OR; D89RA-M 16OR; E89LA-M 16OR; E89RA-M 16OR
See also sheets: CH18_40, CH6_06, CH6_08, CH6_10, CH6_11, CH6_13, CH7_13
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.2. PUPIL WARNING LIGHT CONTROLS WITH AMBER LIGHT, P. 2 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090657 95885P 20DEC20 / CHAPTER 6 PUPIL WARNING LIGHT CONTROLS W/AMBER LIGHT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/ LEFT BODY (10400A/B) / J H G / F E D / B89F 16OR / ELEC PANEL/ PLATFORM (1702) / B89A 16OR / B89D 16OR B89B 16OR B89C 16OR / INPOWER STROBE MODULE (10500) CH7_13 / LEFT BODY/ REAR CAP C3 (10406) / D89RA-M 16OR / D89LA-M 16OR / C LEFT FRONT AMBER PWL K RIGHT REAR AMBER PWL G LEFT REAR AMBER PWL / J2-10 WAY BODY CONTROLLER (1604) RIGHT FRONT J AMBER PWL / A89YY 14OR A89JJ 14OR A89SS 14OR / J1-12 WAY BODY CONTROLLER (1603) / %A89ZZ 14OR / ELEC PANEL/ LEFT BODY (10400A/B) CH6_13,14 / ELEC PANEL/FRONT CAP (10000) CH6_06 / E89LA-M 16OR / E89RA-M 16OR / @A89ZZ 14OR / B128LA B89LFA 16OR 16OR / L AMBER INPUT (1085) CH6_11 / R AMBER INPUT (1087) CH6_11 / B128RA 16OR / B119S 18GY / WARNING (10113) WARNING (10118) AMBER CH6_08 CH6_08 LIGHT AMBER LIGHT / A89ZX 18OR / A89ZY 14OR / Figure 238 / PUPIL WARNING LIGHT CONTROLS WITH AMBER LIGHT

6.3. PUPIL WARNING LIGHT WITH 8 LAMP LIGHT MONITOR, P. 3
Figure 239 PUPIL WARNING LIGHT WITH 8 LAMP LIGHT MONITOR

Components: AMBER (10113); CONNECTOR A (10025A); CONNECTOR B (10025B); CONNECTOR D (10025D); FR CAP/ELEC PANEL (10000); FUSE (10305); FUSE B9-P (10302); L BODY (10400A/B); OUTPUT (1081/1086); OUTPUT (1083/1088); REAR CAP (10406); RED (10112); RH AMBER (10118); RH RED (10117); SPLICE (10010)
Wires (circuit gauge+color): B128 16LTBL; B89A 16OR; B89B 16OR; B89D 16OR; B89LA-M 16OR; B89LR-M 16OR; B89RA-M 16OR; B89RR-M 16OR; C128 16LTBL; C128-G 16WH; C89A-M 16OR; C89B-M 16OR; C89C-M 16OR; C89D-M 16OR; C89LA 16OR; C89LR 16OR; C89RA 16OR; C89RR 16OR; D89LA-M 16OR; D89LR-M 16OR; D89RA-M 16OR; D89RR-M 16OR; E89LA-M 16OR; E89LR-M 16OR; E89RA-M 16OR; E89RR-M 16OR
See also sheets: CH3_15, CH3_44, CH6_08, CH6_12
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.3. PUPIL WARNING LIGHT WITH 8 LAMP LIGHT MONITOR, P. 3 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090657 95885P 20DEC20 / CHAPTER 6 PUPIL WARNING LIGHT W/8 LAMP LIGHT MONITOR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / C89RA 16OR C89RR 16OR / C89A-M 16OR / C89B-M 16OR / C128-G 16WH / ELEC PANEL/ L BODY (10400A/B) C2 B89RA-M 16OR / B89RR-M 16OR / B89D 16OR B89D 16OR / LT MONITOR CONNECTOR D (10025D) / GROUND SPLICE (10010) CH3_44 FUSE (10305) CH3_94M FUSE B9-P (10302) CH3_15 / E89RA-M 16OR / E89RR-M 16OR / D89RR-M 16OR / D89RA-M 16OR / LEFT BODY/ REAR CAP (10406) C5 / LT MONITOR CONNECTOR A (10025A) / C128 16LTBL / #B128 16LTBL / FR CAP/ELEC PANEL (10000) B11 / C89LR 16OR C89LA 16OR / C89C-M 16OR / C89D-M 16OR / LEFT BODY/ REAR CAP (10406) C3 D89LA-M 16OR / B89LA-M 16OR / B89LR-M 16OR / E89LR-M 16OR / ELEC PANEL/ L BODY (10400A/B) B12 E89LA-M 16OR / B89B 16OR B89A 16OR / D89LR-M 16OR / LT MONITOR CONNECTOR B (10025B) / R RED/AMBER OUTPUT (1083/1088) CH6_12 / L RED/AMBER OUTPUT (1081/1086) CH6_12 / WARNING LIGHT RH AMBER (10118) CH6_08 / WARNING LIGHT RH RED (10117) CH6_08 / WARNING LIGHT AMBER (10113) CH6_08 / WARNING LIGHT RED (10112) CH6_08 * N/0508108 - NOT MTA FUSE BLOCK # W/0508108 - MTA FUSE BLOCK / *B128 16LTBL / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 239 / PUPIL WARNING LIGHT WITH 8 LAMP LIGHT MONITOR

6.4. PUPIL WARNING LIGHT WITH 8 LAMP LIGHT MONITOR (CONT.), P. 4
Figure 240 PUPIL WARNING LIGHT WITH 8 LAMP LIGHT MONITOR (CONT.)

Components: CONNECTOR A (10025A); CONNECTOR B (10025B); LEFT FRONT (10028); LEFT FRONT (10029); RIGHT FRONT (10030); RIGHT FRONT (10031); SPLICE (10010)
Wires (circuit gauge+color): C89-G 16WH; C89-GA 16WH; C89-GB 16WH; C89-GC 16WH; C89-GD 16WH; C89LA-M 16OR; C89LR-M 16OR; C89RA-M 16OR; C89RR-M 16OR
See also sheets: CH3_44
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.4. PUPIL WARNING LIGHT WITH 8 LAMP LIGHT MONITOR (CONT.), P. 4 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090657 NO. 95885P 20DEC20 / CHAPTER 6 PUPIL WARNING LIGHT W/8 LAMP LIGHT MONITOR (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / RED PWL RIGHT FRONT (10031) 1 C89RR-M 16OR C89-GD 16WH / C89-G 16WH / GROUND SPLICE (10010) CH3_44 / AMBER PWL RIGHT FRONT (10030) 1 C89RA-M 16OR C89-GC 16WH / RED PWL LEFT FRONT (10028) 1 / C89LR-M 16OR C89-GA 16WH / AMBER PWL LEFT FRONT (10029) 1 / C89LA-M 16OR C89-GB 16WH / LT MONITOR CONNECTOR A (10025A) / LT MONITOR CONNECTOR B (10025B) / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 240 / PUPIL WARNING LIGHT WITH 8 LAMP LIGHT MONITOR (CONT.)

6.5. PUPIL WARNING LIGHT CONTROLS WITHOUT LIGHT MONITOR, P. 5
Figure 241 PUPIL WARNING LIGHT CONTROLS WITHOUT LIGHT MONITOR

Components: AMBER PWL LEFT FRONT (10029); AMBER PWL RIGHT FRONT (10030); ELEC PANEL (10000); RED PWL LEFT FRONT (10028); RED PWL RIGHT FRONT (10031); SPLICE (10010)
Wires (circuit gauge+color): C89-G 16WH; C89-GA 16WH; C89-GB 16WH; C89-GC 16WH; C89-GD 16WH; C89LA 16OR; C89LR 16OR; C89RA 16OR; C89RR 16OR
See also sheets: CH3_44, CH6_09
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.5. PUPIL WARNING LIGHT CONTROLS WITHOUT LIGHT MONITOR, P. 5 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090657 95885P 20DEC20 / CHAPTER 6 PUPIL WARNING LIGHT CONTROLS N/LIGHT MONITOR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FRONT CAP/ ELEC PANEL (10000) CH6_09,12 / RED PWL RIGHT FRONT (10031) 1 / C89-GD 16WH @C89-GB 16WH AMBER PWL LEFT FRONT (10029) 1 / C89RR 16OR C89-G 16WH / GROUND SPLICE (10010) CH3_44 / C89-GB 16WH RED PWL LEFT FRONT (10028) 1 / C89LA 16OR / C89LR 16OR / C89-GA 16WH AMBER PWL RIGHT FRONT (10030) 1 / C89RA 16OR / C89-GC 16WH / @ W/4 LAMP WARNING LT / Figure 241 / PUPIL WARNING LIGHT CONTROLS WITHOUT LIGHT MONITOR

6.6. PUPIL WARNING LIGHT CONTROLS WITHOUT LIGHT MONITOR (CONT.), P. 6
Figure 242 PUPIL WARNING LIGHT CONTROLS WITHOUT LIGHT MONITOR (CONT.)

Components: ELEC PANEL/FR CAP (10000); SPLICE (10360A); SPLICE (10360R)
Wires (circuit gauge+color): B89LFA 16OR; B89LFR 16OR; B89RFA 16OR; B89RFR 16OR; C89LA 16OR; C89LR 16OR; C89RA 16OR; C89RR 16OR
See also sheets: CH6_01, CH6_02, CH6_07
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.6. PUPIL WARNING LIGHT CONTROLS WITHOUT LIGHT MONITOR (CONT.), P. 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090657 NO. 95885P 20DEC20 / CHAPTER 6 PUPIL WARNING LIGHT CONTROLS N/LIGHT MONITOR (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/FR CAP (10000) / C89LA 16OR / C89LR 16OR / C89RA 16OR / C89RR 16OR / B89LFR 16OR / B89RFR 16OR / B89LFA 16OR / B89RFA 16OR / AMBER PWL SPLICE (10360A) CH6_02 / RH/LH RED/AMBER WARN LIGHTS CH6_07 / RED PWL SPLICE (10360R) CH6_01 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 242 / PUPIL WARNING LIGHT CONTROLS WITHOUT LIGHT MONITOR (CONT.)

6.7. PUPIL WARNING LIGHT CONTROLS WITHOUT LIGHT MONITOR WITH ADDITIONAL WARNING LIGHT, P. 7
Figure 243 PUPIL WARNING LIGHT CONTROLS WITHOUT LIGHT MONITOR WITH ADDITIONAL

Components: AMBER PWL LEFT FRONT (10029); AMBER PWL RIGHT FRONT (10030); ELEC PANEL (10000); LEFT AMBER WARN LIGHT (10075); LEFT RED WARN LIGHT (10076); RED PWL LEFT FRONT (10028); RED PWL RIGHT FRONT (10031); RIGHT AMBER WARN LIGHT (10077); RIGHT RED WARN LIGHT (10078); SPLICE (10009); SPLICE (10010)
Wires (circuit gauge+color): C89-G 16WH; C89-GA 16WH; C89-GA 18WH; C89-GB 16WH; C89-GB 18WH; C89-GC 16WH; C89-GC 18WH; C89-GD 16WH; C89-GD 18WH; C89LA 16OR; C89LAA 16OR; C89LAB 18OR; C89LR 16OR; C89LRA 16OR; C89LRB 18OR; C89RA 16OR; C89RAA 16OR; C89RAB 18OR; C89RR 16OR; C89RRA 16OR; C89RRB 18OR
See also sheets: CH3_43, CH3_44, CH6_06
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.7. PUPIL WARNING LIGHT CONTROLS WITHOUT LIGHT MONITOR WITH ADDITIONAL WARNING LIGHT, P. 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090657 NO. 95885P 20DEC20 / CHAPTER 6 PUPIL WARNING LIGHT CONTROLS N/LIGHT MONITOR W/ADDITIONAL WARNING LIGHT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / RIGHT RED WARN LIGHT (10078) A C89RRB 18OR C89-GD 18WH LEFT AMBER WARN LIGHT (10075) A C89LAB 18OR C89-GA 18WH AMBER PWL LEFT FRONT (10029) 1 / C89-G 16WH / GROUND SPLICE (10009) CH3_43 / C89LA 16OR / C89LR 16OR / C89RA 16OR / C89RAB 18OR C89-GC 18WH / C89RR 16OR / C89RRA 16OR C89-GD 16WH / AMBER PWL RIGHT FRONT (10030) 1 C89RAA 16OR C89-GC 16WH / GROUND SPLICE C89-G (10010) 16WH CH3_44 NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / RED PWL RIGHT FRONT (10031) 1 / FRONT CAP/ ELEC PANEL (10000) CH6_06 / Figure 243 / PUPIL WARNING LIGHT CONTROLS WITHOUT LIGHT MONITOR WITH ADDITIONAL WARNING LIGHT

6.8. PUPIL WARNING LIGHT WITH REAR LIGHTS, P. 8
Figure 244 PUPIL WARNING LIGHT WITH REAR LIGHTS

Components: AMBER WARNING LIGHT (10113); AMBER WARNING LIGHT (10118); GROUND SPLICE (10160); LEFT BODY/REAR CAP (10406); RED WARNING LIGHT (10112); RED WARNING LIGHT (10117)
Wires (circuit gauge+color): D89-G 16WH; D89LA-G 16WH; D89LA-M 16OR; D89LR-G 16WH; D89LR-M 16OR; D89RA-G 16WH; D89RA-M 16OR; D89RR-G 16WH; D89RR-M 16OR
See also sheets: CH3_45, CH6_01, CH6_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.8. PUPIL WARNING LIGHT WITH REAR LIGHTS, P. 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090657 95885P 20DEC20 / CHAPTER 6 PUPIL WARNING LIGHT W/REAR LIGHTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / RED WARNING LIGHT (10112) 1 / AMBER WARNING LIGHT (10113) 1 / RED WARNING LIGHT (10117) 2 / AMBER WARNING LIGHT (10118) 2 / D89LR-M 16OR D89LR-G 16WH / D89LA-M 16OR D89LA-G 16WH / D89RR-G 16WH / D89RA-G 16WH D89RA-M 16OR / LEFT REAR RED PWL LAMP / LEFT REAR AMBER PWL LAMP / RIGHT REAR RED PWL LAMP / RIGHT REAR AMBER PWL LAMP / D89-G 16WH / LEFT REAR CAP GROUND SPLICE (10160) CH3_45 / LEFT BODY/REAR CAP (10406) CH6_01,03,09,12 / LEFT BODY/REAR CAP (10406) CH6_02,03,09,12 / LEFT BODY/REAR CAP (10406) CH6_02,03,09,12 / D89RR-M 16OR / LEFT BODY/REAR CAP (10406) CH6_01,03,09,12 / NOTE: R/D 10112 & 10117 USED W/STANDARD & W/4 LAMP WARN LIGHT. NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 244 / PUPIL WARNING LIGHT WITH REAR LIGHTS

6.9. PUPIL WARNING LIGHT WITH RED AND BLUE LIGHT WITH 9, P. 9
Figure 245 PUPIL WARNING LIGHT WITH RED AND BLUE LIGHT WITH 9

Components: AMBER (10113); CONTROLLER (1603); FRONT CAP (10000); FUSE 38 (10304); FUSE B6-F (10304-F1); INDICATOR (1060); LEFT BODY (10400B/10400); LEFT FRONT (10028); LEFT FRONT (10029); PLATFORM (1702/1702); REAR CAP (10406); RED (10112); RIGHT AMBER (10118); RIGHT FRONT (10030); RIGHT FRONT (10031); RIGHT RED (10117); SPLICE (10334)
Wires (circuit gauge+color): A89LB 14OR; A89LF 14OR; A89RB 14OR; A89RF 14OR; A89RH 14OR; A89RK 18OR; B89 14OR; B89AL 14OR; B89G 16WH; B89GA 16WH; B89GG 16WH; B89H 14OR; B89HH 14OR; B89L 14OR; B89LA 16OR; B89LA-M 16OR; B89LB 14OR; B89LF 14OR; B89LR 16OR; B89LR-M 16OR; B89LRR 18OR; B89RA 16OR; B89RA-M 16OR; B89RB 14OR; B89RF 14OR; B89RM 18OR; B89RR 16OR; B89RR-M 16OR; C89LA 16OR; C89LR 16OR; C89RA 16OR; C89RR 16OR; D89LA-M 16OR; D89LR-M 16OR; D89RA-M 16OR; D89RR-M 16OR; E89LA-M 16OR; E89LR-M 16OR; E89RA-M 16OR; E89RR-M 16OR
See also sheets: CH3_10, CH3_34, CH6_05, CH6_08, CH6_10
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.9. PUPIL WARNING LIGHT WITH RED AND BLUE LIGHT WITH 9, P. 9 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090657 95885P 20DEC20 / CHAPTER 6 PUPIL WARNING LIGHT W/RED AND BLUE LIGHT W/9 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / #B1 B89RR TEMP 16OR SENSOR RELAY *(10310-R3) #F2 #(10310) #E2 *86 *30 / B89RF 14OR B89RM 18OR *85 #E1 / B89G 16WH ELEC PANEL/ PLATFORM (1702/1702) !A89RF 14OR 7 / RED/ AMBER INDICATOR (1060) CH6_10 GORUND SPLICE (10334) CH3_34,95F J1-12 WAY BODY CONTROLLER !A89RH (1603) 14OR &A89RF F 14OR / B89RA-M 16OR / ELEC PANEL/ LEFT BODY/ LEFT BODY REAR CAP (10400B/10400) (10406) C2 C5 E89RA-M D89RA-M 16OR 16OR / B89GA 16WH / WARNING LIGHT RIGHT AMBER (10118) CH6_08 WARNING LIGHT RIGHT RED (10117) CH6_08 WARNING LIGHT AMBER (10113) CH6_08 WARNING LIGHT RED (10112) CH6_08 / B89LA-M 16OR / B89AL 14OR / B89LB 14OR / B89LF 14OR / B89L 14OR / B89LA 16OR / ELEC PANEL/ FRONT CAP (10000) B9 / B89LR 16OR / A89LB 14OR / A89LF 14OR / B89RB 14OR / B89RR-M 16OR / E89RR-M 16OR / A89RB 14OR / B89H 14OR / B89HH 14OR / *B89 14OR / FUSE 38 (10304) CH3_94J FUSE B6-F (10304-F1) CH3_10 / STOP ARM RELAY *(10310-R1) #(10310) #A2 #B2 *86 *30 / *85 #A1 / B89LRR 18OR / B89GG 16WH / B89LR-M 16OR / E89LA-M 16OR / E89LR-M 16OR / B89RA 16OR / C89RA 16OR / RED PWL RIGHT FRONT (10031) CH6_05 AMBER PWL LEFT FRONT (10029) CH6_05 RED PWL LEFT FRONT (10028) CH6_05 AMBER PWL RIGHT FRONT (10030) CH6_05 / C89LR 16OR / C89LA 16OR / C89RR 16OR / D89RR-M 16OR / D89LA-M 16OR / D89LR-M 16OR / A89RK 18OR / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / #B89 14OR / Figure 245 / PUPIL WARNING LIGHT WITH RED AND BLUE LIGHT WITH 9

6.10. PUPIL WARNING LIGHT INDICATORS WITH RIGHT LIGHT, P. 10
Figure 246 PUPIL WARNING LIGHT INDICATORS WITH RIGHT LIGHT

Components: CONTROLLER (1603); CONTROLLER (1604); INDICATORS (1060)
Wires (circuit gauge+color): A89RH 14OR; A89RK 18OR; A89RK-G 18WH; A89ZX 18OR; A89ZX-G 18WH; A89ZY 14OR
See also sheets: CH3_33, CH6_02, CH6_09
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.10. PUPIL WARNING LIGHT INDICATORS WITH RIGHT LIGHT, P. 10 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090657 95885P 20DEC20 / CHAPTER 6 PUPIL WARNING LIGHT INDICATORS W/RIGHT LIGHT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A89RK 18OR / RED/AMBER INDICATORS (1060) / J1-12 WAY BODY CONTROLLER (1603) CH6_09 / A89RH 14OR / A89ZX 18OR / A89ZY 14OR / J2-10 WAY BODY CONTROLLER (1604) CH6_02 / A89ZX-G 18WH / A89RK-G 18WH / GROUND SPLICE #1 (1003B) CH3_33,95C / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 246 / PUPIL WARNING LIGHT INDICATORS WITH RIGHT LIGHT

6.11. PUPIL WARNING LIGHTS WITH SWITCH PANEL INDICATOR MONITOR, P. 11
Figure 247 PUPIL WARNING LIGHTS WITH SWITCH PANEL INDICATOR MONITOR

Components: ELEC PANEL/PLATFORM (1703); FUSE B9-K (10302); FUSE B9-P (10302); FUSE F57-F2 (10305); FUSE F57-H3 (10305); GROUND SPLICE (10334); L RED INPUT (1089); RED/AMBER INDICATORS (1060A); SPLICE (10360A); SPLICE (10360R)
Wires (circuit gauge+color): A89RK 18OR; A89RK-G 18WH; A89ZX 18OR; A89ZX-G 18WH; B128 16LTBL; B128-G 16WH; B128A 16LTBL; B128LA 16OR; B128LR 16OR; B128R 16LTBL; B128RA 16OR; B128RR 16OR
See also sheets: CH3_15, CH3_33, CH3_34, CH6_01, CH6_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.11. PUPIL WARNING LIGHTS WITH SWITCH PANEL INDICATOR MONITOR, P. 11 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090657 95885P 20DEC20 / CHAPTER 6 PUPIL WARNING LIGHTS W/SWITCH PANEL INDICATOR MONITOR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B128-G 16WH / B128RA 16OR / B128RR 16OR / @A89ZX 18OR / (1082) A / B128A 16LTBL / B128LA 16OR / (1079) LT MONITOR POWER / (1090) GROUND / (1089) AMBER PILOT LT / (1085) L AMBER INPUT / (1087) R AMBER INPUT / R RED INPUT / #B128 16LTBL / B128R 16LTBL / @A89RK 18OR / B128LR 16OR / ELEC PANEL/PLATFORM (1703) / @A89ZX-G 18WH / @A89RK-G 18WH / GROUND SPLICE#1 (1003B) CH3_33,95C / RED PWL SPLICE (10360R) CH6_01 / AMBER PWL SPLICE (10360A) CH6_02 / GROUND SPLICE (10334) CH3_34,95F / L RED INPUT / RED PILOT LT / RED/AMBER INDICATORS (1060A) / #B128 16LTBL / *B128 16LTBL / Figure 247 / PUPIL WARNING LIGHTS WITH SWITCH PANEL INDICATOR MONITOR

6.12. PUPIL WARNING LIGHTS WITH SWITCH PANEL INDICATOR MONITOR (CONT.), P. 12
Figure 248 PUPIL WARNING LIGHTS WITH SWITCH PANEL INDICATOR MONITOR (CONT.)

Components: AMBER WARN LT (10113); AMBER WARN LT (10118); CONNECTOR A (10025A); CONNECTOR B (10025B); FRONT CAP (10000); L BODY (10400A/B); REAR CAP (10406); RED WARN LT (10112); RED WARN LT (10117)
Wires (circuit gauge+color): B128LAA 16LTBL; B128LRA 16LTBL; B128RAA 16LTBL; B128RRA 16LTBL; B89A 16OR; B89B 16OR; B89C 16OR; B89D 16OR; B89E 16OR; B89F 16OR; B89H 16OR; B89J 16OR; C89LA 16OR; C89LR 16OR; C89RA 16OR; C89RR 16OR; D89LA-M 16OR; D89LR-M 16OR; D89RA-M 16OR; D89RR-M 16OR; E89LA-M 16OR; E89LR-M 16OR; E89RA-M 16OR; E89RR-M 16OR
See also sheets: CH6_03, CH6_05, CH6_08
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.12. PUPIL WARNING LIGHTS WITH SWITCH PANEL INDICATOR MONITOR (CONT.), P. 12 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090657 95885P 20DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / L AMBER O/P A / (1086) B128LAA 16LTBL / B89B 16OR / (1081) B128LRA 16LTBL / (1083) B128RRA 16LTBL / L RED O/P / R RED O/P / R AMBER O/P A / (1088) B128RAA 16LTBL / B89D 16OR / ELEC PANEL/ FRONT CAP (10000) CH6_6B / B89A 16OR / B89C 16OR / C89LA 16OR / C89LR 16OR / C89RA 16OR / C89RR 16OR / LEFT BODY/ REAR CAP (10406) / ELEC PANEL/ L BODY (10400A/B) / E89LA-M 16OR / E89LR-M 16OR / E89RA-M 16OR / E89RR-M 16OR / D89LA-M 16OR / B89E 16OR / B89F 16OR / B89J 16OR / B89H 16OR / AMBER WARN LT (10113) CH6_08 / D89LR-M 16OR / D89RA-M 16OR / D89RR-M 16OR / RED WARN LT (10112) CH6_08 / AMBER WARN LT (10118) CH6_08 / RED WARN LT (10117) CH6_08 / LT MONITER CONNECTOR B (10025B) CH6_03 / LT MONITOR CONNECTOR A (10025A) CH6_03 / RIGHT/ LEFT FRONT RED/ AMBER LIGHTS CH6_05 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 248 / PUPIL WARNING LIGHTS WITH SWITCH PANEL INDICATOR MONITOR (CONT.)

6.13. PUPIL WARNING LIGHT WITH DRIVER ALERT SIGN WITH ABOVE BUMPER, P. 13
Figure 249 PUPIL WARNING LIGHT WITH DRIVER ALERT SIGN WITH ABOVE BUMPER

Components: L BODY (10400A/B); LOWER RIGHT WARNING LIGHT (10173); REAR CAP (10406); SIGN (10128); SPLICE (10160); SPLICE (10161); SPLICE (10360A); SPLICE (10360R); WARNING LIGHT (10172)
Wires (circuit gauge+color): B89AA 16OR; B89AB 16OR; B89AC 16OR; B89AD 16OR; D11-GF 16WH; D89-GA 16WH; D89-GB 16WH; D89-GC 16WH; D89LA 16OR; D89RA 16OR
See also sheets: CH3_45, CH3_46, CH6_01, CH6_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.13. PUPIL WARNING LIGHT WITH DRIVER ALERT SIGN WITH ABOVE BUMPER, P. 13 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090657 NO. 95885P 20DEC20 / CHAPTER 6 PUPIL WARNING LIGHT W/DRIVER ALERT SIGN W/ABOVE BUMPER / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / %D89RR @D89RR 160R 160R / @D89RRA 160R D89-GA 16WH / @D89LRB 160R / LEFT BODY/ D7 REAR CAP (10406) / %D89LR @D89LR 160R 160R / LOWER RIGHT WARNING LIGHT (10173) NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / LOWER LEFT WARNING LIGHT (10172) 1 / @D89LRA D89-GB 160R 16WH / @D89RRB 160R / E89RR 160R / E89LR 160R / (10360R) PWL SPLICE CH6_01 RED / @ PWL ABOVE BUMPER W/DRIVER ALERT SIGN % PWL ABOVE BUMPER / D89-GC 16WH / LEFT REAR CAP GROUND SPLICE (10160) CH3_45 / RH REAR CAP GROUND SPLICE (10161) CH3_46 / D11-GF 16WH / D89RA 16OR / D89LA 16OR / E89RA 160R / E89LA 160R / B89AB 16OR / B89AC 16OR / B89AA 16OR / B89AD 16OR / PWL (10360A) SPLICE CH6_02 AMBER / CAUTION DO NOT PASS STOPPING / DRIVERS ALERT SIGN (10128) / ELEC PANEL/ L BODY (10400A/B) / Figure 249 / PUPIL WARNING LIGHT WITH DRIVER ALERT SIGN WITH ABOVE BUMPER

6.14. PUPIL WARNING LIGHT WITH DRIVER ALERT SIGN, P. 14
Figure 250 PUPIL WARNING LIGHT WITH DRIVER ALERT SIGN

Components: BODY (10406); GROUND SPLICE (10161); L BODY/REAR CAP (10406); PANEL (10400A/B); SIGN (10128); SPLICE (10360A); SPLICE (10360R)
Wires (circuit gauge+color): B89AA 16OR; B89AB 16OR; B89AC 16OR; B89AD 16OR; D11-GF 16WH; D57B 16LTGN; D71 16LTBL; D89LR 16OR; E89LA 16OR; E89RA 16OR; E89RR 16OR
See also sheets: CH3_46, CH6_01, CH6_02, CH7_01, CH7_18
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.14. PUPIL WARNING LIGHT WITH DRIVER ALERT SIGN, P. 14 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090657 95885P 20DEC20 / CHAPTER 6 PUPIL WARNING LIGHT W/DRIVER ALERT SIGN / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / D89RR 160R / D89LA 160R / DRIVERS ALERT SIGN (10128) / D89RA 160R / D11-GF 16WH / B89AC 16OR / L BODY/REAR CAP (10406) CH7_18 REAR CAP/LEFT BODY (10406) / LEFT BODY/ELEC PANEL (10400A/B) / E89LR 160R / B89AB 16OR / E89RR 16OR / D89LR 16OR / AMBER PWL SPLICE (10360A) CH6_02 / B89AA 16OR / B89AD 16OR / E89RA 16OR / E89LA 16OR / RED PWL SPLICE (10360R) CH6_01 / CAUTION DO NOT PASS STOPPING / 16YL D56 / 16LTGN D57B / L BODY/REAR CAP (10406) CH7_01,05,5A RH REAR CAP GROUND SPLICE (10161) CH3_46 / 16LTBL D71 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 250 / PUPIL WARNING LIGHT WITH DRIVER ALERT SIGN

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 291 | printed page 251 | section 6.15
6.15. FLASHER SYSTEM MASTER SWITCH EFFECTS, P. 15
Figure 251 FLASHER SYSTEM MASTER SWITCH EFFECTS

Components: DOOR CONTROL (10200); ELECTRIC (10203A); FLASHER CANCEL (10239); J5-TAN BODY CONTROLLER (1602); PLATFORM (1702); PWL RELAY (10308); PWL RELAY (10308-R3); RELAY COIL (10364); SPLICE (10327/10330); SPLICE (10330); SWITCH (10236); ZVR SPLICE (10350A)
Wires (circuit gauge+color): A89KK 18OR; B123A 18GY; B123A 18LTGN; B123A 18OR; B123B 18GY; B123B 18LTGN; B123B 18OR; B123F 18LTGN; B123T 18GY; B62-GAC 18WH; B62-GAD 18WH; B62AC 18DKBL; B62AD 18DKBL; B9H 18GY
See also sheets: CH15_24, CH16_01, CH16_23, CH3_29, CH3_60, CH8_29, CH8_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.15. FLASHER SYSTEM MASTER SWITCH EFFECTS, P. 15 / CHAPTER 6 FLASHER SYSTEM MASTER SWITCH EFFECTS / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090657 95885P 20DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/ PLATFORM (1702) 60 A89KK 18OR / B123F 18LTGN B9H 18GY #B123A 18LTGN ##B123T 18GY %%B123B %%B123B 18LTGN 18LTGN B123B 18LTGN / *B123A 18LTGN %B123A 18OR ##B123A 18GY %%B123A 18LTGN / B62-GAC 18WH B62AC 18DKBL / SWITCH ILLUMINATION SPLICE (10330) CH8_31 / MASTER F16 FLASHER SWITCH / J5-TAN BODY CONTROLLER (1602) / MASTER FLASHER SWITCH (10236) 7 / @B123A 18LTGN @B123B 18GY / %B123B 18OR / LEFT AED ELECTRIC (10203A) CH16_23 / W/CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK / W/CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 251 / FLASHER SYSTEM MASTER SWITCH EFFECTS

6.16. FLASHER SYSTEM MASTER SWITCH EFFECTS (CONT.), P. 16
Figure 252 FLASHER SYSTEM MASTER SWITCH EFFECTS (CONT.)

Components: AED RELAY (10312-R3); ALARM RELAY (10310-R6); CONTROLLER (1602); DIODE B6-K (10303); FLASHER CANCEL (10239); ILLUMINATION (10330); MASTER WARN CANCEL (10236A); PLATFORM (1702); RELAY (10311-R6); RELAY (10312-R2); RELAY COILS (10369); SPLICE (10336); SW ILLUM (10329); SW ILLUM (10330); ZVR SPLICE (10350A)
Wires (circuit gauge+color): A89KK 18OR; B120WA 18LTGN; B123-GK 18WH; B123-GL 18WH; B123F 18GY; B123K 18GY; B123L 18GY; B123M 18GY; B123N 18GY; B123R 18GY; B123S 18GY; B123T 18GY; B123V 18GY; B123W 18GY; B13H 18PK; B62-BG 18DKBL; B62-GAG 18WH; B62-GBG 18WH; B62AC 18DKBL; B62AG 18DKBL; B9C 18GY; B9S 18GY
See also sheets: CH16_03, CH16_04, CH16_12, CH3_30, CH3_40, CH3_60, CH8_30, CH8_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.16. FLASHER SYSTEM MASTER SWITCH EFFECTS (CONT.), P. 16 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090657 NO. 95885P 20DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B62-GAG 18WH B62AG B62AC 18DKBL 18DKBL / @ W/MASTER & PRX/AMB CANCEL W/3 POS TOGGLE SW # W/MASTER WARN & RRX CANCEL / 87 87 87A / MASTER WARN CANCEL (10236A) 7 / FLASHER SYSTEM RELAY (10312-R2) 86 86 30 / 87 8787A / B123M 18GY B123-GL 18WH B123-GK 18WH / SWITCH ILLUMINATION (10330) CH8_31 / ELEC PANEL/ PLATFORM (1702) 60 #B123S A89KK 18GY 18OR @B123W 18GY / J5-TAN BODY CONTROLLER (1602) MASTER F16 FLASHER SW / B120WA 18LTGN / DIODE B6-K (10303) CH16_12 / GROUND SPLICE (10336) CH3_40 / B123K 18GY / B9C 18GY FLASHER SYSTEM RELAY (10311-R6) / AED RELAY (10312-R3) CH16_03,04 / ACCESORY SPLICE RELAY COILS (10369) CH3_30 ZVR SPLICE (10350A) CH3_60 CHILD SAFETY ALARM RELAY (10310-R6) CH16_04 / B13H 18PK B9S 18GY / FLASHER CANCEL (10239) 7 / @B123T 18GY / B62-GBG 18WH B62-BG 18DKBL / B123N 18GY / B123F 18GY / B123L 18GY / SW ILLUM (10329) CH8_30 / SW ILLUM (10330) CH8_31 / @B123V 18GY / B123R 18GY / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 252 / FLASHER SYSTEM MASTER SWITCH EFFECTS (CONT.)

6.17. LEFT MOUNTED MASTER SWITCH EFFECTS, P. 17
Figure 253 LEFT MOUNTED MASTER SWITCH EFFECTS

Components: AED RELAY (10312-R3); CONTROLLER (1602); DIODE B6-K (10303); FLASHER CANCEL (10239); LOCK RELAY (10312-R6); MASTER FLASHER (10236); PLATFORM (1702); RELAY (10311-R6); RELAY (10312-R2); RELAY COIL (10364); RELAY COIL (10369); SPLICE (10330); SPLICE (10336); SW ILLUM (10329); SW ILLUM (10330); ZVR SPLICE (10350A)
Wires (circuit gauge+color): A89KK 18OR; B123-GK 18WH; B123-GL 18WH; B123A 18LTGN; B123B 18LTGN; B123C 18LTGN; B123F 18LTGN; B123K 18LTGN; B123L 18LTGN; B123M 18LTGN; B123N 18LTGN; B123P 18LTGN; B123R 18LTGN; B123S 18LTGN; B123T 18LTGN; B13H 18PK; B62-GAC 18WH; B62AC 18DKBL; B9H 18GY
See also sheets: CH16_03, CH16_05, CH16_09, CH3_29, CH3_30, CH3_40, CH3_60, CH8_30, CH8_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.17. LEFT MOUNTED MASTER SWITCH EFFECTS, P. 17 / CHAPTER 6 LEFT MOUNTED MASTER SWITCH EFFECTS / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B62-GAC 18WH / FLASHER CANCEL (10239) 7 / @ W/FLASHER CANCEL VIRGINIA % W/SINGLE CYCLE CANCEL / SWITCH ILLUMINATION SPLICE (10330) CH8_31 / FLASHER SYSTEM RELAY (10312-R2) 85 B123-GK 18WH / 87 87 87A / MASTER MASTER FLASHER FLASHER (10236) (10236) / B123T 18LTGN 86 86 / FLASHER SYSTEM RELAY (10311-R6) 85 / 87 87 87A / B62AC 18DKBL / B123B 18LTGN B9H 18GY B123F 18LTGN / ZVR SPLICE (10350A) CH3_60 ACC SPLICE RELAY COIL (10364) CH3_29 / ACC SPLICE RELAY COIL (10369) CH3_30 / 18LTGN B123R 86 86 / 8787A 87 / 18LTGN B123A / ELEC PANEL/ PLATFORM (1702) 60 A89KK %B123S 18LTGN 18OR @B123S 18LTGN @B123T 18LTGN / J5-TAN BODY CONTROLLER (1602) MASTER F16 FLASHER SW / @B123C 18LTGN / AED RELAY (10312-R3) CH16_03 / B123L 18LTGN B13H 18PK / GROUND SPLICE (10336) CH3_40 / B123N 18LTGN / B123-GL 18WH / SW ILLUM (10330) CH8_31 SW ILLUM (10329) CH8_30 / AED VANDAL LOCK RELAY (10312-R6) / B123K 18LTGN / B123S 18LTGN / 18LTGN B123P / DIODE B6-K (10303) CH16_09, 16,17 / B123-GL 18WH / FLASHER SYSTEM RELAY (10311-R6) CH16_05 / Figure 253 / LEFT MOUNTED MASTER SWITCH EFFECTS

6.18. MASTER FLASHER SWITCH WITH MOMENTARY CANCEL WITH OMIT, P. 18
Figure 254 MASTER FLASHER SWITCH WITH MOMENTARY CANCEL WITH OMIT

Components: FLASHER CANCEL (10239); J5-TAN BODY CONTROLLER (1602); PLATFORM (1702); SW ILLUM (10329); SW ILLUM (10330); ZVR SPLICE (10350A)
Wires (circuit gauge+color): A89KK 18OR; B123A 18LTGN; B123B 18GY; B62-GAC 16LTGN; B62AC 16LTGN
See also sheets: CH3_60, CH8_30, CH8_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.18. MASTER FLASHER SWITCH WITH MOMENTARY CANCEL WITH OMIT, P. 18 / CHAPTER 6 MASTER FLASHER SWITCH W/MOMENTARY CANCEL W/OMIT / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090657 95885P 20DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/ PLATFORM (1702) 60 / B62-GAC 16LTGN B62AC 16LTGN / B123A 18LTGN / SW ILLUM (10330) CH8_31 SW ILLUM (10329) CH8_30 J5-TAN BODY CONTROLLER (1602) MASTER F16 FLASHER SW ZVR SPLICE (10350A) CH3_60,95N / B123B 18GY / A89KK 18OR / FLASHER CANCEL (10239) 7 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 254 / MASTER FLASHER SWITCH WITH MOMENTARY CANCEL WITH OMIT

6.19. RIGHT SIDE MASTER FLASHER SWITCH EFFECTS, P. 19
Figure 255 RIGHT SIDE MASTER FLASHER SWITCH EFFECTS

Components: CONTROLLER (1602); FLASHER SW (1137); ROTARY DOOR SW (3201); SPLICE (1002B); ZVR SPLICE (1005A)
Wires (circuit gauge+color): A123H 18GY; A123K 18GY; A62R 18DKBL; A62R-G 18WH; A89A 18OR; A89KK 18OR; A9W 18GY
See also sheets: CH16_02, CH3_28, CH3_59, CH8_26
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.19. RIGHT SIDE MASTER FLASHER SWITCH EFFECTS, P. 19 / CHAPTER 6 RIGHT SIDE MASTER FLASHER SWITCH EFFECTS / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090657 95885P 20DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A9W 18GY / A62R-G 18WH A62R 18DKBL / J5-TAN BODY MASTER CONTROLLER F16 FLASHER (1602) SW / ZVR SPLICE (1005A) CH3_59 / *A89KK 18OR #A123K 18GY #A123H 18GY A89A 18OR / IGN SPLICE PACK (5 AMP MAX) %(1014A) CH3_28 IGN SPLICE @(1014) CH3_28A / R MASTER FLASHER SW (1137) / PANEL LT SPLICE (1002B) CH8_26 / ROTARY DOOR SW (3201) CH16_02 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / * W/R MASTER FLASHER SW # W/R MASTER FLASHER SW & W/3 POSITION ROTARY DOOR CONTROL SW % W/0508108 - MTA FUSE BLOCK @ N/0508108 - NOT MTA FUSE BLOCK / Figure 255 / RIGHT SIDE MASTER FLASHER SWITCH EFFECTS

6.20. FLASHER START SWITCH EFFECTS, P. 20
Figure 256 FLASHER START SWITCH EFFECTS

Components: CONTROLLER (1602); PLATFORM (1702); SPLICE (1002B); SPLICE (10366); SPLICE CONN (1006); START SWITCH (10237); SWITCH (1138); ZVR SPLICE (1005A); ZVR SPLICE (10350A)
Wires (circuit gauge+color): A62S 18DKBL; A62S-G 18WH; A89DD 18OR; A89H 18OR; A9X 18GY; B123E 18LTGN; B123EL 18LTGN; B123H 18LTGN; B62-GAC 18WH; B62-GAV 18WH; B62AC 18DKBL; B62ACA 18DKBL; B9E 18GY
See also sheets: CH3_59, CH3_60, CH6_22, CH8_24, CH8_26
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.20. FLASHER START SWITCH EFFECTS, P. 20 / CHAPTER 6 FLASHER START SWITCH EFFECTS / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090657 95885P 20DEC20 / - MJV0488 - 19NOV21 ADDED CIRC B62-GAV, B B62ACA, B123EL AT R/D 10237. / ELEC PANEL/ PLATFORM (1702) 57 A89H 18OR / A89H 18OR A9X 18GY / A62S 18DKBL A62S-G 18WH / J5-TAN BODY CONTROLLER (1602) AMBER F11 FLASHER SWITCH / ZVR SPLICE (1005A) CH3_59 / FLASHER START SWITCH (10237) #B62-GAC 18WH 7 %B62-GAV 18WH #B62AC 18DKBL %B62ACA 18DKBL B123H 18LTGN B9E 18GY %B123EL 18LTGN #B123E 18LTGN / PRIMARY SWITCH ILLUMINATION SPLICE (10366) CH8_24 / ZVR SPLICE (10350A) CH3_60,95N / RED OVERRIDE SPLICE CONN (1006) CH6_22 / J5-TAN BODY CONTROLLER (1602) AMBER F11 FLASHER SWITCH / RIGHT FLASHER START SWITCH / LEFT FLASHER START SW W/3 POSITION START SW/LEFT PANEL MOUNTED START SW / PANEL LIGHTS SPLICE (1002B) CH8_26 / FLASHER START SWITCH (1138) 8 / A89DD 18OR / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / % W/0508108 - MTA FUSE BLOCK # N/0508108 - NOT FUSE BLOCK. / Figure 256 / FLASHER START SWITCH EFFECTS

6.21. LEFT PANEL MOUNTED OVERRIDE SWITCH EFFECTS, P. 21
Figure 257 LEFT PANEL MOUNTED OVERRIDE SWITCH EFFECTS

Components: OVERRIDE (10238); PWL OVERRIDE (10402); RELAY COIL (10364); SWITCH ILLUMINATION (10330); ZVR SPLICE (10350A)
Wires (circuit gauge+color): B123E 18GY; B123J 18LTGN; B62-GAR 18WH; B62AR 18DKBL; B9J 18LTGN
See also sheets: CH3_29, CH3_60, CH6_22, CH8_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.21. LEFT PANEL MOUNTED OVERRIDE SWITCH EFFECTS, P. 21 / CHAPTER 6 LEFT PANEL MOUNTED OVERRIDE SWITCH EFFECTS / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090657 95885P 20DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B123E 18GY B9J 18LTGN / B62-GAR 18WH B62AR 18DKBL / SWITCH ILLUMINATION (10330) CH8_31 / PWL OVERRIDE (10402) CH6_22 ZVR SPLICE (10350A) CH3_60,95N ACCESSORY SPLICE RELAY COIL (10364) CH3_29 / B123J 18LTGN / 7 7 / 8 8 / FLASHER OVERRIDE (10238) / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 257 / LEFT PANEL MOUNTED OVERRIDE SWITCH EFFECTS

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 298 | printed page 258 | section 6.22
6.22. RED OVERRIDE SWITCH EFFECTS, P. 22
Figure 258 RED OVERRIDE SWITCH EFFECTS

Components: ALTERNATE ENTRANCE DOOR (10203); CHILD SAFETY ALARM RELAY (10308); CHILD SAFETY ALARM RELAY (10310-R6); ELEC PANEL/PLATFORM (1702); ELEC PANEL/PLATFORM (1702/1702); EXIT RELAY (1012-R4); FLASHER OVERRIDE (10238); FLASHER START SW (10237); IGN SPLICE (1014); IGN SPLICE (1014A); J3-RED BODY CONTROLLER (1600); L ALTERNATE ENTRANCE DOOR ELEC (10203A); PANEL LT (1002B); PWL OVERRIDE SPLICE (10402); PWL RELAY (10308); PWL RELAY (10308-R3); RED OVERRIDE SW (1139); RELAY (1020); ROTARY DOOR SW (3201); SPLICE CONN (1006); ZVR SPLICE (1005A)
Wires (circuit gauge+color): A117 18GY; A117 18OR; A123A 18GY; A123F 18GY; A62-GT 18WH; A62T 18DKBL; A89AA 18OR; A89F 18PK; A89H 18OR; A89HB 18OR; A9Y 18GY; B123E 18GY; B123E 18LTGN; B123EL 18LTGN; B123P 18LTGN; B89L 18OR; B89N 18OR
See also sheets: CH14_02, CH15_24, CH15_36, CH16_01, CH16_02, CH16_22, CH16_23, CH18_40, CH3_28, CH3_59, CH6_20, CH6_21, CH8_26
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.22. RED OVERRIDE SWITCH EFFECTS, P. 22 / CHAPTER 6 RED OVERRIDE SWITCH EFFECTS / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090657 95885P 20DEC20 / MJV0488 19NOV21 ADDED CIRC B123EL AT R/D 1702. / A62-GT 18WH / #B123EL FLASHER START SW 18LTGN (10237) CH6_20 @B123E 18LTGN PWL OVERRIDE SPLICE (10402) A &B123P 18LTGN B89N 18OR / A62T 18DKBL ROTARY DOOR SW (3201) CH16_02 ELEC PANEL/PLATFORM (1702) CH16_01 / ELEC PANEL/PLATFORM (1702/1702) 58 / E F / B123E 18GY B89L 18OR B89L 18OR B123E 18LTGN @B123E 18LTGN / RED OVERRIDE SW (1139) 7 7 / R SW PANEL LT (1002B) CH8_26 / RED OVRD SPLICE CONN (1006) A123A 18GY A123F 18GY / EMERGENCY EXIT RELAY (1012-R4) CH14_02 / EMERGENCY EXIT RELAY (1020) CH14_2A / W/0508108 - MTA FUSE BLOCK / B89N 18OR / Figure 258 / RED OVERRIDE SWITCH EFFECTS

6.23. LEFT MOUNTED MASTER SWITCH WITH SINGLE CYCLE CANCEL, P. 23
Figure 259 LEFT MOUNTED MASTER SWITCH WITH SINGLE CYCLE CANCEL

Components: AED RELAY (10310); CONTROLLER (1602); DIODE D64 (10306); FLASHER CANCEL (10239); LOCK (10310); MASTER FLASHER (10236); PLATFORM (1702); RELAY (10309); RELAY (10311); RELAY (10312); RELAY COIL (10364); RELAY COIL (10369); SPLICE (10329); SPLICE (10330); SPLICE (10336); ZVR SPLICE (10350A)
Wires (circuit gauge+color): A89KK 18OR; B120W 18LTGN; B123-GK 18WH; B123-GL 18WH; B123A 18LTGN; B123B 18LTGN; B123C 18LTGN; B123F 18LTGN; B123K 18LTGN; B123L 18LTGN; B123M 18LTGN; B123N 18LTGN; B123P 18LTGN; B123R 18LTGN; B123S 18LTGN; B13H 18PK; B62-GAC 18WH; B62AC 18DKBL; B9H 18GY; B9S 18GY
See also sheets: CH16_31, CH3_29, CH8_30, CH8_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.23. LEFT MOUNTED MASTER SWITCH WITH SINGLE CYCLE CANCEL, P. 23 / CHAPTER 6 LEFT MOUNTED MASTER SWITCH W/SINGLE CYCLE CANCEL / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / DIODE D64 (10306) B2 / B62-GAC 18WH / FLASHER CANCEL (10239) 7 / @ W/FLASHER CANCEL VIRGINIA / SWITCH ILLUMINATION SPLICE (10330) CH8_31 / 85 C1 B123-GK 18WH / 87 87 87A D1 E2 / B123K 18LTGN C2 / 18LTGN B123P E1 86 / MASTER MASTER FLASHER FLASHER (10236) (10236) / G4 30 / J4 86 86 / 85 G3 / 87 8787A H3 J3 / FLASHER SYSTEM RELAY (10311) / B62AC 18DKBL / B123B 18LTGN B9H 18GY B123F 18LTGN / ZVR SPLICE (10350A) CH3_95N ACC SPLICE RELAY COIL (10364) CH3_29 / ACC SPLICE RELAY COIL (10369) CH3_30A / 18LTGN B123A G4 30 / 18LTGN B123R J4 86 86 / 87 87 87A H3 J3 ELEC PANEL/ PLATFORM (1702) 60 A89KK B123S 18LTGN 18OR / 85 G3 / J5-TAN BODY CONTROLLER (1602) MASTER F16 FLASHER SW / @B123C 18LTGN / AED RELAY (10310) CH16_31 / B120W 18LTGN / B123N 18LTGN / DOOR CONTROL RELAY (10309) CH16_9A / B123L 18LTGN B13H 18PK / B123-GL 18WH / B62-GAC 18WH B62AC 18DKBL B123M 18LTGN B9H 18GY / SW ILLUMINATION SPLICE (10330) CH8_31 SW ILLUMINATION SPLICE (10329) CH8_30 / AED VANDAL LOCK (10310) / FLASHER SYSTEM RELAY (10312) / GROUND SPLICE (10336) CH3_95K / B9S 18GY / ZVR SPLICE (10350A) CH3_95N / Figure 259 / LEFT MOUNTED MASTER SWITCH WITH SINGLE CYCLE CANCEL

6.24. LEFT MOUNTED MASTER SWITCH WITH WARNING & RAILROAD CROSSING
Figure 260 LEFT MOUNTED MASTER SWITCH WITH WARNING & RAILROAD CROSSING CANCEL

Components: AED RELAY (10310); ALARM RELAY (10308); CONTROLLER (1602); DIODE D64 (10306); FLASHER CANCEL (10239); GROUND SPLICE (10336); MASTER WARN CANCEL (10236A); PLATFORM (1702); RELAY (10309); RELAY (10311); RELAY (10312); RELAY COILS (10369); SPLICE (10329); SPLICE (10330); ZVR SPLICE (10350A)
Wires (circuit gauge+color): A89KK 18OR; B120WA 18LTGN; B123-GK 18WH; B123-GL 18WH; B123F 18GY; B123K 18GY; B123L 18GY; B123M 18GY; B123N 18GY; B123R 18GY; B123S 18GY; B123T 18GY; B123W 18GY; B13H 18PK; B62-AG 18DKBL; B62-BG 18DKBL; B62-GAG 18WH; B62-GBG 18WH; B9C 18GY; B9S 18GY
See also sheets: CH16_31, CH8_30, CH8_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 6.24. LEFT MOUNTED MASTER SWITCH WITH WARNING & RAILROAD CROSSING CANCEL WITH 3 POSITION SWITCH, P. 24 / CHAPTER 6 LEFT MOUNTED MASTER SWITCH W/WARN & RRX CANCEL W/3 POSITION SWITCH / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090657 NO. 94295T 24FEB21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / DIODE D64 (10306) B120WA B120WA 18LTGN 18LTGN B2 A2 / B62-GAG 18WH B62-AG 18DKBL / @ W/NON SEQUENTIAL 3 POSITION ROTARY SWITCH # W/MASTER WARN & RRX CANCEL NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / 85 G3 / 87 87 87A H3 / G4 30 / J4 86 / MASTER WARN CANCEL (10236A) 7 / C2 30 / FLASHER SYSTEM RELAY (10312) D1 86 86 / 85 C1 / 87 8787A D2 / B123M 18GY B123-GL 18WH B123-GK 18WH / SWITCH ILLUMINATION SPLICE (10330) CH8_31 / FLASHER SYSTEM RELAY (10311) ELEC PANEL/ PLATFORM (1702) 60 A89KK #B123S 18OR 18GY @B123W 18GY @B123T 18GY B123T 18GY / J5-TAN BODY CONTROLLER (1602) MASTER F16 FLASHER SW AED RELAY (10310) CH16_31,37 AED RELAY (10310) CH16_4A / DOOR CONTROL RELAY (10309) CH16_9A ACCESSORY SPLICE RELAY COILS (10369) CH3_30A ZVR SPLICE (10350A) CH3_95N CHILD SAFETY ALARM RELAY (10308) CH16_4A / GROUND SPLICE (10336) CH3_95K SW ILLUM SPLICE (10329) CH8_30 SW ILLUM SPLICE (10330) CH8_31 / B123K 18GY / B13H 18PK B9S 18GY B9C 18GY / FLASHER CANCEL (10239) 7 / B62-GBG 18WH B62-BG 18DKBL / B123N 18GY / B123F 18GY / B123R 18GY / B123L 18GY / Figure 260 / LEFT MOUNTED MASTER SWITCH WITH WARNING & RAILROAD CROSSING CANCEL WITH 3 POSITION SWITCH

Figure 261 BACKUP LIGHTS

Components: CHECK RELAY (1012-R3); CHECK RELAY (1016); CONN C (10025C); CONN D (10025D); FEATURES (10001); GROUND SPLICE (10161); LEFT BACKUP LIGHT (10103); LEFT BODY (10400A/+B/10400); LOWER LEFT BACKUP LIGHT (10174); LOWER RIGHT BACKUP LIGHT (10175); PLATFORM (1703); REAR CAP (10406); RIGHT BACKUP LIGHT (10122); SEALED ENG (11500); SIGN (10128)
Wires (circuit gauge+color): A71D 18DKBL; A71D 18LTBL; B71 16LTBL; B71D 16LTBL; B71L 16LTBL; B71L-M 16LTBL; B71R 16LTBL; B71R-M 16LTBL; C71 18LTBL; C71L-M 18LTBL; C71R-M 18LTBL; D71 16LTBL; D71-G 16WH; D71A 16LTBL; D71B 16LTBL; D71L-G 16WH; D71L-M 16LTBL; D71R-G 16WH; D71R-M 16LTBL; E71 16LTBL; E71L-M 16LTBL; E71R-M 16LTBL
See also sheets: CH3_46, CH6_14, CH7_02, CH7_06
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / EXTERNAL LIGHTS (CHAPTER 7) / 7.1. BACKUP LIGHTS, P. 1 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 23DEC20 / BACKUP LIGHTS / CHAPTER 7 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / RIGHT BACKUP LIGHT (10122) 2 / LEFT BACKUP LIGHT (10103) 1 @D71L-M 16LTBL @D71L-G 16WH / @D71-G RIGHT REAR CAP 16WH GROUND SPLICE (10161) %D71-G CH3_46 16WH LOWER LEFT BACKUP LIGHT (10174) 1 / ##B71D 16LTBL / @D71R-G 16WH / @D71R-M 16LTBL / %D71L-M 16LTBL #D71A 16LTBL %D71L-G 16WH / LOWER RIGHT BACKUP LIGHT (10175) 2 / %D71R-G 16WH %D71R-M 16LTBL #D71B 16LTBL / ELEC PANEL/ PLATFORM (1703) A11 / E71L-M 16LTBL E71R-M 16LTBL / ##B71L 16LTBL ##B71R 16LTBL / **B71D 16LTBL / **A71D 18LTBL / E71 16LTBL / 16LTBL #D71 / B71 16LTBL / **B71L-M 16LTBL / **B71R-M 16LTBL / ELEC PANEL/ SEALED ENG (11500) CH7_06 / ELEC PANEL/ FR CAP OPTIONAL FEATURES (10001) / 18LTBL C71 / C71R-M 18LTBL / C71L-M 18LTBL / LIGHT MONITOR CONN D (10025D) / LIGHT MONITOR CONN C (10025C) / !D71 16LTBL / DRIVER ALERT SIGN (10128) CH6_14 / Figure 261 / BACKUP LIGHTS

7.2. BACKUP LIGHTS (CONT.), P. 2
Figure 262 BACKUP LIGHTS (CONT.)

Components: CONTROLLER (1601); ENGINE (1701); FR CAP (10001); FUSE A3-M (1016); GEN4 TCM (7150); GEN5 TCM (7150); LOWER (7106); PLATFORM (1703/1703); RELAY (1010-R6); RELAY (1012-R3); SEALED ENGINE (11500); TRANS MODULE 1 (1232)
Wires (circuit gauge+color): A71 16OR; A71 18OR; A71A 18OR; A71AB 16OR; A71B 18OR; A71BB 16LTBL; A71C 18OR; A71CK 18OR; A71D 18LTBL; A71E 18OR; A71F 16OR; A71H 16OR; A92E 18GY; B71A 16LTBL; B71D 16LTBL; K92D 18TN; K92E 18TN
See also sheets: CH12_10, CH12_12, CH12_14, CH12_18, CH3_06, CH7_01, CH7_04
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.2. BACKUP LIGHTS (CONT.), P. 2 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 23DEC20 / BACKUP LIGHTS (CONT) / CHAPTER 7 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / BACKUP LIGHT RELAY (1010-R6) / ELEC PANEL/ PLATFORM (1703/1703) A11 / J4-RED BODY CONTROLLER (1601) BACKUP E4 LIGHT CHECK / %A71 16OR / FUSE A3-M (1016) CH3_06 / PLATFORM/ ENGINE (1701) 22 / @A71 18OR / %A71BB 16LTBL @A71H 16OR / %A71H 16OR @A71H 16OR / BACKUP LIGHT CHECK RELAY (1012-R3) 87A / 85 %A71A 18OR @A71A 18OR / A71D 18LTBL / %A71F 16OR / A71C 18OR / *B71D 16LTBL / ELEC PANEL/ FR CAP (10001) CH7_01,06 / ELEC PANEL/ SEALED ENGINE (11500) CH7_04 / B71A 16LTBL / * W/ADDITIONAL LIGHT % W/GEN 4 XMSN W/LAMP CKECK @ W/EATON PRO 4 XMSN W/LAMP CKECK # W/2017/2021 ISB/B6.7 DIESEL ENG & W/F-2018-PROP/GAS-ENG / @A71F 16OR / @A71E %A71E 18OR 18OR / %A71B 18OR / %A71CK 18OR / @A71AB 16OR / %A#165 18TN / @A92E 18GY / #K71#165 18TN &K71#165 18TN #K92D 18TN #K92E 18TN / #K71#165 18TN / GEN4 TCM (7150) CH12_10 TRANS MODULE 1 (1232) CH12_12 GEN5 TCM (7150) CH12_18,21 EATON PRO XMSN BODY LOWER (7106) CH12_14 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 262 / BACKUP LIGHTS (CONT.)

7.3. BACKUP LIGHTS (CONT.), P. 2A
Figure 263 BACKUP LIGHTS (CONT.)

Components: CONTROLLER (1601); ENG (1701); FEATURES (10001); FUSE F20 (1011); GEN 4 TCM (7150); PLATFORM (1703/1703); RELAY (1011-R4); RELAY (1016); RELAY (10308); SEALED ENG (11500); XMSN LOWER (7106)
Wires (circuit gauge+color): A71 16OR; A71A 18OR; A71B 16OR; A71B 18OR; A71BB 16LTBL; A71BB 16OR; A71C 18OR; A71D 16LTBL; A71D 18LTBL; A71E 18OR; A71F 16OR; A71H 16LTBL; A92D 18GY; A92E 18GY; B71A 16LTBL; B71D 16LTBL; K92D 18TN; K92E 18TN
See also sheets: CH7_01, CH7_04, CH7_68
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.3. BACKUP LIGHTS (CONT.), P. 2A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 11MAR21 / BACKUP LIGHTS (CONT) / CHAPTER 7 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / BACKUP LT RELAY (1011-R4) 87A D / W/ADDITIONAL LT ELEC PANEL/ PLATFORM (1703/1703) A11 / B 86 / 87 C / E 30 / BACKUP LT CHECK RELAY (1016) J4-RED BODY CONTROLLER (1601) BACKUP E4 LIGHT CHECK / A71 16OR #A71B 16OR @A71B 18OR / FUSE F20 (1011) CH3_94C / PLATFORM/ ENG %A92D K71#165 (1701) 18GY 18TN %%A71#165 18TN 22 *A#165 18TN %A92E 18GY / K92D 18TN K92E 18TN / #A71D 18LTBL @A71BB 16LTBL / @A71D 16LTBL / @A71H 16LTBL #A71H 16LTBL #A71F 16OR #A71E 18OR / #A71BB 16OR / 87A 4 #A71C 18OR / #A71A 18OR 1 86 / 3 30 / 87 5 / ELEC PANEL/ FR CAP OPTIONAL FEATURES (10001) CH7_01 BACKUP LT RELAY (10308) CH7_5A ELEC PANEL/ SEALED ENG (11500) CH7_04 BACK UP LT RELAY (10308 CH7_68 / B71A 16LTBL / EATON PROCISION XMSN LOWER (7106) CH12_15F / GEN 4 TCM (7150) CH12_10A,23 / B71D 16LTBL / B71D 16LTBL / @@B71D 16LTBL / FUSE F20 (1011) CH3_94C / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK / Figure 263 / BACKUP LIGHTS (CONT.)

7.4. BACKUP LIGHTS (CONT.), P. 3
Figure 264 BACKUP LIGHTS (CONT.)

Components: ENG (1701); FUSE A3-M (1016); GEN4 TCM (7150); GEN5 TCM (7150); LOWER (7106); PLATFORM (1703/1703); RELAY (1010-R6); RELAY (10308-R2); SEALED ENG (11500); TRANS MODULE 1 (1232)
Wires (circuit gauge+color): A71 16OR; A71A 18OR; A71B 18OR; A71BB 16LTBL; A71D 16LTBL; A71H 16LTBL; A92E 18GY; B71A 16LTBL; B71D 16LTBL; K92D 18TN; K92E 18TN
See also sheets: CH12_10, CH12_12, CH12_14, CH12_18, CH3_06, CH7_04, CH7_05
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.4. BACKUP LIGHTS (CONT.), P. 3 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 23DEC20 / BACKUP LIGHTS (CONT) / CHAPTER 7 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / BACKUP LT RELAY (1010-R6) 87A / ELEC PANEL/ PLATFORM (1703/1703) A11 / %A71 16OR / FUSE A3-M (1016) CH3_06 / @A71 16OR / %A71BB 16LTBL @A71BB 16LTBL / %A71D 16LTBL @A71D 16LTBL %A71H 16LTBL @A71H 16LTBL / ELEC PANEL/ SEALED ENG (11500) CH7_04 / B71A 16LTBL / * W/2017/2021 ISB/B6.7 DIESEL ENGINE # W/F-2018-PROPANE/GASOLINE-ENGINE % W/GEN 4 XMSN N/LAMP CKECK @ W/EATON PRO 4 XMSN N/LAMP CKECK / BACKUP LT RELAY (10308-R2) CH7_05 / B71D 16LTBL / %A71B 18OR %A71A 18OR / PLATFORM/ ENG (1701) 22 / %A#165 18TN / @A92E 18GY / *K71#165 18TN #K71#165 18TN *K92D 18TN *K92E 18TN / *K71#165 18TN / GEN4 TCM (7150) CH12_10 TRANS MODULE 1 (1232) CH12_12 GEN5 TCM (7150) CH12_18,21 EATON PRO XMSN BODY LOWER (7106) CH12_14 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 264 / BACKUP LIGHTS (CONT.)

7.5. BACKUP LIGHTS (CONT.), P. 4
Figure 265 BACKUP LIGHTS (CONT.)

Components: ALARM (11516); ELEC PANEL (1703/1703); ELEC PANEL/L BODY (10400); FUSE B12-C (10301); FUSE F33 (10303); SEALED ENGINE (11500); SENSOR (11515); SPLICE (11507)
Wires (circuit gauge+color): B71A 16LTBL; B71H 16LTBL; B71H 18LTBL; Y71 16LTBL; Y71-G 16WH; Y71H 16LTBL
See also sheets: CH3_12, CH3_48, CH7_02, CH7_06
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.5. BACKUP LIGHTS (CONT.), P. 4 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 23DEC20 / BACKUP LIGHTS (CONT) / CHAPTER 7 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (11507) CH3_48 / REVERSE MOTION SENSOR (11515) A @Y71H 16LTBL / REVERSE MOTION SENSOR / 16LTBL @Y71 / ELEC PANEL/ SEALED ENGINE (11500) / B71A 16LTBL / @Y71-G 16WH / Y71 16LTBL / FUSE B12-C (10301) CH3_12 FUSE F33 (10303) CH3_94H ELEC PANEL/L BODY (10400) CH7_06 W/ADDITIONAL LIGHT / B71H 18LTBL / + - / RD BK / BACKUP ALARM (11516) 1 2 / PLATFORM/ ELEC PANEL (1703/1703) CH7_02,2A,03 / Y71-G 16WH / W/DRIVELINE SENSOR / W/BACKUP ALARM / B71H 18LTBL B71H 16LTBL / @ W/REVERSE MOTION SENSOR AND SIDE MOUNTED BACKUP LIGHTS / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 265 / BACKUP LIGHTS (CONT.)

7.6. BACKUP LIGHTS ACTIVATED BY REAR EMERGENCY EXIT, P. 5
Figure 266 BACKUP LIGHTS ACTIVATED BY REAR EMERGENCY EXIT

Components: BACKUP LT (10174); BACKUP LT (10175); CONN C (10025C); CONN C (10025D); FR CAP (10001); FUSE B6-G (10303); L BODY (10400); PLATFORM (1703); REAR CAP (10406); RELAY (1010-R6); RELAY (10308-R2); SIGN (10128); SPLICE (10386)
Wires (circuit gauge+color): A71D 16LTBL; B117B 18LTBL; B71A 16LTBL; B71B 16LTBL; B71C 16LTBL; B71C 16OR; B71D 16LTBL; B71DA 16LTBL; B71DB 16LTBL; B71E 16LTBL; B71F 16LTBL; B71L 16LTBL; B71L 16OR; B71L-M 16LTBL; B71R 16LTBL; B71R 16OR; B71R-M 16LTBL; B71S 16OR; C71 18LTBL; C71L-M 18LTBL; C71R-M 18LTBL; D71 16LTBL; D71L-M 16LTBL; D71R-M 16LTBL; E71 16LTBL; E71L-M 16LTBL; E71R-M 16LTBL
See also sheets: CH3_14, CH6_14, CH7_01, CH7_03, CH8_06
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.6. BACKUP LIGHTS ACTIVATED BY REAR EMERGENCY EXIT, P. 5 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. FUSE B6-G (10303) CH3_14 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 BACKUP LIGHTS ACTIVATED BY REAR EMERGENCY EXIT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 87A !B71B 16LTBL %B71F 16LTBL *B71S #B71DB 16LTBL 16OR &B71A 16LTBL *B71D 16LTBL / B71D 16LTBL / REAR DOOR SPLICE (10386) CH8_06 / B71C 16LTBL / 30 30 / BACKUP LT RELAY (10308-R2) 85 / B117B 18LTBL / !B71A 16LTBL B71D 16LTBL &B71B 16LTBL #B71D 16LTBL *B71B 16LTBL / ELEC PANEL/ PLATFORM (1703) A11 A71D 16LTBL / BACKUP LT RELAY (1010-R6) CH7_03 / 16LTBL 16LTBL %B71R 16LTBL %B71C *B71L *B71R !B71R !B71L %B71L 16OR 16OR 16OR 16OR #B71DA 16LTBL &B71C *B71C 16OR 16OR / ELEC PANEL/ L BODY B4 B5 B6 (10400) / 16LTBL E71L-M 16LTBL E71R-M 16LTBL E71 / B8 B9 / DRIVER ALERT SIGN (10128) CH6_14 LOWER LOWER LEFT BACKUP LT (10174) CH7_01 LOWER LOWER RIGHT BACKUP LT (10175) CH7_01 LT MONITOR CONN C (10025C) / D71 16LTBL / D71L-M 16LTBL / D71R-M 16LTBL / C71R-M 18LTBL C71 18LTBL / ELEC PANEL/ FR CAP (10001) / L BODY/ REAR CAP (10406) / C12 C8 C2 / @/&B71L-M @/&B71R-M 16LTBL 16LTBL @B71E 16LTBL / C71L-M 18LTBL / LT MONITOR CONN C (10025D) / 16LTBL B71B / Figure 266 / BACKUP LIGHTS ACTIVATED BY REAR EMERGENCY EXIT

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 307 | printed page 267 | section 7.7
7.7. BACKUP LIGHTS ACTIVATED BY REAR EMERGENCY EXIT (CONT.), P. 5A
Figure 267 BACKUP LIGHTS ACTIVATED BY REAR EMERGENCY EXIT (CONT.)

Components: BACKUP LT (10174); BACKUP LT (10175); CHECK RELAY (1016); CONN C (10025C); CONN C (10025D); FR CAP (10001); FUSE F39 (10304); L BODY (10400A/B/10400); PLATFORM (1703); REAR CAP (10406); RELAY (10308); SIGN (10128); SPLICE (10386)
Wires (circuit gauge+color): A71D 18LTBL; B117B 18LTBL; B71A 16LTBL; B71B 16LTBL; B71C 16LTBL; B71C 16OR; B71D 16LTBL; B71DA 16LTBL; B71E 16LTBL; B71F 16LTBL; B71L 16LTBL; B71L-M 16LTBL; B71R 16LTBL; B71R-M 16LTBL; C71 18LTBL; C71L-M 18LTBL; C71R-M 18LTBL; D71 16LTBL; D71L-M 16LTBL; D71R-M 16LTBL; E71 16LTBL; E71L-M 16LTBL; E71R-M 16LTBL
See also sheets: CH6_14, CH7_01, CH8_06
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.7. BACKUP LIGHTS ACTIVATED BY REAR EMERGENCY EXIT (CONT.), P. 5A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 11MAR21 / CHAPTER 7 BACKUP LIGHTS ACTIVATED BY REAR EMERGENCY EXIT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 87A C2 16LTBL @B71F / B71B 16LTBL / REAR DOOR SPLICE (10386) CH8_06 / B71C 16LTBL / E1 30 30 / E2 86 / FUSE F39 (10304) CH3_94J / BACKUP LT RELAY (10308) / B117B 18LTBL / 85 C1 D1 / &B71A 16LTBL B71D 16LTBL *B71A 16LTBL / ELEC PANEL/ PLATFORM (1703) A11 *B71B 16LTBL / A71D 18LTBL / BACKUP LT CHECK RELAY (1016) CH7_2A / 16LTBL 16LTBL 16LTBL #B71DA 16LTBL @B71L 16LTBL @B71R 16LTBL &B71C &B71L &B71R / 16LTBL B71L-M 16LTBL B71R-M 16LTBL %B71E / ELEC PANEL/ B4 B5 B6 L BODY (10400A/B/10400) / 16LTBL E71L-M 16LTBL E71R-M 16LTBL E71 / B7 B8 B9 / DRIVER ALERT SIGN (10128) CH6_14 LOWER LOWER LEFT BACKUP LT (10174) CH7_01 LOWER LOWER RIGHT BACKUP LT (10175) CH7_01 / D71 16LTBL / D71L-M 16LTBL / D71R-M 16LTBL / C71 18LTBL C71R-M 18LTBL / ELEC PANEL/ FR CAP (10001) / L BODY/ REAR CAP (10406) / *B71C 16OR / C2 C8 C12 / LT MONITOR CONN C (10025C) / LT MONITOR CONN C (10025D) / &B71B 16LTBL / Figure 267 / BACKUP LIGHTS ACTIVATED BY REAR EMERGENCY EXIT (CONT.)

7.8. BACKUP LIGHTS WITH ADDITIONAL LIGHTS, P. 6
Figure 268 BACKUP LIGHTS WITH ADDITIONAL LIGHTS

Components: BACKUP LT (10174); BACKUP LT (10175); CHECK RELAY (1012-R3); CONN C (10025C); ELEC PANEL (11500); FR CAP (10001); L BODY (10400A/B/10400); PLATFORM/ELEC PANEL (1703); REAR CAP (10406); SENSOR (11515)
Wires (circuit gauge+color): A71D 18LTBL; B71 16LTBL; B71D 16LTBL; B71E 16LTBL; B71H 16LTBL; B71L 16LTBL; B71R 16LTBL; C71 18LTBL; D71 16LTBL; D71L-M 16LTBL; D71R-M 16LTBL; E71 16LTBL; E71L-M 16LTBL; E71R-M 16LTBL; Y71H 16LTBL
See also sheets: CH7_01, CH7_02, CH7_04
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.8. BACKUP LIGHTS WITH ADDITIONAL LIGHTS, P. 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 BACKUP LIGHTS WITH ADDITIONAL LIGHTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B71D 16LTBL / PLATFORM/ELEC PANEL (1703) A11 / A71D 18LTBL / BACKUP LT CHECK RELAY (1012-R3) CH7_02 / 16LTBL 16LTBL 16LTBL B71 B71L B71R / 16LTBL #B71E ELEC PANEL/ FR CAP (10001) / ELEC PANEL/ L BODY B4 (10400A/B/10400) / 16LTBL E71L-M 16LTBL E71R-M 16LTBL E71 / L BODY/ REAR CAP B7 (10406) / LOWER RIGHT BACKUP LT (10175) CH7_01 LOWER LEFT BACKUP LT (10174) CH7_01 LOWER RIGHT BACKUP LT (10175) CH7_01 / D71 16LTBL / D71L-M 16LTBL / D71R-M 16LTBL / C71 18LTBL / LT MONITOR CONN C (10025C) / # W/LIGHT MONITOR / B71H 16LTBL / SEALED ENG/ ELEC PANEL (11500) D8 / Y71H 16LTBL / REVERSE MOTION SENSOR (11515) CH7_04 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 268 / BACKUP LIGHTS WITH ADDITIONAL LIGHTS

7.9. DESTINATION SIGN FRONT AND REAR WITH DUAL SWITCH, P. 7
Figure 269 DESTINATION SIGN FRONT AND REAR WITH DUAL SWITCH

Components: FRONT CAP (10000); FUSE B3-M (10304); FUSE F21 (10302); GROUND SPLICE (10010); LEFT BODY (10401A/B/10401); REAR CAP (10406); SIGN 2 (10267B); SIGN SWITCH (10267A); SPLICE (10333); SPLICE GROUND (10161)
Wires (circuit gauge+color): B134 16OR; B134A 16OR; B134F 16OR; B134R 16OR; B62-GAE 18WH; B62-GAF 18WH; B62AE 18LTBL; B62AF 18LTBL; C134-G 16WH; C134A 16OR; D134-G 16WH; D134A 16OR; E134A 16OR
See also sheets: CH3_07, CH3_44, CH3_46, CH8_34
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.9. DESTINATION SIGN FRONT AND REAR WITH DUAL SWITCH, P. 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 DESTINATION SIGN FRONT AND REAR W/DUAL SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / C134A 16OR / B62AE 18LTBL B62-GAE 18WH / SWITCH ILLUMINATION SPLICE (10333) CH8_34 ELEC PANEL/ D8 LEFT BODY (10401A/B/10401) / DESTINATION SIGN SWITCH (10267A) / B134F 16OR / SWITCH ILLUMINATION SPLICE DESTINATION (10333) SIGN 2 CH8_34 (10267B) 2 / B134A 16OR B134R 16OR / D134-G 16WH DESTINATION SIGN *(10143) %(10144) / D134A 16OR / B62-GAF 18WH B62AF 18LTBL / E134A 16OR / B134 16OR B134 16OR / LEFT BODY/ REAR CAP (10406) / REAR DESTINATION SIGN / FRONT DESTINATION SIGN / FUSE B3-M (10304) CH3_07,25 FUSE F21 (10302) CH3_94F / ELEC PANEL/ FRONT CAP (10000) / GROUND SPLICE C134-G (10010) 16WH CH3_44 DESTINATION SIGN *(10036) %(10037) / RIGHT REAR CAP SPLICE GROUND (10161) CH3_46 / * N/LED ILLUM % W/LED ILLUM NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 269 / DESTINATION SIGN FRONT AND REAR WITH DUAL SWITCH

7.10. DESTINATION SIGN FRONT AND REAR WITH SINGLE SWITCH, P. 8
Figure 270 DESTINATION SIGN FRONT AND REAR WITH SINGLE SWITCH

Components: FRONT CAP (10000); FUSE B3-M (10304); FUSE F21 (10302); GROUND SPLICE (10010); LEFT BODY (10401A/B/10401); REAR CAP (10406); SIGN SWITCH (10267A); SPLICE (10333); SPLICE GROUND (10161)
Wires (circuit gauge+color): B134 16OR; B134F 16OR; B134R 16OR; B62-GAE 18WH; B62AE 18LTBL; C134-G 16WH; C134A 16OR; D134-G 16WH; D134A 16OR; E134A 16OR
See also sheets: CH3_07, CH3_44, CH3_46, CH8_34
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.10. DESTINATION SIGN FRONT AND REAR WITH SINGLE SWITCH, P. 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 DESTINATION SIGN FRONT AND REAR W/SINGLE SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / C134-G 16WH / C134A 16OR / B62AE 18LTBL B62-GAE 18WH / DESTINATION SIGN SWITCH (10267A) 8 / B134F 16OR / D134-G 16WH DESTINATION SIGN B *(10143) %(10144) / RIGHT REAR CAP SPLICE GROUND (10161) CH3_46 / SWITCH ILLUMINATION SPLICE (10333) CH8_34 / E134A 16OR / B134 16OR B134 16OR / REAR DESTINATION SIGN / FRONT DESTINATION SIGN / GROUND SPLICE (10010) CH3_44 DESTINATION SIGN *(10036) %(10037) / B134R 16OR / D134A 16OR / FUSE B3-M (10304) CH3_07,25 FUSE F21 (10302) CH3_94F / ELEC PANEL/ LEFT BODY D8 (10401A/B/10401) / LEFT BODY/ REAR CAP (10406) / ELEC PANEL/ FRONT CAP (10000) / * N/LED ILLUM % W/LED ILLUM NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 270 / DESTINATION SIGN FRONT AND REAR WITH SINGLE SWITCH

7.11. DESTINATION SIGN ACTIVATED BY CLEARANCE LIGHTS, P. 9
Figure 271 DESTINATION SIGN ACTIVATED BY CLEARANCE LIGHTS

Components: DOOR RELAY (10312_R3); FRONT CAP (10000); FUSE B3-M (10304); GROUND SPLICE (10010); LEFT BODY (10401A/10401); OPTION (10380); REAR CAP (10406); SPLICE (10336); SPLICE GROUND (10161)
Wires (circuit gauge+color): B134 16RD; B134-G 16WH; B134A 16OR; B134B 16OR; B134F 16OR; B134H 16OR; B134R 16OR; C134-G 16WH; C134A 16OR; D134-G 16WH; D134A 16OR; E134A 16OR
See also sheets: CH3_07, CH3_40, CH3_44, CH3_46, CH7_66
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.11. DESTINATION SIGN ACTIVATED BY CLEARANCE LIGHTS, P. 9 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 DESTINATION SIGN ACTIVATED BY CLEARANCE LIGHTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE C134-G 16WH (10010) CH3_44 DESTINATION SIGN *(10036) #(10037) / C134A 16OR / @B134B %B134F 16OR 16OR / D134-G 16WH DESTINATION SIGN B *(10143) #(10144) / RIGHT REAR CAP SPLICE GROUND (10161) CH3_46 / E134A 16OR / REAR DESTINATION SIGN / FRONT DESTINATION SIGN @ W/FRONT ONLY COM BUS % W/FRONT AND REAR SIGN * N/LED ILLUM # W/LED ILLUM / D134A 16OR / ELEC PANEL/ LEFT BODY (10401A/10401) D8 / LEFT BODY/ REAR CAP (10406) / ELEC PANEL/ FRONT CAP (10000) / 87 %B134H 16OR / ALTERNATE ENTRANCE DOOR RELAY (10312_R3) 85 / B134-G 16WH / GROUND SPLICE (10336) CH3_40 / @B134A 16OR %B134B 16OR / CL LIGHT OPTION (10380) CH7_66 / B134 16RD / FUSE B3-M (10304) CH3_07,25 / %B134R 16OR / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 271 / DESTINATION SIGN ACTIVATED BY CLEARANCE LIGHTS

7.12. DESTINATION SIGN ACTIVATED BY CLEARANCE LIGHTS (CONT.), P. 9A
Figure 272 DESTINATION SIGN ACTIVATED BY CLEARANCE LIGHTS (CONT.)

Components: AED RELAY (10310); FRONT CAP (10000); FUSE F21 (10302); GROUND SPLICE (10010); GROUND SPLICE (10336); LEFT BODY (10401A/10401); OPTION (10380); REAR CAP (10406); SIGN (10036); SIGN (10143); SPLICE GROUND (10161)
Wires (circuit gauge+color): B134 16RD; B134-G 16WH; B134A 16OR; B134B 16OR; B134F 16OR; B134R 16OR; C134-G 16WH; C134A 16OR; D134-G 16WH; D134A 16OR; E134A 16OR
See also sheets: CH3_44, CH3_46
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.12. DESTINATION SIGN ACTIVATED BY CLEARANCE LIGHTS (CONT.), P. 9A / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 11MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / C134-G 16WH GROUND SPLICE (10010) CH3_44 DESTINATION SIGN (10036) / C134A 16OR / %B134F @B134B 16OR 16OR / DESTINATION B SIGN (10143) / RIGHT REAR CAP SPLICE GROUND (10161) CH3_46 / E134A 16OR / D134-G 16WH / REAR DESTINATION SIGN / FRONT DESTINATION SIGN @ W/FRONT ONLY COM BUS % W/FRONT AND REAR NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / D134A 16OR / ELEC PANEL/ LEFT BODY D8 (10401A/10401) / LEFT BODY/ REAR CAP (10406) / ELEC PANEL/ FRONT CAP (10000) / %B134R 16OR / H2 86 / 85 G1 / 87 H1 / G2 30 / AED RELAY (10310) / B134-G 16WH / GROUND SPLICE (10336) CH3_95K / @B134A 16OR %B134B 16OR / CL LIGHT OPTION (10380) CH7_66A / B134 16RD / FUSE F21 (10302) CH3_94F / Figure 272 / DESTINATION SIGN ACTIVATED BY CLEARANCE LIGHTS (CONT.)

7.13. STROBE LIGHT ACTIVATED WITH IGNITION, P. 10
Figure 273 STROBE LIGHT ACTIVATED WITH IGNITION

Components: FUSE B3-E (10304); GROUND SPLICE (10160); L BODY (10400/10400A/B); LT SECT 1 (10474A); REAR CAP (10406); RELAY (10318-R1); SPLICE (10473); STROBE LT (10109); STROBE LT (10109A); STROBE LT (10517)
Wires (circuit gauge+color): B127A 16OR; B127B 16OR; B12L 14BK; D127-G 16WH; D127A 18OR; E127-GA 18WH; E127A 18OR; E127B 18OR
See also sheets: CH3_15, CH3_45, CH3_56, CH7_15
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.13. STROBE LIGHT ACTIVATED WITH IGNITION, P. 10 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 STROBE LIGHT ACTIVATED W/IGNITION / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / * REAR STROBE LIGHT N/ CONSTRUCTION REINFORCEMENT # REAR STROBE LIGHT W/ CONSTRUCTION REINFORCEMENT % N/9 @ W/9 / #D127-G 16WH / STROBE STROBE LT LT SECT SECT 1 1 (10474A) (10474A) / E127-GA 18WH / L BODY/ REAR CAP (10406) / E127-GA 18WH / E127B 18OR / STROBE LT (10109A) / STROBE LT (10109) / E127A 18OR / L REAR CAP GROUND SPLICE (10160) CH3_45 / *D127-G *D127A 18OR 16WH / #D127A 18OR / ELEC PANEL/ L BODY (10400/10400A/B) / E127A 18OR / %B127A @B127B 16OR 16OR / GROUND SPLICE (10473) CH3_56 / E127A 18OR / SPLICE PACK STROBE LT (10517) CH7_15,16 / FUSE B3-E (10304) 13 9 / B12L 14BK / ACCESSORY 1 RELAY (10318-R1) CH3_15 / Figure 273 / STROBE LIGHT ACTIVATED WITH IGNITION

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 314 | printed page 274 | section 7.14
7.14. STROBE LIGHT ACTIVATED WITH SWITCH, P. 11
Figure 274 STROBE LIGHT ACTIVATED WITH SWITCH

Components: FUSE B3-E (10304); FUSE F62 (10306); GROUND SPLICE (10160); ILLUMINATION (10333); LEFT BODY (10400); REAR CAP (10406); SPLICE (10473); STROBE LIGHT (10517); STROBE LIGHT SWITCH (10270); STROBE LT (10109); STROBE LT (10109A); STROBE LT SECT 1 (10474A)
Wires (circuit gauge+color): B127A 16OR; B127B 16OR; B62-GW 18WH; B62W 18DKBL; D127-G 16WH; D127A 18OR; E127-GA 18WH; E127A 18OR; E127B 18OR
See also sheets: CH3_15, CH3_45, CH3_56, CH7_15, CH8_34
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.14. STROBE LIGHT ACTIVATED WITH SWITCH, P. 11 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 STROBE LIGHT ACTIVATED W/SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (10473) CH3_56 / #D127-G 16WH / STROBE LT SECT 1 (10474A) / E127-GA 18WH / LEFT BODY/ REAR CAP (10406) / E127-GA 18WH / E127B 18OR E127A 18OR / FUSE B3-E (10304) CH3_15 FUSE F62 (10306) CH3_94N / STROBE LT (10109A) / STROBE LT (10109) / LEFT REAR CAP GROUND SPLICE (10160) CH3_45 / *D127-G *D127A 16WH 18OR / #D127A 18OR / E127A 18OR / ##B127A 16OR &B127A 16OR B127B 16OR / STROBE LIGHT SWITCH (10270) / SWITCH ILLUMINATION (10333) CH8_34 / B62W 18DKBL B62-GW 18WH / E127A 18OR / ELEC PANEL/ LEFT BODY (10400) / SPLICE PACK STROBE LIGHT (10517) CH7_15,16 / Figure 274 / STROBE LIGHT ACTIVATED WITH SWITCH

7.15. STROBE LIGHT ACTIVATED WITH SWITCH OR STOP ARM, P. 12
Figure 275 STROBE LIGHT ACTIVATED WITH SWITCH OR STOP ARM

Components: EXTEND (10358A); FUSE B3-E (10304); GROUND SPLICE (10160); ILLUMINATION (10333); L BODY (10400); REAR CAP (10406); RELAY (10308-R2); RELAY (10318-R1); SPLICE (10337); SPLICE (10473); STROBE LT (10109); STROBE LT (10109A); STROBE LT (10517); STROBE LT SECT 1 (10474A); STROBE LT SW (10270)
Wires (circuit gauge+color): B127-G 16WH; B127A 16OR; B127B 16OR; B127D 16OR; B127E 16OR; B127F 16OR; B127J 16OR; B12L 14BK; B62-GW 18WH; B62W 18DKBL; D127-G 16WH; D127A 18OR; E127-GA 18WH; E127A 18OR; E127B 18OR
See also sheets: CH3_15, CH3_41, CH3_45, CH3_56, CH7_15, CH8_34, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.15. STROBE LIGHT ACTIVATED WITH SWITCH OR STOP ARM, P. 12 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 STROBE LIGHT ACTIVATED W/SWITCH OR STOP ARM / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (10473) CH3_56 / #D127-G #D127A 18OR 16WH / STROBE LT SECT 1 (10474A) / E127-GA 18WH / L BODY/ REAR CAP (10406) / E127-GA 18WH / E127B E127A 18OR 18OR / STROBE LT (10109A) / STROBE LT (10109) / L REAR CAP GROUND SPLICE (10160) CH3_45 / *D127-G *D127A 18OR 16WH / ELEC PANEL/ L BODY (10400) E127A 18OR / E127A 18OR / B127-G 16WH / STROBE LT SW (10270) / B127E 16OR B127B 16OR / SW ILLUMINATION (10333) CH8_34 / B127A 16OR / B12L 14BK / FUSE B3-E (10304) 9 13 / B62W 18DKBL B62-GW 18WH / B127D 16OR / ACCESSORY 1 RELAY (10318-R1) CH3_15 / STOP ARM EXTEND (10358A) CH9_03 / STROBE LT RELAY (10308-R2) / GROUND SPLICE (10337) CH3_41 / B127J 16OR B127F 16OR / SPICE PACK STROBE LT (10517) CH7_15,16 / Figure 275 / STROBE LIGHT ACTIVATED WITH SWITCH OR STOP ARM

7.16. STROBE LIGHT ACTIVATED WITH SWITCH OR STOP ARM WITH 9, P. 12A
Figure 276 STROBE LIGHT ACTIVATED WITH SWITCH OR STOP ARM WITH 9

Components: EXTEND (10358A); FUSE F62 (10306); GROUND SPLICE (10160); ILLUMINATION (10333); L BODY (10400); REAR CAP (10406); RELAY (10308); SPLICE (10337); SPLICE (10473); STROBE LT (10109); STROBE LT (10109A); STROBE LT (10517); STROBE LT SECT 1 (10474A); STROBE LT SW (10270)
Wires (circuit gauge+color): B127-G 16WH; B127A 16OR; B127B 16OR; B127D 16OR; B127E 16OR; B127F 16OR; B62-GW 18WH; B62W 18DKBL; D127-G 16WH; D127A 18OR; E127-GA 18WH; E127A 18OR; E127B 18OR
See also sheets: CH7_15, CH7_45, CH7_56, CH8_34, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.16. STROBE LIGHT ACTIVATED WITH SWITCH OR STOP ARM WITH 9, P. 12A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 12MAR21 / CHAPTER 7 STROBE LIGHT ACTIVATED W/SWITCH OR STOP ARM W/9 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (10473) CH7_56 / #D127-G #D127A 18OR 16WH / STROBE LT SECT 1 (10474A) / E127-GA 18WH / L BODY/ REAR CAP (10406) / E127-GA 18WH / E127B E127A 18OR 18OR / STROBE LT (10109A) / STROBE LT (10109) / L REAR CAP GROUND SPLICE (10160) CH7_45 / *D127-G *D127A 18OR 16WH / ELEC PANEL/ L BODY (10400) E127A 18OR / E127A 18OR / B127-G 16WH / STROBE LT SW (10270) / B127E 16OR B127B 16OR / SW ILLUMINATION (10333) CH8_34 / B127A 16OR / B62W 18DKBL B62-GW 18WH / 85 C1 B127D 16OR / FUSE F62 (10306) CH3_94N / STOP ARM EXTEND (10358A) CH9_03 / E2 86 / C2 30 / STROBE LT RELAY (10308) / GROUND SPLICE (10337) CH7_95L / E1 B127F 16OR / SPICE PACK STROBE LT (10517) CH7_15,16 / Figure 276 / STROBE LIGHT ACTIVATED WITH SWITCH OR STOP ARM WITH 9

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 317 | printed page 277 | section 7.17
7.17. STROBE LIGHT ACTIVATED WITH SWITCH OR PUPIL WARNING LIGHT, P. 13
Figure 277 STROBE LIGHT ACTIVATED WITH SWITCH OR PUPIL WARNING LIGHT

Components: FUSE B3-E (10304); FUSE F62 (10306); GROUND SPLICE (10160); LEFT BODY (10400); MODULE (10500); REAR CAP (10406); SPLICE (10333); SPLICE (10337); SPLICE (10360A); SPLICE (10360R); SPLICE (10473); STROBE LIGHT (10517); STROBE LIGHT SWITCH (10270); STROBE LT (10109); STROBE LT (10109A); STROBE LT SECT 1 (10474A)
Wires (circuit gauge+color): B127-G 16OR; B127A 16OR; B127B 16OR; B127C 16OR; B127D 16OR; B62-GW 18WH; B62W 18DKBL; B89E 16OR; B89F 16OR; D127-G 16WH; D127A 18OR; E127-GA 18WH; E127A 18OR; E127B 18OR
See also sheets: CH3_15, CH3_41, CH3_45, CH3_56, CH6_01, CH6_02, CH7_15, CH8_34
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.17. STROBE LIGHT ACTIVATED WITH SWITCH OR PUPIL WARNING LIGHT, P. 13 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 STROBE LIGHT ACTIVATED W/SWITCH OR PUPIL WARNING LIGHT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (10473) CH3_56 / #D127A #D127-G 18OR 16WH / STROBE LT SECT 1 (10474A) / E127-GA 18WH / LEFT BODY/ REAR CAP (10406) / E127-GA 18WH / E127A E127B 18OR 18OR / STROBE LT (10109A) / STROBE LT (10109) / LEFT REAR CAP GROUND SPLICE (10160) CH3_45 / *D127-G *D127A 18OR 16WH / ELEC PANEL/ LEFT BODY (10400) E127A 18OR / E127A 18OR / STROBE LIGHT SWITCH (10270) / INPOWER STROBE MODULE (10500) / FUSE F62 (10306) CH3_94N FUSE B3-E (10304) CH3_15 / SPLICE PACK STROBE LIGHT (10517) CH7_15,16 / B127-G 16OR B127D 16OR B89E 16OR / B89F 16OR / GROUND SPLICE (10337) CH3_41,95L / B127B 16OR / Figure 277 / STROBE LIGHT ACTIVATED WITH SWITCH OR PUPIL WARNING LIGHT

7.18. STROBE LIGHT ACTIVATED WITH MOMENTARY SWITCH, P. 14
Figure 278 STROBE LIGHT ACTIVATED WITH MOMENTARY SWITCH

Components: FUSE B3-E (10304); FUSE F62 (10306); GROUND SPLICE (10160); LATCH RELAY (10300); LT SECT 1 (10474A); REAR CAP (10406); SPLICE (10333); SPLICE (10337); SPLICE (10473); STROBE LT (10109); STROBE LT (10109A); STROBE LT (10517); SWITCH (10270)
Wires (circuit gauge+color): B127 16BK; B127-G 16WH; B127A 16BK; B127B 16OR; B127C 16OR; B127D 16OR; B62-GW 18WH; B62W 18DKBL; D127-G 16WH; D127A 18OR; E127-GA 18WH; E127A 18OR; E127B 18OR
See also sheets: CH3_15, CH3_41, CH3_45, CH3_56, CH7_15, CH8_34
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.18. STROBE LIGHT ACTIVATED WITH MOMENTARY SWITCH, P. 14 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 STROBE LIGHT ACTIVATED W/MOMENTARY SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / STROBE LT SWITCH (10270) / 87 85 / STOBE LT LATCH RELAY (10300) / B62W 18DKBL B62-GW 18WH !B127 16BK !B127A 16BK @B127 16BK @B127A 16BK / B127-G 16WH / GROUND SPLICE (10337) CH3_41,95L / SW ILLUMINATION SPLICE (10333) CH8_34 FUSE B3-E (10304) CH3_15 / B127B 16OR B127D 16OR / B127C 16OR / E127A 18OR / ELEC PANEL/ L BODY D1 (10400A/B /10400) / SPLICE PACK STROBE LT (10517) CH7_15,16 / E127-GA 18WH / L BODY/ REAR CAP (10406) / E127-GA 18WH E127A 18OR / E127B 18OR / STROBE LT (10109) / #D127-G 16WH / L REAR CAP GROUND SPLICE (10160) CH3_45 / #D127A 18OR / GROUND SPLICE (10473) CH3_56 / *D127-G *D127A 18OR 16WH / STROBE LT SECT 1 (10474A) / FUSE F62 (10306) CH3_94N / E127A 18OR / Figure 278 / STROBE LIGHT ACTIVATED WITH MOMENTARY SWITCH

7.19. DOUBLE STROBE LIGHT WITHOUT 7 WINDOW, P. 15
Figure 279 DOUBLE STROBE LIGHT WITHOUT 7 WINDOW

Components: FUSE B3-E (10304); FUSE F62 (10306); L BODY (10400/10400A/B); LATCH RELAY (10300); RELAY (10308-R2); SPLICE (10473); STROBE LT (10517); STROBE LT RELAY (10308); STROBE LT SW (10270)
Wires (circuit gauge+color): B127A 16OR; B127B 16OR; B127C 16OR; E127-GA 18WH; E127-GB 18WH; E127A 18OR; E127C 18OR
See also sheets: CH3_56, CH7_10, CH7_11, CH7_12, CH7_14
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.19. DOUBLE STROBE LIGHT WITHOUT 7 WINDOW, P. 15 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 DOUBLE STROBE LIGHT N/7 WINDOW / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / E127-GB E127-GB E127-GA E127C 18OR 18WH 18WH 18WH / E127C 18OR / ELEC PANEL/ L BODY (10400/10400A/B) / E127-GB 18WH / E127A E127A 18OR 18OR / RELAY SW RELAY (10308-R2) LT CH7_11,13 LT LT LT (10300) STROBE (10270) STROBE STROBE STROBE (10308) CH3_12A CH7_12 CH7_14 LATCH RELAY / B127B 16OR / !B127B 16OR / @B127B @B127A !B127A !B127B 16OR 16OR 16OR 16OR / B3-E (10304) CH7_10 FUSE / STROBE LT SECT 1 (10474A) SECT 2 (10474B) SECT 3 (10474C) / GROUND SPLICE (10473) CH3_56 / E127A 18OR / W/12 WDO / SPLICE PACK STROBE LT (10517) / E127C E127C 18OR 18OR / W/SECT 1-2 W/12 WINDOW / E127-GA 18WH / B127C 16OR / W/12 WINDOW W/SECT 1-3 / W/12 WINDOW W/SECT 4-12 / @B127B 16OR / F62 (10306) CH3_94N FUSE / Figure 279 / DOUBLE STROBE LIGHT WITHOUT 7 WINDOW

7.20. DOUBLE STROBE LIGHT WITH 7 WINDOW, P. 16
Figure 280 DOUBLE STROBE LIGHT WITH 7 WINDOW

Components: FUSE B3-E (10304); FUSE F62 (10306); LATCH RELAY (10300); LEFT BODY (10400/10400A/B); RELAY (10308-R2); SPLICE (10473); STROBE LIGHT (10517); STROBE LIGHT RELAY (10308); SWITCH (10270)
Wires (circuit gauge+color): B127A 16OR; B127B 16OR; B127C 16OR; E127-GA 18WH; E127-GB 18WH; E127A 18OR; E127C 18OR
See also sheets: CH3_56, CH7_10, CH7_11, CH7_12, CH7_14
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.20. DOUBLE STROBE LIGHT WITH 7 WINDOW, P. 16 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / DOUBLE STROBE LIGHT W/7 WINDOW / CHAPTER 7 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / E127-GB E127-GA 18WH 18WH / STROBE LT SECT 3 (10474C) / SPLICE PACK STROBE LIGHT (10517) E / E127C 18OR / E127C 18OR / E127A 18OR / E127-GA E127-GB E127C 18OR 18WH 18WH / STROBE LT SECT 1 (10474A) SECT 2 (10474B) / GROUND SPLICE (10473) CH3_56 / ELEC PANEL/ LEFT BODY (10400/10400A/B) / RELAY LIGHT LIGHT LIGHT LIGHT RELAY (10308-R2) CH7_11,13 STROBE (10270) STROBE STROBE (10300) STROBE (10308) CH3_12A SWITCH CH7_12 CH7_14 LATCH RELAY / B127B 16OR / !B127B 16OR / @B127A !B127A !B127B @B127B 16OR 16OR 16OR 16OR / B3-E (10304) CH7_10 FUSE / B127C @B127B 16OR 16OR / E127-GB 18WH / E127-GA 18WH / F62 (10306) CH3_94N FUSE / Figure 280 / DOUBLE STROBE LIGHT WITH 7 WINDOW

7.21. STROBE LIGHT INDICATOR, P. 17
Figure 281 STROBE LIGHT INDICATOR

Components: FUSE B3-E (10304); INDICATOR (10394); INDICATOR (10395); SPLICE (10334); STROBE LIGHT SWITCH (10270); SWITCH ILLUM SPLICE (10333)
Wires (circuit gauge+color): B127-GA 16WH; B127A 16OR; B127F 16OR; B62-GW 18WH; B62W 18DKBL
See also sheets: CH3_15, CH3_34, CH8_34
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.21. STROBE LIGHT INDICATOR, P. 17 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 / STROBE LIGHT INDICATOR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / STROBE LIGHT SWITCH (10270) 8 / STROBE LIGHT INDICATOR (10394) A / B62W 18DKBL B62-GW 18WH / GROUND FUSE B3-E SPLICE (10304) (10334) CH3_15 CH3_34,95F / B127F 16OR / SWITCH ILLUM SPLICE (10333) CH8_34 / B127A 16OR / STROBE LIGHT INDICATOR (10395) / B127-GA B127-GA 16WH 16WH / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 281 / STROBE LIGHT INDICATOR

7.22. STOP / TAIL / DIRECTIONAL LIGHTS, P. 18
Figure 282 STOP / TAIL / DIRECTIONAL LIGHTS

Components: ELEC PANEL (10400); GROUND SPLICE (10160); LEFT BODY/REAR CAP (10406/10406); LEFT STOP/TAIL LIGHT (10102); LIGHT (10101); LIGHT (10124); LIGHT SPLICE (10420); RIGHT BODY (10700); SIGN (10128); SPLICE (10161); SPLICE (10704); STOP/TAIL LT (10123)
Wires (circuit gauge+color): D11-GD 16WH; D11-GE 16WH; D56-G 16WH; D57 16LTGN; D57-G 16WH; D57-M 16LTGN; D57A 16LTGN; D57B 16LTGN; D58B 16BN; D68L-G 16WH; D68L-M 16BN; D68R-G 16WH; D68R-M 16BN; D70L-M 16RD; D70R-M 16RD; E57 16LTGN; E57-M 16LTGN; E58B 16BN; E68L-M 16BN; E68R-M 16BN; E70L-M 14RD; E70R-M 14RD; F57B 16LTGN
See also sheets: CH3_45, CH3_46, CH6_14, CH7_20, CH7_37, CH7_47, CH7_54, CH7_55, CH7_66
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.22. STOP / TAIL / DIRECTIONAL LIGHTS, P. 18 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 STOP/TAIL/DIRECTIONAL LIGHTS / MJV0488 19NOV21 ADDED CHAPTER CH7_34A,34B. / LEFT BODY/REAR CAP (10406/10406) A7 / D68L-M 16BN / D70L-M 16RD D70R-M 16RD D68R-M 16BN / D56-M 16YL D57-M 16LTGN RIGHT REAR CAP GROUND SPLICE (10161) CH3_46 / D56 16YL / E68L-M 16BN / E70L-M 14RD E70R-M 14RD / E68R-M 16BN / E56-M 16YL E57-M 16LTGN / E57 16LTGN / *E56 16YL / @E56 16YL / LEFT STOP/TAIL LIGHT (10102) 2 / D58B 16BN / D68R-G 16WH 2 / D68L-G 16WH / 2 D57-G 16WH / RIGHT STOP/TAIL LT (10123) / LEFT DIRECTIONAL LIGHT (10101) / W/STANDERD TURN LIGHT REAR CAP/ RIGHT BODY (10700) A1 F57B 16LTGN / D57A 16LTGN D57B 16LTGN / CLEARANCE/ IDENTIFICATION LIGHTS CH7_47,48,49,50,51 / DRIVERS ALERT SIGN (10128) CH6_14 / @E58B 16BN / *E58B 16BN / COMBINATION SPLICE (10704) CH7_37,38 / RIGHT DIRECTIONAL LIGHT (10124) / D57 16LTGN D57 16LTGN D11-GD 16WH / DIRECTIONAL /CLEARANCE LIGHT SPLICE (10420) CH7_54 LEFT BODY/ ELEC PANEL (10400) CH7_20,21,22, 23,24,25,26,27, 28,29,30.31, 32,33,34,34A,34B / D11-GE 16WH / GROUND SPLICE (10160) CH3_45 / D56-G 16WH / LEFT BODY/ ELEC PANEL (10400) CH7_20,21,22, 23,24,25,26, 27,28,29, 30.31,32,33,34 34A,34B W/DRIVER ALERT SIGN / LEFT BODY/ ELEC PANEL (10400) CH7_20,21,22, 23,24,25,26, 27,28,29,30,31 32,33,34,34A,34B / Figure 282 / STOP / TAIL / DIRECTIONAL LIGHTS

7.23. STOP / TAIL / DIRECTIONAL / LICENSE PLATE LIGHT, P. 19
Figure 283 STOP / TAIL / DIRECTIONAL / LICENSE PLATE LIGHT

Components: ELEC PANEL (10400); GROUND SPLICE (10160); LEFT BODY/REAR CAP (10406/10406); LEFT LICENSE LT (10105); RIGHT LICENSE LT (10126); SPLICE (10160); SPLICE (10161)
Wires (circuit gauge+color): D68 16BN; D68-G 16WH; D68-GA 16WH; D68-GB 16WH; D68-GC 16WH; D68-GD 16WH; D68-GE 16WH; D68A 16BN; D68B 16BN; D68C 16BN; D68D 16BN; D68G 16WH; D68GA 16WH; D70 14RD; D70A 16RD; D70B 16RD; D70C 16RD; D70D 16RD; E68 16BN; E68L-M 16BN; E68R-M 16BN; E70 14RD
See also sheets: CH3_45, CH3_46, CH7_20
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.23. STOP / TAIL / DIRECTIONAL / LICENSE PLATE LIGHT, P. 19 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 7 STOP / TAIL / DIRECTIONAL / LICENSE PLATE LIGHT / MJV0488 19NOV21 ADDED CHAPTER CH7_34A,34B. / GROUND SPLICE (10160) CH3_45 / LEFT BODY/REAR CAP (10406/10406) A6 / D70 14RD *D68A 16BN / D68 16BN / E70 14RD E68L-M 16BN / E68 16BN / D70A 16RD D68-GA 16WH / @D68A 16BN / D70B 16RD D68-GC 16WH %D68C 16BN D68B 16BN *D68C 16BN *D68B 16BN / %D68B 16BN / RIGHT LICENSE LT (10126) 1 / ##D68D 16BN ##D68-GD 16WH / LEFT LICENSE LT (10105) / LEFT STOP/TAIL LICENSE LT (#10104) / RIGHT STOP/TAIL LICENSE LT (#10125) / D68B 16BN ##D68-GB 16WH D68-GB 16WH / GROUND SPLICE (10160) CH3_45 / GROUND SPLICE (10161) CH3_46 / *D68G 16WH @D68-G 16WH *D68GA 16WH @D68-GA 16WH / @D68C 16BN @D70C 16RD / @D68D 16BN @D70D 16RD / ADDITIONAL RH STOP/TAIL LT (@10126A) / GROUND SPLICE (10160) CH3_45 ADDITIONAL LH STOP/TAIL LT (@10105A) / E68R-M 16BN / W/OMIT TAIL LT / *D68-GB 16WH @D68-GB 16WH / LEFT BODY/ ELEC PANEL (10400) CH7_20,21,22, 23,24,25,26, 27,28,29,30,31, 32,33,34,34A,34B / Figure 283 / STOP / TAIL / DIRECTIONAL / LICENSE PLATE LIGHT

7.24. STOP / TAIL / TURN LIGHTS WITH CHECK WITHOUT CHILD CHECK MATE
Figure 284 STOP / TAIL / TURN LIGHTS WITH CHECK WITHOUT CHILD CHECK MATE WITH 9

Components: CL LT RELAY (10308); CL LT RELAY (10308-R1); CL LT SPLICE (10420); CONN C (10025C); CONN D (10025D); CONTROLLER (1600); CONTROLLER (1603); CONTROLLER (1604); ELEC PANEL (1702); FR CAP (10001); HAZZARD ASSERT (11338); L BODY (10406); OPTION (10381); PLATFORM (1702); PLATFORM (1703)
Wires (circuit gauge+color): A56A 18OR; A56B 18OR; A57C 14LTGN; A58 14BN; A58B 14BN; A58C 14BN; A70BC 16OR; B57 16LTGN; B57A 16LTGN; B57B 16LTGN; B57C 16LTGN; B57R-M 16LTGN; B58E 16BN; B58F 18BN; B68 16BN; B68A 16BN; B68D 16BN; B68L-M 16BN; B68R-M 16BN; B70 16RD; B70A 16RD; B70B 16RD; B70L-M 16RD; C57R-M 18LTGN; C68 16BN; C68L-M 16BN; C68R-M 16BN; C70 16RD; C70L-M 16RD; C70R-M 16RD; E57 16LTGN; E57-M 16LTGN; E68 16BN; E68L-M 16BN; E68R-M 16BN; E70 14RD; E70L-M 14RD; E70R-M 14RD
See also sheets: CH13_15, CH18_23, CH7_18, CH7_19, CH7_54, CH7_66
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.24. STOP / TAIL / TURN LIGHTS WITH CHECK WITHOUT CHILD CHECK MATE WITH 9, P. 20 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 23DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / E68 16BN E56-M 16YL E70L-M 14RD E68L-M 16BN / #B58F 18BN !B58F 18BN L BODY/ ELEC PANEL (10400/10400A/ @10400B) A2 / B68A 16BN / B68 16BN B56L-M 16YL B70L-M 16RD B68L-M 16BN / ELEC PANEL/ PLATFORM (1702) 6 B58E A58B 16BN 14BN ELEC PANEL/ FR CAP (10001) C1 / REAR CAP/ L BODY (10406) CH7_19 REAR CAP/ L BODY (10406) CH7_18 / C68 16BN C56L-M 18YL C70L-M 16RD C68L-M 16BN / CL LT RELAY (10308) CH7_66A CL LT RELAY (10308-R1) CH7_66 / B68D 16BN / A58C 14BN A58 14BN / J2-10 WAY BODY CONTROLLER (1604) PARK LT F COMMAND 2 PARK LT G COMMAND 1 LT MONITOR CONN D (10025D) / A56B 18OR / B66 16YL / J3-RED BODY CONTROLLER (1600) LEFT TURN A7 SIGNAL / ELEC PANEL/ PLATFORM (1703) B11 A56A 18OR / TAIL LT OPTION (10381) / 8 2 / PLATFORM/ ELEC PANEL (1702) 64 A56C 14YL A57C 14LTGN / REAR CAP/ L BODY (10406) CH7_19 J1-12 WAY BODY CONTROLLER (1603) LEFT REAR TURN SIGN D RIGHT REAR M TURN SIGN / E68R-M 16BN E56A 16YL E70R-M 14RD E57-M 16LTGN E56 16YL E57 16LTGN E70 14RD / REAR CAP/ L BODY (10406) CH7_18 / B70R-M 16DR B57R-M 16LTGN B56A 16YL B57A 16LTGN B70A 16RD / B57B 16LTGN B70B 16RD / C10 C7 C4 / C70R-M 16RD C57R-M 18LTGN C56 18YL C57 18YL / C70 16RD / B56B 16YL / C68R-M 16BN / B68R-M 16BN / LT MONITOR CONN C (10025C) / 2 3 / B56 16YL B57 16LTGN / REAR CAP/ L BODY (10406) CH7_18,19 / B70 16RD / A6 B3 C4 / DIRECTIONAL CL LT SPLICE (10420) CH7_54 / Figure 284 / STOP / TAIL / TURN LIGHTS WITH CHECK WITHOUT CHILD CHECK MATE WITH 9

7.25. STOP / TAIL / TURN LIGHTS WITH CHECK WITH CHILD CHECK MATE WITH 9, P. 21
Figure 285 STOP / TAIL / TURN LIGHTS WITH CHECK WITH CHILD CHECK MATE WITH 9

Components: CL LT RELAY (10308); CL LT RELAY (10308-R1); CONN C (10025C); CONN D (10025D); CONTROLLER (1600); CONTROLLER (1603); CONTROLLER (1604); ELEC PANEL (1702); FR CAP (10001); L BODY (10406); MODULE (10212); OPTION (10381); PLATFORM (1702); PLATFORM (1703); STOP LT RELEY (1011-R3)
Wires (circuit gauge+color): A56A 18OR; A56B 18OR; A57C 14LTGN; A58 14BN; A58B 14BN; A58C 14BN; A70BC 16OR; B57 16LTGN; B57A 16LTGN; B57B 16LTGN; B57R-M 16LTGN; B58E 16BN; B58F 18BN; B68 16BN; B68A 16BN; B68D 16BN; B68L-M 16BN; B68R-M 16BN; B70 18RD; B70A 16RD; B70B 16RD; B70C 18RD; B70L-M 16RD; B70R-M 16RD; C57R-M 18LTGN; C68 16BN; C68L-M 16BN; C68R-M 16BN; C70 16RD; C70L-M 16RD; C70R-M 16RD; E57 16LTGN; E57-M 16LTGN; E68 16BN; E68L-M 16BN; E68R-M 16BN; E70 14RD; E70L-M 14RD; E70R-M 14RD
See also sheets: CH18_14, CH7_18, CH7_19, CH7_66, CH7_70
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.25. STOP / TAIL / TURN LIGHTS WITH CHECK WITH CHILD CHECK MATE WITH 9, P. 21 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 STOP/TAIL/TURN LIGHTS W/CHECK W/CHILD CHECK MATE W/9 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / TAIL TAIL LT LT OPTION OPTION (10381) (10381) #B58F 18BN !B58F 18BN L BODY/ ELEC PANEL (10400/10400A/ @10400B) A2 / B58E B58E 16BN 16BN ELEC PANEL/ FR CAP (10001) C1 / ELEC ELEC PANEL/ PANEL/ PLATFORM PLATFORM (1702) (1702) 6 6 A58B A58B 14BN 14BN / CL LT RELAY (10308) CH7_66A CL LT RELAY (10308-R1) CH7_66 / B68D B68D 16BN 16BN / A58C A58C 14BN 14BN A58 A58 14BN 14BN / A56B A56B 18OR 18OR / B66 B66 16YL 16YL / J3-RED J3-RED BODY BODY CONTROLLER CONTROLLER (1600) (1600) A7 A7 LEFT LEFT TURN TURN SIGNAL SIGNAL / ELEC ELEC PANEL/ PANEL/ PLATFORM PLATFORM (1703) (1703) B11 B11 A56A A56A 18OR 18OR / J1-12 WAY BODY CONTROLLER (1603) LEFT REAR TURN SIGN D RIGHT REAR M TURN SIGN / PLATFORM/ ELEC PANEL (1702) 64 / LT MONITOR CONN C (10025C) / B70 18RD / ELEC PANEL/ PLATFORM (1703) A1 A1 / A70BC A70BC 16OR 16OR #A70BC 16OR / E68 16BN E56-M 16YL E70L-M 14RD E68L-M 16BN / E70R-M 14RD E57-M 16LTGN E56 16YL E57 16LTGN E70 14RD / E68R-M 16BN / B68A 16BN / B70R-M 16RD B57R-M 16LTGN B56A 16YL / B68 16BN B56L-M 16YL B70L-M 16RD B68L-M 16BN / B56B 16YL B57B 16LTGN B70B 16RD / B57A 16LTGN B70A 16RD / C68 16BN C56L-M 18YL C70L-M 16RD C68L-M 16BN / C70R-M 16RD C57R-M 18LTGN C56 18YL C57 18YL / C70 16RD / C68R-M 16BN / B68R-M 16BN / A56C 14YL A57C 14LTGN / B56 16YL 65 B57 16LTGN / REAR CAP/ L BODY (10406) CH7_19 REAR CAP/ L BODY (10406) CH7_18 / REAR CAP/ L BODY (10406) CH7_18 / REAR CAP/ L BODY (10406) CH7_19 / REAR CAP/ L BODY (10406) CH7_18,19 / 8 2 / Figure 285 / STOP / TAIL / TURN LIGHTS WITH CHECK WITH CHILD CHECK MATE WITH 9

7.26. STOP / TAIL / TURN LIGHTS WITH VIDEO LIGHT MONITOR WITH 9, P. 22
Figure 286 STOP / TAIL / TURN LIGHTS WITH VIDEO LIGHT MONITOR WITH 9

Components: CL LT RELAY (10308); CL LT RELAY (10308-R1); CONN C (10025C); CONN D (10025D); CONTROLLER (1603); CONTROLLER (1604); ELEC PANEL (1702); ELEC PANEL/PLATFORM (1703); FR CAP (10001); J3-RED BODY CONTROLLER (1600); L BODY (10406); OPTION (10381); PLATFORM (1702); PLATFORM (1703); SEON SIGNALS (11644); STOP ARM EXTEND (10358B)
Wires (circuit gauge+color): A56A 18OR; A56B 18OR; A57C 14LTGN; A58 14BN; A58B 14BN; A58C 14BN; A70BC 16OR; B119V 18GY; B57 16LTGN; B57A 16LTGN; B57B 16LTGN; B57R-M 16LTGN; B57RA 18LTGN; B58E 16BN; B58F 18BN; B68 16BN; B68A 16BN; B68D 16BN; B68L-M 16BN; B68R-M 16BN; B70 16RD; B70A 16RD; B70B 16RD; B70C 18RD; B70L-M 16RD; B70R-M 16RD; C57R-M 18LTGN; C68 16BN; C68L-M 16BN; C68R-M 16BN; C70 16RD; C70L-M 16RD; C70R-M 16RD; E57 16LTGN; E57-M 16LTGN; E68 16BN; E68L-M 16BN; E68R-M 16BN; E70 14RD; E70L-M 14RD; E70R-M 14RD
See also sheets: CH7_18, CH7_19, CH7_66, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.26. STOP / TAIL / TURN LIGHTS WITH VIDEO LIGHT MONITOR WITH 9, P. 22 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 STOP/TAIL/TURN LIGHTS W/VIDEO LIGHT MONITOR W/9 ELEC PANEL/PLATFORM (1703) B11 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / TAIL LT OPTION (10381) !B58F 18BN #B58F 18BN L BODY/ ELEC PANEL (10400/10400A/ @10400B) A2 / B58E 16BN ELEC PANEL/ FR CAP (10001) C1 / ELEC PANEL/ PLATFORM (1702) 6 A58B 14BN / CL LT RELAY (10308-R1) CH7_66 CL LT RELAY (10308) CH7_66A / B68D 16BN / A58C 14BN A58 14BN / J3-RED BODY CONTROLLER (1600) LEFT TURN A7 SIGNAL J2-10 WAY BODY CONTROLLER (1604) PARK LT F COMMAND 2 G PARK LT COMMAND 1 LT MONITOR CONN D (10025D) / A56B 18OR / B66 16YL / A56A 18OR / J1-12 WAY BODY CONTROLLER (1603) LEFT REAR TURN SIGN D RIGHT REAR M TURN SIGN / PLATFORM/ ELEC PANEL (1702) 64 / LT MONITOR CONN C (10025C) / E68 16BN E56-M 16YL E70L-M 14RD E68L-M 16BN / E68R-M 16BN E70R-M 14RD E57-M 16LTGN E56 16YL E57 16LTGN E70 14RD / B68R-M 16BN B70R-M 16RD B57R-M 16LTGN / C68R-M 16BN C70R-M 16RD C57R-M 18LTGN C56 B56B 18YL 16YL B57B C57 16LTGN 18YL B70B C70 16RD 16RD ELEC PANEL/ PLATFORM (1703) A1 / B56A 16YL B57A 16LTGN B70A 16RD / D1 C10 / C7 C4 / A56C 14YL A57C 14LTGN / B70 16RD / A70BC A70BC 16OR 16OR / J2-10 WAY BODY CONTROLLER (1604) TAIL LIGHT D SIGNAL / B56 16YL B57 16LTGN / REAR CAP/ L BODY (10406) CH7_19 REAR CAP/ L BODY (10406) CH7_18 / REAR CAP/ L BODY (10406) CH7_18 / REAR CAP/ L BODY (10406) CH7_19 / REAR CAP/ L BODY (10406) CH7_18,19 / B68A 16BN / B68 16BN B56L-M 16YL B70L-M 16RD B68L-M 16BN / C68 16BN C56L-M 18YL C70L-M 16RD C68L-M 16BN / A8 A6 / 8 2 / 7 2 / 3 4 1 2 / SEON SIGNALS (11644) / Figure 286 / STOP / TAIL / TURN LIGHTS WITH VIDEO LIGHT MONITOR WITH 9

7.27. STOP / TAIL / TURN LIGHTS WITH CHECK WITH THEFT MATE WITH 9, P. 23
Figure 287 STOP / TAIL / TURN LIGHTS WITH CHECK WITH THEFT MATE WITH 9

Components: CL LT RELAY (10308); CL LT RELAY (10308-R1); CONN C (10025C); CONN D (10025D); CONTROLLER (1600); CONTROLLER (1603); CONTROLLER (1604); ELEC PANEL (1702); FR CAP (10001); L BODY (10406); OPTION (10381); PLATFORM (1702); PLATFORM (1703); STOP LT RELAY (1011-R3); YEL DOT (11647)
Wires (circuit gauge+color): A56A 18OR; A56B 18OR; A57C 14LTGN; A58 14BN; A58B 14BN; A58C 14BN; A70BC 16OR; A70D 18RD; B57 16LTGN; B57A 16LTGN; B57B 16LTGN; B57R-M 16LTGN; B58E 16BN; B58F 18BN; B68 16BN; B68A 16BN; B68D 16BN; B68L-M 16BN; B68R-M 16BN; B70 16RD; B70A 16RD; B70B 16RD; B70L-M 16RD; C57R-M 18LTGN; C68 16BN; C68L-M 16BN; C68R-M 16BN; C70 16RD; C70L-M 16RD; C70R-M 16RD; E57 16LTGN; E57-M 16LTGN; E68 16BN; E68L-M 16BN; E68R-M 16BN; E70 14RD; E70L-M 14RD; E70R-M 14RD
See also sheets: CH18_05, CH7_18, CH7_19, CH7_66, CH7_70
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.27. STOP / TAIL / TURN LIGHTS WITH CHECK WITH THEFT MATE WITH 9, P. 23 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 STOP/TAIL/TURN LIGHTS W/CHECK W/THEFT MATE W/9 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / E68 16BN E56-M 16YL E70L-M 14RD E68L-M 16BN / E68R-M 16BN E70R-M 14RD E57-M 16LTGN E56 16YL E57 16LTGN E70 14RD / B68A 16BN / B68R-M 16BN B70R-M 16DR B57R-M 16LTGN B56A 16YL B57A 16LTGN B70A 16RD / B68 16BN B56L-M 16YL B70L-M 16RD B68L-M 16BN / B56B 16YL B57B 16LTGN B70B 16RD / #B58F 18BN !B58F 18BN L BODY/ ELEC PANEL (10400/10400A/ @10400B) / ELEC PANEL/ PLATFORM (1702) 6 B58E A58B 16BN 14BN ELEC PANEL/ FR CAP (10001) / REAR CAP/ L BODY (10406) CH7_19 REAR CAP/ L BODY (10406) CH7_18 / C68 16BN C56L-M 18YL C70L-M 16RD C68L-M 16BN / C68R-M 16BN C70R-M 16RD C57R-M 18LTGN C56 18YL C57 18YL / C70 16RD / REAR CAP/ L BODY (10406) CH7_19 / A56C 14YL A57C 14LTGN / PLATFORM/ ELEC PANEL (1702) 64 / J1-12 WAY BODY CONTROLLER (1603) LEFT REAR TURN SIGN D RIGHT REAR M TURN SIGN / CL LT RELAY (10308) CH7_66A CL LT RELAY (10308-R1) CH7_66 / B68D 16BN / J2-10 WAY BODY CONTROLLER (1604) PARK LT F COMMAND 2 PARK LT G COMMAND 1 / A58C 14BN A58 14BN / B70 16RD / ELEC PANEL/ PLATFORM (1703) A1 / LT MONITOR CONN D (10025D) / LT MONITOR CONN C (10025C) / B56 16YL B57 16LTGN / A56B 18OR / B66 16YL / J3-RED BODY CONTROLLER (1600) LEFT TURN A7 SIGNAL / ELEC PANEL/ PLATFORM (1703) B11 A56A 18OR / TAIL LT OPTION (10381) / 8 2 / REAR CAP/ L BODY (10406) CH7_18 / REAR CAP/ L BODY (10406) CH7_18,19 / J2-10 WAY BODY CONTROLLER (1604) TAIL LIGHT D SIGNAL / A70BC 16OR / #A70BC 16OR / Figure 287 / STOP / TAIL / TURN LIGHTS WITH CHECK WITH THEFT MATE WITH 9

7.28. STOP / TAIL / TURN LIGHTS WITH CHECK WITH VIDEO WITH THEFT MATE
Figure 288 STOP / TAIL / TURN LIGHTS WITH CHECK WITH VIDEO WITH THEFT MATE WITH 9

Components: CL LT RELAY (10308); CL LT RELAY (10308-R1); CONN C (10025C); CONN D (10025D); CONTROLLER (1603); CONTROLLER (1604); ELEC PANEL (1702); ELEC PANEL/PLATFORM (1703); FR CAP (10001); J3-RED BODY CONTROLLER (1600); L BODY (10406); OPTION (10381); PLATFORM (1702); PLATFORM (1703); SIGNALS (11644); STOP ARMEXTEND (10358B); STOP LT RELAY (1011); THEFT MATE YEL DOT (11647)
Wires (circuit gauge+color): A56A 18OR; A56B 18OR; A57C 14LTGN; A58 14BN; A58B 14BN; A58C 14BN; A70BC 16OR; B119V 18GY; B57 16LTGN; B57A 16LTGN; B57B 16LTGN; B57R-M 16LTGN; B57RA 18LTGN; B58E 16BN; B58F 18BN; B68 16BN; B68A 16BN; B68D 16BN; B68L-M 16BN; B68R-M 16BN; B70 16RD; B70A 16RD; B70B 16RD; B70C 18RD; B70D 18RD; B70L-M 16RD; B70R-M 16RD; C57R-M 18LTGN; C68 16BN; C68L-M 16BN; C68R-M 16BN; C70 16RD; C70L-M 16RD; C70R-M 16RD; E57 16LTGN; E57-M 16LTGN; E68 16BN; E68L-M 16BN; E68R-M 16BN; E70 14RD; E70L-M 14RD; E70R-M 14RD
See also sheets: CH18_05, CH7_18, CH7_19, CH7_66, CH7_70, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.28. STOP / TAIL / TURN LIGHTS WITH CHECK WITH VIDEO WITH THEFT MATE WITH 9, P. 24 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 23DEC20 / CHAPTER 7 STOP/TAIL/TURN LIGHTS W/CHECK W/VIDEO W/THEFT MATE W/9 ELEC PANEL/PLATFORM (1703) B11 A56A 18OR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / E68 16BN E56-M 16YL E70L-M 14RD E68L-M 16BN / TAIL LT OPTION (10381) #B58F 18BN !B58F 18BN L BODY/ ELEC PANEL (10400/10400A/ @10400B) A2 / B68A 16BN / B68 16BN B56L-M 16YL B70L-M 16RD B68L-M 16BN / B3 C4 B2 / B56B 16YL B57B 16LTGN B70B C70 16RD 16RD ELEC PANEL/ PLATFORM (1703) A1 A70BC A70BC 16OR 16OR #A70BC 16OR / B58E 16BN ELEC PANEL/ FR CAP (10001) C1 / REAR CAP/ L BODY (10406) CH7_19 REAR CAP/ L BODY (10406) CH7_19 / C10 C7 C4 / C68 16BN C56L-M 18YL C70L-M 16RD C68L-M 16BN / C68R-M 16BN C70R-M 16RD C57R-M 18LTGN C56 18YL C57 18YL / REAR CAP/ L BODY (10406) CH7_18 / REAR CAP/ L BODY (10406) CH7_19 J1-12 WAY BODY CONTROLLER (1603) LEFT REAR TURN SIGN D RIGHT REAR M TURN SIGN / A56C 14YL A57C 14LTGN / ELEC PANEL/ PLATFORM (1702) 6 A58B 14BN / CL LT RELAY (10308) CH7_66A CL LT RELAY (10308-R1) CH7_66 / B68D 16BN / B70 16RD / B70D 18RD / LT MONITOR CONN C (10025C) / J2-10 WAY BODY CONTROLLER (1604) TAIL LIGHT D SIGNAL STOP LT RELAY (1011) CH7_70 THEFT MATE YEL DOT (11647) CH18_05 / B56 16YL B57 16LTGN / A56B 18OR / B66 16YL / 8 2 / 2 3 / B A / SEON SIGNALS (11644) / 3 4 1 2 / REAR CAP/ L BODY (10406) CH7_18,19 / Figure 288 / STOP / TAIL / TURN LIGHTS WITH CHECK WITH VIDEO WITH THEFT MATE WITH 9

7.29. STOP / TAIL / TURN LIGHTS WITH SEON WITH ADDITIONAL POWER WITH 9, P. 25
Figure 289 STOP / TAIL / TURN LIGHTS WITH SEON WITH ADDITIONAL POWER WITH 9

Components: CL LT RELAY (10308); CL LT RELAY (10308-R1); CL LT SPLICE (10420); CONN C (10025C); CONN D (10025D); CONTROLLER (1600); CONTROLLER (1603); CONTROLLER (1604); ELEC PANEL (1702); EXTEND (10358B); FR CAP (10001); L BODY (10406); OPTION (10381); PLATFORM (1702); PLATFORM (1703); SEON SIGNALS (11654)
Wires (circuit gauge+color): A56A 18OR; A56B 18OR; A57C 14LTGN; A58 14BN; A58B 14BN; A58C 14BN; A70BC 16OR; B119 18GY; B57 16LTGN; B57A 16LTGN; B57B 16LTGN; B57R-M 16LTGN; B57RA 18LTGN; B58E 16BN; B58F 18BN; B68 16BN; B68A 16BN; B68D 16BN; B68L-M 16BN; B68R-M 16BN; B70 16RD; B70A 16RD; B70B 16RD; B70C 18RD; B70L-M 16RD; C57R-M 18LTGN; C68 16BN; C68L-M 16BN; C68R-M 16BN; C70 16RD; C70L-M 16RD; C70R-M 16RD; E57 16LTGN; E57-M 16LTGN; E68 16BN; E68L-M 16BN; E68R-M 16BN; E70 14RD; E70L-M 14RD; E70R-M 14RD
See also sheets: CH7_18, CH7_19, CH7_31, CH7_66, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.29. STOP / TAIL / TURN LIGHTS WITH SEON WITH ADDITIONAL POWER WITH 9, P. 25 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 23DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / #B58F 18BN !B58F 18BN L BODY/ ELEC PANEL (10400/10400A/ @10400B) A2 E68 16BN B1 E56-M 16YL A5 E70L-M 14RD A7 E68L-M 16BN / B68A 16BN / B68 16BN B56L-M 16YL B70L-M 16RD B68L-M 16BN / REAR CAP/ L BODY (10406) CH7_19 REAR CAP/ L BODY (10406) CH7_18 / C68 16BN C56L-M 18YL C70L-M 16RD C68L-M 16BN / B58E 16BN / CL LT RELAY (10308) CH7_66A CL LT RELAY (10308-R1) CH7_66 / B68D 16BN / A58C 14BN A58 14BN / J3-RED BODY CONTROLLER (1600) LEFT TURN A7 SIGNAL J2-10 WAY BODY CONTROLLER (1604) PARK LT F COMMAND 2 G PARK LT COMMAND 1 LT MONITOR CONN D (10025D) / 7 3 1 8 2 / A56B 18OR / B66 16YL / TAIL LT OPTION (10381) / B A / PLATFORM/ ELEC PANEL (1702) 64 A56C 14YL A57C 14LTGN / REAR CAP/ L BODY (10406) CH7_19 J1-12 WAY BODY CONTROLLER (1603) LEFT REAR TURN SIGN D RIGHT REAR M TURN SIGN / E68R-M 16BN E56A 16YL E70R-M 14RD E57-M 16LTGN E56 16YL E57 16LTGN E70 14RD / REAR CAP/ L BODY (10406) CH7_18 / B70R-M 16DR B57R-M 16LTGN B56A 16YL B57A 16LTGN B70A 16RD / C70R-M 16RD C57R-M 18LTGN B56B C56 16YL 18YL B57B C57 16LTGN 18YL B70B C70 16RD 16RD ELEC PANEL/ PLATFORM (1703) A1 A70BC A70BC 16OR 16OR / C10 C7 C4 / C3 C5 / C68R-M 16BN / B68R-M 16BN / LT MONITOR CONN C (10025C) / 2 3 / B56 16YL B57 16LTGN / REAR CAP/ L BODY (10406) CH7_18,19 / B70 16RD / J2-10 WAY BODY CONTROLLER (1604) TAIL LIGHT D SIGNAL SEON SIGNALS (11654) / A6 B3 C4 B2 / DIRECTIONAL CL LT SPLICE (10420) CH7_31 / B70C 18RD B56LA 18YL B57RA 18LTGN B119 18GY / Figure 289 / STOP / TAIL / TURN LIGHTS WITH SEON WITH ADDITIONAL POWER WITH 9

7.30. STOP / TAIL / TURN LIGHTS WITHOUT CHECK WITHOUT CHILD CHECK MATE
Figure 290 STOP / TAIL / TURN LIGHTS WITHOUT CHECK WITHOUT CHILD CHECK MATE WITH 9

Components: CL LT RELAY (10308); CL LT RELAY (10308-R1); CONTROLLER (1600); CONTROLLER (1603); CONTROLLER (1604); L BODY (10406); OPTION (10381); PLATFORM (1702); PLATFORM (1703); STOP LT RELEY (1011-R3)
Wires (circuit gauge+color): A56A 18OR; A56B 18OR; A57C 14LTGN; A58 14BN; A58B 14BN; A58C 14BN; A70BC 16OR; B57 16LTGN; B57A 16LTGN; B57R 16LTGN; B58E 16BN; B58F 18BN; B68 16BN; B68D 16BN; B68L 16BN; B68R 16BN; B70 16RD; B70A 16RD; B70L 16RD; B70R 16RD; E57 16LTGN; E57-M 16LTGN; E68 16BN; E68L-M 16BN; E68R-M 16BN; E70 14RD; E70L-M 14RD; E70R-M 14RD
See also sheets: CH7_18, CH7_19, CH7_66, CH7_70
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.30. STOP / TAIL / TURN LIGHTS WITHOUT CHECK WITHOUT CHILD CHECK MATE WITH 9, P. 26 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 23DEC20 / CHAPTER 7 STOP/TAIL/TURN LIGHTS N/CHECK N/CHILD CHECK MATE W/9 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / !B58F 18BN / CL LT RELAY (10308-R1) CH7_66 CL LT RELAY (10308) CH7_66A J2-10 WAY BODY CONTROLLER (1604) PARK LT F COMMAND 2 G PARK LT COMMAND 1 / B68D 16BN / A56B 18OR / B66 16YL / J3-RED BODY CONTROLLER (1600) LEFT TURN A7 SIGNAL / ELEC PANEL/ PLATFORM (1703) B11 A56A 18OR / TAIL LT OPTION (10381) B / J1-12 WAY BODY CONTROLLER (1603) / ELEC PANEL/ PLATFORM (1702) 6 A58B 14BN / LEFT REAR D TURN SIGN / RIGHT REAR M TURN SIGN / A58C 14BN A58 14BN / A56C 14YL A57C 14LTGN / L BODY/ ELEC PANEL (10400/10400A/ @10400B) A2 B68 E68 16BN 16BN / B57 16LTGN / B56L 16YL B56A 16YL / B57R 16LTGN / B57A 16LTGN / B68R 16BN B68L 16BN / B56 16YL / B58E 16BN / A70BC 16OR / J2-10 WAY BODY CONTROLLER (1604) D TAIL LIGHT SIGNAL STOP LT RELEY (1011-R3) CH7_70 / B70A 16RD / B70 16RD / B70L 16RD B70R 16RD / ELEC PANEL/ PLATFORM (1703) A1 / E70L-M 14RD E70R-M 14RD / E57-M 16LTGN / E56-M 16YL E56 16YL E57 16LTGN / E68R-M 16BN E68L-M 16BN / E70 14RD / REAR CAP/ L BODY (10406) CH7_19 / REAR CAP/ L BODY (10406) CH7_19 / REAR CAP/ L BODY (10406) CH7_18 / REAR CAP/ L BODY (10406) CH7_18,19 / @ W/9 FRONT WINDOW ! W/CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK # W/CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK / #B58F 18BN / #A70BC 16OR / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 290 / STOP / TAIL / TURN LIGHTS WITHOUT CHECK WITHOUT CHILD CHECK MATE WITH 9

7.31. STOP / TAIL / TURN LIGHTS WITHOUT CHECK WITH CHILD CHECK MATE
Figure 291 STOP / TAIL / TURN LIGHTS WITHOUT CHECK WITH CHILD CHECK MATE WITH 9

Components: CL LT RELAY (10308); CL LT RELAY (10308-R1); CONTROLLER (1600); CONTROLLER (1603); CONTROLLER (1604); L BODY (10406); MODULE (10212); OPTION (10381); PLATFORM (1702); PLATFORM (1703); STOP LT RELEY (1011)
Wires (circuit gauge+color): A56A 18OR; A56B 18OR; A57C 14LTGN; A58 14BN; A58B 14BN; A58C 14BN; A70BC 16OR; B57 16LTGN; B57A 16LTGN; B57R 16LTGN; B58E 16BN; B58F 18BN; B68 16BN; B68D 16BN; B68L 16BN; B68R 16BN; B70 16RD; B70A 16RD; B70C 18RD; B70L 16RD; B70R 16RD; E57 16LTGN; E57-M 16LTGN; E68 16BN; E68L-M 16BN; E68R-M 16BN; E70 14RD; E70L-M 14RD; E70R-M 14RD
See also sheets: CH18_14, CH7_18, CH7_19, CH7_66, CH7_70
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.31. STOP / TAIL / TURN LIGHTS WITHOUT CHECK WITH CHILD CHECK MATE WITH 9, P. 27 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 23DEC20 / CHAPTER 7 STOP/TAIL/TURN LIGHTS N/CHECK W/CHILD CHECK MATE W/9 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A7 A8 / E68 16BN / E70L-M 14RD E70R-M 14RD / B70L 16RD B70R 16RD / B68 16BN / E57-M 16LTGN / E68L-M 16BN E68R-M 16BN E56-M 16YL E56 16YL / B56 16YL B57 16LTGN / B68L 16BN B68R 16BN B56L 16YL B56A 16YL / B57R 16LTGN / B57A 16LTGN / E57 16LTGN / L BODY/ ELEC PANEL (10400/10400A/ @10400B) / REAR CAP/ L BODY (10406) CH7_19 REAR CAP/ L BODY (10406) CH7_18,19 / REAR CAP/ L BODY (10406) CH7_18 / J1-12 WAY BODY CONTROLLER (1603) / B58E 16BN / ELEC PANEL/ PLATFORM (1702) 6 A58B 14BN / !B58F 18BN / CL LT RELAY (10308-R1) CH7_66 CL LT RELAY (10308) CH7_66A J2-10 WAY BODY CONTROLLER (1604) PARK LT F COMMAND 2 G PARK LT COMMAND 1 / LEFT REAR D TURN SIGN / RIGHT REAR M TURN SIGN / B68D 16BN / A58C 14BN A58 14BN / A56C 14YL A57C 14LTGN / A56B 18OR / B66 16YL / J3-RED BODY CONTROLLER (1600) LEFT TURN A7 SIGNAL / ELEC PANEL/ PLATFORM (1703) B11 / TAIL LT OPTION (10381) B / A56A 18OR / B70A B70C 16RD 18RD @ W/9 FRONT WINDOW ! W/CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK # W/CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK / E70 14RD / CHECK MATE MODULE (10212) CH18_14 / ELEC PANEL/ PLATFORM (1703) A1 / B70 16RD / J2-10 WAY BODY CONTROLLER (1604) TAIL LIGHT D SIGNAL / REAR CAP/ L BODY (10406) CH7_19 / A70BC 16OR / #B58F 18BN / #A70BC 16OR / STOP LT RELEY (1011) CH7_70 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / Figure 291 / STOP / TAIL / TURN LIGHTS WITHOUT CHECK WITH CHILD CHECK MATE WITH 9

7.32. STOP / TAIL / TURN LIGHTS WITH VIDEO PREWIRE WITH 9, P. 28
Figure 292 STOP / TAIL / TURN LIGHTS WITH VIDEO PREWIRE WITH 9

Components: BODY (10406); BODY CONTROLLER (1604); CONTROLLER (1600); CONTROLLER (1603); CONTROLLER (1604); EXTENDED (10358B); OPTION (10381); PLATFORM (1702); PLATFORM (1703); PLATFORM (1703/1703); REAR CAP (10406); RELAY (10308); SEON SIGNALS (11644)
Wires (circuit gauge+color): A56A 18OR; A56B 18OR; A57C 14LTGN; A58 14BN; A58C 14BN; A70BC 16OR; B119V 18GY; B57 16LTGN; B57A 16LTGN; B57H 16LTGN; B57R 16LTGN; B57RA 18LTGN; B58E 16BN; B58F 18BN; B68 16BN; B68D 16BN; B68L 16BN; B68R 16BN; B70 16RD; B70A 16RD; B70C 18RD; B70L 16RD; B70R 16RD; E57 16LTGN; E57-M 16LTGN; E68 16BN; E68L-M 16BN; E68R-M 16BN; E70 14RD; E70L-M 14RD; E70R-M 14RD
See also sheets: CH7_18, CH7_19, CH7_66, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.32. STOP / TAIL / TURN LIGHTS WITH VIDEO PREWIRE WITH 9, P. 28 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 STOP/TAIL/TURN LIGHTS W/VIDEO PREWIRE W/9 J2-10 WAY BODY CONTROLLER (1604) TAIL D LIGHT SIGNAL / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / L BODY/ ELEC PANEL (10400/10400A 10400/#B) A4 / B70A 16RD / B57A 16LTGN / E70 14RD / ELEC PANEL/ PLATFORM (1703/1703) A1 / ELEC PANEL/ PLATFORM (1702) / B70C 18RD / SEON SIGNALS (11644) 3 / E57-M 16LTGN E56-M 16YL E57 16LTGN / E56 16YL / B56A 16YL / 16LTGN B57 B58E 16BN 16YL B56 / B57RA 18LTGN / 1 2 / B56LA 18YL / *B57H 16LTGN B119V 18GY / STOP ARM EXTENDED (10358B) CH9_03 / 14LTGN A56C A56C 14YL 14YL A57C / D M LEFT REAR TURN SIGNAL RIGHT REAR TURN SIGNAL J2-10 WAY BODY CONTROLLER (1604) / J1-12 WAY BODY CONTROLLER (1603) / E70L-M 14RD E70R-M 14RD / B70L 16RD B70R 16RD / B57R 16LTGN B56L 16YL / L BODY/ REAR CAP (10406) CH7_19 / L BODY/ REAR CAP (10406) CH7_18 / A70BC 16OR / E68R-M 16BN A7 E68L-M 16BN E68 E68 16BN 16BN !B58F 18BN / B68R 16BN B68L 16BN B68 16BN / A2 A2 / REAR CAP/L BODY (10406) CH7_18,19 REAR CAP/L BODY (10406) CH7_19 CL LT RELAY (10308) CH7_66 CL LT RELAY (10308) CH7_66A / 14BN A58 / G F LT 2 LT 1 CONN CONN PARK PARK ELEC PANEL/ PLATFORM (1703) B11 / A58C 14BN 14BN A58 / #B58F 18BN / TAIL LT OPTION (10381) A / A56A 18OR / A56B 18OR / B66 16YL / B68D 16BN / A7 LEFT TURN SIGNAL / J3-RED BODY CONTROLLER (1600) / 16RD B70 / STOP ARM EXTENDED (10358B) CH9_03 / B56H 16YL / Figure 292 / STOP / TAIL / TURN LIGHTS WITH VIDEO PREWIRE WITH 9

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 333 | printed page 293 | section 7.33
7.33. STOP / TAIL / TURN LIGHTS WITHOUT CHECK WITH THEFT MATE WITH 9, P. 29
Figure 293 STOP / TAIL / TURN LIGHTS WITHOUT CHECK WITH THEFT MATE WITH 9

Components: CL LT RELAY (10308); CL LT RELAY (10308-R1); CONTROLLER (1600); CONTROLLER (1603); CONTROLLER (1604); L BODY (10406); OPTION (10381); PLATFORM (1702); PLATFORM (1703); STOP LT RELAY (1011); YEL DOT (11647)
Wires (circuit gauge+color): A56A 18OR; A56B 18OR; A57C 14LTGN; A58 14BN; A58B 14BN; A58C 14BN; A70BC 16OR; A70D 18RD; B57 16LTGN; B57A 16LTGN; B57R 16LTGN; B58E 16BN; B58F 18BN; B68 16BN; B68D 16BN; B68L 16BN; B68R 16BN; B70 16RD; B70A 16RD; B70B 16RD; B70C 16RD; E57 16LTGN; E57-M 16LTGN; E68 16BN; E68L-M 16BN; E68R-M 16BN; E70 14RD; E70L-M 14RD; E70R-M 14RD
See also sheets: CH18_05, CH7_18, CH7_19, CH7_66, CH7_70
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.33. STOP / TAIL / TURN LIGHTS WITHOUT CHECK WITH THEFT MATE WITH 9, P. 29 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / L BODY/ ELEC PANEL (10400/10400A/ @10400B) A2 E68 B68 16BN 16BN / E70L-M 14RD E70R-M 14RD / B70B 16RD B70C 16RD / E57-M 16LTGN / E56-M 16YL E56 16YL E57 16LTGN / B57 16LTGN / B56L 16YL B56A 16YL / B57R 16LTGN / B57A 16LTGN / E68R-M 16BN E68L-M 16BN / B68R 16BN B68L 16BN / REAR CAP/ L BODY (10406) CH7_19 / B56 16YL / J1-12 WAY BODY CONTROLLER (1603) / B58E 16BN / ELEC PANEL/ PLATFORM (1702) 6 A58B 14BN / !B58F 18BN / CL LT RELAY (10308-R1) CH7_66 / LEFT REAR D TURN SIGN / M RIGHT REAR TURN SIGN / B68D 16BN / CL LT RELAY (10308) CH7_66A J2-10 WAY BODY CONTROLLER (1604) PARK LT F COMMAND 2 PARK LT G COMMAND 1 / A58C 14BN A58 14BN / A56C 14YL A57C 14LTGN / A56B 18OR / B66 16YL / J3-RED BODY CONTROLLER (1600) LEFT TURN A7 SIGNAL / ELEC PANEL/ PLATFORM (1703) B11 A56A 18OR / TAIL LT OPTION (10381) B / E70 14RD / B70A 16RD / ELEC PANEL/ PLATFORM (1703) A1 / B70 16RD / A70D 18RD / J2-10 WAY BODY CONTROLLER (1604) TAIL LIGHT D SIGNAL / REAR CAP/ L BODY (10406) CH7_19 / REAR CAP/ L BODY (10406) CH7_18 / REAR CAP/ L BODY (10406) CH7_18,19 / A70BC 16OR / #B58F 18BN / #A70BC 16OR / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 293 / STOP / TAIL / TURN LIGHTS WITHOUT CHECK WITH THEFT MATE WITH 9

7.34. STOP / TAIL / TURN LIGHTS WITHOUT VIDEO WITH THEFT MATE WITH 9, P. 30
Figure 294 STOP / TAIL / TURN LIGHTS WITHOUT VIDEO WITH THEFT MATE WITH 9

Components: CL LT RELAY (10308); CL LT RELAY (10308-R1); CONTROLLER (1600); CONTROLLER (1603); CONTROLLER (1604); EXTEND (10358B); L BODY (10406); OPTION (10381); PLATFORM (1702); PLATFORM (1703); SEON SIGNALS (11644); STOP LT RELAY (1011); YEL DOT (11647)
Wires (circuit gauge+color): A56A 18OR; A56B 18OR; A57C 14LTGN; A58 14BN; A58B 14BN; A58C 14BN; A70BC 16OR; A70D 18RD; B119V 18GY; B57 16LTGN; B57A 16LTGN; B57R 16LTGN; B57RA 18LTGN; B58E 16BN; B58F 18BN; B68 16BN; B68D 16BN; B68L 16BN; B68R 16BN; B70 16RD; B70A 16RD; B70C 18RD; B70L 16RD; B70R 16RD; E57 16LTGN; E57-M 16LTGN; E68 16BN; E68L-M 16BN; E68R-M 16BN; E70 14RD; E70L-M 14RD; E70R-M 14RD
See also sheets: CH18_05, CH7_18, CH7_19, CH7_66, CH7_70, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.34. STOP / TAIL / TURN LIGHTS WITHOUT VIDEO WITH THEFT MATE WITH 9, P. 30 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. TAIL LT OPTION (10381) B / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 STOP/TAIL/TURN LIGHTS N/VIDEO W/THEFT MATE W/9 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / E68 16BN / L BODY/ ELEC PANEL (10400/10400A/ @10400B) A2 / E70L-M 14RD E70R-M 14RD / B70L 16RD B70R 16RD / B68 16BN / E57-M 16LTGN / E56-M 16YL E56 16YL E57 16LTGN / B57 16LTGN / B56L 16YL B56A 16YL / B57R 16LTGN / B57A 16LTGN / E68L-M 16BN E68R-M 16BN / B68L 16BN B68R 16BN / REAR CAP/ L BODY (10406) CH7_19 / B56 16YL / REAR CAP/ L BODY (10406) CH7_18 / J1-12 WAY BODY CONTROLLER (1603) / B58E 16BN / #B58F 18BN ELEC PANEL/ PLATFORM (1702) 6 A58B 14BN / !B58F 18BN / CL LT RELAY (10308-R1) CH7_66 CL LT RELAY (10308) CH7_66A J2-10 WAY BODY CONTROLLER (1604) PARK LT F COMMAND 2 G PARK LT COMMAND 1 / LEFT REAR D TURN SIGN / RIGHT REAR M TURN SIGN / B68D 16BN / A58C 14BN A58 14BN / A56C 14YL A57C 14LTGN / A56B 18OR / B66 16YL / J3-RED BODY CONTROLLER (1600) LEFT TURN A7 SIGNAL / ELEC PANEL/ PLATFORM (1703) B11 A56A 18OR / B56LA 18YL B57RA 18LTGN B70C 18RD B119V 18GY / E70 14RD / B70A 16RD / ELEC PANEL/ PLATFORM (1703) A1 / B70 16RD / A70BC A70BC 16OR 16OR / A70D 18RD / J2-10 WAY BODY CONTROLLER (1604) TAIL LIGHT D SIGNAL / REAR CAP/ L BODY (10406) CH7_19 / SEON SIGNALS (11644) / STOP ARM EXTEND (10358B) CH9_03 / 4 3 / REAR CAP/ L BODY (10406) CH7_18,19 / #A70BC 16OR / Figure 294 / STOP / TAIL / TURN LIGHTS WITHOUT VIDEO WITH THEFT MATE WITH 9

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 335 | printed page 295 | section 7.35
7.35. STOP / TAIL / TURN LIGHTS WITH VIDEO, CCM AND SNOOZE WITH 9, P. 31
Figure 295 STOP / TAIL / TURN LIGHTS WITH VIDEO, CCM AND SNOOZE WITH 9

Components: ASSERT (11338); CL LT RELAY (10308); CL LT RELAY (10308-R1); CONTROLLER (1600); CONTROLLER (1603); CONTROLLER (1604); EXTEND (10358B); L BODY (10406); OPTION (10381); PLATFORM (1702); PLATFORM (1703); SEON SIGNALS (11644); YEL DOT (11647)
Wires (circuit gauge+color): A56A 18OR; A56B 18OR; A57C 14LTGN; A58 14BN; A58B 14BN; A58C 14BN; A70BC 16OR; A70D 18RD; B119V 18GY; B56 16OR; B56A 16OR; B56H 16OR; B56L 16OR; B56LA 18OR; B57 16OR; B57A 16OR; B57H 16OR; B57R 16OR; B57RA 18OR; B58E 16BN; B58F 18BN; B68 16BN; B68D 16BN; B68L 16BN; B68R 16BN; B70 16RD; B70A 16RD; B70C 18RD; B70L 16RD; B70R 16RD; E57 16LTGN; E57-M 16LTGN; E68 16BN; E68L-M 16BN; E68R-M 16BN; E70 14RD; E70L-M 14RD; E70R-M 14RD
See also sheets: CH18_05, CH18_23, CH7_18, CH7_19, CH7_66, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.35. STOP / TAIL / TURN LIGHTS WITH VIDEO, CCM AND SNOOZE WITH 9, P. 31 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 STOP/TAIL/TURN LIGHTS W/VIDEO & CCM & SNOOZE W/9 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / E68 16BN E68L-M 16BN E68R-M 16BN E56-M 16YL E56 16YL E57 16LTGN / L BODY/ ELEC PANEL (10400/10400A/ @10400B) A2 / E70L-M 14RD E70R-M 14RD E70 14RD / B70L 16RD B70R 16RD B70A 16RD / B68 16BN B68L 16BN B68R 16BN B56L 16OR B56A 16OR / E57-M 16LTGN / A8 B1 / B56 16OR B57 16OR / B57R 16OR / B57A 16OR / REAR CAP/ L BODY (10406) CH7_19 REAR CAP/ L BODY (10406) CH7_18,19 / REAR CAP/ L BODY (10406) CH7_18 / J1-12 WAY BODY CONTROLLER (1603) LEFT REAR D TURN SIGN / B58E 16BN / ELEC PANEL/ PLATFORM (1702) 6 A58B 14BN / ELEC PANEL/ PLATFORM (1703) B11 A56A 18OR !B58F 18BN #B58F 18BN / RIGHT REAR M TURN SIGN / B68D 16BN / A58C 14BN A58 14BN / A56C 14YL A57C 14LTGN / A56B 18OR / B66 16YL / TAIL LT OPTION (10381) B / B56LA 18OR B57RA 18OR B70C 18RD / ELEC PANEL/ PLATFORM (1703) A1 / B70 16RD / A70BC A70BC 16OR 16OR / REAR CAP/ L BODY (10406) CH7_19 / INPOWER HAZARD ASSERT (11338) CH18_23 SEON SIGNALS (11644) / B119V 18GY / STOP ARM EXTEND (10358B) CH9_03 / B56H 16OR B57H 16OR / Figure 295 / STOP / TAIL / TURN LIGHTS WITH VIDEO, CCM AND SNOOZE WITH 9

7.36. STOP / TAIL / TURN LIGHTS WITH CHECK AND SNOOZE WITH 9, P. 32
Figure 296 STOP / TAIL / TURN LIGHTS WITH CHECK AND SNOOZE WITH 9

Components: ASSERT (11338); CL LT RELAY (10308); CL LT RELAY (10308-R1); CONTROLLER (1600); CONTROLLER (1603); CONTROLLER (1604); L BODY (10406); OPTION (10381); PLATFORM (1702); PLATFORM (1703)
Wires (circuit gauge+color): A56A 18OR; A56B 18OR; A57C 14LTGN; A58 14BN; A58B 14BN; A58C 14BN; A70BC 16OR; B56 16OR; B56A 16OR; B56H 16OR; B56L 16OR; B57 16OR; B57A 16OR; B57H 16OR; B57R 16OR; B58E 16BN; B58F 18BN; B68 16BN; B68D 16BN; B68L 16BN; B68R 16BN; B70 16RD; B70A 16RD; B70L 16RD; B70R 16RD; E57 16LTGN; E57-M 16LTGN; E68 16BN; E68L-M 16BN; E68R-M 16BN; E70 14RD; E70L-M 14RD; E70R-M 14RD
See also sheets: CH18_23, CH7_18, CH7_19, CH7_66
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.36. STOP / TAIL / TURN LIGHTS WITH CHECK AND SNOOZE WITH 9, P. 32 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 23DEC20 / CHAPTER 7 STOP/TAIL/TURN LIGHTS W/CHECK W/SNOOZE W/9 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / !B58F 18BN / CL LT RELAY (10308-R1) CH7_66 CL LT RELAY (10308) CH7_66A J2-10 WAY BODY CONTROLLER (1604) PARK LT F COMMAND 2 PARK LT G COMMAND 1 / B68D 16BN / A56B 18OR / B66 16YL / J3-RED BODY CONTROLLER (1600) LEFT TURN A7 SIGNAL / ELEC PANEL/ PLATFORM (1703) B11 A56A 18OR / TAIL LT OPTION (10381) B / J1-12 WAY BODY CONTROLLER (1603) / ELEC PANEL/ PLATFORM (1702) 6 A58B 14BN / LEFT REAR D TURN SIGN / M RIGHT REAR TURN SIGN / A58C 14BN A58 14BN / A56C 14YL A57C 14LTGN / B68 16BN / B57 16OR / B56L 16OR B56A 16OR / B57R 16OR / B57A 16OR / B68R 16BN B68L 16BN / B56 16OR / B58E 16BN / L BODY/ ELEC PANEL (10400/10400A/ @10400B) A2 / A70BC 16OR / J2-10 WAY BODY CONTROLLER (1604) TAIL LIGHT D SIGNAL / B70A 16RD / B70 16RD / B70L 16RD B70R 16RD / ELEC PANEL/ PLATFORM (1703) A1 / E68 16BN / E70L-M 14RD E70R-M 14RD / E57-M 16LTGN / E56-M 16YL E56 16YL E57 16LTGN / E68R-M 16BN E68L-M 16BN / E70 14RD / REAR CAP/ L BODY (10406) CH7_19 / REAR CAP/ L BODY (10406) CH7_19 / REAR CAP/ L BODY (10406) CH7_18 / REAR CAP/ L BODY (10406) CH7_18,19 / @ W/9 FRONT WINDOW # W/CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK ! W/CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK / B56H 16OR / INPOWER HAZARD ASSERT (11338) CH18_23 / B57H 16OR / #B58F 18BN / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 296 / STOP / TAIL / TURN LIGHTS WITH CHECK AND SNOOZE WITH 9

7.37. STOP / TAIL / TURN LIGHTS WITH VIDEO, LT MONITOR AND WITH 9, P. 33
Figure 297 STOP / TAIL / TURN LIGHTS WITH VIDEO, LT MONITOR AND WITH 9

Components: CL LT RELAY (10308); CL LT RELAY (10308-R1); CONTROLLER (1600); CONTROLLER (1603); CONTROLLER (1604); EXTEND (10358B); L BODY (10406); OPTION (10381); PLATFORM (1702); PLATFORM (1703); SEON SIGNALS (11654)
Wires (circuit gauge+color): A56A 18OR; A56B 18OR; A57C 14LTGN; A58 14BN; A58B 14BN; A58C 14BN; A70BC 16OR; B119 18GY; B57 16LTGN; B57A 16LTGN; B57R 16LTGN; B57RA 18LTGN; B58E 16BN; B58F 18BN; B68 16BN; B68D 16BN; B68L 16BN; B68R 16BN; B70 16RD; B70A 16RD; B70C 18RD; B70L 16RD; B70R 16RD; E57 16LTGN; E57-M 16LTGN; E68 16BN; E68L-M 16BN; E68R-M 16BN; E70 14RD; E70L-M 14RD; E70R-M 14RD
See also sheets: CH7_18, CH7_19, CH7_66, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.37. STOP / TAIL / TURN LIGHTS WITH VIDEO, LT MONITOR AND WITH 9, P. 33 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 24DEC20 / CHAPTER 7 STOP/TAIL/TURN LIGHTS W/VIDEO W/LT MONITOR W/9 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / !B58F 18BN / CL LT RELAY (10308-R1) CH7_66 / B68D 16BN / CL LT RELAY (10308) CH7_66A J2-10 WAY BODY CONTROLLER (1604) PARK LT F COMMAND 2 PARK LT G COMMAND 1 / A56B 18OR / B66 16YL / J3-RED BODY CONTROLLER (1600) LEFT TURN A7 SIGNAL / ELEC PANEL/ PLATFORM (1703) B11 A56A 18OR / TAIL LT OPTION (10381) B / J1-12 WAY BODY CONTROLLER (1603) / ELEC PANEL/ PLATFORM (1702) 6 A58B 14BN / LEFT REAR D TURN SIGN / M RIGHT REAR TURN SIGN / A58C 14BN A58 14BN / A56C 14YL A57C 14LTGN / L BODY/ ELEC PANEL (10400/10400A/ @10400B) A2 B68 16BN B68R 16BN B68L 16BN B56L 16YL B56A 16YL / B57 16LTGN / B57R 16LTGN / B57A 16LTGN / B56 16YL / B58E 16BN / A70BC 16OR / J2-10 WAY BODY CONTROLLER (1604) TAIL LIGHT D SIGNAL / B70A 16RD / B70 16RD / B70L 16RD B70R 16RD / ELEC PANEL/ PLATFORM (1703) A1 / E68 16BN E68R-M 16BN E68L-M 16BN E56-M 16YL E56 16YL E57 16LTGN / E70L-M 14RD E70R-M 14RD / E57-M 16LTGN / E70 14RD / REAR CAP/ L BODY (10406) CH7_19 / REAR CAP/ L BODY (10406) CH7_19 REAR CAP/ L BODY (10406) CH7_18,19 / REAR CAP/ L BODY (10406) CH7_18 / # W/CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK ! W/CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK @ W/9 FRONT WINDOW / SEON SIGNALS (11654) / B56LA 18YL B57RA 18LTGN B119 18GY / B70C 18RD / STOP ARM EXTEND (10358B) CH9_03 / #B58F 18BN / NOTE:CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 297 / STOP / TAIL / TURN LIGHTS WITH VIDEO, LT MONITOR AND WITH 9

7.38. STOP / TAIL / TURN LIGHTS WITH VIDEO, CCM AND SNOOZE WITH 9, P. 34
Figure 298 STOP / TAIL / TURN LIGHTS WITH VIDEO, CCM AND SNOOZE WITH 9

Components: ASSERT (11338); CL LT RELAY (10308); CL LT RELAY (10308-R1); CONTROLLER (1600); CONTROLLER (1603); CONTROLLER (1604); EXTEND (10358B); L BODY (10406); OPTION (10381); PLATFORM (1702); PLATFORM (1703); SEON SIGNALS (11654)
Wires (circuit gauge+color): A56A 18OR; A56B 18OR; A57C 14LTGN; A58 14BN; A58B 14BN; A58C 14BN; A70BC 16OR; B119 18GY; B56 16OR; B56A 16OR; B56H 16OR; B56L 16OR; B57 16OR; B57A 16OR; B57H 16OR; B57R 16OR; B57RA 18LTGN; B58E 16BN; B58F 18BN; B68 16BN; B68D 16BN; B68L 16BN; B68R 16BN; B70 16RD; B70A 16RD; B70C 18RD; B70L 16RD; B70R 16RD; E57 16LTGN; E57-M 16LTGN; E68 16BN; E68L-M 16BN; E68R-M 16BN; E70 14RD; E70L-M 14RD; E70R-M 14RD
See also sheets: CH18_23, CH7_18, CH7_19, CH7_48, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.38. STOP / TAIL / TURN LIGHTS WITH VIDEO, CCM AND SNOOZE WITH 9, P. 34 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 24DEC20 / CHAPTER 7 STOP/TAIL/TURN LIGHTS W/VIDEO CCM & SNOOZE W/9 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / !B58F 18BN / CL LT RELAY (10308-R1) CH7_48 CL LT RELAY (10308) CH7_66A J2-10 WAY BODY CONTROLLER (1604) PARK LT F COMMAND 2 PARK LT G COMMAND 1 / B68D 16BN / A56B 18OR / B66 16YL / J3-RED BODY CONTROLLER (1600) LEFT TURN A7 SIGNAL / ELEC PANEL/ PLATFORM (1703) B11 A56A 18OR / TAIL LT OPTION (10381) B / J1-12 WAY BODY CONTROLLER (1603) / ELEC PANEL/ PLATFORM (1702) 6 A58B 14BN / LEFT REAR D TURN SIGN / RIGHT REAR M TURN SIGN / A58C 14BN A58 14BN / A56C 14YL A57C 14LTGN / L BODY/ ELEC PANEL (10400/10400A/ @10400B) A2 B68 16BN B68R 16BN B68L 16BN / B56L 16OR B56A 16OR / B57R 16OR / B57A 16OR / B56 16OR / B58E 16BN / A70BC 16OR / J2-10 WAY BODY CONTROLLER (1604) TAIL LIGHT D SIGNAL / B70A 16RD / B70 16RD / B70L 16RD B70R 16RD / ELEC PANEL/ PLATFORM (1703) A1 / E68 16BN E68R-M 16BN E68L-M 16BN / E70L-M 14RD E70R-M 14RD / E57-M 16LTGN / E56-M 16YL E56 16YL E57 16LTGN / E70 14RD / REAR CAP/ L BODY (10406) CH7_19 / REAR CAP/ L BODY (10406) CH7_19 REAR CAP/ L BODY (10406) CH7_18,19 / REAR CAP/ L BODY (10406) CH7_18 / INPOWER HAZZARD ASSERT (11338) CH18_23 SEON SIGNALS (11654) / 4 2 / B56LA 18YL B57RA 18LTGN B119 18GY B70C 18RD / STOP ARM EXTEND (10358B) CH9_03 / B56H 16OR / B57H 16OR / B57 16OR / #B58F 18BN / Figure 298 / STOP / TAIL / TURN LIGHTS WITH VIDEO, CCM AND SNOOZE WITH 9

7.39. STOP / TAIL / TURN LIGHTS WITH SEON SIGNAL WITH ADDITIONAL POWER, P. 34A
Figure 299 STOP / TAIL / TURN LIGHTS WITH SEON SIGNAL WITH ADDITIONAL POWER

Components: CL LT RELAY (10308); CONN C (10025C); CONN D (10025D); CONTROLLER (1603); CONTROLLER (1604); ELEC PANEL (1702); ELEC PANEL/PLATFORM (1703); FR CAP (10001); J3-RED BODY CONTROLLER (1600); L BODY (10406); OPTION (10381); PLATFORM (1703); SEON SIGNALS (11654); STOP ARM EXTEND (10358B)
Wires (circuit gauge+color): A56A 18OR; A56B 18OR; A57C 14LTGN; A70BC 16OR; B119 18GY; B57 16LTGN; B57A 16LTGN; B57B 16LTGN; B57RA 18LTGN; B58F 18BN; B68 16BN; B68A 16BN; B68D 16BN; B68L-M 16BN; B68R-M 16BN; B70 16RD; B70A 16RD; B70B 16RD; B70C 18RD; B70L-M 16RD; B70R-M 16RD; C68 16BN; C68L-M 16BN; C68R-M 16BN; C70 16RD; C70L-M 16RD; C70R-M 16RD; E57 16LTGN; E68 16BN; E68L-M 16BN; E68R-M 16BN; E70 14RD; E70L-M 14RD; E70R-M 14RD
See also sheets: CH7_18, CH7_19, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.39. STOP / TAIL / TURN LIGHTS WITH SEON SIGNAL WITH ADDITIONAL POWER, P. 34A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 96289K 24SEP21 / CHAPTER 7 STOP/TAIL/TURN LIGHTS W/SEON SIGNAL W/ADDITIONAL POWER ELEC PANEL/PLATFORM (1703) B11 / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / B58F 18BN L BODY/ ELEC PANEL (10400/ 10400A/B) A2 / ELEC PANEL/ FR CAP (10001) C1 / B68D 16BN / LT MONITOR CONN D (10025D) / A56B 18OR / B66 16YL / J3-RED BODY CONTROLLER (1600) LEFT TURN A7 SIGNAL / TAIL LT OPTION (10381) / A56A 18OR / J1-12 WAY BODY CONTROLLER (1603) LEFT REAR TURN SIGN D RIGHT REAR M TURN SIGN / PLATFORM/ ELEC PANEL (1702) 64 / LT MONITOR CONN C (10025C) / E68 16BN / E70L-M 14RD E68L-M 16BN / E68R-M 16BN E70R-M 14RD / E56 16YL E57 16LTGN E70 14RD / B68R-M 16BN B70R-M 16RD / B56B C56 18YL 16YL B57B C57 16LTGN 18YL B70B C70 16RD 16RD ELEC PANEL/ PLATFORM (1703) A1 / B56A 16YL B57A 16LTGN B70A 16RD / D1 C10 / C68R-M 16BN C70R-M 16RD / A56C 14YL A57C 14LTGN / B70 16RD / A70BC A70BC 16OR 16OR / J2-10 WAY BODY CONTROLLER (1604) TAIL LT D SIGNAL SEON SIGNALS (11654) / B56 16YL B57 16LTGN / REAR CAP/ L BODY (10406) CH7_19 / REAR CAP/ L BODY (10406) CH7_18 / REAR CAP/ L BODY (10406) CH7_19 / REAR CAP/ L BODY (10406) CH7_18 / REAR CAP/ L BODY (10406) CH7_18,19 / B68A 16BN / B70L-M 16RD B68L-M 16BN / B68 16BN / C68 16BN / C70L-M 16RD C68L-M 16BN / A8 A6 / 8 2 / 7 2 / 3 4 1 2 / STOP ARM EXTEND (10358B) CH9_03 / B70C 18RD B57RA 18LTGN B56LA 18YL B119 18GY / CL LT RELAY (10308) CH7_66A / NOTE: CONNECTIONS FOR VEHICLE N/0508108 - NOT MTA FUSE BLOCK. / Figure 299 / STOP / TAIL / TURN LIGHTS WITH SEON SIGNAL WITH ADDITIONAL POWER

7.40. STOP / TAIL / TURN LIGHTS WITH VIDEO AND LT MONITOR, P. 34B
Figure 300 STOP / TAIL / TURN LIGHTS WITH VIDEO AND LT MONITOR

Components: CL LT RELAY (10308); CONTROLLER (1600); CONTROLLER (1603); CONTROLLER (1604); EXTEND (10358B); L BODY (10406); OPTION (10381); PLATFORM (1702); PLATFORM (1703); SEON SIGNALS (11654)
Wires (circuit gauge+color): A56A 18OR; A56B 18OR; A57C 14LTGN; A58 14BN; A58B 14BN; A58C 14BN; A70BC 16OR; B119 18GY; B56 16OR; B56A 16OR; B56L 16OR; B57 16OR; B57A 16OR; B57R 16OR; B57RA 18LTGN; B58E 16BN; B58F 18BN; B68 16BN; B68D 16BN; B68L 16BN; B68R 16BN; B70 16RD; B70A 16RD; B70C 18RD; B70L 16RD; B70R 16RD; E57 16LTGN; E57-M 16LTGN; E68 16BN; E68L-M 16BN; E68R-M 16BN; E70 14RD; E70L-M 14RD; E70R-M 14RD
See also sheets: CH7_18, CH7_19, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.40. STOP / TAIL / TURN LIGHTS WITH VIDEO AND LT MONITOR, P. 34B / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 96289K 24SEP21 / CHAPTER 7 STOP/TAIL/TURN LIGHTS W/VIDEO W/LT MONITOR / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / B68D 16BN / CL LT RELAY (10308) CH7_66A PLATFORM PARK LT OPTION(4600) CH7_45B,45C,45D J2-10 WAY BODY CONTROLLER (1604) PARK LT F COMMAND 2 G PARK LT COMMAND 1 / A56B 18OR / B66 16YL / J3-RED BODY CONTROLLER (1600) LEFT TURN A7 SIGNAL / ELEC PANEL/ PLATFORM (1703) B11 A56A 18OR / TAIL LT OPTION (10381) B / J1-12 WAY BODY CONTROLLER (1603) / A58B 14BN / LEFT REAR D TURN SIGN / RIGHT REAR M TURN SIGN / A58C 14BN A58 14BN / A56C 14YL A57C 14LTGN / ELEC PANEL/ PLATFORM (1702) 6 / L BODY/ ELEC PANEL (10400/ 10400A/B) A2 B68 16BN B68R 16BN B68L 16BN / B56L 16OR B56A 16OR / B57R 16OR / B57A 16OR / B56 16OR / B58E 16BN / A70BC 16OR / J2-10 WAY BODY CONTROLLER (1604) TAIL LIGHT D SIGNAL / B70A 16RD / B70 16RD / B70L 16RD B70R 16RD / ELEC PANEL/ PLATFORM (1703) A1 / E68 16BN E68R-M 16BN E68L-M 16BN / E70L-M 14RD E70R-M 14RD / E57-M 16LTGN / E56-M 16YL E56 16YL E57 16LTGN / E70 14RD / REAR CAP/ L BODY (10406) CH7_19 / REAR CAP/ L BODY (10406) CH7_19 REAR CAP/ L BODY (10406) CH7_18,19 / REAR CAP/ L BODY (10406) CH7_18 / SEON SIGNALS (11654) / 4 2 / B56LA 18YL B57RA 18LTGN B119 18GY B70C 18RD / STOP ARM EXTEND (10358B) CH9_03 / B57 16OR / B58F 18BN / NOTE: : CONNECTIONS FOR VEHICLE N/0508108 - NOT MTA FUSE BLOCK. / A58B 14BN / Figure 300 / STOP / TAIL / TURN LIGHTS WITH VIDEO AND LT MONITOR

7.41. LEFT SIDE DIRECTIONAL LIGHTS, P. 35
Figure 301 LEFT SIDE DIRECTIONAL LIGHTS

Components: LT MIDSHIP (10411A); PKT (10511); SPLICE (10419); SPLICE (10420); SPLICE (10482); WHL PKT CE (10506)
Wires (circuit gauge+color): E56-GB 18WH; E56-GC 18WH; E56-GD 18WH; E56-GH 18WH; E56-GJ 18WH
See also sheets: CH3_54, CH3_57, CH7_54
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.41. LEFT SIDE DIRECTIONAL LIGHTS, P. 35 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 24DEC20 / CHAPTER 7 LEFT SIDE DIRECTIONAL LIGHTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / DIRECTIONAL/ CL LT SPLICE (10420) CH7_54 / SIDE DIRECTIONAL LIGHTOVER REAR WHL PKT (10413/10413A/ 10413B) / SIDE DIRECTIONAL LT MIDSHIP (10411A) / SIDE DIRECTIONAL LT FWD REAR WHL PKT (10412/10412A/ 10412B) / SIDE DIRECTIONAL LT FWD REAR WHL PKT CE (10506) / E56-GJ 18WH *E56-GD 18WH E56M 18YL *E56H 18YL / @E56-GC 18WH W/13 WINDOW @E56F 18YL / E56-GC 18WH E56-GH 18WH %E56-GB 18WH / E56L 18YL %E56E 18YL W/10,12,13,9 E56F 18YL / ##E56-GH 18WH **E56-GJ 18WH / W/11 **E56M 18YL ##E56L 18YL ##E56-GJ 18WH ##E56M 18YL / W/5,7,9 SIDE DIRECTIONAL LT OVER REAR WHL PKT (10511) / GROUND SPLICE (10482) CH3_57 / GROUND SPLICE (10419) CH3_54 / Figure 301 / LEFT SIDE DIRECTIONAL LIGHTS

7.42. LEFT SIDE DIRECTIONAL LIGHTS (CONT.), P. 36
Figure 302 LEFT SIDE DIRECTIONAL LIGHTS (CONT.)

Components: DIRECTIONAL/CL LT SPLICE (10420); MIDSHIP (10411); PKT (10511A); PKT (10511B); SIDE DIR LT (10410); SPLICE (10419); SPLICE (10482); WHL PKT (10414); WHL PKT (10506B); WHL PKT CE (10506A)
Wires (circuit gauge+color): E56-G 18WH; E56-GA 18WH; E56-GC 18WH; E56-GD 18WH; E56-GH 18WH; E56-GJ 18WH
See also sheets: CH3_54, CH3_57, CH7_54
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.42. LEFT SIDE DIRECTIONAL LIGHTS (CONT.), P. 36 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 24DEC20 / CHAPTER 7 LEFT SIDE DIRECTIONAL LIGHTS (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / DIRECTIONAL/CL LT SPLICE (10420) CH7_54 / SIDE DIR LT OVER REAR WHL PKT (10511A) / SIDE DIR LT (10410) / SIDE DIR LT MIDSHIP (10411) / SIDE DIR LT FWD REAR WHL PKT (10506B) / SIDE DIR LT FWD REAR WHL PKT CE (10506A) / @ W/8 WINDOW BUS * W/10 WINDOW / E56-G 18WH E56C 18YL / @E56-GJ 18WH E56M 18YL / E56-GC 18WH *E56-GD 18WH E56F 18YL *E56G 18YL @E56-GA 18WH @E56A 18YL / E56-GA 18WH E56D 18YL / @E56-GH 18WH @E56L 18YL / E56-GA 18WH / E56A 18YL / SIDE DIR LT AFTER REAR WHL PKT (10414) / SIDE DIR LT OVER REAR WHL PKT (10511B) / GROUND SPLICE (10419) CH3_54 / GROUND SPLICE (10482) CH3_57 / NOTE: : CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 302 / LEFT SIDE DIRECTIONAL LIGHTS (CONT.)

7.43. RIGHT SIDE DIRECTIONAL LIGHTS, P. 37
Figure 303 RIGHT SIDE DIRECTIONAL LIGHTS

Components: MIDSHIP (10709/10709A); PKT (10706); PKT (10706A); PKT (10706B); PKT (10780); PKT (10807A); PKT (10807B); R BODY (10700); SPLICE (10701); SPLICE (10704)
Wires (circuit gauge+color): F57-GB 18WH; F57-GD 18WH; F57-GH 18WH; F57-K 18LTGN; F57B 16LTGN; F57B 18LTGN; F57D 18LTGN; F57K 18LTGN
See also sheets: CH3_52, CH7_18
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.43. RIGHT SIDE DIRECTIONAL LIGHTS, P. 37 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 06JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / COMBINATION SPLICE (10704) A / SIDE DIR LT OVER REAR WHL PKT (10706) / SIDE DIR LT MIDSHIP (10709/10709A) / W/5,6,7,8,9,10,11,12,13 WINDOW A / W/6 WINDOW A SIDE DIR LT OVER REAR WHL PKT (10780) / SIDE DIR LT OVER REAR WHL PKT (10706B) / SIDE DIR LT OVER REAR WHL PKT (10807A) / GROUND SPLICE (10701) CH3_52 / SIDE DIR LT OVER REAR WHL PKT (10807B) / F57B 16LTGN F57B 18LTGN / REAR CAP/ R BODY (10700) CH7_18 / F57D 18LTGN %F57K 18LTGN / F57-GB 18WH W/6 WINDOW F57K 18LTGN W/9-13 WINDOW @F57-GD 18WH F57-GH 18WH W/7,9 WINDOW / %F57-GH %F57-GH 18WH 18WH W/12 WINDOW F57K F57K 18LTGN 18LTGN #F57D #F57D 18LTGN 18LTGN #F57-GD #F57-GD 18WH 18WH F57-GH 18WH #F57D 18LTGN #F57-GD 18WH / *F57D 18LTGN *F57-GD 18WH / SIDE DIR LT OVER REAR WHL PKT (10706A) / * W/8 WINDOW # W/11,13 WINDOW % W/5,7,9 WINDOW 10709A - W/13 WINDOW / *F57-K 18LTGN *F57-GH 18WH / NOTE: : CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 303 / RIGHT SIDE DIRECTIONAL LIGHTS

7.44. RIGHT SIDE DIRECTIONAL LIGHTS (CONT.), P. 38
Figure 304 RIGHT SIDE DIRECTIONAL LIGHTS (CONT.)

Components: DOOR (10711); R BODY (10700); SPLICE (10701); SPLICE (10704); WHL PKT (10705); WHL PKT (10779); WHL PKT (10779A); WHL PKT (10779B)
Wires (circuit gauge+color): F57-G 18WH; F57-GC 18WH; F57-GE 18WH; F57-GF 18WH; F57A 18LTGN; F57B 18LTGN; F57C 18LTGN; F57E 18LTGN; F57J 18LTGN
See also sheets: CH3_52, CH7_18
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.44. RIGHT SIDE DIRECTIONAL LIGHTS (CONT.), P. 38 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 24DEC20 / RIGHT SIDE DIRECTIONAL LIGHTS (CONT.) / CHAPTER 7 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / COMBINATION SPLICE (10704) A / SIDE DIR LT FWD REAR WHL PKT (10705) / SIDE DIR LT AFTER ENTRANCE DOOR (10711) / SIDE DIR LT FWD REAR WHL PKT (10707/10707A/ 10707B) / W/6 WINDOW A / SIDE DIR LT FWD REAR WHL PKT (10779) / SIDE DIR LT FWD REAR WHL PKT (10779A) / # W/5-13 WINDOW * W/8 WINDOW BUS @ W/5,7,9,11 WINDOW % W/9,10 TO 13 WINDOW BUS 10707A-W/12,13 WINDOW 10707B-W/13 WINDOW / GROUND SPLICE (10701) CH3_52 / F57B 18LTGN #F57A 18LTGN / #F57C 18LTGN / REAR CAP / R BODY (10700) CH7_18 / F57J 18LTGN %F57E 18LTGN / %F57-GE 18WH F57-GF 18WH / @F57J 18LTGN @F57-GF 18WH / *F57-GE 18WH / *F57-GF 18WH / *F57J 18LTGN / *F57E 18LTGN / SIDE DIR LT FWD REAR WHL PKT (10779B) / #F57-GC 18WH / W/6 WINDOW / #F57-G 18WH / NOTE: : CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 304 / RIGHT SIDE DIRECTIONAL LIGHTS (CONT.)

7.45. COMBINATION LIGHT AFTER ENTRANCE DOOR AND FORWARD OR REAR WHEEL POCKET WITH RIGHT BODY, P. 39
Figure 305 COMBINATION LIGHT AFTER ENTRANCE DOOR AND FORWARD OR REAR WHEEL

Components: AFTER ENTRANCE DOOR (10712); GROUND SPLICE (10701); LT SPLICE (10714); SPLICE (10704); WHL PKT (10781); WHL PKT (10808)
Wires (circuit gauge+color): F143 18DKBL; F143AL 18DKBL; F57C 18LTGN; F57F 18LTGN; F57H 18LTGN; F57L 18LTGN; F58-GB 18WH; F58-GC 18WH; F58-GH 18WH; F58B 18BN; F58C 18BN; F58D 18BN
See also sheets: CH14_10, CH14_25, CH3_52
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.45. COMBINATION LIGHT AFTER ENTRANCE DOOR AND FORWARD OR REAR WHEEL POCKET WITH RIGHT BODY, P. 39 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 24DEC20 / CHAPTER 7 COMBINATION LIGHT AFTER ENTRANCE DOOR AND FORWARD OR REAR WHEEL POCKET W/RIGHT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (10701) CH3_52 / SIDE DIR / MARKER LT AFTER ENTRANCE DOOR (10712) A / F57C 18LTGN F57F 18LTGN F58B 18BN F58-GB 18WH / SIDE DIR/ MARKER LT FWD REAR WHL PKT (10808) A / SIDE DIR/ MARKER LT FWD REAR WHL PKT (10708/10708A/ 10708B) / SIDE DIR/ MARKER LT FWD REAR WHL PKT (10781) / #F57H 18LTGN / #F58C 18BN #F58-GC 18WH / F58-GH 18WH F57H 18LTGN / F58C 18BN F58-GC 18WH / %F57H 18LTGN %F58C 18BN / %F58-GC 18WH / COMBINATION SPLICE (10704) / W/12,13 WINDOW / W/12 WINDOW / F57L 18LTGN F58D 18BN / F143 18DKBL / EMERGENCY EXIT LT SPLICE (10714) CH14_10,11,26 / F143AL 18DKBL / SED LT *(10773) CH14_25 / Figure 305 / COMBINATION LIGHT AFTER ENTRANCE DOOR AND FORWARD OR REAR WHEEL POCKET WITH RIGHT BODY

7.46. MARKER LIGHT AFTER ENTRANCE DOOR AND AFTER REAR WHEEL POCKET WITH RIGHT BODY, P. 40
Figure 306 MARKER LIGHT AFTER ENTRANCE DOOR AND AFTER REAR WHEEL POCKET WITH

Components: ENTRANCE DOOR (10837); SPLICE (10701); SPLICE (10704); WHEEEL PKT (10838)
Wires (circuit gauge+color): F58-GD 18WH; F58-GE 18WH; F58-GH 18WH; F58-GJ 18WH; F58D 18BN; F58E 18BN; F58H 18BN; F58J 18BN
See also sheets: CH3_52
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.46. MARKER LIGHT AFTER ENTRANCE DOOR AND AFTER REAR WHEEL POCKET WITH RIGHT BODY, P. 40 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 24DEC20 / CHAPTER 7 MARKER LIGHT AFTER ENTRANCE DOOR AND AFTER REAR WHEEL POCKET W/RIGHT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SIDE MARKER LT AFTER REAR WHEEEL PKT (10838) / F58E 18BN W/6,8,9,10,12 WINDOW F58J 18BN F58J 18BN F58J 18BN / COMBINATION SPLICE (10704) / F58-GJ 18WH / F58-GE 18WH / SIDE MARKER LT AFTER ENTRANCE DOOR (10837) / F58-GD 18WH / F58-GH 18WH / F58H 18BN F58H 18BN F58D 18BN F58D 18BN / GROUND SPLICE (10701) CH3_52 / W/5,13 WINDOW / W/11 WINDOW / W/7 WINDOW / W/7,11 WINDOW / W/6,8,9,10,12 WINDOW / W/13 WINDOW / W/5 WINDOW / W/15,13 WINDOW / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 306 / MARKER LIGHT AFTER ENTRANCE DOOR AND AFTER REAR WHEEL POCKET WITH RIGHT BODY

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 347 | printed page 307 | section 7.47
7.47. COMBINATION LIGHT AFTER ENTRANCE DOOR AND FORWARD OR REAR WHEEL POCKET WITH LEFT BODY, P. 41
Figure 307 COMBINATION LIGHT AFTER ENTRANCE DOOR AND FORWARD OR REAR WHEEL

Components: CL LT SPLICE (10420); MARKER LT (10416); SPLICE (10419)
Wires (circuit gauge+color): E56-GE 18WH; E56-GF 18WH; E56-GG 18WH; E58D 18BN; E58E 18BN; E58F 18BN
See also sheets: CH3_54, CH7_54, CH7_55
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.47. COMBINATION LIGHT AFTER ENTRANCE DOOR AND FORWARD OR REAR WHEEL POCKET WITH LEFT BODY, P. 41 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 24DEC20 / CHAPTER 7 COMBINATION LIGHT AFTER ENTRANCE DOOR AND FORWARD OR REAR WHEEL POCKET W/LEFT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / **E58F 18BN **E56L 18YL / **E56-GG 18WH / SIDE MARKER LT (10417B) / %E56-GF 18WH / %E58E 18BN %E56K 18YL / SIDE MARKER LT (10417A) / SIDE MARKER LT (10512) / @E56-GF 18WH @E58E 18BN / @E56K 18YL / SIDE MARKER LT (10417) / #E58E 18BN #E56K 18YL / #E56-GF 18WH / DIRECTIONAL/ CL LT SPLICE (10420) CH7_55 DIRECTIONAL/ CL LT SPLICE (10420) CH7_54 / *E56-GE 18WH / *E56J 18YL / SIDE DIRECTIONAL / MARKER LT (10416) / *E58D 18BN / GROUND SPLICE (10419) CH3_54 / DIRECTIONAL/ CL LT SPLICE (10420) CH7_55 DIRECTIONAL/ CL LT SPLICE (10420) CH7_54 / DIRECTIONAL/ CL LT SPLICE (10420) CH7_55 DIRECTIONAL/ CL LT SPLICE (10420) CH7_54 / DIRECTIONAL/ CL LT SPLICE (10420) CH7_55 DIRECTIONAL/ CL LT SPLICE (10420) CH7_54 / DIRECTIONAL/ CL LT SPLICE (10420) CH7_55 DIRECTIONAL/ CL LT SPLICE (10420) CH7_54 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 307 / COMBINATION LIGHT AFTER ENTRANCE DOOR AND FORWARD OR REAR WHEEL POCKET WITH LEFT BODY

7.48. MARKER LIGHT AFTER ENTRANCE DOOR AND AFTER REAR WHEEL POCKET WITH LEFT BODY, P. 42
Figure 308 MARKER LIGHT AFTER ENTRANCE DOOR AND AFTER REAR WHEEL POCKET WITH

Components: AFTER ENTRANCE DOOR (10518); DIR/CL LT (10420); GROUND SPLICE (10419); GROUND SPLICE (10482); SPLICE (10482); WHEEL PKT (10519)
Wires (circuit gauge+color): E58-GB 18WH; E58-GC 18WH; E58-GF 18WH; E58-GH 18WH; E58-GJ 18WH; E58E 18BN; E58F 18BN; E58H 18BN; E58J 18BN
See also sheets: CH3_54, CH3_57, CH7_54, CH7_55
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.48. MARKER LIGHT AFTER ENTRANCE DOOR AND AFTER REAR WHEEL POCKET WITH LEFT BODY, P. 42 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 24DEC20 / CHAPTER 7 MARKER LIGHT AFTER ENTRANCE DOOR AND AFTER REAR WHEEL POCKET W/LEFT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SIDE MARKER LT AFTER REAR WHEEL PKT (10519) B / E58-GB 18WH E58-GC 18WH E58-GJ 18WH W/6,7,8,9,10,11,12 WINDOW / W/5 WINDOW E58E 18BN W/7,8 WINDOW E58J 18BN E58J 18BN E58H 18BN / SIDE MARKER LT AFTER ENTRANCE DOOR (10518) / E58-GH 18WH E58-GB 18WH W/7,8 WINDOW E58H 18BN / E58-GF 18WH / E58H 18BN E58F 18BN E58F 18BN / GROUND SPLICE (10419) CH3_54 / W/13 WINDOW / W/6,9,10,11,12 WINDOW / W/13 WINDOW / W/5 WINDOW / SPLICE DIR/CL LT (10420) CH7_55 / W/5 WINDOW / GROUND SPLICE (10482) CH3_57 W/6,7,8,9,10,11,12 WINDOW / W/13 WINDOW / SPLICE DIR/CL LT (10420) CH7_54,55 / GROUND SPLICE (10482) CH3_57 / W/5 WINDOW / W/6,9,11,10,12 WINDOW / W/13 WINDOW / SPLICE DIR/CL LT (10420) CH7_55 / SPLICE DIR/CL LT (10420) CH7_54 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 308 / MARKER LIGHT AFTER ENTRANCE DOOR AND AFTER REAR WHEEL POCKET WITH LEFT BODY

7.49. DIRECTIONAL LIGHTS NOT COWL MOUNTED WITH 2017 ISB / 2021 B6.7
Figure 309 DIRECTIONAL LIGHTS NOT COWL MOUNTED WITH 2017 ISB / 2021 B6.7 DIESEL AND

Components: BATT FEED (11505); BATT FEED (11506); CONTROLLER (1603); CONTROLLER (1604); DIGITAL LED CLOCK (4500); FUSE A1-C (10305); FUSE B12-D (10301); FWD CHASSIS/PLATFORM (1700); HOOD HARNESS (8003A); PLATFORM (1702); SPLICE (1003)
Wires (circuit gauge+color): A13SE 16PK; A56AA 14OR; A57AA 14OR; A58 14BN; A58A 14BN; A58C 14BN; A58D 14BN; A88-G 18WH; A88BAT 18LTGN; A88IGN 18LTGN; B14SE 16RD; B88BAT 18LTGN; B88IGN 18LTGN; M56A 14OR; M57A 14OR; M58AA 14BN
See also sheets: CH3_12, CH3_18, CH3_31, CH7_57
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.49. DIRECTIONAL LIGHTS NOT COWL MOUNTED WITH 2017 ISB / 2021 B6.7 DIESEL AND WITH 2018 PROPANE / GAS ENGINE, P. 43 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 24DEC20 / MJV0488 19NOV21 REMOVED R/D 8003B. / LEFT FRONT TURN SIGNAL / M56A 14OR / M57A 14OR / A56AA 14OR / J1-12 WAY BODY CONTROLLER (1603) / FWD CHASSIS/PLATFORM (1700) 6 / RIGHT FRONT TURN SIGNAL / A57AA 14OR / M58AA 14BN / A58A 14BN / A58 14BN / A58C 14BN / PARK LT F COMMAND 2 / J2-10 WAY BODY CONTROLLER (1604) PARK LT G COMMAND 1 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / @A58D 14BN / @A88BAT 18LTGN / DIGITAL LED CLOCK (4500) / A88-G 18WH / @A88IGN 18LTGN / ELEC PANEL/ PLATFORM (1702) 38 / B14SE 16RD / B88IGN 18LTGN / A13SE 16PK / SPECIAL EQUIPMENT BATT FEED (11505) / FUSE A1-C (10305) CH3_18 / GROUND SPLICE (1003) CH3_31 / SPECIAL EQUIPMENT BATT FEED (11506) / B88BAT 18LTGN / FUSE B12-D (10301) CH3_12 / @ W/LED CLOCK SPECIAL / FWD CHASSIS/ HOOD HARNESS (8003A) CH7_57,58 / Figure 309 / DIRECTIONAL LIGHTS NOT COWL MOUNTED WITH 2017 ISB / 2021 B6.7 DIESEL AND WITH 2018 PROPANE / GAS ENGINE

7.50. DIRECTIONAL LIGHTS WITH COWL MOUNTED WITH 2017 ISB / 2021 B6.7
Figure 310 DIRECTIONAL LIGHTS WITH COWL MOUNTED WITH 2017 ISB / 2021 B6.7 DIESEL AND

Components: CONTROLLER (1603); CONTROLLER (1604); FWD CHASSIS/PLATFORM (1700); GROUND (4037K); HOOD HARNESS (8003A)
Wires (circuit gauge+color): A56A 14OR; A56D 14OR; A56E 16OR; A56E-G 16WH; A57A 14OR; A57D 14OR; A57E 16OR; A57E-G 16WH; A58 14BN; A58A 14OR; A58C 14BN; M56A 14OR; M57A 14OR; M58AA 14BN
See also sheets: CH7_57
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.50. DIRECTIONAL LIGHTS WITH COWL MOUNTED WITH 2017 ISB / 2021 B6.7 DIESEL AND WITH 2018 PROPANE / GAS ENGINE, P. 44 / LEFT FRONT TURN SIGNAL / M56A 14OR / M57A 14OR / A56A 14OR / J1-12 WAY BODY CONTROLLER (1603) / FWD CHASSIS/PLATFORM (1700) 6 / RIGHT FRONT TURN SIGNAL / A57A 14OR / FWD CHASSIS/ HOOD HARNESS (8003A) CH7_57,58 / M58AA 14BN / %A58A 14OR / %A58 14BN / %A58C 14BN / PARK LT F COMMAND 2 / PARK LT G COMMAND 1 / J2-10 WAY BODY CONTROLLER (1604) / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / A57D 14OR / A56D 14OR / R COWL MOUNTED DIRECTIONAL LT (4049) 2 / A57E-G 16WH A57E 16OR / GROUND (4037K) / A56E-G 16WH A56E 16OR / L COWL MOUNTED DIRECTIONAL LT (4050) 2 / % W/0508108 - MTA FUSE BLOCK / Figure 310 / DIRECTIONAL LIGHTS WITH COWL MOUNTED WITH 2017 ISB / 2021 B6.7 DIESEL AND WITH 2018 PROPANE / GAS ENGINE

7.51. DIRECTIONAL AND MARKER COMBINATION LIGHTS WITH COWL MOUNTED
Figure 311 DIRECTIONAL AND MARKER COMBINATION LIGHTS WITH COWL MOUNTED WITH 2017

Components: CONTROLLER (1603); CONTROLLER (1604); DIRECT LT (4049A); DIRECT LT (4050A); GROUND (4037K); HOOD HARNESS (8003A); PLATFORM (1700)
Wires (circuit gauge+color): A56-GA 16WH; A56A 14OR; A56D 14OR; A56E 16OR; A57-GA 16WH; A57A 14OR; A57D 14OR; A57E 16OR; A58 14BN; A58A 14BN; A58C 14BN; A58D 16BN; A58E 16BN; M56A 14OR; M57A 14OR; M58AA 14BN
See also sheets: CH7_57
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.51. DIRECTIONAL AND MARKER COMBINATION LIGHTS WITH COWL MOUNTED WITH 2017 ISB / 2021 B6.7 DIESEL AND WITH 2018 PROPANE / GAS ENGINE, P. 45 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 24DEC20 / CHAPTER 7 DIRECTIONAL AND MARKER COMBINATION LIGHTS W/COWL MOUNTED W/2017/2021 ISB/B6.7 DIESEL & W/F-2018-PROPANE/GASOLINE-ENGINE / MJV0488 19NOV21 REMOVED R/D 8003B. / LEFT FRONT TURN SIGNAL / M56A 14OR / M57A 14OR / A56A 14OR / J1-12 WAY BODY CONTROLLER (1603) / FWD CHASSIS/ PLATFORM (1700) 6 / RIGHT FRONT TURN SIGNAL / A57A 14OR / FWD CHASSIS/ HOOD HARNESS (8003A) CH7_57,58 / M58AA 14BN / A58A 14BN / A58 14BN / A58C 14BN / PARK LT F COMMAND 2 / PARK LT G COMMAND 1 / J2-10 WAY BODY CONTROLLER (1604) / A57D 14OR / A56D 14OR / R COWL MOUNTED MARKER/ DIRECT LT (4049A) 3 / A57-GA 16WH A57E 16OR A58D 16BN / GROUND (4037K) / L COWL MOUNTED MARKER/ DIRECT LT (4050A) 3 / A56-GA 16WH A56E 16OR A58E 16BN / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 311 / DIRECTIONAL AND MARKER COMBINATION LIGHTS WITH COWL MOUNTED WITH 2017 ISB / 2021 B6.7 DIESEL AND WITH 2018 PROPANE / GAS ENGINE

7.52. DIRECTIONAL LIGHTS NOT COWL MOUNTED WITH 2017 ISB DIESEL AND WITH
Figure 312 DIRECTIONAL LIGHTS NOT COWL MOUNTED WITH 2017 ISB DIESEL AND WITH 2018

Components: BATT FEED (11505); BATT FEED (11506); CONTROLLER (1603); CONTROLLER (1604); DIGITAL LED CLOCK (4500); FUSE F36 (10303); FUSE F46 (10304); FWD CHASSIS/PLATFORM (1700); HOOD HARNESS (8003A); LIGHT OPTIONS (4600); PLATFORM (1702); SPLICE (1003)
Wires (circuit gauge+color): A13SE 16PK; A56A 14OR; A57A 14OR; A58 14BN; A58A 14BN; A58C 14BN; A58D 14BN; A58D 18BN; A88-G 18WH; A88BAT 18LTGN; A88IGN 18LTGN; B14SE 16RD; B88BAT 18LTGN; B88IGN 18LTGN; M56A 14OR; M57A 14OR; M58AA 14BN
See also sheets: CH7_57
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.52. DIRECTIONAL LIGHTS NOT COWL MOUNTED WITH 2017 ISB DIESEL AND WITH 2018 PROPANE / GAS ENGINE, P. 45A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 13MAR21 / CHAPTER 7 DIRECTIONAL LIGHTS N/COWL MOUNTED W/2017 ISB DIESEL & W/F-2018-PROPANE/GASOLINE-ENGINE / MJV0488 19NOV21 ADDED CIRC A58D IN R/D 4500.REMOVED R/D 8003B. / LEFT FRONT TURN SIGNAL / M56A 14OR / M57A 14OR / #A56A 14OR / J1-12 WAY BODY CONTROLLER (1603) / FWD CHASSIS/PLATFORM (1700) 6 / RIGHT FRONT TURN SIGNAL / #A57A 14OR / M58AA 14BN / #A58A 14BN / #A58 14BN / #A58C 14BN / PARK LT F COMMAND 2 / J2-10 WAY BODY CONTROLLER (1604) PARK LT G COMMAND 1 / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / @A58D 14BN / @A88BAT 18LTGN / DIGITAL LED CLOCK (4500) / A88-G 18WH / @A88IGN 18LTGN / ELEC PANEL/ PLATFORM (1702) 38 / PLATFORM PARK LIGHT OPTIONS (4600)CH7_45D FUSE F36 B14SE (10303) 16RD CH3_94H SPECIAL EQUIPMENT BATT FEED (11505) / B88IGN 18LTGN / A13SE 16PK / FUSE F46 (10304) CH3_94K / GROUND SPLICE (1003) CH3_95A / SPECIAL EQUIPMENT BATT FEED (11506) / B88BAT 18LTGN / FWD CHASSIS/ HOOD HARNESS (8003A) CH7_57,58 / *A58D 18BN / Figure 312 / DIRECTIONAL LIGHTS NOT COWL MOUNTED WITH 2017 ISB DIESEL AND WITH 2018 PROPANE / GAS ENGINE

7.53. LED CLOCK WITH PARK LIGHT OPTIONS WITH 2017 ISB DIESEL ENGINE, P. 45B
Figure 313 LED CLOCK WITH PARK LIGHT OPTIONS WITH 2017 ISB DIESEL ENGINE

Components: BATT FEED (11505); BATT FEED (11506); CLOCK (4500); CONTROLLER (1604); ELEC PANEL (1702); FWD HARNESS (1700); GROUND SPLICE (1003); HOOD HARNESS (8003A); L BODY (10400A); LIGHT OPTION (4600)
Wires (circuit gauge+color): A58 14BN; A58A 14BN; A58B 14BN; A58C 14BN; A58C 14LTGN; A58D 18BN; A88-G 18WH; A88BAT 18LTGN; A88IGN 18LTGN; B58E 16BN; B68 16BN; B88BAT 18LTGN; B88IGN 18LTGN; M58AA 14BN
See also sheets: CH7_57
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.53. LED CLOCK WITH PARK LIGHT OPTIONS WITH 2017 ISB DIESEL ENGINE, P. 45B / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 96289K 10OCT21 / CHAPTER 7 LED CLOCK W/PARK LIGHT OPTIONS W/F-2017-ISB-DISEL-ENG / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / # N/COWL MOUNTED DIRECTIONAL LIGHT N/LED CLOCK * W/COWL MOUNTED DIRECTIONAL LIGHT % N/COWL MOUNTED DIRECTIONAL LIGHT W/LED CLOCK / PLATFORM PARK LIGHT OPTION (4600) A / *A58C 14BN / *A58 14BN / J2 10 WAY BODY CONTROLLER (1604) / *A58B 14BN / 6 PLATFORM/ FWD HARNESS (1700) / *A58A 14BN / *A58D 18BN / PLATFORM/ ELEC PANEL (1702) B58E 16BN / B68 16BN / ELEC PANEL/ L BODY (10400A) CH7_38B / M58AA 14BN / %A58B 14BN %A58A #A58B #A58A 14BN 14BN 14BN / FWD CHASSIS HOOD HARNESS (8003A) CH7_57,58 / %A58D 18BN A88-G 18WH / #A58 14BN %A58 14BN #A58C 14BN %A58C 14LTGN / J2-10 WAY BODY CONTROLLER (1604) / GROUND SPLICE (1003) CH3_95A / PLATFORM/ ELEC PANEL (1702) 38 / A88BAT 18LTGN A88IGN 18LTGN / B88BAT 18LTGN / B88IGN 18LTGN / DIGITAL LED CLOCK (4500) / SPECIAL EQUIPMENT BATT FEED (11505) CH7_45E SPECIAL EQUIPMENT BATT FEED (11506) CH7_45E / Figure 313 / LED CLOCK WITH PARK LIGHT OPTIONS WITH 2017 ISB DIESEL ENGINE

7.54. DIRECTIONAL AND MARKER COMBINATION LIGHTS WITH COWL MOUNTED
Figure 314 DIRECTIONAL AND MARKER COMBINATION LIGHTS WITH COWL MOUNTED AND PARK

Components: CONTROLLER (1603); CONTROLLER (1604); DIRECT LT (4049A); DIRECT LT (4050A); GROUND (4037K); HOOD HARNESS (8003A); L BODY (10400A); OPTION (4600); PLATFORM (1700); PLATFORM (1702)
Wires (circuit gauge+color): A56-GA 16WH; A56A 14OR; A56D 14OR; A56E 16OR; A57-GA 16WH; A57A 14OR; A57D 14OR; A57E 16OR; A58 14BN; A58A 14BN; A58B 14BN; A58C 14BN; A58D 16BN; A58E 16BN; B58E 16BN; M56A 14OR; M57A 14OR; M58AA 14BN
See also sheets: CH7_57
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.54. DIRECTIONAL AND MARKER COMBINATION LIGHTS WITH COWL MOUNTED AND PARK LIGHT OPTIONS WITH 2017 ISB DIESEL ENGINE, P. 45C / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 96289K 07OCT21 / CHAPTER 7 DIRECTIONAL & MARKER COMBINATION LIGHTS W/CAWL MOUNTED W/PARK LIGHT OPTIONS W/2017-ISB-DIESEL ENG / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / LEFT FRONT TURN SIGNAL / M56A 14OR / M57A 14OR / A56A 14OR / J1-12 WAY BODY CONTROLLER (1603) / FWD CHASSIS/ PLATFORM (1700) 6 / D F / RIGHT FRONT TURN SIGNAL / A57A 14OR / B58E A58B 16BN 14BN PLATFORM PARK LT OPTION (4600) C / FWD CHASSIS/ HOOD HARNESS (8003A) CH7_57,58 / M58AA 14BN / A58A 14BN / A58 14BN A58C 14BN / PARK LT COMMAND 1 G PARK LT F COMMAND 2 / J2-10 WAY BODY CONTROLLER (1604) / A57D 14OR / A56D 14OR / R COWL MOUNTED MARKER/ DIRECT LT (4049A) 3 / A57-GA 16WH A57E 16OR A58D 16BN / GROUND (4037K) / L COWL MOUNTED MARKER/ DIRECT LT (4050A) 3 / A56-GA 16WH A56E 16OR A58E 16BN / NOTE: CONNECTIONS FOR VEHICLE N/0508108 - NOT MTA FUSE BLOCK. / ELEC PANEL/ PLATFORM (1702) 6 / ELEC PANEL/ L BODY (10400A) CH7_34B / Figure 314 / DIRECTIONAL AND MARKER COMBINATION LIGHTS WITH COWL MOUNTED AND PARK LIGHT OPTIONS WITH 2017 ISB DIESEL ENGINE

7.55. DIRECTIONAL AND MARKER COMBINATION LIGHTS WITH COWL MOUNTED,
Figure 315 DIRECTIONAL AND MARKER COMBINATION LIGHTS WITH COWL MOUNTED, PARK

Components: CLOCK (4500); CONTROLLER (1603); CONTROLLER (1604); DIRECTIONAL LT (4049A); DIRECTIONAL LT (4050A); GROUND (4037K); HOOD HARNESS (8003A); L BODY (10400A); OPTION (4600); PLATFORM (1700); PLATFORM (1702)
Wires (circuit gauge+color): A56-GA 16WH; A56A 14OR; A56D 14OR; A56E 16OR; A57-GA 16WH; A57A 14OR; A57D 14OR; A57E 16OR; A58 14BN; A58A 14BN; A58B 14BN; A58C 14BN; A58D 16BN; A58D 18BN; A58E 16BN; B58E 16BN; M56A 14OR; M57A 14OR; M58AA 14BN
See also sheets: CH7_57
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.55. DIRECTIONAL AND MARKER COMBINATION LIGHTS WITH COWL MOUNTED, PARK LIGHT OPTIONS WITH 2018 PROPANE / GAS ENGINE, P. 45D / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 96289K 07OCT21 / CHAPTER 7 DIRECTIONAL & MARKER COMBINATION LIGHTS W/CAWL MOUNTED W/PARK LIGHT OPTIONS W/F-2018-PROPANE/GASOLINE-ENG / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / LEFT FRONT TURN SIGNAL / M56A 14OR / M57A 14OR / A56A 14OR / J1-12 WAY BODY CONTROLLER (1603) / FWD CHASSIS/ PLATFORM (1700) 6 / D F / RIGHT FRONT TURN SIGNAL / A57A 14OR / B58E A58B 16BN 14BN PLATFORM PARK LT OPTION (4600) C / FWD CHASSIS/ HOOD HARNESS (8003A) CH7_57,58 / M58AA 14BN / A58A 14BN / A58 14BN A58C 14BN / PARK LT G COMMAND 1 PARK LT F COMMAND 2 / J2-10 WAY BODY CONTROLLER (1604) / A57D 14OR / A56D 14OR / R COWL MOUNTED MARKER/ DIRECTIONAL LT (4049A) 3 / A57-GA 16WH A57E 16OR A58D 16BN / GROUND (4037K) / L COWL MOUNTED MARKER/ DIRECTIONAL LT (4050A) 3 / A56-GA 16WH A56E 16OR A58E 16BN / NOTE: CONNECTIONS FOR VEHICLE N/0508108 - NOT MTA FUSE BLOCK. / ELEC PANEL/ PLATFORM (1702) 6 / ELEC PANEL/ L BODY (10400A) CH7_34B / A58D 18BN / DIGITAL LED CLOCK (4500)CH7_45A / Figure 315 / DIRECTIONAL AND MARKER COMBINATION LIGHTS WITH COWL MOUNTED, PARK LIGHT OPTIONS WITH 2018 PROPANE / GAS ENGINE

7.56. LED CLOCK WITH PARK LIGHT OPTIONS WITH 2017 ISB DIESEL ENGINE, P. 45E
Figure 316 LED CLOCK WITH PARK LIGHT OPTIONS WITH 2017 ISB DIESEL ENGINE

Components: BATTERY FEED (11505); BATTERY FEED (11506); CLOCK (4500); ELEC PANEL (1702); FUSE F36 (10303); FUSE F46 (10304)
Wires (circuit gauge+color): A88BAT 18LTGN; A88IGN 18LTGN; B13SE 16PK; B14SE 16RD; B88BAT 18LTGN; B88IGN 18LTGN
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.56. LED CLOCK WITH PARK LIGHT OPTIONS WITH 2017 ISB DIESEL ENGINE, P. 45E / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 96289K 07OCT21 / CHAPTER 7 LED CLOCK W/PARK LIGHT OPTIONS W/2017-ISB-DIESEL ENG / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / A88BAT 18LTGN / A88IGN 18LTGN / SPECIAL EQUIPMENT BATTERY FEED (11505) / PLATFORM/ ELEC PANEL (1702) 38 / DIGITAL LED CLOCK (4500) CH7_45B / B14SE 16RD / B88BAT 18LTGN / NOTE: CONNECTIONS FOR VEHICLE N/0508108 - NOT MTA FUSE BLOCK. / B13SE 16PK / B88IGN 18LTGN / FUSE F36 (10303) CH3_94H / SPECIAL EQUIPMENT BATTERY FEED (11506) / FUSE F46 (10304) CH3_94K / Figure 316 / LED CLOCK WITH PARK LIGHT OPTIONS WITH 2017 ISB DIESEL ENGINE

7.57. CORNER MARKER LIGHTS, P. 46
Figure 317 CORNER MARKER LIGHTS

Components: FRONT CAP (10000); LIGHT (10016); LIGHT (10018); LIGHT RELAY (10308); LIGHT RELAY (10308-R1); MARKER LIGHT (10017); MARKER LIGHT (10019); SPLICE (10010)
Wires (circuit gauge+color): B58A 16BN; B58C 18BN; C58 18BN; C58-G 18WH; C58-GE 18WH; C58-GF 18WH; C58-GH 18WH; C58-GJ 18WH; C58E 18BN; C58F 18BN; C58H 18BN; C58J 18BN
See also sheets: CH3_44, CH7_66
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.57. CORNER MARKER LIGHTS, P. 46 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 24DEC20 / CORNER MARKER LIGHTS / CHAPTER 7 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CORNER MARKER LIGHT (10018) A / CORNER MARKER LIGHT (10016) A / ELEC PANEL/ FRONT CAP A2 (10000) / * CORNER MARKER LT - SINGLE # CORNER MARKER LT - DUAL @ W/VEHICLES BUILT AFTER 8/4/2017 & BEFORE 01/08/2020 ! W/VEHICLES BUILT AFTER 01/08/2020. / SECOND CORNER MARKER LIGHT (10019) A / SECOND CORNER MARKER LIGHT (10017) A / GROUND SPLICE (10010) CH3_44 / #C58 18BN *C58 18BN / *C58F 18BN #C58F 18BN / *C58E 18BN / B58C 18BN / C58-GF 18WH / C58-GE 18WH / #C58E 18BN / #C58J 18BN C58-GJ 18WH / C58-G 18WH / #C58H 18BN C58-GH 18WH / CLEARANCE LIGHT RELAY (10308) CH7_66A CLEARANCE LIGHT RELAY (10308-R1) CH7_66 / !B58A 16BN / @B58A 16BN / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 317 / CORNER MARKER LIGHTS

7.58. CLEARANCE / IDENTIFICATION LIGHTS (STANDARD), P. 47
Figure 318 CLEARANCE / IDENTIFICATION LIGHTS (STANDARD)

Components: CL LT SPLICE (10420); CLUSTER LT (10114); CLUSTER LT (10115); CLUSTER LT (10116); GROUND SPLICE (10160); L BODY (10400); MARKER LT (10119); REAR CAP (10406); REAR CAP/R BODY (10700); SPLICE (10704)
Wires (circuit gauge+color): D58-G 16WH; D58-GC 16WH; D58-GD 16WH; D58-GE 16WH; D58-GH 16WH; D58-GK 16WH; D58B 16BN; D58C 16BN; D58D 16BN; D58E 16BN; D58F 16BN; D58H 16BN; D58J 16BN; D58K 16BN; E58B 16BN; F58BJ 16BN
See also sheets: CH3_45, CH7_18, CH7_53, CH7_55
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.58. CLEARANCE / IDENTIFICATION LIGHTS (STANDARD), P. 47 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 24DEC20 / CHAPTER 7 CLEARANCE/IDENTIFICATION LIGHTS (STANDARD) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / L REAR CLUSTER LT (10114) A / R REAR CLUSTER LT (10116) A / L CORNER MARKER LT (10108) A / CTR REAR CLUSTER LT (10115) A / R CORNER MARKER LT (10119) A / D58C 16BN D58-GC 16WH / D58E 16BN D58-GE 16WH / D58K 16BN D58-GK 16WH / D58D 16BN D58-GD 16WH / L REAR CAP GROUND SPLICE (10160) CH3_45 / D58B 16BN / REAR CAP/R BODY (10700) A4 F58BJ 16BN / D58F 16BN / L BODY/ REAR CAP (10406) C8 / E58B 16BN / DIRECTIONAL/ CL LT SPLICE (10420) CH7_55 / ELEC PANEL/ L BODY (10400) CH7_18 / E58B 16BN / D58J 16BN / D58H 16BN D58-GH 16WH / D58-G 16WH / COMBINATION SPLICE (10704) CH7_53 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 318 / CLEARANCE / IDENTIFICATION LIGHTS (STANDARD)

7.59. CLEARANCE / IDENTIFICATION LIGHTS ACTIVATED BY EMERGENCY EXIT LIGHT, P. 48
Figure 319 CLEARANCE / IDENTIFICATION LIGHTS ACTIVATED BY EMERGENCY EXIT LIGHT

Components: CL LT SPLICE (10420); CLUSTER LT (10114); CLUSTER LT (10115); CLUSTER LT (10116); EMER EXIT LT (10142); GROUND SPLICE (10160); GROUND SPLICE (10161); L BODY (10400); MARKER LIGHT (10119); REAR CAP (10406); REAR CAP/R BODY (10700); SPLICE (10704)
Wires (circuit gauge+color): D58-G 16WH; D58-GC 16WH; D58-GD 16WH; D58-GE 16WH; D58-GH 16WH; D58-GK 16WH; D58-GN 16WH; D58B 16BN; D58C 16BN; D58D 16BN; D58E 16BN; D58F 16BN; D58H 16BN; D58J 16BN; D58K 16BN; D58N 16BN; E58B 16BN; F58BJ 16BN
See also sheets: CH3_45, CH3_46, CH7_18, CH7_53, CH7_55
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.59. CLEARANCE / IDENTIFICATION LIGHTS ACTIVATED BY EMERGENCY EXIT LIGHT, P. 48 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 24DEC20 / CHAPTER 7 CLEARANCE/IDENTIFICATION LIGHTS ACTIVATED BY EMERGENCY EXIT LIGHT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / L REAR CLUSTER LT (10114) A / R REAR CLUSTER LT (10116) A / L CORNER MARKER LT (10108) A / CTR REAR CLUSTER LT (10115) A / R CORNER MARKER LIGHT (10119) A / D58C 16BN D58-GC 16WH / D58E 16BN D58-GE 16WH / D58K 16BN D58-GK 16WH / D58D 16BN D58-GD 16WH / R REAR CAP GROUND SPLICE (10161) CH3_46 L REAR CAP GROUND SPLICE (10160) CH3_45 / D58B 16BN / REAR CAP/R BODY (10700) A4 F58BJ 16BN / D58F 16BN / LEFT BODY/ REAR CAP (10406) C8 / E58B 16BN / DIRECTIONAL/ CL LT SPLICE (10420) CH7_55 / ELEC PANEL/ L BODY (10400) CH7_18 / E58B 16BN / D58J 16BN / D58H 16BN D58-GH 16WH / D58-G 16WH / BULKHEAD MOUNTED EMER EXIT LT (10142) A / D58N 16BN D58-GN 16WH / COMBINATION SPLICE (10704) CH7_53 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 319 / CLEARANCE / IDENTIFICATION LIGHTS ACTIVATED BY EMERGENCY EXIT LIGHT

7.60. CLEARANCE / IDENTIFICATION LIGHTS / DUAL CORNER / ACTIVATED BY EMERGENCY EXIT LIGHT, P. 49
Figure 320 CLEARANCE / IDENTIFICATION LIGHTS / DUAL CORNER / ACTIVATED BY EMERGENCY

Components: CL LT SPLICE (10420); CLUSTER LT (10114); CLUSTER LT (10115); CLUSTER LT (10116); EMER EXIT LT (10142); GROUND SPLICE (10160); GROUND SPLICE (10161); L BODY (10400); MARKER LT (10119); MARKER LT (10156); MARKER LT (10157); REAR CAP (10406); REAR CAP/R BODY (10700); SPLICE (10704)
Wires (circuit gauge+color): D58-G 16WH; D58-GA 16WH; D58-GC 16WH; D58-GD 16WH; D58-GE 16WH; D58-GH 16WH; D58-GK 16WH; D58-GL 16WH; D58-GM 16WH; D58-GN 16WH; D58B 16BN; D58C 16BN; D58D 16BN; D58E 16BN; D58F 16BN; D58H 16BN; D58J 16BN; D58K 16BN; D58L 16BN; D58M 16BN; D58N 16BN; E58B 16BN; F58BJ 16BN
See also sheets: CH3_45, CH3_46, CH7_18, CH7_53, CH7_55
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.60. CLEARANCE / IDENTIFICATION LIGHTS / DUAL CORNER / ACTIVATED BY EMERGENCY EXIT LIGHT, P. 49 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 24DEC20 / CHAPTER 7 CLEARANCE/IDENTIFICATION LIGHTS/DUAL CORNER/ACTIVATED BY EMERGENCY EXIT LIGHT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / L REAR CLUSTER LT (10114) A / R REAR CLUSTER LT (10116) A / L CORNER MARKER LT (10108) A / CTR REAR CLUSTER LT (10115) A / R CORNER MARKER LT (10119) A / D58C 16BN D58-GC 16WH / D58E 16BN D58-GE 16WH / D58K 16BN D58-GK 16WH / D58D 16BN D58-GD 16WH / D58B 16BN / REAR CAP/R BODY (10700) A4 / D58F 16BN / L BODY/ REAR CAP (10406) C8 / E58B 16BN / DIRECTIONAL/ CL LT SPLICE (10420) CH7_55 / ELEC PANEL/ L BODY (10400) CH7_18 / E58B 16BN / D58J 16BN / D58H 16BN D58-GH 16WH R CORNER MARKER LT (10156) #D58M A 16BN #D58-GM 16WH BULKHEAD MOUNTED EMER EXIT LT (10142) A @D58N 16BN @D58-GN 16WH / D58-GA 16WH D58-G 16WH / R REAR CAP GROUND SPLICE (10161) CH3_46 / L DUAL CORNER MARKER LT (10157) A / #D58L 16BN / #D58-GL 16WH / @ W/EMERGENCY EXIT LIGHT # W/DUAL CORNER LIGHT NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / F58BJ 16BN / COMBINATION SPLICE (10704) CH7_53 / L REAR CAP GROUND SPLICE (10160) CH3_45 / Figure 320 / CLEARANCE / IDENTIFICATION LIGHTS / DUAL CORNER / ACTIVATED BY EMERGENCY EXIT LIGHT

7.61. CLEARANCE / IDENTIFICATION LIGHTS / DUAL CORNER / CEILING MOUNTED REAR EMERGENCY EXIT LIGHT, P. 50
Figure 321 CLEARANCE / IDENTIFICATION LIGHTS / DUAL CORNER / CEILING MOUNTED REAR

Components: CL LT SPLICE (10420); CLUSTER LT (10114); CLUSTER LT (10115); CLUSTER LT (10116); EMER EXIT LT (10142A); GROUND SPLICE (10160); GROUND SPLICE (10161); L BODY (10400); MARKER LT (10119); MARKER LT (10156); MARKER LT (10157); REAR CAP (10406); REAR CAP/R BODY (10700); SPLICE (10704)
Wires (circuit gauge+color): D143 16DKBL; D143-G 16WH; D58-G 16WH; D58-GA 16WH; D58-GC 16WH; D58-GD 16WH; D58-GE 16WH; D58-GH 16WH; D58-GK 16WH; D58-GL 16WH; D58-GM 16WH; D58B 16BN; D58C 16BN; D58D 16BN; D58E 16BN; D58F 16BN; D58H 16BN; D58J 16BN; D58K 16BN; D58L 16BN; D58M 16BN; D58P 16BN; E58B 16BN; F58BJ 16BN
See also sheets: CH3_45, CH3_46, CH7_18, CH7_53, CH7_55
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.61. CLEARANCE / IDENTIFICATION LIGHTS / DUAL CORNER / CEILING MOUNTED REAR EMERGENCY EXIT LIGHT, P. 50 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 25DEC20 / CHAPTER 7 CLEARANCE/IDENTIFICATION LIGHTS/DUAL CORNER/CEILING MOUNTED REAR EMERGENCY EXIT LIGHT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / L REAR CLUSTER LT (10114) A / R REAR CLUSTER LT (10116) A / L CORNER MARKER LT (10108) A / CTR REAR CLUSTER LT (10115) A / R CORNER MARKER LT (10119) A / D58C 16BN D58-GC 16WH / D58E 16BN D58-GE 16WH / D58K 16BN D58-GK 16WH / D58D 16BN D58-GD 16WH / L REAR CAP GROUND SPLICE (10160) CH3_45 / D58P 16BN / REAR CAP/R BODY (10700) A4 D58J F58BJ 16BN 16BN / D58F 16BN / L BODY/ REAR CAP (10406) C8 / E58B 16BN / DIRECTIONAL/ CL LT SPLICE (10420) CH7_55 / ELEC PANEL/ L BODY (10400) CH7_18 / E58B 16BN / D58H 16BN D58-GH 16WH R CORNER MARKER LT (10156) A / D58-GA 16WH D58-G 16WH / CELLING-MOUNTED EMER EXIT LT (10142A) @D143 A 16DKBL D143-G 16WH / R REAR CAP GROUND SPLICE (10161) CH3_46 / D58M 16BN D58-GM 16WH / L DUAL CORNER MARKER LT (10157) A / #D58L 16BN #D58-GL 16WH / D58B 16BN / COMBINATION SPLICE (10704) CH7_53 / @ W/CELLING MOUNTED REAR EMERGENCY LT # W/DUAL CORNER LT / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 321 / CLEARANCE / IDENTIFICATION LIGHTS / DUAL CORNER / CEILING MOUNTED REAR EMERGENCY EXIT LIGHT

7.62. CLEARANCE / IDENTIFICATION LIGHTS & CEILING MOUNTED REAR EMERGENCY EXIT LIGHT & RIGHT REAR MARKER LIGHT, P. 51
Figure 322 CLEARANCE / IDENTIFICATION LIGHTS & CEILING MOUNTED REAR EMERGENCY EXIT

Components: CAP GROUND (10161); CL LT SPLICE (10420); CLUSTER LT (10114); CLUSTER LT (10115); CLUSTER LT (10116); EMER EXIT LT (10142); EMER EXIT LT (10142A); GROUND SPLICE (10160); GROUND SPLICE (10161); L BODY (10400); MARKER LT (10119); MARKER LT (10183); REAR CAP (10406); REAR CAP/R BODY (10700); SPLICE (10704)
Wires (circuit gauge+color): D143 16DKBL; D143-G 16WH; D58-G 16WH; D58-GC 16WH; D58-GD 16WH; D58-GE 16WH; D58-GH 16WH; D58-GK 16WH; D58-GL 16WH; D58-GN 16WH; D58B 16BN; D58C 16BN; D58D 16BN; D58E 16BN; D58F 16BN; D58H 16BN; D58J 16BN; D58K 16BN; D58N 16BN; D58P 16BN; D58R 16BN; E58B 16BN; F58BJ 16BN
See also sheets: CH3_45, CH3_46, CH7_18, CH7_55, CH7_63
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.62. CLEARANCE / IDENTIFICATION LIGHTS & CEILING MOUNTED REAR EMERGENCY EXIT LIGHT & RIGHT REAR MARKER LIGHT, P. 51 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 25DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / DIRECTIONAL/ CL LT SPLICE (10420) CH7_55 ELEC PANEL/ L BODY (10400) CH7_18 L REAR CLUSTER LT (10114) A / COMBINATION SPLICE (10704) CH7_63 R REAR CLUSTER LT (10116) A / L CORNER MARKER LT (10108) A / CTR REAR CLUSTER LT (10115) A / R CORNER MARKER LT (10119) A / D58C 16BN D58-GC 16WH / D58E 16BN D58-GE 16WH / D58K 16BN D58-GK 16WH / D58D 16BN D58-GD 16WH / R REAR CAP GROUND SPLICE (10161) CH3_46 L REAR CAP GROUND SPLICE (10160) CH3_45 / %D58P 16BN / REAR CAP/R BODY (10700) A4 D58J 16BN / %D58F 16BN / L BODY/ REAR CAP @D58B (10406) 16BN C8 / E58B 16BN / E58B 16BN / D58H 16BN D58-GH 16WH / D58-G 16WH / R REAR MARKER LT (10183) A / D58R 16BN D58-GL 16WH / D58B 16BN / D143 16DKBL D143-G 16WH BULKHEAD MOUNTED EMER EXIT LT (10142) A / CELLING MOUNTED EMER EXIT LT (10142A) A / R REAR CAP GROUND (10161) CH3_46 / F58BJ 16BN / @D58F 16BN / *D58N 16BN D58-GN 16WH / Figure 322 / CLEARANCE / IDENTIFICATION LIGHTS & CEILING MOUNTED REAR EMERGENCY EXIT LIGHT & RIGHT REAR MARKER LIGHT

7.63. INTERMEDIATE / SIDE MARKER LIGHT / 3 INCH LIGHT OVER KICK OUT WINDOW WITH L BODY, P. 52
Figure 323 INTERMEDIATE / SIDE MARKER LIGHT / 3 INCH LIGHT OVER KICK OUT WINDOW WITH L

Components: CL LT SPLICE (10420); GROUND SPLICE (10482); SPLICE (10419)
Wires (circuit gauge+color): E58-GA 18WH; E58-GB 18WH; E58C 18BN; E58D 18BN
See also sheets: CH3_54, CH3_55, CH3_57, CH7_55
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.63. INTERMEDIATE / SIDE MARKER LIGHT / 3 INCH LIGHT OVER KICK OUT WINDOW WITH L BODY, P. 52 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 25DEC20 / CHAPTER 7 INTERMEDIATE/SIDE MARKER LIGHT/3 INCH LIGHT OVER KICK OUT WINDOW W/LEFT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / W/5 WINDOW INTERMEDIATE MARKER LT (10418) B / E58-GA 18WH @E58-GB 18WH #E58-GA 18WH #E58C 18BN / DIRECTIONAL/ CL LT SPLICE (10420) CH7_55 / @E58D 18BN / GROUND SPLICE (10482) CH3_57 GROUND SPLICE (10419) CH3_55 / INTERMEDIATE MARKER LT (10418A) B / %E58-GA 18WH / %E58C 18BN / GROUND SPLICE (10419) CH3_54 DIRECTIONAL/ CL LT SPLICE (10420) CH7_55 / @ W/10 WINDOW # W/5,6,7,8,9,11,12,13 WINDOW % W/13 WINDOW W/SECT 6 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 323 / INTERMEDIATE / SIDE MARKER LIGHT / 3 INCH LIGHT OVER KICK OUT WINDOW WITH L BODY

7.64. INTERMEDIATE / SIDE MARKER LIGHT / 3 INCH LIGHT OVER KICK OUT WINDOW WITH R BODY, P. 53
Figure 324 INTERMEDIATE / SIDE MARKER LIGHT / 3 INCH LIGHT OVER KICK OUT WINDOW WITH R

Components: CLUSTER LT (10116); LT MIDSHIP (10710); LT MIDSHIP (10710A); R BODY/REAR CAP (10700); SPLICE (10701); SPLICE (10704)
Wires (circuit gauge+color): D58J 16BN; F58 16BN; F58-GA 18WH; F58A 18BN; F58B 16BN; F58BJ 16BN; F58J 16BN
See also sheets: CH3_52, CH7_47
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.64. INTERMEDIATE / SIDE MARKER LIGHT / 3 INCH LIGHT OVER KICK OUT WINDOW WITH R BODY, P. 53 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 25DEC20 / CHAPTER 7 INTERMEDIATE/SIDE MARKER LIGHT/3 INCH LIGHT OVER KICK OUT WINDOW W/RIGHT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / COMBINATION SPLICE (10704) / %F58 16BN %F58A 18BN @F58A 18BN F58-GA 18WH / GROUND SPLICE (10701) CH3_52 / INTERMEDIATE MARKER LT MIDSHIP (10710) / &F58BJ 16BN *F58J 16BN %F58B 16BN / & W/5,6,7,8,10,11 WINDOW * W/9,13 WINDOW @ W/5,6,7,8,9,10,11 WINDOW # W/13 WINDOW / #F58-GA 18WH #F58A 18BN / INTERMEDIATE MARKER LT MIDSHIP (10710A) / R BODY/REAR CAP (10700) A4 / D58J 16BN / R REAR CLUSTER LT (10116) CH7_47,48,49,50,51 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 324 / INTERMEDIATE / SIDE MARKER LIGHT / 3 INCH LIGHT OVER KICK OUT WINDOW WITH R BODY

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 365 | printed page 325 | section 7.65
7.65. DIRECTIONAL / CLEARANCE LIGHT SPLICE, P. 54
Figure 325 DIRECTIONAL / CLEARANCE LIGHT SPLICE

Components: DIRECTIONAL CL LT SPLICE (10420); FWD REAR WHL PKT (10506B); L BODY/ELEC PANEL (10400); L BODY/REAR CAP (10406); MARKER LT (10416); MARKER LT (10417/A); MARKER LT (10417B); OVER REAR WHL PKT (10511B); SIDE DIRECTIONAL LT (10410); SIDE DIRECTIONAL LT (10411); SIDE DIRECTIONAL LT (10411A); SIDE DIRECTIONAL LT (10412); SIDE DIRECTIONAL LT (10412A/B); SIDE DIRECTIONAL LT (10413); SIDE DIRECTIONAL LT (10413A); SIDE DIRECTIONAL LT (10413A/B); SIDE DIRECTIONAL LT (10414); SIDE DIRECTIONAL LT (10506/10506A); SIDE DIRECTIONAL LT (10511/10511A); SIDE DIRECTIONAL LT (10519); SIDE MARKER LT (10512); SIDE MARKER LT FWD (10518)
Wires (circuit gauge+color): E58H 18BN; E58J 18BN
See also sheets: CH7_18, CH7_20, CH7_35, CH7_36, CH7_41, CH7_42
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.65. DIRECTIONAL / CLEARANCE LIGHT SPLICE, P. 54 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 25DEC20 / CHAPTER 7 DIRECTIONAL/CLEARANCE LIGHT SPLICE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / D D / E56D 18YL E56K 18YL E56L 18YL E56L 18YL E56M 18YL E56A 18YL E56M 18YL E56A 18YL / SIDE DIRECTIONAL LT (10412) CH7_35 / SIDE DIRECTIONAL LT (10412A/B) CH7_35 SIDE DIRECTIONAL LT (10413) CH7_35 / W/6 WINDOW / W/12,13 WINDOW W/10,11,12,13 WINDOW / W/7,8 WINDOW / W/7,8 WINDOW W/11 WINDOW W/9,10,12,13 WINDOW W/6 WINDOW / W/8 WINDOW / W/8 WINDOW / W/5,7,8,9 WINDOW W/11 WINDOW / W/5,6,7,8,9,11,12,13 WINDOW / W/13 WINDOW / W/10 WINDOW / W/12,13 WINDOW / Figure 325 / DIRECTIONAL / CLEARANCE LIGHT SPLICE

7.66. DIRECTIONAL / CLEARANCE LIGHT SPLICE (CONT.), P. 55
Figure 326 DIRECTIONAL / CLEARANCE LIGHT SPLICE (CONT.)

Components: AFTER ENTRANCE DOOR (10518); AFTER ENTRANCE WHL PKT (10519); DIRECTIONAL/CL LT SPLICE (10420); INTERMEDIATE MARKER LT (10418/10418A); L BODY/ELECTRICAL PANAL (10400); L BODY/REAR CAP (10406); MARKER LT (10416); SIDE MARKER LT (10417/10417A); SIDE MARKER LT (10417B); SIDE MARKER LT (10512); SPLICE (10423)
Wires (circuit gauge+color): E143A 18DKBL; E58A 16BN; E58B 16BN; E58C 18BN; E58D 18BN; E58E 18BN; E58F 18BN; E58H 18BN; E58J 18BN
See also sheets: CH14_05, CH7_18, CH7_41, CH7_42, CH7_52, CH7_66
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.66. DIRECTIONAL / CLEARANCE LIGHT SPLICE (CONT.), P. 55 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 25DEC20 / CHAPTER 7 DIRECTIONAL/CLEARANCE LIGHT SPLICE (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / E58B 16BN / E58A 16BN / E58C 18BN E58D 18BN E58D 18BN / E143A 18DKBL / E58E 18BN E58F 18BN E58E 18BN E58F 18BN / DIRECTIONAL/CL LT SPLICE (10420) / INTERMEDIATE MARKER LT (10418/10418A) CH7_52 SIDE DIRECTIONAL/ MARKER LT (10416) CH7_41 / L BODY/REAR CAP (10406) CH7_18,47,48,49,50,51 L BODY/ELECTRICAL PANAL (10400) CH7_66 / E58J 18BN / E58H 18BN / SIDE MARKER LT AFTER ENTRANCE WHL PKT (10519) CH7_42 / E58E E58E 18BN 18BN / W/5-9,11-13 WINDOW / W/8,10-13 WINDOW / W/8 WINDOW / W/5,6,7,9 WINDOW / W/5 WINDOW / W/6,9-12 WINDOW / W/13 WINDOW / W/5 WINDOW / E58H E58H 18BN 18BN / E58F 18BN / SIDE MARKER LT AFTER ENTRANCE DOOR (10518) CH7_42 / W/10 WINDOW / W/13 WINDOW / W/6,9,10,11,12 WINDOW / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 326 / DIRECTIONAL / CLEARANCE LIGHT SPLICE (CONT.)

7.67. HEAD LIGHTS WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 56
Figure 327 HEAD LIGHTS WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: BODY CONTROLLER (1604); HI/LOW BEAMS (8004A); HOOD/FWD CHASSIS (8003A); PLATFORM (1700)
See also sheets: CH7_57, CH7_59
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.67. HEAD LIGHTS WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 56 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 25DEC20 / CHAPTER 7 HEAD LIGHTS W/2017/2021 ISB/B6.7 DIESEL ENG & W/F-2018-PROPANE/GASOLINE-ENGINE / MJV0488 19NOV21 REMOVED R/D 8003B, 8004B. / M53B 12YL / M52B 12YL / M53A 12YL M52A 12YL / W/F-2018-PROPANE/GASOLINE-ENGINE FWD CHASSIS/ PLATFORM (1700) 4 / A53A 14YL A52A 14YL / HEADLAMP LOW H BEAM RIGHT HEADLAMP HIGH BEAM RIGHT HEADLAMP HIGH BEAM LEFT HEADLAMP LOW BEAM LEFT / A52B 14YL A53B 14YL / J2-10 WAY BODY CONTROLLER (1604) / R HEADLIGHT HI/LOW BEAMS (8004A) CH7_59 / HOOD/FWD CHASSIS (8003A) CH7_59 / W/2017/2021 ISB/B6.7 DIESEL ENG / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / FWD CHASSIS/ PLATFORM (1700) 4 / M53A 12YL M52A 12YL / J2-10 WAY BODY CONTROLLER (1604) / HEADLAMP LOW H BEAM RIGHT HEADLAMP HIGH BEAM RIGHT HEADLAMP HIGH BEAM LEFT HEADLAMP LOW BEAM LEFT / A52B 14YL A53B 14YL / A53A 14YL A52A 14YL / HOOD/FWD CHASSIS (8003A) CH7_57,58 / M53B 12YL / R HEADLIGHT HI/LOW BEAMS (8004A) CH7_57,58 / M52B 12YL / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 327 / HEAD LIGHTS WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

7.68. HEAD LIGHTS WITH PEDESTAL MOUNT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 57
Figure 328 HEAD LIGHTS WITH PEDESTAL MOUNT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: CHASSIS (1700); HI/LOW BEAMS (8004A); HOOD (8003A); PLATFORM (1700); TURN SIGNAL (8000); TURN SIGNAL (8001)
Wires (circuit gauge+color): M11-G 10WH; M11-G 14WH; M11-GB 12WH; M11-GC 12WH; M56A 14OR; M57A 14OR; M58AA 14BN; U11-GA 14WH; U11-GB 12WH; U11-GC 14WH; U11-GD 14WH; U11-GG 16WH; U11-GH 16WH; U56A 14OR; U56B 16OR; U56F 16OR; U57A 14OR; U57B 16OR; U57F 16OR; U58B 14BN; U58C 16BN; U58D 16BN; U58H 16BN; U58J 16BN
See also sheets: CH3_50, CH7_43, CH7_56
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.68. HEAD LIGHTS WITH PEDESTAL MOUNT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 57 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 25DEC20 / MJV0488 19NOV21 ADDED CIRC M58AA IN B 96289K R/D 1700.REMOVED R/D 8003B,8004B. / U11-GD 14WH U58C 16BN U56B 16OR U53B 14YL U52B 14YL LEFT PEDESTAL MOUNT TURN SIGNAL (@8156L/#8100L) 1/A / U11-GA 14WH U52A 14YL U53A 14YL U57B 16OR U58D 16BN RIGHT PEDESTAL MOUNT TURN SIGNAL (#8100R/@8156R) A/1 / @M52A 12YL #M53A 12YL / LEFT HEADLIGHT TURN SIGNAL (8001) / U57F 16OR U58J 16BN C/3 U11-GH 16WH / FRONT MARKER AND TURN LIGHT / U56F 16OR 2/B U58H 16BN 2/C U11-GG 16WH / BODY GROUND STUD (2GA) CH3_50 / PEANUT LIGHT / U11-GB 12WH U58B 14BN U56A 14OR / M11-GC M11-GB M58AA 12WH 12WH 14BN M56A 14OR M53B 12YL M52B 12YL M57A 14OR / RIGHT HEADLIGHT TURN SIGNAL (8000) / FORWARD CHASSIS/ HOOD (8003A) M11-G 14WH M11-G 10WH / # N/LED @ W/LED * W/LED CLOCK W/PARK LT / FRONT MARKER AND TURN LIGHT / U11-GC U57A 14OR 14WH / PEANUT LIGHT / M11-G 10WH M11-G 14WH / RIGHT HEAD LIGHT HI/LOW BEAMS (8004A) / PLATFORM/ FORWARD CHASSIS (1700) CH7_56,60,60A / PLATFORM/ FORWARD CHASSIS (1700) CH7_56 / *M58AA 14BN / Figure 328 / HEAD LIGHTS WITH PEDESTAL MOUNT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

7.69. HEAD LIGHTS WITHOUT PEDESTAL MOUNT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 58
Figure 329 HEAD LIGHTS WITHOUT PEDESTAL MOUNT WITHOUT 2017 ISB / 2021 B6.7 DIESEL

Components: CHASSIS (8003A); HI/LOW BEAMS (8004A); PLATFORM (1700); TURN SIGNAL (8000); TURN SIGNAL (8001)
Wires (circuit gauge+color): M11-GB 12WH; M11-GD 12WH; M56A 14OR; M57A 14OR; M58AA 14BN; U11-GA 14WH; U11-GB 12WH; U11-GD 14WH; U56A 14OR; U57A 14OR; U58B 14BN; U58C 16BN; U58D 16BN
See also sheets: CH3_50, CH7_43, CH7_56
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.69. HEAD LIGHTS WITHOUT PEDESTAL MOUNT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 58 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 25DEC20 / MJV0488 19NOV21 ADDED CIRC M58AA B 96289K IN R/D 1700.R/D 8004A WAS 8004. / HOOD/FORWARD CHASSIS (8003A) / U52A 14YL U53A 14YL / U58B 14BN U11-GB 12WH / PEANUT LIGHT LEFT HEADLIGHT HEADLIGHT TURN SIGNAL (8001) A C / RADIATOR GROUND (LOCATED AT ENGINE COMPARTMENT FRONT) (9737) CH3_50 / RIGHT HEADLIGHT TURN SIGNAL (8000) A / M52B 12YL / U52B 14YL U53B 14YL / D E / FRONT MARKER AND TURN LIGHT / U57A 14OR U58D 16BN U11-GA 14WH / M11-GB 12WH / D E / U56A 14OR U58C 16BN U11-GD 14WH / RIGHT HEADLIGHT HI/LOW BEAMS (8004A) B / M56A 14OR #M58AA 14BN / M52A 12YL M53A 12YL / # N/CRS * W/LED CLOCK W/PARK LT / M11-GD 12WH / M57A 14OR / FRONT MARKER AND TURN LIGHT / PEANUT LIGHT / M53B 12YL / FORWARD CHASSIS PLATFORM (1700) CH7_56 FORWARD CHASSIS PLATFORM (1700) CH7_56,60,60A / FORWARD CHASSIS/ PLATFORM (1700) CH7_43,44,45,45A ,45C,45D / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / *M58AA 14BN / Figure 329 / HEAD LIGHTS WITHOUT PEDESTAL MOUNT WITHOUT 2017 ISB / 2021 B6.7 DIESEL ENGINE

7.70. HEAD LIGHTS WITH 2018 PROPANE / GAS ENGINE, P. 59
Figure 330 HEAD LIGHTS WITH 2018 PROPANE / GAS ENGINE

Components: BODY CONTROLLER (1603); BODY CONTROLLER (1604); CHASSIS/PLATFORM (1700/1700); CONTROLLER (1604); HARNESS (8003/8003A); HI/LOW BEAMS (8004/8004A); PLATFORM (1700/1700); SPLICE (6740); TURN SIGNAL (8000); TURN SIGNAL (8001)
Wires (circuit gauge+color): A56A 14OR; A56D 14OR; A57A 14OR; A57D 14OR; A58 14BN; A58A 14BN; A58C 14BN; M11-G 10WH; M11-GA 10WH; M11-GB 12WH; M11-GC 12WH; M11-GE 4WH; M56A 14OR; M57A 14OR; M58AA 14BN; U11-GA 14WH; U11-GB 12WH; U11-GD 14WH; U56A 14OR; U57A 14OR; U58B 14BN; U58C 16BN; U58D 16BN
See also sheets: CH3_51
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.70. HEAD LIGHTS WITH 2018 PROPANE / GAS ENGINE, P. 59 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 25DEC20 / MJV0488 19NOV21 REMOVED CIRC A58A/14ORB FROM R/D 1700. / M11-GB 12WH M11-GC 12WH / M11-G 10WH / A56D 14OR A58 14BN A58C 14BN M11-GE 4WH / HOOD FWD CHASSIS/ HARNESS PLATFORM (8003/8003A) (1700/1700) C 7 / M57A 14OR M53B 12YL / M56A 14OR M58AA 14BN / A57A 14OR %A53B 14YL @A125D 14YL / RIGHT TURN A LIGHT B LEFT TURN LIGHT / A56A 14OR A58A 14BN / J2-10 WAY BODY CONTROLLER (1604) B HEADLAMP LOW BEAM LEFT C HEADLAMP HIGH BEAM LEFT / G PARK LIGHTS F MARKER LIGHTS / M52B 12YL / A52B 14YL / R HEADLIGHT HI/LOW BEAMS (8004/8004A) B / M53A 12YL / M52A 12YL / HEADLAMP LOW H BEAM RIGHT / J2-10 WAY BODY CONTROLLER (1604) HEADLAMP HIGH K BEAM RIGHT / A52A 14YL @A125C 14YL %A53A 14YL / HEADLIGHT L HEADLIGHT TURN SIGNAL (8001) A C / R HEADLIGHT TURN SIGNAL HEADLIGHT (8000) A / U57A 14OR U58D 16BN U11-GA 14WH / U56A 14OR U58C 16BN U11-GD 14WH / PEANUT LT / D E / U52A 14YL U53A 14YL / U58B 14BN U11-GB 12WH / FR MARKER AND TURN LT / FR MARKER AND TURN LT / U52B 14YL U53B 14YL / D E / PEANUT LT / J1-12 WAY BODY CONTROLLER (1603) / CHASSIS/PLATFORM (1700/1700) / UPPER DASH GROUND (2GA) GROUND SPLICE (6740) CH3_51 / M11-GA 10WH / @ W/BUS SCAN/CHILD CHECKMATE % W/POST TRIP INSPECTION NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK. / A57D 14OR / Figure 330 / HEAD LIGHTS WITH 2018 PROPANE / GAS ENGINE

7.71. HEAD LIGHTS WITH CHILD REMINDER SYSTEM, P. 60
Figure 331 HEAD LIGHTS WITH CHILD REMINDER SYSTEM

Components: CHASSIS (1700); CONTROLLER (1603); CONTROLLER (1604); HI/LOW BEAM (8004A); HI/LOW BEAMS (8004A); HOOD (8003A); HORN (8310/8310A); PLATFORM (1703); RELAY (10309-R4); RELAY (10309-R5); RELAY (10309-R6)
Wires (circuit gauge+color): A85 16GY; A85A 16GY; B85 16GY; B85A 16GY; B85AA 14GY; B85AB 14GY; B85B 16GY; B85C 16GY; B85D 14GY; B85E 14GY; B85S 14GY; B85T 14GY; M85A 16GY
See also sheets: CH18_02, CH18_10, CH18_13, CH18_16, CH18_24, CH7_57
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.71. HEAD LIGHTS WITH CHILD REMINDER SYSTEM, P. 60 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 7 HEAD LIGHTS W/CHILD REMINDER SYSTEM / MJV0488 19NOV21 REMOVED R/D 8003B, 8004B. / HEADLAMP LOW H BEAM RIGHT HEADLAMP LOW BEAM LEFT / ELEC PANEL/ PLATFORM (1703) A15 / M53B 12YL M53A 12YL M85A 16GY / %A53F 16YL %A53B 16YL %A85A 16GY / @A125C @A125D *A53A 14YL 14YL *A53B 14YL 14YL PLATFORM/ FWD CHASSIS (1700) 5 / J2-10 WAY BODY CONTROLLER (1604) / FWD CHASSIS/ HOOD (8003A) CH7_57,58 R HEADLIGHT HI/LOW BEAMS (8004A) CH7_57,58 HORN (8310/8310A) CH18_13 / %A53C 14YL / %A53A 16YL / B53A 16YL B53C 16YL B53F 16YL B53B 16YL B85C 16GY / PTI RELAY (10309-R5) CH18_02 / *A85 16GY E / J1-12 WAY BODY CONTROLLER (1603) / %A85 16GY / B85B 16GY / A53A 16YL / A53F 16YL / B85 16GY / B85A 16GY / PTI RELAY (10309-R5) CH18_10,16, 20,24,29 / PLATFORM/FWD CHASSIS (1700) 4 / M53B 12YL / FWD CHASSIS/ HOOD (8003A) CH7_57,58 / J1-12 WAY BODY CONTROLLER (1603) / ELEC PANEL/ PLATFORM &B53AD (1703) 16YL B1 ^/#B53E 16YL / A53B 16YL / M53A 12YL / A53C 14YL / J2-10 WAY BODY CONTROLLER (1604) / M85A 16GY / PTI RELAY (10309-R4) CH18_10,16, 20,24,29 / PTI RELAY (10309-R6) CH18_10,16, 20,24,29 / PTI RELAY (10309-R6) CH18_10,16, 20,24,29 / R HEADLIGHT HI/LOW BEAM (8004A) CH7_57,58 / HORN (8310/8310A) CH18_13 / HEADLAMP HEADLAMP LOW LOW BEAM BEAM LEFT LEFT / HEADLAMP LOW BEAM RIGHT / CITY HORN / CITY HORN / Figure 331 / HEAD LIGHTS WITH CHILD REMINDER SYSTEM

7.72. HEAD LIGHTS WITH CHILD REMINDER SYSTEM (CONT.), P. 60A
Figure 332 HEAD LIGHTS WITH CHILD REMINDER SYSTEM (CONT.)

Components: CHASSIS (1700); CONTROLLER (1603); CONTROLLER (1604); HI/LOW BEAM (8004A); HI/LOW BEAMS (8004A); HOOD (8003A); HORN (8310/8310A); PLATFORM (1703); RELAY (10309)
Wires (circuit gauge+color): A85 16GY; A85A 16GY; B85 16GY; B85A 16GY; B85AA 14GY; B85AB 14GY; B85B 16GY; B85C 16GY; B85D 14GY; B85E 14GY; B85S 14GY; B85T 14GY; M85A 16GY
See also sheets: CH18_44, CH7_57
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.72. HEAD LIGHTS WITH CHILD REMINDER SYSTEM (CONT.), P. 60A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 13MAR21 / CHAPTER 7 HEAD LIGHTS W/CHILD REMINDER SYSTEM / MJV0488 19NOV21 REMOVED R/D 8003B, 8004B. / HEADLAMP LOW H BEAM RIGHT HEADLAMP LOW BEAM LEFT / ELEC PANEL/ PLATFORM (1703) A15 / M53B 12YL M53A 12YL M85A 16GY / %A53F 16YL %A53B 16YL %A85A 16GY / @A125C @A125D *A53A 14YL 14YL 14YL *A53B 14YL PLATFORM/ FWD CHASSIS (1700) 5 / J2-10 WAY BODY CONTROLLER (1604) / FWD CHASSIS/ HOOD (8003A) CH7_57,58 R HEADLIGHT HI/LOW BEAMS (8004A) CH7_57,58 HORN (8310/8310A) CH18_13A / %A53C 14YL / %A53A 16YL / B53A 16YL B53C 16YL B53F 16YL B53B 16YL B85C 16GY / PTI RELAY (10309) CH18_4A / *A85 16GY E / J1-12 WAY BODY CONTROLLER (1603) / %A85 16GY / B85B 16GY / A53A 16YL / A53F 16YL / B85 16GY / B85A 16GY / PTI RELAY (10309) CH18_41B, 42A,43, 44,45B / PLATFORM/FWD CHASSIS (1700) 4 / M53B 12YL / FWD CHASSIS/ HOOD (8003A) CH7_57,58 / J1-12 WAY BODY CONTROLLER (1603) / ELEC PANEL/ PLATFORM &B53AD (1703) 16YL B1 ^/#B53E 16YL / A53B 16YL / M53A 12YL / A53C 14YL / J2-10 WAY BODY CONTROLLER (1604) / M85A 16GY / PTI RELAY (10309) CH18_41B, 42A,43, 44,45B / PTI RELAY (10309) CH18_41B, 42A,43, 44,45B / PTI RELAY (10309) CH18_41B, 42A,43, 44,45B / R HEADLIGHT HI/LOW BEAM (8004A) CH7_57,58 / HORN (8310/8310A) CH18_13A / CITY HORN / CITY HORN / HEADLAMP LOW BEAM LEFT / Figure 332 / HEAD LIGHTS WITH CHILD REMINDER SYSTEM (CONT.)

7.73. FOG LIGHTS, P. 61
Figure 333 FOG LIGHTS

Components: BODY CONTROLLER (1601); FUSE A6-P (1014); FWD CHASSIS (1700/1700); GROUND (6740); RELAY (1012-R1)
Wires (circuit gauge+color): M64-G 14WH; M64A-G 14WH; M64B-G 14WH
See also sheets: CH3_01, CH3_50, CH3_51
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.73. FOG LIGHTS, P. 61 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 25DEC20 / CHAPTER 7 / FOG LIGHTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J4-RED BODY CONTROLLER (1601) / FOG LT RELAY (1012-R1) / A64C 18YL / A64B 16YL A64A 16YL / *M64-G 14WH / L FOG LT @(4302/4302A) / M64A-G M64A 14YL 14WH / M64B-G 14WH M64B 14YL / UPPER DASH CHASSIS B/2 GROUND GROUND (2GA) (6740) CH3_50 CH3_51 / PLATFORM/ FWD CHASSIS (1700/1700) / 14YL M64 / 12YL A64 / FOG LIGHT E3 RELAY / FUSE A6-P (1014) CH3_01 / L FOG LT (*4302) / M64A-G M64A 14YL 14WH / M64B-G 14WH M64B 14YL / M64-G 14WH / Figure 333 / FOG LIGHTS

7.74. FOG LIGHTS WITH 2018 PROPANE / GAS ENGINE, P. 61A
Figure 334 FOG LIGHTS WITH 2018 PROPANE / GAS ENGINE

Components: BODY CONTROLLER (1601); FUSE F33 (1011); FWD CHASSIS (1700/1700); GROUND (6740); RELAY (1017)
Wires (circuit gauge+color): M64-G 14WH; M64A-G 14WH; M64B-G 14WH
See also sheets: CH3_50, CH3_51, CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.74. FOG LIGHTS WITH 2018 PROPANE / GAS ENGINE, P. 61A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 14MAR21 / CHAPTER 7 FOG LIGHTS W/DIESEL & W/F-2018-PROPANE/ GASOLINE-ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J4-RED BODY CONTROLLER (1601) / FOG LT RELAY (1017) / A64C 18YL / A64B 16YL A64A 16YL / *M64-G 14WH / R FOG R FOG LT LT @(4303/4303A) (*4303) * W/F-2018-PRO/GAS-ENG @ W/DIESEL ENGINE / L FOG LT @(4302/4302A) / M64A-G M64A 14YL 14WH / M64B-G 14WH M64B 14YL / UPPER DASH CHASSIS B/2 GROUND GROUND (2GA) (6740) CH3_50 CH3_51 / PLATFORM/ FWD CHASSIS (1700/1700) / 14YL M64 / 12YL A64 / 85 2 / 3 30 / 1 86 / 87A 4 / FOG LIGHT E3 RELAY / FUSE F33 (1011) CH3_94 / L FOG LT (*4302) / M64A-G M64A 14YL 14WH / M64B-G 14WH M64B 14YL / M64-G 14WH / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 334 / FOG LIGHTS WITH 2018 PROPANE / GAS ENGINE

7.75. PEDESTRIAN LIGHTS WITH TIMER, P. 62
Figure 335 PEDESTRIAN LIGHTS WITH TIMER

Components: DOOR OPTION (10389); EXTEND (10358A); FRONT CAP (10000); FUSE B9-K (10302); LIGHT RELAY (10282); SPLICE (10010); SPLICE (10336)
Wires (circuit gauge+color): B119T 16GY; B120AL 16LTGN; B139-G 16WH; C139-GB 14WH; C139-GB 16WH
See also sheets: CH3_15, CH3_40, CH3_44, CH8_22, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.75. PEDESTRIAN LIGHTS WITH TIMER, P. 62 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 25DEC20 / CHAPTER 7 / PEDESTRIAN LIGHTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PEDESTRIAN LIGHT RELAY (10282) / B139 16YL / ELEC PANEL/ FRONT CAP (10000) *C139B 16YL D5 #C139B 14YL #C139-GB 14WH *C139-GB 16WH / B139-G 16WH / GROUND SPLICE (10336) CH3_40 / PEDESTRIAN LIGHT (#10046/*10046A) 1/A / GROUND SPLICE (10010) CH3_44 / FUSE B9-K (10302) CH3_15 / B139B 16YL / @B119T 16GY / %B120AL 16LTGN / STOP ARM EXTEND (10358A) CH9_03 DOOR OPTION (10389) CH8_22 / PED LIGHT W/TIMER / @ W/STOP ARM % N/STOP ARM * W/LED RIGHT SIDE PED LIGHT # W/RIGHT SIDE PED LIGHT / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 335 / PEDESTRIAN LIGHTS WITH TIMER

7.76. PEDESTRIAN LIGHTS WITH SWITCH OR TIMER, P. 62A
Figure 336 PEDESTRIAN LIGHTS WITH SWITCH OR TIMER

Components: DOOR OPTION (10389); EXTEND (10358A); FRONT CAP (10000); FUSE F53 (10305); GROUND SPLICE (10336); LIGHT (10046/*10046A); LIGHT RELAY (10282); PEDESTRIAN LIGHT SWITCH (10344); RELAY (10310); SPLICE (10010); SPLICE (10399)
Wires (circuit gauge+color): B119T 16GY; B120AL 16LTGN; B139-G 16WH; B62-GBM 18WH; B62BM 18DKBL; C139-GB 14WH
See also sheets: CH3_32, CH3_44, CH7_63, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.76. PEDESTRIAN LIGHTS WITH SWITCH OR TIMER, P. 62A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. PED LIGHT W/TIMER / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 14MAR21 / CHAPTER 7 / PEDESTRIAN LIGHTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PEDESTRIAN LIGHT SWITCH (10344) 8 / PEDESTRIAN LIGHT RELAY (10282) / B139 16YL / PEDESTRIAN LIGHT (10046/*10046A) 1/A C139B 14YL C139-GB 14WH C139-GB 14WH / B62-GBM 18WH / B62BM 18DKBL / SWITCH ILLUMINATION SPLICE (10399) CH7_63 / B139-G 16WH / GROUND SPLICE (10336) CH3_95J / GROUND SPLICE (10010) CH3_32 / FUSE F53 (10305) CH3_94M / B139B 16YL / ELEC PANEL/ FRONT CAP (10000) D5 / @B119T 16GY / %B120AL 16LTGN / STOP ARM EXTEND (10358A) CH9_03 DOOR OPTION (10389) CH8_23A / B139 16YL B139A 16YL / PEDESTRIAN LIGHT (10046/*10046A) 1/A C139B 14YL C139-GB 14WH C139-GB 14WH / B139B 16YL GROUND SPLICE (10010) CH3_44 / ELEC PANEL/ FRONT CAP (10000) D5 / C2 86 / D1 30 / 85 C1 / 87A D2 / B139-G 16WH / GROUND SPLICE (10336) CH3_95J / @B119T 16GY / %B120AL 16LTGN / PED LIGHT RELAY (10310) / FUSE F53 (10305) CH3_94M / PED LIGHT W/SWITCH / Figure 336 / PEDESTRIAN LIGHTS WITH SWITCH OR TIMER

7.77. DUAL PEDESTRIAN LIGHTS WITH TIMER, P. 62B
Figure 337 DUAL PEDESTRIAN LIGHTS WITH TIMER

Components: EXTEND (10358A); FRONT CAP (10000); FUSE F53 (10305); LIGHT (10205); LIGHT RELAY (10282); SPLICE (10010); SPLICE (10336)
Wires (circuit gauge+color): B119T 16GY; B139-G 16WH; B139-GA 16WH; C139-GB 14WH; C139-GB 16WH
See also sheets: CH3_44, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.77. DUAL PEDESTRIAN LIGHTS WITH TIMER, P. 62B / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 96289K 24SEP21 / CHAPTER 7 DUAL PEDESTRIAN LIGHTS W/TIMER / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / PEDESTRIAN LIGHT RELAY (10282) / B139 16YL / ELEC PANEL/ FRONT CAP (10000) *C139B 16YL D5 #C139B 14YL #C139-GB 14WH / B139-G 16WH / GROUND SPLICE (10336) CH3_95K / PEDESTRIAN LIGHT (#10046/*10046A) 1/A / GROUND SPLICE (10010) CH3_44 / FUSE F53 (10305) CH3_94M / B139B 16YL / B119T 16GY / B139C 16YL / STOP ARM EXTEND (10358A) CH9_03 LED PED LIGHT (10205) A / W/DUAL PED LIGHT W/TIMER / *C139-GB 16WH / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / B139-GA 16WH / Figure 337 / DUAL PEDESTRIAN LIGHTS WITH TIMER

7.78. SWITCH ILLUMINATION SPLICE, P. 63
Figure 338 SWITCH ILLUMINATION SPLICE

Components: AMBER CANCEL (11760); ENABLE (10283); ENTRANCE DOOR SWITCH (10203/10203A); ILLUMINATION SPLICE (10399); OVERHEAD LIGHT (11645); PEDESTRIAN LIGHT SWITCH (10344)
Wires (circuit gauge+color): B62 18DKBL; B62-G 18WH; B62-GA 18WH; B62-GBH 18WH; B62-GBL 18WH; B62-GBM 18WH; B62-GBR 18WH; B62A 18DKBL; B62BH 18DKBL; B62BL 18DKBL; B62BM 18DKBL; B62BR 18DKBL
See also sheets: CH13_55, CH13_65, CH16_04, CH16_22, CH8_12, CH8_28
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.78. SWITCH ILLUMINATION SPLICE, P. 63 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 25DEC20 / CHAPTER 7 / SWITCH ILLUMINATION SPLICE / MJV0488 19NOV21 ADDED CHAPTER CH13_65. / ALTERNATE ENTRANCE DOOR SWITCH (10203/10203A) CH16_22,23,31 / B62 18DKBL / B62-GBL 18WH B62-GBH 18WH #B62-GBM 18WH / B62BL 18DKBL / B62BH 18DKBL / SWITCH ILLUMINATION SPLICE (10399) / B62-GA 18WH / B62A 18DKBL / RED DRIVERS OVERHEAD LIGHT (11645) CH8_12 / B62BR 18DKBL / B62-GBR 18WH / B62-G 18WH / AMBER CANCEL (11760) CH16_04,4A,05 / B62-GA 18WH / B62A 18DKBL / #B62BM 18DKBL / # W/CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / LDW DISABLE/ ENABLE (10283) CH13_55,55A,65 / AMBER CANCEL (11760) CH16_04,4A,05 / Figure 338 / SWITCH ILLUMINATION SPLICE

7.79. LUGGAGE COMPARTMENT LIGHT WITH PANEL MOUNTED SWITCH, P. 64
Figure 339 LUGGAGE COMPARTMENT LIGHT WITH PANEL MOUNTED SWITCH

Components: FUSE B12-E (10301); FUSE F34 (10303); LUGGAGE BOX LIGHT (10268); LUGGAGE BOX LIGHT (11511); SEALED ENGINE (11500); SPLICE (10328); SPLICE (11507)
Wires (circuit gauge+color): B135 16OR; B135A 16OR; B62-GX 18WH; B62X 18DKBL; Y135 16OR; Y135-G 16WH
See also sheets: CH3_07, CH3_48, CH8_28
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.79. LUGGAGE COMPARTMENT LIGHT WITH PANEL MOUNTED SWITCH, P. 64 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 25DEC20 / CHAPTER 7 LUGGAGE COMPARTMENT LIGHT W/PANEL MOUNTED SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / LUGGAGE BOX LIGHT (10268) 8 / B135 16OR / LUGGAGE BOX LIGHT (11511) 1 / B62-GX 18WH / B62X 18DKBL / GROUND SPLICE (11507) CH3_48 / ELEC PANEL/ SEALED ENGINE (11500) B5 / SWITCH ILLUMINATION SPLICE (10328) CH8_28 / !B135A 16OR / Y135 16OR Y135-G 16WH / FUSE F34 (10303) CH3_94H FUSE B12-E (10301) CH3_07 / #B135A 16OR / # W/CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK ! W/CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 339 / LUGGAGE COMPARTMENT LIGHT WITH PANEL MOUNTED SWITCH

7.80. LOWER PANEL MOUNTED HAZARD SWITCH WITH STEERING COLUMN SWITCH, P. 65
Figure 340 LOWER PANEL MOUNTED HAZARD SWITCH WITH STEERING COLUMN SWITCH

Components: BODY CONTROLLER (1600); DIODE B3-A (10304); DIODE B3-N (10304); DIODE D70 (10306); ELEC PANEL/PLATFORM (1703); FUSE B9-X (10302); FUSE F27 (10303-H1); FUSE F55 (10305); HAZARD LIGHT SWITCH (10256); HAZARD LIGHT SWITCH (10256B); ILLUMINATION (10366); RELAY (1022); ZVR SPLICE (10350A)
Wires (circuit gauge+color): A56A 18OR; A57A 18OR; B57A 18OR; B60 18OR; B60A 18OR; B60BA 18OR; B60BB 18OR; B60BC 18OR; B60BD 18OR; B60BE 18OR; B60BF 18OR; B60BH 18OR; B62-GBK 18WH; B62BK 18DKBL
See also sheets: CH13_08, CH3_13, CH3_60, CH8_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.80. LOWER PANEL MOUNTED HAZARD SWITCH WITH STEERING COLUMN SWITCH, P. 65 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 25DEC20 / CHAPTER 7 LOWER PANEL MOUNTED HAZARD SWITCH W/ STEERING COLUMN SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / HAZARD LIGHT SWITCH (10256) 8 / B62-GBK 18WH / B62BK 18DKBL / B60A B60A 18OR 18OR / PRIMARY SWITCH ILLUMINATION (10366) CH8_24 / !B60 18OR / ELEC PANEL/PLATFORM (1703) B4 / B57A 18OR / AUX HAZARD RELAY (1022) CH13_8C / FUSE F27 (10303-H1) CH3_94G FUSE B9-X (10302) CH3_13 / W/0508095 W/ENHANCED VCM FUCTION HAZARD LIGHT SWITCH (10256B) 8 / !B60BD 18OR / ELEC PANEL/PLATFORM (1703) B4 !A57A 18OR / PRIMARY SWITCH ILLUMINATION (10366) CH8_24 / J3-RED BODY CONTROLLER (1600) CH13_08 / W/0508051 W/MUX FOR BC PROGRRAM ONLY / #B60 18OR / #B60BD 18OR / #B60BB 18OR / #B60BE 18OR / #A57A 18OR / J3-RED BODY CONTROLLER (1600) CH13_8D / #B60BF 18OR / Figure 340 / LOWER PANEL MOUNTED HAZARD SWITCH WITH STEERING COLUMN SWITCH

7.81. CLEARANCE LIGHT CONNECTION, P. 66
Figure 341 CLEARANCE LIGHT CONNECTION

Components: AED RELAY (10310-R3); AED RELAY (10312-R3); CLUSTER LIGHT (10021); DIMMER (10372); ELEC PANEL/FR CAP (10000); ELEC PANEL/L BOBY (10400A/B); ELEC PANEL/SEALED ENGINE (11500); FUSE B6-C (10303); L BODY/REAR CAP (10406); LEFT BODY (10400A/B); LIGHT SPLICE (10420); OPTION (10380); RELAY (10308-R1); SED LIGHT (10456); SPLICE (10335A); STEP LIGHT RELAY (10309-R3); SWITCH POWER (11503)
Wires (circuit gauge+color): B131A 16DKBL; B131C 18DKBL; B134A 16OR; B134B 16OR; B143 18DKBL; B58 16BN; B58-GF 18WH; B58A 16BN; B58B 16BN; B58C 18BN; B58D 16BN; B58F 18BN; B58J 16BN; B62AN 18DKBL; B68 16BN; C58A 18BN; C58C 18BN; E143V 18DKBL; E58A 16BN; E58B 16BN
See also sheets: CH14_19, CH16_23, CH3_14, CH3_35, CH7_09, CH7_18, CH7_20, CH7_46, CH7_55, CH8_03, CH8_05, CH8_23, CH8_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.81. CLEARANCE LIGHT CONNECTION, P. 66 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 25DEC20 / CHAPTER 7 CLEARANCE LIGHT CONNECTION / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B58A 16BN / B58D 16BN / B58-GF 18WH / GROUND SPLICE (10335A) CH3_35 / B58 16BN / B58F 18BN / B68 16BN / ELEC PANEL/ LEFT BODY (10400A/B) CH7_20,21,22, 23,24,25,26, 27,28,29,30,31, 32,33,34 / CLEARANCE LIGHT OPTION (10380) / CLEARANCE LIGHT RELAY (10308-R1) / ELEC PANEL/L BOBY (10400A/B) C10 / ELEC PANEL/FR CAP (10000) A1 / ELEC PANEL/SEALED ENGINE (11500) B1 / B143 18DKBL / B58B 16BN / B58C 18BN / E143V 18DKBL E58B 16BN / B131A 16DKBL / STEP LIGHT RELAY (10309-R3) CH8_23 / B58J 16BN / B121 B121 18YL 18YL / ENGINE COMP SWITCH POWER (11503) CH8_03 ELECTRONIC PANEL DIMMER (10372) CH8_24 AED RELAY (10312-R3) CH7_09 / B62AN 18DKBL B134B 16OR / B134A 16OR / B131C 18DKBL / AED RELAY (10310-R3) CH16_23 / C58A 18BN / Y121 16YL / CLUSTER LIGHT (10021) CH8_05 / C58C 18BN / E58A 16BN / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 341 / CLEARANCE LIGHT CONNECTION

7.82. CLEARANCE LIGHT CONNECTION (CONT.), P. 66A
Figure 342 CLEARANCE LIGHT CONNECTION (CONT.)

Components: AED RELAY (10310); CLUSTER LT (10021); DIMMER (10372); ELEC PANEL/FR CAP (10000); ELEC PANEL/L BOBY (10400A/B); ELEC PANEL/SEALED ENG (11500); FUSE F30 (10303); L BODY (10400A/B); L BODY/REAR CAP (10406); OPTION (10380); RELAY (10308); SED LT (10456); SPLICE (10335A); STEP LT RELAY (10309); SWITCH POWER (11503)
Wires (circuit gauge+color): B131A 16DKBL; B131C 18DKBL; B134A 16OR; B134B 16OR; B143 18DKBL; B58 16BN; B58-GF 18WH; B58A 16BN; B58B 16BN; B58C 18BN; B58D 16BN; B58F 18BN; B58J 16BN; B62AN 18DKBL; B68 16BN; E143V 18DKBL; E58B 16BN; YC58A 18BN; YC58C 18BN
See also sheets: CH16_31, CH7_18, CH7_20, CH7_46, CH8_03, CH8_05, CH8_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.82. CLEARANCE LIGHT CONNECTION (CONT.), P. 66A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 15MAR21 / CHAPTER 7 CLEARANCE LIGHT CONNECTION / MJV0488 19NOV21 ADDED CHAPTER CH7_34A,34B. / 85 A1 / B1 86 / A2 30 / B58C 18BN B58A 16BN / B58D 16BN / B58-GF 18WH / GROUND SPLICE (10335A) CH3_95G / SED LT (10456) CH14_19A L BODY/REAR CAP (10406) CH7_18 ELEC PANEL/FR CAP (10000) CH7_46 FUSE F30 (10303) CH3_94H / B2 B58F 18BN / B68 16BN / ELEC PANEL/ L BODY (10400A/B) CH7_20,21,22, 23,24,25,26, 27,28,29,30,31, 32,33,34,34A,34B STEP LT RELAY (10309) CH8_23A / CL LT OPTION (10380) / CLEARANCE LT RELAY (10308) / ELEC PANEL/L BOBY (10400A/B) C10 / ELEC PANEL/FR CAP (10000) A1 / ELEC PANEL/SEALED ENG (11500) B1 / B143 18DKBL / B58B 16BN / B58 16BN / E143V 18DKBL E58B 16BN / B131A 16DKBL / B58J 16BN / B121 B121 18YL 18YL / ENG COMP SWITCH POWER (11503) CH8_03 ELECTRONIC PANEL DIMMER (10372) CH8_24 / B62AN 18DKBL B134B 16OR / B134A 16OR / B131C 18DKBL / AED RELAY (10310) CH7_9A / AED RELAY (10310) CH16_31 / YC58A 18BN / Y121 16YL / CLUSTER LT (10021) CH8_05 / YC58C 18BN / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 342 / CLEARANCE LIGHT CONNECTION (CONT.)

7.83. SED LANDING LIGHT, P. 67
Figure 343 SED LANDING LIGHT

Components: A/C RELAY (10308-R4); BUZZER SPLICE (10204); FUSE B6-T (10303); LEFT BODY (10400); SPLICE (10482)
Wires (circuit gauge+color): B131 16DKBL; B131-GS 16WH; B131A 16DKBL; B131B 16DKBL; E131 16DKBL; E131-G 16WH
See also sheets: CH14_01, CH3_14, CH3_57
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.83. SED LANDING LIGHT, P. 67 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 01MAR21 / SED LANDING LIGHT / CHAPTER 7 / MJV0488 19NOV21 ADDED R/D 10801D. / SED LANDING LIGHT / FUSE B6-T (10303) CH3_14 / B131B 16DKBL B131A 16DKBL / @ W/WINDOW SECT 3 & 4 # W/WINDOW SECT 5 & 6 % W/WINDOW SECT 4 & 5 / A/C RELAY (10308-R4) / B131-GS 16WH / EMER EXIT BUZZER SPLICE (10204) CH14_01 / B131 16DKBL / LEFT BODY/ SED TRANSITION (@10801C/#10801E/ %10801D) A / E131-G 16WH / GROUND SPLICE (10482) CH3_57 / 16DKBL E131 / ELEC PANEL/ LEFT BODY (10400) D6 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 343 / SED LANDING LIGHT

7.84. SED LANDING LIGHT (CONT.), P. 67A
Figure 344 SED LANDING LIGHT (CONT.)

Components: A/C RELAY (10308); BUZZER SPLICE (10204); FUSE F84 (10307); LEFT BODY (10400); LIGHT (11599); SED TRANSITION (10801C); SPLICE PACK (10482)
Wires (circuit gauge+color): B131 16DKBL; B131-GS 16WH; B131A 16DKBL; B131B 16DKBL; E131 16DKBL; E131-G 16WH
See also sheets: CH3_57
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.84. SED LANDING LIGHT (CONT.), P. 67A / SED LANDING LIGHT / CHAPTER 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 15MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 85 A3 / B4 86 / A4 30 / 87A B3 / B131-GS 16WH / EMER EXIT BUZZER SPLICE (10204) CH14_1A / B131B 16DKBL B131A 16DKBL / A/C RELAY (10308) / ELEC PANEL/ LEFT BODY (10400) D6 / B131 16DKBL / 143LT 18DKBL 143LT-G 18WH / FUSE F84 (10307) CH3_94P / SED LANDING LIGHT (11599) / LEFT BODY/ SED TRANSITION (10801C) 1 / E131 16DKBL / SPLICE PACK (10482) CH3_57 / E131-G 16WH / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 344 / SED LANDING LIGHT (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 385 | printed page 345 | section 7.85
7.85. FULL / REAR VIEW CAMERA WITH STANDALONE DISPLAY ON DIESEL & 2018 PROPANE / GAS ENGINE, P. 68
Figure 345 FULL / REAR VIEW CAMERA WITH STANDALONE DISPLAY ON DIESEL & 2018 PROPANE

Components: AND GROUND (14520); CONTROLLER (1601); FUSE F20 (10302); LT RELAY (1011); PLATFORM (1702); PLATFORM (1703); RELAY (10308); SPLICE (10334)
Wires (circuit gauge+color): A137A 18LTBL; A17H 16LTBL; A71BB 16LTBL; B137-GA 16WH; B137-GB 16WH; B137-GC 16WH; B137A 16LTBL; B137B 16LTBL; B137C 18LTBL; B137D 16LTBL; B14U 12BK; B71D 16LTBL; B86-G 16WH
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.85. FULL / REAR VIEW CAMERA WITH STANDALONE DISPLAY ON DIESEL & 2018 PROPANE / GAS ENGINE, P. 68 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 15MAR21 / CHAPTER 7 FULL/REAR VIEW CAMERA W/STANDALONE DISPLAY W/DIESEL & W/F-2018-PROPANE/GASOLINE-ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / BACKUP LT RELAY (10308) 87A D3 / D4 86 / B86-G 16WH C4 30 / J4-BLUE BODY CONTROLLER (1601) OUTPUT 12V E15 LOW CURRENT / B137B 16LTBL / B137D 16LTBL / B137-GB 16WH / B71D 16LTBL / B137A 16LTBL / B137-GA 16WH / B137-GC 16WH / GROUND SPLICE (10334) CH3_95F / ELEC PANEL/ PLATFORM (1703) A3 / A17H 16LTBL / B137C 18LTBL / ELEC PANEL/ PLATFORM (1702) 70 / A137A 18LTBL / A71BB 16LTBL / BACK UP LT RELAY (1011) CH7_2A / FUSE F20 (10302) F3 E3 15A / B14U 12BK / POWER STUD (OPWR) / TO SPLITTER PWR AND GROUND (14520) / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 345 / FULL / REAR VIEW CAMERA WITH STANDALONE DISPLAY ON DIESEL & 2018 PROPANE / GAS ENGINE

7.86. FULL / REAR VIEW CAMERA WITH MIRROR DISPLAY ON DIESEL & 2018 PROPANE / GAS ENGINE, P. 69
Figure 346 FULL / REAR VIEW CAMERA WITH MIRROR DISPLAY ON DIESEL & 2018 PROPANE /

Components: AND GROUND (14520); CONTROLLER (1601); FUSE F20 (10302); PLATFORM (1702); PWR 7 GROUND (14521); RELAY (1011); RELAY (10308); SPLICE (10334-K)
Wires (circuit gauge+color): A137A 18LTBL; A17H 16LTBL; A71BB 16LTBL; B137-GA 18WH; B137-GB 16WH; B137-GC 16WH; B137-GK 16WH; B137A 16LTBL; B137B 16LTBL; B137C 18LTBL; B137D 16LTBL; B137K 16LTBL; B14U 12BK; B71D 16LTBL; B86-G 16WH
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.86. FULL / REAR VIEW CAMERA WITH MIRROR DISPLAY ON DIESEL & 2018 PROPANE / GAS ENGINE, P. 69 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090658 NO. 95885P 15MAR21 / CHAPTER 7 FULL/REAR VIEW CAMERA W/MIRROR DISPLAY W/DIESEL & W/F-2018-PROPANE/GASOLINE-ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / BACKUP LT RELAY (10308) 87A D3 / D4 86 / C4 30 / J4-BLUE BODY CONTROLLER (1601) OUTPUT 12V E15 LOW CURRENT / TO SPLITTER PWR AND GROUND (14520) / B86-G 16WH / B137B 16LTBL / B137D 16LTBL / B137-GB 16WH / B71D 16LTBL / B137A 16LTBL / B137-GA 18WH / B137-GC 16WH / GROUND SPLICE (10334-K) CH3_95F / ELEC PANEL/ PLATFORM (1702) A3 / A17H 16LTBL / B137C 18LTBL / ELEC PANEL/ PLATFORM (1702) 70 / A137A 18LTBL / A71BB 16LTBL / POWER STUD (OPWR) BACK UP LT RELAY (1011) CH7_2A / FUSE F20 (10302) F3 E3 15A / B14U 12BK / TO DIST UNIT PWR 7 GROUND (14521) / B137-GK 16WH / B137K 16LTBL / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 346 / FULL / REAR VIEW CAMERA WITH MIRROR DISPLAY ON DIESEL & 2018 PROPANE / GAS ENGINE

7.87. BRAKE MONITORING EFFECTS, P. 70
Figure 347 BRAKE MONITORING EFFECTS

Components: BODY CONTROLLER (1604); CONTROLLER (1601); FUSE F5-B (1011); PLATFORM (1703); PWR INPUT (1404); RELAY (1011-R3); VALVE RELAY (1018)
Wires (circuit gauge+color): A39D 16GY; A59C 18GY; A70 18OR; A70A 18OR; A70BB 14OR; A70BC 16OR; A70BD 14RD; B70 16RD; B70A 16RD
See also sheets: CH3_94, CH7_20
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 7.87. BRAKE MONITORING EFFECTS, P. 70 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090658 95885P 15MAR21 / CHAPTER 7 / BRAKE MONITORING EFFECTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 85 B / A A 86 / 87A D / A70BB 14OR A70 A70 18OR 18OR / @A70BC 16OR / *A70BC %A70BC 16OR 16OR / STOP LT RELAY (1011-R3) / FUSE F5-B (1011) CH3_94 / *A70BD 14RD / *A59C 18GY / 16RD B70 / B70A 16RD / PWR INPUT (1404) CH13_21A / J2-10 WAY BODY CONTROLLER (1604) TAIL LIGHT D SIGNAL / J4-BLUE BODY CONTROLLER (1601) STOP E5 RELAY / A70A 18OR / ELEC PANEL/ PLATFORM A1 (1703) / A39D 16GY / AUTO DRAIN VALVE RELAY (1018) CH13_2A / Figure 347 / BRAKE MONITORING EFFECTS

Figure 348 GUARD DOME LIGHT

Components: DOME LT GUARD (10492); ELEC PANEL (10401); GUARD DOME LT (10235); LT SECTION 1 (10768); PWR (10201); R BODY (10700); REAR CAP (10405); SPLICE (10333); SPLICE (10482); SPLICE (10701)
Wires (circuit gauge+color): B62-GAL 18WH; B62AL 18DKBL; B63AE 18DKBL; B63AF 18DKBL; D63BE 18DKBL; E63-GAF 18WH; E63BC 18DKBL; E63BD 18DKBL; E63BE 18DKBL; F63-GA 16WH; F63BE 16DKBL
See also sheets: CH3_52, CH3_57, CH8_34, CH8_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / INTERNAL LIGHTS (CHAPTER 8) / 8.1. GUARD DOME LIGHT, P. 1 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 29DEC20 / GUARD DOME LIGHT / CHAPTER 8 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / DOME LT GUARD (10492) A / GUARD DOME B LT SECTION 1 (10768) / DOME LT PWR (10201) CH8_35,36A / F63-GA 16DKBL 16WH F63BE / REAR CAP/ R BODY B4 (10700) / GROUND SPLICE (10701) CH3_52 / E63-GAF 18WH / B63AE 18DKBL / B62-GAL 18WH B62AL 18DKBL / GROUND SPLICE (10482) CH3_57 / L BODY / ELEC PANEL (10401) B1 / GUARD DOME LT (10235) 2 / SW ILLUM SPLICE (10333) CH8_34 / E63BD 18DKBL / B63AF 18DKBL / 18DKBL E63BE / L BODY/ REAR CAP (10405) / 18DKBL D63BE / E63BC 18DKBL / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 348 / GUARD DOME LIGHT

8.2. ACTIVITY DOME LIGHT, P. 2
Figure 349 ACTIVITY DOME LIGHT

Components: ACTIVITY LT (10491@); ELEC PANEL (10401/A/B); LIGHT (10765%); LT SW (10232); PWR (10201); REAR CAP (10405); REAR CAP (10700); SPLICE (10333); SPLICE (10482); SPLICE (10702)
Wires (circuit gauge+color): B62-GAK 18WH; B62AK 18DKBL; B63AC 18DKBL; B63AD 18DKBL; D63AS 18DKBL; E63-GAE 18WH; E63-GW 16WH; E63AS 18DKBL; E63AT 16DKBL; E63AT 18DKBL; E63BA 18DKBL; F63-GX 16WH; F63AS 16DKBL; F63X 16DKBL
See also sheets: CH3_53, CH3_57, CH8_34, CH8_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.2. ACTIVITY DOME LIGHT, P. 2 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 29DEC20 / ACTIVITY DOME LIGHT / CHAPTER 8 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ACTIVITY LT (10491@) A / ACTIVITY DOME LIGHT (10765%) / A A / B B / DOME LT PWR (10201) CH8_35,36A / R BODY/ REAR CAP (10700) / GROUND SPLICE (10702) CH3_53 / E63-GAE 18WH / B63AC 18DKBL E63AT 18DKBL E63BA 18DKBL E63AT 16DKBL / B62-GAK 18WH B62AK 18DKBL / GROUND SPLICE (10482) CH3_57 / W/8 WINDOW L BODY/ ELEC PANEL (10401/A/B) W/7,11 WINDOW A8 B63AD 18DKBL E63BA 18DKBL E63AS 18DKBL SW ILLUM SPLICE (10333) CH8_34 / ACTIVITY DOME LT SW (10232) 2 / 18DKBL D63AS / 16DKBL 16DKBL F63-GX F63AS 16WH F63X / L BODY/ REAR CAP (10405) / E63-GW 16WH / W/12 WINDOW / W/5,6,9,10 WINDOW / W/13 WINDOW / W/13 WINDOW / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 349 / ACTIVITY DOME LIGHT

8.3. ENGINE COMPARTMENT LIGHTS, P. 3
Figure 350 ENGINE COMPARTMENT LIGHTS

Components: LTS (11505); RELAY (10308); SEALED ENGINE (11500); SPLICE (11507); SW OUT (11504); SW PWR (11503)
Wires (circuit gauge+color): B58A 16BN; B58D 16BN; Y121-GA 16WH
See also sheets: CH3_10, CH3_14, CH3_17, CH3_48, CH7_66
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.3. ENGINE COMPARTMENT LIGHTS, P. 3 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 29DEC20 / ENGINE COMPARTMENT LIGHTS / CHAPTER 8 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CL LT OPTION ^(10380) CH7_66 / Y121 16YL / GROUND SPLICE (11507) CH3_48 / ELEC PANEL/ SEALED ENGINE (11500) B1 / %B121 18YL / Y121A 16YL Y121-GA 16WH / ENG COMPARTMENT LTS (11505) 1 / ENG COMPARTMENT A SW OUT (11504) / ENG A COMPARTMENT SW PWR (11503) / B58D 16BN / CL LT RELAY (10308) CH7_66 / *B121 18YL / @B121 18YL / %B121 18YL / B58A 16BN / *B121 18YL / @B121 18YL / %B121 18YL / Figure 350 / ENGINE COMPARTMENT LIGHTS

8.4. ELECTRICAL COMPARTMENT LIGHTS, P. 4
Figure 351 ELECTRICAL COMPARTMENT LIGHTS

Components: FUSE B6-P (10303); FUSE F81 (10307); LT SW (10342); LT SW (10343); SPLICE (10334)
Wires (circuit gauge+color): B136-GA 16WH
See also sheets: CH3_10, CH3_34
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.4. ELECTRICAL COMPARTMENT LIGHTS, P. 4 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 29DEC20 / CHAPTER 8 ELECTRICAL COMPARTMENT LIGHTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELECTRICAL COMPARTMENT LT (10341) 1 / #B136A 16YL / @B136 16YL / #B136-GA 16WH / ENG COMPARTMENT LT SW (10343) / FUSE B6-P (10303) CH3_10 FUSE F81 (10307) CH3_94P / GROUND SPLICE (10334) CH3_34,95F / ENG COMPARTMENT LT SW (10342) / %B136 16YL / Figure 351 / ELECTRICAL COMPARTMENT LIGHTS

8.5. FRONT AMBER CLUSTER LIGHTS, P. 5
Figure 352 FRONT AMBER CLUSTER LIGHTS

Components: CLUSTER LTS (10020); CLUSTER LTS (10021); CLUSTER LTS (10022); FR CAP (10000); RELAY (10308); SPLICE (10010)
Wires (circuit gauge+color): B58A 16BN; B58D 16BN; B58J 16BN; C11-GA 12WH; C58-G 18WH; C58-GB 18WH; C58-GC 18WH; C58-GD 18WH; C58A 18BN; C58B 18BN; C58C 18BN; C58D 18BN
See also sheets: CH3_15, CH3_44, CH7_66
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.5. FRONT AMBER CLUSTER LIGHTS, P. 5 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 29DEC20 / CHAPTER 8 FRONT AMBER CLUSTER LIGHTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CLUSTER LTS (10022) A / CLUSTER LTS (10021) A / CLUSTER LTS (10020) A / *B58J 16BN / ELEC PANEL/ FR CAP (10000) A1 / C58C 18BN C58-GC 18WH / C58B 18BN C58-GB 18WH / C58A 18BN / C58D 18BN C58-GD 18WH / C11-GA 12WH / CL LT OPTION &(10380) CH7_66 A / B58D 16BN / B58A 16BN / CL LT RELAY (10308) CH7_66 / #B58J 16BN / GROUND SPLICE (10010) CH3_44 / C58-G 18WH / FUSE B9-F @(10302) CH3_15 FUSE F50 %(10305) CH3_94L / #B58J 16BN / Figure 352 / FRONT AMBER CLUSTER LIGHTS

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 393 | printed page 353 | section 8.6
8.6. REAR DOOR SPLICE CONNECTIONS, P. 6
Figure 353 REAR DOOR SPLICE CONNECTIONS

Components: ACTIVATION RELAY (10311); BACK UP LT RELAY (10308); BACK UP LT RELAY (10308-R2); BUZZER RELAY (10310-R4); BUZZER SPLICE (10204); DIODE B3-P (10304); DIODE B6-U (10303); DIODE D67 (10306); DIODE D79 (10307); DOME LT RELAY (10311-R1); L BODY (10401A/B/10401); L BODY/REAR CAP (10406); LT RELAY (10311); REAR DOOR SPLICE (10386)
Wires (circuit gauge+color): B117 18GY; B117B 18LTBL; B117D 18GY; B117F 18GY; B117J 18LTGN; B117JZ 16LTGN; B117L 18GY; B117M 18GY; B63-G 18WH; B63-GM 18WH; B63E 16GY; B63G 16WH; E117 18GY
See also sheets: CH14_24, CH16_26, CH7_05, CH8_08, CH8_18
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.6. REAR DOOR SPLICE CONNECTIONS, P. 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 29DEC20 / CHAPTER 8 REAR DOOR SPLICE CONNECTIONS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/ L BODY (10401A/B/10401) A5 @B117F 18GY / REAR DOOR SPLICE (10386) / #B117M 18GY / L BODY/REAR CAP (10406) CH14_24 BACK UP LT RELAY (10308-R2) CH7_05 BACK UP LT RELAY (10308) CH7_5A / #B117B 18LTBL %B117B 18LTBL DIODE B6-U (10303) / #B117J 37 33 18LTGN DIODE D67 (10306) / BUZZER RELAY (10310-R4) CH16_26 / #B117D 18GY #B63E 16GY / #B63-GM 18WH / B117L 18GY / %B117J 18LTGN B3 A3 DIODE B3-P (10304) 30 26 / #B63-G 18WH / E117 18GY / B117JZ 16LTGN / %B117M 18GY / EMER EXIT BUZZER SPLICE (10204) CH14_1A / %B117D 18GY %B63E 16GY / %B117 18GY / DIODE D79 (10307) B3 A3 / %B63-GM 18WH / %B63-G 18WH / %B63G 16WH / Figure 353 / REAR DOOR SPLICE CONNECTIONS

8.7. DOME LIGHT RHEOSTAT, P. 7
Figure 354 DOME LIGHT RHEOSTAT

Components: DOME LT O/P (10202); DOME LT SPLICE (10202); DOME LT SW (10230); DOME LT SW (10231); ELEC PANEL/L BODY (10401); FUSE 25 (10303); FUSE B9-V (10302); GROUND (10215G); OUTPUT 1 (84273); OUTPUT 2 (83174); PWR (10201); R ROW SW (10233); RHEOSTAT DIMMER (10376); RHEOSTAT DIODE (10337); RHEOSTAT DIODE (10377); SPLICE (10328)
Wires (circuit gauge+color): B62-GBP 18WH; B62BP 18DKBL; B63-GRA 12WH; B63A 12DKBL; B63A 16DKBL; B63AA 16DKBL; B63AH 12DKBL; B63AL 12DKBL; B63B 16DKBL; B63RA 12DKBL; B63RB 12DKBL; B63RC 12DKBL; B63RC 16DKBL; B63RD 12DKBL; B63RD 16DKBL; B63RE 12DKBL; B63RE 14DKBL; B63RE 16DKBL; B63RF 12DKBL; B63RH 12DKBL
See also sheets: CH3_13, CH8_08, CH8_09, CH8_10, CH8_13, CH8_14, CH8_28, CH8_35, CH8_36
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.7. DOME LIGHT RHEOSTAT, P. 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 29DEC20 / DOME LIGHT RHEOSTAT / CHAPTER 8 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / RHEOSTAT DIMMER (10376) 1 / SW ILLUM SPLICE (10328) CH8_28 / B62BP 18DKBL B62-GBP 18WH / I-3 PWRON &(10215J) / OUTPUT-1 ^(10216C) / OUTPUT-2 ^(10215D) / OUTPUT-2 ^(10216D) / INPUT-3 ^(10215E) / INPUT-3 ^(10216E) GROUND (10215G) / %B63RA 12DKBL %B63RB 12DKBL B63RH 12DKBL B63RF 12DKBL *B63RC 12DKBL @B63RC 12DKBL @B63RE 14DKBL / #B63RC 16DKBL B63A 16DKBL *B63RD 12DKBL @B63RD 12DKBL / #B63RD 16DKBL B63B 16DKBL *B63RE 12DKBL @B63RE 12DKBL / #B63RE 16DKBL &B63-GRA 12WH !B63-GRA 12WH / &B63AH 12DKBL / GROUND STUD (20) GROUND STUD (1GND) CH3_95E / %B63AL 12DKBL / ^B63A 12DKBL / &B63AA 16DKBL / &B63AH 12DKBL !B63AH 12DKBL / A A / Figure 354 / DOME LIGHT RHEOSTAT

8.8. REAR ROW DOME LIGHTS, P. 8
Figure 355 REAR ROW DOME LIGHTS

Components: DIODE B3-P (10304); DOME LT (10233); DOME LT RH (10216C/D); ELEC PANEL (10401/A/B); FUSE B9-W (10302); LT RELAY (10311-R2); PWR (10201); R BODY (10700); REAR CAP (10405); REAR CAP/L BODY (10405); RELAY (10311-R1); RELAY (10311-R2); RELAY (10313-R3); RH MODULE (10216E); SECTION 11 (10488); SECTION 11 (10762); SPLICE (10333); SPLICE (10386); SPLICE (10701)
Wires (circuit gauge+color): B62-GAH 18WH; B62AH 18DKBL; B63-G 18WH; B63C 16DKBL; B63D 18DKBL; B63E 16GY; B63F 16DKBL; B63RC 16DKBL; B63RD 16DKBL; B63RE 16DKBL; B63RR 16DKBL; B63RW 16DKBL; B63W 16DKBL; B63W 18DKBL; B63WA 16DKBL; B63WB 16DKBL; B63X 18DKBL; B63Z 16DKBL; B63Z 18DKBL; D63A 16DKBL; D63B 16DKBL; D63E 16DKBL; D63M 16DKBL; E124 12LTGN; E63AN 16DKBL; E63AP 18DKBL; E63BB 18DKBL; E63M 18DKBL; F63-G 16WH; F63-GF 16WH; F63M 16DKBL
See also sheets: CH3_08, CH3_52, CH8_06, CH8_07, CH8_09, CH8_16, CH8_18, CH8_34, CH8_35, CH8_40
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.8. REAR ROW DOME LIGHTS, P. 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 29DEC20 / REAR ROW DOME LIGHTS / CHAPTER 8 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / DOME LT SECTION 11 (10762) A / F63M 16DKBL F63-GF 16WH / B62AH 18DKBL B62-GAH 18WH / REAR ROW DOME LT (10233) 2 / **B63WA 16DKBL **B63Z 16DKBL &B63RR 16DKBL / !B63W 16DKBL *B63W 18DKBL **B63RW 16DKBL **B63WB 16DKBL L BODY/ ELEC PANEL (10401/A/B) A7 E63AN 16DKBL %%E63BB 18DKBL ##E63M 18DKBL / DOME LT PWR (10201) CH8_35 RR DOME LT RELAY (10311-R2) CH8_18,19,20 / L BODY/ REAR CAP A7 (10405) / REAR CAP/ R BODY (10700) / GROUND FUSE B9-W SPLICE (10302) (10701) CH3_08 CH3_52 / 16DKBL D63M / #B63X 18DKBL %B63X 18DKBL *B63D 18DKBL #B63Z 18DKBL 16DKBL B63C @B63RC 16DKBL @B63RD 16DKBL / SW ILLUM SPLICE (10333) CH8_34 / F63-G 16WH / E124 12LTGN / REAR CAP/L BODY (10405) A3 / 16DKBL 16DKBL 16DKBL D63E D63A D63B REAR ROW DOME LT RELAY (10311-R1) 86 30 / @B63RE 16DKBL / *B63F 16DKBL / B63-G 18WH / DIODE B3-P (10304) / B63E 16GY / E63AP 18DKBL / DOME LT SECTION 11 (10488) CH8_40 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 355 / REAR ROW DOME LIGHTS

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 396 | printed page 356 | section 8.9
8.9. REAR ROW DOME LIGHTS (CONT.), P. 9
Figure 356 REAR ROW DOME LIGHTS

Components: DIMMER O/P 1 (84273); DIMMER O/P 2 (83174); DOME LT (10230); DOME LT (10233); ELEC PANEL (10401/A/B); FUSE B9-W (10302); L BODY (10405); R BODY (10700); REAR CAP (10405); RELAY (10311-R1); RELAY (10313-R3); RHEOSTAT (10216C); RHEOSTAT (10216D); SECT11 (10762); SPLICE (10701)
Wires (circuit gauge+color): B63 14DKBL; B63A 16DKBL; B63B 16DKBL; B63C 16DKBL; B63D 16DKBL; B63D 16WH; B63E 16DKBL; B63F 16DKBL; B63H 16DKBL; B63H 16WH; B63K 16DKBL; B63L 16DKBL; B63P 16WH; B63R 16DKBL; B63RC 16DKBL; B63RD 16DKBL; B63RR 16DKBL; B63RW 16DKBL; D63M 16DKBL; E124 12LTGN; E63BB 18DKBL; E63M 18DKBL; F63-G 16WH; F63-GF 16WH; F63M 16DKBL
See also sheets: CH3_08, CH3_52, CH8_07, CH8_08, CH8_13
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.9. REAR ROW DOME LIGHTS (CONT.), P. 9 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 29DEC20 / CHAPTER 8 REAR ROW DOME LIGHTS (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 16DKBL B63R 2 MIN TIMER RELAY (10313-R3) 86 30 / 87 85 / IN PWR DIMMER O/P 1 (84273) / %B63A 16DKBL / %B63C 16DKBL / IN PWR DIMMER O/P 2 (83174) / DOME LT SECT11 (10762) A / F63M 16DKBL F63-GF 16WH / L BODY/ ELEC PANEL (10401/A/B) A7 *E63M %B63RC 18DKBL 16DKBL #E63BB 18DKBL / L BODY/ REAR CAP (10405) / REAR CAP/ R BODY (10700) / GROUND FUSE B9-W SPLICE (10302) (10701) CH3_08 CH3_52 / 16DKBL D63M / F63-G 16WH / REAR CAP/ L BODY (10405) A3 E124 12LTGN / %B63B 16DKBL / %B63RD 16DKBL / %B63D 16DKBL / @B63RW 16DKBL %B63E 16DKBL / DOME LT RHEOSTAT (10216D) CH8_07 DOME LT RHEOSTAT (10216C) CH8_07 / %B63H 16DKBL B63H 16WH / 16DKBL %B63F / B63 14DKBL @B63RR 16DKBL / STD/FR DOME LT (10230) CH8_13 REAR ROW DOME LT (10233) CH8_08 REAR ROW DOME LT RELAY (10311-R1) CH8_1T / B63K 16DKBL B63P 16WH / B63D 16WH / 16DKBL B63L / % W/RHEOSTAT W/9 @ W/EMER EXIT W/2 MIN # W/7,8,11,12 WINDOW * W/7,8 WINDOW / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 356 / REAR ROW DOME LIGHTS

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 397 | printed page 357 | section 8.10
8.10. REAR ROW DOME LIGHTS (CONT.), P. 9A
Figure 357 REAR ROW DOME LIGHTS

Components: DIMMER O/P 1 (84273); DIMMER O/P 2 (83174); DOME LT (10233); DOME LT RELAY (10311); ELEC PANEL (10401/A/B); GROUND SPLICE (10701); LT RELAY (10311); PWR (10201); R BODY (10700); REAR CAP (10405); REAR CAP/L BODY (10405); RELAY (10311); RH MODULE (10216E); RHEOSTAT (10216C); SECTION 11 (10488); SECTION 11 (10762); SPLICE (10333)
Wires (circuit gauge+color): B62-GAH 18WH; B62AH 18DKBL; B63A 16DKBL; B63B 16DKBL; B63C 16DKBL; B63D 16DKBL; B63E 16DKBL; B63F 16DKBL; B63RC 16DKBL; B63RD 16DKBL; B63RE 16DKBL; B63W 16DKBL; B63W 18DKBL; B63WA 16DKBL; B63WB 16DKBL; B63X 18DKBL; B63Z 16DKBL; B63Z 18DKBL; D63M 16DKBL; E124 12LTGN; E63AN 16DKBL; E63AP 18DKBL; E63BB 18DKBL; F63-G 16WH; F63-GF 16WH; F63M 16DKBL
See also sheets: CH18_54, CH3_52, CH8_07, CH8_34, CH8_40
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.10. REAR ROW DOME LIGHTS (CONT.), P. 9A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 26FEB21 / CHAPTER 8 REAR ROW DOME LIGHTS (CONT.) / MJV0488 19NOV21 ADDED CIRC B63WA & B63WB IN R/D 10311. / DOME LT SECTION 11 (10762) A / F63M 16DKBL F63-GF 16WH / B62AH 18DKBL B62-GAH 18WH / REAR ROW DOME LT (10233) 2 / B63Z 18DKBL / #B63W 16DKBL *B63W 18DKBL %B63WA 16DKBL %B63WB 16DKBL L BODY/ ELEC PANEL E63AN (10401/A/B) 16DKBL %E63BB 18DKBL / DOME LT PWR (10201) CH8_36A REAR DOME LT RELAY (10311) CH18_54 / L BODY/ REAR CAP (10405) / REAR CAP/ R BODY (10700) / GROUND SPLICE (10701) CH3_52 / 16DKBL D63M / B63X 18DKBL / B63Z 16DKBL B63WA 16DKBL B63WB 16DKBL **B63RE 16DKBL B63RD 16DKBL **B63RC 16DKBL @B63B 16DKBL / F63-G 16WH / ** W/RHEOSTAT @ N/RHEOSTAT W/+9 FRONT WINDOW * DOME LT REAR ROW COMMON # REAR ROW FEED % W/7,8,11,12 WINDOW / DOME LT RHEOSTAT (10216C)CH8_07 (10216D)CH8_07 / E124 12LTGN / REAR CAP/L BODY (10405) A3 / 1 IN PWR DIMMER O/P 2 2 (83174) 2 MIN TIMER RELAY (10311) CH8_9C 1 IN PWR DIMMER O/P 1 (84273) 2 2 MIN TIMER RELAY (10311) CH8_9C / @B63D 16DKBL @B63E 16DKBL @B63A 16DKBL @B63C 16DKBL / @B63RD 16DKBL / @B63F 16DKBL NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / @B63RC 16DKBL / DOME LT SECTION 11 (10488) CH8_40 / E63AP 18DKBL / Figure 357 / REAR ROW DOME LIGHTS

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 398 | printed page 358 | section 8.11
8.11. REAR ROW DOME LIGHTS (CONT.), P. 9B
Figure 358 REAR ROW DOME LIGHTS

Components: DIODE D79 (10307); ELEC PANEL (10401/A/B); FUSE F26 (10303); GROUND SPLICE (10701); LT RELAY (10311); PTI RELAY (10309); PWR (10201); R BODY (10700); REAR CAP (10405); REAR ROW DOME LT (10233); SECTION 11 (10762); SPLICE (10333); SPLICE (10386)
Wires (circuit gauge+color): B117D 18GY; B62-GAH 18WH; B62AH 18DKBL; B63-G 18WH; B63A 16DKBL; B63B 16DKBL; B63C 16DKBL; B63D 16DKBL; B63D 16WH; B63E 16DKBL; B63E 16GY; B63G 16WH; B63H 16WH; B63L 16DKBL; B63RR 14DKBL; B63RR 16DKBL; B63RW 16DKBL; B63W 16DKBL; B63W 18DKBL; B63X 16DKBL; D63M 16DKBL; E63BB 18DKBL; F63-G 16WH; F63-GF 16WH; F63M 16DKBL
See also sheets: CH18_51, CH3_52, CH8_06, CH8_34
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.11. REAR ROW DOME LIGHTS (CONT.), P. 9B / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 26FEB21 / CHAPTER 8 REAR ROW DOME LIGHTS (CONT.) / MJV0488 19NOV21 ADDED CIRC B63X, B63RW & R/D 10309. / DOME LT SECTION 11 (10762) A / F63M 16DKBL F63-GF 16WH / B62AH 18DKBL B62-GAH 18WH B63L 16DKBL / REAR ROW DOME LT (10233) / B63RW 16DKBL L BODY/ ELEC PANEL (10401/A/B) A7 / 18DKBL E63BB / L BODY/ REAR CAP (10405) / REAR CAP/ R BODY B2 (10700) / GROUND SPLICE (10701) CH3_52 / 16DKBL D63M / B63D 16DKBL B63RR 14DKBL *B63RR 16DKBL / SW ILLUM SPLICE (10333) CH8_34 FUSE F26 (10303) CH3_94G / F63-G 16WH / 87 85 G1 / G2 30 / J2 86 / REAR DOME LT RELAY (10311) / DIODE D79 (10307) B117D B63G 18GY 16WH A3 B3 / B63H 16WH / B63D 16WH / REAR DOME LT RELAY (10311) CH8_21B / 16DKBL 16DKBL B63C B63RW / REAR ROW DOME LT RELAY (10311) B63B 16DKBL B2 86 / A2 30 / 87 85 A1 B63-G 18WH D79 (10307) A3 DIODE B3 B63E 16GY / 16DKBL B63A / FUSE F26 (10303) CH3_94G / #B63W 16DKBL *B63W 18DKBL %B63X 16DKBL %B63RW 16DKBL / DOME LT PWR (10201) CH8_21C / PTI RELAY (10309) CH18_51 REAR DOME LT RELAY (10311) CH8_21A / B63E 16DKBL / Figure 358 / REAR ROW DOME LIGHTS

8.12. DOME LIGHTS WITH IGNITION FEED AND RHEOSTAT, P. 9C
Figure 359 DOME LIGHTS WITH IGNITION FEED AND RHEOSTAT

Components: BUZZER SPLICE (10204); DOME LT OUTPUT (10202); EMER DOME LT (84331); FUSE F25 (10303); IN PWR DIMMER O/P 1 (84273); IN PWR DIMMER O/P 2 (83174); RELAY (10311)
Wires (circuit gauge+color): B63-G 14WH; B63-GA 14WH; B63A 14DKBL; B63AA 16DKBL; B63AB 16DKBL; B63E 16DKBL; B63F 16DKBL
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.12. DOME LIGHTS WITH IGNITION FEED AND RHEOSTAT, P. 9C / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 15MAR21 / CHAPTER 8 DOME LIGHTS W/IGNITION FEED W/RHEOSTAT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR ROW EMER DOME LT (84331) 1 / B63-G 14WH B63-GA 14WH / B63AB 16DKBL H2 86 / G2 30 / 85 G1 / 2 MIN TIMER RELAY (10311) / B63E 16DKBL / B63F 16DKBL / B63AA 16DKBL / IN PWR DIMMER O/P 2 (83174) CH8_9A IN PWR DIMMER O/P 1 (84273) CH8_9A EMER EXIT BUZZER SPLICE (10204) CH14_1A / FUSE F25 (10303) CH3_94G / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / B63A 14DKBL / DOME LT OUTPUT (10202) CH8_36A / Figure 359 / DOME LIGHTS WITH IGNITION FEED AND RHEOSTAT

8.13. DOME LIGHTS WITH IGNITION FEED AND RHEOSTAT (CONT.), P. 10
Figure 360 DOME LIGHTS WITH IGNITION FEED AND RHEOSTAT (CONT.)

Components: BUZZER SPLICE (10204); EMER DOME LT (84331); FUSE B6-N (10303); FUSE B9-V (10302); RELAY (10313-R3); RHEOSTAT DIMMER (10376)
Wires (circuit gauge+color): B14 14RD; B14A 18RD; B14AA 14RD; B63-G 14WH; B63AA 16DKBL; B63AAH 12DKBL; B63AB 16DKBL; B63AC 16DKBL; B63AH 12DKBL; B63AL 12DKBL; F63-GA 14WH
See also sheets: CH14_01, CH3_13, CH3_17, CH8_07
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.13. DOME LIGHTS WITH IGNITION FEED AND RHEOSTAT (CONT.), P. 10 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 29DEC20 / CHAPTER 8 DOME LIGHTS W/IGNITION FEED W/RHEOSTAT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR ROW EMER DOME LT (84331) 1 / B63-G 14WH F63-GA 14WH / 87 85 / 2 MIN TIMER RELAY (10313-R3) / 16DKBL B63AC / B63AA 16DKBL / EMER EXIT BUZZER SPLICE (10204) CH14_01 / FUSE B9-V (10302) CH3_13 / 16DKBL B63AB / B63AH 12DKBL / B63AL 12DKBL / RHEOSTAT DIMMER (10376) CH8_07 / B63AAH 12DKBL / B14AA 14RD / B14 14RD / B14A 18RD / FUSE B6-N (10303) CH3_17 / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 360 / DOME LIGHTS WITH IGNITION FEED AND RHEOSTAT (CONT.)

8.14. DRIVER DOME LIGHTS ACTIVATED BY STEP LIGHT, P. 11
Figure 361 DRIVER DOME LIGHTS ACTIVATED BY STEP LIGHT

Components: DRIVERS DOME LT (10234); LT PWR (10201); PWR (10201); RELAY (10309-R6); SPLICE (10330); SPLICE (10334); SPLICE (10389)
Wires (circuit gauge+color): B62-GAJ 18WH; B62AJ 18DKBL; B63-GAB 16WH; B63-GAC 16WH; B63-GAD 14WH; B63AA 14DKBL; B63AB 14DKBL; B63AB 16DKBL; B63AG 16DKBL; B63AJ 18DKBL; B63AK 18DKBL
See also sheets: CH3_34, CH8_22, CH8_31, CH8_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.14. DRIVER DOME LIGHTS ACTIVATED BY STEP LIGHT, P. 11 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 29DEC20 / CHAPTER 8 DRIVERS DOME LIGHTS ACTIVATED BY STEP LIGHT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / DOME LT PWR (10201) CH8_35 / #B63AA 14DKBL #B63AB 16DKBL / DRIVERS DOME LT (10234) 2 / SW ILLUM SPLICE (10330) CH8_31 / B62-GAJ 18WH B62AJ 18DKBL / GROUND SPLICE (10334) CH3_34 / #B63-GAB 16WH / DRIVER DOME LT (10207) / DOOR OPTION SPLICE (10389) CH8_22 / PTI CONTROL RELAY (10309-R6) 85 / B63AJ 18DKBL / @B63-GAB 16WH / @B63-GAD 14WH / GROUND SPLICE (10334) CH3_34 / @B63AB 14DKBL @B63AG 16DKBL / DOME LT PWR (10201) CH8_35 / @B63AK 18DKBL / #W/STANDARD @W/ACTIVATED BY STEP LT / @B63-GAC 16WH / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 361 / DRIVER DOME LIGHTS ACTIVATED BY STEP LIGHT

8.15. DRIVER DOME LIGHTS ACTIVATED BY STEP LIGHT (CONT.), P. 11A
Figure 362 DRIVER DOME LIGHTS ACTIVATED BY STEP LIGHT (CONT.)

Components: LT PWR (10201); PWR (10201); RELAY (10309); SPLICE (10330); SPLICE (10334); SPLICE (10389)
Wires (circuit gauge+color): B62-GAJ 18WH; B62AJ 18DKBL; B63-GAB 16WH; B63-GAC 14WH; B63AA 14DKBL; B63AB 14DKBL; B63AB 16DKBL; B63AG 16DKBL; B63AJ 18DKBL; B63AK 18DKBL
See also sheets: CH8_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.15. DRIVER DOME LIGHTS ACTIVATED BY STEP LIGHT (CONT.), P. 11A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 15MAR21 / CHAPTER 8 DRIVERS DOME LIGHTS ACTIVATED BY STEP LIGHT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / DOME LT PWR (10201) CH8_36A / B63AA 14DKBL #B63AB 16DKBL / DRIVERS DOME LT (10234 2 / SW ILLUM SPLICE (10330) CH8_31 / B62-GAJ 18WH B62AJ 18DKBL / GROUND SPLICE (10334) CH3_95F / #B63-GAB 16WH / DRIVER DOME LT (10207) / DOOR OPTION SPLICE (10389) CH8_23A / 85 G3 / G4 30 / 87A H3 / J4 86 / B63AJ 18DKBL / @B63-GAB 16WH / B63-GAC 14WH / GROUND SPLICE (10334) CH3_95F / @B63AB 14DKBL @B63AG 16DKBL / B63AK 18DKBL / #W/STANDARD @W/ACTIVATED BY STEP LT / PTI CONTROL RELAY (10309) / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / DOME LT PWR (10201) CH8_36A / Figure 362 / DRIVER DOME LIGHTS ACTIVATED BY STEP LIGHT (CONT.)

8.16. DRIVER DOME LIGHTS, 1 INCH RED, P. 12
Figure 363 DRIVER DOME LIGHTS, 1 INCH RED

Components: DOME LT DROP (11646); FUSE B6-M (10303); FUSE F69 (10306); GROUND SPLICE (10334); OVERHEAD LT (11645); SW ILLUM (10399)
Wires (circuit gauge+color): B62-GA 18WH; B62A 18DKBL; B63-GA 16WH; B63A 16DKBL; B63B 18DKBL
See also sheets: CH3_17, CH7_63
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.16. DRIVER DOME LIGHTS, 1 INCH RED, P. 12 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 29DEC20 / CHAPTER 8 DRIVERS DOME LIGHTS W/1 INCH/RED / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / RED DRIVERS OVERHEAD LT (11645) 8 / %B63A 16DKBL / @B62A 18DKBL @B62-GA 18WH / RED DRIVERS DOME LT DROP (11646) A / FUSE F69 (10306) CH3_94N FUSE B6-M (10303) CH3_17 @B63B 18DKBL / @B63-GA 16WH / SW ILLUM (10399) CH7_63 / #B63A 16DKBL / GROUND SPLICE (10334) CH3_95F / Figure 363 / DRIVER DOME LIGHTS, 1 INCH RED

8.17. DOME LIGHT, SINGLE SWITCH, P. 13
Figure 364 DOME LIGHT, SINGLE SWITCH

Components: CHILD MONITER RELAY (10313-R6); DOME LT (10230); DOME LT OUTPUT (10202); DOME LT PWR (10201); DOME LT RELAY (10313-R5); DOME LT RHEOSTAT (10215E); MIN TIMER RELAY (10313-R3); REAR DOME LT RELAY (10311-R2); SPLICE (10328)
Wires (circuit gauge+color): B62-GU 18WH; B62U 18DKBL; B63 14DKBL; B63A 14DKBL; B63AN 16DKBL; B63B 16DKBL; B63DV 16DKBL; B63RE 12DKBL; B63SA 14DKBL
See also sheets: CH18_09, CH8_07, CH8_09, CH8_15, CH8_17, CH8_28, CH8_35, CH8_36
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.17. DOME LIGHT, SINGLE SWITCH, P. 13 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 29DEC20 / CHAPTER 8 / DOME LIGHT W/SINGLE SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / DOME LT PWR (10201) CH8_35 REAR DOME LT RELAY (10311-R2) CH8_15,16 DOME LT RHEOSTAT (10215E) CH8_07 DOME LT RELAY (10313-R5) CH8_17 / B63A 14DKBL / B63B 16DKBL / STD/FR DOME LT (10230) 2 / # W/RHEOSTAT * N/RHEOSTAT / B63SA 14DKBL #B63RE 12DKBL / B62-GU 18WH B62U 18DKBL / SW ILLUM SPLICE (10328) CH8_28 / B63A 14DKBL / W/ STANDARD DOME LT / SW ILLUM SPLICE (10328) CH8_28 / B63B 16DKBL *B63AN 16DKBL / DOME LT PWR (10201) CH8_35 DOME LT OUTPUT (10202) CH8_36 / #B62-GU 18WH #B62U 18DKBL / STD/FR DOME LT (10230) 2 / # W/RHEOSTAT * N/RHEOSTAT / W/ DELUX DOME LT / 2 MIN TIMER RELAY (10313-R3) CH8_09 CHILD MONITER RELAY (10313-R6) CH18_09 / B63 14DKBL / B63DV 16DKBL / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 364 / DOME LIGHT, SINGLE SWITCH

8.18. DOME LIGHT, SINGLE SWITCH (CONT.), P. 13A
Figure 365 DOME LIGHT, SINGLE SWITCH (CONT.)

Components: DOME LT OUTPUT (10202); DOME LT PWR (10201); DOME LT RHEOSTAT (10215E); FUSE F78 (10307); LIGHT SWITCH (10230); LT RELAY (10311); REAR DOME LT RELAY (10311); RELAY (10311); SPLICE (10328)
Wires (circuit gauge+color): B62-GU 18WH; B62U 18DKBL; B63A 14DKBL; B63AM 16DKBL; B63AN 16DKBL; B63AP 16DKBL; B63B 16DKBL; B63D 12DKBL; B63D 16DKBL; B63P 14DKBL; B63RE 12DKBL
See also sheets: CH18_54, CH8_07, CH8_28
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.18. DOME LIGHT, SINGLE SWITCH (CONT.), P. 13A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 17MAR21 / CHAPTER 8 DOME LIGHT W/SINGLE SWITCH(CONT.) / MJV0488 19NOV21 ADDED CIRC B63P, B63D B IN R/D 10230. / %B63D 12DKBL %B63P 14DKBL *B63D 16DKBL #B63RE 12DKBL / B63B 16DKBL / STD/FRONT DOME LIGHT SWITCH (10230) 2 / # W/RHEOSTAT * N/RHEOSTAT % W/2 MIN TIMER / B62-GU 18WH B62U 18DKBL / B63A 14DKBL / W/ STANDARD DOME LT / DOME LT PWR (10201) CH8_36A DOME LT OUTPUT (10202) CH8_36B FUSE F78 (10307) CH3_94P DOME LT OUTPUT (10202) CH8_36B SW ILLUM SPLICE (10328) CH8_28 / B63B 16DKBL *B63AN 16DKBL / #B63AM 16DKBL *B63AP 16DKBL #B62-GU 18WH #B62U 18DKBL / # W/RHEOSTAT * N/RHEOSTAT NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / W/ DELUX DOME LT / STD/FRONT DOME LIGHT SWITCH (10230) / Figure 365 / DOME LIGHT, SINGLE SWITCH (CONT.)

8.19. DOME LIGHT, SPLIT SWITCH, P. 14
Figure 366 DOME LIGHT, SPLIT SWITCH

Components: DIODE (10377); DOME LT (10230); DOME LT (10231); FUSE B6-V (10303); LT RELAY (10311-R1); OUTPUT (10202); PLATFORM (1702); PWR (10201); RHEOSTAT (10215J/E/C/D); SPLICE (10328); SPLICE (10335A)
Wires (circuit gauge+color): B120KA 18LTGN; B120KB 18LTGN; B62-GU 18WH; B62-GV 18WH; B62U 18DKBL; B62V 18DKBL; B63-G 16WH; B63AM 16DKBL; B63AP 16DKBL; B63B 16DKBL; B63C 16DKBL; B63D 14DKBL; B63D 16DKBL; B63E 16DKBL; B63F 16DKBL; B63RC 12DKBL; B63RD 12DKBL; B63RE 14DKBL; B63RJ 12DKBL; B63RK 12DKBL; B63RM 14DKBL; B63RN 14DKBL
See also sheets: CH16_09, CH3_26, CH3_36, CH8_07, CH8_28, CH8_35, CH8_36
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.19. DOME LIGHT, SPLIT SWITCH, P. 14 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 29DEC20 / DOME LIGHT W/SPLIT SWITCH / CHAPTER 8 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / RHEOSTAT DIODE (10377) 3 / B63B 16DKBL *B63D 16DKBL / STD/FR DOME LT (10230) 2 / # W/SPLIT SW W/ RHEOSTAT * W/REAR SW O/P N/ RHEOSTAT @ W/3 POSITION SWITCH W/ FR NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / B62-GU 18WH B62U 18DKBL / REAR DOME LT (10231) 2 / B63C 16DKBL *B63E 16DKBL / B62-GV 18WH B62V 18DKBL / #B63RD 12DKBL #B63RK 12DKBL / B63AM 16DKBL #B63RC 12DKBL #B63RJ 12DKBL / @B63-G 16WH DOME LT PWR (10201) CH8_35 DOME LT OUTPUT (10202) CH8_36 DOME LT RHEOSTAT (10215J/E/C/D) CH8_07 / DOME LT OUTPUT (10202) CH8_35,36 / SW ILLUM SPLICE (10328) CH8_28 @B63D 16DKBL @B63B 16DKBL / #B63RN 14DKBL B63RE 14DKBL #B63RM 14DKBL / @B63F 16DKBL / @B63C 16DKBL B63D 14DKBL / GROUND SPLICE (10335A) CH3_36 / REAR ROW DOME LT RELAY (10311-R1) / B63AP 16DKBL / @B120KA 18LTGN / @B120KB 18LTGN / ELEC PANEL/ PLATFORM (1702) CH16_09 / FUSE B6-V (10303) CH3_26 / Figure 366 / DOME LIGHT, SPLIT SWITCH

8.20. DOME LIGHT, SPLIT SWITCH (CONT.), P. 14A
Figure 367 DOME LIGHT, SPLIT SWITCH (CONT.)

Components: DOME LIGHT (10231); DOME LT (10230); DOME LT (10233); OUTPUT (10202); PLATFORM (1702); PTI RELAY (10309); PWR (10201); RELAY (10311); RHEOSTAT (10215E/C/D); RHEOSTAT DIODE (10377); SPLICE (10328); SPLICE (10335A)
Wires (circuit gauge+color): B120KA 18LTGN; B120KB 18LTGN; B62-GU 18WH; B62-GV 18WH; B62U 18DKBL; B62V 18DKBL; B63-G 16WH; B63B 16DKBL; B63C 16DKBL; B63D 16DKBL; B63D 16LTBL; B63E 16DKBL; B63F 16DKBL; B63RC 12DKBL; B63RD 12DKBL; B63RE 12DKBL; B63RJ 12DKBL; B63RK 12DKBL; B63RM 12DKBL; B63RN 12DKBL; B63Z 18DKBL
See also sheets: CH18_51, CH8_07, CH8_28
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.20. DOME LIGHT, SPLIT SWITCH (CONT.), P. 14A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 15MAR21 / CHAPTER 8 DOME LIGHT W/SPLIT SWITCH(CONT.) / MJV0488 19NOV21 ADDED CIRC B63D IN CAV 3 R/D 10230. / RHEOSTAT DIODE (10377) 3 / %B63D 16LTBL @B63C 16DKBL B63B 16DKBL *B63D 16DKBL / STD/FRONT DOME LT (10230) 2 / B62-GU 18WH B62U 18DKBL / REAR DOME LIGHT (10231) 2 / B63C 16DKBL *B63E 16DKBL / B62-GV 18WH B62V 18DKBL / #B63RD 12DKBL #B63RK 12DKBL / #B63RC 12DKBL #B63RJ 12DKBL / 85 A1 B1 @B63-G 16WH *B63Z 18DKBL DOME LT PWR (10201) CH8_36A DOME LT OUTPUT CH8_36B DOME LT RHEOSTAT (10215E/C/D) CH8_07 / DOME LT OUTPUT (10202) CH8_36A,36B / SW ILLUM SPLICE (10328) CH8_28 @B63D 16DKBL @B63B 16DKBL / #B63RN 12DKBL B63RE 12DKBL #B63RM 12DKBL / @B63F 16DKBL / A2 30 / B2 86 / ELEC PANEL/ REAR ROW PLATFORM DOME LT (1702) RELAY CH16_9A (10311) GROUND SPLICE (10335A) CH3_95G REAR ROW DOME LT (10233) CH8_9A / B120KA 18LTGN / B120KB 18LTGN / PTI RELAY (10309) CH18_51 / Figure 367 / DOME LIGHT, SPLIT SWITCH (CONT.)

8.21. DOME LIGHT ACTIVATED BY 2 MINUTE TIMER, P. 15
Figure 368 DOME LIGHT ACTIVATED BY 2 MINUTE TIMER

Components: DOME LT (10230); FUSE B12-J (10301); FUSE B3-F (10304); FUSE B9-W (10302); LT RELAY (10311-R2); LT RELAY (10311-R3); OUTPUT (10202); SPLICE (10335A); TIMER RELAY (10313-R3); TIMER RELAY (10397)
Wires (circuit gauge+color): B11-G 16WH; B11-GA 16WH; B11-GB 16WH; B11-GC 16WH; B11-GD 16WH; B12A 18LTBL; B12B 16LTBL; B13A 18PK; B63A 14DKBL; B63B 14DKBL; B63M 16DKBL; B63N 16DKBL; B63NA 16DKBL; B63P 16DKBL; B63S 16DKBL; B63SA 14DKBL; B63T 16DKBL; B63U 18DKBL; B63V 18DKBL; B63W 14DKBL
See also sheets: CH3_08, CH3_17, CH3_19, CH3_36, CH8_13, CH8_36
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.21. DOME LIGHT ACTIVATED BY 2 MINUTE TIMER, P. 15 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 29DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 85 B11-GA 16WH / FR DOME LT RELAY (10311-R3) / STD/FR DOME LT (10230) CH8_13 DOME LT OUTPUT (10202) CH8_36 / 2 MIN TIMER RELAY (10313-R3) / B11-G 16WH / B12B 16LTBL / B63W 14DKBL / B63P 16DKBL / B63T 16DKBL / GROUND SPLICE (10335A) CH3_36 / FUSE B12-J (10301) CH3_19 / FUSE B3-F (10304) CH3_17 / B13A 18PK / DOME LT TIMER RELAY (10397) / B63SA 14DKBL / B12A 18LTBL / B11-GD 16WH / REAR DOME LT RELAY (10311-R2) 86 30 / FUSE B9-W (10302) CH3_08 / 18DKBL B11-GB B63V 16WH / GROUND SPLICE (10335A) CH3_36 / 85 B11-GC 16WH / B63U 18DKBL / B63M 16DKBL / B63N 16DKBL / B63B 14DKBL / DOME LT OUTPUT (10202) CH8_36 / B63A 14DKBL B63S 16DKBL / B63NA 16DKBL / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 368 / DOME LIGHT ACTIVATED BY 2 MINUTE TIMER

8.22. DOME LIGHT ACTIVATED BY 2 MINUTE TIMER WITH REAR ROW, P. 16
Figure 369 DOME LIGHT ACTIVATED BY 2 MINUTE TIMER WITH REAR ROW

Components: DOME LT (10230); DOME LT RELAY (10311-R1); FUSE B12-J (10301); FUSE B3-F (10304); FUSE B9-W (10301); LT RELAY (10311-R2); LT RELAY (10311-R3); OUTPUT (10202); RELAY (10233); SPLICE (10335A); TIMER RELAY (10313-R3); TIMER RELAY (10397)
Wires (circuit gauge+color): B11-G 16WH; B11-GA 16WH; B11-GB 16WH; B11-GC 16WH; B11-GD 16WH; B11-GJ 16WH; B12A 18LTBL; B12B 16LTBL; B13A 18PK; B63A 14DKBL; B63B 14DKBL; B63M 16DKBL; B63N 16DKBL; B63NA 16DKBL; B63NB 16DKBL; B63NC 14DKBL; B63P 16DKBL; B63S 16DKBL; B63SA 14DKBL; B63T 16DKBL; B63U 18DKBL; B63V 18DKBL; B63W 16DKBL; B63Z 18DKBL
See also sheets: CH3_08, CH3_17, CH3_19, CH3_36, CH8_08, CH8_13, CH8_36
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.22. DOME LIGHT ACTIVATED BY 2 MINUTE TIMER WITH REAR ROW, P. 16 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 29DEC20 / CHAPTER 8 DOME LIGHT ACTIVATED BY 2 MIN TIMER W/REAR ROW / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 85 B11-GA 16WH / FR DOME LT RELAY (10311-R3) / STD/FR DOME LT (10230) CH8_13 DOME LT OUTPUT (10202) CH8_36 / 2 MIN TIMER RELAY (10313-R3) / B11-G 16WH / B12B 16LTBL / B63NA 16DKBL B63NB 16DKBL B63NC 14DKBL / B63P 16DKBL / B63T 16DKBL / GROUND SPLICE (10335A) CH3_36 / FUSE B12-J (10301) CH3_19 / FUSE B3-F (10304) CH3_17 / B13A 18PK / DOME LT TIMER RELAY (10397) / B63SA 14DKBL / B12A 18LTBL / B11-GB 16WH / REAR DOME LT RELAY (10311-R2) 86 30 / FUSE B9-W (10301) CH3_08 / 85 B11-GC 16WH / B63U 18DKBL / 18DKBL B63V / B63M 16DKBL / B63N 16DKBL / B63B 14DKBL / DOME LT OUTPUT (10202) CH8_36 / B63A 14DKBL B63S 16DKBL / B63Z 18DKBL / REAR ROW DOME LT RELAY (10233) CH8_08 / B11-GJ 16WH / B11-GD 16WH / GROUND SPLICE (10335A) CH3_36 / B63W 16DKBL / REAR ROW DOME LT RELAY (10311-R1) / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 369 / DOME LIGHT ACTIVATED BY 2 MINUTE TIMER WITH REAR ROW

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 410 | printed page 370 | section 8.23
8.23. DOME LIGHT ACTIVATED BY 2 MINUTE TIMER, WITH REAR ROW AND EMERGENCY EXIT, P. 17
Figure 370 DOME LIGHT ACTIVATED BY 2 MINUTE TIMER, WITH REAR ROW AND EMERGENCY EXIT

Components: DIODE B3-P (10304); DOME LT RELAY (10230); FUSE B9-U (10302); FUSE B9-V (10302); FUSE B9-W (10302); OUTPUT (10202); RELAY (10311-R1); RELAY (10313-R3); RELAY (10313-R5); SPLICE (10204); SPLICE (10335A); TIMER RELAY (10397)
Wires (circuit gauge+color): B117D 18GY; B63-GA 16WH; B63-GB 16WH; B63-GE 14WH; B63-GF 16WH; B63A 14DKBL; B63A 16DKBL; B63B 14DKBL; B63B 16DKBL; B63C 16DKBL; B63D 16WH; B63G 16WH; B63H 16WH; B63J 16DKBL; B63L 16DKBL; B63M 16DKBL; B63N 16DKBL; B63P 16WH
See also sheets: CH14_01, CH3_08, CH3_13, CH3_15, CH3_36, CH8_09, CH8_13, CH8_36
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.23. DOME LIGHT ACTIVATED BY 2 MINUTE TIMER, WITH REAR ROW AND EMERGENCY EXIT, P. 17 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 29DEC20 / CHAPTER 8 DOME LIGHT ACTIVATED BY 2 MIN TIMER MIN W/REAR ROW W/EMERGENCY EXIT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (10335A) CH3_36 / DOME LT TIMER RELAY (10397) / B63-GA 16WH / FUSE B9-V (10302) CH3_13 / B63C 16DKBL / B63A 16DKBL / B63-GF 16WH / B63-GE 14WH / FUSE B9-U (10302) CH3_15 / B63D 16WH / B63G 16WH / DIODE B3-P (10304) B117D 18GY 26 30 / EMER EXIT BUZZER SPLICE (10204) CH14_01 / DOME LT RELAY (10313-R5) 85 / B63B 14DKBL / DOME LT OUTPUT (10202) CH8_36 / B63A 14DKBL / STD/FR DOME LT RELAY (10230) CH8_13 / B63J 16DKBL / REAR ROW DOME LT RELAY (10311-R1) / B63M 16DKBL / FUSE B9-W (10302) CH3_08 / B63B 16DKBL / B63-GB 16WH / B63H 16WH / B63P 16WH / 2 MIN TIMER RELAY (10313-R3) CH8_09 / B63N 16DKBL / B63L 16DKBL / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 370 / DOME LIGHT ACTIVATED BY 2 MINUTE TIMER, WITH REAR ROW AND EMERGENCY EXIT

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 411 | printed page 371 | section 8.24
8.24. DOME LIGHT ACTIVATED BY EMERGENCY EXIT, P. 18
Figure 371 DOME LIGHT ACTIVATED BY EMERGENCY EXIT

Components: DIODE B3-P (10304); DIODE-B3-A (10304); DOME LT (10233); ELEC PANEL (10401); FUSE B9-W (10302); LT RELAY (10311-R1); LT RELAY (10311-R2); LT RELAY (10311-R3); OUTPUT (10202); SPLICE (10335A); SPLICE (10389)
Wires (circuit gauge+color): B11-G 18WH; B11-GA 18WH; B11-GB 18WH; B63-GM 18WH; B63M 16DKBL; B63MA 16DKBL; B63MB 16DKBL; B63MJ 18DKBL; B63MK 16DKBL; B63P 18DKBL; B63S 16DKBL; B63T 16DKBL; B63U 18DKBL; B63UA 18DKBL; B63UB 18DKBL; B63UC 18DKBL; B63W 18DKBL; B63WA 16DKBL; B63WB 16DKBL; B63WC 16DKBL
See also sheets: CH3_08, CH3_36, CH8_06, CH8_08, CH8_22, CH8_36
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.24. DOME LIGHT ACTIVATED BY EMERGENCY EXIT, P. 18 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 29DEC20 / CHAPTER 8 DOME LIGHT ACTIVATED BY EMERGENCY EXIT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / *B63W 18DKBL %B63U 18DKBL 86 / B63P 18DKBL 86 / FR DOME LT RELAY (10311-R3) / B63M 16DKBL / B11-GA 18WH / DIODE B3-P (10304) CH8_06 / DOME LT OUTPUT (10202) CH8_36 / B63-GM 18WH / REAR ROW DOME LT RELAY (10311-R1) / FUSE B9-W (10302) CH3_08 / B63T 16DKBL / DOOR OPTION SPLICE (10389) CH8_22 / B63MJ 18DKBL / B63MB 16DKBL B63MA 16DKBL / *B63U 18DKBL %B63UC 18DKBL / B63UA 18DKBL / B63MK 16DKBL / 18DKBL B63UB / DIODE-B3-A (10304) / B11-G 18WH / B11-GB 18WH / GROUND SPLICE (10335A) CH3_36 REAR ROW DOME LT (10233) CH8_08 L BODY/ ELEC PANEL (10401) CH8_08 / @B63WA 16DKBL / @B63WC 16DKBL / B63S 16DKBL / REAR DOME LT RELAY (10311-R2) / @B63WB 16DKBL / % W/ENTRANCE DOOR * W/ANY EMER EXIT @ W/ENTRANCE DOOR W/REAR ROW / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 371 / DOME LIGHT ACTIVATED BY EMERGENCY EXIT

8.25. DOME LIGHT ACTIVATED BY EMERGENCY EXIT, WITH REAR ROW, P. 19
Figure 372 DOME LIGHT ACTIVATED BY EMERGENCY EXIT, WITH REAR ROW

Components: BUZZER SPLICE (10204); DOME LT (10233); FUSE B9-W (10302); L BODY (10401); LT RELAY (10311-R1); LT RELAY (10311-R2); OUTPUT (10202)
Wires (circuit gauge+color): B117D 16GY; B117DA 16DKBL; B117DB 16DKBL; B63M 16DKBL; B63MA 16DKBL; B63MB 16DKBL; B63MC 16DKBL; B63MD 16DKBL; B63RW 16DKBL; B63T 12DKBL; B63Z 16DKBL
See also sheets: CH14_01, CH3_08, CH8_08, CH8_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.25. DOME LIGHT ACTIVATED BY EMERGENCY EXIT, WITH REAR ROW, P. 19 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 29DEC20 / CHAPTER 8 DOME LIGHT ACTIVATED BY EMERGENCY EXIT W/REAR ROW / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B63M 16DKBL / REAR ROW DOME LT RELAY (10311-R1) / FUSE B9-W (10302) CH3_08 / B63MC 16DKBL / B63T 12DKBL / B117DB 16DKBL / B63MA 16DKBL / B63MD 16DKBL / B63Z 16DKBL / REAR DOME LT RELAY (10311-R2) / DOME LT OUTPUT (10202) CH8_35 / B63MB 16DKBL / REAR ROW DOME LT (10233) CH8_08 / B63RW 16DKBL / ELEC PANEL/ L BODY (10401) CH8_08 / B117DA 16DKBL / B117D 16GY / EMER EXIT BUZZER SPLICE (10204) CH14_01 / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 372 / DOME LIGHT ACTIVATED BY EMERGENCY EXIT, WITH REAR ROW

8.26. DOME LIGHT ACTIVATED BY ENTRANCE DOOR, P. 20
Figure 373 DOME LIGHT ACTIVATED BY ENTRANCE DOOR

Components: DOME LT (10233); L BODY (10401A); LT RELAY (10311-R2); LT RELAY (10311-R3); OUTPUT (10202); PWR (10201); SPLICE (10335A); SPLICE (10389)
Wires (circuit gauge+color): B11-G 18WH; B11-GA 18WH; B11-GB 18WH; B120A 18LTGN; B63D 18DKBL; B63M 16DKBL; B63N 16DKBL; B63P 16DKBL; B63T 16DKBL; B63U 18DKBL; B63WA 16DKBL; B63WB 16DKBL; B63WC 16DKBL
See also sheets: CH3_36, CH8_08, CH8_22, CH8_35, CH8_36
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.26. DOME LIGHT ACTIVATED BY ENTRANCE DOOR, P. 20 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 29DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B120A 18LTGN / REAR DOME LT RELAY (10311-R2) / DOOR OPTION SPLICE (10389) CH8_22 / B63D 18DKBL / B63P 16DKBL / B63WC 16DKBL / B11-GB 18WH / B11-GA 18WH / FR DOME LT RELAY (10311-R3) / DOME LT PWR (10201) CH8_35 / B63U 18DKBL / B63N 16DKBL / B63T 16DKBL / DOME LT OUTPUT (10202) CH8_36 / B63WA 16DKBL / GROUND SPLICE (10335A) CH3_36 / B11-G 18WH / B63M 16DKBL / B63WB 16DKBL / REAR ROW DOME LT (10233) CH8_08 / ELEC PANEL/ L BODY (10401A) CH8_08 / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 373 / DOME LIGHT ACTIVATED BY ENTRANCE DOOR

8.27. DOME LIGHT ACTIVATED BY ENTRANCE DOOR, WITH REAR ROW, P. 21
Figure 374 DOME LIGHT ACTIVATED BY ENTRANCE DOOR, WITH REAR ROW

Components: FUSE B9-W (10302); LT RELAY (10311-R2); LT RELAY (10311-R3); OUTPUT (10202); SPLICE (10335A); SPLICE (10389)
Wires (circuit gauge+color): B11-G 16WH; B11-GA 16WH; B11-GB 16WH; B120A 18LTGN; B63M 16DKBL; B63MA 16DKBL; B63MV 16DKBL; B63S 16DKBL; B63T 16DKBL; B63U 18DKBL; B63V 18DKBL
See also sheets: CH3_08, CH3_36, CH8_22, CH8_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.27. DOME LIGHT ACTIVATED BY ENTRANCE DOOR, WITH REAR ROW, P. 21 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 29DEC20 / CHAPTER 8 DOME LIGHT ACTIVATED BY ENTRANCE DOOR W/REAR ROW / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B120A 18LTGN / REAR DOME LT RELAY (10311-R2) / DOOR OPTION SPLICE (10389) CH8_22 / B63V 18DKBL / B63MV 16DKBL / B63S 16DKBL / B11-GB 16WH / B11-GA 16WH / FR DOME LT RELAY (10311-R3) / FUSE B9-W (10302) CH3_08 / B63U 18DKBL / B63MA 16DKBL / B63T 16DKBL / GROUND SPLICE (10335A) CH3_36 / B11-G 16WH / B63M 16DKBL / DOME LT OUTPUT (10202) CH8_35,36 / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 374 / DOME LIGHT ACTIVATED BY ENTRANCE DOOR, WITH REAR ROW

8.28. DOME LIGHT ACTIVATED BY TIMER, P. 21A
Figure 375 DOME LIGHT ACTIVATED BY TIMER

Components: DOME LT (10233); DOME LT RELAY (10311); ELEC PANEL (10401); FUSE F26 (10303); FUSE F48 (10304); FUSE F63 (10306); GROUND SPLICE (10335B); LT RELAY (10311); OUTPUT (10202); SPLICE (10335A); TIMER RELAY (10311); TIMER RELAY (10397)
Wires (circuit gauge+color): B11-G 16WH; B11-GA 16WH; B11-GJ 16WH; B125-GL 18WH; B12A 18LTBL; B12B 16LTBL; B13A 18PK; B63M 16DKBL; B63N 16DKBL; B63P 16DKBL; B63RW 16DKBL; B63S 16LTBL; B63T 16DKBL; B63U 18DKBL; B63V 18DKBL; B63Z 16DKBL; B63Z 18DKBL
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.28. DOME LIGHT ACTIVATED BY TIMER, P. 21A / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 16MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 85 B11-GA 16WH / (B63N) C2 30 / 85 E1 (B11-G) / FR DOME LT RELAY (10311) F2 E2 86 30 / A2 30 / B2 86 / REAR ROW DOME LT RELAY (10311) / DOME LT OUTPUT (10202) CH8_36B / B13A 18PK J2 86 / 2 MIN TIMER RELAY (10311) / 85 G1 / 87A H1 / G2 30 / FUSE F63 (10306) CH3_94N # W/REAR ROW DOME LT * N/REAR ROW DOME LT / #B11-GJ 16WH / B11-G 16WH / B63Z 18DKBL / REAR ROW DOME LT (10233) CH8_9A / B12B 16LTBL / B63N 16DKBL REAR DOME LT RELAY (10311) 86 / B63P 16DKBL B63U 18DKBL / B63T 16DKBL / GROUND SPLICE (10335A) CH3_95G REAR DOME LT RELAY (10311) CH8_21B REAR ROW DOME LT (10233) CH8_9A / FUSE F48 (10304) CH3_94K / DOME LT TIMER RELAY (10397) / B63S 16LTBL / B12A 18LTBL / #B63V 18DKBL / FUSE F26 (10303) CH3_94G / B125-GL 18WH / GROUND SPLICE (10335B) CH3_95H L BODY/ ELEC PANEL (10401) CH8_9B / B63U 18DKBL / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / B63M 16DKBL / B63RW 16DKBL / B63Z 16DKBL / Figure 375 / DOME LIGHT ACTIVATED BY TIMER

8.29. DOME LIGHT WITH 2 MINUTE TIMER, REAR ROW AND EMERGENCY EXIT, P. 21B
Figure 376 DOME LIGHT WITH 2 MINUTE TIMER, REAR ROW AND EMERGENCY EXIT

Components: DIODE D79 (10307); FUSE F25 (10303); FUSE F26 (10303); FUSE F59 (10305); LT RELAY (10311); OUTPUT (10202); RELAY (10311); SPLICE (10335A); STD/FR DOME LT (10230); TIMER RELAY (10397)
Wires (circuit gauge+color): B63-GA 16WH; B63-GB 16WH; B63-GE 14WH; B63-GF 16WH; B63A 14DKBL; B63A 16DKBL; B63B 14DKBL; B63B 16DKBL; B63C 16DKBL; B63D 16WH; B63G 16WH; B63H 16WH; B63J 16DKBL; B63K 16DKBL; B63L 16DKBL; B63M 16DKBL; B63N 16DKBL; B63U 18DKBL
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.29. DOME LIGHT WITH 2 MINUTE TIMER, REAR ROW AND EMERGENCY EXIT, P. 21B / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 16MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (10335A) CH3_95G / DOME LT TIMER RELAY (10397) / B63-GA 16WH / FUSE F25 (10303) CH3_94G / B63C 16DKBL / B63-GB 16WH / B63A 16DKBL / A2 30 / B2 86 / 85 A1 / B63-GF 16WH / B63-GE 14WH / FUSE F59 (10305) CH3_94M / B63D 16WH / B63G 16WH / DIODE D79 (10307) CH8_9B / B63B 14DKBL C2 30 / D2 86 / 85 C1 / DOME LIGHT OUTPUT (10202) CH8_36B / B63A 14DKBL B63J 16DKBL B63N 16DKBL E2 30 / J2 86 / 85 E1 B63K 16DKBL / 87A J1 / STD/FR DOME LT (10230) CH8_13A / B63H 16WH / B63M 16DKBL B63L 16DKBL / FUSE F26 (10303) CH3_94G / REAR DOME LT RELAY (10311) / REAR DOME LT RELAY (10311) / REAR ROW DOME LT RELAY (10311) / B63U 18DKBL / FR DOME LT RELAY (10311) CH8_21A / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / B63B 16DKBL / Figure 376 / DOME LIGHT WITH 2 MINUTE TIMER, REAR ROW AND EMERGENCY EXIT

8.30. DOME LIGHT ACTIVATED BY EMERGENCY EXIT, P. 21C
Figure 377 DOME LIGHT ACTIVATED BY EMERGENCY EXIT

Components: BUZZER SPLICE (10204); DIODE D70 (10306); DIODE D79 (10307); DOME SW (10233); FUSE F26 (10303); L BODY (10401A); LT RELAY (10311); OUTPUT (10202); RELAY (10311); SPLICE (10335A); SPLICE (10386); SPLICE (10389)
Wires (circuit gauge+color): B11-G 16WH; B11-G 18WH; B11-GJ 18WH; B117D 16GY; B120A 18LTGN; B63-GM 18WH; B63E 16GY; B63M 16DKBL; B63MJ 18DKBL; B63P 18DKBL; B63S 16DKBL; B63T 16DKBL; B63U 18DKBL; B63UA 18DKBL; B63UB 18DKBL; B63WA 16DKBL; B63WB 16DKBL
See also sheets: CH8_06
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.30. DOME LIGHT ACTIVATED BY EMERGENCY EXIT, P. 21C / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 16MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / D2 86 / 87A D1 / C2 30 / 85 (B11-G) B63T 16DKBL / (B63M) E2 30 / F2 86 / FR DOME LT RELAY (10311) / A2 30 / B63MJ 18DKBL B2 86 / EMER EXIT ACTIVATION RELAY (10311) / B63M 16DKBL / B11-GJ 18WH B117D 16GY / GROUND SPLICE (10335A) CH3_95G / B63-GM 18WH / REAR DOOR SPLICE (10386) CH8_06 / B11-G 16WH B11-G 18WH / B63S 16DKBL B63P 18DKBL / REAR DOME LT RELAY (10311) / FUSE F26 (10303) CH3_94G DOOR OPTION SPLICE (10389) CH8_23A / DOME LT OUTPUT (10202) CH8_36A / DIODE D79 (10307) / B63E 16GY / DOOR OPTION SPLICE (10389) CH8_23A / B63U 18DKBL / B63UB 18DKBL / B63UA 18DKBL / DIODE D70 (10306) B4 A4 / B120A 18LTGN / B63WB 16DKBL / B63WA 16DKBL / REAR ROW DOME SW (10233) CH8_9A,9B ELEC PANEL/ L BODY (10401A) CH8_9A,9B / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / EMER EXIT BUZZER SPLICE (10204) CH14_1A / Figure 377 / DOME LIGHT ACTIVATED BY EMERGENCY EXIT

8.31. STEPWELL LIGHTS, P. 22
Figure 378 STEPWELL LIGHTS

Components: CROSSING GATE RELAY (10313-R1); DIODE B3-A (10304); DIODE B3-D (10304); FR DOME LT RELAY (10311-R3); PEDESTRIAN LT RELAY (10282); PTI CONTROL RELAY (10309-R6); REAR DOME LT RELAY (10311-R2); SEALED ENG (11500); SPLICE (11509); STEPWELL LT RELAY (10309-R3)
Wires (circuit gauge+color): B119S 16GY; B120A 18LTGN; B120AL 16LTGN; B125RA 18GY; B131AA 18DKBL; B131BC 16DKBL; B131CV 16DKBL; B63AJ 18DKBL; B63D 18DKBL; B63U 18DKBL; B63UB 18DKBL; B63V 18DKBL; Y131 16DKBL; Y131-GA 16WH; Y131-GB 16WH; Y131-GC 16WH; Y131A 16DKBL; Y131B 16DKBL; Y131C 16DKBL
See also sheets: CH16_08, CH18_04, CH18_20, CH18_26, CH3_49, CH7_62, CH8_11, CH8_18, CH8_20, CH8_21, CH8_23, CH9_11
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.31. STEPWELL LIGHTS, P. 22 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / STEP WELL LIGHTS / CHAPTER 8 / B131CV 16DKBL 1 / B131BC 16DKBL / STEPWELL LT RELAY (10309-R3) CH8_23 CH16_08,09,10,10A, 12,13,14,16,17 PEDESTRIAN LT RELAY (10282) CH7_62 DIODE B3-A (10304) CH8_18 / FWD STEP LT @(11526) / Y131B 16DKBL Y131-GB 16WH / Y131 16DKBL Y131A 16DKBL Y131-GA 16WH / ELEC PANEL/ SEALED ENG (11500) A1 / AFT STEP LT @(11530) / DOOR OPTION SPLICE %(10389) A / SKIRT LT @(1531) / GROUND/PWR SPLICE (11509) CH3_49 / B120AL 16LTGN / B63UB 18DKBL / B125RA 18GY / PTI CONTROL RELAY (10309-R6) CH8_11 / B63AJ 18DKBL / B131AA 18DKBL / B63D 18DKBL / CROSSING GATE RELAY (10313-R1) CH9_11 / B119S 16GY / DIODE B3-D (10304) CH18_04 / DIODE B3-D (10304) CH18_26 / REAR DOME LT RELAY (10311-R2) CH18_20 / B120A 18LTGN / B63U 18DKBL / FR DOME LT RELAY (10311-R3) CH8_20,21 / B63V 18DKBL / REAR DOME LT RELAY (10311-R2) CH8_21 / Figure 378 / STEPWELL LIGHTS

8.32. STEPWELL LIGHTS (CONT.), P. 23
Figure 379 STEPWELL LIGHTS (CONT.)

Components: ALARM RELAY (10310-R6); DOOR SW O/P (11641); FUSE B6-G (10303); OPTION (10380); OUTPUT (10202); RELAY (10309-R3); SPLICE (10389)
Wires (circuit gauge+color): B117B 18GY; B117CC 18GY; B12AA 18LTBL; B12AB 18LTBL; B131A 16DKBL; B131BC 16DKBL
See also sheets: CH18_01, CH18_12, CH3_14, CH7_66, CH8_22, CH8_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.32. STEPWELL LIGHTS (CONT.), P. 23 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 29DEC20 / STEP WELL LIGHTS (CONT.) / CHAPTER 8 / MJV0488 19NOV21 CIRC B131BC WAS B131B B AT R/D 10389. / B131BC 16DKBL / CHILD MONITOR DOOR SW O/P (11641) CH18_01 / B12AA 18LTBL / *B131A 16DKBL / STEPWELL LIGHT RELAY (10309-R3) / DOME LT OUTPUT (10202) CH8_35 CL LT OPTION (10380) CH7_66 / DOOR OPTION SPLICE (10389) CH8_22 / &&B131A 16DKBL / FUSE B6-G (10303) CH3_14 / && W/STEPWELL LT WIRED TO ENTRY DOOR W/ACCESSORY @ W/STEPWELL LT WIRED TO DOME LT * W/STEPWELL LT WIRED TO CLEARANCE LT / B12AB 18LTBL / CHILD SAFETY ALARM RELAY (10310-R6) CH18_12 / B117B 18GY / B117CC 18GY / @B131A 16DKBL / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 379 / STEPWELL LIGHTS (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 420 | printed page 380 | section 8.33
8.33. STEPWELL LIGHTS (CONT.), P. 23A
Figure 380 STEPWELL LIGHTS (CONT.)

Components: BODY CONTROLLER (1601); CL LT OPTION (10380); DIODE D73 (10307); DIODE D76 (10307); DOOR CONTROL RELAY1 (10309); DOOR CONTROL RELAY2 (10309); ELEC PANEL (11500); ELEC PANEL/FR CAP (10000); FR DOME LT RELAY (10311); FUSE F39 (10304); GATE RELAY (10307); GROUND SPLICE (10335B); OUTPUT (10202); PEDESTRIAN LT RELAY (10310); PEDESTRIAN LT TIMER (10282); PLATFORM/ELEC PANEL (1702); PTI CONTROL RELAY (10309); RELAY (10309); RELAY (10311); SPLICE (10389); SPLICE (11509)
Wires (circuit gauge+color): A120D 16LTGN; A120EE 16LTGN; A120EE 18LTGN; B117BA 18GY; B117C 18GY; B119S 16GY; B120-GK 18WH; B120-GL 18WH; B120A 18LTGN; B120AL 16LTGN; B120K 16LTGN; B120K 18LTGN; B120L 18LTGN; B120S 16LTGN; B120S 18LTGN; B125RA 18GY; B131A 16DKBL; B131AA 18DKBL; B131AB 18DKBL; B131BC 16DKBL; B131C 16DKBL; B63AJ 18DKBL; B63F 18DKBL; B63UB 18DKBL; Y131 16DKBL
See also sheets: CH16_27, CH18_35, CH18_53, CH18_54, CH3_49, CH9_11
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.33. STEPWELL LIGHTS (CONT.), P. 23A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF STEP WELL LIGHTS (CONT.) NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 16MAR21 / CHAPTER 8 / MJV0488 19NOV21 ADDED CIRC B63F IN CAV E AT R/D 10389. / DOOR CONTROL RELAY1 (10309) CH16_27 / B131BC 16DKBL B119S 16GY / Y131 16DKBL / SEALED ENG/ ELEC PANEL (11500) A1 / DOOR OPTION SPLICE (10389) A / G2 30 / B131C 16DKBL / DOOR CONTROL RELAY2 (10309) CH16_12A / PLATFORM/ELEC PANEL (1702) 74 / B120S 18LTGN B120S 16LTGN / B131A 16DKBL @B131A 16DKBL / STEPWELL LT RELAY (10309) / %B120K 18LTGN &B120K 18LTGN B120K 16LTGN / B120L 18LTGN / FUSE F39 (10304) CH3_94J DOME LT OUTPUT (10202) CH8_36A CL LT OPTION (10380) CH7_66A / A120D 16LTGN A120EE 16LTGN A120EE 18LTGN / MANUAL DOOR SW (3202B) CH16_27 J4-TAN BLUE BODY CONTROLLER (1601) CH16_12A / H2 86 / G1 H1 / &&B117BA 18GY B120-GK 18WH B120-GL 18WH B117C 18GY **B120AL 16LTGN ##B120AL 16LTGN B63UB 18DKBL B125RA 18GY B120A 18LTGN B131AB 18DKBL / B63F 18DKBL B63AJ 18DKBL / *B131A 16DKBL / CROSSING GATE RELAY (10307) CH9_11 / GROUND/PWR SPLICE (11509) CH3_49 # W/STEPWELL LT WIRED TO IGN % W/DOOR CONTROL W/MANUAL & W/DOOR CONTROL W/AIR OR ELEC ## W/PED LT W/SW ACT BY STEP LT / B131AA 18DKBL / DIODE D76 (10307) / Figure 380 / STEPWELL LIGHTS (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 421 | printed page 381 | section 8.34
8.34. PRIMARY SWITCH ILLUMINATION, P. 24
Figure 381 PRIMARY SWITCH ILLUMINATION

Components: DAY TIMER WEBASTO (11630); ELEC PANEL/PLATFORM (1702); FUSE A3-X (1016); FUSE F26 (1011); HAZARD LT SW (10256/10256B); ILLUM SPLICE (10366); NOISE SUPPRESSION SW (10264); NOISE SUPRESSION SW (10264); OPTION (10380); SPLICE (10328); SPLICE (10337); START (10237)
Wires (circuit gauge+color): A62A 18DKBL; A62AN 18DKBL; A62Z 16DKBL; B62-G 18WH; B62-GAC 18WH; B62-GAN 18WH; B62-GAV 18WH; B62-GAX 18WH; B62-GBF 18WH; B62-GBK 18WH; B62AC 18DKBL; B62ACA 18DKBL; B62AM 18DKBL; B62AN 18DKBL; B62AP 18DKBL; B62AX 18DKBL; B62BF 18DKBL; B62BK 18DKBL; B74K 18DKBL
See also sheets: CH19_61, CH3_02, CH3_21, CH3_41, CH6_20, CH7_65, CH7_66, CH8_28, CH8_29, CH8_30, CH8_31, CH8_32, CH8_33, CH8_34
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.34. PRIMARY SWITCH ILLUMINATION, P. 24 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 30DEC20 / CHAPTER 8 PRIMARY SWITCH ILLUMINATION / MJV0488 19NOV21 ADDED CIRC B62-GAV, B62ACA AT R/D 10237. / #B62AX 18DKBL #B62-GAX 18WH / 7 DAY TIMER WEBASTO (11630) CH19_61 NOISE SUPRESSION SW (10264) CH3_21,94U HAZARD LT SW (10256/10256B) CH7_65 / !B62-GAV 18WH &B62-GAC 18WH #B62-G 18WH *B62-G 18WH %B62-GBF 18WH #B62-GBK 18WH / NOISE SUPPRESSION SW (10264) CH3_21,94U HAZARD LT SW (10256/10256B) CH7_65 / DIMMER UNIT #(10372) B C A / @B62-GAN 18WH / @B62AP 18DKBL / GROUND SPLICE (10337) CH3_41,95L / CL LT OPTION (10380) CH7_66 / YEL LBLU / @B62AN 18DKBL / &B74K 18DKBL #B62BF 18DKBL #B62BK 18DKBL !B62ACA 18DKBL / PRIMARY SW ILLUM SPLICE (10366) D / FLASHER START (10237) CH6_20 / Figure 381 / PRIMARY SWITCH ILLUMINATION

8.35. PANEL LIGHTS, P. 25
Figure 382 PANEL LIGHTS

Components: ARENS SHIFT SELECTOR A (7808); AUTO XMSN PANEL LT (1501); CLOCK SPRING (1832); EATON PROCISION PUSH BUTTON SHIFTER (7905A); FUSE A3-X (1016); L HAND DEFOG FAN SW (1135); L HAND DEFOG FAN SW (1135A); LCT XMSN PARK SW AND PANEL LT (1830); PANEL LTS SPLICE PACK (9995); R HAND DEFOG FAN SW (1136); R HAND DEFOG FAN SW (1136A); R SW PANEL LTS (1002B); SHIFT SELECTOR (1850); SPLICE (1002A); SW PACK (1101)
Wires (circuit gauge+color): A62A 14DKBL; A62C 18DKBL; A62D 18DKBL; A62E 18DKBL; A62F 18DKBL; A62G 18DKBL; A62GK 16DKBL; A62H 18DKBL; A62K 20DKBL; A62L 18DKBL; A62Z 16DKBL; A62ZA 18DKBL; A92NE 18DKBL
See also sheets: CH12_03, CH12_04, CH12_24, CH19_26, CH19_27, CH27_27, CH3_02, CH8_26, CH8_27, CH8_51, CH8_53
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.35. PANEL LIGHTS, P. 25 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 96275E 10AUG21 / PANEL LIGHTS / CHAPTER 8 / MJV0488 22SEP21 ADDED CHAPTER 27 AT FUSE A3-X. / */@A62C 18DKBL #A92NE 18DKBL W/ARENS SHIFTER / *A62H 18DKBL *A62K 20DKBL *A62A 14DKBL / PANEL LTS SPLICE (1002A) A / !A62Z 16DKBL / *A62GK 16DKBL / *A62L 18DKBL W/EATON XMSN #A62C 18DKBL / *A62G 18DKBL / #A62ZA 18DKBL !A62ZA 18DKBL / */%%A62E 18DKBL / L HAND DEFOG FAN SW (1135) CH19_26 L HAND DEFOG FAN SW (1135A) CH19_27 R HAND DEFOG FAN SW (1136) CH19_27 R HAND DEFOG FAN SW (1136A) CH19_26 / */&A62E 18DKBL / A62D 18DKBL / Figure 382 / PANEL LIGHTS

8.36. PANEL LIGHTS (CONT.), P. 26
Figure 383 PANEL LIGHTS (CONT.)

Components: DOOR CONTROL SW (3201); FLASHER START SW (1138); PANEL LTS SPLICE (1002A); R MASTER FLASHER SW (1137); R STOP ARM CANCEL SW (1140); RED OVERRIDE SW (1139); REDNDUNT DOOR CONTROL SW (3203); REDUNDANT DOOR SW (3203); SPLICE (1002B); STUD (4037Z); STUD (4037ZE)
Wires (circuit gauge+color): A11-GK 16WH; A120-GM 18WH; A62-GN 18WH; A62-GP 18WH; A62-GT 18WH; A62GK 16DKBL; A62M 18DKBL; A62N 18DKBL; A62P 18DKBL; A62R 18DKBL; A62R-G 18WH; A62S 18DKBL; A62S-G 18WH; A62T 18DKBL
See also sheets: CH16_02, CH16_07, CH3_95, CH6_19, CH6_20, CH6_22, CH8_25, CH9_05
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.36. PANEL LIGHTS (CONT.), P. 26 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 30DEC20 / PANEL LIGHTS (CONT.) / CHAPTER 8 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / !A62S 18DKBL / !A62S-G 18WH !A62-GT 18WH / PANEL LTS SPLICE (1002B) A / !A62T 18DKBL / !A62P 18DKBL !A62M 18DKBL / FLASHER START SW (1138) CH6_20 RED OVERRIDE SW (1139) CH6_22 / !A62R 18DKBL / PANEL LTS SPLICE (1002A) CH8_25 R MASTER FLASHER SW (1137) CH6_19 / !A62R-G 18WH / !A62GK 16DKBL / !A62N 18DKBL / !A62-GP 18WH / R STOP ARM CANCEL SW (1140) CH9_05 DOOR CONTROL SW (3201) CH16_02 REDNDUNT DOOR CONTROL SW (3203) CH16_07 / !A120-GM 18WH !A62-GN 18WH / &A11-GK 16WH / GROUND STUD (4037ZE) GROUND STUD (4037Z) CH3_95 / @A11-GK 16WH / Figure 383 / PANEL LIGHTS (CONT.)

8.37. PANEL LIGHTS (CONT.), P. 27
Figure 384 PANEL LIGHTS (CONT.)

Components: COOLANT HTR W/TIMER (9997); HTR W/TIMER (9996); PANEL LT SPLICE (1002A); SPLICE (1002A); SPLICE PACK (9995)
Wires (circuit gauge+color): A62-GL 18WH; A62A 14DKBL; A62L 18DKBL; A74A 18DKBL
See also sheets: CH19_12, CH19_62, CH3_31, CH8_25
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.37. PANEL LIGHTS (CONT.), P. 27 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 30DEC20 / PANEL LIGHTS (CONT.) / CHAPTER 8 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PANEL LTS SPLICE PACK (9995) / &A62A 14DKBL / &A74A 18DKBL / &A62L 18DKBL / PANEL LT SPLICE (1002A) CH8_25 ESPAR COOLANT HTR W/TIMER (9996) CH19_12 COOLANT HTR W/TIMER (9997) CH19_62 AMMETER(-) (52) W/2017/2021 ISB/B6.7 DIESEL ENGINE / B - / A + / &A62-GL 18WH / GROUND SPLICE PACK # 4 (1003) CH3_31,95A / *A62-GL 18WH / GROUND SPLICE # 2 (1004) CH3_31,95A / *A62L 18DKBL / PANEL LT SPLICE (1002A) CH8_25 / #A74A 18DKBL / W/F-2018-PROPANE/GASOLINE ENGINE / Figure 384 / PANEL LIGHTS (CONT.)

8.38. SWITCH PANEL ILLUMINATION, P. 28
Figure 385 SWITCH PANEL ILLUMINATION

Components: DOME LT (10230); ILLUM SPLICE (10366); LUGGAGE BOX LT (10268); RHEOSTAT DIMMER (10376); SPLICE (10328); SPLICE (10399); STD / DOME LT (10230); STEPWELL HTR (10258); STEPWELL HTR FAN (10258); SW ILLUM SPLICE (10399)
Wires (circuit gauge+color): B62-GAX 18WH; B62-GAZ 18WH; B62-GBH 18WH; B62-GBP 18WH; B62-GJ 18WH; B62-GU 18WH; B62-GX 18WH; B62AX 18DKBL; B62AZ 18DKBL; B62BH 18DKBL; B62BP 18DKBL; B62J 18DKBL; B62U 18DKBL; B62X 18DKBL
See also sheets: CH19_35, CH7_63, CH7_64, CH8_07, CH8_13, CH8_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.38. SWITCH PANEL ILLUMINATION, P. 28 / CHAPTER 8 SWITCH PANEL ILLUMINATION / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SW ILLUM SPLICE (10328) / B62-GAZ 18WH / B62-GAX 18WH / B62-GJ 18WH / B62J 18DKBL / STD / DOME LT (10230) CH8_13,14,13A,14A STEPWELL HTR (10258) CH19_35 PRIMARY SW ILLUM SPLICE (10366) CH8_24 SW ILLUM SPLICE (10399) CH7_63 / B62AZ 18DKBL / B62AX 18DKBL / B62U 18DKBL / LUGGAGE BOX LT (10268) CH7_64 RHEOSTAT DIMMER (10376) CH8_07 / B62-GU 18WH / B62BP 18DKBL / PRIMARY SW ILLUM SPLICE (10366) CH8_24 STEPWELL HTR FAN (10258) CH19_35 STD / FR DOME LT (10230) CH8_13,14,13A, 14A / B62-GBP 18WH / B62-GX 18WH / B62X 18DKBL / SW ILLUM SPLICE (10399) CH7_63 / RHEOSTAT DIMMER (10376) CH8_07 LUGGAGE BOX LT (10268) CH7_64 / B62BH 18DKBL / B62-GBH 18WH / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 385 / SWITCH PANEL ILLUMINATION

8.39. SWITCH PANEL ILLUMINATION (CONT.), P. 29
Figure 386 SWITCH PANEL ILLUMINATION (CONT.)

Components: AIR HORN (10286); BOTTOM STEP HTR SW (10228); DRIVERS HTR SW (10229); FLASHER CANCEL (10239); GATE CANCEL (10241); PRIMARY SW ILLUM SPLICE (10366); SPLICE (10327); SPLICE (10366); STROBE LT INTENSITY (10242); SW ILLUM SPLICE (10399)
Wires (circuit gauge+color): B62-GA 18WH; B62-GAD 18WH; B62-GAX 18WH; B62-GAY 18WH; B62-GB 18WH; B62-GBH 18WH; B62-GD 18WH; B62-GE 18WH; B62-GH 18WH; B62A 18DKBL; B62AD 18DKBL; B62AX 18DKBL; B62AY 18DKBL; B62B 18DKBL; B62BH 18DKBL; B62D 18DKBL; B62E 18DKBL; B62H 18DKBL
See also sheets: CH13_09, CH19_11, CH19_33, CH6_15, CH7_63, CH8_24, CH9_04, CH9_12
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.39. SWITCH PANEL ILLUMINATION (CONT.), P. 29 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 30DEC20 / CHAPTER 8 SWITCH PANEL ILLUMINATION (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SW ILLUM SPLICE (10327) A / #B62-GAY 18WH / B62-GAX 18WH / #B62-GA 18WH / #B62A 18DKBL / #B62AY 18DKBL / B62AX 18DKBL / #B62B 18DKBL / #B62-GB 18WH / #B62H 18DKBL / @B62-GAD 18WH %B62-GD 18WH #B62-GH 18WH / @B62AD 18DKBL %B62D 18DKBL #B62E 18DKBL / #B62-GE 18WH / B62BH 18DKBL / SW ILLUM SPLICE (10399) CH7_63 / B62-GBH 18WH / SW ILLUM SPLICE (10399) CH7_63 / Figure 386 / SWITCH PANEL ILLUMINATION (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 427 | printed page 387 | section 8.40
8.40. SWITCH PANEL ILLUMINATION (CONT.), P. 30
Figure 387 SWITCH PANEL ILLUMINATION (CONT.)

Components: DOOR CONTROL SW (10200); FLASHER CANCEL SW (10239); ILLUM SPLICE (10366); LIFT SW (10281); POST TRIP INDICATOR (10387); PWR VENT SW (10226/10227); REDUNDANT DOOR SW (10365); SPLICE (10329); SPLICE (10399); VENT SW (10226/10227)
Wires (circuit gauge+color): B62-BG 18DKBL; B62-GAA 18DKBL; B62-GAB 18WH; B62-GAC 18WH; B62-GAD 18WH; B62-GAX 18WH; B62-GBA 18WH; B62-GBH 18WH; B62-GY 18WH; B62-GZ 18WH; B62AB 18DKBL; B62AC 16LTGN; B62AC 18DKBL; B62AD 18DKBL; B62AX 18DKBL; B62BA 18DKBL; B62BH 18DKBL; B62Y 18DKBL; B62Z 18DKBL
See also sheets: CH15_03, CH16_01, CH16_06, CH19_41, CH6_16, CH7_63, CH8_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.40. SWITCH PANEL ILLUMINATION (CONT.), P. 30 / CHAPTER 8 SWITCH PANEL ILLUMINATION (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SW ILLUM SPLICE (10329) A / #B62-GBA 18WH / B62-GAX 18WH / #B62-GY 18WH / #B62Y 18DKBL / #B62BA 18DKBL / B62AX 18DKBL / PRIMARY SW ILLUM SPLICE (10366) CH8_24 SW ILLUM SPLICE (10399) CH7_63 / #B62Z 18DKBL #B62AC 16LTGN #B62-BG 18DKBL #B62AC 18DKBL #B62AB 18DKBL #B62AC 18DKBL / DOOR CONTROL SW (10200) CH16_01 REDUNDANT DOOR SW (10365) CH16_06 POST TRIP INDICATOR (10387) CH18_4D FR/REAR PWR VENT SW (10226/10227) CH19_41 / #B62-GAB 18WH @B62-GAA 18DKBL #B62-GZ 18WH / #B62-GAC 18WH / #B62AD 18DKBL / #B62-GAD 18WH / REDUNDANT DOOR SW (10365) CH16_06 DOOR CONTROL SW (10200) CH16_01 / FR/REAR PWR VENT SW (10226/10227) CH19_41 / PRIMARY SW ILLUM SPLICE (10366) CH8_24 / B62BH 18DKBL / SW ILLUM SPLICE (10399) CH7_63 / B62-GBH 18WH / FLASHER CANCEL SW (10239) CH6_16,17,18,20 / LIFT SW (10281) CH15_03 / @ W/CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK # W/CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK / Figure 387 / SWITCH PANEL ILLUMINATION (CONT.)

8.41. SWITCH PANEL ILLUMINATION (CONT.), P. 31
Figure 388 SWITCH PANEL ILLUMINATION (CONT.)

Components: DRIVERS DOME LT (10234); FLASHER CANCEL (10239); FLASHER OVERRIDE (10238); HEATED MIRROR (10293); ILLUM SPLICE (10366); MASTER DISCONNECT SW (10257); MASTER FLASHER SW (10236); MASTER FLASTER SW (10236); MASTER WARN CANCEL (10236A); MIRROR SW (10353/10354); SPLICE (10330); SPLICE (10366); SW ILLUM (10399); SW ILLUM SPLICE (10399)
Wires (circuit gauge+color): B62-AG 18DKBL; B62-GAC 16LTGN; B62-GAC 18WH; B62-GAD 18WH; B62-GAG 18WH; B62-GAJ 18WH; B62-GAR 18WH; B62-GAS 18WH; B62-GAW 18WH; B62-GAX 18WH; B62-GBB 18WH; B62-GBG 18WH; B62-GBH 18WH; B62AC 18DKBL; B62AD 18DKBL; B62AJ 18DKBL; B62AR 18DKBL; B62AS 18DKBL; B62AT 18DKBL; B62AU 20DKBL; B62AV 20DKBL; B62AW 18DKBL; B62AX 18DKBL; B62BB 18DKBL; B62BH 18DKBL
See also sheets: CH10_01, CH10_02, CH16_32, CH3_24, CH6_15, CH6_16, CH6_21, CH7_63, CH8_11, CH8_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.41. SWITCH PANEL ILLUMINATION (CONT.), P. 31 / CHAPTER 8 SWITCH PANEL ILLUMINATION (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SW ILLUM SPLICE (10330) A B / %B62-GBB 18WH / B62-GAX 18WH / %B62-GAG 18WH @B62-GAD 18WH %B62-GAW 18WH %B62-GAS 18WH %B62-GAJ 18WH / B62AX 18DKBL %B62AJ 18DKBL %B62AS 18DKBL %B62AU 20DKBL %B62AV 20DKBL %B62AW 18DKBL / %B62BB 18DKBL / %B62AC 18DKBL / %B62-AG 18DKBL @B62AD 18DKBL %B62-GAC 18WH %B62-GAR 18WH / %B62AT 18DKBL / B62BH 18DKBL / B62-GBH 18WH / %B62AR 18DKBL / FLASHER CANCEL (10239) CH6_16,17,18,24 / Figure 388 / SWITCH PANEL ILLUMINATION (CONT.)

Components: BOOSTER PUMP SW (10255); HTR 2 SW (10246B); HTR SW (10243B); ILLUM SPLICE (10366); L FR HTR SW (10243A); PTI ACTIVE INDICATER LT (14601); SPLICE (10331); SPLICE (10399)
Wires (circuit gauge+color): B125-G 18WH; B62-GA 18WH; B62-GAX 18WH; B62-GBC 18WH; B62-GBH 18WH; B62-GC 18WH; B62-GK 18WH; B62-GL 18WH; B62-GT 18WH; B62A 18DKBL; B62AX 18DKBL; B62BC 18DKBL; B62BH 18DKBL; B62C 18DKBL; B62K 18DKBL; B62L 18DKBL; B62T 18DKBL
See also sheets: CH18_22, CH19_01, CH19_02, CH19_21, CH19_24, CH7_63, CH8_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.42. SWITCH PANEL ILLUMINATION (CONT.), P. 32 / CHAPTER 8 SWITCH PANEL ILLUMINATION (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SW ILLUM SPLICE (10331) A / %B62-GBC 18WH / B62-GAX 18WH / %B62-GC 18WH / %B62C 18DKBL / %B62BC 18DKBL / B62AX 18DKBL / SW ILLUM SPLICE (10399) CH7_63 PRIMARY SW ILLUM SPLICE (10366) CH8_24 BOOSTER PUMP SW (10255) CH19_01,02,03,04,05, 06,07,08,09 BOOSTER PUMP SW (10255) CH19_02 / R REAR HTR 2 SW (10246B) CH19_24 / @B125-G 18WH / %B62T 18DKBL / %B62-GT 18WH / L FR HTR SW (10243B) CH19_21 / %B62-GK 18WH / %B62K 18DKBL / %B62L 18DKBL / %B62-GL 18WH / B62BH 18DKBL / B62-GBH 18WH / %B62A 18DKBL / %B62-GA 18WH / @ W/CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK % W/CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK / L FR HTR SW (10243A) CH19_21 / Figure 389 / SWITCH PANEL ILLUMINATION (CONT.)

8.43. SWITCH PANEL ILLUMINATION (CONT.), P. 33
Figure 390 SWITCH PANEL ILLUMINATION (CONT.)

Components: CONVECTION HTR SW (10253); ILLUM SPLICE (10366); L REAR HTR SW (10244A); L REAR HTR SW (10244B); R FR HTR SW (10245A); R FR HTR SW (10245B); R REAR HTR SW (10246A); SPLICE (10332); SPLICE (10399)
Wires (circuit gauge+color): B62-GAX 18WH; B62-GBD 18WH; B62-GBH 18WH; B62-GBJ 18WH; B62-GM 18WH; B62-GN 18WH; B62-GP 18WH; B62-GR 18WH; B62-GS 18WH; B62AX 18DKBL; B62BD 18DKBL; B62BH 18DKBL; B62BJ 18DKBL; B62M 18DKBL; B62N 18DKBL; B62P 18DKBL; B62R 18DKBL; B62S 18DKBL
See also sheets: CH19_22, CH19_23, CH19_24, CH19_34, CH7_63, CH8_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.43. SWITCH PANEL ILLUMINATION (CONT.), P. 33 / CHAPTER 8 SWITCH PANEL ILLUMINATION (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SW ILLUM SPLICE (10332) / B62-GBD 18WH / B62-GAX 18WH / B62-GM 18WH / B62M 18DKBL / B62BD 18DKBL / B62AX 18DKBL / B62P 18DKBL / B62-GP 18WH / B62R 18DKBL / B62-GR 18WH / R REAR HTR SW (10246A) CH19_24 / B62S 18DKBL B62-GS 18WH / B62N 18DKBL B62BJ 18DKBL / B62-GN 18WH B62-GBJ 18WH / B62BH 18DKBL / B62-GBH 18WH / R FR HTR SW (10245B) CH19_23 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 390 / SWITCH PANEL ILLUMINATION (CONT.)

8.44. SWITCH PANEL ILLUMINATION (CONT.), P. 34
Figure 391 SWITCH PANEL ILLUMINATION (CONT.)

Components: ACTIVITY DOME LT SW (10232); DESTINATION SIGN 2 SW (10267B); DESTINATION SIGN 2 SW (16267B); DESTINATION SIGN SW (10267A); GUARD DOME LT SW (10235); ILLUM SPLICE (10366); REAR ROW DOME LT SW (10233); SPLICE (10333); SPLICE (10399); STROBE LT SW (10270)
Wires (circuit gauge+color): B62-GAE 18WH; B62-GAF 18WH; B62-GAH 18WH; B62-GAK 18WH; B62-GAL 18WH; B62-GAX 18WH; B62-GBE 18WH; B62-GBH 18WH; B62-GW 18WH; B62AE 18DKBL; B62AF 18DKBL; B62AH 18DKBL; B62AK 18DKBL; B62AL 18DKBL; B62AX 18DKBL; B62BE 18DKBL; B62BH 18DKBL; B62W 18DKBL
See also sheets: CH7_07, CH7_11, CH7_63, CH8_01, CH8_02, CH8_08, CH8_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.44. SWITCH PANEL ILLUMINATION (CONT.), P. 34 / CHAPTER 8 SWITCH PANEL ILLUMINATION (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SW ILLUM SPLICE (10333) A / B62-GBE 18WH / B62-GAX 18WH / B62-GW 18WH / B62W 18DKBL / SW ILLUM SPLICE (10399) CH7_63 PRIMARY SW ILLUM SPLICE (10366) CH8_24 STROBE LT SW (10270) CH7_11,12,13,14,17,12A DESTINATION SIGN SW (10267A) CH7_07,08 / B62BE 18DKBL / B62AX 18DKBL / B62AE 18DKBL / B62-GAE 18WH / B62AF 18DKBL / B62-GAF 18WH / B62-GAH 18WH / B62AH 18DKBL / B62AK 18DKBL B62AL 18DKBL / B62-GAK 18WH / B62-GAL 18WH / B62BH 18DKBL / B62-GBH 18WH / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 391 / SWITCH PANEL ILLUMINATION (CONT.)

8.45. DOME LIGHT FEED, P. 35
Figure 392 DOME LIGHT FEED

Components: ACTIVITY DOME LT SW (10232); CHILD MONITER RELAY (10313-R6); DOME LT RH (10215C); ELEC PANEL/L BODY (10401); FR DOME LT RELAY (10311-R3); FUSE B3-J (10304); FUSE B9-V (10302); GUARD DOME LT SW (10235); LT SW (10233); MIN TIMER RELAY (10313-R3); OUTPUT (10202); PTI CONTROL RELAY (10309-R6); PWR (10201); R DOME LT RELAY (10311-R2); REAR DOME LT SW (10231); REAR ROW DOME LT RELAY (10311-R1); REAR ROW DOME LT RELAY (10311-R2); S DOME LT SW (10234); STD/FR DOME LT (10230); STD/FR DOME LT SW (10230); STEP WELL LT RELAY (10309-R3)
Wires (circuit gauge+color): B131A 16DKBL; B63A 12DKBL; B63A 14DKBL; B63A 16DKBL; B63AA 14DKBL; B63AA 16DKBL; B63AC 16DKBL; B63AE 18DKBL; B63AK 18DKBL; B63B 16DKBL; B63C 16DKBL; B63D 14DKBL; B63D 16DKBL; B63E 14DKBL; B63F 16DKBL; B63M 16DKBL; B63N 16DKBL; B63P 16DKBL; B63RC 12DKBL; B63RJ 12DKBL; B63S 16DKBL; B63T 12DKBL; B63T 16DKBL; B63T 16LTBL; B63W 16DKBL; B63W 18DKBL
See also sheets: CH18_03, CH18_07, CH18_08, CH18_15, CH18_19, CH18_36, CH3_07, CH3_13, CH8_01, CH8_02, CH8_07, CH8_08, CH8_10, CH8_11, CH8_13, CH8_14, CH8_15, CH8_19, CH8_20, CH8_23, CH8_37, CH8_56
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.45. DOME LIGHT FEED, P. 35 / DOME LIGHT FEED / CHAPTER 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. DOME LT PWR (10201) A / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / F G / B63F 16DKBL B63D 16DKBL B63RJ 12DKBL / C D / DOME LT OUTPUT (10202) A / &B63A 12DKBL %B63A 12DKBL @B63A 12DKBL B63B 16DKBL B63C 16DKBL B63AK 18DKBL &&B63W 18DKBL **B63W 16DKBL B63AA 14DKBL B63AC 16DKBL B63AE 18DKBL B63AA 16DKBL / % W/BATT @ W/IGN # W/RHEOSTAT & SINGLE SW * N/RHEOSTAT & W/RHEOSTAT & BATT ## W/RHEOSTAT & DUAL SW && DOME LT RR COMMON ** RR FEED / B63M 16DKBL / B63A 16DKBL B63C 16DKBL B63P 16DKBL B63N 16DKBL / B63F 16DKBL B63B 16DKBL / STD/FR DOME LT (10230) CH8_14 / Figure 392 / DOME LIGHT FEED

8.46. DOME LIGHT FEED (CONT.), P. 36
Figure 393 DOME LIGHT FEED (CONT.)

Components: CHILD CHECKMATE RELAY (10310-R2); DOME LT RELAY (10313-R5); DOME LT RH (10215D); DOME LT TIMER RELAY (10397); ELEC PANEL/L BODY (10401); FR DOME LT RELAY (10311-R3); OUTPUT (10202); REAR DOME LT RELAY (10311-R2); REAR DOME LT SW (10231); REAR ROW DOME LT RELAY (10311-R1); STD/FR DOME LT (10230)
Wires (circuit gauge+color): B63AN 16DKBL; B63AP 16DKBL; B63C 14DKBL; B63C 16DKBL; B63D 14DKBL; B63E 16DKBL; B63N 16DKBL; B63NA 16DKBL; B63NB 16DKBL; B63NC 14DKBL; B63R 16DKBL; B63RD 12DKBL; B63RK 12DKBL; B63S 16DKBL; B63S 16LTBL; B63SA 14DKBL; B63T 16DKBL; B63W 14DKBL
See also sheets: CH18_03, CH18_07, CH18_08, CH18_15, CH18_19, CH18_31, CH18_36, CH8_07, CH8_13, CH8_14, CH8_15, CH8_16, CH8_17, CH8_18, CH8_37
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.46. DOME LIGHT FEED (CONT.), P. 36 / DOME LIGHT FEED (CONT.) / CHAPTER 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. DOME LIGHT OUTPUT (10202) / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 23MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR DOME LT SW (10231) CH8_14 DOME LT RH (10215D) CH8_07 ELEC PANEL/L BODY (10401) CH8_37,38,39, 40,44,46,47 28,30,31,33 / *B63E 16DKBL ##B63RK 12DKBL #B63RD 12DKBL B63R 16DKBL / %B63AP 16DKBL @B63E 16DKBL %B63AN 16DKBL B63AN 16DKBL B63AN 16DKBL / F G / STD/FR DOME LT (10230) CH8_13,14 / B63S 16DKBL B63S 16DKBL B63S 16LTBL B63S 16LTBL B63C 14DKBL B63C 16DKBL B63D 14DKBL B63D 14DKBL / DOME LT RELAY (10313-R5) CH8_17 / B63NA 16DKBL B63W 14DKBL B63N 16DKBL B63NB 16DKBL B63NC 14DKBL / B63T 16DKBL / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / % W/DELUX DOME LT @ W/SINGLE DOME LT # W/RHEOSTAT & SINGLE SW * N/RHEOSTAT ##W/RHEOSTAT & DUAL SW / B63SA 14DKBL / FR DOME LT RELAY (10311-R3) CH18_03,04 / Figure 393 / DOME LIGHT FEED (CONT.)

8.47. DOME LIGHT FEED (CONT.), P. 36A
Figure 394 DOME LIGHT FEED (CONT.)

Components: ACTIVITY DOME LT (10232); DOME LT (10233); DOME LT RHEOSTAT (10215C); ELEC PANEL/L BODY (10401); FR DOME LT RELAY (10311); FUSE F17 (10302); FUSE F25 (10303); GUARD DOME LT (10235); LT RELAY (10311); MIN TIMER RELAY (10311); OUTPUT (10202); PTI CONTROL RELAY (10309-R6); PTI RELAY (10309); PWR (10201); REAR DOME LT (10231); REAR DOME LT RELAY (10311); REAR ROW DOME LT RELAY (10311); S DOME LT (10234); STD/FR DOME LT (10230); STD/FR DOME LT SW (10230); STEPWELL LT RELAY (10309)
Wires (circuit gauge+color): B131A 16DKBL; B63A 12DKBL; B63A 14DKBL; B63A 16DKBL; B63AA 14DKBL; B63AA 16DKBL; B63AC 16DKBL; B63AE 18DKBL; B63AK 18DKBL; B63B 16DKBL; B63C 16DKBL; B63D 14DKBL; B63D 16DKBL; B63E 14DKBL; B63F 16DKBL; B63M 16DKBL; B63RC 12DKBL; B63RJ 12DKBL; B63S 16DKBL; B63T 16DKBL; B63T 16LTBL; B63W 16DKBL; B63W 18DKBL
See also sheets: CH18_41, CH18_42, CH18_51, CH18_53, CH18_54, CH8_01, CH8_02, CH8_07, CH8_37, CH8_56
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.47. DOME LIGHT FEED (CONT.), P. 36A / DOME LIGHT FEED (CONT.) / CHAPTER 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. DOME LT PWR (10201) A / MJV0488 19NOV21 ADDED CIRC B63T IN R/D 10202 IN CAV C. / F G / B63F 16DKBL #B63RC 12DKBL *B63D 16DKBL / C D / DOME LT OUTPUT (10202) A / B63D 16DKBL ##B63RJ 12DKBL B63A 14DKBL B63S 16DKBL B63B 16DKBL B63T 16DKBL B63D 14DKBL B63D 16DKBL B63E 14DKBL B63T 16LTBL / &B63A 12DKBL %B63A 12DKBL @B63A 12DKBL B63B 16DKBL B63C 16DKBL B63AK 18DKBL &&B63W 18DKBL **B63W 16DKBL B63AA 14DKBL B63AC 16DKBL B63AE 18DKBL B63AA 16DKBL / % W/BATT @ W/IGN # W/RHEOSTAT & SINGLE SW * N/RHEOSTAT & W/RHEOSTAT & BATT ## W/RHEOSTAT & DUAL SW && W/DOME LT REAR ROW COMMON ** W/REAR ROW FEED / B63M 16DKBL / B63A 16DKBL B63C 16DKBL / B63B 16DKBL B63F 16DKBL / Figure 394 / DOME LIGHT FEED (CONT.)

8.48. DOME LIGHT FEED (CONT.), P. 36B
Figure 395 DOME LIGHT FEED (CONT.)

Components: DOME LT RHEOSTAT (10215D); ELEC PANEL/L BODY (10401); FR DOME LT RELAY (10311); LT SW (10231); OUTPUT (10202); REAR DOME LT RELAY (10311); STD/FR DOME LT (10230)
Wires (circuit gauge+color): B63AN 16DKBL; B63AP 16DKBL; B63B 14DKBL; B63C 14DKBL; B63C 16DKBL; B63D 14DKBL; B63E 16DKBL; B63R 14DKBL; B63R 16DKBL; B63RD 12DKBL; B63RK 12DKBL; B63S 16LTBL; B63T 16DKBL
See also sheets: CH18_41, CH18_42, CH18_53, CH18_54, CH8_07, CH8_37
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.48. DOME LIGHT FEED (CONT.), P. 36B / DOME LIGHT FEED (CONT.) / CHAPTER 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 19MAR21 / MJV0488 19NOV21 ADDED CHAPTER CH18_53,54. / DOME LT OUTPUT (10202) F G / ELEC PANEL/L BODY (10401) CH8_37,38,39,40,44,46,47 / B63R 16DKBL / B63AP 16DKBL B63E 16DKBL B63AN 16DKBL / #B63RD 12DKBL *B63E 16DKBL ##B63RK 12DKBL / # W/RHEOSTAT & SINGLE SW * N/RHEOSTAT ##W/RHEOSTAT & DUAL SW / DOME LT RHEOSTAT (10215D) CH8_07 / REAR DOME LT SW (10231) CH8_14A / STD/FR DOME LT (10230) CH8_13A / B63S 16LTBL B63B 14DKBL B63T 16DKBL B63C 16DKBL B63D 14DKBL B63C 14DKBL B63R 14DKBL / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 395 / DOME LIGHT FEED (CONT.)

8.49. STANDARD STAGGER DOME LIGHT WITH REAR ROW, P. 37
Figure 396 STANDARD STAGGER DOME LIGHT WITH REAR ROW

Components: LEFT BODY (10401); OUTPUT (10202); REAR CAP (10405); REAR CAP (10700); RHEOSTAT (10216C); SECTION 11 (10762); SECTION 13 (10489); SECTION 3 (10758); SECTION 5 (10485); SECTION 7 (10760); SECTION 9 (10487); SPLICE (10482); SPLICE (10701); STRAGGER SECTION 1 (10483)
Wires (circuit gauge+color): B63F 16DKBL; B63R 16DKBL; B63RC 16DKBL; D63M 16DKBL; D63U 16DKBL; E63-GA 16WH; E63-GB 16WH; E63-GD 16WH; E63-GE 16WH; E63A 16DKBL; E63B 16DKBL; E63C 16DKBL; E63D 16DKBL; E63E 16DKBL; E63F 16DKBL; E63GC 16WH; E63K 16DKBL; E63L 16DKBL; E63M 16DKBL; E63U 16DKBL; F63-G 16WH; F63-GB 16WH; F63-GD 16WH; F63-GF 16WH; F63B 16DKBL; F63D 16DKBL; F63F 16DKBL; F63M 16DKBL; F63U 16DKBL
See also sheets: CH3_52, CH3_57, CH8_07, CH8_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.49. STANDARD STAGGER DOME LIGHT WITH REAR ROW, P. 37 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 8 / STANDARD STAGGER DOME LIGHT W/REAR ROW / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / W/5,6,9-13 WINDOW DOME LT STD STRAGGER SECTION 1 (10483) A / DOME LT SECTION 5 (10485) A / DOME LT SECTION 9 (10487) A / E63M 16DKBL / W/5,6,7,8 WINDOW W/5,6 WINDOW L BODY/ R BODY/ REAR CAP REAR CAP (10700) (10405) A2 B5 D63U 16DKBL / B2 D63M 16DKBL / F63U 16DKBL *F63U 16DKBL F63U 16DKBL / DOME LT SECTION 3 (10758) A / F63B 16DKBL / F63-GB 16WH W/7,8,9,10 WINDOW DOME LT SECTION 7 *F63M (10760) 16DKBL A F63D 16DKBL F63-GD 16WH / DOME LT SECTION 11 F63F (10762) 16DKBL *F63M A 16DKBL F63-GF 16WH / GROUND SPLICE (10701) CH3_52 / DOME LT SECTION 13 (10489) A / W/13 WINDOW E63F 16DKBL *E63L 16DKBL E63-GE 16WH / W/5,6 WINDOW W/7,8,9, 10-13 WINDOW / Figure 396 / STANDARD STAGGER DOME LIGHT WITH REAR ROW

8.50. STANDARD STAGGER SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW, P. 38
Figure 397 STANDARD STAGGER SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW

Components: L BODY (10401); OUTPUT (10202); REAR CAP (10405); REAR CAP (10700); RHEOSTAT (10216C); SECTION 11 (10762); SECTION 13 (10489); SECTION 3 (10758); SECTION 5 (10485); SECTION 7 (10760); SECTION 9 (10487); SPLICE (10482); SPLICE (10701); STAGGER SECTION 1 (10483)
Wires (circuit gauge+color): B63F 16DKBL; B63R 16DKBL; B63RC 16DKBL; D63AU 16DKBL; D63M 16DKBL; D63U 16DKBL; E63-GA 16WH; E63-GB 16WH; E63-GC 16WH; E63-GD 16WH; E63-GK 16WH; E63-GL 16WH; E63A 16DKBL; E63AU 16DKBL; E63B 16DKBL; E63C 16DKBL; E63D 16DKBL; E63E 16DKBL; E63K 16DKBL; E63L 16DKBL; E63M 16DKBL; E63P 16DKBL; E63R 16DKBL; E63S 16DKBL; E63T 16DKBL; E63U 16DKBL; F63-G 16WH; F63-GB 16WH; F63-GD 16WH; F63-GF 16WH; F63AU 16DKBL; F63B 16DKBL; F63D 16DKBL; F63J 16WH; F63M 16DKBL; F63N 16DKBL; F63U 16DKBL
See also sheets: CH3_52, CH3_57, CH8_07, CH8_35, CH8_46
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.50. STANDARD STAGGER SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW, P. 38 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 30DEC20 / CHAPTER 8 STANDARD STAGGER SWITCHED DOME LIGHT FRONT AND REAR W/REAR ROW / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/ L BODY (10401) E63B 16DKBL A1 @E63A B63F 16DKBL 16DKBL E63R 16DKBL A2 B63R E63P 16DKBL 16DKBL A7 #B63RC *E63K 16DKBL 16DKBL / *E63T 16DKBL E63S 16DKBL E63-GK 16WH DOME LT STD STAGGER SECTION 1 (10483) A / DOME LT SECTION 5 (10485) A / DOME LT SECTION 9 (10487) A / E63C 16DKBL E63-GB 16WH E63T 16DKBL E63D 16DKBL *E63R 16DKBL E63-GC 16WH / A7 E63M 16DKBL / L BODY / REAR CAP (10405) A8 E63AU 16DKBL @E63U 16DKBL E63U 16DKBL / E63R 16DKBL *E63E 16DKBL E63-GD 16WH *E63-GL 16WH / F63D R BODY / 16DKBL REAR CAP (10700) *F63AU 16DKBL F63AU 16DKBL / E63-GA 16WH / B3 D63AU 16DKBL B5 D63U 16DKBL B2 D63M 16DKBL / DOME LT SECTION 3 (10758) A / F63-GB 16WH W/ 5,6 WINDOW F63-G 16WH / DOME LT SECTION 7 (10760) A / F63D 16DKBL F63-GD 16WH / *F63J 16WH F63N 16DKBL F63-GF 16WH / DOME LT SECTION 11 (10762) A / F63U 16DKBL F63M 16DKBL *F63M 16DKBL / F63-G 16WH / GROUND SPLICE (10701) CH3_52 / GROUND SPLICE (10482) CH3_57 / DOME LT OUTPUT (10202) CH8_35,36, 36A,36B / DOME LT SECTION 13 (10489) A / 16DKBL *F63B / 16DKBL E63L / W/5,6 WINDOW / W/ 7,8 WINDOW / W/5,6 WINDOW / W/ 12,13 WINDOW / REAR ROW RHEOSTAT (10216C) CH8_07 / W/9-12 WINDOW / W/7,8 WINDOW / Figure 397 / STANDARD STAGGER SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW

8.51. STANDARD STAGGER SWITCHED DOME LIGHT FRONT AND REAR WITH REAR
Figure 398 STANDARD STAGGER SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW

Components: DOME LT SECTION 1 (10757); DOME LT SECTION 3 (10484); DOME LT SECTION 3 (10758); DOME LT SECTION 5 (10485); DOME LT SECTION 5 (10759); L BODY (10401); OUTPUT (10202); REAR CAP (10405); REAR CAP (10700); SPLICE (10482); SPLICE (10701); STAGGER SECTION 1 (10483)
Wires (circuit gauge+color): B63F 16DKBL; B63R 16DKBL; D63U 16DKBL; E63-GA 16WH; E63-GC 16WH; E63-GD 16WH; E63-GH 16WH; E63A 16DKBL; E63C 16DKBL; E63D 16DKBL; E63H 16DKBL; E63U 16DKBL; F63-G 16WH; F63-GA 16WH; F63-GB 16WH; F63-GC 16WH; F63A 16DKBL; F63B 16DKBL; F63C 16DKBL; F63U 16DKBL
See also sheets: CH3_52, CH3_57, CH8_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.51. STANDARD STAGGER SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW AND 6, P. 39 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 30DEC20 / CHAPTER 8 STANDARD STAGGER SWITCHED DOME LIGHT FRONT AND REAR W/REAR ROW W/6 WINDOW / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A1 B63F 16DKBL / E63A 16DKBL E63-GA 16WH DOME LT SECTION 3 (10484) A / DOME LT SECTION 5 (10485) A / A2 E63U B63R 16DKBL 16DKBL / E63H 16DKBL E63-GH 16WH / E63D 16DKBL E63-GD 16WH / L BODY / REAR CAP (10405) A2 D63U 16DKBL / E63-GC 16WH / DOME LT SECTION 1 (10757) A / F63A 16DKBL F63-GA 16WH / DOME LT SECTION 3 (10758) A / F63B 16DKBL F63-GB 16WH / F63C 16DKBL F63-GC 16WH / DOME LT SECTION 5 (10759) A / E63C 16DKBL / F63U 16DKBL / F63-G 16WH / GROUND SPLICE (10701) CH3_52 / GROUND SPLICE (10482) CH3_57 / ELEC PANEL / L BODY (10401) / DOME LT OUTPUT (10202) CH8_35,36, 36A,36B / DOME LT STD STAGGER SECTION 1 (10483) A / R BODY / REAR CAP (10700) / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 398 / STANDARD STAGGER SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW AND 6

8.52. DOUBLE DOME LIGHT WITH REAR ROW AND LEFT BODY, P. 40
Figure 399 DOUBLE DOME LIGHT WITH REAR ROW AND LEFT BODY

Components: DOME LT (10233); L BODY (10401); OUTPUT (10202); R BODY (10700); REAR CAP (10405); SECTION 1 (10483); SECTION 11 (10488); SECTION 13 (10489); SECTION 3 (10484); SECTION 5 (10485); SECTION 7 (10486); SECTION 9 (10487); SPLICE (10482)
Wires (circuit gauge+color): B63F 16DKBL; B63R 16DKBL; B63X 18DKBL; D63M 16DKBL; D63U 16DKBL; E63-GM 16WH; E63-GN 16WH; E63-GP 16WH; E63-GR 16WH; E63-GT 16WH; E63-GU 16WH; E63-GV 16WH; E63-GW 16WH; E63A 16DKBL; E63AA 16DKBL; E63AA 18DKBL; E63AB 16DKBL; E63AC 16DKBL; E63AD 16DKBL; E63AN 16DKBL; E63AP 16DKBL; E63AP 18DKBL; E63AR 16DKBL; E63AR 18DKBL; E63B 16DKBL; E63K 16DKBL; E63M 16DKBL; E63M 18DKBL; E63U 16DKBL; E63W 16DKBL; E63X 16DKBL; E63Y 16DKBL; E63Z 16DKBL
See also sheets: CH3_57, CH8_08, CH8_35, CH8_41
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.52. DOUBLE DOME LIGHT WITH REAR ROW AND LEFT BODY, P. 40 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 8 DOUBLE DOME LIGHT W/REAR ROW W/LEFT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / *E63AP 16DKBL E63Z 16DKBL E63-GR 16WH / E63-GM 16WH W/12 WINDOW *E63AP 18DKBL *E63AP 16DKBL E63AC 16DKBL E63-GV 16WH *E63-GU 16WH / DOME LT SECTION 9 (10487) A / DOME LT SECTION 11 (10488) A / E63-GP 16WH / E63Y 16DKBL / W/7-13 WINDOW DOME LT SECTION 7 (10486) A / DOME LT SECTION 3 (10484) A / L BODY / REAR CAP (10405) A7 / E63X 16DKBL / W/7,8 WINDOW E63-GT 16WH W/ 5,6 WINDOW DOME LT SECTION 5 (10485) A / DOME LT OUTPUT (10202) CH8_35,36, 36A,36B / DOME LIGHT STD STRAGGER SECTION 1 (10483) A / *E63-GV 16WH E63AA 16DKBL *E63AA 18DKBL #E63AA 16DKBL / B63R 16DKBL / E63AB 16DKBL *E63AP 16DKBL #E63AP 16DKBL E63-GU 16WH W/11 WINDOW / B63F 16DKBL / ELEC PANEL/ L BODY (10401) *E63K 16DKBL A7 B63X *E63AN 18DKBL 16DKBL / E63U 16DKBL / E63A 16DKBL E63W 16DKBL / * W/REAR ROW # W/RHEOSTAT / W/10,11 WINDOW *E63AR 16DKBL *E63AR 18DKBL E63M 16DKBL *E63M 18DKBL E63B 16DKBL W/ 10,11 WINDOW / REAR CAP / R BODY (10700) CH8_41,42,43,50 / D63M 16DKBL / D63U 16DKBL / DOME LT SECTION 13 (10489) A / *E63AD 16DKBL E63AD 16DKBL E63-GW 16WH / W/11 WINDOW W/11 WINDOW / REAR ROW DOME LT (10233) CH8_08,9A / Figure 399 / DOUBLE DOME LIGHT WITH REAR ROW AND LEFT BODY

8.53. DOUBLE DOME LIGHT WITH REAR ROW AND RIGHT BODY, P. 41
Figure 400 DOUBLE DOME LIGHT WITH REAR ROW AND RIGHT BODY

Components: R BODY (10700); REAR CAP (10405); SECTION 1 (10757); SECTION 11 (10762); SECTION 3 (10758); SECTION 5 (10759); SECTION 7 (10760); SECTION 9 (10761); SPLICE (10701)
Wires (circuit gauge+color): D63M 16DKBL; D63U 16DKBL; F63-G 16WH; F63-GA 16WH; F63-GB 16WH; F63-GC 16WH; F63-GD 16WH; F63-GE 16WH; F63-GF 16WH; F63A 16DKBL; F63B 16DKBL; F63C 16DKBL; F63D 16DKBL; F63E 16DKBL; F63F 16DKBL; F63M 16DKBL; F63U 16DKBL
See also sheets: CH3_52, CH8_40
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.53. DOUBLE DOME LIGHT WITH REAR ROW AND RIGHT BODY, P. 41 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 30DEC20 / CHAPTER 8 DOUBLE DOME LIGHT W/REAR ROW W/RIGHT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / *F63M 16DKBL *F63E 16DKBL F63E 16DKBL F63-GE 16WH / F63-GC 16WH / F63-GB 16WH *F63M 16DKBL F63C 16DKBL *F63C 16DKBL / DOME LT SECTION 11 (10762) A / DOME LT SECTION 5 (10759) A / GROUND F63-G SPLICE 16WH (10701) CH3_52 NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / DOME LT SECTION 1 *F63A (10757) 16DKBL A F63A 16DKBL F63-GA 16WH / DOME LT SECTION 7 (10760) A / L BODY/ REAR CAP (10405) CH8_40 / DOME LT SECTION 3 *F63B (10758) 16DKBL A F63B 16DKBL / W/7,8 WINDOW W/9,10 WINDOW DOME LT SECTION 9 (10761) A / *F63D 16DKBL F63D 16DKBL *F63M 16DKBL F63-GD 16WH / D63U 16DKBL / D63M 16DKBL / F63-GF 16WH / * W/REAR ROW / REAR CAP/ R BODY (10700) *F63U 16DKBL F63U 16DKBL / W/11,12 WINDOW W/13 WINDOW *F63F 16DKBL F63F 16DKBL *F63M 16DKBL / Figure 400 / DOUBLE DOME LIGHT WITH REAR ROW AND RIGHT BODY

8.54. DOUBLE DOME LIGHT WITH REAR ROW AND 12-13 WINDOW WITH RIGHT BODY, P. 42
Figure 401 DOUBLE DOME LIGHT WITH REAR ROW AND 12-13 WINDOW WITH RIGHT BODY

Components: DOME LT SECTION 1 (10757); R BODY (10700); REAR CAP (10405); SECTION 11 (10762); SECTION 12 (10763); SECTION 3 (10758); SECTION 5 (10759); SECTION 7 (10760); SECTION 9 (10761); SPLICE (10701)
Wires (circuit gauge+color): D63M 16DKBL; D63U 16DKBL; F63-G 12WH; F63-GA 16WH; F63-GB 16WH; F63-GC 16WH; F63-GD 16WH; F63-GE 16WH; F63-GF 16WH; F63-GH 16WH; F63A 16DKBL; F63B 16DKBL; F63C 16DKBL; F63D 16DKBL; F63E 16DKBL; F63F 16DKBL; F63G 10DKBL; F63H 16DKBL; F63M 16DKBL; F63U 16DKBL
See also sheets: CH3_52, CH8_40
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.54. DOUBLE DOME LIGHT WITH REAR ROW AND 12-13 WINDOW WITH RIGHT BODY, P. 42 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 30DEC20 / CHAPTER 8 DOUBLE DOME LIGHT W/REAR ROW W/12-13 WINDOW W/RIGHT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / %F63H 16DKBL F63-GH 16WH / F63-GD 16WH / F63D 16DKBL / DOME LT SECTION 9 (10761) A / F63-GC 16WH / DOME LT SECTION 7 (10760) A / GROUND SPLICE F63-G (10701) 12WH CH3_52 NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / F63B 16DKBL F63-GB 16WH / DOME LT SECTION 11 (10762) A / DOME LT SECTION 3 (10758) A / L BODY/ REAR CAP (10405) CH8_40 / DOME LT SECTION 12 (10763) A / DOME LT SECTION 5 (10759) A / D63U 16DKBL / F63F 16DKBL F63-GF 16WH / D63M 16DKBL / F63-GE 16WH / REAR CAP/ R BODY (10700) B5 / F63U 16DKBL / F63C 16DKBL / F63E 16DKBL / F63G 10DKBL / @F63M 16DKBL / F63A 16DKBL F63-GA 16WH / DOME LT SECTION 1 (10757) A / @ W/REAR ROW % W/STANDERD / Figure 401 / DOUBLE DOME LIGHT WITH REAR ROW AND 12-13 WINDOW WITH RIGHT BODY

8.55. DOUBLE DOME LIGHT WITH REAR ROW, 6 WINDOW AND RIGHT BODY, P. 43
Figure 402 DOUBLE DOME LIGHT WITH REAR ROW, 6 WINDOW AND RIGHT BODY

Components: DOME LT SECTION 1 (10757); DOME LT SECTION 3 (10758); DOME LT SECTION 5 (10759); R BODY (10700); REAR CAP (10405); SPLICE (10701)
Wires (circuit gauge+color): D63AU 16DKBL; D63M 16DKBL; D63U 16DKBL; F63-G 16WH; F63-GA 16WH; F63-GB 16WH; F63-GC 16WH; F63A 16DKBL; F63AU 16DKBL; F63B 16DKBL; F63M 16DKBL; F63U 16DKBL
See also sheets: CH3_52, CH8_40, CH8_44
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.55. DOUBLE DOME LIGHT WITH REAR ROW, 6 WINDOW AND RIGHT BODY, P. 43 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 30DEC20 / CHAPTER 8 DOUBLE DOME LIGHT W/REAR ROW W/6 WINDOW W/RIGHT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / F63-GA 16WH / F63A 16DKBL / F63-GB 16WH / DOME LT SECTION 1 (10757) A / F63-G 16WH / F63-GC 16WH / DOME LT SECTION 3 (10758) A / L BODY/ REAR CAP (10405) CH8_40,44 L BODY/ REAR CAP (10405) CH8_40 L BODY/ REAR CAP (10405) CH8_44 / DOME LT SECTION 5 (10759) A / GROUND SPLICE (10701) CH3_52 / D63U 16DKBL / D63M 16DKBL / REAR CAP/ R BODY (10700) B5 / F63U 16DKBL / F63B 16DKBL / F63M 16DKBL / D63AU 16DKBL / *F63AU 16DKBL / * W/REAR ROW / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 402 / DOUBLE DOME LIGHT WITH REAR ROW, 6 WINDOW AND RIGHT BODY

8.56. DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH LEFT BODY, P. 44
Figure 403 DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH LEFT BODY

Components: L BODY (10401); OUTPUT (10202); R BODY (10700); REAR CAP (10405); SECTION 1 (10483); SECTION 11 (10488); SECTION 13 (10489); SECTION 3 (10484); SECTION 5 (10485); SECTION 7 (10486); SECTION 9 (10487); SPLICE (10482)
Wires (circuit gauge+color): B63F 16DKBL; B63R 16DKBL; D63AU 16DKBL; D63U 16DKBL; E63-GM 16WH; E63-GN 16WH; E63-GP 16WH; E63-GR 16WH; E63-GT 16WH; E63-GU 16WH; E63-GV 16WH; E63A 16DKBL; E63AA 16DKBL; E63AF 16DKBL; E63AH 16DKBL; E63AJ 16DKBL; E63AN 16DKBL; E63AT 16DKBL; E63AU 16DKBL; E63GW 16WH; E63P 16DKBL; E63U 16DKBL; E63W 16DKBL; E63X 16DKBL; E63Y 16DKBL; E63Z 16DKBL
See also sheets: CH3_57, CH8_35, CH8_43
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.56. DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH LEFT BODY, P. 44 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 30DEC20 / CHAPTER 8 DOUBLE SWITCHED DOME LIGHT FRONT AND REAR W/LEFT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / E63AJ 16DKBL E63GW 16WH / L BODY / REAR CAP (10405) A8 E63AU D63AU 16DKBL 16DKBL / E63-GP 16WH W/9,10,11,12,13 WINDOW DOME LT SECTION 5 E63Z (10485) 16DKBL A E63AF 16DKBL E63AJ 16DKBL E63-GR 16WH W/7,8 WINDOW / DOME LT SECTION 9 (10487) A / GROUND SPLICE E63-GN (10482) 16WH CH3_57 NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / E63X 16DKBL E63-GM 16WH / DOME LT SECTION 11 E63AN (10488) 16DKBL A E63AJ 16DKBL E63AH 16DKBL E63-GV 16WH / DOME LT SECTION 1 (10483) A / E63Y 16DKBL / W/12 WINDOW DOME LT SECTION 13 (10489) W/13 WINDOW A / DOME LT SECTION 3 (10484) A / E63AF 16DKBL E63AH 16DKBL E63-GU 16WH / B63R 16DKBL / B63F 16DKBL / E63P 16DKBL E63AT 16DKBL / D63U 16DKBL / RR CAP/ R BODY (10700) CH8_43,45, 54,55 / ELEC PANEL/ L BODY (10401) E63A 16DKBL E63W 16DKBL / DOME LT OUTPUT (10202) CH8_35,36 36A,36B / W/13 WINDOW DOME LT SECTION 7 E63AA (10486) 16DKBL A E63AF 16DKBL E63-GT 16WH / W/10,11 WINDOW / W/13 WINDOW / W/11 WINDOW / W/5,6 WINDOW / E63U 16DKBL / W/10,11 WINDOW / FR CAP / R BODY (10700) CH8_43,45 / Figure 403 / DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH LEFT BODY

8.57. DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH RIGHT BODY, P. 45
Figure 404 DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH RIGHT BODY

Components: DOME LT SECTION 1 (10757); DOME LT SECTION 11 (10762); DOME LT SECTION 13 (10763); DOME LT SECTION 3 (10758); DOME LT SECTION 7 (10760); DOME LT SECTION 9 (10761); R BODY (10700); REAR CAP (10405); SECTION 5 (10759); SPLICE (10701)
Wires (circuit gauge+color): D63AU 16DKBL; D63U 16DKBL; F63-G 16WH; F63-GA 16WH; F63-GB 16WH; F63-GC 16WH; F63-GD 16WH; F63-GE 16WH; F63-GF 16WH; F63-GH 16WH; F63A 16DKBL; F63AU 16DKBL; F63B 16DKBL; F63C 16DKBL; F63D 16DKBL; F63M 16DKBL; F63N 16DKBL; F63P 16DKBL; F63U 16DKBL
See also sheets: CH3_52, CH8_44
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.57. DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH RIGHT BODY, P. 45 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 8 DOUBLE SWITCHED DOME LIGHT FRONT AND REAR W/RIGHT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / F63M 16DKBL F63-GE 16WH / F63C 16DKBL F63AU 16DKBL @F63C 16DKBL F63-GC 16WH / F63B 16DKBL F63-GB 16WH / DOME LT SECTION 5 (10759) A / F63-G 16WH / F63A 16DKBL F63-GA 16WH / DOME LT SECTION 11 (10762) A / DOME LT SECTION 1 (10757) A / REAR CAP/ R BODY (10700) B5 / W/9,10,11,12,13 WINDOW DOME LT SECTION 9 (10761) A / DOME LT SECTION 3 (10758) A / F63N 16DKBL F63-GF 16WH / GROUND SPLICE (10701) CH3_52 / D63U 16DKBL / F63U 16DKBL / D63AU 16DKBL / @F63AU 16DKBL / L BODY/ REAR CAP (10405) CH8_44 / F63D 16DKBL F63-GD 16WH / DOME LT SECTION 7 (10760) A / F63P 16DKBL F63-GH 16WH / DOME LT SECTION 13 (10763) A / W/13 WINDOW / W/7,8,9,10,11,12,13 WINDOW / W/9 WINDOW / Figure 404 / DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH RIGHT BODY

8.58. DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW AND
Figure 405 DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW AND 5-10

Components: CAP (10700); L BODY (10401); OUTPUT (10202); R CAP (10405); RHEOSTAT (10216C); SECTION 1 (10483); SECTION 3 (10484); SECTION 5 (10485); SECTION 7 (10486); SECTION 9 (10487); SPLICE (10482)
Wires (circuit gauge+color): B63F 16DKBL; B63R 16DKBL; B63RC 16DKBL; D63AU 16DKBL; D63M 16DKBL; D63U 16DKBL; E63-GM 16WH; E63-GN 16WH; E63-GP 16WH; E63-GR 16WH; E63-GT 16WH; E63-GU 16WH; E63A 16DKBL; E63AA 16DKBL; E63AA 18DKBL; E63AH 16DKBL; E63AN 18DKBL; E63AP 18DKBL; E63AT 16LTBL; E63AT 16LTGN; E63AU 16DKBL; E63AW 16DKBL; E63AX 16DKBL; E63K 16DKBL; E63M 16DKBL; E63P 16DKBL; E63U 16DKBL; E63U 16LTGN; E63W 16DKBL; E63X 16DKBL; E63Y 16DKBL; E63Z 16DKBL
See also sheets: CH3_57, CH8_07, CH8_35, CH8_38
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.58. DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW AND 5-10 WINDOW WITH LEFT BODY, P. 46 / CHAPTER 8 DOUBLE SWITCHED DOME LIGHT FRONT AND REAR W/REAR ROW W/5-10 WINDOW W/LEFT BODY / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL / L BODY (10401) A7 B63RC 16DKBL / E63AN 18DKBL W/10 WINDOW E63K 16DKBL / E63M 16DKBL / E63W 16DKBL E63A 16DKBL W/10 WINDOW E63AH 16DKBL E63AU 16DKBL E63AT 16LTBL E63AT 16LTGN E63P 16DKBL / E63U 16DKBL E63U 16LTGN / E63X 16DKBL E63-GM 16WH / E63Y 16DKBL E63Y 16DKBL E63-GP 16WH W/7,8,9,10 WINDOW / DOME LT SECTION 7 (10486) A / E63-GR 16WH / A1 B63F 16DKBL / DOME LT SECTION 5 (10485) A / A2 B63R 16DKBL / R BODY/ REAR CAP (10700) CH8_38 / E63AU 16DKBL / DOME LT STD STRAGGER SECTION 1 (10483) A / DOME LT SECTION 3 (10484) A / W/10 WINDOW / REAR ROW RHEOSTAT (10216C) CH8_07 / L BODY / R CAP (10405) A7 / D63M 16DKBL / D63AU 16DKBL / D63U 16DKBL / E63AW 16DKBL / W/10 WINDOW / W/7,8 WINDOW / DOME LT OUTPUT (10202) CH8_35,36, 36A,36B / Figure 405 / DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW AND 5-10 WINDOW WITH LEFT BODY

8.59. DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW AND
Figure 406 DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW AND 11-13

Components: CAP (10700); L BODY (10401); OUTPUT (10202); R CAP (10405); RHEOSTAT (10216C); SECTION 1 (10483); SECTION 11 (10488); SECTION 13 (10489); SECTION 3 (10484); SECTION 5 (10485); SECTION 9 (10486); SECTION 9 (10487); SPLICE (10482)
Wires (circuit gauge+color): B63F 16DKBL; B63R 16DKBL; B63RC 16DKBL; D63AU 16DKBL; D63M 16DKBL; D63U 16DKBL; E63-GM 16WH; E63-GN 16WH; E63-GP 16WH; E63-GR 16WH; E63-GT 16WH; E63-GV 16WH; E63-GW 16WH; E63A 16DKBL; E63AA 16DKBL; E63AC 16DKBL; E63AF 16DKBL; E63AH 16DKBL; E63AN 16DKBL; E63AP 16DKBL; E63AR 18DKBL; E63AT 16DKBL; E63AU 16DKBL; E63AV 16DKBL; E63E 16DKBL; E63K 16DKBL; E63M 16DKBL; E63P 16DKBL; E63U 16DKBL; E63W 16DKBL; E63X 16DKBL; E63Y 16DKBL; E63Z 16DKBL
See also sheets: CH3_57, CH8_07, CH8_35, CH8_38
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.59. DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW AND 11-13 WINDOW WITH LEFT BODY, P. 47 / CHAPTER 8 DOUBLE SWITCHED DOME LIGHT FRONT AND REAR W/REAR ROW W/11-13 WINDOW W/LEFT BODY / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / L BODY / R CAP (10405) A7 D63M 16DKBL D63U 16DKBL D63AU 16DKBL / DOME LT SECTION 13 (10489) A / ELEC PANEL/ L BODY (10401) *E63K 16DKBL A7 #E63AN 16DKBL #E63W 16DKBL *E63A 16DKBL #E63AT 16DKBL *E63P 16DKBL / #E63AR 18DKBL E63M 16DKBL E63U 16DKBL E63AU 16DKBL / E63-GM 16WH / %E63AV 16DKBL *E63E 16DKBL @E63AF 16DKBL E63-GV 16WH / @E63AP 16DKBL @E63-GW 16WH / DOME LT SECTION 1 (10483) A / DOME LT SECTION 9 (10487) A / E63X 16DKBL / B63F 16DKBL B63R 16DKBL / DOME LT OUTPUT (10202) CH8_35,36, 36A,36B / R BODY/ REAR CAP (10700) CH8_38 / REAR ROW RHEOSTAT (10216C) CH8_07 / B63RC 16DKBL / #E63AP 16DKBL *E63AP 16DKBL @E63AH 16DKBL E63-GV 16WH / DOME LT SECTION 11 (10488) A / DOME LT SECTION 3 (10484) A / E63-GP 16WH / E63Y 16DKBL / DOME LT SECTION 5 (10485) A / DOME LT SECTION 9 (10486) A / E63Z 16DKBL / E63-GR 16WH / %E63AC 16DKBL E63AA 16DKBL / E63-GN 16WH / GROUND SPLICE (10482) CH3_57 / Figure 406 / DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW AND 11-13 WINDOW WITH LEFT BODY

8.60. DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW AND
Figure 407 DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW AND 5-13

Components: R BODY (10700); REAR CAB (10405); SECTION 1 (10757); SECTION 11 (10762); SECTION 12 (10763); SECTION 3 (10758); SECTION 5 (10759); SECTION 7 (10760); SECTION 9 (10761); SPLICE (10701)
Wires (circuit gauge+color): D63AU 16DKBL; D63M 16DKBL; D63U 16DKBL; F63-G 12WH; F63-G 16WH; F63-GA 16WH; F63-GB 16WH; F63-GC 16WH; F63-GD 16WH; F63-GE 16WH; F63-GF 16WH; F63-GH 16WH; F63A 16DKBL; F63AU 16DKBL; F63B 16DKBL; F63C 16DKBL; F63D 16DKBL; F63E 16DKBL; F63M 16DKBL; F63N 16DKBL; F63R 16DKBL; F63U 16DKBL
See also sheets: CH3_52, CH8_38
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.60. DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW AND 5-13 WINDOW WITH RIGHT BODY, P. 48 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 8 DOUBLE SWITCHED DOME LIGHT FRONT AND REAR W/REAR ROW W/5-13 WINDOW W/R BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / F63-GC 16WH / DOME LT SECTION 3 *F63AU (10758) 16DKBL A A F63B 16DKBL F63-GB 16WH F63C 16DKBL F63C 16DKBL *F63AU 16DKBL #F63M 16DKBL / REAR CAP/ R BODY (10700) D63U B5 16DKBL / DOME LT STD STRAGGER SECTION 1 *F63U (10757) 16DKBL A F63A 16DKBL F63-GA 16WH / DOME LT SECTION 9 (10761) / GROUND SPLICE (10701) CH3_52 / D63M 16DKBL / DOME LT SECTION 5 (10759) A A / B B / * W/5,6 WINDOW LENGTH # W/7,8 WINDOW LENGTH / F63U 16DKBL / L BODY/ REAR CAB (10405) CH8_38 / DOME LT SECTION 7 (10760) A / F63AU 16DKBL F63D 16DKBL F63-GD 16WH / #F63M 16DKBL / F63AU 16DKBL / D63AU 16DKBL / W/9 WINDOW / DOME LT SECTION 12 (10763) A / F63-GH 16WH / F63M 16DKBL / W/10 WDO / Figure 407 / DOUBLE SWITCHED DOME LIGHT FRONT AND REAR WITH REAR ROW AND 5-13 WINDOW WITH RIGHT BODY

8.61. DOME LIGHT ABOVE EACH SEAT WITH LEFT BODY, P. 49
Figure 408 DOME LIGHT ABOVE EACH SEAT WITH LEFT BODY

Components: L BODY (10401); OUTPUT (10202); OVER EACH SEAT (10483A); OVER EACH SEAT (10484A); SPLICE (10482)
Wires (circuit gauge+color): B63F 16DKBL; E63-GAA 16WH; E63-GAC 16DKBL; E63-GAD 16DKBL; E63-GAG 16WH; E63-GF 16WH; E63-GH 16WH; E63-GJ 16WH; E63-GL 16WH; E63-GS 16WH; E63-GZ 16WH; E63AC 16DKBL; E63AD 16DKBL; E63AL 16DKBL; E63AM 16DKBL; E63AS 16DKBL; E63AU 16DKBL; E63H 16DKBL; E63J 16DKBL; E63U 16DKBL; E63V 16DKBL
See also sheets: CH3_57, CH8_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.61. DOME LIGHT ABOVE EACH SEAT WITH LEFT BODY, P. 49 / CHAPTER 8 DOME LIGHT ABOVE EACH SEAT W/LEFT BODY / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / DOME LT OVER EACH SEAT (8) (10510) / DOME LT OVER EACH SEAT (5) (10516) / DOME LT OVER EACH SEAT (9) (10514) / DOME LT OVER EACH SEAT (10484A) B / DOME LT OVER EACH SEAT (6) (10509) / DOME LT OVER EACH SEAT (2) (10507) / DOME LT OVER EACH SEAT (4) (10508) / DOME LT OVER EACH SEAT (7) (10515) / FOR 9 WINDOW LENGTH / E63-GJ 16WH / E63-GS 16WH / E63-GZ 16WH / E63-GAA 16WH / E63-GL 16WH / GROUND SPLICE (10482) CH3_57 / E63-GF 16WH / E63-GAG 16WH / E63J 16DKBL / E63U 16DKBL / E63AM 16DKBL / E63AL 16DKBL / E63AS 16DKBL / E63AU 16DKBL / E63V 16DKBL / ELEC PANEL/ L BODY (10401) A1 / E63H 16DKBL / B63F B63F 16DKBL 16DKBL / E63-GH 16WH / DOME LT OVER EACH SEAT (10483A) B / E63-GAD 16DKBL E63AD 16DKBL / E63-GAC 16DKBL E63AC 16DKBL / DOME LT OUTPUT (10202) CH8_35 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 408 / DOME LIGHT ABOVE EACH SEAT WITH LEFT BODY

8.62. DOME LIGHT ABOVE EACH SEAT WITH RIGHT BODY, P. 50
Figure 409 DOME LIGHT ABOVE EACH SEAT WITH RIGHT BODY

Components: DOME LT OVER EACH SEAT (10757A); DOME LT OVER EACH SEAT (10758A); REAR CAP (10405); REAR CAP (10700); SPLICE (10701)
Wires (circuit gauge+color): D63U 16DKBL; F63-GK 16WH; F63-GL 16WH; F63-GM 16WH; F63-GN 16WH; F63-GP 16WH; F63-GR 16WH; F63-GS 16WH; F63-GT 16WH; F63-GV 16DKBL; F63-GW 16DKBL; F63AA 16DKBL; F63AB 16DKBL; F63S 16DKBL; F63T 16DKBL; F63U 16DKBL; F63V 16DKBL; F63W 16DKBL; F63X 16DKBL; F63Y 16DKBL; F63Z 16DKBL
See also sheets: CH3_52, CH8_40
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.62. DOME LIGHT ABOVE EACH SEAT WITH RIGHT BODY, P. 50 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 8 DOME LIGHT ABOVE EACH SEAT W/RIGHT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / F63Y 16DKBL F63-GS 16WH / DOME LT OVER EACH SEAT (8) (10803) A / F63W 16DKBL F63-GP 16WH / DOME LT OVER EACH SEAT (6) (10802) A / F63S 16DKBL F63-GM 16WH / DOME LT OVER EACH SEAT (4) (10801) A / DOME LT OVER EACH SEAT (9) (10806) A / F63T 16DKBL F63-GL 16WH / DOME DOME DOME DOME LT LT LT LT OVER OVER OVER OVER EACH EACH EACH EACH SEAT SEAT SEAT SEAT (2) (2) (2) (2) (10800) (10800) (10800) (10800) A / DOME LT OVER EACH SEAT (7) (10805) A / F63X 16DKBL F63-GR 16WH / F63V 16DKBL F63-GN 16WH / F63Z 16DKBL F63-GT 16WH / F63U 16DKBL / L BODY/ REAR CAP (10405) CH8_40 DOME DOME LT LT OVER OVER EACH EACH SEAT SEAT (5) (5) (10804) (10804) A / D63U 16DKBL / FOR 9 WINDOW LENGTH / R BODY/ REAR CAP (10700) B5 / DOME LT OVER EACH SEAT (10757A) A / F63AA 16DKBL F63-GV 16DKBL / DOME LT OVER EACH SEAT (10758A) A F63AB 16DKBL F63-GW 16DKBL / Figure 409 / DOME LIGHT ABOVE EACH SEAT WITH RIGHT BODY

8.63. LIGHTED STEERING WHEEL SWITCHES, 2017 ISB, 2021 B6.7 DIESEL, 2018 PROPANE AND GAS ENGINE, P. 51
Figure 410 LIGHTED STEERING WHEEL SWITCHES, 2017 ISB, 2021 B6.7 DIESEL, 2018 PROPANE

Components: BODY CONTROLLER (1600); CLOCK SPRING (1832); GROUND SPLICE (1003A); REFERENCE (1005); SPLICE (1002A)
Wires (circuit gauge+color): A11-GE 20WH; A62K 20DKBL; A85B 20GY; A9HA 20TN
See also sheets: CH3_22, CH3_58, CH8_25
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.63. LIGHTED STEERING WHEEL SWITCHES, 2017 ISB, 2021 B6.7 DIESEL, 2018 PROPANE AND GAS ENGINE, P. 51 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / STEERING WHEEL SWITCHES / #A89C 20VT / J3-RED BODY CONTROLLER (1600) / PANEL LTS SPLICE (1002A) CH8_25 GROUND SPLICE (1003A) CH3_22,95B / ELECTRIC HORN A5 SW INPUT / &A85B 20GY / CITY HORN / DOOR CLOSE 1210 / DOOR OPEN 6190 FLASHER ON / OFF 2370 / RED OVERIDE / &A62K 20DKBL / STEERING WHEEL B16 SW INPUT / &A9HA 20TN / &A11-GE 20WH / ZERO VOLT (1005) CH3_58,95M / CLOCK SPRING (1832) / 'R' (SEE NOTE) / NOTE: THE VALUE OF RESISTOR 'R' DEPENDS UPON DESIRED INTENSITY OF THE LED. / %A89C 20PL / Figure 410 / LIGHTED STEERING WHEEL SWITCHES, 2017 ISB, 2021 B6.7 DIESEL, 2018 PROPANE AND GAS ENGINE

8.64. WITHOUT LIGHTED STEERING WHEEL SWITCHES, 2017 ISB, 2021 B6.7 DIESEL,
Figure 411 WITHOUT LIGHTED STEERING WHEEL SWITCHES, 2017 ISB, 2021 B6.7 DIESEL, 2018

Components: BODY CONTROLLER (1600); CLOCK SPRING (1809); REFERENCE (1005)
Wires (circuit gauge+color): A85B 18GY; A89C 18GY; A9HA 18GY
See also sheets: CH3_58
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.64. WITHOUT LIGHTED STEERING WHEEL SWITCHES, 2017 ISB, 2021 B6.7 DIESEL, 2018 PROPANE AND GAS ENGINE, P. 52 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELECTRIC HORN A5 A5 SW INPUT / DOOR DOOR DOOR DOOR OPEN OPEN OPEN OPEN 6190 6190 6190 6190 FLASHER FLASHER FLASHER FLASHER ON ON ON ON / / / / OFF OFF OFF OFF 2370 2370 2370 2370 / A89C A89C 18GY 18GY / A A / CITY CITY CITY CITY HORN HORN HORN HORN / STEERING WHEEL B16 B16 SW INPUT / DOOR DOOR DOOR DOOR CLOSE CLOSE CLOSE CLOSE 1210 1210 1210 1210 / A9HA 18GY / A85B A85B 18GY 18GY / B B / STEERING STEERING WHEEL WHEEL SWITCHES SWITCHES / BODY BODY CONTROLLER CONTROLLER (1600) (1600) / CLOCK CLOCK SPRING SPRING (1809) (1809) D D / RED RED RED RED OVERIDE OVERIDE OVERIDE OVERIDE / ZERO VOLT (1005) CH3_58, 95M / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 411 / WITHOUT LIGHTED STEERING WHEEL SWITCHES, 2017 ISB, 2021 B6.7 DIESEL, 2018 PROPANE AND GAS ENGINE

8.65. SWITCH PACK 2017 ISB, 2021 B6.7 DIESEL, 2018 PROPANE AND GAS ENGINE, P. 53
Figure 412 SWITCH PACK 2017 ISB, 2021 B6.7 DIESEL, 2018 PROPANE AND GAS ENGINE

Components: CONTROLLER (1602); FUSE A3-W (1016); FUSE A3-X (1016); FUSE F12 (1011); FUSE F26 (1011); SPLICE (1002A); STUD (4037A); SW PACK (1101)
Wires (circuit gauge+color): A11-GC 18WH; A11-GZ 8WH; A12C 18LTBL; A62D 18DKBL; A62DM 18DKBL; A62Z 16DKBL; A62ZA 18DKBL
See also sheets: CH3_02, CH3_03, CH8_25
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.65. SWITCH PACK 2017 ISB, 2021 B6.7 DIESEL, 2018 PROPANE AND GAS ENGINE, P. 53 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090659 NO. 95885P 30DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J1708 - / %A11-GC 18WH / %A3F(-) 18GY / &A62DM 18DKBL / E2 SW DATA LINK + / SW PACK (1101) / E1 SW DATA LINK - / FUSE A3-W (1016) CH3_03 / &A12C 18LTBL / BACKUP LT / %A3E(+) 18DKBL / J1708 + / J5-TAN BODY CONTROLLER (1602) / GROUND STUD (4037A) / &A62Z 16DKBL / %A11-GZ 8WH / FUSE A3-X (1016) CH3_02 / #A12C 18LTBL / FUSE F12 (1011) CH3_94A / #A62D 18DKBL / #A62Z 16DKBL / FUSE F26 (1011) CH3_94C / #A62ZA 18DKBL / PANEL LTS SPLICE (1002A) CH8_25 / Figure 412 / SWITCH PACK 2017 ISB, 2021 B6.7 DIESEL, 2018 PROPANE AND GAS ENGINE

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 453 | printed page 413 | section 8.66
8.66. DOME LIGHT 10 LED, P. 54
Figure 413 DOME LIGHT 10 LED

Components: DOME LT SECTION 10 (10844); DOME LT SECTION 2 (10840); DOME LT SECTION 4 (10841); DOME LT SECTION 6 (10842); DOME LT SECTION 8 (10843); REAR CAP (10405); REAR CAP (10700); SPLICE PACK (10701)
Wires (circuit gauge+color): D63U 16DKBL; F63-GA 16WH; F63-GB 16WH; F63-GC 16WH; F63-GD 16WH; F63-GE 16WH; F63-GF 16WH; F63A 16DKBL; F63B 16DKBL; F63C 16DKBL; F63D 16DKBL; F63E 16DKBL; F63F 16DKBL
See also sheets: CH3_52, CH8_54
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.66. DOME LIGHT 10 LED, P. 54 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 30DEC20 / CHAPTER 8 / DOME LIGHT 10 LED / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / F63D 16DKBL F63-GD 16WH / DOME LT SECTION 8 (10843) A / F63C 16DKBL F63-GC 16WH / DOME LT SECTION 6 (10842) A / F63B 16DKBL F63-GB 16WH / DOME LT SECTION 4 (10841) A / F63A 16DKBL F63-GA 16WH / DOME LT SECTION 2 (10840) A / F63F 16DKBL / L BODY/ REAR CAP (10405) CH8_54 / GROUND SPLICE PACK (10701) CH3_52 / F63-GF 16WH / D63U 16DKBL / FOR 10 WINDOW LENGTH / R BODY/ REAR CAP (10700) B5 / F63E 16DKBL F63-GE 16WH / DOME LT SECTION 10 (10844) A / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 413 / DOME LIGHT 10 LED

8.67. DOME LIGHT 12 LED, P. 55
Figure 414 DOME LIGHT 12 LED

Components: DOME LT (10757B); DOME LT (10760A); DOME LT (10761A); DOME LT (10800A); DOME LT (10801A); DOME LT (10804A); REAR CAP (10405); REAR CAP (10700); SPLICE PACK (10701)
Wires (circuit gauge+color): D63U 16DKBL; F63 16DKBL; F63-GA 16WH; F63A 16DKBL; F63A-G 16WH; F63B 16DKBL; F63B-G 16WH; F63C 16DKBL; F63C-G 16WH; F63D 16DKBL; F63D-G 16WH; F63E 16DKBL; F63E-G 16WH; F63F 16DKBL; F63F-G 16WH
See also sheets: CH3_52, CH8_44
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.67. DOME LIGHT 12 LED, P. 55 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 30DEC20 / CHAPTER 8 / DOME LIGHT 12 LED / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / F63B 16DKBL F63B-G 16WH / 12 DOME LT (10800A) A / F63F 16DKBL F63F-G 16WH / 12 DOME LT (10761A) A / F63E 16DKBL F63E-G 16WH / 12 DOME LT (10760A) A / F63 16DKBL / L BODY/ REAR CAP (10405) CH8_44 / GROUND SPLICE PACK (10701) CH3_52 / F63-GA 16WH / D63U 16DKBL / FOR 9 WINDOW LENGTH / R BODY/ REAR CAP (10700) B5 / 12 DOME LT (10801A) A F63C 16DKBL F63C-G 16WH / F63A 16DKBL F63A-G 16WH / 12 DOME LT (10757B) A / 12 DOME LT (10804A) A / F63D 16DKBL F63D-G 16WH / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 414 / DOME LIGHT 12 LED

8.68. DOME LIGHT ACTIVATED BY LIFT DOOR, P. 56
Figure 415 DOME LIGHT ACTIVATED BY LIFT DOOR

Components: DOME LT O/P (10202); DOME LT PWR (10201); LIFT SPLICE (10370); LT RELAY (10311); LT RELAY (10311-R2); PWR (10201)
Wires (circuit gauge+color): B63-G 16WH; B63A 16DKBL; B63AA 16DKBL; B63B 16DKBL; B63C 16DKBL; B63M 16DKBL
See also sheets: CH15_24, CH15_36, CH8_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 8.68. DOME LIGHT ACTIVATED BY LIFT DOOR, P. 56 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090659 95885P 09JAN21 / CHAPTER 8 DOME LIGHT ACTIVATED BY LIFT DOOR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B63B 16DKBL / DOME LT PWR (10201) CH8_35 / B63AA 16DKBL / REAR DOME LT RELAY (10311-R2) / DOME LT O/P (10202) CH8_35 / B63A 16DKBL / LIFT SPLICE (10370) CH15_24 / B63-G 16WH / B63C 16DKBL / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / B63-G 16WH / B63B 16DKBL / DOME LT O/P (10202) CH8_36A / LIFT SPLICE (10370) CH15_36 / REAR DOME LT RELAY (10311) / B63AA 16DKBL / B63C 16DKBL / B63M 16DKBL B63A 16DKBL / DOME LT PWR (10201) CH8_36A / D2 86 / 85 C1 / C2 30 / Figure 415 / DOME LIGHT ACTIVATED BY LIFT DOOR

Figure 416 FRONT AND REAR OR REAR ONLY STOP ARM

Components: BODY CONTROLLER (1601); ENT DOOR-CAV 7 (1351); EXTEND (10358A); EXTEND (10358B); FUSE B6-F (10303); GROUND SPLICE (10334); LIGHTS SPLICE (11601); PLATFORM (1702); REAR STOP ARM (10475A/B); STOP ARM (10221); STOP ARM POWER (10359); STOP ARM RELAY (10310-R1)
Wires (circuit gauge+color): B119 16GY; B119-GC 18WH; B119A 16GY; B119B 18GY; B119C 18GY; B119D 16GY; B119E 18GY; B119F 18GY; B119H 16GY; B119K 16GY; B119P 16GY; B119R 16GY; B89AA 18OR; B89BB 18OR
See also sheets: CH17_30, CH3_10, CH3_34, CH9_02, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / STOP ARM / CROSSING GATE (CHAPTER 9) / 9.1. FRONT AND REAR OR REAR ONLY STOP ARM, P. 1 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090660 NO. 95885P 18DEC20 / CHAPTER 9 FRONT AND REAR OR REAR ONLY STOP ARM / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / STOP ARM-CAV 1 ENT DOOR-CAV 7 (1351) CH17_30 J4-BLUE BODY CONTROLLER (1601) STOP E2 ARM / B119A 16GY / STOP ARM EXTEND (10358A) CH9_03 / B119D 16GY / STOP ARM WARNING LIGHTS SPLICE (11601) CH9_02 GROUND SPLICE (10334) CH3_34 / B119K 16GY / STOP ARM POWER (10359) C / STOP ARM RELAY ELEC PANEL/ (10310-R1) PLATFORM (1702) 42 B119B 18GY / FLASHING LIGHT / STOP ARM EXTEND (10358A) CH9_03 / ACTIVATION SWITCH / B89BB 18OR / B119-GC 18WH / STOP ARM (10221) 1 / B119R 16GY / B119 16GY / B89AA 18OR / B119E 18GY / FLASHING LIGHT / FUSE B6-F (10303) CH3_10 / B119P 16GY / STOP ARM EXTEND (10358B) CH9_03 / A89HH 18VT / REAR STOP ARM (10475A/B) CH9_02 / B119F 18GY / A89HJ A89HH 20VT 18VT A89HK 18VT / B119H 16GY / B119C 18GY / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 416 / FRONT AND REAR OR REAR ONLY STOP ARM

9.2. FRONT AND REAR OR REAR ONLY STOP ARM (CONT.), P. 1A
Figure 417 FRONT AND REAR OR REAR ONLY STOP ARM (CONT.)

Components: BODY CONTROLLER (1601); ENT DOOR-CAV 7 (1351); EXTEND (10358A); FUSE F38 (10304); GROUND SPLICE (10334); ITENSITY (10242); LIGHTS SPLICE (11601); PLATFORM (1702); REAR STOP ARM (10475A/B); STOP ARM (10221); STOP ARM EXTEND (10358A); STOP ARM EXTEND (10358B); STOP ARM POWER (10359); STOP ARM RELAY (10310)
Wires (circuit gauge+color): B119 16GY; B119-GC 18WH; B119-GH 18WH; B119A 16GY; B119B 18GY; B119C 18GY; B119D 16GY; B119E 18GY; B119F 18GY; B119K 16GY; B119P 16GY; B119R 16GY; B89AA 18OR; B89BB 18OR
See also sheets: CH16_30, CH9_02, CH9_03, CH9_12
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 9.2. FRONT AND REAR OR REAR ONLY STOP ARM (CONT.), P. 1A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090660 NO. 95885P 12MAR21 / CHAPTER 9 FRONT AND REAR OR REAR ONLY STOP ARM / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J4-BLUE BODY CONTROLLER (1601) STOP E2 ARM / B119A 16GY / STOP ARM EXTEND (10358A) CH9_03 / B119D 16GY 87A B1 / STOP ARM WARNING LIGHTS SPLICE (11601) CH9_02 GROUND SPLICE (10334) CH3_95F STROBE LT ITENSITY (10242) CH9_12 / B119K 16GY / STOP ARM POWER (10359) C / ELEC PANEL/ PLATFORM (1702) 42 B119B 18GY / FLASHING LIGHT / STOP ARM EXTEND (10358A) CH9_03 / STOP ARM RELAY (10310) / ACTIVATION SWITCH / B89BB 18OR / B119-GC 18WH / 86 B2 B119C 18GY / 85 A1 / STOP ARM (10221) 1 / B119R 16GY / B119 16GY / B89AA 18OR / B119E 18GY / FLASHING LIGHT / FUSE F38 (10304) CH3_94J / B119P 16GY / STOP ARM EXTEND (10358B) CH9_03 / A89HJ 18VT A89HH 18PL / REAR STOP ARM (10475A/B) CH9_02 / B119F 18GY / A89HH 18VT / B119-GH 18WH / STROBE LT INTENSITY / A89HJ 20VT / STOP ARM-CAV 1 ENT DOOR-CAV 7 (1351) CH16_30 / Figure 417 / FRONT AND REAR OR REAR ONLY STOP ARM (CONT.)

9.3. FRONT AND REAR OR REAR ONLY STOP ARM (CONT.), P. 2
Figure 418 FRONT AND REAR OR REAR ONLY STOP ARM (CONT.)

Components: EXTEND (10358A); LIGHT SPLICE (11601); POWER (10359); REAR STOP ARM (10475A/B); RED PWL SPLICE (10360R); SNOOZE ON (11337); SPLICE (10334); SPLICE (10360R); STOP ARM (10221); STOP ARM (10476)
Wires (circuit gauge+color): B119-GE 16WH; B119J 16GY; B119K 16GY; B89 18OR; B89AA 18OR; B89BB 18OR; B89C 16OR; B89D 16OR; B89P 16OR; B89S 16OR; B89T 16OR; E119-G 18WH; E119-GA 18WH; E119A 18BK; E119A 18GY; E119B 18GY; E119C 18GY; E119D 18GY; E119E 18OR; E119F 18OR; E89A 18OR; E89B 18OR
See also sheets: CH18_23, CH3_34, CH6_01, CH9_01, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 9.3. FRONT AND REAR OR REAR ONLY STOP ARM (CONT.), P. 2 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090660 NO. 95885P 18DEC20 / CHAPTER 9 FRONT AND REAR OR REAR ONLY STOP ARM (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (10334) CH3_34,95F / STOP ARM WARNING LIGHT SPLICE (11601) / REAR STOP ARM (10475A/B) / B89C 16OR / B119J 16GY / B119K 16GY / B119-GE 16WH / STOP ARM POWER (10359) CH9_01,1A / B89BB 18OR / B89AA 18OR / 2 GROUND / REAR STOP ARM (10476) / 3 ACTIVATION SWITCH / 6 FLASHING LIGHT / 5 FLASHING LIGHT / 4 OPTIONAL INTENSITY SWITCH / @E89A 18OR *E119F 18OR / B89P 16OR / B89T B89T 16OR 16OR / B89D 16OR / STOP ARM (10221) CH9_01,1A / STOP ARM EXTEND (10358A) CH9_03 RED PWL SPLICE (10360R) CH6_01 / RED PWL SPLICE (10360R) CH6_01 CA 2018 SNOOZE ON (11337) CH18_23 / *E119A 18BK @E119A 18GY / *E119D 18GY @E119B 18GY / *E119E 18OR @E119C 18GY / *E119C 18GY @E89B 18OR / *E119-GA 18WH @E119-G 18WH / STOP ARM (10221) CH9_01,1A / * W/WINDOW SECTION 5,6,7,8,9,10,11 @ W/WINDOW SECTION 12,13 NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / B89 18OR / B89S 16OR / Figure 418 / FRONT AND REAR OR REAR ONLY STOP ARM (CONT.)

9.4. STOP ARM EXTEND, P. 3
Figure 419 STOP ARM EXTEND

Components: CHECKMATE MODULE (10212); CHILD MONITOR (11642); EXTEND (10358B); LIGHT RELAY (10310); LIGHT TIMER (10282); REAR STOP ARM (10475A/B); RED DOT (11642A); RELAY (10307); RELAY (10308); RELAY (10308-R2); RELAY (10313-R1); SEON SIGNALS (11644); SEON SIGNALS (11654); SOLENOID (10219); STOP ARM (10221); STOP ARM EXTEND (10358A); STOP ARM RELAY (10310)
Wires (circuit gauge+color): B119 18GY; B119D 16GY; B119F 18GY; B119H 18GY; B119J 16GY; B119L 16GY; B119P 16GY; B119R 16GY; B119T 16GY; B119V 18GY; B127E 16OR
See also sheets: CH18_01, CH18_13, CH18_34, CH7_12, CH7_22, CH7_25, CH7_62, CH9_01, CH9_02, CH9_06, CH9_07
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 9.4. STOP ARM EXTEND, P. 3 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090660 95885P 18DEC20 / CHAPTER 9 / STOP ARM EXTEND / MJV0488 19NOV21 ADDED CHAPTER CH18_5A & 48. / B119F 18GY / STOP ARM EXTEND (10358A) A / !B119D 16GY #B119D 16GY / #B119L 16GY / B119H 18GY / !B119L 16GY / !B127E 16OR / B119P 16GY / B119T 16GY / B119R 16GY / STOP ARM EXTEND (10358B) C / B119V 18GY / SEON SIGNALS (11644) CH7_22,24,28,30,31,34 / B119 18GY / B119 18GY / THEFT MATE RED DOT (11642A) CH18_34,5A,48,49 CHILD MONITOR (11642) CH18_01,26 CHECKMATE MODULE (10212) CH18_13 / SEON SIGNALS (11654) CH7_25,33,34A,34B / B119 18GY / B119 18GY / B119J 16GY / #B127E 16OR / #B119T 16GY / # N/0508108 - NOT MTA FUSE BLOCK ! W/0508108 - MTA FUSE BLOCK NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 419 / STOP ARM EXTEND

9.5. AIR / ELECTRIC STOP ARM / CROSSING GATE CANCEL SWITCH, P. 4
Figure 420 AIR / ELECTRIC STOP ARM / CROSSING GATE CANCEL SWITCH

Components: BODY CONTROLLER (1600); CANCEL RELAY (1030); ELEC PANEL (1702); FUSE A1-D (10305); FUSE F47 (10304); SPLICE (10327); SWITCH (10241)
Wires (circuit gauge+color): A119A 18GY; B119L 18GY; B119M 18GY; B62-GE 18WH; B62E 18DKBL
See also sheets: CH3_19, CH8_29
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 9.5. AIR / ELECTRIC STOP ARM / CROSSING GATE CANCEL SWITCH, P. 4 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090660 95885P 18DEC20 / CHAPTER 9 AIR/ELECTRIC STOP ARM/XGT CANCEL SWITCH / MJV0488 19NOV21 ADDED CIRC A119L AT R/D 1702. / FUSE F47 (10304) CH3_94K FUSE A1-D J3-RED (10305) BODY CONTROLLER CH3_19 (1600) / B62-GE 18WH B62E 18DKBL / B119M 18GY / STOP ARM CROSSING GATE CANCEL SWITCH (10241) 7 / !B119L 18GY PLATFORM/ ELEC PANEL (1702) 56 / CROSSING GATE B12 DISABLE SWITCH / *A119A 18GY / SWITCH ILLUMINATION SPLICE (10327) CH8_29 / * W/LEFT STOP ARM/XGT CANCEL SW # N/0508108 - NOT MTA FUSE BLOCK ! W/0508108 - MTA FUSE BLOCK / #B119L 18GY / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / CROSSING GATE CANCEL RELAY (1030) CH5_10B / #B119L 18GY / W/CROSSING GATE CANCEL SWITCH N/PWL / Figure 420 / AIR / ELECTRIC STOP ARM / CROSSING GATE CANCEL SWITCH

9.6. RIGHT STOP ARM / CROSSING GATE CANCEL SWITCH, P. 5
Figure 421 RIGHT STOP ARM / CROSSING GATE CANCEL SWITCH

Components: BODY CONTROLLER (1600); CANCEL SWITCH (1140); SPLICE (1002B); SPLICE PACK (1014); SPLICE PACK (1014A)
Wires (circuit gauge+color): A119A 18GY; A119M 18GY; A62-GP 18WH; A62P 18DKBL
See also sheets: CH3_28, CH8_26
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 9.6. RIGHT STOP ARM / CROSSING GATE CANCEL SWITCH, P. 5 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090660 95885P 18DEC20 / CHAPTER 9 RIGHT STOP ARM/CROSSING GATE CANCEL SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A62-GP 18WH / @A119M 18GY / A119A 18GY / A62P 18DKBL / PANEL LIGHTS SPLICE (1002B) CH8_26 / J3-RED BODY CONTROLLER (1600) / CROSSING GATE B12 DISABLE SWITCH / RIGHT STOP ARM CANCEL SWITCH (1140) / IGNITION SPLICE PACK (1014) CH3_28A IGNITION SPLICE PACK (1014A) CH3_28 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / % W/CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK @ W/CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK / %A119M 18GY / Figure 421 / RIGHT STOP ARM / CROSSING GATE CANCEL SWITCH

9.7. STOP ARM AND CROSSING GATE VALVE WITH CROSSING GATE CANCEL, P. 6
Figure 422 STOP ARM AND CROSSING GATE VALVE WITH CROSSING GATE CANCEL

Components: CROSSING GATE (10219B); EXTENDED (10358A); GROUND SPLICE (10334); GROUND SPLICE (10336); RELAY (10313-R1); SPLICE (10389)
Wires (circuit gauge+color): B119-G 16WH; B119-GN 16WH; B119C 16GY; B119L 16GY; B119S 16GY
See also sheets: CH3_34, CH3_40, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 9.7. STOP ARM AND CROSSING GATE VALVE WITH CROSSING GATE CANCEL, P. 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090660 95885P 18DEC20 / CHAPTER 9 STOP ARM AND XGT VALVE W/XGT CANCEL / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 30 30 / CROSSING GATE RELAY (10313-R1) / B119L 16GY / B119C 16GY / B119-G 16WH / B119S 16GY / STOP ARM EXTENDED (10358A) CH9_03 / B119-GN 16WH / GROUND SPLICE (10336) CH3_40 GROUND SPLICE (10334) CH3_34 / CROSSING GATE (10219B) / DOOR OPTION SPLICE (10389) / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 422 / STOP ARM AND CROSSING GATE VALVE WITH CROSSING GATE CANCEL

9.8. STOP ARM AND CROSSING GATE VALVE WITH CROSSING GATE CANCEL
Figure 423 STOP ARM AND CROSSING GATE VALVE WITH CROSSING GATE CANCEL (CONT.)

Components: CROSSING GATE (10219B); EXTENDED (10358A); GROUND SPLICE (10334); GROUND SPLICE (10336); RELAY (10307); SPLICE (10389)
Wires (circuit gauge+color): B119-G 16WH; B119-GN 16WH; B119C 16GY; B119L 16GY; B119S 16GY
See also sheets: CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 9.8. STOP ARM AND CROSSING GATE VALVE WITH CROSSING GATE CANCEL (CONT.), P. 6A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090660 NO. RELEASE NO. 95885P 12MAR21 / CHAPTER 9 STOP ARM AND XGT VALVE W/XGT CANCEL / - INITIAL PRODUCTION RELEASE. / C2 30 30 / 87 D1 / 85 C1 / D2 86 / CROSSING GATE RELAY (10307) / B119L 16GY / B119C 16GY / B119-G 16WH / B119S 16GY / STOP ARM EXTENDED (10358A) CH9_03 / B119-GN 16WH / GROUND SPLICE (10336) CH3_95K GROUND SPLICE (10334) CH3_95F / CROSSING GATE (10219B) / DOOR OPTION SPLICE (10389) CH8_23A / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 423 / STOP ARM AND CROSSING GATE VALVE WITH CROSSING GATE CANCEL (CONT.)

9.9. AIR STOP ARM VALVE, P. 7
Figure 424 AIR STOP ARM VALVE

Components: GROUND SPLICE (10334); STOP ARM EXTEND (10358A); STOP ARM SOLENOID (10219)
Wires (circuit gauge+color): B119-GB 18WH; B119H 18GY
See also sheets: CH3_34, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 9.9. AIR STOP ARM VALVE, P. 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090660 95885P 18DEC20 / CHAPTER 9 / AIR STOP ARM VALVE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / STOP ARM EXTEND (10358A) CH9_03 / GROUND SPLICE (10334) CH3_34,95F / B119-GB 18WH / STOP ARM SOLENOID (10219) 1 / AIR SUPPLY LINE / AIR REGULATOR / TO AIR CROSSING GATE / B119H 18GY / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 424 / AIR STOP ARM VALVE

9.10. CROSSING GATE VALVE, P. 8
Figure 425 CROSSING GATE VALVE

Components: CONTROLLER (1602); ELEC PANEL (1703); GROUND SPLICE (10334); SOLENOID 2 (10219A)
Wires (circuit gauge+color): A119E 18GY; A119F 18GY; B119-GN 18WH; B119N 18GY
See also sheets: CH3_34
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 9.10. CROSSING GATE VALVE, P. 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090660 95885P 18DEC20 / CHAPTER 9 / CROSSING GATE VALVE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / AIR REGULATOR / AIR SUPPLY LINE / TO FRONT STOP ARM / AIR REGULATOR / STOP ARM SOLENOID 2 (10219A) 1 / TO REAR STOP ARM / B119-GN 18WH / GROUND SPLICE (10334) CH3_34,95F / B119N 18GY / PLATFORM / ELEC PANEL (1703) A5 / A119F 18GY / A119E 18GY / J5-TAN BODY CONTROLLER (1602) CROSSING E12 GATE / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 425 / CROSSING GATE VALVE

9.11. CROSSING GATE WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 9
Figure 426 CROSSING GATE WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: BODY CONTROLLER (1602); CANCEL RELAY (1030); CROSSING GATE (4301); FUSE A6-A (1014); FUSE F4 (1011); PLATFORM (1700); RELAY (1027); SPLICE (6740)
Wires (circuit gauge+color): A119 16GY; A119A 18GY; A119C 16GY; A119D 16GY; A119E 18GY; A119H 18GY; M89-G 16WH
See also sheets: CH3_02, CH3_50, CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 9.11. CROSSING GATE WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 9 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090660 95885P 18DEC20 / CHAPTER 9 CROSSING GATE W/2017/2021 ISB/B6.7 DIESEL ENG / MJV0488 19NOV21 ADDED CIRC A119C, B 96289K A119H, REMOVED CIRC M11-GA,M89-G. / A119E 18GY / ACTIVATION 50mA / CROSSING GATE (4301) / FUSE F4 (1011) CH3_94 FUSE A6-A (1014) CH3_02 CROSSING GATE RELAY (1027) CH5_10B / M89A 16VT / M89 16VT / CROSSING GATE E12 / J5-TAN BODY CONTROLLER (1602) / CONSTANT MAX 2.5A 12V / FORWARD CHASSIS/ PLATFORM (1700) / #A119H 18GY A119A #A119 !A119 18GY 16GY 16GY #A119C 16GY / CROSSING GATE CANCEL RELAY (1030) CH5_10B GROUND SPLICE (6740) CH3_50 / M89-G 16WH / # N/0508108 - NOT MTA FUSE BLOCK ! W/0508108 - MTA FUSE BLOCK / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / #A119D 16GY / Figure 426 / CROSSING GATE WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

9.12. CROSSING GATE WITH 300A WITH F 2018 PROPANE / GASOLINE ENGINE, P. 10
Figure 427 CROSSING GATE WITH 300A WITH F 2018 PROPANE / GASOLINE ENGINE

Components: BODY CONTROLLER (1602); FUSE A6-A (1014); FUSE F4-B (1011); GATE (4301); PLATFORM (1700); SPLICE (6740)
Wires (circuit gauge+color): A119 16GY; A119A 18GY; A119E 18GY; M89-G 16WH
See also sheets: CH3_02, CH3_51, CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 9.12. CROSSING GATE WITH 300A WITH F 2018 PROPANE / GASOLINE ENGINE, P. 10 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090660 95885P 18DEC20 / CHAPTER 9 CROSSING GATE W/300A W/F-2018-PROP/GAS-ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A119E 18GY / ACTIVATION 50mA / CROSSING GATE (4301) / M119A 16VT / M119 16VT / J5-TAN BODY CONTROLLER (1602) CROSSING GATE E12 / CONSTANT MAX 2.5A 12V / FORWARD CHASSIS/ PLATFORM (1700) / A119A #A119 16GY !A119 16GY 18GY / GROUND SPLICE (6740) CH3_51 / M89-G 16WH / FUSE F4-B (1011) CH3_94 FUSE A6-A (1014) CH3_02 / Figure 427 / CROSSING GATE WITH 300A WITH F 2018 PROPANE / GASOLINE ENGINE

9.13. CROSSING GATE WITH 150A WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 11
Figure 428 CROSSING GATE WITH 150A WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: BODY CONTROLLER (1602); CROSSING GATE (4301); FUSE A6-A (1014); FUSE F4-B (1011); PLATFORM (1700)
Wires (circuit gauge+color): A119 16GY; A119A 18GY; A119AC 18GY; A119E 18GY
See also sheets: CH3_02, CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 9.13. CROSSING GATE WITH 150A WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 11 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090660 95885P 18DEC20 / CHAPTER 9 CROSSING GATE W/150A W/2017/2021 ISB/B6.7 DIESEL ENG / MJV0488 19NOV21 REMOVED:CIRC M89-G, B 96289K M89B AT R/D 4301,CIRC A89B AT R/D 1700. / A119E 18GY / ACTIVATION 50mA / CROSSING GATE ! W/0508108 - MTA FUSE BLOCK (4301) NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / FUSE F4-B (1011) CH3_94 FUSE A6-A (1014) CH3_02 / M89A 16VT / M89 16VT / CROSSING GATE E12 / J5-TAN BODY CONTROLLER (1602) / CONSTANT MAX 2.5A 12V / FORWARD CHASSIS/ PLATFORM (1700) / A119A 18GY / A119 16GY / !A119AC 18GY / !A119A 18GY / Figure 428 / CROSSING GATE WITH 150A WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

9.14. STOP ARM STROBE HI / LO INTENSITY SWITCH, P. 12
Figure 429 STOP ARM STROBE HI / LO INTENSITY SWITCH

Components: GROUND SPLICE (10334); INTENSITY (10242); SPLICE (10327); STOP ARM (10221)
Wires (circuit gauge+color): B119-GG 18WH; B119-GH 18WH; B62-GD 18WH
See also sheets: CH8_29
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 9.14. STOP ARM STROBE HI / LO INTENSITY SWITCH, P. 12 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090660 95885P 06APR21 / CHAPTER 9 SARM STROBE HI/LO INTENSITY SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (10334) CH3_95F / B62-GD 18WH B62D 18YL / STROBE LIGHT INTENSITY (10242) / B119-GG 18WH / SWITCH ILLUMINATION SPLICE (10327) CH8_29 / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / STOP ARM (10221) CH9_1A / B119-GH 18WH / Figure 429 / STOP ARM STROBE HI / LO INTENSITY SWITCH

Figure 430 HEATED AND MOTORIZED MIRROR

Components: ELEC PANEL/FR CAP (10000); FUSE B3-U (10304); FUSE F19 (10302); GROUND SPLICE (10334); HEATED MIRROR (10293); HEATED MIRROR (10295); SEALED ENG (11500); SPLICE (10330); SPLICE (10356)
Wires (circuit gauge+color): B62-GAS 18WH; B62AS 18DKBL; B78-GE 18WH; B78A 18LTGN; B78AD 18LTGN; B78B 18LTGN; B78D 18LTGN; B78E 18LTGN; B78J 18LTGN
See also sheets: CH10_03, CH10_06, CH3_07, CH3_34, CH8_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / MIRROR SYSTEM (CHAPTER 10) / 10.1. HEATED AND MOTORIZED MIRROR, P. 1 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090661 NO. 95885P 29OCT20 / HEATED AND MOTORIZED MIRROR W/CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK / CHAPTER 10 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B78B 18LTGN / @B78D 18LTGN HEATED MIRROR (10293) #B78A 18LTGN 2 #B78A 18LTGN / B62-GAS 18WH / SWITCH ILLUMINATION SPLICE (10330) CH8_31 / B62AS 18DKBL / GROUND SPLICE (10334) CH3_34,95F / HEATED MIRROR (10295) 1 / B78-GE 18WH / HEATED MIRROR SPLICE (10356) A / B78E 18LTGN / B78AD 18LTGN / ELEC PANEL/ SEALED ENG (11500) CH10_06 / 20 MIN TIMER / B78J 18LTGN / FUSE B3-U (10304) CH3_07,25 / @ W/TIMER # N/TIMER / ELEC PANEL/FR CAP (10000) CH10_03,05 / B78D 18LTGN / @B78D 18LTGN / FUSE F19 (10302) CH3_94F / W/CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 430 / HEATED AND MOTORIZED MIRROR

Figure 431 HEATED AND MOTORIZED MIRROR (CONT.)

Components: FR CAP (10001); FRONT CAP (10001); FUSE B9-N (10302); FUSE F56 (10305); MIRROR SWITCH (10354); SPLICE (10330); SPLICE (10337); SWITCH (10353)
Wires (circuit gauge+color): B62AT 18DKBL; B62AU 20DKBL; B62AV 20DKBL; B78-G 18WH; B78-GC 20WH; B78-GD 20WH; B78A 18LTGN; B78B 20LTGN; B78C 20LTGN; B78LA 20LTGN; B78LB 20LTGN; B78LC 20LTGN; B78LD 20LTGN; B78LE 18LTGN; B78LF 20LTGN; B78N 20LTGN; B78RA 20LTGN; B78RB 20LTGN; B78RC 20LTGN; B78RD 20LTGN; B78RE 20LTGN; B78RF 20LTGN; B78S 20LTGN
See also sheets: CH10_03, CH10_04, CH3_16, CH3_41, CH8_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 10.2. HEATED AND MOTORIZED MIRROR (CONT.), P. 2 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090661 NO. 95885P 29OCT20 / CHAPTER 10 HEATED AND MOTORIZED MIRROR (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B78C 20LTGN B62AV 20DKBL / B78RA 20LTGN B78RD 20LTGN #B78A 18LTGN !B78A 18LTGN / SWITCH ILLUMINATION B62AT SPLICE 18DKBL (10330) CH8_31 / FUSE F56 (10305) CH3_94M FUSE B9-N (10302) CH3_16 / B62AU 20DKBL B78-GC 20WH B78N 20LTGN / B78RC 20LTGN / B78B 20LTGN / DRIVER MIRROR SWITCH (10353) 2 / PASSENGER MIRROR SWITCH (10354) 6 / B78RF 20LTGN / B78RE 20LTGN B78RB 20LTGN @B78LB 20LTGN @B78LE 18LTGN / GROUND SPLICE (10337) CH3_41,95L / ELEC PANEL/ FR CAP (10001) CH10_03 / B78-G 18WH / @B78LA 20LTGN @B78LD 20LTGN / ELEC PANEL/ FR CAP (10001) CH10_04 / ELEC PANEL/ FR CAP (10001) CH10_04 / ELEC PANEL/ FRONT CAP (10001) CH10_04 / Figure 431 / HEATED AND MOTORIZED MIRROR (CONT.)

10.3. MOTORIZED MIRROR, P. 3
Figure 432 MOTORIZED MIRROR

Components: CIRCUIT (10010); FR CAP (10000); FR CAP (10001/10001); MIRROR (10048); MIRROR (10070); SPLICE (10356); SWITCH (10353); SWITCH (10354)
Wires (circuit gauge+color): B78D 18LTGN; B78RA 20LTGN; B78RB 20LTGN; B78RC 20LTGN; B78RD 20LTGN; B78RE 20LTGN; B78RF 20LTGN; C78 18LTGN; C78-G 18WH; C78-GB 18WH; C78A 18LTGN; C78B 18LTGN; C78RA 18LTGN; C78RB 18LTGN; C78RC 18LTGN; C78RD 18LTGN; C78RE 18LTGN; C78RF 18LTGN
See also sheets: CH10_01, CH10_02, CH10_04, CH3_44
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 10.3. MOTORIZED MIRROR, P. 3 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090661 95885P 29OCT20 / CHAPTER 10 / MOTORIZED MIRROR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / C78RB 18LTGN C78RF 18LTGN C78RC 18LTGN / L MOTORIZED MIRROR (10070) CH10_04 / 3 4 / *C78 18LTGN / C78RE 18LTGN C78RD 18LTGN C78RA 18LTGN / @C78-GB 18WH / RIGHT FLAT MIRROR MOTOR / RD RIGHT CONVEX MIRROR MOTOR INSIDE MIRROR / HEATER-FLAT MIRROR / HEATER-CONVEX MIRROR / ELEC PANEL/ FR CAP (10001/10001) / 3 4 / MOTORIZED MIRROR (10048) / B78RB 20LTGN B78RF 20LTGN B78RC 20LTGN / B78RE 20LTGN B78RD 20LTGN B78RA 20LTGN / @C78-G 18WH / @C78A 18LTGN / INSIDE MIRROR / DRIVER MIRROR SWITCH (10353) CH10_02 / PASSENGER MIRROR SWITCH (10354) CH10_02 / @C78B 18LTGN / 18LTGN @C78 / *C78-G 18WH / GROUND CIRCUIT (10010) CH3_44 / ELEC PANEL/ FR CAP (10000) B5 / HEATED MIRROR SPLICE (10356) CH10_01 / B78D 18LTGN / @ W/LEFT AND RIGHT MTZ/HTD MIRROR * W/RIGHT MTD/HTD MIRROR ONLY / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 432 / MOTORIZED MIRROR

10.4. MOTORIZED MIRROR (CONT.), P. 4
Figure 433 MOTORIZED MIRROR (CONT.)

Components: CIRCUIT (10010); ELEC PNL/FR CAP (10001/10001); MIRROR (10048); MIRROR (10070); SWITCH (10353); SWITCH (10354)
Wires (circuit gauge+color): B78LA 20LTGN; B78LB 20LTGN; B78LC 20LTGN; B78LD 20LTGN; B78LE 18LTGN; B78LF 20LTGN; C78-G 18WH; C78-GA 18WH; C78A 18LTGN; C78B 18LTGN; C78LA 18LTGN; C78LB 18LTGN; C78LC 18LTGN; C78LD 18LTGN; C78LE 18LTGN; C78LF 18LTGN
See also sheets: CH10_02, CH10_03, CH3_44
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 10.4. MOTORIZED MIRROR (CONT.), P. 4 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090661 NO. 95885P 29OCT20 / MOTORIZED MIRROR (CONT) / CHAPTER 10 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / C78-GA 18WH / C78-G 18WH / C78A 18LTGN / GROUND CIRCUIT (10010) CH3_44 / 16BN 16BN / 16BL 16BL / 16RD 16RD / RIGHT FLAT MIRROR MOTOR 1 1 / 3 4 RD RIGHT CONVEX MIRROR MOTOR INSIDE MIRROR / 3 4 / C78LB 18LTGN C78LF 18LTGN C78LC 18LTGN / C78LE 18LTGN C78LD 18LTGN C78LA 18LTGN / RD RD / B78LB 20LTGN B78LF 20LTGN B78LC 20LTGN / B78LE 18LTGN B78LD 20LTGN B78LA 20LTGN / ELEC PNL/FR CAP (10001/10001) / L MOTORIZED MIRROR (10070) / DRIVER MIRROR SWITCH (10353) CH10_02 / PASSENGER MIRROR SWITCH (10354) CH10_02 / INSIDE MIRROR / HEATER-FLAT MERROR / HEATER-CONVEX MIRROR / MOTORIZED MIRROR (10048) CH10_03 / C78B 18LTGN / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 433 / MOTORIZED MIRROR (CONT.)

10.5. HEATED MIRROR - LEFT AND RIGHT OVERHEAD, P. 5
Figure 434 HEATED MIRROR - LEFT AND RIGHT OVERHEAD

Components: FRONT CAP/ELEC PANEL (10000); HEATED MIRROR (10023); HEATED MIRROR (10024); SPLICE (10010); SPLICE (10356)
Wires (circuit gauge+color): B78D 18LTGN; C78 18LTGN; C78-G 18WH; C78-GL 18WH; C78-GR 18WH; C78L 18LTGN; C78R 18LTGN
See also sheets: CH10_01, CH3_44
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 10.5. HEATED MIRROR - LEFT AND RIGHT OVERHEAD, P. 5 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090661 95885P 29OCT20 / CHAPTER 10 HEATED MIRROR - LEFT AND RIGHT OVERHEAD / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / HEATED MIRROR (10024) A / *C78R 18LTGN / HEATED MIRROR SPLICE (10356) CH10_01 / *C78-GR 18WH #C78-GR 18WH / REARVIEW HEATED MIRROR / GROUND SPLICE (10010) CH3_44 / #C78R 18LTGN / #C78-GL 18WH / HEATED MIRROR (10023) A / #C78L 18LTGN / REARVIEW HEATED MIRROR / #C78-G 18WH / #C78 18LTGN / FRONT CAP/ELEC PANEL (10000) B5 / B78D 18LTGN / * W/HTD MIRROR, RIGHT OVERHEAD ONLY # W/HTD MIRROR, LEFT AND RIGHT OVERHEAD / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 434 / HEATED MIRROR - LEFT AND RIGHT OVERHEAD

10.6. HEATED CROSSVIEW MIRRORS, P. 6
Figure 435 HEATED CROSSVIEW MIRRORS

Components: COVER MIRROR (11519); ELEC PANEL (11500); GROUND SPLICE (11507); SPLICE (10356)
Wires (circuit gauge+color): B78J 18LTGN; Y78-GA 16WH; Y78A 16LTGN
See also sheets: CH10_01, CH3_48
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 10.6. HEATED CROSSVIEW MIRRORS, P. 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090661 95885P 29OCT20 / HEATED CROSSVIEW MIRRORS / CHAPTER 10 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SEALED ENGINE/ ELEC PANEL (11500) B2 / Y78-GA 16WH / Y78A 16LTGN / LEFT HEATED COVER MIRROR (11519) / DRIVER SIDE CROSSVIEW HEATED MIRROR / B78J 18LTGN / HEATED MIRROR SPLICE (10356) CH10_01 / GROUND SPLICE (11507) CH3_48 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 435 / HEATED CROSSVIEW MIRRORS

10.7. HEATED AND MOTORIZED MIRROR WITH LOWER MOUNT, P. 7
Figure 436 HEATED AND MOTORIZED MIRROR WITH LOWER MOUNT

Components: MIRROR (10070); MIRROR (10355); SPLICE (10337); SWITCH (10353); SWITCH (10354)
Wires (circuit gauge+color): B78-GA 18WH; B78AB 20LTGN; B78N 20LTGN; B78P 18LTGN; B78S 20LTGN; B78T 18LTGN; B78V 20LTGN; B78X 20LTGN; B78Z 20LTGN
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 10.7. HEATED AND MOTORIZED MIRROR WITH LOWER MOUNT, P. 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090661 95885P 19APR21 / CHAPTER 10 HEATED & MOTORIZED MIRROR W/LOWER MOUNT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / INSIDE MIRROR LEFT FLAT MIRROR MOTOR 1 BL 2 BN 3 4 / E D F / BL BN RD / L MOTORIZED MIRROR (10070) A B C / RD LEFT CONVEX MIRROR MOTOR / 1 2 3 / HEATER-CONVEX MIRROR 1 BL 2 BN 3 / DRIVER SIDE HEATED MIRROR LOCATED BELOW / 1 2 3 4 / OR GN YL / RD HEATER-FLAT MIRROR / 16OR 16GN 16YL / 16BL 16BN 16RD / B F C / DRIVERS MIRROR (10355) E D A / B78T 18LTGN B78AB 20LTGN B78Z 20LTGN / B78P 18LTGN B78X 20LTGN B78V 20LTGN / B78-GA 18WH / GROUND SPLICE (10337) CH3_95L / INSIDE MIRROR / PASSENGER MIRROR SWITCH (10353) 7 3 1 / B78N 20LTGN / B78S 20LTGN / 7 PASSENGER 3 MIRROR SWITCH 1 (10354) / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 436 / HEATED AND MOTORIZED MIRROR WITH LOWER MOUNT

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 477 | printed page 437 | section
ENGINE AND ENGINE SYSTEM (CHAPTER 11)
Figure 437 ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: BLOCK (6303E); ECM CONN (6021); FUSE (4104); FUSE A3-K (1016); FUSE F17 (1011); FUSE F18 (1011); IGNITION FAN RELAY (4014); PLATFORM (1701/1701); POSITION SENSOR (1804); POSITIVE CONN (9261); SIGNAL (1109)
Wires (circuit gauge+color): K97-GV 10WH; K97-GVA 16WH; K97-GVB 16WH; K97-GVC 16WH; K97-GW 10WH; K97-GWA 16WH; K97-GWB 16WH; K97UD 18RD
See also sheets: CH11_08, CH3_05, CH3_06, CH3_64
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / ENGINE AND ENGINE SYSTEM (CHAPTER 11) / 11.1. ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 1 / CHAPTER 11 ELECTRONIC ENG CONTROL W/2017/2021 ISB/B6.7 DIESEL ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. ECM CONN (6021) / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS, RELEASE NO. PART AE08090662 NO. 95885P 22DEC20 / MJV0488 22SEP21 CHANGED SYMBOL FOR 1804. / K97FAC 16VT K97FBA 16VT K97FBB 16VT / K97FAA 16VT / K97FA 10VT / K97 10VT / K97FAB 16VT / K97FB 10VT / K97UE 18VT / K97UC 14VT / *K97UA 18VT #K97UA 14VT / ENG/ PLATFORM !A97UA (1701/1701) 18VT 21 ^A97UA 18VT / FUSE F17 (1011) CH3_94C FUSE A3-K (1016) CH3_05 ACCELERATOR POSITION SENSOR (1804) B / K97R 20VT K99A 20VT K97C 20VT **K97WC 20VT / **K99F 20VT **K99DA 20VT / %K97HS 18VT @K97HS 18VT / K97-GVC 16WH K97-GVB 16WH K97-GVA 16WH K97-GWB 16WH K97-GWA 16WH / K97-GV 10WH / SOLENOID SIGNAL (1109) / ECM ENG GROUND BLOCK (6303E) / *K97UB 14VT / **K99D 20VT / KEY PWR FUSE (4104) B A 5A / K97UD 18RD / IGNITION FAN RELAY (4014) CH11_08 / BATT ECM POSITIVE CONN (9261) CH3_64 / A97R 18VT A99A 18VT A97C 18VT A97WC 18PL !A99F 18PL ^A99F 18VT A99D 18VT / FUSE A3-J ^(1016) CH3_06 FUSE F18 (1011) CH3_94C / &A99F 18VT / !A99F 18VT / Figure 437 / ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

11.2. ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE
Figure 438 ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

Components: CES (6370); ECM CONN (6021); INTERCONNECTION KEY B (6366/6366A); LEVEL/QUALITY (6369); NEGATIVE CONN (9260); RELAY (4103); RELAY (4116); RETURN (1110); RETURN (6706M); SOLENOID (4111M); SOLENOID CONN (6375)
Wires (circuit gauge+color): K23-G 20WH; K6A 18GY; K95-GA 20TN; K95-GG 12WH; K95-GJ 14WH; K95A 20TN; K95AA 18WH; K95B 20TN; K95C 20TN; K95D 20TN; K95E 18TN; K95EA 20TN; K95FA 20TN; K95H 20TN; K95J 20TN; K95M 20TN; K95N 20TN; K95XD 14TN; K97-G 20WH; K97-GGR 18WH; K97-GRS 20WH; K9A 20GY; K9A 20TN; K9AA 20GY; K9AA 20TN
See also sheets: CH11_06, CH11_07, CH11_08, CH3_64
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 11.2. ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 2 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090662 NO. RELEASE NO. 95885P 22DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ECM CONN (6021) / POWERTRAIN/DEF INTERCONNECTION KEY B (6366/6366A) 2 95J 18TN 95FA 18TN 95N 18TN 95M 18TN / K95EA 20TN K95J 20TN K95FA 20TN K95N 20TN / DEF PUMP SUPPLY MODULE (680) CH11_07 COOLANT VALVE SOLENOID CONN (6375) CH11_07 / CES (6370) / 95D 18TN 95H 18TN 95B 18TN 95C 18TN 95A 18TN 6A 18TN 9A 18TN / K95D 20TN K95H 20TN K95B 20TN K95C 20TN K95A 20TN K99DA 20VT %K9AA 20GY *K9AA 20TN / 77 8 / K6A 18GY K9A 20GY *K9A 20TN K95-GG K95-GJ 12WH 14WH BATT ECM NEGATIVE CONN (9260) CH3_64 %K95XD 14TN K5H(-) 18GN K5H(+) 18YL / POWERTRAIN/CES INTERCONNECTION KEY A (*6365B/%6365/6365A) 3 / *K97-GRS 20WH K95M 20TN K95AA 18WH / ECM GENERAL RETURN (6706M) / 57 54 / K97-GGR 18WH / K23-G 20WH / K97-G 20WH / 95-GJ 16WH / 16 53 / 95XD 14PK 5A(-) 18GN 5A(+) 18YL 5HD(+) 5HE(+) 18YL 18YL 5HD(-) 5HE(-) 18GN 18GN / K95E 18TN / DEF PUMP RELAY (4103) CH11_06 / DEF TANK LEVEL/QUALITY (6369) CH11_07 / %K95-GA 20TN / * N/16.5 GAL DEF TANK % W/16.5 GAL DEF TANK / Figure 438 / ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

11.3. ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE
Figure 439 ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

Components: A/C PRESSURE SW (6201); ECM CONN (6021); FAN AIR SOLENOID (4111M); FAN DRIVE RELAY (4116); HTR LINE (6372); HTR LINE (6373); HTR LINE (6374); HTR RELAY (4011); HTR RELAY (4012); HTR RELAY (4013); INTERCONNECT KEY B (6366/6366A)
Wires (circuit gauge+color): K23 20TN; K23A 20TN; K77B 20LTGN; K95P 18TN; K95PA 18TN; K95PB 20TN; K95R 18TN; K95RA 18TN; K95RB 20TN; K95S 18TN; K95SA 18TN; K95SB 20TN; K95V 18TN; K95VA 20TN; K95VB 18TN; K95VC 18TN; K97-GS 20WH; K97-GSP 18WH
See also sheets: CH11_05, CH11_07, CH11_08
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 11.3. ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 3 / CHAPTER 11 ELECTRONIC ENG CONTROL W/2017/2021 ISB/B6.7 DIESEL ENGINE (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090662 NO. RELEASE NO. 95885P 22DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ECM CONN (6021) / POWERTRAIN/DEF INTERCONNECT KEY B (6366/6366A) K95P 8 18TN / K95PB 20TN / K95PA 18TN K95VC 18TN K95RA 18TN K95VA 20TN K95SA 18TN K95VB 18TN / K95RB 20TN / K95R 18TN / SUCTION LINE HTR RELAY (4012) CH11_05 / K95SB 20TN / K95S 18TN / K95V 18TN / PRESSURE LINE HTR RELAY (4011) CH11_05 / BACKFLOW LINE HTR RELAY (4013) CH11_05 / 95P 16TN / 95R 16TN / 95S 16TN / PRESSURE HTR LINE (6372) CH11_07 BACKFLOW HTR LINE (6374) CH11_07 SUCTION HTR LINE (6373) CH11_07 / #K23A 20TN / FAN DRIVE RELAY (4116) CH11_08 FAN AIR SOLENOID (4111M) CH11_08 / @K23 20TN / K77B 20LTGN / A/C PRESSURE SW (6201) / K97-GSP 18WH / # W/ ELECTRIC CLUTCH FAN W/BCM 4TH GEN @ W/ HORTON FAN / K97-GS 20WH / W/LOW COOLANT SENSOR WRG / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 439 / ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

11.4. ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE
Figure 440 ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

Components: ECM CONN (6021); SENSOR (6401); TEMP (6715); WIF SENSOR (6710)
Wires (circuit gauge+color): K97-GS 20WH; K97-GSC 18WH; K97-GSW 18WH
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 11.4. ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 4 / CHAPTER 11 ELECTRONIC ENG CONTROL W/2017/2021 ISB/B6.7 DIESEL ENGINE (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090662 NO. RELEASE NO. 95885P 22DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ECM CONN (6021) / AMBIENT AIR TEMP (6715) A / K97AB 20VT K97-GS 20WH / K97-GSA 20VT / K97-GSC 18WH K97LCL 18VT / K97LCS 20VT / K97-GSW 18WH K97WIF 18VT / K97WI 20VT / LOW COOLANT SENSOR (6401) / WIF SENSOR (6710) / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 440 / ELECTRONIC ENGINE CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

Figure 441 DEF AND AFTERTREATMENT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: ECM CONN (6021); HTR FUSE (4109); HTR RELAY (4011); HTR RELAY (4012); MEGA FUSE STUD (4001A); RELAY (4013)
Wires (circuit gauge+color): K14H 14RD; K14HA 12RD; K14HB 18RD; K14HC 18RD; K14HD 18RD; K14K 12RD; K14KA 18RD; K14KB 18RD; K14KC 18RD; K14SCR 10RD; K95PA 18TN; K95PB 20TN; K95RA 18TN; K95RB 20TN; K95SA 18TN; K95SB 20TN; K95V 18TN; K95VA 20TN; K95VB 18TN; K95VC 18TN
See also sheets: CH11_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 11.5. DEF AND AFTERTREATMENT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 5 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090662 95885P 22DEC20 / CHAPTER 11 DEF AND AFTERTREATMENT W/2017/2021 ISB/B6.7 DIESEL ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K95VC 18TN K95PA 18TN / K95V 18TN K95PB 20TN / PRESSURE LINE HTR RELAY (4011) / K14KA 18RD 1 30 / K14KC 18RD / K14HB 18RD 2 86 / K14K 12RD / BACKFLOW LINE HTR RELAY (4013) / K14HA 12RD / SUCTION LINE HTR RELAY (4012) / K95VB 18TN K95SA 18TN / K95V 18TN K95SB 20TN / K95RA 18TN / SCR PWR LOWER MEGA FUSE STUD (4001A) / K95RB 20TN / SCR LINE HTR FUSE (4109) K14H 14RD A B 15A / K14SCR 10RD / 85 5 / K14HC 18RD 2 86 / 1 30 / 85 5 / K14KB 18RD / K14HD 18RD 2 86 / 1 30 / K95VA 20TN / 85 5 / ECM CONN (6021) CH11_03 / ECM CONN (6021) CH11_03 / ECM CONN (6021) CH11_03 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 441 / DEF AND AFTERTREATMENT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

11.6. DEF AND AFTERTREATMENT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE
Figure 442 DEF AND AFTERTREATMENT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

Components: AFTER TREATMENT FUSE (4107); CES (6370); CONN (9261); CONNECTION (9260); CROSS OVER (6022); ECM CONN (6021); FUSE STUD (4001A); HTR FUSE (4108); INTERCONNECT KEY A (6365/6365A); INTERCONNECT KEY B (6366/6366A); LEVEL/QUALITY (6369); PWR RELAY (4101); RELAY (4103); RETURN (6706M)
Wires (circuit gauge+color): K14E 12RD; K14EA 12RD; K14M 14RD; K14PB 12RD; K14SCR 10RD; K14XA 14GY; K14Y 18TN; K95-GG 10WH; K95-GG 12WH; K95-GHA 18WH; K95-GK 18WH; K95AA 18WH; K95E 18TN; K95EA 20TN; K95MC 20TN; K95TB 18GY; K95XA 14TN; K95XB 14TN; K95XC 18TN; K95XD 14TN; K95XE 14TN; K95XF 18TN; K95XG 14TN
See also sheets: CH11_02, CH11_07, CH3_64
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 11.6. DEF AND AFTERTREATMENT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090662 NO. RELEASE NO. 95885P 22DEC20 / CHAPTER 11 DEF AND AFTER TREATMENT W/2017/2021 ISB/B6.7 DIESEL ENGINE (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K14M 14RD / AFTER TREATMENT FUSE (4107) B A 15A / K95XD 14TN / CUMMINS CROSS OVER (6022) / AFTER TREATMENT PWR RELAY (4101) 85 5 K95TB 18GY / 2 86 / 1 30 DEF PUMP RELAY (4103) / K14EA 12RD / K14E 12RD / 85 5 K14PB 12RD / ECM CONN (6021) CH11_02 / K95-GG BATT ECM 12WH NEGATIVE CONNECTION K95-GG (9260) 10WH CH3_64 SCR SUPPLY MODULE HTR FUSE (4108) B A 10A / K95XB 14TN 1 30 / DEF TANK LEVEL/QUALITY (6369) CH11_07 DEF PUMP SUPPLY MODULE (680) CH11_07 / K95XC 18TN 2 86 / K95-GHA 18WH / K95EA 20TN / K95E 18TN NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / K14SCR 10RD / POWERTRAIN/CES INTERCONNECT KEY A (6365/6365A) 12 / K95XF 18TN K5H(-) 18GN K5H(+) 18YL / 95XD 14PK 5A(-) 18GN 5A(+) 18YL / 95XA 18PK 95MC 18TN 14X 16TN / CES (6370) CH11_02 / K95MC 20TN K14Y 18TN / K95XA 14TN / 4 K95XG 14TN / SCR PWR LOWER MEGA FUSE STUD (4001A) / POWERTRAIN/DEF INTERCONNECT KEY B (6366/6366A) 12 / K95XE 14TN / K95-GK 18WH / K14XA 14GY / K95AA 18WH / ECM GENERAL RETURN (6706M) CH11_02 / BATT ECM POSITIVE CONN (9261) CH3_64 / Figure 442 / DEF AND AFTERTREATMENT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

11.7. DEF AND AFTERTREATMENT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE
Figure 443 DEF AND AFTERTREATMENT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

Components: BACKFLOW HTR LINE (6374); CES (6370); CONN (6021); CROSSOVER (6022); DEF TANK LEVEL/QUALITY (6369); INTERCONNECT KEY B (6366/6366A); NEG CONN (9260); NEGATIVE CONN (9260); PRESSURE HTR LINE (6372); RESISTOR (7802M); RETURN (6706M); SOLENOID CONN (6375); SUCTION HTR LINE (6373)
Wires (circuit gauge+color): K14XA 14GY; K14Y 18TN; K95-GG 12WH; K95-GH 12WH; K95-GH 14WH; K95-GH1 18WH; K95-GH2 18TN; K95-GK 14WH; K95FA 20TN; K95J 20TN; K95M 20TN; K95MC 20TN; K95N 20TN; K95P 18TN; K95PB 20TN; K95R 18TN; K95RB 20TN; K95S 18TN; K95SB 20TN; K95XE 14TN; K95XF 18TN
See also sheets: CH11_02, CH11_03, CH11_06, CH3_64
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 11.7. DEF AND AFTERTREATMENT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090662 NO. RELEASE NO. 95885P 22DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 1 2 / ECM CONN (6021) CH11_02 / K95-GH 14WH / 1 2 5 / K95MC 20TN K14Y 18TN K95FA 20TN K95J 20TN K95N 20TN / 5HE(-) CES 18GN (6370) CH11_02 5HE(+) 18YL NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / 95GH2 18WH / K95-GG 12WH / OHMS 120 / 95R 16TN 95GH1 16TN / J1939 TERMINATING RESISTOR (7802M) / K95PB 20TN / K95SB 20TN / K95XF 18TN / BATT ECM NEGATIVE CONN (9260) CH3_64 CUMMINS CROSSOVER (6022) CH11_06 / K95R 18TN K95-GH1 18WH / K14XA 14GY / 95ZC 16TN / K95P 18TN / PRESSURE HTR LINE (6372) / 1 2 SUCTION HTR LINE (6373) / ECM GENERAL RETURN (6706M) CH11_02 / 5HC(+) 18YL / 95N 18TN 95M 18TN / K95XE 14TN 5HC(-) 18GN / 4 3 / 95S 16TN / K95-GH2 18TN / 95ZE 16TN / K95M 20TN / 95ZD 16TN DEF TANK LEVEL/QUALITY (6369) 3 / 5HD(+) 18YL / 5HD(-) 18GN / ECM CONN (6021) CH11_03 / COOLENT VALVE SOLENOID CONN (6375) / K95S 18TN / BACKFLOW HTR LINE (6374) / 95P 16TN / 95XA 18PK / K95RB 20TN / DEF PUMP SUPPLY MODULE (680) / CUMMINS CROSSOVER (6022) CH11_06 / BATT ECM NEG CONN (9260) CH3_64 / K95-GH 12WH / K95-GK 14WH / Figure 443 / DEF AND AFTERTREATMENT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

11.8. FAN WIRING WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 8
Figure 444 FAN WIRING WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: ECM CONN 1 (6021); FAN AIR SOLENOID (4111M); FAN CLUTCH (6406M); FAN FUSE (4115); FUSE (4104); FUSE (4111); FUSE STUD (4001A); RELAY (4014); RELAY (4116); RETURN (6706M); SPLICE (6704M)
Wires (circuit gauge+color): K14NA 14RD; K14P 14RD; K14SCR 10RD; K23 18TN; K23 20TN; K23-G 18WH; K23-G 20WH; K23-G1 20TN; K23-G2 18WH; K23A 20TN; K23B 14RD; K95XH 14RD; K97-G 20WH; K97UD 18RD
See also sheets: CH11_01, CH11_02, CH11_03, CH3_61
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 11.8. FAN WIRING WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 8 / CHAPTER 11 FAN WIRING W/2017/2021 ISB/B6.7 DIESEL ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090662 95885P 22DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / %K23-G 20WH / %K23 20TN #K23A 20TN / FAN AIR SOLENOID (4111M) / #K23B 14RD / FAN FUSE (4115) #K95XH B 14RD 10A A / FAN CLUTCH (6406M) 2 / #K23-G2 18WH / GROUND SPLICE (6704M) CH3_61 / IGN FAN RELAY (4014) / ECM CONN 1 (6021) CH11_03 / ECM NEUTRAL RETURN (6706M) CH11_02 / K23-G 18WH / #K14P 14RD / IGN FAN FUSE (4111) *K14NA B A 14RD 20A / SCR PWR LOWER MEGA FUSE STUD (4001A) K14SCR 10RD / % W/HORTON FAN # W/ELECTRIC CLUTCH FAN W/BCM 4TH GEN * N/EATON TRANSMISSION / 87 4 / 2 86 / 1 30 / 85 5 / #K97UD 18RD / #K97UB 14VT / KEY PWR FUSE (4104) CH11_01 / #K23-G1 20TN / 85 5 / 2 86 / 1 30 / 87A 3 / FAN DRIVE RELAY (4116) / #K23 18TN / ECM NEUTRAL RETURN (6706M) CH11_02 / #K97-G 20WH / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 444 / FAN WIRING WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

11.9. FREON COMPRESSOR WIRING WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 9
Figure 445 FREON COMPRESSOR WIRING WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: CLUTCH O/P (4206); ENG/PLATFORM (1701/1701); SPLICE (6704M)
Wires (circuit gauge+color): A77G 18LTGN; K77A 16LTGN; K77A-G 16WH; K77B 16LTGN
See also sheets: CH3_61
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 11.9. FREON COMPRESSOR WIRING WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 9 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090662 95885P 22DEC20 / CHAPTER 11 FREON COMPRESSOR WIRING W/2017/2021 ISB/B6.7 DIESEL ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K77A 16LTGN / ENG/PLATFORM (1701/1701) 61 / A77G 18LTGN / A/C COMPRESSOR CLUTCH O/P (4206) / K77A-G 16WH / FREON COMPRESSOR %(6200) / FREON COMPRESSOR @(6202) / @K77A-G 16WH / @K77B 16LTGN / GROUND SPLICE (6704M) CH3_61 / @ W/FREON COMPRESSOR W/2021 % W/FREON COMPRESSOR W/2017 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 445 / FREON COMPRESSOR WIRING WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

11.10. ELECTRONIC ENGINE CONTROL WITH F-2018 PROPANE ENGINE, P. 10
Figure 446 ELECTRONIC ENGINE CONTROL WITH F-2018 PROPANE ENGINE

Components: CONN (6021); ENG/PLATFORM (1701/1701); FUEL PUMP RELAY (4103); POSITION SENSOR (1804); RELAY (4116); VALVE RELAY (4016)
Wires (circuit gauge+color): K17RD 16RD; K37CC 18TN; K37DC 18TN; K37EC 18TN
See also sheets: CH4_02, CH5_17
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 11.10. ELECTRONIC ENGINE CONTROL WITH F-2018 PROPANE ENGINE, P. 10 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS, PART NO. RELEASE NO. AE08090662 95885P 22DEC20 / CHAPTER 11 ELECTRONIC ENGINE CONTROLW/F-2018- PROPANE-ENGINE / MJV0488 22SEP21 CHANGED SYMBOL FOR 1804. / VEHICLE INTERFACE CONN (6021) / K97R 18VT K99A 18VT K97C 18VT K97WC 18VT K99D 18VT K99F 18VT / A97R 18VT A99A 18VT A97C 18VT A97WC 18PL A99D 18VT A99F 18PL / ACCELERATOR POSITION SENSOR (1804) B / K37CC 18TN K37DC 18TN / FUEL RETURN VALVE RELAY (4016) CH5_17 FUEL SUPPLY VALVE RELAY (4011) CH5_17 FUEL PUMP RELAY (4103) CH5_17 ECM CONTROL RELAY (4116) CH4_02 / K37EC 18TN / K17RD 16RD / ENG/PLATFORM (1701/1701) / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 446 / ELECTRONIC ENGINE CONTROL WITH F-2018 PROPANE ENGINE

Figure 447 ELECTRONIC ENGINE CONTROL WITH F-2018 PROPANE ENGINE (CONT.)

Components: CLEAN GROUND (9260); CLEAN PWR (9261); CONN (6021); ECM FUSE (4108); INJ 1 FUSE (4109); INJ 2 FUSE (4110); PTIGN 1 FUSE (4006); PTIGN 2 FUSE (4017); RELAY (4007)
Wires (circuit gauge+color): K97 10RD; K97-G 12WH; K97JA 12RD; K97JB 12RD; K97KA 12RD; K97KB 12RD; K97KC 18RD; K97KD 18RD; K97P 6RD; K97PA 12RD; K97PB 12RD; K97PC 10RD; K97PD 10RD; K97PE 10RD
See also sheets: CH3_65
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 11.11. ELECTRONIC ENGINE CONTROL WITH F-2018 PROPANE ENGINE (CONT.), P. 11 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090662 NO. 95885P 22DEC20 / CHAPTER 11 ELECTRONIC ENGINE CONTROL W/F-2018-PROPANE- ENGINE(CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / POWERTRAIN RELAY (4007) / 2 86 / 87A 3 / 1 30 / 85 5 / K97KE 18VT / K97KD 18RD / K97KC 18RD / ECM FUSE (4108) K97KA K97KB 12RD 12RD A 10A B / K97PE 10RD / K97 10RD / K97PBC 14VT / K97PBB 12VT / PTIGN 2 FUSE (4017) K97PB 12RD B A 10A PTIGN 1 FUSE (4006) K97PA B A 12RD 10A / K97PAC 14VT / K97PAB 12VT / K97PD 10RD / INJ 1 FUSE (4109) B A 10A INJ 2 FUSE (4110) K97JB B A 12RD 10A / K97JAB 12VT / K97JA 12RD / K97JBB 12VT / K97PC 10RD / K97JAC 16VT / K97JBC K97JBC 16VT 16VT / VEHICLE INTERFACE CONN (6021) / BATT POSITIVE CLEAN PWR (9261) CH3_65 C / BATT NEGATIVE CLEAN GROUND (9260) CH3_65 C / K97-G 12WH / K97P 6RD / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 447 / ELECTRONIC ENGINE CONTROL WITH F-2018 PROPANE ENGINE (CONT.)

11.12. FREON COMPRESSOR WIRING WITH F-2018 PROPANE ENGINE, P. 12
Figure 448 FREON COMPRESSOR WIRING WITH F-2018 PROPANE ENGINE

Components: AC COMPRESSOR (6200); CLEAN GROUND (9260); CLUTCH OUTPUT (4206); CONN (6021); FUSE STUD (4000A); PLATFORM (1701); RELAY (4018); VALVE FUSE (4107)
Wires (circuit gauge+color): A77G 18LTGN; K77A 14GY; K77B 18RD; K77C 14RD; K77D 18RD; K77E 16LTGN; K77F 18LTGN; K77G 18LTGN; K77H-G 16WH
See also sheets: CH3_65
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 11.12. FREON COMPRESSOR WIRING WITH F-2018 PROPANE ENGINE, P. 12 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090662 95885P 22DEC20 / CHAPTER 11 FREON COMPRESSOR WIRING W/F-2018-PROPANE- ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ENG/ 61 PLATFORM (1701) / FREON COMPRESSOR RELAY (4018) / 1 30 / 2 86 / 85 5 / 87A 3 / K77D 18RD / K77A 14GY / VALVE FUSE (4107) / LOWER MEGA FUSE STUD (4000A) / K77C 14RD / K77B 18RD / K77F 18LTGN / K77G 18LTGN / VEHICLE INTERFACE CONN (6021) / K77E 16LTGN / K77H-G 16WH / 18LTGN A77G / AC COMPRESSOR CLUTCH OUTPUT (4206) / BATT NEGATIVE CLEAN GROUND (9260) CH3_65 / AC COMPRESSOR (6200) / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 448 / FREON COMPRESSOR WIRING WITH F-2018 PROPANE ENGINE

11.13. ELECTRONIC ENGINE CONTROL WITH F-2018 GASOLINE ENGINE, P. 13
Figure 449 ELECTRONIC ENGINE CONTROL WITH F-2018 GASOLINE ENGINE

Components: CONN (6021); ENG/PLATFORM (1701/1701); FUEL PUMP RELAY (4103); POSITION SENSOR (1804); VALVE RELAY (4011)
Wires (circuit gauge+color): K10D-G 18WH; K37EC 18TN
See also sheets: CH5_15
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 11.13. ELECTRONIC ENGINE CONTROL WITH F-2018 GASOLINE ENGINE, P. 13 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS, PART NO. RELEASE NO. AE08090662 95885P 22DEC20 / CHAPTER 11 ELECTRONIC ENGINE CONTROL W/F-2018-GASOLINE- ENGINE / MJV0488 22SEP21 CHANGED SYMBOL FOR 1804. / VEHICLE INTERFACE CONN (6021) / K97R 18VT K99A 18VT K97C 18VT K97WC 18VT K99D 18VT K99F 18VT / A97R 18VT A99A 18VT A97C 18VT A97WC 18PL A99D 18VT A99F 18PL / ENG/PLATFORM (1701/1701) 47 / ACCELERATOR POSITION SENSOR (1804) / K37EC 18TN / K10D-G 18WH / FUEL PUMP RELAY (4103) CH5_15 FUEL SUPPLY VALVE RELAY (4011) CH5_15 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 449 / ELECTRONIC ENGINE CONTROL WITH F-2018 GASOLINE ENGINE

11.14. ELECTRONIC ENGINE CONTROL WITH F-2018 GASOLINE ENGINE (CONT.), P. 14
Figure 450 ELECTRONIC ENGINE CONTROL WITH F-2018 GASOLINE ENGINE (CONT.)

Components: CLEAN GROUND (9260); CLEAN PWR (9261); ECM FUSE (4108); INJ 1 FUSE (4109); INJ 2 FUSE (4110); INTERFACE CONN (6021); PTIGN 1 FUSE (4006); PTIGN 2 FUSE (4017); RELAY (4007); VALVE RELAY (4011)
Wires (circuit gauge+color): K37DC 18TN; K97 10RD; K97-G 12WH; K97JA 12RD; K97JB 12RD; K97KA 12RD; K97KB 12RD; K97KC 18RD; K97KD 18RD; K97P 6RD; K97PA 12RD; K97PB 12RD; K97PC 10RD; K97PD 10RD; K97PE 10RD
See also sheets: CH3_66, CH5_15
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 11.14. ELECTRONIC ENGINE CONTROL WITH F-2018 GASOLINE ENGINE (CONT.), P. 14 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090662 95885P 22DEC20 / CHAPTER 11 ELECTRONIC ENGINE CONTROL W/F-2018-GASOLINE- ENGINE (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / POWERTRAIN RELAY (4007) / 2 86 / 87A 3 / 1 30 / 85 5 / K97KE 18VT / K37DC 18TN K97KD 18RD / K97KC 18RD / ECM FUSE (4108) K97KA K97KB 12RD A B 12RD 10A / K97PE 10RD / K97 10RD / K97PBC 14VT / K97PBB 12VT / PTIGN 2 FUSE (4017) K97PB B 12RD 10A A PTIGN 1 FUSE (4006) K97PA B A 12RD 10A / K97PAC 14VT / K97PAB 12VT / K97PD 10RD K97PC 10RD / INJ 1 FUSE (4109) B A 10A INJ 2 FUSE (4110) K97JB B A 12RD 10A / K97JAB 12VT / K97JA 12RD / K97JBB 12VT / K97JAC 16VT / K97JBC K97JBC 16VT 16VT / VEHICLE INTERFACE CONN (6021) / BATT POSITIVE CLEAN PWR (9261) CH3_66 C / BATT NEGATIVE CLEAN GROUND (9260) CH3_66 C / K97-G 12WH / K97P 6RD / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / FUEL SUPPLY VALVE RELAY (4011) CH5_15 / Figure 450 / ELECTRONIC ENGINE CONTROL WITH F-2018 GASOLINE ENGINE (CONT.)

11.15. FREON COMPRESSOR WIRING WITH F-2018 GASOLINE ENGINE, P. 15
Figure 451 FREON COMPRESSOR WIRING WITH F-2018 GASOLINE ENGINE

Components: AC COMPRESSOR (6200); CLEAN GROUND (9260); CLUTCH OUTPUT (4206); CONN (6021); FUSE (4114); FUSE STUD (4000A); PLATFORM (1701); RELAY (4018)
Wires (circuit gauge+color): A77G 18LTGN; K77A 14RD; K77B 18RD; K77C 14RD; K77D 18RD; K77E 16LTGN; K77F 18LTGN; K77G 18LTGN; K77H-G 16WH
See also sheets: CH11_14
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 11.15. FREON COMPRESSOR WIRING WITH F-2018 GASOLINE ENGINE, P. 15 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090662 95885P 22DEC20 / CHAPTER 11 FREON COMPRESSOR WIRING W/F-2018-GASOLINE- ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ENG/ 61 PLATFORM (1701) / FREON COMPRESSOR RELAY (4018) / 1 30 / 2 86 / 85 5 / 87A 3 / K77D 18RD / K77A 14RD / AC COMPRESSOR FUSE (4114) / UPPER MEGA FUSE STUD (4000A) / K77C 14RD / B 10A A / K77B 18RD / K77F 18LTGN / K77G 18LTGN / VEHICLE INTERFACE CONN (6021) / K77E 16LTGN / K77H-G 16WH / 18LTGN A77G / AC COMPRESSOR CLUTCH OUTPUT (4206) / BATT NEGATIVE CLEAN GROUND (9260) CH11_14 / AC COMPRESSOR (6200) / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 451 / FREON COMPRESSOR WIRING WITH F-2018 GASOLINE ENGINE

11.16. FREON COMPRESSOR WIRING WITH F-2018 PROPANE / GASOLINE ENGINE, P. 16
Figure 452 FREON COMPRESSOR WIRING WITH F-2018 PROPANE / GASOLINE ENGINE

Components: CLEAN GROUND (9260); FUSE 2 (4117); FUSE STUD 2 (4000F); INTERCONNECTION (6200A); PLATFORM (1701); RELAY (1027A); RELAY (4018); RELAY (4019)
Wires (circuit gauge+color): A77C 18GY; K77AB 14GY; K77BB 14RD; K77CA 10RD; K77CB 14RD; K77DB 18RD; K77E 16LTGN; K77EB 16LTGN; K77FB 18LTGN; K77GB 18LTGN; K77HA-G 10WH; K77HB-G 16WH; K77HC-G 16WH
See also sheets: CH11_17, CH11_18, CH3_65
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 11.16. FREON COMPRESSOR WIRING WITH F-2018 PROPANE / GASOLINE ENGINE, P. 16 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090662 NO. 96289K 11OCT21 / CHAPTER 11 FREON COMPRESSOR WIRING W/F-2018-PROPANE/ GASOLINE-ENG / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / FREON COMPRESSOR RELAY (4019) / 1 30 / 2 86 / 85 5 / 87A 3 / K77DB 18RD / K77CB 14RD / FREON COMPRESSOR FUSE 2 (4117) / LOWER MEGA FUSE STUD 2 (4000F) K77CA 10RD / K77AB 14GY / K77BB 14RD / K77FB 18LTGN K77EB 16LTGN K77E 16LTGN / K77GB 18LTGN / ENG/ PLATFORM (1701) 64 / AC COMPRESSOR INTERCONNECTION (6200A) / NOTE: CONNECTIONS FOR VEHICLE N/0508108-NOT MTA FUSE BLOCK. / K77HC-G 16WH K77HB-G 16WH / FREON COMPRESSOR RELAY (4018) CH11_17 / A77C 18GY / DUAL AC RELAY (1027A) CH11_18 BATT NEGATIVE CLEAN GROUND (9260) CH3_65,66 / K77HA-G 10WH / Figure 452 / FREON COMPRESSOR WIRING WITH F-2018 PROPANE / GASOLINE ENGINE

11.17. FREON COMPRESSOR WIRING WITH F-2018 PROPANE / GASOLINE ENGINE
Figure 453 FREON COMPRESSOR WIRING WITH F-2018 PROPANE / GASOLINE ENGINE (CONT.)

Components: CLUTCH OUTPUT (4206); CONNECTOR (6021); ENGINE (1701); FUSE STUD 2 (4000F); INTERCONNECTION (6200A); RELAY (4018); VALVE FUSE (4107)
Wires (circuit gauge+color): K77A 14GY; K77B 18RD; K77C 14RD; K77CA 10RD; K77D 18RD; K77E 16LTGN; K77F 18LTGN; K77G 18LTGN
See also sheets: CH11_16
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 11.17. FREON COMPRESSOR WIRING WITH F-2018 PROPANE / GASOLINE ENGINE (CONT.), P. 17 / CHAPTER 11 FREON COMPRESSOR WIRING W/F-2018-PROPANE/ GASOLINE-ENG (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090662 NO. RELEASE NO. 96289K 07OCT21 / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / K77F 18LTGN / K77G 18LTGN / PLATFORM/ ENGINE 61 (1701) / AC COMPRESSOR CLUTCH OUTPUT (4206) / VEHICLE INTERFACE CONNECTOR (6021) / FREON COMPRESSOR RELAY (4018) / K77E 16LTGN / AC COMPRESSOR INTERCONNECTION (6200A) CH11_16 / K77B 18RD / K77A 14GY / AIR DRYER/ VALVE FUSE (4107) / K77C 14RD / K77CA 10RD / LOWER MEGA FUSE STUD 2 (4000F) / K77D 18RD / 18LTGN K77G / Figure 453 / FREON COMPRESSOR WIRING WITH F-2018 PROPANE / GASOLINE ENGINE (CONT.)

11.18. A / C COMPRESSOR WIRING WITH F-2018 PROPANE ENGINE, P. 18
Figure 454 A / C COMPRESSOR WIRING WITH F-2018 PROPANE ENGINE

Components: CONNECTOR (6021); ENGINE (1701); GROUND SPLICE (1003B); INTERCONNECTION (6200A); OUTPUT (4208); RELAY (1027A)
Wires (circuit gauge+color): A77A 18WH; A77B 18WH; A77C 18GY; A77E 14LTGN; A77F 18LTGN; A77H 18WH; K77G 18LTGN; K77GB 18LTGN
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 11.18. A / C COMPRESSOR WIRING WITH F-2018 PROPANE ENGINE, P. 18 / CHAPTER 11 A/C COMPRESSOR WIRING W/F-2018-PROPANE-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, PART NO. RELEASE NO. AE08090662 96289K 07OCT21 / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (1003B) CH3_95C / DUAL AC RELAY (1027A) / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / A77E 14LTGN / A77F 18LTGN / PLATFORM/ ENGINE (1701) / A77C 18GY / A77H 18WH / A77B 18WH / 18LTGN K77G / BUS BODY A/C COMPRESSOR TRANS AIR OUTPUT (4208) / A77A 18WH / VEHICLE INTERFACE CONNECTOR (6021) / K77GB 18LTGN / AC COMPRESSOR INTERCONNECTION (6200A) / Figure 454 / A / C COMPRESSOR WIRING WITH F-2018 PROPANE ENGINE

11.19. A / C COMPRESSOR WIRING WITH F-2018 GASOLINE ENGINE, P. 19
Figure 455 A / C COMPRESSOR WIRING WITH F-2018 GASOLINE ENGINE

Components: CONNECTOR (6021); CONTROL RELAY (1010-R4); ENGINE (1701); INTERCONNECT (6200A); OUTPUT (4208); SPLICE (1003B)
Wires (circuit gauge+color): A77A 18WH; A77B 18WH; A77C 18GY; A77E 14LTGN; A77F 18LTGN; A77H 18WH; K77G 18LTGN; K77GB 18LTGN
See also sheets: CH3_33
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 11.19. A / C COMPRESSOR WIRING WITH F-2018 GASOLINE ENGINE, P. 19 / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090662 96289K 07OCT21 / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / A77E 14LTGN / A77F 18LTGN / PLATFORM/ 64 ENGINE (1701) / 18LTGN K77G / BUS BODY A/C COMPRESSOR TRANS AIR OUTPUT (4208) / GROUND SPLICE (1003B) CH3_33 / DUAL A/C COMPRESSOR CONTROL RELAY (1010-R4) / VEHICLE INTERFACE CONNECTOR (6021) / K77GB 18LTGN / A/C COMPRESSOR INTERCONNECT (6200A) / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / A77C 18GY / A77B 18WH / A77A 18WH / A77H 18WH / Figure 455 / A / C COMPRESSOR WIRING WITH F-2018 GASOLINE ENGINE

Figure 456 ECONOMY MODE RELAY CONNECTIONS

Components: BODY CONTROLLER (1601); ENGINE (1701); RELAY (1011-R2); RELAY (1012-R5); SPLICE PACK (1003A)
Wires (circuit gauge+color): A103 18TN; A103A 18TN; A92-G 18WH; A92T 18TN
See also sheets: CH12_02, CH12_07, CH12_10, CH3_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / TRANSMISSION AND TRANSMISSION SYSTEM (CHAPTER 12) / 12.1. ECONOMY MODE RELAY CONNECTIONS, P. 1 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090663 NO. 95885P 22DEC20 / CHAPTER 12 ECONOMY MODE RELAY CONNECTIONS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J4-BLUE BODY CONTROLLER (1601) / ECONOMY MODE RELAY (1012-R5) / A92-G 18WH / ECONOMY MODE F11 RELAY / A92T 18TN / SHIFT INHIBIT RELAY (1011-R2) CH12_02 / A#142 16TN / @A103 18TN / @A103A 18TN / GROUND SPLICE PACK (1003A) CH3_32 / PLATFORM/ ENGINE (1701) CH12_10,18,21 / @ W/KEY OFF AIR PARK BRAKE INTERLOCK W/LIFT & W/LCT XMSN / PLATFORM/ ENGINE (1701) CH12_07,09,12,17,20 / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 456 / ECONOMY MODE RELAY CONNECTIONS

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 497 | printed page 457 | section 12.2
12.2. ECONOMY MODE RELAY CONNECTIONS (CONT.), P. 1A
Figure 457 ECONOMY MODE RELAY CONNECTIONS (CONT.)

Components: BODY CONTROLLER (1601); GEN 4 TCM (7150); GEN 5 TCM (7150); GROUND SPLICE PACK (1003A); RELAY (1026); SWITCH RELAY (1015)
Wires (circuit gauge+color): A103 18TN; A103A 18TN; A92-G 18WH; A92T 18TN
See also sheets: CH12_23, CH15_33
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.2. ECONOMY MODE RELAY CONNECTIONS (CONT.), P. 1A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090663 NO. 95885P 17MAR21 / CHAPTER 12 ECONOMY MODE RELAY CONNECTIONS (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / *A#142 16TN / 4 87A / 2 85 / 30 3 / 86 1 / J4-BLUE BODY CONTROLLER (1601) / ECONOMY MODE SWITCH RELAY (1015) / *A103A 18TN / A92-G 18WH / ECONOMY MODE F11 RELAY / A92T 18TN / GEN 4 TCM (7150) CH12_10A,23 / GROUND SPLICE PACK (1003A) CH3_95B / SHIFT INHIBIT RELAY (1026) CH12_2A SHIFT INHIBIT RELAY (1026) CH15_33 / * W/2017 ISB DISEL ENGINES W/WHEELCHAIR LIFT @ W/F-2018-PROP/GAS-ENG W/WHEELCHAIR LIFT / @A92#142 16TN / @A103 18TN / *A103 18TN / GEN 5 TCM (7150) CH12_23 / @A103A 18TN / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / Figure 457 / ECONOMY MODE RELAY CONNECTIONS (CONT.)

12.3. SHIFT INHIBIT RELAY CONNECTIONS, P. 2
Figure 458 SHIFT INHIBIT RELAY CONNECTIONS

Components: DIODE ASSY CONN (1014F); ECONOMY MODE RELAY (1012-R5); ENGINE (1701); FUSE A6-H (1014); RELAY (1011-R2)
Wires (circuit gauge+color): A101 18TN; A103 18TN; A103A 18TN; A122F 18TN; A15A 18RD; A15B 16RD; A92G 18GY
See also sheets: CH12_01, CH12_10, CH12_12, CH12_14, CH15_08, CH3_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.3. SHIFT INHIBIT RELAY CONNECTIONS, P. 2 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090663 95885P 22DEC20 / CHAPTER 12 SHIFT INHIBIT RELAY CONNECTIONS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SHIFT INHIBIT RELAY (1011-R2) / A15A 18RD / A89CF 18VT / %A92G 18GY %A122F 18TN / A101 18TN / FUSE A6-H (1014) CH3_02 / PLATFORM/ ENGINE (1701) CH12_10,12,14,18,21 / A15B 16RD / @A103A 18TN / ECONOMY MODE RELAY (1012-R5) CH12_01 / *A103 18TN / PLATFORM/ ENGINE (1701) CH12_12 / PLATFORM/ ENGINE (1701) CH12_14 / WHEELCHAIRLIFT DIODE ASSY CONN (1014F) CH15_08,09,11 / @ W/WHEELCHAIR LIFT OR PARK BRAKE INTLK * W/LCT AND WTEC XMSN % W/EATON PROCISION XMSN / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 458 / SHIFT INHIBIT RELAY CONNECTIONS

12.4. SHIFT INHIBIT RELAY, P. 2A
Figure 459 SHIFT INHIBIT RELAY

Components: BODY LOWER (7106); DIODE ASSY CONN (1014F); FUSE F7 (1011); GEN4 TCM (7150); RELAY (1026); SWITCH RELAY (1015)
Wires (circuit gauge+color): A101 18TN; A103 18TN; A103A 18TN; A122F 18TN; A15A 18RD; A92G 18GY
See also sheets: CH12_23, CH15_32, CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.4. SHIFT INHIBIT RELAY, P. 2A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090663 95885P 17MAR21 / SHIFT INHIBIT RELAY / CHAPTER 12 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / W/ WTEC TRANSMISSION / ECONOMY MODE SWITCH RELAY (1015) CH12_1A / A89CF 18VT / 86 1 / 2 85 SHIFT INHIBIT RELAY (1026) / 4 87A / 30 3 / A103A 18TN / FUSE F7 (1011) CH3_94 / A15A 18RD / SHIFT INHIBIT RELAY (1026) / A101 18TN / 86 1 / 4 87A / A15A 18RD / 30 3 / A103 18TN / 2 85 / A89CF 18VT / W/ LCT TRANSMISSION / GEN4 TCM (7150) CH12_23,10A / FUSE F7 (1011) CH3_94 / WHEEL CHAIR LIFT DIODE ASSY CONN (1014F) CH15_32 / WHEEL CHAIR LIFT DIODE ASSY CONN (1014F) CH15_32 / @ W/CE BUS W/PROPANE # W/EATON PROCISION XMSN W/F-2017-ISB-ENG / A101 18TN / #A122F 18TN #A92G 18GY / EATON PROCISION TRANSMISSION BODY LOWER (7106) CH12_15F / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / Figure 459 / SHIFT INHIBIT RELAY

12.5. SHIFT SELECTOR CONNECTIONS, P. 3
Figure 460 SHIFT SELECTOR CONNECTIONS

Components: ENGINE / PLATFORM (1701/1701); FUSE A3-E (1016); FUSE A6-M (1014); FUSE F21 (1011); FUSE F30 (1011); GROUND SPLICE (1003A); SHIFT SELECTOR (1850); SPLICE (1002A)
Wires (circuit gauge+color): A134 18WH; A62C 18DKBL
See also sheets: CH12_7, CH3_02, CH3_05, CH3_32, CH3_94, CH8_25
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.5. SHIFT SELECTOR CONNECTIONS, P. 3 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090663 95885P 22DEC20 / CHAPTER 12 SHIFT SELECTOR CONNECTIONS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FUSE F21 (1011) CH3_94C FUSE A3-E (1016) CH3_05 / 11 DIRECTION SIGNAL / PANEL LIGHTS SPLICE (1002A) CH8_25 FUSE F30 (1011) CH3_94 FUSE A6-M (1014) CH3_02 / 12 IGNITION SENSE / !A134 18WH / GROUND SPLICE (1003A) CH3_32,95B / !A#170A 18PK / 13 BATTERY VOLTAGE / BATTERY GROUND / DIMMER INPUT / A#169A 18GY / @A#163A 18YL !A#163A 18YL / A62C 18DKBL / SHIFT SELECTOR (1850) / ENGINE / PLATFORM (1701/1701) CH12_12A / @A134 18WH / ENGINE / PLATFORM (1701/1701) CH12_7,9,12,20 / !A#163AA 18YL / @A#170A 18PK / @ W/CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. ! W/CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 460 / SHIFT SELECTOR CONNECTIONS

12.6. SHIFTER INTERLOCK EFFECTS, P. 4
Figure 461 SHIFTER INTERLOCK EFFECTS

Components: AND PANEL LIGHT (1830); GROUND SPLICE (1003A); LIFT INTERLOCK RELAY (10312); LIFT SPLICE (10370); PANEL LIGHT (1501); PLATFORM/ELEC PANEL (1703/1703); SPLICE (1002A); WHEELCHAIR RELAY (1010-R3)
Wires (circuit gauge+color): A122AC 18GY; A122AD 18GY; A62-GC 18WH; A62-GE 18WH; A62G 18DKBL; A62H 18DKBL; A92E 18TN; A92F 18TN; B44A 18GY; B44B 18GY
See also sheets: CH13_58, CH15_04, CH3_32, CH8_25
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.6. SHIFTER INTERLOCK EFFECTS, P. 4 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090663 95885P 22DEC20 / CHAPTER 12 SHIFTER INTERLOCK EFFECTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PLATFORM/ELEC PANEL (1703/1703) A8 / LCT XMSN PARK SWITCH AND PANEL LIGHT (1830) A / AUTO XMSN PANEL LIGHT (1501) / B44A 18GY B44B 18GY / GROUND SPLICE (1003A) CH3_32,95B / A62H 18DKBL %A62G 18DKBL / %A62-GC 18WH / #A92E 18TN / A62-GE 18WH / A92F 18TN / LIFT SPLICE (10370) CH15_04,05,06,07 LIFT INTERLOCK RELAY (10312) CH15_04 / PANEL LIGHT SPLICE (1002A) CH8_25 / *A122AD 18GY / NEXT GEN HYD PARK BRAKE/ WHEELCHAIR RELAY (1010-R3) CH13_58 / @A122AC 18GY / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 461 / SHIFTER INTERLOCK EFFECTS

12.7. SHIFTER INTERLOCK EFFECTS (CONT.), P. 5
Figure 462 SHIFTER INTERLOCK EFFECTS (CONT.)

Components: BODY CONTROLLER (1601); CONTROL SOLENOID (1828); FUSE A3-F (1016); FUSE F22 (1011)
Wires (circuit gauge+color): A92 18TN; A92AB 18TN
See also sheets: CH3_06
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.7. SHIFTER INTERLOCK EFFECTS (CONT.), P. 5 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090663 NO. 95885P 22DEC20 / CHAPTER 12 SHIFTER INTERLOCK EFFECTS (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J4-BLUE BODY CONTROLLER (1601) LCT SHIFTER- PARK BRAKE E8 POSITION UNLOCK SOLENOID / A92AB 18TN / SHIFTER LEVEL CONTROL SOLENOID (1828) / !A92 18TN / FUSE A3-F (1016) CH3_06 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / # W/CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. ! W/CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / FUSE F22 (1011) CH3_94C / #A92 18TN / Figure 462 / SHIFTER INTERLOCK EFFECTS (CONT.)

12.8. 1 / 2000 ALLISON XMSN GEN5 (LCT) WITH BCM GEN4 WITH 2017 ISB / 2021
Figure 463 1 / 2000 ALLISON XMSN GEN5 (LCT) WITH BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL

Components: GEN4 TCM (7150); LCT TRANSMISSION BULKHEAD (7350)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.8. 1 / 2000 ALLISON XMSN GEN5 (LCT) WITH BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090663 NO. 95885P 22DEC20 / CHAPTER 12 1/2000 ALLISON XMSN GEN5 (LCT) W/BCM GEN4 W/2017/2021 ISB/B6.7 DIESEL ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K92#111 18OR K92#114 18GY K92#117 18LTBL K92#133 18YL K92#134 18WH / PRESSURE CONTROL 55 SOLENOID 1 / PRESSURE CONTROL 36 SOLENOID 2 / PRESSURE 57 SWITCH MANIFOLD SIGNAL RETURN 58 / HIGH SIDE DRIVER 1 INTERNAL MODE SW PRESSURE SWITCH MANIFOLD 33 SHIFT SOLENOID 2 / PRESSURE SW 77 MANIFOLD TORQUE CONVERTER 78 CLUTCH PRESSURE 79 SWITCH MANIFOLD 31 / SHIFT SOLENOID 1 52 / 14 HIGH SIDE DRIVER 1 20 INTERNAL MODE SWITCH C / 21 INTERNAL MODE SWITCH B / 11 14 / PRESSURE SWITCH 4 / MAIN MOD / SUMP TEMP / INTERNAL MODE SWITCH A / ANALOG RETURN / GEN4 TCM (7150) / TORQUE CONVERTER CLUTCH PRESSURE SWITCH 2 / PRESSURE CONTROL SOLENOID 1 / PRESSURE CONTROL SOLENOID 2 / SHIFT SOLENOID 2 / INTERNAL MODE SW / INTERNAL MODE SW / INTERNAL MODE SWITCH P / PRESSURE SWITCH 1 / SHIFT SOLENOID 3 / SHIFT SOLENOID 3 / MAIN MOD / HIGH SIDE DRIVER 2 / INTERNAL MODE SW / LCT TRANSMISSION BULKHEAD (7350) / XMSN ID / SUMP TEMP / SHIFT SOLENOID 1 / XMSN ID / INTERNAL MODE SWITCH-NS / HIGH SIDE DRIVER 2 / INTERNAL MODE SW / PRESSURE SWITCH 3 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 463 / 1 / 2000 ALLISON XMSN GEN5 (LCT) WITH BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

12.9. 1 / 2000 ALLISON XMSN GEN5 (LCT) WITH BCM GEN4 WITH 2017 ISB / 2021
Figure 464 1 / 2000 ALLISON XMSN GEN5 (LCT) WITH BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL

Components: ENGINE / PLATFORM (1701/1701); GEN4 TCM (7150); RELAY (1012_R5); SHIFT SELECTOR (1850); SPEED SENSOR (7600M); SPEED SENSOR (7604M); SPEED SENSOR (7607M); SWITCH RELAY (1015)
Wires (circuit gauge+color): A134 18WH; K92A142 18WH; K92B142 18WH
See also sheets: CH12_01, CH12_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.9. 1 / 2000 ALLISON XMSN GEN5 (LCT) WITH BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090663 NO. RELEASE NO. 95885P 22DEC20 / CHAPTER 12 1/2000 ALLISON XMSN GEN5 (LCT) W/BCM GEN4 W/2017/2021 ISB/B6.7 DIESEL ENG (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GEN4 TCM (7150) / K47#160 18YL K47#140 18LTGN / K148#159 18TN K148#139 18OR / O/P SPEED 40 / ENGINE / PLATFORM (1701/1701) 31 / A134 18WH / SHIFT SELECTOR (1850) CH12_03 / ALLISON BULKHEAD VSS ALLISON BULKHEAD VSS / O/P SPEED / !A#142 16TN / ECONOMY MODE RELAY (1012_R5) CH12_01 / ECONOMY MODE SWITCH RELAY (1015) CH12_1A LCT TURBINE SPEED SENSOR (7607M) / K92#120 18LTBL / K92#180 18OR / TURBINE SPEED / TURBINE SPEED / LCT ENGINE SPEED SENSOR (7604M) / LCT OUTPUT SPEED SENSOR (7600M) / K92#142 18WH / K92A142 18WH / K92B142 18WH / SHIFT SELECTER SIGNAL / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / &A#142 16TN / & W/CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. ! W/CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 464 / 1 / 2000 ALLISON XMSN GEN5 (LCT) WITH BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

12.10. ALLISON XMSN LCT WITH 2017 ISB DIESEL ENGINE, P. 7A
Figure 465 ALLISON XMSN LCT WITH 2017 ISB DIESEL ENGINE

Components: BODY CONTROLLER (1601); CONNECTION (8008); ENG/PLATFORM (1701/1701)
Wires (circuit gauge+color): A92A 18GY; A92B 18GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.10. ALLISON XMSN LCT WITH 2017 ISB DIESEL ENGINE, P. 7A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090663 95885P 17MAR21 / CHAPTER 12 ALLISON XMSN LCT W/2017 ISB DIESEL ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / RECTIFIER CONNECTION (8008) 1 / A92A 18GY / A92B 18GY A92#141 18GY / ENG/PLATFORM (1701/1701) 76 / J4-BLUE BODY CONTROLLER (1601) / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / Figure 465 / ALLISON XMSN LCT WITH 2017 ISB DIESEL ENGINE

12.11. 3000 ALLISON XMSN GEN5 (WTEC) WITH BCM GEN4 WITH 2017 ISB / 2021
Figure 466 3000 ALLISON XMSN GEN5 (WTEC) WITH BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL

Components: GEN4 TCM (7150); WTEC MD TRANSMISSION BULKHEAD (7250M)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.11. 3000 ALLISON XMSN GEN5 (WTEC) WITH BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090663 NO. 95885P 22DEC20 / CHAPTER 12 3000 ALLISON XMSN GEN5 (WTEC) W/BCM GEN4 W/2017/2021 ISB/B6.7 DIESEL ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PRESSURE SW MANIFOLD / SHIFT SOLENOID 1 52 / GEN4 TCM (7150) / PRESSURE CONTROL SOLENOID 2 / SHIFT SOLENOID 2 33 / TORQUE CONVERTER CLUTCH SHIFT SOLENOID 3 / MAIN MOD / 58 SIGNAL RETURN / PRESSURE CONTROL 55 SOLENOID 1 / HIGH SIDE DRIVER 1 / HIGH SIDE DRIVE 2 / WTEC MD TRANSMISSION BULKHEAD (7250M) / SUMP TEMP / XMSN ID / K92#112 18PK K92#116 18LTBL / K92#131 18YL K92#133 18YL K92#136 18OR K92#137 18WH / K92#111 18OR / K92#152 18LTGN / K92#118 18BK K92#177 18LTGN / K31#154 18TN / K92#155 18WH / K92#158 18LTGN K92#171 18YL K92#174 18LTBL K92#176 18YL K92#120 18LTBL K92#180 18OR / K92#151 18WH / 80 TURBINE SPEED / TURBINE SPEED / OPTIONAL OIL LEVEL / OPTIONAL OIL LEVEL / HIGH SPEED DRIVE 3 / HIGH SPEED DRIVE 2 / OPTIONAL OIL LEVEL / TORQUE CONVERTER CLUTCH / ANALOG RETURN / HIGH SPEED DRIVE 3 / XMSN ID / PRESSURE CONTROL SOLENOID 2 / PRESSURE CONTROL SOLENOID 4 / SHIFT SOLENOID 1 / OPTIONAL OIL LEVEL / PRESSURE CONTROL SOLENOID 3 / HIGH SPEED DRIVE 1 / MAIN MOD / TURBINE SPEED / PRESSURE SWITCH 1 / SUMP TEMP / TURBINE SPEED / PRESSURE CONTROL SOLENOID 1 / PRESSURE SWITCH 2 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 466 / 3000 ALLISON XMSN GEN5 (WTEC) WITH BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

12.12. 3000 ALLISON XMSN GEN5 (WTEC) WITH BCM GEN4 WITH 2017 ISB / 2021
Figure 467 3000 ALLISON XMSN GEN5 (WTEC) WITH BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL

Components: ENGINE / PLATFORM (1701/1701); GEN4 TCM (7150); RELAY (1012_R5); SHIFT SELECTOR (1850); SPEED SENSOR (7603M); SPEED SENSOR (7605M); SWITCH RELAY (1015)
Wires (circuit gauge+color): A134 18WH
See also sheets: CH12_01, CH12_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.12. 3000 ALLISON XMSN GEN5 (WTEC) WITH BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 9 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090663 NO. RELEASE NO. 95885P 22DEC20 / CHAPTER 12 3000 ALLISON XMSN GEN5 (WTEC) W/BCM GEN4 W/2017/2021 ISB/B6.7 DIESEL ENG (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GEN4 TCM (7150) / K47#160 18YL K47#140 18LTGN / K48#159 18TN K48#139 18OR / O/P SPEED 40 SENSER / ENGINE / PLATFORM (1701/1701) 31 / A134 18WH / SHIFT SELECTOR (1850) CH12_03 / ENGINE SPEED SENSER / O/P SPEED SENSER / !A#142 16TN / ECONOMY MODE RELAY (1012_R5) CH12_01 ECONOMY MODE SWITCH RELAY (1015) CH12_1A / WTEC ENGINE SPEED SENSOR (7603M) / WTEC O/P SPEED SENSOR (7605M) / K92#134 18YL / K92A134 18YL / K92B134 18YL / SHIFT SELECTER SWITCH / ENGINE SPEED SENSER / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / & W/CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. ! W/CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / &A#142 16TN / Figure 467 / 3000 ALLISON XMSN GEN5 (WTEC) WITH BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

12.13. 1 / 2 / 3000 ALLISON XMSN GEN5 (WTEC / LCT) WITH BCM GEN4 WITH 2017
Figure 468 1 / 2 / 3000 ALLISON XMSN GEN5 (WTEC / LCT) WITH BCM GEN4 WITH 2017 ISB / 2021

Components: BACKUP LIGHT RELAY (1010-R6); BODY CONTROLLER (1606); ECM NEGATIVE (9260); ECM POSITIVE (9261); ENGINE / PLATFORM (1701/1701); FUSE A3-E (1016); GEN4 TCM (7150); MODE RELAY (1012-R5); PLATFORM/FWD CHASSIS (1700); RELAY (1011-R2)
Wires (circuit gauge+color): A101 18TN; A103 18TN; A47A 18GY; K47A 18GY; K92A109 10WH; K92A110 10RD
See also sheets: CH12_01, CH12_02, CH13_15, CH3_05, CH3_64, CH7_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.13. 1 / 2 / 3000 ALLISON XMSN GEN5 (WTEC / LCT) WITH BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 10 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090663 NO. 95885P 22DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GEN4 TCM (7150) / K92#163 18YL / K92#101 18LTBL / K92#103 18YL / K71#165 18TN / 70 9 / K92#110 18PK K92#170 18PK K92#109 18GY K92#169 18GY / ECM POSITIVE (9261) CH3_64 / ECM NEGATIVE (9260) CH3_64 / K92A110 10RD / K92A109 10WH / ENGINE / PLATFORM (1701/1701) 55 / BATTERY PWR / BATTERY PWR / A#165 18TN / A101 18TN / BACKUP LIGHT RELAY (1010-R6) CH7_02,03 PLATFORM/FWD CHASSIS (1700) CH13_15 / SHIFT INHIBIT RELAY (1011-R2) CH12_02 ECONOMY MODE RELAY (1012-R5) CH12_01 FUSE A3-E (1016) CH3_05 / #A#163 18YL / #A103 18TN / SIGNAL RETURN / REVERSE WARN / IGNITION POWER / NEUTRAL START / K92#141 18GY / A92#141 18GY / J6-18 WAY BODY CONTROLLER (1606) / % W/ROAD SPEED WIRE # W/LCT XMSN / %K47A 18GY / A47A 18GY / ROAD SPEED / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 468 / 1 / 2 / 3000 ALLISON XMSN GEN5 (WTEC / LCT) WITH BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

12.14. 1 / 2 / 3000 ALLISON XMSN GEN5 (WTEC / LCT) WITH BCM GEN4 WITH 2017
Figure 469 1 / 2 / 3000 ALLISON XMSN GEN5 (WTEC / LCT) WITH BCM GEN4 WITH 2017 ISB DIESEL

Components: BACKUP LIGHT RELAY (1011); BODY CONTROLLER (1606); ECM NEGATIVE (9260); ECM POSITIVE (9261); ENGINE / PLATFORM (1701/1701); FUSE F21 (1011); GEN4 TCM (7150); PLATFORM/FWD CHASSIS (1700); RELAY (1026); SWITCH RELAY (1015)
Wires (circuit gauge+color): A101 18TN; A103 18TN; A47A 18GY; K47A 18GY; K92A109 10WH; K92A110 10RD
See also sheets: CH13_15, CH3_64
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.14. 1 / 2 / 3000 ALLISON XMSN GEN5 (WTEC / LCT) WITH BCM GEN4 WITH 2017 ISB DIESEL ENGINE, P. 10A / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090663 NO. 95885P 19MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GEN4 TCM (7150) / K92#163 18YL / K92#101 18LTBL / K92#103 18YL / K71#165 18TN / 70 9 / K92#110 18PK K92#170 18PK K92#109 18GY K92#169 18GY / ECM POSITIVE (9261) CH3_64 / ECM NEGATIVE (9260) CH3_64 / K92A110 10RD / K92A109 10WH / ENGINE / PLATFORM (1701/1701) 55 / BATTERY PWR / BATTERY PWR / A#165 18TN / BACKUP LIGHT RELAY (1011) CH7_2A PLATFORM/FWD CHASSIS (1700) CH13_15 / A#163 18YL A#163 18PK / SHIFT INHIBIT RELAY (1026) CH12_2A ECONOMY MODE SWITCH RELAY (1015) CH12_1A / A103 18TN / SIGNAL RETURN / REVERSE WARN / IGNITION POWER / NEUTRAL START / K92#141 18GY / A92#141 18GY / J6-18 WAY BODY CONTROLLER (1606) / % W/ROAD SPEED WIRE / %K47A 18GY / A47A 18GY / ROAD SPEED / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / FUSE F21 (1011) CH3_94C / A101 18TN / Figure 469 / 1 / 2 / 3000 ALLISON XMSN GEN5 (WTEC / LCT) WITH BCM GEN4 WITH 2017 ISB DIESEL ENGINE

12.15. 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021
Figure 470 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021 B6.7

Components: BULKHEAD (7250M); TRANS MODULE 1 (1232); TRANS MODULE 2 (1233); TRANS MODULE 3 (1234)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.15. 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 11 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090663 NO. 95885P 22DEC20 / CHAPTER 12 3000 ALLISON XMSN GEN5 W/PTO W/BCM GEN4 W/2017/2021 ISB/B6.7 DIESEL ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / WT MD TRANS BULKHEAD (7250M) / K92#158 18LTGN K92#171 18YL K92#151 18WH K92#152 18LTGN K31#154 18TN / K92#111 18OR K92#112 18PK / TRANS MODULE 2 (1233) / TRANS MODULE 1 (1232) / K92#116 18LTBL K92#118 18BK K92#120 18LTBL K92#131 18YL K92#133 18YL / TRANS MODULE 3 (1234) / K92#136 18OR K92#137 18WH K92#155 18WH K92#174 18LTBL K92#176 18YL / K92#177 18LTGN K92#180 18OR / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 470 / 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

12.16. 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021
Figure 471 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL

Components: ALLISION BODY BUILDER 2 (7206F); ALLISON BODY BUILDER 1 (7205M); BACKUP LIGHT RELAY (1010-R6); BODY CONTROLLER (1606); ECM NEGATIVE (9260); ECM POSITIVE (9261); ECONOMY MODE RELAY (1012-R5); ENGINE / PLATFORM (1701/1701); FUSE A3-E (1016); RELAY (1011-R2); SHIFT SELECTER (1850); TRANSMODULE 1 (1232)
Wires (circuit gauge+color): A101 18TN; A103 18TN; A134 18WH; K92A109 10WH; K92A110 10RD; K92B101 18LTBL; K92C101 18LTBL
See also sheets: CH12_01, CH12_02, CH12_03, CH3_05, CH3_64, CH7_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.16. 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 12 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. TRANSMODULE 1 (1232) / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090663 NO. RELEASE NO. 95885P 22DEC20 / CHAPTER 12 3000 ALLISON XMSN GEN5 W/PTO W/BCM GEN4 W/2017/2021 ISB/B6.7 DIESEL ENG (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ENGINE / PLATFORM (1701/1701) 55 K92B101 18LTBL K92B103 18YL K92A134 18YL K92B134 18YL / K71#165 18TN / 22 5 21 / K92#141 18GY K92#170 18PK K92#110 18PK K92#169 18GY K92#109 18GY / ECM POSITIVE (9261) CH3_64 / ECM NEGATIVE (9260) CH3_64 / K92A110 10RD / K92A109 10WH / A101 18TN @A103 18TN A134 18WH A#142 16TN A#165 18TN / A92#141 18GY / @ W/WTEC XMSN / K92#163 18YL / K92#117 18LTBL K92#123 18LTGN K92#130 18WH K92#143 18LTBL K92#145 18OR K92#101 18LTBL / 8 10 13 / C B / H G / G A ALLISION BODY BUILDER 2 (7206F) / K92#105 180R K92#113 18WH K92#122 18YL K92#164 18LTBL K92#103 18YL / 17 7 / 19 2 / F B E / ALLISON BODY BUILDER 1 (7205M) / K92C103 18YL / K92C101 18LTBL / K92D103 18YL / K92#134 18YL / @A#163 18YL / @A#163AA 18YL / Figure 471 / 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

12.17. 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021
Figure 472 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL

Components: ALLISION BODY BUILDER 2 (7206F); ALLISON BODY BUILDER 1 (7205M); BACKUP LIGHT RELAY (1011); BODY CONTROLLER (1606); ECM NEGATIVE (9260); ECM POSITIVE (9261); ECONOMY MODE SWITCH RELAY (1015); ENGINE / PLATFORM (1701/1701); FUSE F21 (1011); SHIFT INHIBIT RELAY (1026); SHIFT SELECTER (1850); TRANS MODULE 1 (1232)
Wires (circuit gauge+color): A101 18TN; A103 18TN; A134 18WH; K92A109 10WH; K92A110 10RD; K92B101 18LTBL; K92C101 18LTBL
See also sheets: CH12_03, CH3_64
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.17. 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 12A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. TRANS MODULE 1 (1232) 3 / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090663 NO. RELEASE NO. 95885P 19MAR21 / CHAPTER 12 3000 ALLISON XMSN GEN5 W/PTO W/BCM GEN4 W/2017/2021 ISB/B6.7 DIESEL ENG (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ENGINE / PLATFORM (1701/1701) 55 K92B101 18LTBL K92B103 18YL K92A134 18YL K92B134 18YL / K71#165 18TN K92#163 18YL / 22 5 21 / K92#141 18GY K92#170 18PK K92#110 18PK K92#169 18GY K92#109 18GY / ECM POSITIVE (9261) CH3_64 / ECM NEGATIVE (9260) CH3_64 / K92A110 10RD / K92A109 10WH / A101 18TN A103 18TN A134 18WH A#142 16TN A#165 18TN A#163 18YL A#163 18PK / A92#141 18GY / @ W/WTEC XMSN / K92#117 18LTBL K92#123 18LTGN K92#130 18WH K92#143 18LTBL K92#145 18OR K92#101 18LTBL / 8 10 13 / C B / H G / G A ALLISION BODY BUILDER 2 (7206F) / K92#105 180R K92#113 18WH K92#122 18YL K92#164 18LTBL K92#103 18YL / 17 7 / 19 2 / F B E / ALLISON BODY BUILDER 1 (7205M) / K92C103 18YL / K92C101 18LTBL / K92D103 18YL / K92#134 18YL / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / Figure 472 / 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

12.18. 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021
Figure 473 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL

Components: ALLISON BODY BUILDER 1 (7205M); ALLISON BODY BUILDER 2 (7206F); SPEED SENSOR (7603MB); SPEED SENSOR (7605M); TRANS MODULE 2 (1233); TRANS MODULE 3 (1234)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.18. 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 13 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090663 NO. RELEASE NO. 95885P 22DEC20 / CHAPTER 12 3000 ALLISON XMSN GEN5 W/PTO W/BCM GEN4 W/2017/2021 ISB/B6.7 DIESEL ENG (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K47#160 18YL / K48#159 18TN K48#139 18OR / K47#140 18LTGN / WT MD OUTPUT SPEED SENSOR (7605M) / ENGINE INPUT SPEED SENSOR (7603MB) / K92#129 18LTGN / TRANS MODULE 2 (1233) / ALLISON BODY BUILDER 1 (7205M) / K92#102 18YL K92#104 18YL / TRANS MODULE 3 (1234) / ALLISON BODY BUILDER 2 (7206F) / K92#142 18WH / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 473 / 3000 ALLISON XMSN GEN5 WITH PTO AND BCM GEN4 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

12.19. EATON PROCISION XMSN WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 14
Figure 474 EATON PROCISION XMSN WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: BODY LOWER (7106); ENGINE/PLATFORM (1701/1701); RELAY (1010-R6); RELAY (1011-R2)
Wires (circuit gauge+color): A101 18TN; A122F 18TN; A92D 18GY; A92E 18GY; A92G 18GY; K122F 18TN; K122G 18TN; K122H 18TN; K92D 18TN; K92E 18TN; K92K 18TN; K92M 18TN; K92P 18TN
See also sheets: CH12_02, CH7_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.19. EATON PROCISION XMSN WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 14 / CHAPTER 12 EATON PROCISION XMSN W/2017/2021 ISB/B6.7 DIESEL ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090663 95885P 22DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K92(+) 18YL K92(-) 18GN K92K 18TN K92M 18TN K92P 18TN / EATON PROCISION TRANSMISSION VEHICLE UPPER %(7105) / ENGINE/PLATFORM (1701/1701) 34 / K122F 18TN K122G 18TN K122H 18TN K92D 18TN K92E 18TN / EATON PROCISION TRANSMISSION BODY LOWER (7106) 4 / A122F 18TN A92G 18GY A101 18TN A92D 18GY A92E 18GY / SHIFT INHIBIT RELAY (1011-R2) CH12_02 / BACK UP LIGHT RELAY (1010-R6) CH7_03 / % W/PUSH BUTTON / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 474 / EATON PROCISION XMSN WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

12.20. EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017 ISB DIESEL ENGINE, P. 15
Figure 475 EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017 ISB DIESEL

Components: CONTROLLER (1606); ENG/PLATFORM (1701/1701); ENGINE/PLATFORM (1701/1701); FUSE A3-E (1016); FUSE STUD (4001A); NEGATIVE CONN (9260); POSITIVE CONN (9261); POSITIVE CONN (9263); RANGE SENSOR (7107); SWITCH (4009); TCM FUSE (4112); VEHICLE UPPER (7105)
Wires (circuit gauge+color): A14R 14RD; A14SCR 10RD; A92B 18GY; K10-GC 16WH; K10-GD 16WH; K13 18GY; K14AA 16RD; K14N 16RD; K14PA 14RD; K17B 18GY; K92B 14TN; K92J 18TN; K92L 18TN; K92N 18TN; K92R 18TN
See also sheets: CH3_69, CH4_06
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.20. EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017 ISB DIESEL ENGINE, P. 15 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090663 NO. 95885P 08JUN21 / CHAPTER 12 1/2000 ALLISON XMSN GEN 4/5 (LCT) W/F-2018-PROP-ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / TCM NEUTRAL SWITCH (4009) / 2 86 / 85 5 / 1 30 / K14N 16RD / K10-GC 16WH K10-GD 16WH / EATON PROCISION TRANSMISSION RANGE SENSOR (7107) / @K92J 18TN / @K92L 18TN / @K92N 18TN / @K92R 18TN / BATTERY ECM POSITIVE CONN (9261) CH3_69 BATTERY ECM NEGATIVE CONN (9260) CH3_69 / K13 18GY / ENGINE/PLATFORM (1701/1701) 7 / A92B 18GY / FUSE A3-E (1016) CH3_XX / K92#104 18TN / K92#114 18TN / @ W/T-HANDLE TRS / TCM FUSE (4112) K14PA K92B 14TN 14RD B A 15A / K17B 18GY / ENG/PLATFORM (1701/1701) 26 / A92#141 18GY / J6-18 WAY BODY CONTROLLER (1606) CH4_06 / K14AA 16RD / A14R 14RD A14SCR 10RD / SCR POWER LOWER MEGA FUSE STUD (4001A) / AUX BATT TCM POSITIVE CONN (9263) / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 475 / EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017 ISB DIESEL ENGINE

12.21. EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017
Figure 476 EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017 ISB DIESEL

Components: CONTROLLER (1606); ENGINE/PLATFORM (1701); FUSE (4104); FUSE F17 (1011); FUSE F21 (1011); FUSE STUD (4001A); NEGATIVE CONN (9260); PASS THROUGH (1701/1701); PLATFORM (1701); POSITIVE CONN (9261); POSITIVE CONN (9263); RANGE SENSOR (7107); SWITCH (4009); TCM FUSE (4112); VEHICLE UPPER (7105)
Wires (circuit gauge+color): A13BB 12PK; A14R 14RD; A14SCR 10RD; A92 18GY; K10-GC 16WH; K10-GD 16WH; K13 18GY; K14 16RD; K14N 16RD; K14PA 14RD; K17B 18GY; K92B 14TN; K92J 18TN; K92L 18TN; K92N 18TN; K92R 18TN
See also sheets: CH11_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.21. EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017 ISB DIESEL ENGINE (CONT.), P. 15A / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090663 NO. RELEASE NO. 95885P 19MAR21 / CHAPTER 12 EATON PROCISION XMSN W/PUSH BUTTON & W/T-HANDLE TRS W/2017 ISB DIESEL ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / TCM NEUTRAL SWITCH (4009) ENGINE/DASH PASS THROUGH (1701/1701) 26 K17B A92#141 18GY 18GY / 85 5 / 2 86 / 87A 3 / 1 30 / K14 16RD / K14N 16RD / K10-GC 16WH K10-GD 16WH / EATON PROCISION TRANS RANGE SENSOR (7107) / @K92J 18TN / @K92L 18TN / @K92N 18TN / @K92R 18TN / BATTERY ECM NEGATIVE CONN (9260) / BATTERY ECM POSITIVE CONN (9261) AUX BATT TCM POSITIVE CONN (9263) / K13 18GY / ENGINE/PLATFORM (1701) 7 / @A92 18GY / FUSE F21 (1011) @A13BB B A 12PK ENGINE/ PLATFORM (1701) 21 / A (A13BA) FUSE F17 (1011) / K92#104 18TN / K92#114 18TN / IGNITION RELAY#2 R6 (1011) CH3_94B,94C / @ W/ T-HANDLE TRS NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / K92B 14TN / A14SCR 10RD J-6 18 WAY BODY CONTROLLER (1606) / A97UA 18VT / K97UA 18VT / K97UB 14VT / KEY POWER FUSE (4104) CH11_01 / TCM FUSE (4112) K14PA B 14RD A 15A / A14R 14RD / SCR POWER LOWER MEGA FUSE STUD (4001A) / Figure 476 / EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017 ISB DIESEL ENGINE (CONT.)

12.22. EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017
Figure 477 EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017 ISB DIESEL

Components: ASSY CONN (1014F); BODY LOWER (7106); ENGINE/DASH PASS THROUGH (1701/1701); FUSE F7-B (1011); PUSH BUTTON SHIFTER (7905A); RELY (1026); VEHICLE UPPER (7105)
Wires (circuit gauge+color): A101 18TN; A122F 18TN; A15A 18RD; A92D 18GY; A92E 18GY; A92G 18GY; A92K 18GY; A92M 18GY; A92P 18GY; K122F 18TN; K122G 18TN; K122H 18TN; K92D 18TN; K92E 18TN; K92K 18TN; K92M 18TN; K92P 18TN
See also sheets: CH15_32, CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.22. EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017 ISB DIESEL ENGINE (CONT.) , P. 15B / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090663 NO. RELEASE NO. 95885P 17MAR21 / CHAPTER 12 EATON PROCISION XMSN W/ PUSH BUTTON & W/T-HANDLE TRS W/2017 ISB DIESEL ENG (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SHIFT INHIBIT RELY (1026) 85 2 / A89CF 18VT / A15A 18RD / 3 30 / 1 86 / 87A 4 / FUSE F7-B (1011) CH3_94 / WHEEL CHAIR LIFT DIODE ASSY CONN (1014F) CH15_32 / A122F 18TN / A92G 18GY / #A101 18TN / K122H 18TN / K122G 18TN / K122F 18TN / ENGINE/DASH PASS THROUGH (1701/1701) / K92D 18TN K92E 18TN / A92D 18GY A92E 18GY / BACK UP LIGHT RELAY#4 (1011) CH12_15C / EATON PROCISION TCM VEHICLE UPPER (7105) / A92K 18GY / A92M 18GY A92P 18GY / A92(-) 18GN / @K92(+) 18YL / A92(+) 18YL / @K92(-) 18GN / @K92K 18TN / @K92M 18TN @K92P 18TN / EATON PROCISION PUSH BUTTON SHIFTER (7905A) / @ W/ PUSH BUTTON # W/ WHEEL CHAIR LIFT INTERLOCK NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / Figure 477 / EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017 ISB DIESEL ENGINE (CONT.)

12.23. EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017
Figure 478 EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017 ISB DIESEL

Components: BODY CONTROLLER (1601); CHECK RELAY (1016); ELECRTICAL PANEL (1703); FUSE F17 (1011); FUSE F20 (1011); PASS THROUGH (1701/1701)
Wires (circuit gauge+color): A71 16OR; A71A 18OR; A71BB 16LTBL; A71BB 16OR; A71C 18OR; A71D 16LTBL; A71D 18LTBL; A71E 18OR; A71F 16OR; A71H 16LTBL; A71H 16OR; A92D 18GY; A92E 18GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.23. EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017 ISB DIESEL ENGINE (CONT.), P. 15C / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090663 NO. RELEASE NO. 95885P 17MAR21 / CHAPTER 12 EATON PROCISION XMSN W/ PUSH BUTTON & W/T-HANDLE TRS W/2017 ISB DIESEL ENG (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / BACKUP LIGHT RELAY#R4 (1011) / 86 B / E 30 / A 85 / 87A D %A71BB 16LTBL / J4-BLUE BODY CONTROLLER (1601) / A92D 18GY / A92E 18GY / A71 16OR / ENGINE/DASH PASS THROUGH (1701/1701) CH12_15B / %A71H 16LTBL / *A71H 16OR A71D 18LTBL / *A71BB 16OR / %A71D 16LTBL / 86 2 / 87A 4 / BACK UP LIGHT FUSE F20 CHECK RELAY (1011) %A71A (1016) (A13BB) 18OR A B 1 85 / 3 30 / A71C 18OR / FUSE F20 (1011) FUSE F17 (A13BB) (1011) B A CH3_94C 30-WAY PASS THRU TO ELECRTICAL PANEL (1703) / *A71F 16OR / %A71E 18OR / FUSE F17 (1011) CH3_94C / % W/ LAMP CHECK * N/ LAMP CHECK / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / Figure 478 / EATON PROCISION XMSN WITH PUSH BUTTON & T-HANDLE TRS WITH 2017 ISB DIESEL ENGINE (CONT.)

12.24. J1939 EATON PROCISION XMSN WITH 250K, P. 15D
Figure 479 J1939 EATON PROCISION XMSN WITH 250K

Components: ABS-6 CONN (9538); CLUSTER (1505); CONTROLLER (1602); ECM CONN (6021); INTERCONNECT (9530M/9530F); PAM MODULE (4087); PASS THROUGH (1701/1701); TERMINATING RESISTER (7801M); UPPER (7105); W/4100 (1029A)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.24. J1939 EATON PROCISION XMSN WITH 250K, P. 15D / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090663 95885P 17MAR21 / CHAPTER 12 J1939 EATON PROCISION XMSN W/250K / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J1939 INTERCONNECT (9530M/9530F) 1 / K5A(+) 18YL / K5A(-) 18GN / K5B(-) 20GN / BENDIX AIR ABS-6 CONN (9538) / M5E(+) 18YL / K5B(+) 20YL / M5E(-) 18GN / A5A(+) 18YL / A5A(-) 18GN / EATON PROCISION TCM VECHICLE UPPER (7105) / K5C(-) K5C(+) 18GN 18YL / K5D(+) 20YL / K5D(-) 20GN / ECM CONN (6021) / PAM MODULE (4087) / #K5F(+) 18YL / #K5F(-) 18GN / ENGINE/DASH PASS THROUGH (1701/1701) 45 / @K5G(+) 18YL / @K5G(-) 18GN / M5(+) 18YL / M5(-) 18GN / A5AL(+) 18YL / A5AM(-) 18GN / INSTRUMENT CLUSTER (1505) / J1939 TERMINATING RESISTER (7801M) A / M5A(+) 18YL / OHMS 120 / M5A(-) 18GN / A5BC(+) 18YL / J1939 SPLICE W/4100 (1029A) / A5BC(-) 18GN / A5BB(-) 18GN / A5BA(+) 18YL / #K5E(-) #K5G(-) #K5E(+) #K5G(+) 18GN 18GN 18YL 18GN / A5BK(-) 18GN / J5-TAN BODY CONTROLLER (1602) / A5BJ(+) 18YL / @ N/PAM # W/PAM NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / Figure 479 / J1939 EATON PROCISION XMSN WITH 250K

12.25. J1939 WITH 500K EATON PROCISION XMSN WITH 4100, P. 15E
Figure 480 J1939 WITH 500K EATON PROCISION XMSN WITH 4100

Components: CONNECTOR (1650); PLATFORM/FWD CHASSIS (1700/1700); RESISTER (7801M); SELECTOR (1850); W/4100 (1029A)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.25. J1939 WITH 500K EATON PROCISION XMSN WITH 4100, P. 15E / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090663 95885P 17MAR21 / CHAPTER 12 J1939 W/500K EATON PROCISION XMSN W/4100 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5B(-) 18GN / J1939 SPLICE W/4100 (1029A) / A5B(+) 18YL / A5BD(+) 18YL A5BD(-) 18GN / DIGNOSTIC CONNECTOR (1650) / A5AH(+) 18YL A5AH(-) 18GN / SHIFT SELECTOR (1850) / A5E(+) 18YL / PLATFORM/FWD CHASSIS (1700/1700) 30 *M5A(+) 18YL / J1939 TERMINATING RESISTER (7801M) A / A5E(-) 18GN / *M5A(-) 18GN / OHMS 120 / * W/AIR BRAKE EC 80 / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / Figure 480 / J1939 WITH 500K EATON PROCISION XMSN WITH 4100

12.26. EATON PROCISION TRANSMISSION WITH PUSH BUTTON WITH 2017 ISB
Figure 481 EATON PROCISION TRANSMISSION WITH PUSH BUTTON WITH 2017 ISB DIESEL ENGINE

Components: BODY LOWER (7106); BUTTON SHIFTER (7905A); ENGINE/PLATFORM (1701/1701); LIGHT (1002A); RELAY (1011); RELAY (1026); TRANSMISSION VEHICLE UPPER (7105)
Wires (circuit gauge+color): A101 18TN; A122F 18TN; A62C 18DKBL; A92D 18GY; A92E 18GY; A92G 18GY; A92K 18GY; A92M 18GY; A92P 18GY; K122F 18TN; K122G 18TN; K122H 18TN; K92D 18TN; K92E 18TN; K92K 18TN; K92M 18TN; K92P 18TN
See also sheets: CH8_25
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.26. EATON PROCISION TRANSMISSION WITH PUSH BUTTON WITH 2017 ISB DIESEL ENGINE, P. 15F / CHAPTER 12 EATON PROCISION TRANSMISSION W/PUSH BUTTON W/F-2017-ISB-ENG / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090663 NO. 95885P 17MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K92(+) 18YL K92(-) 18GN K92K 18TN K92M 18TN K92P 18TN / EATON PROCISION TRANSMISSION VEHICLE UPPER (7105) / A92(+) 18YL A92(-) 18GN A92K 18GY A92M 18GY / ENGINE/PLATFORM (1701/1701) / A92P 18GY / EATON PROCISION PUSH BUTTON SHIFTER (7905A) / A62C 18DKBL / PANEL LIGHT (1002A) CH8_25 A122F 18TN A92G 18GY A101 18TN A92D 18GY A92E 18GY / K122F 18TN K122G 18TN K122H 18TN K92D 18TN K92E 18TN / EATON PROCISION TRANSMISSION BODY LOWER (7106) 4 / SHIFT INHIBIT RELAY (1026) CH12_2A / BACK UP LIGHT RELAY (1011) CH7_2A / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / Figure 481 / EATON PROCISION TRANSMISSION WITH PUSH BUTTON WITH 2017 ISB DIESEL ENGINE

12.27. 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE ENGINE, P. 16
Figure 482 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE ENGINE

Components: GEN5 TCM (7150); LCT TRANSMISSION BULKHEAD (7350)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.27. 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE ENGINE, P. 16 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. GEN5 TCM (7150) / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090663 NO. 95885P 22DEC20 / CHAPTER 12 1/2000 ALLISON XMSN GEN 4/5 (LCT) W/F-2018-PROP-ENG LCT TRANSMISSION BULKHEAD (7350) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K92#178 18WH K92#179 18PK K92#137 18WH / Figure 482 / 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE ENGINE

12.28. 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE ENGINE
Figure 483 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE ENGINE (CONT.)

Components: ECONOMY MODE RELAY (1012-R5); ENGINE/PLATFORM (1701/1701); GEN4 TCM (7150); SENSOR (7600M); SENSOR (7604M); SENSOR (7607M); SHIFT SELECTOR (1850)
Wires (circuit gauge+color): A134 18WH; K92A142 18WH; K92B142 18WH
See also sheets: CH12_01, CH12_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.28. 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE ENGINE (CONT.), P. 17 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090663 NO. RELEASE NO. 95885P 22DEC20 / CHAPTER 12 1/2000 ALLISON XMSN GEN 4/5 (LCT) W/F-2018-PROP-ENG (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K47#140 18LTGN / K47#160 18YL / K48#139 180R / K48#159 18TN / K92#120 18LTBL / K92#180 180R / K92#142 18WH / GEN4 TCM (7150) / LCT OUTPUT SPEED SENSOR (7600M) / LCT ENGINE SPEED SENSOR (7604M) / LCT TURBINE SPEED SENSOR (7607M) / K92A142 18WH K92B142 18WH / ENGINE/PLATFORM (1701/1701) 31 / A134 18WH A#142 16TN / SHIFT SELECTOR (1850) CH12_03 ECONOMY MODE RELAY (1012-R5) CH12_01 / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 483 / 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE ENGINE (CONT.)

12.29. 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE ENGINE
Figure 484 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE ENGINE (CONT.)

Components: BACKUP LIGHT RELAY (1010-R6); BODY CONTROLLER (1606); ECM NEGATIVE (9260); ECM POSITIVE (9261); ENGINE / PLATFORM (1701/1701); FUSE A3-E (1016); GEN5 TCM (7150); MODE RELAY (1012-R5); RELAY (1011-R2)
Wires (circuit gauge+color): A101 18TN; A103 18TN; K92A109 10WH; K92A110 10RD
See also sheets: CH12_01, CH12_02, CH3_05, CH3_65, CH7_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.29. 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE ENGINE (CONT.), P. 18 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090663 NO. RELEASE NO. 95885P 22DEC20 / CHAPTER 12 1/2000 ALLISON XMSN GEN 4/5 (LCT) W/F-2018-PROP-ENG (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GEN5 TCM (7150) / K92#163 18YL / K92#101 18LTBL / K92#103 18YL / K71#165 18TN / 70 9 / K92#110 18PK K92#170 18PK K92#109 18GY K92#169 18GY / ECM POSITIVE (9261) CH3_65 / ECM NEGATIVE (9260) CH3_65 / K92A110 10RD / K92A109 10WH / ENGINE / PLATFORM (1701/1701) 55 / A#165 18TN / A101 18TN / BACKUP LIGHT RELAY (1010-R6) CH7_02.03 J6-18 WAY BODY CONTROLLER (1606) / SHIFT INHIBIT RELAY (1011-R2) CH12_02 ECONOMY MODE RELAY (1012-R5) CH12_01 FUSE A3-E (1016) CH3_05 / A#163 18YL / A103 18TN / K92#141 18GY / A92#141 18GY / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 484 / 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE ENGINE (CONT.)

12.30. 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 GASOLINE ENGINE, P. 19
Figure 485 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 GASOLINE ENGINE

Components: GEN5 TCM (7150); LCT TRANSMISSION BULKHEAD (7350)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.30. 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 GASOLINE ENGINE, P. 19 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. GEN5 TCM (7150) / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090663 NO. 95885P 22DEC20 / CHAPTER 12 1/2000 ALLISON XMSN GEN 4/5 (LCT) W/F-2018-GAS-ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K92#178 18WH K92#179 18PK K92#137 18WH NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / 7 12 / LCT TRANSMISSION BULKHEAD (7350) / Figure 485 / 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 GASOLINE ENGINE

12.31. 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 GASOLINE ENGINE
Figure 486 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 GASOLINE ENGINE (CONT.)

Components: ECONOMY MODE RELAY (1012-R5); ENGINE/PLATFORM (1701/1701); GEN5 TCM (7150); SENSOR (7600M); SENSOR (7604M); SENSOR (7607M); SHIFT SELECTOR (1850)
Wires (circuit gauge+color): A134 18WH; K92A142 18WH; K92B142 18WH
See also sheets: CH12_01, CH12_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.31. 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 GASOLINE ENGINE (CONT.), P. 20 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090663 NO. RELEASE NO. 95885P 22DEC20 / CHAPTER 12 1/2000 ALLISON XMSN GEN 4/5 (LCT) W/F-2018-GAS-ENG (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K47#140 18LTGN / K47#160 18YL / K48#139 180R / K48#159 18TN / K92#120 18LTBL / K92#180 180R / K92#142 18WH / GEN5 TCM (7150) / LCT OUTPUT SPEED SENSOR (7600M) / LCT ENGINE SPEED SENSOR (7604M) / LCT TURBINE SPEED SENSOR (7607M) / K92A142 18WH K92B142 18WH / ENGINE/PLATFORM (1701/1701) 31 / A134 18WH A#142 16TN / SHIFT SELECTOR (1850) CH12_03 ECONOMY MODE RELAY (1012-R5) CH12_01 / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 486 / 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 GASOLINE ENGINE (CONT.)

12.32. 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 GASOLINE ENGINE
Figure 487 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 GASOLINE ENGINE (CONT.)

Components: BACKUP LIGHT RELAY (1010-R6); BODY CONTROLLER (1606); ECM NEGATIVE (9260); ECM POSITIVE (9261); ENGINE / PLATFORM (1701/1701); FUSE A3-E (1016); GEN5 TCM (7150); MODE RELAY (1012-R5); RELAY (1011-R2)
Wires (circuit gauge+color): A101 18TN; A103 18TN; K92A109 10WH; K92A110 10RD
See also sheets: CH12_01, CH12_02, CH3_05, CH3_66, CH7_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.32. 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 GASOLINE ENGINE (CONT.), P. 21 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090663 NO. RELEASE NO. 95885P 22DEC20 / CHAPTER 12 1/2000 ALLISON XMSN GEN 4/5 (LCT) W/F-2018-GAS-ENG (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GEN5 TCM (7150) / K92#163 18YL / K92#101 18LTBL / K92#103 18YL / K71#165 18TN / 70 9 / K92#110 18PK K92#170 18PK K92#109 18GY K92#169 18GY / ECM POSITIVE (9261) CH3_66 / ECM NEGATIVE (9260) CH3_66 / K92A110 10RD / K92A109 10WH / ENGINE / PLATFORM (1701/1701) 55 / A#165 18TN / A101 18TN / BACKUP LIGHT RELAY (1010-R6) CH7_02,03 J6-18 WAY BODY CONTROLLER (1606) / SHIFT INHIBIT RELAY (1011-R2) CH12_02 ECONOMY MODE RELAY (1012-R5) CH12_01 FUSE A3-E (1016) CH3_05 / A#163 18YL / A103 18TN / K92#141 18GY / A92#141 18GY / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 487 / 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 GASOLINE ENGINE (CONT.)

12.33. 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE / GASOLINE ENGINE, P. 22
Figure 488 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE / GASOLINE ENGINE

Components: GEN5 TCM (7150); LCT TRANSMISSION BULKHEAD (7350)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.33. 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE / GASOLINE ENGINE, P. 22 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. GEN5 TCM (7150) / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090663 NO. 95885P 17MAR21 / CHAPTER 12 1/2000 W/GEN 4/5 ALLISON LCT XMSN W/F-2018-PROP/GAS-ENG LCT TRANSMISSION BULKHEAD (7350) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PRESSURE CONTROL 55 SOLENOID 1 / PRESSURE CONTROL 36 SOLENOID 2 / PRESSURE 57 SWITCH MANIFOLD SIGNAL RETURN 58 / SHIFT SOLENOID 2 33 / SHIFT SOLENOID 1 52 / 21 INTERNAL MODE SWITCH B / 7 12 / 20 INTERNAL MODE SWITCH C / PRESSURE SW 77 MANIFOLD / PRESSURE SWITCH 4 / MAIN MOD / SUMP TEMP / INTERNAL MODE SWITCH A / ANALOG RETURN / TORQUE CONVERTER CLUTCH PRESSURE SWITCH 2 / PRESSURE CONTROL SOLENOID 1 / HIGH SIDE DRIVER 1 / PRESSURE CONTROL SOLENOID 2 / SHIFT SOLENOID 2 / INTERNAL MODE SW / INTERNAL MODE SW / INTERNAL MODE SWITCH P / PRESSURE SWITCH 1 / SHIFT SOLENOID 3 / SHIFT SOLENOID 3 / MAIN MOD / HIGH SIDE DRIVER 1 / HIGH SIDE DRIVER 2 / INTERNAL MODE SW / XMSN ID / SUMP TEMP / SHIFT SOLENOID 1 / XMSN ID / INTERNAL MODE SWITCH-NS / INTERNAL MODE SW PRESSURE SWITCH MANIFOLD / HIGH SIDE DRIVER 2 / INTERNAL MODE SW / PRESSURE SWITCH 3 / HIGH SPEED DRIVE-3 31 / TURBINE SPEED / TORQUE COVERTER CLUTCH / Figure 488 / 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE / GASOLINE ENGINE

12.34. 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE / GASOLINE
Figure 489 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE / GASOLINE ENGINE

Components: BACKUP LIGHT RELAY (1011); CLEAN GROUND (9260); CLEAN POWER (9261); CONNECTOR (1606); ENGINE/PLATFORM (1701); FUSE F21 (1011); GEN 5TCM (7150); SHIFT INHIBIT RELAY (1026); SPEED SENSOR (7600M); SPEED SENSOR (7604M); SPEED SENSOR (7607M); SWITCH RELAY (1015)
Wires (circuit gauge+color): A101 18TN; A103 18TN; K92A109 10WH; K92A110 10RD; K92A142 18WH; K92B142 18WH
See also sheets: CH15_33
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.34. 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE / GASOLINE ENGINE (CONT.), P. 23 / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090663 NO. RELEASE NO. 95885P 17MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GEN 5TCM (7150) / K92#163 18YL / K92#141 18GY / IGNITION POWER 63 / K92#180 18OR K92#120 18LTBL / K92#101 18LTBL K92#103 18YL / K71#165 18TN / K92#142 18WH / K92#109 18GY K92#169 18GY NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / K92#110 18PK K92#170 18PK / K47#160 18YL K47#140 18LTGN / K48#159 18TN K48#139 18OR / GROUND 69 / LCT OUTPUT SPEED SENSOR (7600M) / BATT POSITIVE CLEAN POWER (9261) B K92A110 10RD BATT NEGATIVE CLEAN GROUND (9260) B / K92A109 10WH / LCT TURBINE SPEED SENSOR (7607M) / ENGINE/PLATFORM (1701) 55 / K92B142 18WH / INPUT 5 / ALLISON BULKHEAD VSS / NEUTRAL START / TURBINE SPEED / TURBINE SPEED / ALLISON BULKHEAD VSS ALLISON BULKHEAD VSS / ALLISON BULKHEAD VSS / BATTERY PWR / BATTERY PWR / A92#142 16TN / A71#165 18TN / A101 18TN A103 18TN / A92#163 18YL / LCT ENGINE SPEED SENSOR (7604M) / SIGNAL RETURN / REVERSE WARN / A92#141 18GY / K92A142 18WH / Figure 489 / 1 / 2000 ALLISON XMSN GEN 4 / 5 (LCT) WITH F-2018 PROPANE / GASOLINE ENGINE (CONT.)

12.35. ALLISON LCT GEN5 WITH ARENS SHIFTER, P. 24
Figure 490 ALLISON LCT GEN5 WITH ARENS SHIFTER

Components: ARENS POSITION SENSOR (7805); ARENS SHIFT SELECTOR A (7808); ARENS SHIFTER MOTOR ACTUATOR (7802); ARENS SHIFTER NEGATIVE (9263); CAN-LO (9253); ENGINE / PLATFORM (1701); FUSE BLOCK (9252); FUSE F21 (1011); PANEL LIGHTS SPLICE (1002A); PLATFORM (1029); POSITIVE (9262); SELECTOR B (7809); XMSN MODULE (7150)
Wires (circuit gauge+color): A14MA 14RD; A14MD-G 14WH; A14ME-G 14WH; A14MH 14RD; A14MI 12WH; A92MB 16TN; A92MC 16TN; A92MF 16TN; A92MG 16TN; A92NE 18DKBL; A92NF 18TN; A92NG 18TN; A92NH 18TN; A92NP 18TN; A92NT 18TN; A92NU 18TN; A92NV 18TN; K161 18TN; K92GA 18TN; K92GB 18TN; K92GC 18TN; K92GD 18TN; K92GE 18TN; K92GF 18TN; K92HA 16TN; K92HB 16TN; K92HC 16TN; K92HD 16TN; K92IC 14RD; K92JC 14RD; K92KB-G 12WH; N14 8RD; N14-GC 8WH; N14CA 10RD; N14CB 10RD; N92IC 10RD; N92JC 10RD; N92KB-G 12WH
See also sheets: CH3_96, CH8_25
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.35. ALLISON LCT GEN5 WITH ARENS SHIFTER, P. 24 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090663 95885P 17MAR21 / CHAPTER 12 ALLISON LCT GEN5 W/ ARENS SHIFTER / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ENGINE / PLATFORM (1701) 2 / 15 24 / ARENS SHIFT SELECTOR B (7809) / ARENS SHIFT SELECTOR A (7808) / F MOTOR 2B G / A14ME-G 14WH A14MD-G 14WH / POS SENSOR 2B 6 POS SENSOR 20 2A-POW POS SENSOR 8 2C-GND 18 POS SENSOR 1B POS SENSOR 19 1C-POW POS SENSOR 7 1C-GND / A92NP 18TN / A92NF 18TN A92NV 18TN A92NH 18TN A92NT 18TN A92NU 18TN A92NG 18TN / OVER DRIVE 14 DEFEAT / 60 35 40 30 / K92HA 16TN K92HB 16TN K92HC 16TN K92HD 16TN / K92IC 14RD / K92GD 18TN K92GF 18TN K92GE 18TN K92GC 18TN K92GA 18TN K92GB 18TN / K161 18TN / ARENS SHIFTER POSITIVE (9262) A / B MOTOR 1B C MOTOR 2B / D MOTOR 2A / POS SENSOR 2B 4 POS SENSOR 6 2A-POW 5 POS SENSOR 2C-GND 3 POS SENSOR 2B 1 POS SENSOR 1A-POW 2 POS SENSOR 1C-GN / BATTERY ARENS POSITION SENSOR (7805) / XMSN MODULE (7150) / A92MB 16TN A92MC 16TN A92MF 16TN A92MG 16TN / A14MA 14RD / A14MI 12WH / A14MH 14RD / 61 INPUT / N14-GC 8WH / N14 8RD / A MOTOR 1A / MOTOR 1A MOTOR 1B MOTOR 2A / A#163A 18PK A92NE 18DKBL A5D(+) 18YL A5D(-) 18GN / PANEL LIGHT 5 / FUSE F21 (1011) CH3_94C PANEL LIGHTS SPLICE (1002A) CH8_25 J1939 DATALINK- PLATFORM (1029) CH3_96 / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / Figure 490 / ALLISON LCT GEN5 WITH ARENS SHIFTER

12.36. 1 / 2 / 3000 TRANSMISSION WITH GEN5 / 6 (LCT) WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 25
Figure 491 1 / 2 / 3000 TRANSMISSION WITH GEN5 / 6 (LCT) WITH 2017 ISB / 2021 B6.7 DIESEL

Components: GEN 4 TCM (7150); SPEED SENSOR (7600M); SPEED SENSOR (7605M); TH GEN (7601M); TH GEN (7606M)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.36. 1 / 2 / 3000 TRANSMISSION WITH GEN5 / 6 (LCT) WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 25 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090663 NO. 96289K 24SEP21 / CHAPTER 12 1/2/3000 TRANSMISSION W/GEN5/6(LCT) W/2017/2021-ISB/B6.7-DIESEL ENG / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / GEN 4 TCM (7150) / *K47#160 18YL *K47#140 18LTGN / * W/1/2000 GEN5(LCT), W/BCM 4TH GEN # W/1/2000 GEN6(LCT), W/BCM 4TH GEN % W/3000 GEN5, W/BCM 4TH GEN @ W/3000 GEN6, W/BCM 4TH GEN / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / WT MD OUTPUT SPEED SENSOR 6TH GEN (7606M) A / WT MD OUTPUT SPEED SENSOR (7605M) A / LCT OUTPUT SPEED SENSOR 6TH GEN (7601M) A / LCT OUTPUT SPEED SENSOR (7600M) A / #K47#160 18YL #K47#140 18LTGN / %K47#160 18YL %K47#140 18LTGN / @K47#160 18YL @K47#140 18LTGN / Figure 491 / 1 / 2 / 3000 TRANSMISSION WITH GEN5 / 6 (LCT) WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

12.37. 3000 TRANSMISSION WITH PTO WITH GEN5 / 6 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 26
Figure 492 3000 TRANSMISSION WITH PTO WITH GEN5 / 6 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: SPEED SENSOR (7605M); TH GEN (7606M); TRANS MODULE 3 (1234)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 12.37. 3000 TRANSMISSION WITH PTO WITH GEN5 / 6 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 26 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090663 NO. 96289K 24SEP21 / CHAPTER 12 3000 TRANSMISSION W/PTO W/GEN5/6 W/2017/2021-ISB/B6.7-DIESEL ENG / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / TRANS MODULE 3 (1234) / %K47#160 18YL %K47#140 18LTGN / # W/3000 GEN6 PTO, W/BCM 4TH GEN % W/3000 GEN5 PTO, W/BCM 4TH GEN / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / WT MD OUTPUT SPEED SENSOR 6TH GEN (7606M) A / WT MD OUTPUT SPEED SENSOR (7605M) A / #K47#160 18YL #K47#140 18LTGN / Figure 492 / 3000 TRANSMISSION WITH PTO WITH GEN5 / 6 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

Figure 493 AIR DRYER AND DRAIN VALVE SYSTEM FOR 2017 ISB / 2021 B6.7 DIESEL & 2018

Components: AIR DRYER (9257); AIR DRYER/ DRAIN VALVE FUSE (4107); DRAIN VALVE (9526/9526A); DRAIN VALVE 2 FUSE (4017); FORWARD CHASSIS (1700/1700); FUEL HTR RELAY (4007); FUSE A3-N (1016); FUSE F23 (1011); FUSE STUD (4000E); MEGA FUSE STUD (4000A); PLATFORM (1701); PLATFORM (1701/1701); SPLICE (6740); STARTER FUSE (4106)
Wires (circuit gauge+color): A13BF 18PK; A13F 18PK; A13FD 18PK; A39DE 14BK; A39E 14BK; A39F 14BK; A95CA 18PK; K10-GA 12WH; K10-GAB 14WH; K10-GAB 18WH; K13F 18PK; K13FB 18PK; K13FC 18PK; K14B 12RD; K14B 14RD; K39A 14GY; K39D 14GY; M39B 14BK; M39B-G 14WH; M39C 14BK; M39C-G 14WH; M39D 14BK; M39D-G 14WH
See also sheets: CH13_19, CH3_06, CH3_50, CH3_51, CH3_61, CH3_62
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / CHASSIS SYSTEM (CHAPTER 13) / 13.1. AIR DRYER AND DRAIN VALVE SYSTEM FOR 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE, P. 1 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090664 NO. RELEASE NO. 95885P 21JAN21 / CHAPTER 13 AIR DRYER AND DRAIN VALVE SYSTEM W/2017/2021 ISB/B6.7 DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 19NOV21 REMOVED CIRC M11-GA & M39C-G AT R/D 9257. / @M39B 14BK %M39D 14BK / K39D 14GY / 2 86 / 1 30 / @K39A 14GY / MEGA FUSE STUD (4000A) / A39DE 14BK / ENG/ PLATFORM (1701) 28 A39E 14BK / AIR DRYER (9257) A / PLATFORM / FORWARD CHASSIS (1700/1700) 28 / M39C 14BK %M39C-G 14WH / @M39B-G 14WH %M39D-G 14WH / MEGA FUSE STUD (4000A) DRAIN VALVE (9526/9526A) A / A39F 14BK / @M39C-G 14WH / @K13FC 18PK / %K13F 18PK @K13F 18PK / FUSE A3-N (1016) CH3_06 / W/F-2018-PROPANE/GASOLINE ENGINE W/2017-ISB-DIESEL ENGINE ENG/ PLATFORM (1701/1701) 33 / @K10-GAB 18WH / @K10-GA 12WH / UPPER GND STUD (2G) CH3_61 / *A13F 18PK *A13BF 18PK &A13BF 18PK / FUEL HTR RELAY (4007) CH13_19 / UPPER MEGA FUSE STUD (4000E) / %K10-GAB 14WH / UPPER GND STUD (3G) CH3_62,63 / GROUND SPLICE (6740) CH3_51 / GROUND SPLICE (6740) CH3_50 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / FUSE F23 (1011) CH3_94C / Figure 493 / AIR DRYER AND DRAIN VALVE SYSTEM FOR 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE

13.2. AUTOMATIC DRAIN VALVE EFFECTS WITH HALDEX DRAIN VALVE, P. 2
Figure 494 AUTOMATIC DRAIN VALVE EFFECTS WITH HALDEX DRAIN VALVE

Components: BODY CONTROLLER (1601); FUSE A3-L (1016); FUSE A6-B (1014); FWD CHASSIS (1700); SPLICE (6740); VALVE RELAY (1012-R2)
Wires (circuit gauge+color): A39A 16GY; A39B 16GY; A39C 16GY; A39D 14OR; M39B 14BK; M39B-G 14WH; M39D 14BK; M39D-G 14WH
See also sheets: CH3_01, CH3_06, CH3_50, CH3_51
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.2. AUTOMATIC DRAIN VALVE EFFECTS WITH HALDEX DRAIN VALVE, P. 2 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090664 95885P 21JAN21 / CHAPTER 13 AUTOMATIC DRAIN VALVE EFFECTS W/HALDEX DRAIN VALVE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / *M39D-G 14WH / HALDEX DRAIN VALVE (@9527/#9527A) / A39C 16GY / AUTO DRAIN VALVE RELAY (1012-R2) / FUSE A6-B (1014) CH3_01 / J4- BLUE BODY CONTROLLER (1601) / PLATFORM/ FWD CHASSIS (1700) / ZVR E5 / A39D 14OR / HALDEX DRAIN VALVE (@9527/#9527A) / %M39B-G 14WH / %M39B 14BK / *M39D 14BK / A39A 16GY / FUSE A3-L (1016) CH3_06 / A39B 16GY / GROUND SPLICE (6740) CH3_50 / GROUND SPLICE (6740) CH3_51 / Figure 494 / AUTOMATIC DRAIN VALVE EFFECTS WITH HALDEX DRAIN VALVE

13.3. AUTOMATIC DRAIN VALVE EFFECTS WITH HALDEX DRAIN VALVE (CONT.), P. 2A
Figure 495 AUTOMATIC DRAIN VALVE EFFECTS WITH HALDEX DRAIN VALVE

Components: BODY CONTROLLER (1601); FORWARD CHASSIS (1700); FUSE F19 (1011); FUSE F5 (1011); RELAY (1011-R3); RELAY W/0508095 (1018B); SPLICE (1004); SPLICE (6740); VALVE (9527/9527A); VALVE RELAY (1018)
Wires (circuit gauge+color): A39A 16GY; A39B 16GY; A39C 16GY; A39D 16GY; M39B 14BK; M39B-G 14WH; M39D 14BK; M39D-G 14WH
See also sheets: CH3_50, CH3_51, CH3_94, CH7_70
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.3. AUTOMATIC DRAIN VALVE EFFECTS WITH HALDEX DRAIN VALVE (CONT.), P. 2A / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090664 95885P 25MAR21 / CHAPTER 13 AUTOMATIC DRAIN VALVE EFFECTS W/HALDEX DRAIN VALVE (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / @M39D-G #M39B-G 14WH 14WH / @M39D 14BK #M39B 14BK / HALDEX DRAIN VALVE (9527/9527A) B / FUSE F19 (1011) CH3_94C / A39D 140R / A39A 16GY / AUTO DRAIN RELAY W/0508095 (1018B) / 85 2 / A39C 16GY 1 86 / 3 30 / 87A 5 / GROUND GROUND SPLICE SPLICE (6740) (6740) CH3_50 CH3_51 / PLATFORM/ FORWARD CHASSIS (1700) 23 / A39A 16GY / 3 30 / PLATFORM/ FORWARD CHASSIS (1700) 23 / 85 2 / A39C 16GY / HALDEX DRAIN VALVE (9527/9527A) / FUSE F19 (1011) CH3_94C / GROUND SPLICE (6740) CH3_51 / @M39D 14BK #M39B 14BK @ W/2017-ISB-ENGINE DIESEL ENGINE # W/F-2018-PROPANE/GASOLINE ENGINE NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / 1 86 / @M39D-G 14WH / AUTO DRAIN VALVE RELAY (1018) / A39B 16GY / GROUND SPLICE (1004) CH3_95A / GROUND SPLICE (6740) CH3_50 STOP LIGHT RELAY (1011-R3) CH7_70 / W/MUX FOR BODY CONTROLLER PROG ONLY / A39D 16GY / #M39B-G 14WH / @A39B 16GY / #A39B 16GY / FUSE F5 (1011) CH3_94 / Figure 495 / AUTOMATIC DRAIN VALVE EFFECTS WITH HALDEX DRAIN VALVE

13.4. AIR COMPRESSOR ON HYDRAULIC CHASSIS WITH 2017 ISB / 2021 B6.7
Figure 496 AIR COMPRESSOR ON HYDRAULIC CHASSIS WITH 2017 ISB / 2021 B6.7 DIESEL &

Components: BODY CONTROLLER (1600); BODY CONTROLLER (1602); FWD CHASSIS (1700/1700); PRESSURE SENSOR (6715); REFERENCE (1005)
Wires (circuit gauge+color): A40 18GY; A6H 18GY; A9A 18GY; A9AA 18GY; M40 18GY; M6H 16GY; M9H 18GY
See also sheets: CH3_58
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.4. AIR COMPRESSOR ON HYDRAULIC CHASSIS WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE, P. 3 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 22JAN21 / CHAPTER 13 AIR COMPRESSOR ON HYDRAULIC CHASSIS W/2017/ 2021 ISB/B6.7 DIESEL & W/F-2018-PROPANE/ GASOLINE ENGINE / MJV0488 19NOV21 ADDED CIRC A9AA IN CAV 43 AT R/D 1700. / PLATFORM/ FWD CHASSIS (1700/1700) 54 / J5 - TAN BODY CONTROLLER (1602) / %M40 18GY %M6H 16GY %M9H 18GY / POSITIVE 5V OUTPUT (B) / J3 - RED BODY CONTROLLER (1600) / A6H 18GY / AIR COMPRESSOR PRESSURE SENSOR (6715) C B A / 55 43 / PRIMARY AIR PRESSURE B2 / !!A9A 18GY / A40 18GY / ZERO VOLT (1005) CH3_58,95M / @M40 18GY @M6H 16GY @M9H 18GY / AIR COMPRESSOR PRESSURE SENSOR (*6715/#6715A) 3 2 1 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / !A9AA 18GY / ZERO VOLT (1005) CH3_58 / Figure 496 / AIR COMPRESSOR ON HYDRAULIC CHASSIS WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE

13.5. PARK BRAKE SIGNAL WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE, P. 4
Figure 497 PARK BRAKE SIGNAL WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE

Components: BODY CONTROLLER (1600); BODY CONTROLLER (1601); BODY CONTROLLER (1602); BRAKE SAAR (9777M); BRAKE SW (1813); FUSE A3-U (1016); PARK BRAKE SIGNAL (10396); PLATFORM (1700); PLATFORM (1702); REFERENCE (1005); RELAY (10308-R6); SPLICE (10336); SPLICE (6740)
Wires (circuit gauge+color): A44A 18GY; A44CC 18GY; A44M 16GY; A44N 18GY; A9K 18GY; B44 18GY; B44-G 18WH; B44-GA 18WH; B44-GB 18WH; B44A 18GY; M44-GB 18WH; M44M 18GY; M44N 18GY; R44-GB 18WH; R44M 18GY; R44N 18GY
See also sheets: CH3_03, CH3_40, CH3_50, CH3_58
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.5. PARK BRAKE SIGNAL WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE, P. 4 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. W/PARK BRAKE SIGNAL B44-G 18WH / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / CHAPTER 13 PARK BRAKE SIGNAL W/2017/2021 ISB/B6.7 DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 19NOV21 ADDED ENGINE EFFECTS FOR CIRC A44A AT R/D 1601. / PARK BRAKE F1 RELAY / PARK BRAKE SIGNAL (10396) A / GROUND SPLICE (10336) CH3_40 PARK BRAKE RELAY (10308-R6) 30 / B44A 18GY / ELEC PANEL/ PLATFORM (1702) 63 / B44-GB 18WH / %A44A 18GY / B44 18GY / J4 - BLUE BODY CONTROLLER (1601) / PARK BRAKE F14 INPUT / J5 - TAN BODY CONTROLLER (1602) / FWD CHASSIS/ PLATFORM (1700) 10 A44N 18GY A44M 16GY / M44N 18GY M44M 18GY @M44-GB 18WH %M44-GB 18WH / AIR PARK BRAKE SAAR (9777M) / FWD CHASSIS/ REAR CHASSIS @(9513M/F) %(9516M/F) 7/C / R44N 18GY R44M 18GY R44-GB 18WH / PARK BRAKE A12 INPUT / A9K 18GY / A44CC 18GY / J3 - RED BODY CONTROLLER (1600) / AIR PARK BRAKE SW (1813) D / ZERO VOLT (1005) CH3_58 / FUSE A3-U (1016) CH3_03 GROUND SPLICE (6740) CH3_50 / B44-GA 18WH / W/HYD BRAKES W/AIR PARK BRAKE / LOWER DASH GROUND STUD (2GG) / @ W/2017/2021 ISB/B6.7 DIESEL ENGINE % W/2018-PROPANE/GASOLINE ENGINE / % W/2018-PROPANE/GASOLINE ENGINE / Figure 497 / PARK BRAKE SIGNAL WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE

13.6. PARK BRAKE SIGNAL WITH 2017 ISB & 2018 PROPANE / GASOLINE ENGINE, P. 4A
Figure 498 PARK BRAKE SIGNAL WITH 2017 ISB & 2018 PROPANE / GASOLINE ENGINE

Components: BODY CONTROLLER (1600); BODY CONTROLLER (1601); BODY CONTROLLER (1602); BRAKE SAAR (9777M); BRAKE SW (1813); FUSE F15 (1011); PARK BRAKE SIGNAL (10396); PLATFORM (1700); PLATFORM (1702); REFERENCE (1005); RELAY (10308); SPLICE (10336); SPLICE (6740)
Wires (circuit gauge+color): A44A 18GY; A44CC 18GY; A44M 16GY; A44N 18GY; A9K 18GY; B44 18GY; B44-G 18WH; B44-GA 18WH; B44A 18GY; M44-GB 18WH; M44M 18GY; M44N 18GY; R44-GB 18WH; R44M 18GY; R44N 18GY
See also sheets: CH3_50
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.6. PARK BRAKE SIGNAL WITH 2017 ISB & 2018 PROPANE / GASOLINE ENGINE, P. 4A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090664 95885P 25MAR21 / CHAPTER 13 PARK BRAKE SIGNAL W/2017-ISB-DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 19NOV21 ADDED ENGINE EFFECT B FOR CIRC A44A FROM R/D 1601. / PARK BRAKE F1 RELAY / PARK BRAKE SIGNAL (10396) A / B44-GA 18WH 86 H1 B44-G 18WH / J2 85 / PARK BRAKE RELAY (10308) 30 H2 / B44A 18GY / ELEC PANEL/ PLATFORM (1702) 63 / %A44A 18GY / B44 18GY / GROUND SPLICE (10336) CH3_95J / J4 - BLUE BODY CONTROLLER (1601) / PARK BRAKE F14 INPUT / J5 - TAN BODY CONTROLLER (1602) / FWD CHASSIS/ PLATFORM (1700) 10 / M44N 18GY M44M 18GY @M44-GB 18WH / A44N 18GY A44M 16GY GROUND SPLICE (6740) CH3_50 / FWD CHASSIS/ REAR CHASSIS @(9513M/F) %(9516M/F) 7/C / R44N 18GY R44M 18GY R44-GB 18WH / PARK BRAKE A12 INPUT / A44CC 18GY A9K 18GY / J3 - RED BODY CONTROLLER (1600) / AIR PARK BRAKE SW (1813) / ZERO VOLT (1005) CH3_95M / FUSE F15 (1011) CH3_94A / W/PARK BRAKE SIGNAL / W/HYD BRAKES W/AIR PARK BRAKE / @ W/2017-ISB-DIESEL ENGINE % W/2018-PROPANE/GASOLINE ENGINE NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / %M44-GB 18WH / LOWER DASH GROUND STUD (2GG) / AIR PARK BRAKE SAAR (9777M) / % W/2018-PROPANE/GASOLINE ENGINE / Figure 498 / PARK BRAKE SIGNAL WITH 2017 ISB & 2018 PROPANE / GASOLINE ENGINE

13.7. AIR SOLENOID EFFECTS WITH 4 PACK WITH 2017 ISB / 2021 B6.7 DIESEL &
Figure 499 AIR SOLENOID EFFECTS WITH 4 PACK WITH 2017 ISB / 2021 B6.7 DIESEL & 2018

Components: BODY CONTROLLER (1601); FWD CHASSIS (1700/1700)
Wires (circuit gauge+color): A59J 18GY; A59K 18GY; A59L 18GY; A59M 18GY; M59H-G 14WH; M59J 18GY; M59K 18GY; M59L 18GY; M59M 18GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.7. AIR SOLENOID EFFECTS WITH 4 PACK WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE, P. 5 / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 22JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J4 - BLUE BODY CONTROLLER (1601) / PLATFORM/ FWD CHASSIS (1700/1700) / AIR SOLENOID # 1 E16 / A59J 18GY / M59J 18GY / AIR SOLENOID # 2 F10 / A59K 18GY / AIR SOLENOID # 3 E12 / A59L 18GY / AIR SOLENOID # 4 F8 / A59M 18GY / M59K 18GY / M59L 18GY / M59M 18GY / AIR SOLENOID 4-PACK @(9736) / M59H-G 14WH / LOWER DASH GROUND STUD (2GG) / @ W/2017/2021 ISB/B6.7 DIESEL ENGINE AND W/F-2018-PROPANE/GASOLINE ENGINE / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 499 / AIR SOLENOID EFFECTS WITH 4 PACK WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE

13.8. WINDSHIELD WIPER EFFECTS WITH CE BUS WIPER MOTOR WIRING, P. 6
Figure 500 WINDSHIELD WIPER EFFECTS WITH CE BUS WIPER MOTOR WIRING

Components: BODY CONTROLLER (1601); BODY CONTROLLER (1604); FWD CHASSIS (1700); RELAY (1011-R1); RELAY (1011-R4); SPLICE (1003A); WIPER MOTOR (4046)
Wires (circuit gauge+color): A82 16GY; A82-GA 16WH; A82A 18GY; A82B 18GY; A82C 18GY; A82D 18GY; A82DA 16GY; A82DB 16GY; A82DC 16GY; A82DD 16GY; A82H 16GY; A82K 16GY; A82N 16GY; A82R 16GY
See also sheets: CH3_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.8. WINDSHIELD WIPER EFFECTS WITH CE BUS WIPER MOTOR WIRING, P. 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090664 95885P 22JAN21 / CHAPTER 13 WINDSHIELD WIPER EFFECTS W/CE BUS WIPER MOTOR WIRING / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A82DB 16GY / J4-RED BODY CONTROLLER (1601) / WINDSHIELD E6 WIPER / WIPER MOTOR (4046) / A82DA 16GY A82H 16GY / WINDSHIELD WIPER PWR / GROUND SPLICE (1003A) CH3_32 / A82K 16GY / 4.4uH x3 / A82N 16GY / A82D 18GY / WIPER PWR RELAY (1011-R1) 86 / A82C 18GY / A82 16GY / WV50V 2.2uFx2 / J2-10 WAY BODY CONTROLLER (1604) / A82R 16GY / A82DD A82DC 16GY 16GY / A82-GA 16WH / WIPER HI LOW RELAY (1011-R4) 86 / WINDSHIELD WIPER PWR / PLATFORM/ FWD CHASSIS (1700) 41 / @A82B 18GY / @A82A 18GY / @ W/PASS THRU BUS MOTOR WIRING, DIESEL / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 500 / WINDSHIELD WIPER EFFECTS WITH CE BUS WIPER MOTOR WIRING

13.9. WINDSHIELD WIPER EFFECTS WITH CE BUS WIPER MOTOR WIRING (CONT.), P. 7
Figure 501 WINDSHIELD WIPER EFFECTS WITH CE BUS WIPER MOTOR WIRING (CONT.)

Components: BODY CONTROLLER (1600); BODY CONTROLLER (1602); CONTROLLER (1600); FUSE A3-H (1016); FWD CHASSIS (1700); J3 RED BODY CONTROLLER (1600); PUMP (4500); TURN SIGNAL SW (1810); ZVR (1005)
Wires (circuit gauge+color): A11-GAH 16WH; A56 18OR; A56 20OR; A57 18OR; A57 20OR; A82S 20GY; A82T 20GY; A82U 20GY; A87-G 18GY; A87-GA 18WH; A87-GB 18GY; A87-GC 18GY; A87A 18GY; A9S 18GY; M87-G 18GY; M87A 18GY
See also sheets: CH13_08, CH3_06, CH3_58
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.9. WINDSHIELD WIPER EFFECTS WITH CE BUS WIPER MOTOR WIRING (CONT.), P. 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. J3-RED BODY CONTROLLER (1600) / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090664 95885P 22JAN21 / CHAPTER 13 WINDSHIELD WIPER EFFECTS W/CE BUS WIPER MOTOR WIRING (CONT.) / MJV0488 19NOV21 REMOVED R/D 4500A. / A82T 20GY A82S 20GY A82U 20GY #A9S 18GY A102 20YL A52C 20YL / A11 WIPER SW 2 / CHASSIS GND 11 / A87-GA 18WH / HIGH BEAM / **A87-G 18GY J5 TAN BODY CONTROLLER (1602) E16 / R TURN / WIPER 2 / WIPER 0 / WIPER 1 / L TURN / TURN SIGNAL SW (1810) / **A87-GC 18GY / WIPER SW 1 A10 / WASHER PUMP A15 / **A87-GB 18GY / &A56 20OR / FLASH TO PASS A14 SW INPUT / &A57 20OR / WIPER SW 0 / HIGH BEAM SIGNAL / WASHER PUMP (4500) 2 / FUSE A3-H (1016) CH3_06 / #M87-G 18GY @M87-G 18GY / PLATFORM/ FWD CHASSIS (1700) 25 / @M87A 18GY #M87A 18GY / A87A 18GY / *A57 18OR / J3-RED BODY CONTROLLER (1600) / ZVR (1005) CH3_58 / J3 RED BODY CONTROLLER (1600) CH13_08 J3 RED BODY CONTROLLER (1600) CH13_08 / J3 RED BODY CONTROLLER (1600) CH13_08 J3 RED BODY CONTROLLER (1600) CH13_08 / A11-GAH 16WH / *A56 18OR / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / # W/F-2018-PROPANE/GASOLINE ENGINE @ W/2017/2021 ISB/B6.7 ENGINE * W/REMOTE HAZARD SW & N/REMOTE HAZARD SW **CE/PASS THRU BUS WIPER MOTOR WIRING DIESEL / Figure 501 / WINDSHIELD WIPER EFFECTS WITH CE BUS WIPER MOTOR WIRING (CONT.)

13.10. REMOTE HAZARD SWITCH EFFECTS W/ TILTING & TELESCOPING, P. 8
Figure 502 REMOTE HAZARD SWITCH EFFECTS W/ TILTING & TELESCOPING

Components: BODY CONTROLLER (1600); DIODE B3-A (10304); DIODE B3-N (10304); ELEC PANEL/PLATFORM (1703); SIGNAL SW (1810)
Wires (circuit gauge+color): A56 18OR; A56 20OR; A56A 18OR; A56B 18OR; A57 18OR; A57A 18OR; A57B 18OR; B60BE 18OR; B60BF 18OR
See also sheets: CH13_07, CH7_65
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.10. REMOTE HAZARD SWITCH EFFECTS W/ TILTING & TELESCOPING, P. 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090664 95885P 22JAN21 / CHAPTER 13 REMOTE HAZARD SWITCH EFFECTS W/TILTING & TELESCOPING / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J3-RED BODY CONTROLLER (1600) LEFT TURN SIGNAL A7 SWITCH INPUT RIGHT TURN SIGNAL A6 SWITCH INPUT / ELEC PANEL/PLATFORM (1703) B11 / A56 18OR A57 18OR / DIODE B3-N (10304) CH7_65 / B60BE 18OR / A56B 18OR / A57B 18OR / #A57A 18OR / TURN SIGNAL SW (1810) CH13_07 / B60BF 18OR / #A56A 18OR / DIODE B3-A (10304) CH7_65 / J3-RED BODY CONTROLLER (1600) L TURN SIGNAL A7 SW INPUT / R TURN SIGNAL A6 SW INPUT / A57 200R / A56 20OR / TURN SIGNAL SW (1810) CH13_07 / N/REMOTE HAZARD SW / W/REMOTE HAZARD SW / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 502 / REMOTE HAZARD SWITCH EFFECTS W/ TILTING & TELESCOPING

13.11. WINDSHIELD WIPER EFFECTS W/ WIPER MOTOR WIRING WITH 2017 ISB /
Figure 503 WINDSHIELD WIPER EFFECTS W/ WIPER MOTOR WIRING WITH 2017 ISB / 2021 B6.7

Components: BODY CONTROLLER (1601); BODY CONTROLLER (1604); RELAY R1 (1011); RELAY R2 (1011); SPLICE (1003A); WIPER MOTOR (4046)
Wires (circuit gauge+color): A82 16GY; A82-GA 16WH; A82C 18GY; A82D 18GY; A82DA 16GY; A82DB 16GY; A82DC 16GY; A82DD 16GY; A82H 16GY; A82K 16GY; A82N 16GY; A82R 16GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.11. WINDSHIELD WIPER EFFECTS W/ WIPER MOTOR WIRING WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE, P. 8A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 25MAR21 / CHAPTER 13 WINDSHIELD WIPER EFFECTS W/WIPER MOTOR WIRING W/2017-ISB-DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 10JUN21 INITIAL PRODUCTION RELEASE. / A82DB 16GY / J4-RED BODY CONTROLLER (1601) / WINDSHIELD E6 WIPER / C D 87A / WIPER MOTOR (4046) / A82DA 16GY A82H 16GY / WINDSHIELD WIPER PWR / E 30 / GROUND SPLICE (1003A) CH3_95B / A82K 16GY / C D 87A / 4.4uH x3 / A82N 16GY / A82D 18GY / B 86 / WIPER PWR RELAY R1 (1011) 85 A / A82C 18GY / A82 16GY / WV50V 2.2uFx2 / E 30 / J2-10 WAY BODY CONTROLLER (1604) / A82R 16GY / A82DD 16GY A82DC 16GY / A82-GA 16WH / WIPER SPEED RELAY R2 (1011) B 85 86 A / WINDSHIELD WIPER PWR / Figure 503 / WINDSHIELD WIPER EFFECTS W/ WIPER MOTOR WIRING WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE

13.12. WINDSHIELD WIPER EFFECTS W/ WIPER MOTOR WIRING WITH 2017 ISB /
Figure 504 WINDSHIELD WIPER EFFECTS W/ WIPER MOTOR WIRING WITH 2017 ISB / 2021 B6.7

Components: BODY CONTROLLER (1600); BODY CONTROLLER (1602); FUSE F34 (1011); FWD CHASSIS (1700); J3 RED BODY CONTROLLER (1600); PUMP (4500); REFERENCE (1005); TURN SIGNAL SW (1810)
Wires (circuit gauge+color): A11-GAH 16WH; A56 18OR; A56 20OR; A57 18OR; A57 20OR; A82S 20GY; A82T 20GY; A82U 20GY; A87-G 18GY; A87-GA 18WH; A87-GB 18GY; A87-GC 18GY; A87A 18GY; A9S 18GY; M87-G 18GY; M87A 18GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.12. WINDSHIELD WIPER EFFECTS W/ WIPER MOTOR WIRING WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE (CONT.), P. 8B / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090664 NO. RELEASE NO. 95885P 25MAR21 / MJV0488 19NOV21 REMOVED R/D 4500A. / A82T 20GY A82S 20GY A82U 20GY A9S 18GY A102 20YL A52C 20YL / A11 WIPER SW 2 / CHASSIS GND 11 / A87-GA 18WH / HIGH BEAM / **A87-G 18GY J5 TAN BODY CONTROLLER (1602) E16 GND / R TURN / WIPER 2 / WIPER 0 / WIPER 1 / L TURN / TURN SIGNAL SW (1810) / **A87-GC 18GY / WIPER SW 1 A10 / WASHER PUMP A15 / **A87-GB 18GY / &A56 20OR / FLASH TO PASS A14 SW INPUT / &A57 20OR / WIPER SW 0 / HIGH BEAM SIGNAL / WASHER PUMP (4500) 2 / FUSE F34 (1011) CH3_94B / #M87-G 18GY @M87-G 18GY / PLATFORM/ FWD CHASSIS (1700) 25 / @M87A 18GY #M87A 18GY / A87A 18GY / *A57 18OR / J3-RED BODY CONTROLLER (1600) / ZERO VOLT (1005) CH3_95M / J3 RED BODY CONTROLLER (1600) CH3_8D J3 RED BODY CONTROLLER (1600) CH13_8C,8D / A11-GAH 16WH / *A56 18OR / J3 RED BODY CONTROLLER (1600) CH3_8D J3 RED BODY CONTROLLER (1600) CH13_8C,8D / Figure 504 / WINDSHIELD WIPER EFFECTS W/ WIPER MOTOR WIRING WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE (CONT.)

13.13. REMOTE HAZARD SWITCH EFFECTS W/ TILTING & TELESCOPING WITH 2017
Figure 505 REMOTE HAZARD SWITCH EFFECTS W/ TILTING & TELESCOPING WITH 2017 ISB DIESEL

Components: BODY CONTROLLER (1600); CONTROLLER (1602); ELEC PANEL/PLATFORM (1703); LT SW (10256); REFERANCE (1005); RELAY (1022); RELAY (1025); SPLICE (1003B); TURN SIGNAL SW (1810)
Wires (circuit gauge+color): A56 18OR; A56-G 16OR; A56A 18OR; A56B 18OR; A57 18OR; A57-G 16OR; A57A 18OR; A57B 18OR; A60A 18OR; A60B 16OR; A60C 16OR; A9C 18GY; A9H 18GY; A9T 18GY; A9U 18GY; B60A 18OR
See also sheets: CH7_65
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.13. REMOTE HAZARD SWITCH EFFECTS W/ TILTING & TELESCOPING WITH 2017 ISB DIESEL & 2018 PROPANE / GASOLINE ENGINE, P. 8C / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 25MAR21 / CHAPTER 13 REMOTE HAZARD SWITCH EFFECTS W/TILTING & TELESCOPING W/2017-ISB-DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 86 2 / J3-RED BODY CONTROLLER (1600) L TURN SIGNAL SW INPUT / A56-G 16OR / A9T 18GY / ELEC PANEL/PLATFORM (1703) B4 B60A A60A 18OR 18OR / 85 5 4 A56A 18OR / 87A 4 3 / J5-TAN BODY CONTROLLER (1602) / AUX HAZARD RELAY (1025) / A60C 16OR / A9U 18GY / 1 30 / 18OR 18OR A56 A57 / 5 85 / AUX HAZARD RELAY 2 (1022) 1 86 30 / A56B 18OR / R TURN SIGNAL SW INPUT / A57B 18OR / A60B 16OR / A57A 18OR / 18GY A9H / TURN SIGNAL SW (1810) CH13_8B / HAZARD LT SW (10256) CH7_65 GROUND SPLICE (1003B) CH3_95C / A57-G 16OR / ZERO VOLT REFERANCE (1005) CH3_95M / A9C 18GY / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / ZVR E5 / W/ELECTRICAL SYSTEM MUX FOR BODY CONTROLLER PROG ONLY / Figure 505 / REMOTE HAZARD SWITCH EFFECTS W/ TILTING & TELESCOPING WITH 2017 ISB DIESEL & 2018 PROPANE / GASOLINE ENGINE

13.14. REMOTE HAZARD SWITCH EFFECTS W/ TILTING & TELESCOPING WITH 2017
Figure 506 REMOTE HAZARD SWITCH EFFECTS W/ TILTING & TELESCOPING WITH 2017 ISB DIESEL

Components: BODY CONTROLLER (1600); DIODE D70 (10306); ELEC PANEL/PLATFORM (1703); FUSE F55 (10305); TURN SIGNAL SW (1810)
Wires (circuit gauge+color): A56 18OR; A56 20OR; A56A 18OR; A56B 18OR; A57 18OR; A57A 18OR; A57B 18OR; B60BE 18OR; B60BF 18OR
See also sheets: CH7_65
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.14. REMOTE HAZARD SWITCH EFFECTS W/ TILTING & TELESCOPING WITH 2017 ISB DIESEL & 2018 PROPANE / GASOLINE ENGINE (CONT.), P. 8D / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090664 NO. RELEASE NO. 95885P 25MAR21 / CHAPTER 13 REMOTE HAZARD SWITCH EFFECTS W/TILTING & TELESCOPING W/2017-ISB-DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J3-RED BODY CONTROLLER (1600) L TURN SIGNAL A7 SW INPUT / ELEC PANEL/PLATFORM (1703) B11 / 18OR 18OR A56 A57 / DIODE D70 (10306) CH7_65 FUSE F55 (10305) CH3_94M / B60BE 18OR / A56B 18OR / R TURN SIGNAL A6 SW INPUT / A57B 18OR / A57A 18OR / TURN SIGNAL SW (1810) CH13_8B / B60BF 18OR / A56A 18OR / J3-RED BODY CONTROLLER (1600) L TURN SIGNAL A7 SW INPUT / A57 200R / A56 20OR / TURN SIGNAL SW (1810) CH13_8B / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / W/ENHANCED VEHICLE CONTROL MODULE FUNCTION / N/REMOTE HAZARD SW / R TURN SIGNAL SW INPUT / Figure 506 / REMOTE HAZARD SWITCH EFFECTS W/ TILTING & TELESCOPING WITH 2017 ISB DIESEL & 2018 PROPANE / GASOLINE ENGINE (CONT.)

13.15. AIR HORN EFFECTS WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE, P. 9
Figure 507 AIR HORN EFFECTS WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE

Components: AIR HORN (10285); AIR HORN SW (10286); FOOT SW (8313); FOOT SW (8314); FUSE A1-K (10305); PLATFORM (1702); PULL SW (10287/10287A); SPLICE (10327); SPLICE (10337)
Wires (circuit gauge+color): A100A 18GY; A100B 18GY; B100-G 16GY; B100-G 18WH; B100-GA 16WH; B100A 18GY; B100B 18GY; B62-GB 18WH; B62B 18DKBL
See also sheets: CH3_10, CH3_41, CH8_29
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.15. AIR HORN EFFECTS WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE, P. 9 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 13 AIR HORN EFFECTS W/2017/2021 ISB/B6.7 DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / AIR HORN SW (10286) 7 / *B62-GB 18WH / *B62B 18DKBL / SW ILLUM SPLICE (10327) CH8_29 / *B100A 18GY @B100A 18GY / @B100-G 16GY *B100-G 18WH #B100-G 18WH / GROUND SPLICE (10337) CH3_41 / LOCATED UNDER DRIVER L FOOT / #B100A 18GY / ELEC PANEL/ PLATFORM (1702) 45 / AIR HORN (10285) / #B100B 18GY / A100B 18GY / AIR HORN FOOT SW (8313) / *B100B 18GY / @B100-GA 16WH / AIR HORN PULL SW (10287/10287A) / AIR HORN / AIR INPUT / FUSE A1-K (10305) CH3_10.25 / A100A 18GY / AIR HORN FOOT SW (8314) / Figure 507 / AIR HORN EFFECTS WITH 2017 ISB / 2021 B6.7 DIESEL & 2018 PROPANE / GASOLINE ENGINE

13.16. AIR HORN EFFECTS WITH 2017 ISB DIESEL & 2018 PROPANE / GASOLINE
Figure 508 AIR HORN EFFECTS WITH 2017 ISB DIESEL & 2018 PROPANE / GASOLINE ENGINE

Components: AIR HORN (10285); AIR HORN SW (10286); FOOT SW (8313); FOOT SW (8314); FUSE F16 (10302); PLATFORM (1702); PULL SW (10287/10287A); SPLICE (10327); SPLICE (10337)
Wires (circuit gauge+color): A100A 18GY; A100B 18GY; B100-G 16GY; B100-G 18WH; B1000-GA 16WH; B100A 18GY; B100B 18GY; B62-GB 18WH; B62B 18DKBL
See also sheets: CH8_29
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.16. AIR HORN EFFECTS WITH 2017 ISB DIESEL & 2018 PROPANE / GASOLINE ENGINE, P. 9A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 13 AIR HORN EFFECTS W/2017-ISB-DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / AIR HORN SW (10286) 7 / B62-GB 18WH / B62B 18DKBL / SW ILLUM SPLICE (10327) CH8_29 / *B100A 18GY @B100A 18GY / @B100-G 16GY *B100-G 18WH #B100-G 18WH / GROUND SPLICE (10337) CH3_95L / LOCATED UNDER DRIVER L FOOT / #B100A 18GY / ELEC PANEL/ PLATFORM (1702) 45 / AIR HORN (10285) / #B100B 18GY / A100B 18GY / AIR HORN FOOT SW (8313) / *B100B 18GY / @B1000-GA 16WH / AIR HORN PULL SW (10287/10287A) / AIR HORN / AIR INPUT / FUSE F16 (10302) CH3_94E / A100A 18GY / AIR HORN FOOT SW (8314) / Figure 508 / AIR HORN EFFECTS WITH 2017 ISB DIESEL & 2018 PROPANE / GASOLINE ENGINE

13.17. TRACTION AIDS EFFECTS WITH TRACTION CHAIN, P. 10
Figure 509 TRACTION AIDS EFFECTS WITH TRACTION CHAIN

Components: CHAIN (10265); CHAIN (10266); FUSE B3-V (10304); FUSE F22 (10302)
Wires (circuit gauge+color): B138 16GY; B138A 16GY; Y12 18LTBL; Y138 12GY; Y138 16GY; Y138-G 12WH; Y138-G 16WH; Y62 18DKBL
See also sheets: CH3_26, CH3_47
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.17. TRACTION AIDS EFFECTS WITH TRACTION CHAIN, P. 10 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090664 95885P 22JAN21 / CHAPTER 13 TRACTION AIDS EFFECTS W/TRACTION CHAIN / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/ SEALED ENG %(11500) A7 / Y138 12GY / TRACTION SANDER %(11514) D / Y62 18DKBL / Y12 18LTBL SEALED ENG GROUND %(0GND) CH3_47 Y138 16GY / TRACTION CHAIN (10266) TRACTION SW A %B138 16GY / TRACTION CHAIN %(11513) TRACTION SW 1 / Y138-G 12WH / Y138-G 16WH / SEALED ENG GROUND (0GND) CH3_47 / #B138A 16GY TRACTION CHAIN (10265) / FUSE B3-V (10304) CH3_26 / FUSE F22 (10302) CH3_94F / @B138A 16GY / Figure 509 / TRACTION AIDS EFFECTS WITH TRACTION CHAIN

13.18. TIRE WINCH EFFECTS, P. 11
Figure 510 TIRE WINCH EFFECTS

Components: TIRE WINCH FUSE (11520A); WINCH (11520)
Wires (circuit gauge+color): Y115 10LTGN; Y115-G 10WH; Y115A 10LTGN
See also sheets: CH3_47
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.18. TIRE WINCH EFFECTS, P. 11 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090664 95885P 22JAN21 / CHAPTER 13 / TIRE WINCH EFFECTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / Y115-G 10WH / BOOSTER PUMP HIGH OUTPUT +12 (11539) / SEALED ENG GROUND (0GND) CH3_47 / TIRE WINCH (11520) A / TIRE WINCH FUSE (11520A) Y115 Y115A A 10LTGN 10LTGN B / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 510 / TIRE WINCH EFFECTS

13.19. FIRE SUPPRESSION SYSTEM WITH JOMARR VTS12 AND PRESSURE SWITCH, P. 12
Figure 511 FIRE SUPPRESSION SYSTEM WITH JOMARR VTS12 AND PRESSURE SWITCH

Components: FUSE B9-C (10302); FUSE F42 (10304); SPLICE (1004); SPLICE (10337)
Wires (circuit gauge+color): A144-G 18WH; A144-GA 18WH; A144A 18GY; A144B 18GY; B144 18GY; B144-G 18WH; B144-GA 18WH; B144-GF 18WH; B144-GG 18WH; B144A 18GY; B144B 18GY; B144C 18GY; B144D 18GY; B144E 18GY; B144F 18GY; Y144 16GY; Y144A 16GY
See also sheets: CH3_13, CH3_31, CH3_41
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.19. FIRE SUPPRESSION SYSTEM WITH JOMARR VTS12 AND PRESSURE SWITCH, P. 12 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090664 95885P 22JAN21 / CHAPTER 13 FIRE SUPPRESSION SYSTEM W/JOMARR VTS12 W/PRESSURE SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FIRE SUPPRESSION SYSTEM *(11522) 1 / #B144 18GY / Y144 16GY / FUSE B9-C (10302) CH3_13 #B144B 18GY FIRE SUPPRESSION SYSTEM *(10383) / Y144A 16GY / 2 GROUND SPLICE (10337) CH3_41,95L / ELEC PANEL/ SEALED ENG *(11500) / B144A 18GY / FIRE SUPPRESSION SYSTEM *(10384) / B144E 18GY B144F 18GY / B144-GA 18WH B144-GG 18WH / FIRE SUPPRESSION SYSTEM *(10385) / B144C 18GY B144D 18GY / JOMARR FIRE SUPPRESSOR INDICATORS %(1099A) 3 / ELEC PANEL/ PLATFORM *(1702) 38 / B144-GF 18WH / *A144A 18GY / *A144B 18GY / GROUND SPLICE (1004) CH3_31,95A / *A144-G 18WH / *A144-GA 18WH / B144-G 18WH / @B144 18GY / FUSE F42 (10304) CH3_94K @B144B 18GY / Figure 511 / FIRE SUPPRESSION SYSTEM WITH JOMARR VTS12 AND PRESSURE SWITCH

13.20. FIRE SUPPRESSION WITH INDICATOR WITHOUT BUZZER ON 2017 ISB DIESEL ENGINE, P. 12
Figure 512 FIRE SUPPRESSION WITH INDICATOR WITHOUT BUZZER ON 2017 ISB DIESEL ENGINE

Components: FIRE EXTINGUISHER (1099C); FIRE EXTINGUISHER (1099D); IGN SPLICE (1014); INDICATOR (1099)
Wires (circuit gauge+color): A144-G 18WH; A144C 16GY; A144D 16GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.20. FIRE SUPPRESSION WITH INDICATOR WITHOUT BUZZER ON 2017 ISB DIESEL ENGINE, P. 12 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 25MAR21 / CHAPTER 13 FIRE SUPPRESSION W/INDICATOR N/BUZZER W/2017-ISB-DIESEL ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FIRE EXTINGUISHER (1099C) A / A144C 16GY / A144D 16GY / FIRE EXTINGUISHER (1099D) A / FIRE SUPPRESSION INDICATOR (1099) / IGN SPLICE (1014) CH3_28A / A144-G 18WH / GND SPLICE PACK#2 (1004) CH3_95A / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / Figure 512 / FIRE SUPPRESSION WITH INDICATOR WITHOUT BUZZER ON 2017 ISB DIESEL ENGINE

13.21. FIRE SUPPRESSION SYSTEM WITH 12 AND 13 WINDOW BUS, P. 13
Figure 513 FIRE SUPPRESSION SYSTEM WITH 12 AND 13 WINDOW BUS

Components: FIRE SUPPRESSION JOMARR (10513); REAR CAP (10405)
Wires (circuit gauge+color): E144 16GY; E144-G 16WH; E144A 16GY; E144B 16GY; E144D 16GY; E144E 16GY; E144F 16GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.21. FIRE SUPPRESSION SYSTEM WITH 12 AND 13 WINDOW BUS, P. 13 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090664 95885P 22JAN21 / CHAPTER 13 FIRE SUPPRESSION SYSTEM W/12 AND 13 WINDOW BUS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FIRE SUPPRESSION JOMARR (10513) / E144 16GY / L BODY / REAR CAP (10405) / E144A 16GY / E144B 16GY / E144D 16GY / E144E 16GY / E144F 16GY / E144-G 16WH / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 513 / FIRE SUPPRESSION SYSTEM WITH 12 AND 13 WINDOW BUS

13.22. PASSENGER PULL CORD SYSTEM, P. 14
Figure 514 PASSENGER PULL CORD SYSTEM

Components: PULL CORD (10835); PULL CORD (10836); R BODY (10700); SPLICE (10702)
Wires (circuit gauge+color): F141 16GY; F141 16LTGN; F141-G 16WH
See also sheets: CH3_53
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.22. PASSENGER PULL CORD SYSTEM, P. 14 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090664 95885P 22JAN21 / CHAPTER 13 PASSENGER PULL CORD SYSTEM / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PASSENGER PULL CORD (10836) / GROUND SPLICE (10702) CH3_53 / F141-G 16WH / PASSENGER PULL CORD (10835) / REAR CAP/ R BODY (10700) C12 / %F141 16LTGN / @F141 16GY / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / % W/12,13 WINDOW BUS @ W/9 WINDOW BUS / Figure 514 / PASSENGER PULL CORD SYSTEM

Figure 515 LIQUID SPRING SUSPENSION EFFECTS

Components: CONTROLLER (1604); ELEC PANEL (1702); FR CAP (10001); FUSE B12-M (10301); FUSE B6-D (10304); FUSE B9-D (10302); FUSE F105 (10306); FUSE F98 (10304); FUSE F99 (10304); GEN 4 TCM (7150); PLATFORM (1700); PLATFORM/ELEC PANEL (1703); PLATFORM/ENG (1701); SPRING (2502); SPRING J12 (2512); SPRING J26 (2526)
Wires (circuit gauge+color): A10LA 18WH; A10LB 18WH; A10LC 18WH; A10LS 18WH; A13LA 18PK; A13LB 18PK; A13LC 18PK; A14LA 18RD; A14LB 18RD; A14LC 18RD; A47A 18GY; A5BA 18LTGN; A5BB 18LTGN; A5BC 18LTGN; A70BC 16OR; A70LA 16OR; A70LB 16OR; A70LC 16OR; B10LA 18WH; B10LB 18WH; B13LS 18PK; B14LS 18RD; B70 16RD; K47A 18GY; M10LS 18WH; M13LS 18PK; M14LS 18RD; M47LS 18OR; M5LSB 18LTGN; M70LS 18OR
See also sheets: CH12_10, CH13_16, CH3_13, CH3_19, CH3_26, CH3_31, CH7_20
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.23. LIQUID SPRING SUSPENSION EFFECTS, P. 15 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090664 95885P 22JAN21 / CHAPTER 13 LIQUID SPRING SUSPENSION EFFECTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / @A70LC 16OR / TAIL D LIGHT SIGNAL / M70LS 18OR / M14LS 18RD M13LS 18PK M10LS 18WH / M5LSA 18YL M5LSB 18LTGN / FR/RR CHASSIS LIQUID SPRING (2502) CH13_16 / M47LS 18OR / FWD CHASSIS/ PLATFORM (1700) / A5AC 18YL A5BC 18LTGN / A14LC 18RD A13LC 18PK A10LC 18WH / D A / PLATFORM/ELEC PANEL (1703) A1 / @A70LA 16OR %A70BC 16OR @A70LB 16OR / A5AA 18YL A5BA 18LTGN / A5BB 18LTGN A5AB 18YL A14LB 18RD A13LB 18PK A10LB 18WH / ELEC PANEL/ FR CAP (10001) CH7_20 J2-10 WAY BODY CONTROLLER (1604) / LIQUID SPRING J26 (2526) / LIQUID SPRING J12 (2512) / PLATFORM/ ELEC PANEL (1702) 38 / A14LA 18RD / A13LA 18PK / A10LA 18WH / A10LS 18WH / A47A 18GY / &B10LB 18WH PLATFORM/ENG (1701) 64 / GROUND SPLICE PACK# 4 (1003) CH3_31,95A / K47A 18GY / FUSE B6-D (10304) CH3_26 / #B10LB 18WH &B10LA 18WH / #B10LA 18WH / #B13LS 18PK &B13LS 18PK / FUSE F98 (10304) CH3_94K FUSE B9-D (10302) CH3_13 FUSE B12-M (10301) CH3_19 FUSE F99 (10304) CH3_94K / #B14LS 18RD / B70 16RD / &B14LS 18RD / FUSE F105 (10306) CH3_94N / Figure 515 / LIQUID SPRING SUSPENSION EFFECTS

Figure 516 LIQUID SPRING SUSPENSION EFFECTS (CONT.)

Components: DOOR J36 (2536); ECU J16 (2516); ECU J17 (2517); FUSE HOLDER (2503); LIQUID SPRING (2502); PLATFORM (1700); PWR (2505); PWR BATT EYELET (2504); STEER SENSOR (2535)
Wires (circuit gauge+color): A14BA 8RD; A14BB 8RD; M10LS 18WH; M13LS 18PK; M14LS 18RD; M47LS 18OR; M5LSB 18LTGN; M61LSA 18GY; M61LSB 18GY; M61LSC 18GY; M70LS 18OR; R10LS 18WH; R13LS 18PK; R14LS 18RD; R47LS 18GY; R5LSB 18LTGN; R61SA 18GY; R61SB 18GY; R61SC 18GY; R70LS 18OR
See also sheets: CH13_15, CH13_17
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.24. LIQUID SPRING SUSPENSION EFFECTS (CONT.), P. 16 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 22JAN21 / CHAPTER 13 LIQUID SPRING SUSPENSION EFFECTS(CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / R10LS 18WH R47LS 18GY R70LS 18OR / LIQUID SPRING ECU J17 (2517) CH13_17 / REAR CHASSIS/ FWD CHASSIS LIQUID SPRING (2502) 3 / LIQUID SPRING STEER SENSOR (2535) / R14LS 18RD R5LSA 18YL R13LS 18PK R5LSB 18LTGN / R61SC 18GY / R61SA 18GY R61SB 18GY / FWD CHASSIS/ PLATFORM (1700) CH13_15 / M14LS 18RD M5LSA 18YL M13LS 18PK M5LSB 18LTGN / M10LS 18WH M47LS 18OR M70LS 18OR / LIQUID SPRING ECU J16 (2516) CH13_17 / M61LSA 18GY M61LSB 18GY M61LSC 18GY / LIQUID SPRING PWR BATT EYELET (2504) / LIQUID SPRING FUSE HOLDER (2503) A / A14BA 8RD / A14BB 8RD / LIQUID SPRING PWR (2505) / LIQUID SPRING DOOR J36 (2536) CH13_17 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 516 / LIQUID SPRING SUSPENSION EFFECTS (CONT.)

13.25. LIQUID SPRING SUSPENSION EFFECTS (CONT.), P. 17
Figure 517 LIQUID SPRING SUSPENSION EFFECTS (CONT.)

Components: DOOR J36 (2536); ECU J16 (2516); ECU J17 (2517); L HGT J21 (2521); R HGT J22 (2522); REAR CHASSIS (2502)
Wires (circuit gauge+color): R10LS 18WH; R10LSA 18WH; R10LSB 18WH; R13LS 18PK; R14LS 18RD; R47LS 18GY; R5LSB 18LTGN; R61DA 18GY; R61HA 18GY; R61HLA 18LTBL; R61HLB 18TN; R61HLC 18GY; R61HRA 18LTBL; R61HRC 18GY; R61SA 18GY; R61SB 18GY; R61SC 18GY; R70LS 18OR
See also sheets: CH13_16
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.25. LIQUID SPRING SUSPENSION EFFECTS (CONT.), P. 17 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 22JAN21 / CHAPTER 13 LIQUID SPRING SUSPENSION EFFECTS(CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / LIQUID SPRING DOOR J36 (2536) / R10LSB 18WH / LIQUID SPRING ECU J16 (2516) / LIQUID SPRING ECU J17 (2517) / 3 2 1 / D3 F2 C3 / R61HRC 18GY R61HRB 18YL R61HRA 18LTBL / LIQUID SPRING R HGT J22 (2522) / R61HA 18GY / 3 2 1 / LIQUID SPRING L HGT J21 (2521) / R61HLC 18GY R61HLB 18TN R61HLA 18LTBL / F3 B3 / R14LS 18RD R5LSA 18YL R13LS 18PK R5LSB 18LTGN / R10LS 18WH / R10LSA 18WH R61DA 18GY / FWD CHASSIS LIQUID SPRING/ REAR CHASSIS (2502) CH13_16 / FWD CHASSIS/ LIQUID SPRING REAR CHASSIS (2502) CH13_16 / R47LS 18GY R70LS 18OR / R61SA 18GY R61SB 18GY R61SC 18GY / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 517 / LIQUID SPRING SUSPENSION EFFECTS (CONT.)

Figure 518 LIQUID SPRING SUSPENSION EFFECTS (CONT.)

Components: DUMB J15 (2515); ECU J17 (2517); GROUND J30 (2530); L ISO J13 (2513); L RT J23 (2523); R ISO J14 (2514); R RT J24 (2524); SPRING J18 (2518); SPRING J19 (2519); SPRING J20 (2520); SPRING PWR (2505)
Wires (circuit gauge+color): R10G 8WH; R10GA 18WH; R10GB 18WH; R10GC 18WH; R10GD 18WH; R10GE 18WH; R10GND 8WH; R10PS 18GY; R14B 8RD; R14BAA 16RD; R14BAB 16RD; R14BAC 16RD; R14BBA 16RD; R14BBB 16RD; R14LSA 8RD; R14LSD 16RD; R14LSE 16RD; R14LSF 16RD; R14LSG 16RD; R14LSH 16RD; R61D 18LTGN; R61LI 18GY; R61LR 18BN; R61RI 18TN; R61RR 18LTGN
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.26. LIQUID SPRING SUSPENSION EFFECTS (CONT.), P. 18 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 22JAN21 / CHAPTER 13 LIQUID SPRING SUSPENSION EFFECTS(CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A B / B3 G3 / R10GB 18WH R61LI 18GY / LIQUID SPRING L ISO J13 (2513) / R10PS 18GY / A B / LIQUID SPRING R ISO J14 (2514) / R10GA 18WH R61RI 18TN / R10GE 18WH R61D 18LTGN / A B / LIQUID SPRING DUMB J15 (2515) / LIQUID SPRING J20 (2520) / R10G 8WH / R10GD 18WH R61LR 18BN / B A / LIQUID SPRING L RT J23 (2523) / R10GC 18WH R61RR 18LTGN / B A / LIQUID SPRING R RT J24 (2524) / R14B 8RD / R14BAA 16RD R14BAB 16RD R14BAC 16RD R14BBA 16RD R14BBB 16RD / LIQUID SPRING PWR (2505) / LIQUID SPRING ECU J17 (2517) / LIQUID SPRING J18 (2518) / R14LSA 8RD / LIQUID SPRING J19 (2519) / R10GND 8WH / Figure 518 / LIQUID SPRING SUSPENSION EFFECTS (CONT.)

13.27. FUEL HEATER SYSTEM WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 19
Figure 519 FUEL HEATER SYSTEM WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: DV2 RELAY (4016); FUSE (4106); FUSE STUD (4000A); HTR (6709); RELAY (4007); SPLICE (6704M); STUD (4113)
Wires (circuit gauge+color): K11C 10WH; K13FB 18PK; K13FC 18PK; K14A 10RD; K14FHB 10RD; K14FHC 10RD; K97-GFA 18WH
See also sheets: CH13_01, CH3_61
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.27. FUEL HEATER SYSTEM WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 19 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090664 95885P 22JAN21 / CHAPTER 13 FUEL HEATER SYSTEM W/2017/2021 ISB/B6.7 DIESEL ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 5 86 / 1 30 / K97-GFA 18WH / K14A 10RD / FUEL HTR FUSE (4106) B A / FUEL HTR RELAY (4007) 87A 3 / LOWER MEGA FUSE STUD (4000A) / K14FHB 10RD / K13FB 18PK / K13FC 18PK / AIR DRYER/ DV2 RELAY (4016) CH13_01 / K11C 10WH / K14FHC 10RD / LOWER GROUND STUD (4113) / FUEL HTR (6709) 2 / GROUND SPLICE (6704M) CH3_61 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 519 / FUEL HEATER SYSTEM WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

13.28. REGEN SWITCH EFFECTS WITH RELOCATED WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 20
Figure 520 REGEN SWITCH EFFECTS WITH RELOCATED WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: BODY CONTROLLER (1600); BODY CONTROLLER (1601); FUSE A3-N (1016); FUSE F23 (1011); REGEN SW (9266); SPLICE (1003B)
Wires (circuit gauge+color): A11-GE 18WH; A11-GL 18WH; A95A 18GY; A95B 18GY; A95C 18PK; A95CA 18PK
See also sheets: CH3_06, CH3_33
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.28. REGEN SWITCH EFFECTS WITH RELOCATED WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 20 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 22JAN21 / CHAPTER 13 REGEN SWITCH EFFECTS W/RELOCATED W/2017/2021 ISB/B6.7 DIESEL ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (1003B) CH3_33,95C / PARK REGEN B15 SW INPUT / F9 ZVR 2 / %A95A 18GY / %A95B 18GY / FUSE A3-N (1016) CH3_06 / %A11-GL 18WH / %A11-GE 18WH / J4 - BLUE BODY CONTROLLER (1601) / J3 - RED BODY CONTROLLER (1600) / REGEN SW (9266) / @A95C 18PK / A95CA 18PK / #A95C 18PK / FUSE F23 (1011) CH3_94C / Figure 520 / REGEN SWITCH EFFECTS WITH RELOCATED WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

13.29. MGM E-STROKE BRAKE MONITOR WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 21
Figure 521 MGM E-STROKE BRAKE MONITOR WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: INTERCONNECT (9537); SENSOR (9535); SENSOR (9536)
Wires (circuit gauge+color): R59AA 16RD; R59V 16LTBL; R59W 16LTGN; R59Y 16BK; R59Z 16BN
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.29. MGM E-STROKE BRAKE MONITOR WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 21 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090664 95885P 23JAN21 / CHAPTER 13 MGM E-STROKE BRAKE MONITOR W/2017/2021 ISB/B6.7 DIESEL ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / R59Z 16BN R59Y 16BK / R59AA 16RD / R59X 16VT R59W 16LTGN R59V 16LTBL / E-STROKE CHASSIS INTERCONNECT (9537) 6 / E - STROKE L REAR SENSOR (9536) / E - STROKE R REAR SENSOR (9535) / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 521 / MGM E-STROKE BRAKE MONITOR WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

13.30. MGM E-STROKE BRAKE MONITOR WITH 2017 ISB DIESEL ENGINE, P. 21A
Figure 522 MGM E-STROKE BRAKE MONITOR WITH 2017 ISB DIESEL ENGINE

Components: FORWARD CHASSIS (1700); FUSE F35 (1011); INTERCONNECT (9537); L FR SENSOR (1400); L REAR SENSOR (1402); PWR INPUT (1404); R FR SENSOR (1401); SENSOR (1403); SENSOR (9535); SENSOR (9536); STOP LT RELAY (1011)
Wires (circuit gauge+color): A59-G 18WH; A59AA 18GY; A59B 18GY; A59C 18GY; A59N 18GY; A59P 18GY; A59R 18GY; A59S 18GY; A59T 18GY; A59U 18GY; A59V 18GY; A59W 18GY; A59X 18GY; A59Y 18GY; A59Z 18GY; A70BD 14RD; R59AA 16RD; R59V 16LTBL; R59W 16LTGN; R59Y 16BK; R59Z 16BN
See also sheets: CH7_70
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.30. MGM E-STROKE BRAKE MONITOR WITH 2017 ISB DIESEL ENGINE, P. 21A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090664 95885P 25MAR21 / CHAPTER 13 / MGM E-STROKE BRAKE MONITOR W/2017-ISB-DIESEL ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PWR INPUT (1404) A / F B / A59Z 18GY A59Y 18GY L REAR SENSOR (1402) C / A59T 18GY A59S 18GY L FR SENSOR (1400) A / LRD SIG / LRD PWR / S GND / RRD SIG / RRD PWR / S GND / A59-G 18WH / A59AA 18GY / PLATFORM/ FORWARD CHASSIS (1700) 50 / R REAR SENSOR (1403) C / A59X 18GY / A59W 18GY A59V 18GY R FR SENSOR (1401) C C / A59U 18GY / A59N 18GY / A59P 18GY A59R 18GY NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / R59Z 16BN R59Y 16BK / R59AA 16RD / R59X 16VT R59W 16LTGN R59V 16LTBL / STOP LT RELAY (1011) CH7_70 E-STROKE CHASSIS INTERCONNECT (9537) 6 / E - STROKE R FR SENSOR / E - STROKE L REAR SENSOR (9536) / E - STROKE R REAR SENSOR (9535) / GND SPLICE PACK#2 (1004) CH3_95A / RS SIG / LS PWR / S GND / BRAKE LT / LS SIG / E - STROKE MODULE / RS PWR / SYSTEM PWR / WARNING LT / J1708+ J1708- SYSTEM GROUND / S GND / A59C 18GY / E - STROKE L FR SENSOR / A70BD 14RD / FUSE F35 (1011) CH3_94B / A59B 18GY / Figure 522 / MGM E-STROKE BRAKE MONITOR WITH 2017 ISB DIESEL ENGINE

13.31. AIR BRAKE WITH ABS6, GEN4 BC AND ATC 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 22
Figure 523 AIR BRAKE WITH ABS6, GEN4 BC AND ATC 2017 ISB / 2021 B6.7 DIESEL ENGINE,

Components: FUSE A3-R (1016); FUSE F25 (1011); K BAUD (1651); PLATFORM (1700/1700)
Wires (circuit gauge+color): A94A 12GY; A94BJ 18GY; K14X 10RD; K94B 10GY; M94-G 12WH; M94BCS 18GY; M94BJ 18GY; M94BP 12GY; R94A 16DKBL
See also sheets: CH3_05, CH3_92
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.31. AIR BRAKE WITH ABS6, GEN4 BC AND ATC 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 22 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / L FR WHEEL SPEED SENSOR %(9508) / FWD CHASSIS/PLATFORM %(1700/1700) 35 / M94BCS 18GY / #A94BJ 18GY @A94BJ 18GY / M94R(+) 16DKBL M94R(-) 16YL / OUTPUT 7 / TRACTION SOLENOID 13 GROUND / IGN 9 / OUTPUT 8 / BENDIX AIR ABS-6 CONN %(9540) / GROUND 15 / 4 INPUT / M94BJ 18GY / M94L(+) 16GY M94L(-) 16GY / R94A 16DKBL / R FR WHEEL SPEED SENSOR %(9507) / M94-G 12WH / AIR AUTO TRACTION CONTROL %(9522) / W/AUTOMATIC TRACTION CONTROL / BRAKE SYSTEM FUSE %(4041) B A 30A / FWD CHASSIS/ PLATFORM/ PLATFORM ENG (1700/1700) %(1701/1701) 11 11 A94A K94B 12GY 10GY / M94BP 12GY / BATT 14 / ABS WL / TRACTION SOLENOID SOURCE / FUSE F25 (1011) CH3_94C FUSE A3-R (1016) CH3_05 / LOWER DASH GROUND STUD (2GG) / K14X 10RD / UPPER MEGA FUSE STUD %(4000D) / A3(+) 18DKBL / J1939(+) 5 / M3C(+) 18DKBL / DIAGNOSTIC CONN 500K BAUD (1651) CH3_92 / A3(-) 18GY / J1939(-) 1 / M3C(-) 18GY / Figure 523 / AIR BRAKE WITH ABS6, GEN4 BC AND ATC 2017 ISB / 2021 B6.7 DIESEL ENGINE,

13.32. AIR BRAKE WITH ABS6, GEN4 BC AND ATC 2017 ISB / 2021 B6.7 DIESEL
Figure 524 AIR BRAKE WITH ABS6, GEN4 BC AND ATC 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

Components: CONN (9539); INTERCONNECT (9541F / 9541M); L REAR MODULATOR (9518); MODULATOR (9520); MODULATOR (9521); R REAR MODULATOR (9519); SPEED SENSOR (9501); SPEED SENSOR (9503)
Wires (circuit gauge+color): M94BA 16BK; M94BB 16RD; M94BC 16BN; M94BE 16LTGN; M94BF 16LTBL; R94BA 16BK; R94BB 16RD; R94BC 16BN; R94BE 16LTGN; R94BF 16LTBL; R94M 16BK; R94N 16RD; R94P 16BN; R94S 16LTGN; R94T 16LTBL
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.32. AIR BRAKE WITH ABS6, GEN4 BC AND ATC 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 23 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090664 NO. RELEASE NO. 95885P 23JAN21 / CHAPTER 13 AIR BRAKE W/ABS6 W/GEN4 BC W/AUTOMATIC TRACTION CONTROL W/2017/2021 ISB/B6.7 DIESEL ENGING(CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B A / R94M 16BK R94P 16BN / R94R 16VT R94T 16LTBL / M94BD 16VT M94BF 16LTBL / R94DR+ 16YL R94DR- 16DKBL / R94N 16RD / R94BD 16VT R94BF 16LTBL / B A / B A / BENDIX AIR ABS R FR AIR MODULATOR (9521) / M94BB 16RD / REAR CHASSIS INTERCONNECT (9541F / 9541M) B / BENDIX AIR L REAR WHEEL SPEED SENSOR (9501) / R94BE 16LTGN / M94BA 16BK M94BC 16BN / BENDIX AIR ABS L REAR MODULATOR (9518) / R94BB 16RD / R94S 16LTGN / BENDIX AIR ABS-6 CONN (9539) / R94BA 16BK R94BC 16BN / M94BE 16LTGN / B A / R94DL- 16OR / BENDIX AIR ABS R REAR MODULATOR (9519) / BENDIX AIR R REAR WHEEL SPEED SENSOR (9503) / R94DL+ 16GY / BENDIX AIR ABS L FR AIR MODULATOR (9520) / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 524 / AIR BRAKE WITH ABS6, GEN4 BC AND ATC 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

13.33. AIR BRAKE WITH ABS6, GEN4 BC AND ATC 2017 ISB / 2021 B6.7 DIESEL
Figure 525 AIR BRAKE WITH ABS6, GEN4 BC AND ATC 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

Components: BENDIX AIR ABS (9512); CONTROL (9522); L REAR MODULATOR (9518); R REAR MODULATOR (9519); SPEED SENSOR (9501); SPEED SENSOR (9503)
Wires (circuit gauge+color): R94A 16DKBL; R94M 16BK; R94N 16RD; R94P 16BN; R94S 16LTGN; R94T 16LTBL
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.33. AIR BRAKE WITH ABS6, GEN4 BC AND ATC 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 24 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090664 NO. RELEASE NO. 95885P 23JAN21 / CHAPTER 13 AIR BRAKE W/ABS6 W/GEN4 BC W/AUTOMATIC TRACTION CONTROL W/2017/2021 ISB/B6.7 DIESEL ENGINE (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / C1 EXHAUST HOLD B1 / B A / R94M 16BK R94P 16BN / R94R 16VT R94T 16LTBL / SOURCE F1 / R94RR- 16DKBL R94RR+ 16YL / EXHAUST D1 / INPUT E3 / R94N 16RD / OUTPUT E2 / TRACTION SOLENOID D3 GROUND / HOLD E1 / BENDIX AIR L REAR WHEEL SPEED SENSOR (9501) / BENDIX AIR ABS L REAR MODULATOR (9518) / R94A 16DKBL / R94S 16LTGN / BENDIX AIR ABS (9512) / B A / R94LR+ 16GY / BENDIX AIR ABS R REAR MODULATOR (9519) / SOURCE A1 / TRACTION D2 SOLENOID SOURCE / R94B 16YL / INPUT F3 / OUTPUT F2 / BENDIX AIR R REAR WHEEL SPEED SENSOR (9503) / R94LR- 16OR / AIR AUTO TRACTION CONTROL (9522) / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 525 / AIR BRAKE WITH ABS6, GEN4 BC AND ATC 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

13.34. AIR BRAKE WITH ABS6 AND L MEGA BRACKET ON 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 25
Figure 526 AIR BRAKE WITH ABS6 AND L MEGA BRACKET ON 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: ABS 8 CONN X1 (9543); AIR ABS-6 (9538); CONTROLLER (1606); ELEC PANEL (1703); INTERCONNECT (9530F); PLATFORM (1700); RESISTOR (7801M)
See also sheets: CH3_70, CH3_73, CH3_74, CH3_76
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.34. AIR BRAKE WITH ABS6 AND L MEGA BRACKET ON 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 25 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / BENDIX AIR ABS-6 (9538) / 2 J1939(-) / J1939(+) 6 / FWD CHASSIS/ PLATFORM (1700) 30 / J1939 TERMINATING RESISTOR (7801M) / M5(+) 18YL / OHMS 120 C / A5S(+) 18YL A5S(-) 18GN A5P(+) 18YL A5P(-) 18GN A5U(+) 18YL A5U(-) 18GN A5NE(+) 18YL A5NE(-) 18GN / M5(-) 18GN / M5A(+) 18YL / M5A(-) 18GN / %M5E(+) 18YL %M5E(-) 18GN / @A5E(+) @A5E(-) 18YL 18GN / J1939 INTERCONNECT (9530F) / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / @ N/GEN 4 BODY CONTROLLER % W/GEN 4 BODY CONTROLLER / Figure 526 / AIR BRAKE WITH ABS6 AND L MEGA BRACKET ON 2017 ISB / 2021 B6.7 DIESEL ENGINE

13.35. WABCO AIR ABS 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 26
Figure 527 WABCO AIR ABS 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: FUSE A3-R (1016); FUSE F25 (1011); K BAUD (1651); PLATFORM (1700)
Wires (circuit gauge+color): A94BJ 10GY; A94BK 12GY; K14W 10RD; K94B 10GY; M94-GB 14GY; M94-GC 10GY; M94-GW 14GY; M94-GY 10GY; M94B 12GY; M94BH 14GY; M94BJ 10GY; M94BP 14GY
See also sheets: CH3_05, CH3_92
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.35. WABCO AIR ABS 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 26 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090664 95885P 23JAN21 / CHAPTER 13 WABCO AIR ABS W/2017/2021 ISB/B6.7 DIESEL ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / WABCO L FR WHEEL SPEED SENSOR %(4909) / FWD CHASSIS/ PLATFORM (1700) 11 / @A94BJ 10GY / (MBKRF) 18BK (MBNRF) 18BN / WABCO AIR ABS CONN X2 (BLACK) %(4907) / (MBKLF) 18BK (MBNLF) 18BN / WABCO R FR WHEEL SPEED SENSOR %(4910) / M94-GB 14GY M94-GW 14GY / M94B 12GY / M94BP 14GY / WSS SA L (-) / WSS SA L (+) / WSS SA R (-) / WSS SA R (+) / FUSE A3-R (1016) CH3_05 FUSE F25 (1011) CH3_94C / LOWER DASH GROUND STUD (2GG) / WABCO AIR ABS CONN X1 (GRAY) %(4906) / M94BH 14GY / M94BJ 10GY / M94-GC 10GY M94-GY 10GY / WABCO AIR ABS INTERCONNECT %(4917F/4917M) 1 / K14W 10RD / BRAKE SYSTEM FUSE %(4041) B A 20A / K94B 10GY / UPPER MEGA FUSE STUD %(4000D) / M3C(+) 18DKBL / A3C(+) 18DKBL / DIAGNOSTIC CONN 500K BAUD (1651) CH3_92 / A3C(-) 18GY / M3C(-) 18GY / A94BK 12GY / #A94BJ 10GY / NOTE: SA = STEER AXLE / Figure 527 / WABCO AIR ABS 2017 ISB / 2021 B6.7 DIESEL ENGINE

13.36. WABCO AIR ABS 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 27
Figure 528 WABCO AIR ABS 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

Components: CONN X2 (4907); CONN X3 (4908); L REAR MODULATOR (4915); MODULATOR (4911); MODULATOR (4912); R REAR MODULATOR (4916); SPEED SENSOR (4913); SPEED SENSOR (4914)
Wires (circuit gauge+color): M94BA 14BK; M94BB 14RD; M94BC 14BN; M94BE 14LTGN; M94BF 14LTBL; R94M 14BK; R94N 14RD; R94P 14BN; R94S 14LTGN; R94T 14LTBL
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.36. WABCO AIR ABS 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 27 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 2 1 / R94M 14BK R94P 14BN / R94R 14VT R94T 14LTBL / [RBKRR] 18BK [RBNRR] 18BN / R94N 14RD / M94BD 14VT M94BF 14LTBL / 2 1 / 2 1 / WABCO AIR ABS R FR AIR MODULATOR (4912) / WABCO AIR L REAR WHEEL SPEED SENSOR (4913) / M94BE 14LTGN / WABCO AIR ABS L REAR MODULATOR (4915) / M94BB 14RD / R94S 14LTGN / M94BA 14BK M94BC 14BN / WABCO AIR ABS CONN X2 (4907)(BLACK) / 2 1 / [RBNLR] 18BN / WABCO AIR ABS R REAR MODULATOR (4916) / WABCO AIR R REAR WHEEL SPEED SENSOR (4914) / [RBKLR] 18BK / WABCO AIR ABS L FR AIR MODULATOR (4911) / WSS DA L (+) / WSS DA L (-) / WSS DA R (+) / WSS DA R (-) / DA L CMD / DA LT REL (AV) / DA LT HLD (EV) / DA R CMD / DA RT REL (AV) / DA RT HLD (EV) / PMVSA LEFLMN / PMV SA L REL (AV) / PMV SA L HLD (EV) / SA R / SA R / SA R / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 528 / WABCO AIR ABS 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

13.37. WABCO AIR ABS WITH L MEGA BRACKET WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 28
Figure 529 WABCO AIR ABS WITH L MEGA BRACKET WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: ABS 8 CONN X1 (9543); CONN X1 (4906); CONTROLLER (1606); ELEC PANEL (1703); INTERCONNECT (9530F); PLATFORM (1700); RESISTOR (7801M)
See also sheets: CH3_70, CH3_73, CH3_74, CH3_76
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.37. WABCO AIR ABS WITH L MEGA BRACKET WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 28 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / WABCO AIR ABS CONN X1 (4906) / 6 J1939(-) / J1939(+) 7 / FWD CHASSIS/ PLATFORM (1700) 30 / J1939 TERMINATING RESISTOR (7801M) / M5(+) 18YL / OHMS 120 C / A5S(+) 18YL A5S(-) 18GN A5P(+) 18YL A5P(-) 18GN A5U(+) 18YL A5U(-) 18GN A5NE(+) 18YL A5NE(-) 18GN / M5(-) 18GN / M5A(+) 18YL / M5A(-) 18GN / %M5E(+) 18YL %M5E(-) 18GN / @A5E(+) @A5E(-) 18YL 18GN / J1939 INTERCONNECT (9530F) / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / @ N/GEN 4 BODY CONTROLLER % W/GEN 4 BODY CONTROLLER / Figure 529 / WABCO AIR ABS WITH L MEGA BRACKET WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

13.38. BENDIX ABS-8 WITH EC 80, GEN 4 BC WITHOUT ATC WITH 2017 ISB / 2021
Figure 530 BENDIX ABS-8 WITH EC 80, GEN 4 BC WITHOUT ATC WITH 2017 ISB / 2021 B6.7 DIESEL

Components: CONN X2 (9544); PLATFORM (1700/1700)
Wires (circuit gauge+color): A94R 16BK; A94S 16RD; A94T 16BN; A94V 16LTGN; A94W 16LTBL; M94BA 16GY; M94BB 16GY; M94BC 16GY; M94BD 16GY; M94BE 16GY; M94BF 16GY; M94BH 16GY; M94BJ 16GY; M94BK 16GY; M94BL 16GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.38. BENDIX ABS-8 WITH EC 80, GEN 4 BC WITHOUT ATC WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 29 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / CHAPTER 13 BENDIX ABS-8 W/EC 80 W/GEN 4 BC N/AUTOMATIC TRACTION CONTROLW/2017/2021 ISB/B6.7 DIESEL ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / M94BE 16GY M94BF 16GY / BENDIX L FR AIR MODULATOR @(9522) A / M94BH 16GY / FWD CHASSIS/ PLATFORM (1700/1700) 33 / M94BJ 16GY M94BK 16GY / M94BL 16GY / BENDIX R FR MODULATOR @(9523) A / M94BC 16GY / BENDIX R FR WHEEL SPEED SENSOR @(9512) 2 / M94BD 16GY / M94BA 16GY / M94BB 16GY / BENDIX FR WHEEL SPEED SENSOR AIR @(9509) 1 / A94U 16VT A94V 16LTGN / 3 EXHAUST / 1 SOURCE / A94W 16LTBL / A94T 16BN / A94R 16BK A94S 16RD / 7 HOLD / 4 SOURCE / 6 EXHAUST / BENDIX AIR ABS-8 CONN X2 (9544) / A94M(-) 16YL A94M(+) 16DKBL / 14 OUTPUT / A94N(+) 16GY A94N(-) 16OR / INPUT 11 / 5 INPUT / 8 OUTPUT / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / @ N/AUTOMATIC TRACTION CONTROL / Figure 530 / BENDIX ABS-8 WITH EC 80, GEN 4 BC WITHOUT ATC WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

13.39. BENDIX ABS-8 WITH EC 80, GEN 4 BC AND ATC WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 30
Figure 531 BENDIX ABS-8 WITH EC 80, GEN 4 BC AND ATC WITH 2017 ISB / 2021 B6.7 DIESEL

Components: CONN X1 (9543); CONN X2 (9544); CONTROL (9523); FUSE (4041); FUSE A3-R (1016); FUSE F25 (1011); FUSE STUD (4000D); FWD CHASSIS (1700/1700); FWD/REAR CHASSIS (9513M/9513F); MODULATOR (9520); MODULATOR (9521); PLATFORM/ENG (1701/1701); SENSOR (9502); SENSOR (9504)
Wires (circuit gauge+color): A94-G 12WH; A94-GA 12WH; A94-GB 12WH; A94-GC 12WH; A94-GD 12WH; A94A 12GY; A94AA 18DKBL; A94D 16BK; A94E 16RD; A94F 16BN; A94K 16LTGN; A94L 16LTBL; A94Y 18GY; K14X 10RD; K94B 10GY; M152A 16GY; M152B 16GY; M94A 16GY; M94B 16GY; M94C 16GY; M94D 16GY; M94E 16GY; M94F 16GY; M94H 16GY; M94J 16GY; M94K 16GY; M94L 16GY; R152A 16GY; R152B 16GY; R94A 16GY; R94B 16GY; R94C 16GY; R94D 16GY; R94E 16GY; R94F 16GY; R94H 16GY; R94J 16GY; R94K 16GY; R94L 16GY
See also sheets: CH3_05, CH3_93, CH3_95
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.39. BENDIX ABS-8 WITH EC 80, GEN 4 BC AND ATC WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 30 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B BENDIX AIR ABS R A REAR MODULATOR (9521) / @R94J 16GY @R94L 16GY / FWD/REAR CHASSIS (9513M/9513F) 1 / B BENDIX AIR ABS L A REAR MODULATOR (9520) / BENDIX AIR R REAR WHEELSPEED SENSOR (9504) / BENDIX AIR L REAR WHEEL SPEED SENSOR (9502) / @R94K 16GY / @R94E 16GY @R94H 16GY / @R94B 16GY @R94F 16GY / @R94A 16GY / @R94C 16GY @R94D 16GY / @M94E 16GY @M94H 16GY / PLATFORM/ FWD CHASSIS (1700/1700) 39 / @M94B 16GY @M94F 16GY / @M94K 16GY / @M94A 16GY / @M94C 16GY @M94D 16GY / @M94J 16GY @M94L 16GY / 18 OUTPUT / EXHAUST 13 / BENDIX AIR ABS-8 CONN X2 (9544) / SOURCE 9 / HOLD 16 / INPUT 15 / EXHAUST 17 / SOURCE 12 / A94B(+) 16GY A94B(-) 16OR A94E 16RD / A94D 16BK A94F 16BN / A94H 16VT A94L 16LTBL / OUTPUT 11 / 10 INPUT / TRACTION SOLENOID 5 SOURCE TRACTION 4 SOLENOID GROUND / HOLD 10 / A94K 16LTGN / A94C(+) 16YL A94C(-) 16DKBL / A94AA 18DKBL A94AB 18YL / BENDIX AIR ABS-8 CONN X1 (9543) / AIR AUTO TRACTION CONTROL (9523) / BATT 16 / A94A 12GY *A94Y 18GY #A94Y 18GY A94-GC 12WH A94-GA 12WH W/WINGMAN #A94-G 12WH / K14X 10RD / UPPER MEGA FUSE STUD (4000D) / GROUND 1 / A94-GD 12WH A94-GB 12WH / Figure 531 / BENDIX ABS-8 WITH EC 80, GEN 4 BC AND ATC WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

13.40. BENDIX ABS-8 WITH EC 80,GEN 4 BC AND STABILITY CONTROL WITH 2017
Figure 532 BENDIX ABS-8 WITH EC 80,GEN 4 BC AND STABILITY CONTROL WITH 2017 ISB / 2021

Components: ATR 6 LSM (9513); CHASSIS (1700/1700); CONN X3 (9545); CONN X4 (9546); STEERING ANGLE SENSOR (9547); YAW RATE SANSOR (9514)
Wires (circuit gauge+color): A152B 18GN; A152C 18BK; A152D 18RD; A152E 18DKBL; A152J 18GN; A152K 18BK; A152L 18RD; A152N 18GN; A152P 18BK; A152R 18RD; M152C 18RD; M152D 18BK; M152G 16GY; M152H 16GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.40. BENDIX ABS-8 WITH EC 80,GEN 4 BC AND STABILITY CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 31 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / CHAPTER 13 BENDIX ABS-8 W/EC 80 W/GEN 4 BC W/STABILITY CONTROL W/2017/2021 ISB/B6.7 DIESEL ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / STEERING ANGLE SENSOR (9547) / A152C 18BK A152D 18RD / A152P 18BK / %M152D 18BK %M152C 18RD / A152R 18RD / A152M 18YL / A152A 18YL / %M152(+) 18YL / A152N 18GN / A152B 18GN / %M152(-) 18GN / A152H 18YL / A152J 18GN / A152L 18RD / A152K 18BK / PLATFORM/FWD CHASSIS (1700/1700) 73 / YAW RATE SANSOR (9514) / BENDIX AIR CONN X4 (9546) / A152E 18DKBL / A152F 18YL / %M152H 16GY / %M152G 16GY / BENDIX AIR ABS-8 CONN X3 (9545) / ATR 6 LSM (9513) / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / % W/STABILITY CONTROL / Figure 532 / BENDIX ABS-8 WITH EC 80,GEN 4 BC AND STABILITY CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

13.41. BENDIX ABS-8 WITH EC 80, GEN 4 BC, FUSION & WINGMAN WITH 2017 ISB /
Figure 533 BENDIX ABS-8 WITH EC 80, GEN 4 BC, FUSION & WINGMAN WITH 2017 ISB / 2021 B6.7

Components: CONN XI (9543); CONTROLLER (1606); ELEC PANEL (1702/1702); FR CAP (10001); FUSE A3-B (1016); FUSE F16 (1011); PLATFORM (1700/1700); RESISTOR (1657); RESISTOR (7801M); STUD (4037Z); STUD (4037ZB); WINGMAN (8903)
Wires (circuit gauge+color): A13E 18PK; A13EE 18PK; A13F 18PK; A152Y 18RD; A67-G 18WH; A67-GA 18WH; A94-GB 12WH; A94-GD 12WH; M13AA 18PK; M67-GA 18WH
See also sheets: CH13_55, CH3_06, CH3_70, CH3_93, CH3_95
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.41. BENDIX ABS-8 WITH EC 80, GEN 4 BC, FUSION & WINGMAN WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 32 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / CHAPTER 13 BENDIX ABS-8 W/EC 80 W/GEN 4 BC W/FUSION AND WINGMAN W/2017/2021 ISB/B6.7 DIESEL ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FWD CHASSIS/ PLATFORM (1700/1700) 30 @M5A(+) 18YL / J1939 TERMINATING RESISTOR (1657) / J1939(+) 1 / @M5B(+) 18YL / @M5C(+) 18YL / J1939(-) 6 / @M5C(-) 18GN / 2 J1939(+) / #M5UE(+) 18YL #M5UE(-) 18GN W/CONNECTIONS FOR VEHICLES W/0508108 - 43 MTA FUSE BLOCK @M13AA 18PK / BENDIX WINGMAN (8903) / @M5B(-) 18GN / 120 OHMS / A5U(+) 18YL A5U(-) 18GN A5S(+) 18YL / @M5A(-) 18GN / J1939(-) 7 / BATT 8 / @M67-GA 18WH / GROUND 5 / ELEC PANEL/ FR CAP (10001) CH13_55,55A / @A67-G 18WH #A67-GA 18WH / FUSE A3-B (1016) CH3_06 FUSE F16 (1011) CH3_94B / GROUND STUD (4037ZB) CH3_93 # W/BENDIX FUSION @ W/BENDIX WINGMAN % W/BENDIX AIR EC 80 ONLY / A94-GB 12WH A94-GD 12WH GROUND STUD (4037Z) CH3_95 / J1939 TERMINATING RESISTOR (7801M) / OHMS 120 / %M5A(+) 18YL / %M5A(-) 18GN / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / W/CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK / W/CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK / Figure 533 / BENDIX ABS-8 WITH EC 80, GEN 4 BC, FUSION & WINGMAN WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

13.42. HYDRAULIC BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 33
Figure 534 HYDRAULIC BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: FUSE A3-R (1016); FUSE F25 (1011); K BAUD (1651)
Wires (circuit gauge+color): A90E 18GY; M44C 18GY; M44D 18GY; M90-G 10WH; M90-GA 12WH; M90C 18GY; M90D 16GY; M90D-G 16WH; M90E 18GY; M94-GB 12WH; M94-GE 16WH; R44C 18RD; R44D 18BN; R90D-G 18BN; R94-GE 18GN
See also sheets: CH3_05, CH3_92
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.42. HYDRAULIC BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 33 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090664 95885P 23JAN21 / CHAPTER 13 HYDRAULIC BRAKE W/2017/2021 ISB/B6.7 DIESEL ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / M94-GB 12WH M44D 18GY M90C 18GY / SOLENOID VALVE 19 GROUND PARK BRAKE 7 TRAVEL SENSOR / SAHR SENSOR &(9777) B GROUND / A INGITION / R94-GE 18GN R44D 18BN M90D R90D 16GY 18YL FORWARD CHASSIS/PLATFORM &(1700) 35 / R FR WHEEL 26 SPEED SENSOR R FR WHEEL 31 SPEED SENSOR / SAHR CUT OFF SOLENOID &(9778) / L REAR WHEEL 28 SPEED SENSOR L REAR WHEEL 23 SPEED SENSOR / A3(-) 18GY A3(+) 18DKBL REAR CHASSIS INTERCONNECT &(9513M/9513F) 2 [RBKLR] 18BK / R44C 18RD / IGN 1 / PARK BRAKE 5 VALVE 2 / R REAR WHEEL 22 SPEED SENSOR R REAR WHEEL 27 SPEED SENSOR / LOWER DASH GROUND STUD &(2GG) M90D-G 16WH / C OUTPUT / M44C 18GY M90-G 10WH / M94LR+ 18GY M94LR- 18OR / M94-GE 16WH / M94RR+ 18DKBL M94RR- 18YL / PUMP MOTOR 2 18 GROUND / DIAGNOSTIC CONN 500K BAUD (1651) CH3_92 / M3C- 18GY M3C+ 18DKBL / M90-GA 12WH / R90D-G 18BN / FUSE F25 (1011) CH3_94C FUSE A3-R (1016) CH3_05 / [RBNLR] 18BN / HYD L REAR WHEEL SPEED SENSOR &(9514) / [RBKRR] 18BK [RBNRR] 18BN / HYD L REAR WHEEL SPEED SENSOR &(9515) / FWD CHASSIS/PLATFORM &(1700) 40 / R FR WHEEL 30 SPEED SENSOR R FR WHEEL 25 SPEED SENSOR / [M94R+] 18BK [M94R-] 18BK / [M94L+] 18BK [M94L]- 18BN / L FR WHEEL 24 SPEED SENSOR / HYD BRK R FR WHEEL SPEED SENSOR &(9516) / HYD BRK L FR WHEEL SPEED SENSOR &(9517) / #A90E 18GY / Figure 534 / HYDRAULIC BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

13.43. HYDRAULIC BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 34
Figure 535 HYDRAULIC BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

Components: BODY CONTROLLER (1602); CONTROLLER (1600); ECU PWR FUSE (4006); FUSE (4041); FUSE A6-E (1014); FUSE F3 (1011); FUSE HOLDER (4041); PUMP MOTOR-1 (9510); SPLICE (1003A); SPLICE (6704M); ZVR (1005)
Wires (circuit gauge+color): A44AA 18GY; A44CC 18GY; A90 12GY; A90B 18GY; A90B-G 18WH; A90C 18GY; A90C-G 18WH; A90D-G 18WH; A90F 18GY; A90H 18GY; A94L 12GY; A9K 18GY; K14C 12RD; K14D 10RD; K90 10GY; K90-G 18GY; K90B 18GY; K90C 18GY; K90H 18GY; K94L 12GY; M14H 10RD; M44A 18GY; M44B 18GY; M90 12GY; M90A 12GY; M90A-G 12WH; M90AA-G 12WH; M90B 18GY; M90B-G 18WH; M90E-G 18WH; M90F 18GY; M90H 18GY; M94L 12GY
See also sheets: CH3_01, CH3_32, CH3_50, CH3_58, CH3_61, CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.43. HYDRAULIC BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 34 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. FULL PWR BRAKE CONTROLLER *(9511) / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / CHAPTER 13 HYDRAULIC BRAKE W/2017/2021 ISB/B6.7 DIESEL ENGINE (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / M90H 18GY / K90B 18GY K90C 18GY K90H 18GY @K90-G 18GY J5-TAN BODY CONTROLLER (1602) / PUMP MOTOR 1 SUPPLY 2 / PUMP MOTOR 1 1 GROUND / A90F 18GY / A90B 18GY FUSE A6-E #A90C (1014) 18GY CH3_01 A90H 18GY / M90A 12GY / BRAKE SW 10 / PUMP MOTOR 2 16 SUPPLY / SUPPLY VALVE *(9506) / BRAKE LT 3 SIGNAL PARK VALVE 1 4 / A94L 12GY / M94L 12GY / LOW BRAKE 9 FLUID / BRAKE SW E14 INPUT / M90F 18GY M44B 18GY / M90AA-G 12WH / FWD CHASSIS/ PLATFORM *(1700/1700) 57 M44A 18GY 42 M90B-G 18WH / M90 12GY / M90B 18GY / SOLENOID 17 VALVE SUPPLY / HYDRUALIC PUMP MOTOR-1 (9510) / HYD BRAKE SW *(4036) / LOW HYD FLUID LEVEL *(4034) / HYD BRAKE FUSE HOLDER (4041) B A 30A / M14H 10RD / BATT EYELET (1BAT) / 2 M90E-G 18WH M90A-G 12WH / 1 2 / 2 1 / BODY GROUND STUD (2GA) CH3_50 / UPPER MEGA FUSE STUD *(4000B) / B MANUAL HYD PARK BRAKE SW *(9267) / J3-RED BODY CONTROLLER (1600) / %A44CC 18GY / A9K 18GY / ZVR (1005) CH3_58,95M / GROUND SPLICE (6704M) CH3_61 / GROUND 6 / 1 HYD PARK BRAKE SW *(1105M) / &A90C 18GY / FUSE F3 (1011) CH3_94 / PARK BRAKE SW SIGNAL / Figure 535 / HYDRAULIC BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

13.44. HYDRAULIC BRAKE WITH AIR COMPRESSOR V8 AND L MEGA BRACKET
Figure 536 HYDRAULIC BRAKE WITH AIR COMPRESSOR V8 AND L MEGA BRACKET WITH 2017 ISB

Components: ABS 8 CONN X1 (9543); ABS-8 CONN X1 (9543); CONTROLLER (1606); ELEC PANEL (1703); FUSE A3-R (1016); FUSE F25 (1011); PLATFORM/ENG (1701); RESISTOR (7801M); SPEED SENSOR (9514); SPEED SENSOR (9515)
Wires (circuit gauge+color): A90 10GY; A90E 18GY; A94L 10GY; M90-G 10WH; M90A 10GY; M90C 18PK; M94L 10GY
See also sheets: CH13_37, CH3_05, CH3_70, CH3_73, CH3_74, CH3_76
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.44. HYDRAULIC BRAKE WITH AIR COMPRESSOR V8 AND L MEGA BRACKET WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 35 / CHAPTER 13 HYDRAULIC BRAKE W/AIR COMPRESSOR V8 W/L MEGA BRACKET W/2017/2021 ISB/B6.7 DIESEL ENGINE HYD ABS MODULE CONN *(9511K) 45 INPUT / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 46 OUTPUT / [M94L+] 18BK [M94L-] 18BN / 33 OUTPUT 47 GROUND / [M94R+] 18BK [M94R-] 18BN M90-G 10WH / 34 INPUT / HYD BRAKE R FR WHEEL SPEED SENSOR *(9516A) 1 / LOWER DASH GROUND STUD (2GG) / M94LR- 18TN M94LR+ 18TN / OUTPUT 37 / M94RR- 18TN M94RR+ 18TN / 43 INPUT / 36 INPUT / FWD/REAR CHASSIS *(9513M/F) 4 / HYD R REAR WHEEL SPEED SENSOR (9515) / [RBNRR] 18BN [RBKRR] 18BK / [RBNLR] 18BN [RBKLR] 18BK / HYD L REAR WHEEL SPEED SENSOR (9514) / FWD CHASSIS/ PLATFORM *(1700) 12 / INPBRAKE SYSTEM 1 PWR HYD 32 BRAKE VALVE / M90A 10GY M94L 10GY / M90C 18PK M5E(+) 18YL M5E(-) 18GN / M5(+) 20YL M5(-) 20GN / 8 BATT / 12 J1939(+) / 13 J1939(-) / J1939 TERMINATING RESISTOR (7801M) A / OHMS 120 / M5A(+) 18YL / M5A(-) 18GN / Figure 536 / HYDRAULIC BRAKE WITH AIR COMPRESSOR V8 AND L MEGA BRACKET WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

13.45. HYDRAULIC BRAKE WITH AIR COMPRESSOR V8 AND L MEGA BRACKET
Figure 537 HYDRAULIC BRAKE WITH AIR COMPRESSOR V8 AND L MEGA BRACKET WITH 2017 ISB

Components: ABS 8 CONN X1 (9543); CONN (9511); CONTROLLER (1606); ELEC PANEL (1703); INTERCONNECT (9530F); PLATFORM (1700); RESISTOR (7801M)
See also sheets: CH3_70, CH3_73, CH3_74, CH3_76
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.45. HYDRAULIC BRAKE WITH AIR COMPRESSOR V8 AND L MEGA BRACKET WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 36 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090664 NO. RELEASE NO. 95885P 23JAN21 / CHAPTER 13 HYDRAULIC BRAKE W/AIR COMPRESSOR V8 W/L MEGA BRACKET W/2017/2021 ISB/B6.7 DIESEL ENGINE (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FULL PWR CONN (9511) / J1939(-) 15 / J1939(+) 14 / FWD CHASSIS/ PLATFORM (1700) 30 / J1939 TERMINATING RESISTOR (7801M) / M5(+) 18YL / OHMS 120 C / A5S(+) 18YL A5S(-) 18GN A5P(+) 18YL A5P(-) 18GN A5U(+) 18YL A5U(-) 18GN A5NE(+) 18YL A5NE(-) 18GN / M5(-) 18GN / M5A(+) 18YL / M5A(-) 18GN / %M5E(+) 18YL %M5E(-) 18GN / @A5E(+) @A5E(-) 18YL 18GN / J1939 INTERCONNECT (9530F) / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / @ N/GEN 4 BODY CONTROLLER % W/GEN 4 BODY CONTROLLER / Figure 537 / HYDRAULIC BRAKE WITH AIR COMPRESSOR V8 AND L MEGA BRACKET WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

13.46. HYDROMAX HYDRAULIC BRAKES WITH MANUAL PARK BRAKE WITH 2017
Figure 538 HYDROMAX HYDRAULIC BRAKES WITH MANUAL PARK BRAKE WITH 2017 ISB / 2021

Components: CONN (9511K); CONTROLLER (1600); CONTROLLER (1601); CONTROLLER (1602); DIODE (1044A); ECU PWR FUSE (4006); FLOW SW (4038); FUSE (4041); FUSE STUD (4000B); GROUND (4044); LEVEL (4034); LEVEL (4040); PLATFORM (1700/1700); PLATFORM/ENG (1701/1701); PRESSURE (4037); PRESSURE (4039); PRESSURE FUSE (4046); PUMP RELAY (4043); PWR (9785F); SENSE (4042); SENSE FUSE (4045); SPLICE (6704M)
Wires (circuit gauge+color): A90 10GY; A90B 16GY; A90C 18GY; A90D 18GY; A90F 18GY; A90H 16GY; A90P 18GY; A94L 10GY; A9H 16GY; K14 10GY; K90-G 18GY; K90-GA 16WH; K90-GB 10WH; K90-GC 10WH; K90A 10GY; K90AA 10GY; K90B 16GY; K90BB 12GY; K90C 18GY; K90CC 16GY; K90DA 10GY; K90DB 10GY; K90E 16GY; K90G 16GY; K90H 16GY; K90H 18GY; K90P 14GY; K90R 16GY; K90S 8GY; K90T 16GY; K90W 14GY; K90X 14GY; K90Y 14GY; K94L 12GY; M90A 10GY; M94L 10GY
See also sheets: CH13_35, CH3_61
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.46. HYDROMAX HYDRAULIC BRAKES WITH MANUAL PARK BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 37 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / CHAPTER 13 HYDROMAX HYDRAULIC BRAKES W/MANUAL PARK BRAKE W/2017/2021 ISB/B6.7 DIESEL ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / HYD ABS MODULE CONN (9511K) CH13_35 HYDROMAX DIODE (1044A) / FWD CHASSIS/ PLATFORM (1700/1700) 12 M90A 10GY / @K90H 16GY HYDROMAX BRAKE PRESSURE FUSE (4046) @K90X 14GY A 5A B / HYDROMAX FLOW SW (4038) K90CC A 16GY B / (K90CB) 16 / HYDROMAX DIFF PRESSURE (4039) / GND SPLICE (6704M) CH3_61 K90-GA 16WH / K90H 18GY K90-G 18GY @K90-GC 10WH @K90-GB 10WH / (K90D) 16 @K90W 14GY @K90S 8GY / K90T 16GY / @K90R 16GY / @K14 10GY 1 30 / HYD BRAKE PWR (9785F) / @K90DA 10GY / HYDROMAX MOTOR SENSE FUSE (4045) @K90Y 14GY B A 5A HYDROMAX @K90DB MOTOR 10GY SENSE (4042) / 85 4 5 @K90G 16GY @ W/HYDROMAX HYDRAULIC BRAKES NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / HYDROMAX BOOST PUMP RELAY (4043) / 2 86 / OUTPUT F16 SIGNAL / J4-BLUE BODY CONTROLLER (1601) J5-TAN BODY CONTROLLER (1602) / M94L 10GY / A94L 10GY / A90H 16GY A90F 18GY A90D 18GY / INPUT J3-RED PULL UP B1 BODY SIGNAL CONTROLLER INPUT (1600) B10 SIGNAL INPUT B6 SIGNAL / A90B 16GY A90P 18GY A90C 18GY / HYDROMAX GROUND (4044) / HYDROMAX UPPER GROUND STUD (3G) / K90B 16GY @K90P 14GY @K90C 18GY / A9H 16GY / ZVR E7 / HYDROMAX BRAKE PRESSURE (4037) / HYDROMAX BRAKE FLUID LEVEL (4040) A B / K90E 16GY / UPPER MEGA FUSE STUD (4000B) / B C / LOW HYD FLUID LEVEL (4034) / Figure 538 / HYDROMAX HYDRAULIC BRAKES WITH MANUAL PARK BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

13.47. HYDROMAX HYDRAULIC BRAKES WITH WABCO MK25 AND STABILITY
Figure 539 HYDROMAX HYDRAULIC BRAKES WITH WABCO MK25 AND STABILITY CONTROL WITH

Components: ABS-8 CONN X1 (9543); ANGLE SENSOR (9547A); CONN X1 (9543); CONTROLLER (1606); FUSE (4041); FUSE A3-R (1016); FUSE STUD (4000B); PLATFORM (1700); PLATFORM/ELEC PANEL (1703); PLATFORM/ENG (1701); PWR FUSE (4006); RATE SENSOR (9515); RESISTER (7801M); WITH ESC CONN (9511E)
Wires (circuit gauge+color): A152J 20GY; A152P 20GY; A152PA 18RD; A152R 20GY; A152RA 18BK; A90 12GY; A90E 18GY; A94L 12GY; K14C 12RD; K14D 10RD; K90 10GY; K94L 12GY; M152E 18RD; M152EA 18RD; M152EB 18RD; M152F 18BK; M152FA 18BK; M152FB 18BK; M90A 10GY; M90C 18PK; M94L 10GY
See also sheets: CH3_05, CH3_70, CH3_73, CH3_74, CH3_76
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.47. HYDROMAX HYDRAULIC BRAKES WITH WABCO MK25 AND STABILITY CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 38 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / M152EA 18RD M152FA 18BK M152A+ 18YL M152A- 18GN / WABCO YAW RATE SENSOR (9515) / FWD CHASSIS/ PLATFORM (1700) 64 M152EB A152PA 18RD 18RD 65 M152FB A152RA 18BK 18BK M152B+ A5AAZ(+) 18YL 18YL M152B- A5AAZ(-) 18GN 18GN / M5E(+) 18YL / J1939 TERMINATING RESISTER (7801M) A / M5A(+) 18YL / M5E(-) 18GN / M5A(-) 18GN / 120 OHMS / M90C 18PK M5(-) 20GN M5(+) 20YL M152(-) 18GN M152(+) 18YL M152F 18BK M152E 22 18RD NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / M90A 10GY M94L 10GY / 5 6 / WABCO STEERING ANGLE SENSOR (9547A) / A90 12GY A94L 12GY / HYD ABS MODULE WITH ESC CONN (9511E) / 18 29 / 12 19 / 32 1 8 / A152P 20GY A152R 20GY A5AY(+) 20GY A5AY(-) 20GY A152J 20GY / Figure 539 / HYDROMAX HYDRAULIC BRAKES WITH WABCO MK25 AND STABILITY CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

13.48. HYDROMAX HYDRAULIC BRAKES WITH WABCO MK25 AND STABILITY
Figure 540 HYDROMAX HYDRAULIC BRAKES WITH WABCO MK25 AND STABILITY CONTROL WITH

Components: FUSE HOLDER (4041A); FWD CHASSIS (9513M); SPEED SENSOR (9514); SPEED SENSOR (9515); WHEEL SPEED SENSOR (9516A); WHEEL SPEED SENSOR (9517A); WITH ESC CONNECTOR (9511E); WITH POWERTRAIN (9785M)
Wires (circuit gauge+color): M14HA 8RD; M14M 8RD; M90-G 10WH
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.48. HYDROMAX HYDRAULIC BRAKES WITH WABCO MK25 AND STABILITY CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.), P. 39 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090664 NO. RELEASE NO. 95885P 23JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 46 OUTPUT / [M94L+] 18BK [M94L-] 18BN / 45 INPUT / HYD BRAKE L FR WHEEL SPEED SENSOR (9517A) 1 / 33 OUTPUT / [M94R+] 18BK [M94R-] 18BN / 34 INPUT / HYD BRAKE R FR WHEEL SPEED SENSOR (9516A) 1 / 47 GROUND / M90-G 10WH / LOWER DASH GROUND (2GG) / REDUNDANT PWR FUSE HOLDER (4041A) 1 / M14HA 8RD / M14M 8RD / HYD BRAKE REDUNDENT PWR CONN WITH POWERTRAIN (9785M) / HYD BRAKE REDUNDENT PWR BATT EYELET (1BATA) / M94LR- 18TN M94LR+ 18TN / 37 OUTPUT / M94RR- 18TN M94RR+ 18TN / 36 INPUT / REAR CHASSIS/ FWD CHASSIS (9513M) 4 / HYD R REAR WHEEL SPEED SENSOR (9515) / [RBNRR] 18BN / [RBKRR] 18BK / [RBNLR] 18BN [RBKLR] 18BK / HYD L REAR WHEEL SPEED SENSOR (9514) / HYD ABS MODULE WITH ESC CONNECTOR (9511E) / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 540 / HYDROMAX HYDRAULIC BRAKES WITH WABCO MK25 AND STABILITY CONTROL WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE (CONT.)

13.49. HYDROMAX HYDRAULIC BRAKES WITH WABCO MK25 AND STABILITY
Figure 541 HYDROMAX HYDRAULIC BRAKES WITH WABCO MK25 AND STABILITY CONTROL WITH

Components: ANGLE SENSOR (9547A); FUSE (4041); FUSE F25 (1011); FUSE STUD (4000B); PLATFORM (1700); PLATFORM/ENG (1701); PWR FUSE (4006); RATE SENSOR (9515); RESISTER (7801M); W/4100 (1029A); WITH ESC CONN (9511E)
Wires (circuit gauge+color): A152J 18GY; A152P 18RD; A152R 18BK; A90 12GY; A90E 18GY; A94L 12GY; K14C 12RD; K14D 10RD; K90 10GY; K94L 12GY; M152E 18RD; M152EA 18RD; M152EB 18RD; M152F 18BK; M152FA 18BK; M152FB 18BK; M90A 10GY; M90C 18PK; M94L 10GY
See also sheets: CH13_62
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.49. HYDROMAX HYDRAULIC BRAKES WITH WABCO MK25 AND STABILITY CONTROL WITH 2017 ISB DIESEL ENGINE, P. 39A / CHAPTER 13 HYDROMAX HYDRAULIC BRAKES W/WABCO MK25 W/STABILITY CONTROL W/2017-ISB-DIESEL ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 25MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / M152EA 18RD M152FA 18BK M152A+ 18YL M152A- 18GN / WABCO YAW RATE SENSOR (9515) / FWD CHASSIS/ PLATFORM (1700) 64 M152EB 18RD M152FB 18BK M152B+ 18YL / M152B- 18GN / M5E(+) 18YL / J1939 TERMINATING RESISTER (7801M) A / M5A(+) 18YL / M5E(-) 18GN / M5A(-) 18GN / OHMS 120 / M90C 18PK M5(-) 20GN M5(+) 20YL M152(-) 18GN M152(+) 18YL M152F 18BK M152E 18RD / M90A 10GY / M94L 10GY / A152P 18RD A152R 18BK A5A(+) 18YL A5A(-) 18GN A152J 18GY / WABCO STEERING ANGLE SENSOR (9547A) / A5E(+) 18YL / J1939 SPLICE W/4100 (1029A) CH13_62 / A90 12GY / A94L 12GY / HYD ABS MODULE WITH ESC CONN (9511E) / 18 29 / 12 19 / 32 1 / Figure 541 / HYDROMAX HYDRAULIC BRAKES WITH WABCO MK25 AND STABILITY CONTROL WITH 2017 ISB DIESEL ENGINE

13.50. BENDIX ABS-6 WITHOUT ATC WITH F-2018 PROPANE / GASOLINE ENGINE, P. 40
Figure 542 BENDIX ABS-6 WITHOUT ATC WITH F-2018 PROPANE / GASOLINE ENGINE

Components: AIR MODULATOR (9520); AIR MODULATOR (9521); CONNECTOR (9539); INTERCONNECT (9541F / 9541M); L REAR MODULATOR (9518); R REAR MODULATOR (9519); SPEED SENSOR (9501); SPEED SENSOR (9503)
Wires (circuit gauge+color): M94BA 16GY; M94BB 16GY; M94BC 16GY; M94BD 16GY; M94BE 16GY; M94BF 16GY; R94BA 16GY; R94BB 16GY; R94BC 16GY; R94BD 16GY; R94BE 16GY; R94BF 16GY; R94DA 16GY; R94DB 16GY; R94DC 16GY; R94DD 16GY; R94M 16GY; R94N 16GY; R94P 16GY; R94R 16GY; R94S 16GY; R94T 16GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.50. BENDIX ABS-6 WITHOUT ATC WITH F-2018 PROPANE / GASOLINE ENGINE, P. 40 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / CHAPTER 13 BENDIX ABS-6 N/AUTOMATIC TRACTION CONTROL W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B A / R94M 16GY R94P 16GY / R94R 16GY R94T 16GY / M94BD 16GY M94BF 16GY / R94DC 16GY R94DD 16GY / R94N 16GY / R94BD 16GY R94BF 16GY / B A / B A / BENDIX AIR ABS R FR AIR MODULATOR (9521) / M94BB 16GY / REAR CHASSIS INTERCONNECT (9541F / 9541M) B / R94BE 16GY / M94BA 16GY M94BC 16GY / BENDIX AIR ABS L REAR MODULATOR (9518) / R94BB 16GY / R94S 16GY / BENDIX AIR ABS-6 CONNECTOR (9539) / R94BA 16GY R94BC 16GY / M94BE 16GY / B A / R94DB 16GY / BENDIX AIR ABS R REAR MODULATOR (9519) / BENDIX AIR R REAR WHEEL SPEED SENSOR (9503) / R94DA 16GY / BENDIX AIR ABS L FR AIR MODULATOR (9520) / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / BENDIX AIR L REAR WHEEL SPEED SENSOR (9501) / Figure 542 / BENDIX ABS-6 WITHOUT ATC WITH F-2018 PROPANE / GASOLINE ENGINE

13.51. BENDIX ABS-6 WITH ATC WITH F-2018 PROPANE / GASOLINE ENGINE, P. 41
Figure 543 BENDIX ABS-6 WITH ATC WITH F-2018 PROPANE / GASOLINE ENGINE

Components: ABS-6 CONN (9540); CONTROL (9522)
Wires (circuit gauge+color): R94A 16DKBL
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.51. BENDIX ABS-6 WITH ATC WITH F-2018 PROPANE / GASOLINE ENGINE, P. 41 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090664 95885P 23JAN21 / CHAPTER 13 BENDIX ABS-6 W/AUTOMATIC TRACTION CONTROL W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / TRACTION SOLENOID 13 GROUND / R94B 16YL / BENDIX AIR ABS-6 CONN (9540) / R94A 16DKBL / AIR AUTO TRACTION CONTROL (9522) / W/AUTOMATIC TRACTION CONTROL / TRACTION SOLENOID SOURCE / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 543 / BENDIX ABS-6 WITH ATC WITH F-2018 PROPANE / GASOLINE ENGINE

13.52. BENDIX ABS-6 WITH PARK BRAKE BUZZER WITH F-2018 PROPANE / GASOLINE ENGINE, P. 42
Figure 544 BENDIX ABS-6 WITH PARK BRAKE BUZZER WITH F-2018 PROPANE / GASOLINE ENGINE

Components: ABS 8 CONN X1 (9543); CONTROLLER (1606); ELEC PANEL (1703); FUSE A3-R (1016); FUSE F25 (1011); K BAUD (1651); PLATFORM (1700); PLATFORM/ENG (1701/1701)
Wires (circuit gauge+color): A94A 16GY; A94BA 18GY; A94BP 16GY; K14X 10RD; K94B 10GY; M3CA 18GY; M3CB 18GY; M94-G 12WH; M94BJ 18GY; M94BP 12GY; M94LA 16GY; M94LB 16GY; M94RA 16GY
See also sheets: CH3_05, CH3_70, CH3_73, CH3_74, CH3_76, CH3_92
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.52. BENDIX ABS-6 WITH PARK BRAKE BUZZER WITH F-2018 PROPANE / GASOLINE ENGINE, P. 42 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / BENDIX L FR WHEEL SPEED SENSOR %(9508) 1 / M94LB 16GY FWD CHASSIS/PLATFORM %(1700/1700) 35 M94BJ *A94BA 18GY 18GY / M94RA 16GY M94RB 16YL / OUTPUT 7 / IGN 9 / OUTPUT 8 / INPUT 4 / M94LA 16GY / BATT 14 / BENDIX R FR WHEEL SPEED SENSOR %(9507) 1 / GROUND 15 / M94-G 12WH / M94BP 12GY / FUSE F25 (1011) CH3_94C FUSE A3-R (1016) CH3_05 BRAKE SYSTEM FUSE %(4041) K14X A 10RD B 30A DIGNOSTIC CONN 500K BAUD (1651) CH3_92,97A / PLATFORM/ENG (1701/1701) 11 K94B 10GY / UPPER MEGA FUSE STUD %(4000D) / #A94BP 16GY *A94A 16GY / M3CA 18GY M3CB 18GY M5(+) 18YL M5(-) 18GN / J1939(+) 5 / A3(+) 18DKBL A3(-) 18GY M5A(+) 18YL M5A(-) 18GN FWD CHASSIS/ PLATFORM (1700) 30 / J1939(-) 1 / J1939(-) 2 / J1939(+) 6 / M5E(+) 18YL M5E(-) 18GN / J1939 TERMINATING RESISTER %(7801M) A / 120 OHMS / #A94BA 18GY / Figure 544 / BENDIX ABS-6 WITH PARK BRAKE BUZZER WITH F-2018 PROPANE / GASOLINE ENGINE

13.53. BENDIX ABS-8, WITH EC 80, GEN 4 BC AND ATC WITH F-2018 PROPANE / GASOLINE ENGINE, P. 43
Figure 545 BENDIX ABS-8, WITH EC 80, GEN 4 BC AND ATC WITH F-2018 PROPANE / GASOLINE

Components: FUSE A3-R (1016); FUSE F25 (1011); PLATFORM/ENG (1701/1701)
Wires (circuit gauge+color): A94-G 12WH; A94-GA 12WH; A94-GB 12WH; A94-GC 12WH; A94-GD 12WH; A94A 12GY; A94AA 16DKBL; A94AA 18DKBL; A94D 14BK; A94E 14RD; A94F 14BN; A94K 14LTGN; A94L 14LTBL; A94Y 18GY; K14X 10RD; K94B 10GY; M152A 16GY; M152B 16GY; M94A 16GY; M94B 16GY; M94C 16GY; M94D 16GY; M94E 14GY; M94F 14GY; M94H 14GY; M94J 14GY; M94K 14GY; M94L 14GY; R152A 16GY; R152B 16GY; R94A 16GY; R94B 16GY; R94C 16GY; R94D 16GY; R94E 12GY; R94F 12GY; R94H 12GY; R94J 12GY; R94K 12GY; R94L 12GY
See also sheets: CH3_05, CH3_93, CH3_95
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.53. BENDIX ABS-8, WITH EC 80, GEN 4 BC AND ATC WITH F-2018 PROPANE / GASOLINE ENGINE, P. 43 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B BENDIX AIR ABS R A REAR MODULATOR %(9519) / R94J 12GY R94L 12GY / FWD/REAR CHASSIS %(9513M/9513F) 1 M94A R94A 16GY 16GY M94B R94B 16GY 16GY M94E R94E 14GY 12GY / B BENDIX AIR A ABS L REAR MODULATOR %(9518) / BENDIX AIR R REAR WHEEL SPEED SENSOR %(9503) / BENDIX AIR L REAR WHEEL SPEED SENSOR %(9501) 1 / R152A 16GY / R94K 12GY / R94F 12GY / R94H 12GY / R94C 16GY R94D 16GY / AIR AUTO TRACTION CONTROL %(9522) / R152B 16GY BENDIX PWR FUSE %(4041 / PLATFORM/ FWD CHASSIS %(1700) 45 A94B(+) 16GY A94B(-) 16OR A94D 14BK / M94F 14GY / M94K 14GY / M94J 14GY M94L 14GY / M94H 14GY / M94C 16GY M94D 16GY / M152B 16GY PLATFORM/ENG (1701/1701) 11 K94B 10GY / M152A 16GY / A94H 14VT A94L 14LTBL / A94K 14LTGN / A94F 14BN / A94E 14RD / A94C(+) 16YL A94C(-) 16DKBL #A94AA 16DKBL *A94AA 18DKBL #A94AB 16YL *A94AB 18YL / SOURCE 12 / HOLD 16 / EXHAUST 9 / SOURCE 13 / HOLD 10 BENDIX AIR ABS-8 CONN X1 %(9543) INPUT 10 / INPUT 15 / OUTPUT 18 / EXHAUST 17 / *A94Y 18GY A94-GC 12WH A94-GA 12WH / B 30A A / #A94Y 18GY A94-GD 12WH A94-GB 12WH A94-G 12WH / UPPER MEGA FUSE STUD %(4000D) / A94A 12GY / K14X 10RD / BATT 16 / FUSE A3-R (1016) CH3_05 W/FUSION W/WINGMAN / OUTPUT 11 / TRACTION 5 SOLENOID SOURCE TRACTION 4 SOLENOID GROUND / FUSE F25 (1011) CH3_94C / Figure 545 / BENDIX ABS-8, WITH EC 80, GEN 4 BC AND ATC WITH F-2018 PROPANE / GASOLINE ENGINE

13.54. BENDIX ABS-8, WITH EC 80 AND GEN 4 BC, WITHOUT ATC WITH F-2018 PROPANE / GASOLINE ENGINE, P. 44
Figure 546 BENDIX ABS-8, WITH EC 80 AND GEN 4 BC, WITHOUT ATC WITH F-2018 PROPANE

Components: CONN X2 (9544); FR MODULATOR (9521); MODULATOR (9520); PLATFORM (1700/1700); SPEED SENSOR (9508); WHEEL SPEED SENSOR (9507)
Wires (circuit gauge+color): A94R 16BK; A94S 16RD; A94T 14BN; A94V 14LTGN; A94W 14LTBL; M94BA 14GY; M94BB 14GY; M94BC 14GY; M94BD 14GY; M94BE 14GY; M94BF 14GY; M94LA 16GY; M94LB 16GY; M94RA 16GY; M94RB 16GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.54. BENDIX ABS-8, WITH EC 80 AND GEN 4 BC, WITHOUT ATC WITH F-2018 PROPANE / GASOLINE ENGINE, P. 44 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / CHAPTER 13 BENDIX ABS-8 W/EC 80 W/GEN 4 BC N/AUTOMATIC TRACTION CONTROL W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / M94BA 14GY / M94BB 14GY / BENDIX L FR MODULATOR (9520) A / M94BC 14GY / FWD CHASSIS/ PLATFORM (1700/1700) 39 / M94BD 14GY M94BE 14GY / M94BF 14GY / BENDIX R FR MODULATOR (9521) A / M94RA 16GY / BENDIX R FR WHEEL SPEED SENSOR (9507) 2 / M94RB 16GY / M94LA 16GY / M94LB 16GY / BENDIX L FR WHEEL SPEED SENSOR (9508) 1 / A94U 14VT A94V 14LTGN / A94W 14LTBL / A94T 14BN / A94R 16BK A94S 16RD / 4 SOURCE / 6 EXHAUST / BENDIX AIR ABS-8 CONN X2 (9544) / A94M(-) 16YL A94M(+) 16DKBL / 14 OUTPUT / A94N(+) 16GY A94N(-) 16OR / 11 INPUT / 5 INPUT / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 546 / BENDIX ABS-8, WITH EC 80 AND GEN 4 BC, WITHOUT ATC WITH F-2018 PROPANE / GASOLINE ENGINE

13.55. BENDIX ABS-8 WITH EC 80, GEN 4 BC AND STABILITY CONTROL WITH F-2018 PROPANE / GASOLINE ENGINE, P. 45
Figure 547 BENDIX ABS-8 WITH EC 80, GEN 4 BC AND STABILITY CONTROL WITH F-2018 PROPANE

Components: ATR 6 LSM (9513); CHASSIS (1700/1700); CONN X3 (9545); CONN X4 (9546); STEERING ANGLE SENSOR (9547); YAW RATE SANSOR (9514)
Wires (circuit gauge+color): A152B 18GN; A152C 18BK; A152D 18RD; A152E 16DKBL; A152J 18GN; A152K 18BK; A152L 18RD; A152N 18GN; A152P 18BK; A152R 18RD; A152T 12DKBL; M152C 18RD; M152D 18BK; M152G 16GY; M152H 16GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.55. BENDIX ABS-8 WITH EC 80, GEN 4 BC AND STABILITY CONTROL WITH F-2018 PROPANE / GASOLINE ENGINE, P. 45 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / CHAPTER 13 BENDIX ABS-8 W/EC 80 W/GEN 4 BC W/STABILITY CONTROL W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / STEERING ANGLE SENSOR (9547) / A152C 18BK A152D 18RD / A152P 18BK / M152D 18BK M152C 18RD / A152R 18RD / A152M 18YL / A152A 18YL / M152(+) 18YL / A152N 18GN / A152B 18GN / M152(-) 18GN / A152J 18GN A152H 18YL A152L 18RD A152K 18BK / PLATFORM/FWD CHASSIS (1700/1700) 11 / YAW RATE SANSOR (9514) / BENDIX AIR CONN X4 (9546) / A152E 16DKBL / A152F 16YL / M152H 16GY / M152G 16GY / BENDIX AIR ABS-8 CONN X3 (9545) / ATR 6 LSM (9513) / A152U 12YL / A152T 12DKBL / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 547 / BENDIX ABS-8 WITH EC 80, GEN 4 BC AND STABILITY CONTROL WITH F-2018 PROPANE / GASOLINE ENGINE

13.56. HYDROMAX HYDRAULIC BRAKES WITH F-2018 PROPANE / GASOLINE ENGINE, P. 46
Figure 548 HYDROMAX HYDRAULIC BRAKES WITH F-2018 PROPANE / GASOLINE ENGINE

Components: CONTROLLER (1600); CONTROLLER (1601); CONTROLLER (1602); DIODE (1044A); FLOW SW (4038); FUSE (4046); FUSE (4113); FUSE STUD (4000C); GROUND (4044); LEVEL (4040); MODULE CONN (9511E/9511K); PLATFORM (1700); PLATFORM/ENG (1701/1701); PRESSURE (4037); PRESSURE (4039); PUMP RELAY (4043); PWR (9785F); SENSE (4042)
Wires (circuit gauge+color): A90 10GY; A90B 16GY; A90C 18GY; A90D 18GY; A90F 18GY; A90H 16GY; A90P 18GY; A94L 10GY; A9H 16GY; K14 10GY; K90-GA 16WH; K90-GB 10WH; K90-GC 10WH; K90A 10GY; K90AA 10GY; K90B 16GY; K90BB 12GY; K90C 18GY; K90CC 16GY; K90DA 10GY; K90DB 10GY; K90E 16GY; K90G 16GY; K90H 16GY; K90P 14GY; K90R 16GY; K90S 8GY; K90T 16GY; K90W 14GY; K90X 14GY; K90Y 14GY; K94L 12GY; M90A 10GY; M94L 10GY
See also sheets: CH13_47
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.56. HYDROMAX HYDRAULIC BRAKES WITH F-2018 PROPANE / GASOLINE ENGINE, P. 46 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / HYDROMAX HYDRAULIC BRAKES W/F-2018-PROPANE/GASOLINE ENGINE / CHAPTER 13 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K90H 16GY K90X 14GY A 5A B K90W 14GY HYDROMAX HYDROMAX BRAKE BRAKE PRESSURE PRESSURE (4037) FUSE (4046) / 1 2 / A9H 16GY A90B 16GY / A90H 16GY / HYD BRAKE PWR (9785F) CH13_47 / K90S 8GY / A B / K90E 16GY K90B 16GY / HYDROMAX BRAKE FLUID LEVEL (4040) HYDROMAX DIFF PRESSURE (4039) / HYDROMAX FLOW SW (4038) K90CC A 16GY K90-GA B 16WH K90C 18GY K90R 16GY / K90-GB 10WH K90-GC 10WH / HYDROMAX UPPER GROUND STUD (2G) / HYDROMAX GROUND (4044) / K90T 16GY K14 10GY 1 30 / 87 3 4 K90DA 10GY / 2 86 / 85 5 / HYDROMAX BOOST PUMP RELAY 87A (4043) / K90DB 10GY / HYDROMAX MOTOR SENSE (4042) / PLATFORM/ENG (1701/1701) 68 / K90G 16GY / J3-RED BODY CONTROLLER (1600) INPUT PULL UP SIGNAL INPUT B6 SIGNAL INPUT B10 SIGNAL / HYDROMAX DIODE (1044A) / C C / A A / J5-TAN BODY CONTROLLER (1602) / J4-BLUE BODY CONTROLLER (1601) OUTPUT SIGNAL / A90D 18GY / A94L 10GY / A90 10GY / FWD CHASSIS/ PLATFORM (1700) 12 / M90A 10GY / M94L 10GY / HYD ABS MODULE WITH ECS/HYD ABS MODULE CONN (9511E/9511K) CH13_47,48,49A / Figure 548 / HYDROMAX HYDRAULIC BRAKES WITH F-2018 PROPANE / GASOLINE ENGINE

13.57. HYDROMAX HYDRAULIC BRAKES WABCO MK25 WITH BENDIX AIR
Figure 549 HYDROMAX HYDRAULIC BRAKES WABCO MK25 WITH BENDIX AIR COMPRESSOR

Components: ABS 8 CONN X1 (9543); CONTROLLER (1606); ELEC PANEL (1703); ENG (1701); FUSE (4046); FUSE A3-R (1016); FUSE F25 (1011); FWD CHASSIS/PLATFORM (1700/1700)
Wires (circuit gauge+color): A90 10GY; A90E 18GY; A94L 10GY; K90S 8GY; K90W 14GY; M14H 8RD; M14M 8RD; M90-G 10WH; M90A 10GY; M90C 18PK; M94L 10GY
See also sheets: CH13_46, CH3_05, CH3_70, CH3_73, CH3_74, CH3_76
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.57. HYDROMAX HYDRAULIC BRAKES WABCO MK25 WITH BENDIX AIR COMPRESSOR WITH F-2018 PROPANE / GASOLINE ENGINE, P. 47 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B A 30A / HYD BRAKE REDUNDANT PWR BATT EYELET %(1BATA) M14H 8RD / M90C 18PK M90A 10GY M94L 10GY [M94S+] 18BK [M94S-] 18BN / [M94L+] 18BK [M94L-] 18BN M5(+) 18YL M5(-) 18GN / 12 13 / FWD CHASSIS/PLATFORM @A90E (1700/1700) 18GY 35 #A90E 18GY A90 10GY A94L 10GY / FUSE F25 (1011) CH3_94C FUSE A3-R (1016) CH3_05 PLATFORM/ ENG (1701) CH13_46 HYD BRAKE R FR WHEEL SPEED SENSOR %(9516A) / FWD/RR CHASSIS %(9513F/9513M) 1 [R94L+] 18BK [R94L-] 18BN / INPUT 34 / OUTPUT 33 / 36 INPUT / 37 OUTPUT / OUTPUT 42 / INPUT 43 / INPUT 45 OUTPUT 46 / J1939(+) 12 / J1939(-) 13 / M94+ 18TN / M94- 18TN / M94R- 18TN M94R+ 18TN / HYD BRAKE L FR WHEEL SPEED SENSOR %(9517A) / M5E(+) 18YL M5E(-) 18GN / M5A(+) 18YL / GROUND 47 / M90-G 10WH / LOWER DASH GROUND %(2GG) / HYD L REAR WHEEL SPEED SENSOR %(9515) / [R94R-] 18BN [R94R+] 18BK / HYD L REAR WHEEL SPEED SENSOR %(9514) / A C / OHMS 120 / HYD BRAKE FUSE HOLDER %(4041) / K90W 14GY / Figure 549 / HYDROMAX HYDRAULIC BRAKES WABCO MK25 WITH BENDIX AIR COMPRESSOR WITH F-2018 PROPANE / GASOLINE ENGINE

13.58. HYDROMAX HYDRAULIC BRAKES WABCO MK25 WITH STABILITY CONTROL
Figure 550 HYDROMAX HYDRAULIC BRAKES WABCO MK25 WITH STABILITY CONTROL WITH

Components: ABS 8 CONN X1 (9543); ANGLE SENSOR (9547A); CONTROLLER (1606); ELEC PANEL (1703); ENGINE (1701); FUSE A3-R (1016); PLATFORM (1700); RATE SENSOR (9515); RESISTER (7801M); WITH ESC CONN (9511E)
Wires (circuit gauge+color): A152J 18GY; A152P 20GY; A152PA 18RD; A152R 20GY; A152RA 18BK; A90 10GY; A90E 18GY; A94L 10GY; M152E 18RD; M152EA 18RD; M152EB 18RD; M152F 18BK; M152FA 18BK; M152FB 18BK; M90A 10GY; M90C 18PK; M94L 10GY
See also sheets: CH13_46, CH3_05, CH3_70, CH3_73, CH3_74, CH3_76
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.58. HYDROMAX HYDRAULIC BRAKES WABCO MK25 WITH STABILITY CONTROL WITH F-2018 PROPANE / GASOLINE ENGINE, P. 48 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / CHAPTER 13 HYDROMAX HYDRAULIC BRAKES WABCO MK25 W/STABILITY CONTROL W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / M152EA 18RD M152FA 18BK M152A+ 18YL / WABCO YAW RATE SENSOR (9515) / FWD CHASSIS/ PLATFORM (1700) 59 M152EB 18RD M152FB 18BK M152B(+) 18YL / M152A- 18GN / M152B(-) 18GN / M5E(+) 18YL M5E(-) 18GN / J1939 TERMINATING RESISTER (7801M) A / M5A(+) 18YL M5A(-) 18GN / 120 OHMS / M90C 18PK M5(-) 18GN M5(+) 18YL M152(-) 18GN M152(+) 18YL M152F 18BK M152E 18RD / M90A 10GY M94L 10GY / A152PA 18RD A152RA 18BK / A5AA(+) 18YL A5AA(-) 18GN / WABCO STEERING ANGLE SENSOR (9547A) / A5S(+) 18YL A5S(-) 18GN A5P(+) 18YL A5P(-) 18GN A5U(+) 18YL A5U(-) 18GN A5NE(+) 18YL A5NE(-) 18GN / A90E 18GY A90 10GY A94L 10GY / FUSE A3-R (1016) CH3_05 PLATFORM/ ENGINE (1701) CH13_46 / 18 29 22 / HYD ABS MODULE WITH ESC CONN (9511E) / 12 19 / 32 1 8 / A5A(-) 20GY A152J 18GY / A152P 20GY A152R 20GY A5A(+) 20GY / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 550 / HYDROMAX HYDRAULIC BRAKES WABCO MK25 WITH STABILITY CONTROL WITH F-2018 PROPANE / GASOLINE ENGINE

13.59. HYDROMAX HYDRAULIC BRAKES WABCO MK25 WITH STABILITY CONTROL
Figure 551 HYDROMAX HYDRAULIC BRAKES WABCO MK25 WITH STABILITY CONTROL WITH

Components: CHASSIS (9513M/9513F); WHEEL SPEED SENSOR (9514); WHEEL SPEED SENSOR (9515); WHEEL SPEED SENSOR (9516A); WHEEL SPEED SENSOR (9517A); WITH ESC CONN (9511E)
Wires (circuit gauge+color): M90-G 10WH
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.59. HYDROMAX HYDRAULIC BRAKES WABCO MK25 WITH STABILITY CONTROL WITH F-2018 PROPANE / GASOLINE ENGINE (CONT.), P. 49 / CHAPTER 13 HYDROMAX HYDRAULIC BRAKES WABCO MK25 W/STABILITY CONTROL W/F-2018-PROPANE/GASOLINE ENGINE(CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / [M94L+] 18BK [M94L-] 18BN / HYD BRAKE L FR WHEEL SPEED SENSOR (9517A) 1 / 33 OUTPUT / [M94R+] 18BK [M94R-] 18BN / 34 INPUT / HYD BRAKE R FR WHEEL SPEED SENSOR (9516A) 1 / 47 GROUND / M90-G 10WH / LOWER DASH GROUND (2GG) / M94LR+ 18TN M94LR(-) 18TN / M94RR(-) 18TN / 36 INPUT / 37 OUTPUT / M94RR(+) 18TN / 43 INPUT / 42 OUTPUT / REAR/FWD CHASSIS (9513M/9513F) 1 [R94L+] 18BK / HYD L REAR WHEEL SPEED SENSOR (9514) 1 / [R94L-] 18BN / HYD R REAR WHEEL SPEED SENSOR (9515) 1 / [R94R+] 18BK / [R94R-] 18BN / HYD ABS MODULE WITH ESC CONN (9511E) / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 551 / HYDROMAX HYDRAULIC BRAKES WABCO MK25 WITH STABILITY CONTROL WITH F-2018 PROPANE / GASOLINE ENGINE (CONT.)

13.60. HYDROMAX HYDRAULIC BRAKES WABCO MK25 WITH STABILITY CONTROL
Figure 552 HYDROMAX HYDRAULIC BRAKES WABCO MK25 WITH STABILITY CONTROL WITH

Components: ANGLE SENSOR (9547A); FUSE F25 (1011); J1939 SPLICE (1029A); PLATFORM (1700); PLATFORM/ENG (1701); RATE SENSOR (9515); RESISTER (7801M); WITH ESC CONN (9511E)
Wires (circuit gauge+color): A152J 18GY; A152P 18RD; A152R 18BK; A90 10GY; A90E 18GY; A94L 10GY; M152E 18RD; M152EA 18RD; M152EB 18RD; M152F 18BK; M152FA 18BK; M152FB 18BK; M90A 10GY; M90C 18PK; M94L 10GY
See also sheets: CH13_46
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.60. HYDROMAX HYDRAULIC BRAKES WABCO MK25 WITH STABILITY CONTROL WITH F-2018 PROPANE / GASOLINE ENGINE (CONT.), P. 49A / CHAPTER 13 HYDROMAX HYDRAULIC BRAKES WABCO MK25 W/STABILITY CONTROL W/F-2018-PROPANE/GASOLINE ENGINE(CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 25MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / M152EA 18RD M152FA 18BK M152A+ 18YL / WABCO YAW RATE SENSOR (9515) / FWD CHASSIS/ PLATFORM (1700) 59 M152EB 18RD M152FB 18BK M152B(+) 18YL / M152A- 18GN / M152B(-) 18GN / M5E(+) 18YL M5E(-) 18GN / J1939 TERMINATING RESISTER (7801M) A / M5A(+) 18YL / M5A(-) 18GN / OHMS 120 / M90C 18PK M5(-) 18GN M5(+) 18YL M152(-) 18GN M152(+) 18YL M152F 18BK M152E 18RD / M90A 10GY M94L 10GY / A152P 18RD A152R 18BK A5A(+) 18YL A5A(-) 18GN A152J 18GY / WABCO STEERING ANGLE SENSOR (9547A) 5 / A5E(+) 18YL / A5E(-) 18GN A90E 18GY / J1939 SPLICE (1029A) CH3_97A FUSE F25 (1011) CH3_94C / A90 10GY A94L 10GY / PLATFORM/ENG (1701) CH13_46 / HYD ABS MODULE WITH ESC CONN (9511E) / 32 1 / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / Figure 552 / HYDROMAX HYDRAULIC BRAKES WABCO MK25 WITH STABILITY CONTROL WITH F-2018 PROPANE / GASOLINE ENGINE (CONT.)

13.61. COLLISION AVOIDANCE EFFECTS WITH F-2018 PROPANE / GASOLINE ENGINE, P. 50
Figure 553 COLLISION AVOIDANCE EFFECTS WITH F-2018 PROPANE / GASOLINE ENGINE

Components: ABS 8 CONN X1 (9543); CONTROLLER (1606); ELEC PANEL (10001); ELEC PANEL (1702/1702); ELEC PANEL (1703); FUSE A3-B (1016); FUSE F16 (1011)
Wires (circuit gauge+color): A13E 18PK; A13EE 18PK; A13F 18PK; A13FV 18PK; A152Y 18RD; A67-G 18WH; A67-GA 18WH; A94-GB 12WH; A94-GD 12WH; M13AA 18PK; M67-GA 18WH
See also sheets: CH13_55, CH3_06, CH3_70, CH3_73, CH3_74, CH3_76, CH3_93, CH3_95
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.61. COLLISION AVOIDANCE EFFECTS WITH F-2018 PROPANE / GASOLINE ENGINE, P. 50 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / CHAPTER 13 COLLISION AVOIDANCE EFFECTS W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FWD CHASSIS/ PLATFORM !(1700/1700) 30 / J1939 TERMINATING RESISTOR !(1657) / J1939(+) 1 / @M5B(+) 18YL / @M5C(+) 18YL / J1939(-) 6 / @M5C(-) 18GN / J1939(+) 2 / #M5UE(+) 18YL #M5UE(-) 18GN / BENDIX WINGMAN !(8903) / @M5A(+) 18YL @M5A(-) 18GN / @M5B(-) 18GN / OHMS 120 / J1939(-) 7 / PWR 8 / @M13AA 18PK / @M67-GA 18WH / GROUND 5 / %A13F 18PK A67-G 18WH A67-GA 18WH / FUSE A3-B (1016) CH3_06 / GROUND STUD &(4037ZB) CH3_93 GROUND STUD %(4037Z) CH3_95 / %152Y 18RD A94-GB 12WH A94-GD 12WH / *M5(+) 18YL / *M5(-) 18GN / A13EE 18PK / FR CAP/ ELEC PANEL (10001) CH13_55,55A / %A13E 18PK / FUSE F16 (1011) CH3_94B / Figure 553 / COLLISION AVOIDANCE EFFECTS WITH F-2018 PROPANE / GASOLINE ENGINE

13.62. BENDIX ABS 6 / 8 WITH 2017 ISB / 2021 B6.7 DIESEL OR WITH F-2018 PROPANE / GASOLINE ENGINE, P. 51
Figure 554 BENDIX ABS 6 / 8 WITH 2017 ISB / 2021 B6.7 DIESEL OR WITH F-2018 PROPANE

Components: ALARM (1043A); BODY CONTROLLER (1600); BODY CONTROLLER (1602); BRAKE SW (1104); PRESSURE SENSOR (1811); PRESSURE SENSOR (1812); PRESSURE SW (1823); PRESSURE SW (1824); REFERENCE (1005); STUD (4037Z)
Wires (circuit gauge+color): A40 18GY; A40A 18GY; A44BB 18GY; A6H 16GY; A6H 18GY; A6HA 18GY; A6HB 18GY; A70CA 16GY; A70CA 18OR; A70CB 16GY; A70CB 18OR; A79-G 14WH; A79K 16GY; A79N 16GY; A79P-G 16WH; A9B 18GY; A9VC 18GY; A9VE 18GY; A9VG 16GY; A9VG 18GY; A9VH 16GY; A9VH 18GY; A9VL 14GY; A9VL 18GY
See also sheets: CH13_52, CH3_58, CH3_95
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.62. BENDIX ABS 6 / 8 WITH 2017 ISB / 2021 B6.7 DIESEL OR WITH F-2018 PROPANE / GASOLINE ENGINE, P. 51 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / @ W/BENDIX/WABCO AIR ABS 6 * W/BENDIX AIR ABS 8 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / CHAPTER 13 BENDIX ABS 6/8 W/2017/2021 ISB/B6.7 DIESEL W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SECONDARY AIR PRESSURE SENSOR (1812) C B / */@A6HB 18GY */@A9VC 18GY / POSITIVE 5V OUTPUT (B) / */@A40 18GY / SECONDARY AIR PRESSURE B3 / J3-RED BODY CONTROLLER (1600) / J3-RED BODY CONTROLLER (1600) / */@A40A 18GY / PRIMARY AIR PRESSURE B2 / C B / @A9VL 18GY / @A6H 18GY / PRIMARY AIR PRESSURE SENSOR (1811) / J5-TAN BODY CONTROLLER (1602) / */@A6HA 18GY */@A9VE 18GY / PARK BRAKE INPUT / AIR PARK BRAKE SW (1104) / STOP LT #1 PRESSURE SW (1823) D / BRAKE SW INPUT E14 / BRAKE SW E15 INPUT / @A44BB 18GY / @A9VG 18GY *A9VG 16GY / @A70CA 18OR / @A9VH 18GY *A9VH 16GY @A70CB 18OR *A70CB 16GY / STOP LT #2 PRESSURE SW (1824) D / PARK BRAKE ALARM (1043A) CH13_52 J5-TAN BODY CONTROLLER (1602) / ZERO VOLT (1005) CH3_58 / *A9VL 14GY / *A70CA 16GY / @A9B 18GY / A79-G 14WH / GROUND STUD (4037Z) CH3_95 / *A79K 16GY / *A79N 16GY / *A6H 16GY / *A79P-G 16WH / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 554 / BENDIX ABS 6 / 8 WITH 2017 ISB / 2021 B6.7 DIESEL OR WITH F-2018 PROPANE / GASOLINE ENGINE

13.63. BENDIX ABS 6 / 8 WITH 2017 ISB / 2021 B6.7 DIESEL OR WITH F-2018
Figure 555 BENDIX ABS 6 / 8 WITH 2017 ISB / 2021 B6.7 DIESEL OR WITH F-2018 PROPANE /

Components: AIR BRAKE SW (1104); ALARM (1109A); BODY CONTROLLER (1602); BRAKE SW (1104A); CONN (1043A); CONTROLLER (1600); FUSE A6-E (1014); PRESSURE SW (1023A); PRESSURE SW (1024A); REFERENCE (1005); RELAY (1011-R5); ZVR RELAY (1011-R6); ZVR RELAYS (1009)
Wires (circuit gauge+color): A44BB 16GY; A70CA 16GY; A70CB 16GY; A79-G 12WH; A79-G 14WH; A79A 16RD; A79B 16RD; A79E 16GY; A79F 16GY; A79J 16GY; A79K 16GY; A79L 16GY; A79L-G 16WH; A79N 16GY; A79P 16PK; A79P-G 16WH; A9B 16GY; A9VG 16GY; A9VH 16GY; A9VL 14GY
See also sheets: CH13_51, CH3_01, CH3_02, CH3_58, CH3_95, CH5_12
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.63. BENDIX ABS 6 / 8 WITH 2017 ISB / 2021 B6.7 DIESEL OR WITH F-2018 PROPANE / GASOLINE ENGINE (CONT.), P. 52 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / CHAPTER 13 BENDIX ABS 6/8 W/2017/2021 ISB/B6.7 DIESEL W/F-2018-PROPANE/GASOLINE ENGINE (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J3-RED BODY CONTROLLER (1600) PARK BRAKE A12 INPUT / AIR PARK BRAKE SW (1104A) C / STOP LT 1 PRESSURE SW (1023A) D / BRAKE SW INPUT E14 / BRAKE SW E15 INPUT / A9B 16GY / @/*A44BB 16GY / @A9VG 16GY / @A70CA 16GY / @A9VH 16GY / @A70CB 16GY / STOP LT 2 PRESSURE SW (1024A) / J5-TAN BODY CONTROLLER (1602) / PARK BRAKE ZVR RELAY (1011-R6) / @/*A9VL 14GY / ZERO VOLT (1005) CH3_58 / @/*A79P 16PK / COIL SIGNALS ZVR RELAYS (1009) CH3_02 / PARK BRAKE ALARM RELAY (1011-R5) 86 / @/*A79E 16GY / A79B 16RD / A79A 16RD / @/*A79J 16GY / @A79K 16GY / SEAT BELT ALARM (1109A) CH5_12 / FUSE A6-E (1014) CH3_01 / @A79P-G 16WH / *A79-G 14WH @A79-G 12WH / @/*A79F 16GY / PARK BRAKE ALARM (+) (10751A) / @/*A79L 16GY / @/*A79N 16GY / PARK BRAKE ALARM DIODE ASSY CONN (1043A) A / @/*A79L-G 16WH / PARK BRAKE ALARM (-) (10751) / GROUND STUD (4037Z) CH3_95 / *A79K 16GY / AIR BRAKE SW (1104) CH13_51 / * W/BENDIX AIR ABS 8 @ W/BENDIX AIR ABS 6 W/ PARK BRAKE BUZZER NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 555 / BENDIX ABS 6 / 8 WITH 2017 ISB / 2021 B6.7 DIESEL OR WITH F-2018 PROPANE / GASOLINE ENGINE (CONT.)

13.64. BENDIX ABS 6 / 8 WITH 2017 ISB / 2021 B6.7 DIESEL OR WITH F-2018
Figure 556 BENDIX ABS 6 / 8 WITH 2017 ISB / 2021 B6.7 DIESEL OR WITH F-2018 PROPANE /

Components: BODY CONTROLLER (1600); BODY CONTROLLER (1602); PRESSURE SENSOR (1811A); PRESSURE SENSOR (1812A); REFERENCE (1005)
Wires (circuit gauge+color): A40 18GY; A40A 18GY; A6H 16GY; A6HA 18GY; A6HB 18GY; A9VC 18GY; A9VE 18GY; A9VL 14GY
See also sheets: CH3_58
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.64. BENDIX ABS 6 / 8 WITH 2017 ISB / 2021 B6.7 DIESEL OR WITH F-2018 PROPANE / GASOLINE ENGINE (CONT.), P. 53 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / CHAPTER 13 BENDIX ABS 6/8 W/2017/2021 ISB/B6.7 DIESEL W/F-2018-PROPANE/GASOLINE ENGINE (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / @A6HB 18GY @A9VC 18GY / POSITIVE 5V OUTPUT (B) / @A40 18GY / SECONDARY AIR PRESSURE B3 / J3-RED BODY CONTROLLER (1600) / @A40A 18GY / PRIMARY AIR PRESSURE B2 / C B / @A6H 16GY / PRIMARY AIR PRESSURE SENSOR (1811A) / J5-TAN BODY CONTROLLER (1602) / @A9VE 18GY @A6HA 18GY / SECONDARY AIR PRESSURE SENSOR (1812A) A B C / A9VL 14GY / ZERO VOLT (1005) CH3_58 / @ W/BENDIX AIR ABS-6 W/PARK BRAKE BUZZER NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 556 / BENDIX ABS 6 / 8 WITH 2017 ISB / 2021 B6.7 DIESEL OR WITH F-2018 PROPANE / GASOLINE ENGINE (CONT.)

13.65. BENDIX ABS 6 / 8 WITH 2017 ISB DIESEL & WITH F-2018 PROPANE /
Figure 557 BENDIX ABS 6 / 8 WITH 2017 ISB DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE

Components: ALARM (1043A); BODY CONTROLLER (1600); BODY CONTROLLER (1602); BRAKE SW (1104); PRESSURE SENSOR (1811); PRESSURE SENSOR (1812); PRESSURE SW (1823); PRESSURE SW (1824); REFERENCE (1005); STUD (4037Z)
Wires (circuit gauge+color): A40 18GY; A40A 18GY; A44BB 18GY; A6H 16GY; A6H 18GY; A6HA 18GY; A6HB 18GY; A70CA 16GY; A70CA 18OR; A70CB 16GY; A70CB 18OR; A79-G 14WH; A79K 16GY; A79N 16GY; A79P-G 16WH; A9B 18GY; A9VC 18GY; A9VE 18GY; A9VG 16GY; A9VG 18GY; A9VH 16GY; A9VH 18GY; A9VL 14GY; A9VL 18GY
See also sheets: CH3_95
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.65. BENDIX ABS 6 / 8 WITH 2017 ISB DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE, P. 53A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. J3-RED BODY CONTROLLER (1600) / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 25MAR21 / CHAPTER 13 BENDIX ABS 6/8 W/2017-ISB-DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / C B / A6HB 18GY A9VC 18GY / POSITIVE 5V OUTPUT (B) / A40 18GY / SECONDARY AIR PRESSURE B3 / J3-RED BODY CONTROLLER (1600) / A40A 18GY / PRIMARY AIR PRESSURE B2 / C B / #A9VL 18GY / #A6H 18GY / PRIMARY AIR PRESSURE SENSOR (1811) / J5-TAN BODY CONTROLLER (1602) / A6HA 18GY A9VE 18GY / AIR PARK BRAKE SW (1104) D / PARK BRAKE INPUT / SECONDARY AIR PRESSURE SENSOR (1812) / STOP LT #1 PRESSURE SW (1823) D / BRAKE SW INPUT E14 / BRAKE SW E15 INPUT / #A9B 18GY / #A44BB 18GY / #A9VG 18GY *A9VG 16GY / #A70CA 18OR / STOP LT #2 PRESSURE SW (1824) D / PARK BRAKE ALARM (1043A) CH13_53B J5-TAN BODY CONTROLLER (1602) / VOLT CH3_95M (1005) ZERO / *A9VL 14GY / *A70CA 16GY / A79-G 14WH / *A79K 16GY / A79N 16GY / *A6H 16GY / *A79P-G 16WH / GND STUD (4037Z) CH3_95 / Figure 557 / BENDIX ABS 6 / 8 WITH 2017 ISB DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE

13.66. BENDIX ABS 6 WITH 2017 ISB DIESEL & WITH F-2018 PROPANE / GASOLINE
Figure 558 BENDIX ABS 6 WITH 2017 ISB DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE

Components: AIR BRAKE SW (1104); ALARM (1109A); BODY CONTROLLER (1602); BRAKE SW (1104A); CONNECTOR (1043A); CONTROLLER (1600); FUSE F3-B (1011); GND STUD (4037Z); NOT SET ALARM (9999); PRESSURE SW (1023A); PRESSURE SW (1024A); REFERENCE (1005); ZVR RELAYS (1009); ZVR SIGNAL (9998)
Wires (circuit gauge+color): A44BB 16GY; A70CA 16GY; A70CB 16GY; A79-G 14WH; A79A 16RD; A79B 16RD; A79E 16GY; A79F 16GY; A79J 16GY; A79K 16GY; A79L 16GY; A79L-G 16WH; A79N 16GY; A79P 16PK; A79P-G 16WH; A9B 16GY; A9VG 16GY; A9VH 16GY; A9VL 14GY
See also sheets: CH3_94, CH3_95
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.66. BENDIX ABS 6 WITH 2017 ISB DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE, P. 53B / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 25MAR21 / CHAPTER 13 BENDIX ABS 6 W/2017-ISB-DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE STOP LT 1 PRESSURE SW (1023A) / MJV0488 10JUN21 INITIAL PRODUCTION RELEASE. / J3-RED BODY CONTROLLER (1600) / AIR PARK BRAKE SW (1104A) C / PARK BRAKE INPUT / BRAKE SW INPUT E14 / BRAKE SW E15 INPUT / A9B 16GY / A44BB 16GY / A9VG 16GY / A70CA 16GY / A9VH 16GY / A70CB 16GY / STOP LT 2 PRESSURE SW (1024A) / J5-TAN BODY CONTROLLER (1602) / 5 85 / 3 87A / 30 1 / PARK BRAKE ZVR SIGNAL (9998) / A9VL 14GY / ZERO VOLT (1005) CH3_95M / A79P 16PK / COIL SIGNALS ZVR RELAYS (1009) CH3_94A / 5 87A / 30 1 / 3 85 / PARK BRAKE NOT SET ALARM (9999) / A79E 16GY / A79B 16RD / A79A 16RD / A79J 16GY / %A79K 16GY / FUSE F3-B (1011) CH3_94 / A79P-G 16WH / A79-G 14WH / A79F 16GY / PARK BRAKE ALARM (+) (10751A) / A79L 16GY / A79N 16GY / PARK BRAKE ALARM DIODE ASSLY CONNECTOR (1043A) A / A79L-G 16WH / PARK BRAKE ALARM (-) (10751) / GND STUD (4037Z) CH3_95 / @A79K 16GY / AIR BRAKE SW (1104) CH13_53A / % W/PARK BRAKE BUZZER W/ABS-6 @ W/PARK BRAKE BUZZER W/ABS 8 NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / SEAT BELT ALARM (1109A) CH5_12A / Figure 558 / BENDIX ABS 6 WITH 2017 ISB DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE

13.67. BENDIX ABS 6 WITH 2017 ISB DIESEL & WITH F-2018 PROPANE / GASOLINE
Figure 559 BENDIX ABS 6 WITH 2017 ISB DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE

Components: BODY CONTROLLER (1600); BODY CONTROLLER (1602); PRESSURE SENSOR (1811A); PRESSURE SENSOR (1812A); REFERENCE (1005)
Wires (circuit gauge+color): A40 18GY; A40A 18GY; A6H 16GY; A6HA 18GY; A6HB 18GY; A9VC 18GY; A9VE 18GY; A9VL 14GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.67. BENDIX ABS 6 WITH 2017 ISB DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE (CONT.), P. 53C / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 25MAR21 / CHAPTER 13 BENDIX ABS 6 W/2017-ISB-DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A6HB 18GY A9VC 18GY / POSITIVE 5V OUTPUT (B) / A40 18GY / SECONDARY AIR PRESSURE B3 / J3-RED BODY CONTROLLER (1600) / A40A 18GY / PRIMARY AIR PRESSURE B2 / C B / A6H 16GY / PRIMARY AIR PRESSURE SENSOR (1811A) / J5-TAN BODY CONTROLLER (1602) / A9VE 18GY A6HA 18GY / SECONDARY AIR PRESSURE SENSOR (1812A) A B C / A9VL 14GY / ZERO VOLT (1005) CH03_95M / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / Figure 559 / BENDIX ABS 6 WITH 2017 ISB DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE (CONT.)

13.68. BENDIX AIR ABS-8 WITH FUSION & INTELLIPARK WITH 2017 ISB DIESEL
Figure 560 ENDIX AIR ABS-8 WITH FUSION & INTELLIPARK WITH 2017 ISB DIESEL ENGINE

Components: BODY CONTROLLER (1600); BODY CONTROLLER (1602); BRAKE SW (1104B); PRESSURE SENSOR (1811B); PRESSURE SENSOR (1812B); PRESSURE SW (1823A); PRESSURE SW (1824A); REFERENCE (1005)
Wires (circuit gauge+color): A40 18GY; A40A 18GY; A44BB 18GY; A6H 18GY; A6HA 18GY; A6HB 18GY; A70CA 18OR; A70CB 18OR; A9B 18GY; A9VC 18GY; A9VE 18GY; A9VG 18GY; A9VH 18GY; A9VL 18GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.68. BENDIX AIR ABS-8 WITH FUSION & INTELLIPARK WITH 2017 ISB DIESEL ENGINE, P. 53D / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. J3-RED BODY CONTROLLER (1600) / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 96289K 22SEP21 / CHAPTER 13 BENDIX AIR ABS-8 W/ FUSION & INTELLIPARK W/2017-ISB-DIESEL ENG / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / 1 3 / A6HB 18GY A9VC 18GY / POSITIVE 5V OUTPUT (B) / A40 18GY / SECONDARY AIR PRESSURE B3 / J3-RED BODY CONTROLLER (1600) PARK BRAKE INPUT / A40A 18GY / PRIMARY AIR PRESSURE B2 / 1 3 / A9VL 18GY / A6H 18GY / PRIMARY AIR PRESSURE SENSOR (1811B) / J5-TAN BODY CONTROLLER (1602) / A6HA 18GY A9VE 18GY / AIR PARK BRAKE SW (1104B) D A9B 18GY / SECONDARY AIR PRESSURE SENSOR (1812B) / STOP LT #1 PRESSURE SW (1823A) D / BRAKE SW INPUT E14 / BRAKE SW E15 INPUT / A44BB 18GY / A9VG 18GY / A70CA 18OR STOP LT #2 PRESSURE SW (1824A) D / A9VH 18GY / J5-TAN BODY CONTROLLER (1602) / VOLT CH3_95M (1005) ZERO / A70CB 18OR / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / Figure 560 / ENDIX AIR ABS-8 WITH FUSION & INTELLIPARK WITH 2017 ISB DIESEL ENGINE

13.69. BENDIX ABS 6 WABCO WITH PARK BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL
Figure 561 BENDIX ABS 6 WABCO WITH PARK BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL OR WITH

Components: BRAKE SOLENOID (4905); ELEC PANEL (1703); FUSE A3-A (1016); PLATFORM/ENG (1701); SPLICE (1003B)
Wires (circuit gauge+color): A44C 18GY; A44C-G 18WH; K44 18GY; K44C 18GY
See also sheets: CH15_08, CH3_05, CH3_33
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.69. BENDIX ABS 6 WABCO WITH PARK BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL OR WITH F-2018 PROPANE / GASOLINE ENGINE, P. 54 / CHAPTER 13 BENDIX ABS 6/WABCO W/PARK BRAKE W/2017/2021 ISB/B6.7 DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K44 18GY / K44C 18GY / PLATFORM/ENG (1701) / AIR PARK BRAKE SOLENOID (4905) / A44C-G 18WH / A44C 18GY / PLATFORM/ ELEC PANEL (1703) CH15_08,09 / FUSE A3-A (1016) CH3_05 / GROUND SPLICE (1003B) CH3_33 / W/PARK BRAKE INTERLOCK / W/WHEEL CHAIR LIFT / A44AB 16VT / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 561 / BENDIX ABS 6 WABCO WITH PARK BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL OR WITH F-2018 PROPANE / GASOLINE ENGINE

13.70. BENDIX ABS 6 WABCO WITH PARK BRAKE WITH 2017 ISB DIESEL OR WITH
Figure 562 BENDIX ABS 6 WABCO WITH PARK BRAKE WITH 2017 ISB DIESEL OR WITH F-2018

Components: BRAKE SOLENOID (4905); FUSE F1 (1011); FUSE F1-B (1011); GROUND SPLICE (1003B); PLATFORM/ENG (1701)
Wires (circuit gauge+color): A44 18GY; A44C-G 18WH; K44 18GY; K44C 18GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.70. BENDIX ABS 6 WABCO WITH PARK BRAKE WITH 2017 ISB DIESEL OR WITH F-2018 PROPANE / GASOLINE ENGINE, P. 54A / CHAPTER 13 BENDIX ABS 6/WABCO W/PARK BRAKE W/2017-ISB- DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 25MAR21 / MJV0488 19NOV21 ADDED CIRC A44/16VT & B 96289K REMOVED CIRC A44/18GY IN R/D 1701. / K44 18GY / K44C 18GY / PLATFORM/ENG (1701) / AIR PARK BRAKE SOLENOID (4905) / *A44C-G 18WH / GROUND SPLICE (1003B) CH3_95C / FUSE F1 (1011) CH3_94B / %A44 18GY / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / % W/F-2018-PROPANE/GASOLINE ENGINE * N/WHEEL CHAIR LIFT INTERLOCK # W/AIR BRAKE SENSOR W/F-2017-ISB-DIESEL ENGINE / FUSE F1-B (1011) CH3_94B / #A44 16VT / Figure 562 / BENDIX ABS 6 WABCO WITH PARK BRAKE WITH 2017 ISB DIESEL OR WITH F-2018 PROPANE / GASOLINE ENGINE

13.71. BENDIX ABS-8 WITH WINGMAN FUSION OPTIONS WITH 2017 ISB / 2021 B6.7
Figure 563 BENDIX ABS-8 WITH WINGMAN FUSION OPTIONS WITH 2017 ISB / 2021 B6.7 DIESEL &

Components: CONN XI (9543); ELEC PANEL (10001); ELEC PANEL/PLATFORM (1703); ENABLE (10283); FUSE A3-B (1016); FUSE A6-N (1014); FUSE A6-T (1014); FUSION CAMERA (10084); FWD CHASSIS (1700); MUTE (1302); PLATFORM (1702); PLATFORM (1703); PLATFORM/ELEC PANEL (1702); PROCESSOR MODULE (10083); SW ILLUM (10399); ZVR SPLICE (10350B)
Wires (circuit gauge+color): A152W 18GY; A152X 18GY; A152Y 18RD; A67A 18GY; B152 18GY; B152-G 18WH; B152A 18GY; B62-GBR 18WH; B62BR 18DKBL; B67 18GY; B67-G 18WH; B67-GA 18WH; C152 18GY; C152-G 20WH; C152-GA 20WH; C152-GB 18WH; C152A 20GY; C152B 20GY; C152C 20GY; C152D 20GY; C152E 20GY; C152F 20GY; C152H 18GY; C152K 18GY; C152L 20GY; C152M 18GY; C67 20GY; C67-G 20WH
See also sheets: CH13_32, CH17_01, CH3_01, CH3_02, CH3_06, CH3_60, CH3_73, CH7_63
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.71. BENDIX ABS-8 WITH WINGMAN FUSION OPTIONS WITH 2017 ISB / 2021 B6.7 DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE, P. 55 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / C5A(+) 20YL C5A(-) 20GN C152C 20GY / C152F 20GY / C5F(+) 20YL C5F(-) 20GN / C5H(+) 20YL C5H(-) 20GN / C152L 20GY C5D(+) 20YL C5D(-) 20GN C152-GA 20WH / C152M 18GY C5C(+) 20YL C5C(-) 20GN C152-GB 18WH / C5B(+) 20YL C5B(-) 20GN C152-G 20WH C5E(-) 20GN C152B 20GY C5E(+) 20YL C152A 20GY #C152K 18GY *C152H 18GY / 7 1 / FUSION CAMERA (10084) 4 3 8 6 9 / SPEAKER (*10079/#10081) / SPEAKER (*10080/#10082) / * W/LEFT SPEAKER # W/RIGHT SPEAKER / PLATFORM/ FWD CHASSIS (1700) CH3_73,75, 84,85 FUSE A3-B (1016) CH3_06 / B67 18GY B67-G 18WH B67-GA 18WH B62BR 18DKBL B62-GBR 18WH / SW ILLUM (10399) CH7_63 / C67 20GY C67-G 20WH ZVR SPLICE (10350B) CH3_60 / Figure 563 / BENDIX ABS-8 WITH WINGMAN FUSION OPTIONS WITH 2017 ISB / 2021 B6.7 DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE

13.72. BENDIX ABS-8 WITH WINGMAN FUSION OPTIONS WITH 2017 ISB DIESEL &
Figure 564 BENDIX ABS-8 WITH WINGMAN FUSION OPTIONS WITH 2017 ISB DIESEL & WITH F-2018

Components: CONN XI (9543); DISABLE/ENABLE (10283); ELEC PANEL (10001); ELEC PANEL/PLATFORM (1703); FUSE F16 (1011); FUSE F27 (1011); FUSION CAMERA (10084); FWD CHASSIS (1700); MUTE (1302); PLATFORM (1702); PLATFORM (1703); PLATFORM/ELEC PANEL (1702); PROCESSOR MODULE (10083); SW ILLUM (10399); ZVR SPLICE (10350B)
Wires (circuit gauge+color): A152W 18GY; A152X 18GY; A152Y 18RD; A67A 18GY; B152 18GY; B152-G 18WH; B152A 18GY; B62-GBR 18WH; B62BR 18DKBL; B67 18GY; B67-G 18WH; B67-GA 18WH; C152 18GY; C152-G 20WH; C152-GA 20WH; C152-GB 18WH; C152A 20GY; C152B 20GY; C152C 20GY; C152D 20GY; C152E 20GY; C152F 20GY; C152H 18GY; C152K 18GY; C152L 20GY; C152M 18GY; C67 20GY; C67-G 20WH
See also sheets: CH13_32, CH3_94, CH3_95, CH7_63
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.72. BENDIX ABS-8 WITH WINGMAN FUSION OPTIONS WITH 2017 ISB DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE, P. 55A / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / C5A(+) 20YL C5A(-) 20GN C152C 20GY / C152F 20GY / C5F(+) 20YL C5F(-) 20GN / C5H(+) 20YL C5H(-) 20GN / C152L 20GY C5D(+) 20YL C5D(-) 20GN C152-GA 20WH / C152M 18GY C5C(+) 20YL C5C(-) 20GN C152-GB 18WH / C5B(+) 20YL C5B(-) 20GN C152-G 20WH C5E(-) 20GN C152B 20GY C5E(+) 20YL C152A 20GY #C152K 18GY *C152H 18GY / 7 1 / FUSION CAMERA (10084) 4 3 8 6 9 / A152W 18GY A5T(+) 18YL A5T(-) 18GN B152-G 18WH PLATFORM/ELEC PANEL (1702) A67A 18GY 43 / SPEAKER (*10079/#10081) / SPEAKER (*10080/#10082) / * W/LEFT SPEAKER # W/RIGHT SPEAKER / PLATFORM/ FWD CHASSIS (1700) CH3_97E,97F FUSE F16 (1011) CH3_94B / FUSE F27 (1011) CH3_94 PLATFORM/ FWD CHASSIS (1700) CH13_32,50 ZVR SPLICE (10350B) CH3_95 RADIO A MUTE (1302) / BENDIX AIR ABS-8 CONN XI (9543) CH3_96F,96N, 96W, 97E, 97F / LANE DEPARTURE WARNING ENABLE/ DISABLE SW DISABLE/ENABLE (10283) / B67 18GY B67-G 18WH B67-GA 18WH B62BR 18DKBL B62-GBR 18WH / SW ILLUM (10399) CH7_63 / C67 20GY C67-G 20WH ZVR SPLICE (10350B) CH3_95N / Figure 564 / BENDIX ABS-8 WITH WINGMAN FUSION OPTIONS WITH 2017 ISB DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE

13.73. BENDIX ABS-8 & HYDRAULIC BRAKE WITH CLUSTER WARNING LIGHT WITH
Figure 565 BENDIX ABS-8 & HYDRAULIC BRAKE WITH CLUSTER WARNING LIGHT WITH 2017 ISB /

Components: CONTROLLER (1601); GROUND SPLICE (1003); SPLICE (1003A)
Wires (circuit gauge+color): A94-GE 18WH; A94Z 18GY
See also sheets: CH3_31, CH3_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.73. BENDIX ABS-8 & HYDRAULIC BRAKE WITH CLUSTER WARNING LIGHT WITH 2017 ISB / 2021 B6.7 DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE, P. 56 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / CHAPTER 13 BENDIX ABS-8 & HYDRAULIC BRAKE W/CLUSTER WARN LT W/2017/2021 ISB/B6.7 DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE (1003A) CH3_32,95B J4 BLUE BODY CONTROLLER (1601) OUTPUT HIGH SIGNAL / CLUSTER WARNING LT (1555) D / #A94-GE #A94-GE 18WH 18WH / A94Z 18GY / @A94-GE 18WH / GROUND SPLICE (1003) CH3_31,95A / %A94-GE 18WH / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / @ W/ESC W/HYD BRAKE W/COMMON % W/F-2018-PROPANE/GASOLINE ENGINE, W/BENDIX ABS-8 # W/2017/2021 ISB/B6.7-ENG, W/BENDIX ABS-8 / Figure 565 / BENDIX ABS-8 & HYDRAULIC BRAKE WITH CLUSTER WARNING LIGHT WITH 2017 ISB / 2021 B6.7 DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE

13.74. HYDRAULIC BRAKES WITH MANUAL PARK BRAKE WITH 2017 ISB / 2021 B6.7
Figure 566 HYDRAULIC BRAKES WITH MANUAL PARK BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL &

Components: BRAKE SW (1814); BRAKE SW (9267A); CONTROLLER (1600); CONTROLLER (1601); CONTROLLER (1602); REFERANCE (1005); REFERENCE (1005); SPLICE (1003A)
Wires (circuit gauge+color): A44CC 18GY; A59A 18GY; A70F 18RD; A90-G 18WH; A9K 18GY; A9VF 18GY
See also sheets: CH3_32, CH3_58
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.74. HYDRAULIC BRAKES WITH MANUAL PARK BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE, P. 57 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / CHAPTER 13 HYDRAULIC BRAKES W/MANUAL PARK BRAKE W/2017/2021 ISB/B6.7 DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J3-RED BODY CONTROLLER (1600) / ZERO VOLT (1005) CH3_58,95M / A44CC 18GY / A59A 18GY / PARK A12 BRAKE INPUT / OUTPUT F3 HIGH SIGNAL / J4-BLUE BODY CONTROLLER (1601) / A9K 18GY / A90-G 18WH / GROUND SPLICE (1003A) CH3_32,95B / BRAKE SW (1814) A / A70F 18RD / BRAKE E14 SW INPUT / J5-TAN BODY CONTROLLER (1602) / A9VF 18GY / ZERO VOLT REFERANCE (1005) CH3_58,95M / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / MANUAL NEXT GEN HYDRAULIC PARK BRAKE SW (9267A) / Figure 566 / HYDRAULIC BRAKES WITH MANUAL PARK BRAKE WITH 2017 ISB / 2021 B6.7 DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE

13.75. WHEELCHAIR LIFT WITH PARK BRAKE INTERLOCK WITH LCT / WTEC XMSN
Figure 567 WHEELCHAIR LIFT WITH PARK BRAKE INTERLOCK WITH LCT / WTEC XMSN WITH 2017

Components: ASSEMBLY (1014F); PANEL LT (1830); PLATFORM (1703); RELAY (1010-R3); RELAY (10312-R4); RELAY (10312-R5); SPLICE (10370)
Wires (circuit gauge+color): A122AA 18GY; A122AB 18GY; A122AC 18GY; A122AD 18GY; A122BE 18GY; A122D 18GY; A122FA 18GY; A92EE 18GY; B44A 18GY; B44B 18GY; B44C 18GY; B44D 18GY
See also sheets: CH12_04, CH15_04, CH15_08
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.75. WHEELCHAIR LIFT WITH PARK BRAKE INTERLOCK WITH LCT / WTEC XMSN WITH 2017 ISB / 2021 B6.7 DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE, P. 58 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / CHAPTER 13 WHEELCHAIR LIFT W/PARK BRAKE INTERLOCK W/LCT/WTEC XMSN W/2017/2021 ISB/B6.7 DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A122BE 18GY / A122D 18GY / L DOOR DIODE ASSEMBLY (1014F) CH15_08, 09,11 / A92EE 18GY / ELEC PANEL/ PLATFORM (1703) A8 / NEXT GEN PARK BRAKE SW FOR WHEELCHAIR (168N) A122AA 18GY / NEXT GEN HYDRAULIC PARK BRAKE WHEELCHAIR RELAY (1010-R3) / @A122AB 18GY / B44A 18GY / B44C 18GY / LIFT SPLICE (10370) CH15_04,05, 06,07 / LIFT INTERLOCK RELAY (10312-R4) CH15_04,05, 06,07 LIFT INTERLOCK RELAY (10312-R5) CH15_04,05, 06,07 LCT XMSN PARK SW & PANEL LT (1830) CH12_04 / A122FA 18GY / B44B 18GY / B44D 18GY / %A122AC 18GY / *A122AD 18GY / * W/WHEELCHAIR LIFT INTLK PROC,PARK W/DIESEL ENG @ W/WTEC & W/LCT XMSN N/SHIFT INTERLOCK % W/WHEELCHAIR LIFT INTLK W/LCT XMSN W/PARK BRAKE / NOTE: CONNECTIONS FOR VEHICLES W/0508108-MTA FUSE BLOCK. / Figure 567 / WHEELCHAIR LIFT WITH PARK BRAKE INTERLOCK WITH LCT / WTEC XMSN WITH 2017 ISB / 2021 B6.7 DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE

13.76. WHEELCHAIR LIFT WITH PARK BRAKE INTERLOCK WITH LCT / WTEC XMSN
Figure 568 WHEELCHAIR LIFT WITH PARK BRAKE INTERLOCK WITH LCT / WTEC XMSN WITH 2017

Components: DIODE ASSEMBLY (1014F); PANEL LT (1830); RELAY (1010); RELAY (10312); SPLICE (10370); TO ELECTRIC PANEL (1703/1703)
Wires (circuit gauge+color): A122A 18GY; A122B 18GY; A122D 18GY; A122F 18GY; A92E 18GY; B44A 18GY; B44B 18GY
See also sheets: CH12_04, CH15_31, CH15_32, CH15_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.76. WHEELCHAIR LIFT WITH PARK BRAKE INTERLOCK WITH LCT / WTEC XMSN WITH 2017 ISB DIESEL & WITH 2018 PROPANE / GASOLINE ENGINE, P. 58A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 25MAR21 / CHAPTER 13 WHEELCHAIR LIFT W/PARK BRAKE INTERLOCK W/LCT/WTEC XMSN W/2017-ISB-DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / LCT XMSN PARK SW & PANEL LT (1830) CH12_04 LIFT DOOR DIODE ASSEMBLY (1014F) CH15_32,33 / 85 2 / 5 86 / NEXT GEN HYDRAULIC PARK BRAKE WHEELCHAIR RELAY NEXT GEN PARK (1010) BRAKE SW FOR 87 87A WHEELCHAIR 4 3 (168N) A122A 18GY / 1 30 / %A122B 18GY / %A122F 18GY / %A122D 18GY / 30WAY PASS-THROUGH TO ELECTRIC PANEL (1703/1703) A9 / @A122A 18GY / B44A 18GY / B44B 18GY / LIFT SPLICE (10370) CH15_31,35 / LIFT INTERLOCK RELAY (10312) CH15_35 / %A122A 18GY / %A92E 18GY / @ W/2017-ISB-DIESEL ENGINE % W/2017-ISB-DIESEL ENG & F-2018-PROPANE/GASOLINE ENGINE / Figure 568 / WHEELCHAIR LIFT WITH PARK BRAKE INTERLOCK WITH LCT / WTEC XMSN WITH 2017 ISB DIESEL & WITH 2018 PROPANE / GASOLINE ENGINE

13.77. AIR BRAKES WITH ESP, P. 59
Figure 569 AIR BRAKES WITH ESP

Components: AIR PRESSURE (9549); AIR PRESSURE (9550); CONN X4 (9546); PRESSURE ADJUSTABLE PEDAL (9552)
Wires (circuit gauge+color): A40B 18GY; A40C 18GY; A6A 18GY; A6B 18GY; A6C 18GY; A9E 18GY; A9F 18GY; A9L 18GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.77. AIR BRAKES WITH ESP, P. 59 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 13 AIR BRAKES W/ELECTRONIC STABILITY PROGRAM W/2010 ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PRIMARY DELIVERY AIR PRESSURE (9549) / BENDIX AIR ABS-8 CONN X4 (9546) / A9E 18GY / A40B 18GY / A6A 18GY / SECONDARY DELIVERY AIR PRESSURE (9550) / A40C 18GY / A6C 18GY / A9L 18GY / A6B 18GY A9F 18GY / PRIMARY DELIVERY AIR PRESSURE (9549) / BENDIX AIR ABS-8 CONN X4 (9546) / A9E 18GY / A40B 18GY / A6A 18GY / SECONDARY DELIVERY AIR PRESSURE ADJUSTABLE PEDAL (9552) / A40C 18GY / A6C 18GY / A9L 18GY / A6B 18GY A9F 18GY / N/ADJUSTABLE PEDALS / W/ADJUSTABLE PEDALS / Figure 569 / AIR BRAKES WITH ESP

13.78. AIR BRAKES WITH ADJUSTABLE PEDAL & WITHOUT ESP, P. 60
Figure 570 AIR BRAKES WITH ADJUSTABLE PEDAL

Components: BODY CONTROLLER (1606); PEDAL MOTOR (9551)
Wires (circuit gauge+color): A101-G 16WH; A101A 16TN; A101B 16TN
See also sheets: CH3_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.78. AIR BRAKES WITH ADJUSTABLE PEDAL & WITHOUT ESP, P. 60 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 23JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / GROUND SPLICE #4 (1003) CH3_31, 95A ADJUSTABLE PEDAL MOTOR (9551) / J6-18 WAY BODY CONTROLLER (1606) / A101A 16TN / A101-G 16WH / A101B 16TN / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK. / Figure 570 / AIR BRAKES WITH ADJUSTABLE PEDAL

13.79. HEATED WIPER BLADE WITH 2017 ISB DIESEL ENGINE, P. 61
Figure 571 HEATED WIPER BLADE WITH 2017 ISB DIESEL ENGINE

Components: PLATFORM (1702); SPLICE (1003B); WIPERS (4501); WIPERS (4502); WIPERS (4503); WIPERS (4504)
Wires (circuit gauge+color): A82-GV 16WH; A82-GW 16WH; A82V 16GY; A82W 16GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.79. HEATED WIPER BLADE WITH 2017 ISB DIESEL ENGINE, P. 61 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 25MAR21 / CHAPTER 13 HEATED WIPER BLADE W/2017-ISB-DIESEL ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A82W 16GY / A82-GV 16WH / A82V 16GY / A82-GW 16WH HEATED A WIPERS (4501) / HEATED A WIPERS (4504) / HEATED WIPERS (4502) / GROUND SPLICE (1003B) CH3_95C / HEATED WIPERS (4503) / ELEC PANEL/ PLATFORM (1702) / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / Figure 571 / HEATED WIPER BLADE WITH 2017 ISB DIESEL ENGINE

13.80. DATALINK BASIC WITH LCT / WTEC FOR HYDRAULIC BRAKES (4100) WITH
Figure 572 DATALINK BASIC WITH LCT / WTEC FOR HYDRAULIC BRAKES (4100) WITH 2017 ISB

Components: CLUSTER (1505); CONN (1650); CONTROLLER (1602); ECM CONN (6021); HARNESS (1700/1700); PLATFORM/ENG (1701); RESISTOR (7801M); W/4100 (1029A)
See also sheets: CH3_86
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.80. DATALINK BASIC WITH LCT / WTEC FOR HYDRAULIC BRAKES (4100) WITH 2017 ISB ENGINE, P. 62 / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 25MAR21 / CHAPTER 13 DATALINK BASIC W/LCT/WTEC FOR HYDRAULIC BRAKES (4100), W/2017-ISB-ENG / MJV0488 10JUN21 INITIAL PRODUCTION RELEASE. / J1939 SPLICE W/4100 (1029A) / A5BC(-) 18GN A5BC(+) 18YL A5E(+) 18YL A5E(-) 18GN A5B(+) 18YL / A5BK(-) 18GN A5BJ(+) 18YL / A5AM(-) 18GN / A5AL(+) 18YL / A5BA(+) A5BB(-) 18YL 18GN / J5-TAN BODY CONTROLLER (1602) / PLATFORM/ENG (1701) / INSTRUMENT CLUSTER (1505) 11 / DIAGNOSTIC CONN (1650) / A5BD(+) 18YL A5BD(-) 18GN / ECM CONN (6021) CH3_86, 87 / K5C(-) 20GN / K5C(+) 20YL / A5A(+) A5A(-) 18YL 18GN / K5B(+) K5B(-) 18YL 18GN / A5B(-) 18GN / FWD CHASSIS/ PLATFORM 31 HARNESS (1700/1700) / M5E(+) 18YL / M5E(-) 18GN / J1939 TERMINATING RESISTOR (7801M) CH13_39A / Figure 572 / DATALINK BASIC WITH LCT / WTEC FOR HYDRAULIC BRAKES (4100) WITH 2017 ISB ENGINE

13.81. AIR PARK BRAKE INTLK WITH HYDRAULIC BRAKES WITH F-2018 PROPANE / GASOLINE ENGINE, P. 63
Figure 573 AIR PARK BRAKE INTLK WITH HYDRAULIC BRAKES WITH F-2018 PROPANE / GASOLINE

Components: BODY CONTROLLER (1601); FUSE F1 (1011); GROUND SPLICE (1003B); RELAY (1013); SOLENOID (1031)
Wires (circuit gauge+color): A44 18GY; A44-GB 18GY; A44-GC 18WH; A44-GD 18GY; A44H 18GY; A44J 18GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.81. AIR PARK BRAKE INTLK WITH HYDRAULIC BRAKES WITH F-2018 PROPANE / GASOLINE ENGINE, P. 63 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 95885P 06APR21 / CHAPTER 13 AIR PARK BRAKE INTLK W/HYDRAULIC BRAKES W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 3 30 30 / 85 2 / 87A 5 / AIR PARK BRAKE RELAY (1013) 1 86 / A44J 18GY / FUSE F1 (1011) CH3_94B / AIR PARK BRAKE SOLENOID (1031) / J4-BLUE BODY CONTROLLER (1601) OUTPUT HIGH F3 SIGNAL / NOTE: CONNECTIONS FOR VEHICLES N/0508108-MTA FUSE BLOCK. / A44 18GY / A44H 18GY / A44-GB 18GY / A44-GD 18GY / A44-GC 18WH / GROUND SPLICE (1003B) CH3_95C / Figure 573 / AIR PARK BRAKE INTLK WITH HYDRAULIC BRAKES WITH F-2018 PROPANE / GASOLINE ENGINE

13.82. CITY HORN WITH 2017 ISB / 2021 B6.7 DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE, P. 64
Figure 574 CITY HORN WITH 2017 ISB / 2021 B6.7 DIESEL & WITH F-2018 PROPANE / GASOLINE

Components: CHASSIS (1700)
Wires (circuit gauge+color): M11-G 10WH; M11-G 14WH; M85-GA 16WH; M85-GC 16WH; M85-GD 16WH; M85-GE 16WH; M85A 16GY; M85J 16GY; M85K 16GY; M85L 16GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.82. CITY HORN WITH 2017 ISB / 2021 B6.7 DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE, P. 64 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 96259J 10AUG21 / CHAPTER 13 CITY HORN W/2017/2021 ISB/B6.7 DIESEL & W/F-2018-PROP/GAS-ENG / MJV0488 19AUG21 INITIAL PRODUCTION RELEASE. / PLATFORM/ FORWARD 16 CHASSIS (1700) / HORN (*8310/&8310A) A M85A M85J 16GY 16GY M85-GA M85-GC 16WH 16WH / M85K 16GY M85-GD 16WH / ELECTRIC HORN#1 (8311) / M85L 16GY / M85-GE 16WH / A B / A B / ELECTRIC HORN # 2 (8312) / M11-G 14WH M11-G 10WH / UPPER DASH GROUND STUD (2GA) / * W/DISC STYLE HORN SIGNAL & W/HORN ABOVE FRAME SIGNAL / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108-MTA FUSE BLOCK AND N/0508108-NOT MTA FUSE BLOCK. / Figure 574 / CITY HORN WITH 2017 ISB / 2021 B6.7 DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE

13.83. BENDIX FUSION OPTIONS 3.0, P. 64A
Figure 575 BENDIX FUSION OPTIONS 3.0

Components: CONNECTOR (1979B2); FR CAP/ELEC PANEL (10001); GROUND CIRCUIT (10003); PLATFORM (1702); PLATFORM (1703); PLATFORM (1703A); RESISTOR (19390)
Wires (circuit gauge+color): B125G 18GY; B125L 18GY; B152 18GY; B152A 18GY; B152E 18GY; C152D 18GY; C152E 18GY; C152H 18GY; C152K 18GY
See also sheets: CH13_65, CH3_43
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.83. BENDIX FUSION OPTIONS 3.0, P. 64A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 96289K 10OCT21 / CHAPTER 13 BENDIX FUSION OPTIONS 3.0 / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / 120 OHMS / TERMINATING RESISTOR (19390) / C5D(+) 20YL / C5D(-) 20GN / BENDIX FUSION 3 CONNECTOR (1979B2) / C5B(+) 22YL / C5B(-) 22GN / C5B(+) 22YL / C5E(-) 22GN / C152 0.5PK C11COG 0.5WH / GROUND CIRCUIT (10003) CH3_43 / C5C(+) 20YL C5C(-) 20GN / C5(+) 20YL / C5(-) 20GN / C5H(-) 20GN / C5H(+) 20YL / FR CAP/ELEC PANEL (10001) / B5B(+) 18YL / B5B(-) 18GN / B5(+) 18YL / B5(-) 18GN / B5A(-) 18GN / B5A(+) 18YL / B152 18GY / ELECT PANEL/ PLATFORM (1702) CH13_65 / ELECT PANEL/ PLATFORM (1703) CH13_65 / ELECT PANEL/ PLATFORM (1702) CH13_65 / LDW LEFT SPEAKER (+) (10079) / LDW LEFT SPEAKER (-) (10080) LDW RIGHT SPEAKER (+) (10081) / LDW RIGHT SPEAKER (-) (10082) NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / C152H 18GY C152D 18GY / C152K 18GY C152E 18GY / B152A 18GY B152E 18GY / B125L 18GY / B125G 18GY / ELECT PANEL/ PLATFORM (1703A) CH13_65 / ELECT PANEL/ PLATFORM (1703A) CH13_65 / Figure 575 / BENDIX FUSION OPTIONS 3.0

13.84. BENDIX FUSION OPTIONS 3.0 (CONT.), P. 65
Figure 576 BENDIX FUSION OPTIONS 3.0 (CONT.)

Components: DISABLE SW (10283); ELEC PANEL/ (10001); FWD CHASSIS (1700); PLATFORM (1702); PLATFORM (1703); PLATFORM (1703A); SW ILLUM (10399); UNIT (9548); ZVR SPLICE (10350B)
Wires (circuit gauge+color): A152V 18GY; A152X 18GY; B152 18GY; B152A 18GY; B152E 18GY; B152G 18GY; B152L 18GY; B62-BR 18DKBL; B62-GBR 18WH; B67-G 18WH; B67-GA 18WH
See also sheets: CH13_66, CH7_63
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.84. BENDIX FUSION OPTIONS 3.0 (CONT.), P. 65 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090664 NO. RELEASE NO. 96289K 10OCT21 / CHAPTER 13 BENDIX FUSION OPTIONS 3.0 (CONT.) / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/ PLATFORM (1702) 18 / A152X 18GY ELEC PANEL/ PLATFORM (1703) B12 / B5B(+) 18YL B5B(-) 18GN / B152 18GY / A5T(+) 18YL / A5T(-) 18GN / A5AK(+) 18YL / B152A 18GY / ELEC PANEL/ PLATFORM (1703A) / A152V 18GY / DRIVER INTERFACE UNIT (9548) / PLATFORM/ FWD CHASSIS (1700) CH13_66,67 / FR CAP ELEC PANEL/ (10001) CH13_64A / B5(+) 18YL / B5(-) 18GN / B5A(+) 18YL / B5A(-) 18GN / FR CAP ELEC PANEL/ (10001) CH13_64A / A5AK(-) 18LTGN / B152E 18GY / B152L 18GY / B152G 18GY / FR CAP ELEC PANEL/ (10001) CH13_64A / B67-G 18WH B67-GA 18WH / B62-BR 18DKBL B62-GBR 18WH / LANE DEPARTURE WARNING ENABLE/ DISABLE SW (10283) 2 / SW ILLUM (10399) CH7_63 / ZVR SPLICE (10350B) CH3_95N / Figure 576 / BENDIX FUSION OPTIONS 3.0 (CONT.)

13.85. BENDIX AIR EC 80 WITH BENDIX FUSION 3.0 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 66
Figure 577 BENDIX AIR EC 80 WITH BENDIX FUSION 3.0 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: ELEC PANEL (1702); FUSE F16 (1011); FUSION 3.0 (8904); PLATFORM (1700/1700); RESISTOR (1658); STUD (4037Z)
Wires (circuit gauge+color): A13F 18PK; A152Y 18RD; A67-GA 18WH; A94-GD 12WH; M13AA 20PK; M67-GA 20WH
See also sheets: CH13_65, CH3_95
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.85. BENDIX AIR EC 80 WITH BENDIX FUSION 3.0 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 66 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 96289K 08OCT21 / CHAPTER 13 BENDIX AIR EC 80 W/BENDIX FUSION 3.0 W/2017/2021 ISB/B6.7-DIESEL ENG / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / FWD CHASSIS/ PLATFORM (1700/1700) 55 / J1939 500K TERMINATING RESISTOR (1658) A / J1939(+) 7 / M5E(+) 20YL / M5F(+) 18YL / J1939(-) 4 / M5F(-) 18GN / BENDIX FUSION 3.0 (8904) / M5D(+) 18YL / M5E(-) 20GN / OHMS 120 / A5T(-) 18GN / A5T(+) 18YL / M5D(-) 18GN / BATT 1 / M13AA 20PK / M67-GA 20WH / GROUND 8 / A152Y 18RD / A67-GA 18WH / A94-GD 12WH / FUSE F16 (1011) CH3_94B / A13F 18PK / NOTE: CONNECTIONS FOR VEHICLE N/0508108-NOT MTA FUSE BLOCK. / GROUND STUD (4037Z) CH3_95 / PLATFORM/ ELEC PANEL (1702) CH13_65 / Figure 577 / BENDIX AIR EC 80 WITH BENDIX FUSION 3.0 WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

13.86. BENDIX AIR EC 80 WITH BENDIX FUSION 3.0 WITH F-2018 PROPANE / GASOLINE ENGINE, P. 67
Figure 578 BENDIX AIR EC 80 WITH BENDIX FUSION 3.0 WITH F-2018 PROPANE / GASOLINE ENGINE

Components: ELEC PANEL (1702); FUSE F16 (1011); FUSION 3.0 (8904); PLATFORM (1700/1700); RESISTOR (1658); STUD (4037Z)
Wires (circuit gauge+color): A13F 18PK; A152Y 18RD; A67-GA 18WH; A94-GD 12WH; M13AB 20PK; M67-GB 20WH
See also sheets: CH13_65, CH3_95
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.86. BENDIX AIR EC 80 WITH BENDIX FUSION 3.0 WITH F-2018 PROPANE / GASOLINE ENGINE, P. 67 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 96289K 08OCT21 / CHAPTER 13 BENDIX AIR EC 80 W/BENDIX FUSION 3.0 W/F-2018-PROPANE/GASOLINE-ENG / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / FWD CHASSIS/ PLATFORM (1700/1700) 49 / J1939 500K TERMINATING RESISTOR (1658) A / J1939(+) 7 / M5E(+) 20YL / M5F(+) 18YL / J1939(-) 4 / M5F(-) 18GN / BENDIX FUSION 3.0 (8904) / M5D(+) 18YL / M5E(-) 20GN / OHMS 120 / A5T(-) 18GN / A5T(+) 18YL / M5D(-) 18GN / BATT 1 / M13AB 20PK / M67-GB 20WH / GROUND 8 / A152Y 18RD / A67-GA 18WH / A94-GD 12WH / FUSE F16 (1011) CH3_94B / A13F 18PK / NOTE: CONNECTIONS FOR VEHICLE N/0508108-NOT MTA FUSE BLOCK. / GROUND STUD (4037Z) CH3_95 / PLATFORM/ ELEC PANEL (1702) CH13_65 / Figure 578 / BENDIX AIR EC 80 WITH BENDIX FUSION 3.0 WITH F-2018 PROPANE / GASOLINE ENGINE

13.87. INTELLIPARK WIRING & PVM CONNECTIONS WITH F-2017 ISB ENGINE, P. 68
Figure 579 INTELLIPARK WIRING & PVM CONNECTIONS WITH F-2017 ISB ENGINE

Components: CONNECTION (1101); CONNECTOR (1826); FUSE F28 (1011); FUSE F6 (1011); PLATFORM (1701); SENSOR (1100); SPLICE (1003B)
Wires (circuit gauge+color): A40A1 18GY; A40B1 18GY; A40C1 18GY; A44K-G 14WH; A44K-G1 14WH; A44KA 14PK; A44KB 14RD; A44KB1 14RD; A59A1 18GY; A59B1 18GY; A59C1 18GY; K40A 18GY; K40B 18GY; K40C 18GY; K59A 18GY; K59B 18GY; K59C 18GY
See also sheets: CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.87. INTELLIPARK WIRING & PVM CONNECTIONS WITH F-2017 ISB ENGINE, P. 68 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 96289K 08OCT21 / CHAPTER 13 INTELLIPARK WIRING & PVM CONNECTIONS W/F-2017-ISB-ENG / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / PVM PRESSURE SENSOR (1100) / K40C 18GY K40A 18GY / A40C1 18GY A40A1 18GY / ENGINE/ PLATFORM (1701) 51 / K59A 18GY / A59A1 18GY / PVM SOLENOID CONNECTION (1101) / DECU J1 CONNECTOR (1826) / NOTE: CONNECTIONS FOR VEHICLE N/0508108-NOT FUSE BLOCK. / FUSE F28 (1011) CH3_94B FUSE F6 (1011) CH3_94 GROUND SPLICE (1003B) CH3_95C / K59B 18GY / K59C 18GY / K40B 18GY / A59B1 18GY / A59C1 18GY / A44KA 14PK / A44KB1 14RD / A44KB 14RD / A44K-G 14WH / A44K-G1 14WH / A40B1 18GY / Figure 579 / INTELLIPARK WIRING & PVM CONNECTIONS WITH F-2017 ISB ENGINE

13.88. INTELLIPARK WIRING & PVM CONNECTIONS WITH F-2017 ISB ENGINE
Figure 580 INTELLIPARK WIRING & PVM CONNECTIONS WITH F-2017 ISB ENGINE

Components: CONNECTOR (1826); CONNECTOR (1827); CONNECTOR (1829); ENGINE (1701); FUSE F13 (1011); FUSE F6 (1011); GROUND SPLICE (1003); GROUND SPLICE (1003B)
Wires (circuit gauge+color): A44K-G 14WH; A44K-G2 14WH; A44K-GA 14WH; A44KB 14RD; A44KB2 14RD; A44KC 14RD
See also sheets: CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 13.88. INTELLIPARK WIRING & PVM CONNECTIONS WITH F-2017 ISB ENGINE (CONT.), P. 69 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090664 NO. 96289K 08OCT21 / CHAPTER 13 INTELLIPARK WIRING & PVM CONNECTIONS W/F-2017-ISB-ENG(CONT.) / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / A44KB2 14RD / A44K-G2 14WH / PHMI DISPLAY CONNECTOR (1829) / A5BW(-) 18GN / DECU J2 CONNECTOR (1827) / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK / A44KB 14RD / GROUND SPLICE (1003B) CH3_95C / FUSE F6 (1011) CH3_94 / PLATFORM/ ENGINE (1701) CH3_97P / A44KC 14RD / A5BH(+) 18YL / FUSE F13 (1011) CH3_94 / GROUND SPLICE (1003) CH3_95A / A44K-GA 14WH / A5BZ(+) 18YL / A44K-G 14WH / A5B(-) 18GN / A5B(+) 18YL / A5BL(-) 18GN / A5CB(+) 18YL / A5C(-) 18GN / DECU J1 CONNECTOR (1826) CH3_97P / Figure 580 / INTELLIPARK WIRING & PVM CONNECTIONS WITH F-2017 ISB ENGINE

Figure 581 EMERGENCY EXIT BUZZER

Components: A/C RELAY (10308-R4); ALARM (10299); BUZZER RELAY (10310-R4); CHECK MATE MODULE (10212); CHILD MONITOR RELAY (10308-R5); DIODE B3-C (10304); DIODE B3-P (10304); DIODE B6-J (10303); DIODE B6-U (10303); DOME LT (84331); DRIVER ALARM (11629B); ELEC PANEL/L BODY (10400); ELEC PANEL/L BODY (10401); ELEC PANEL/PLATFORM (1702); FUSE B6-R (10303); FUSE B9-E (10302); PLATFORM (1702); SPLICE (10204); TWO MIN TIMER NC RELAY (11303)
Wires (circuit gauge+color): B11-GAL 16WH; B11-GAL 18WH; B11-GAM 18WH; B117 18GY; B117-JZ 16LTGN; B117A 18GY; B117D 16GY; B117D 18GY; B117E 18GY; B117F 18GY; B117J 18LTGN; B117L 18GY; B117SD 18GY; B125C 18GY; B125F 18GY; B125PB 18GY; B126 18GY; B129 18GY; B12A 18LTBL; B12W 18LTBL; B130 18GY; B131-GS 16WH; B14W 18RD; B63-GA 14WH
See also sheets: CH14_02, CH14_03, CH14_15, CH14_19, CH14_24, CH14_28, CH16_26, CH18_03, CH18_09, CH18_13, CH18_21, CH18_25, CH18_36, CH18_37, CH3_14, CH3_16, CH7_67, CH8_10, CH8_17
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / EMERGENCY EXIT SYSTEM (CHAPTER 14) / 14.1. EMERGENCY EXIT BUZZER EFFECTS, P. 1 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1133 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 14JAN21 / CHAPTER 14 EMERGENCY EXIT BUZZER EFFECTS / MJV0488 19NOV21 CIRC B117SD WAS B117 AT CAV J OF R/D 10204. / B12W 18LTBL / B117F B117F 18GY 18GY / B117E 18GY / B129 18GY / B126 18GY / B117SD 18GY / EMER EXIT BUZZER SPLICE (10204) A / DRIVERS ALARM (10299) A / ELEC PANEL/L BODY (10401) CH14_24 REAR ROW EMER DOME LT (84331) CH8_10 / B11-GAM 18WH / FUSE B6-R (10303) CH3_14 FUSE B9-E (10302) CH3_16 / B12A 18LTBL / B117D B117D 18GY 18GY B117A 18GY / B125C 18GY B125F 18GY / B11-GAL 18WH / B117 18GY / B14W 18RD / B131-GS 16WH / B130 18GY B125PB 18GY / B63-GA 14WH / B130 18GY / B117J 18LTGN B117L 18GY / B117-JZ 16LTGN / B117D 16GY / B11-GAL 16WH / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 581 / EMERGENCY EXIT BUZZER

14.2. EMERGENCY EXIT BUZZER EFFECTS (CONT.), P. 1A
Figure 582 EMERGENCY EXIT BUZZER EFFECTS (CONT.)

Components: AIR COMPRESSOR RELAY (10308); ALARM (10299); ALARM RELAY (10308); BUZZER RELAY (10310); BUZZER SPLICE (10204); CHECK MATE MODULE (10212); DIODE D61 (10306); DIODE D67 (10306); DIODE D73 (10307); DIODE D79 (10307); ELEC PANEL/L BODY (10400A/B); EXIT RELAY (1020); FUSE F49 (10305); FUSE F83 (10307); L BODY (10401A/B); LT RELAY (10311); OPEN INDICATION (1702); PTI ISOLATION RELAY (10309-A4); REAR DOOR SPLICE (10386); REAR ROW DOME LT RELAY (10311); REAR ROW EMER DOME LT (84331); STEP WARMER RELAY (10312); TWO MIN TIMER NC RELAY (11303)
Wires (circuit gauge+color): B11-GAL 18WH; B11-GAM 18WH; B117 18GY; B117A 18GY; B117D 16GY; B117D 18GY; B117E 18GY; B117F 18GY; B117J 18LTGN; B117JZ 16LTGN; B117L 18GY; B117M 18GY; B125C 18GY; B125D 18GY; B125F 18GY; B125PB 18GY; B126 18GY; B129 18GY; B12A 18LTBL; B12W 18LTBL; B130 18GY; B131-GS 16WH; B14W 18RD; B63-GA 14WH; B63-GM 18WH; B63C 16DKBL
See also sheets: CH14_03, CH14_15, CH14_24, CH14_28, CH18_21, CH18_25, CH18_53
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.2. EMERGENCY EXIT BUZZER EFFECTS (CONT.), P. 1A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090665 NO. RELEASE NO. 95885P 25MAR21 / CHAPTER 14 EMERGENCY EXIT BUZZER EFFECTS (CONT.) DRIVERS ALARM (10299) A / MJV0488 19NOV21 ADDED CIRC B63C IN CAV F AT R/D 10204. / B12W 18LTBL / B117F B117F 18GY 18GY / B117JZ 16LTGN B117E 18GY / DIODE D79 (10307) B3 A3 / B129 18GY / B126 18GY / ELEC PANEL/ L BODY (10401A/B) CH14_24 REAR ROW EMER DOME LT (84331) CH8_9C DIODE D67 (10306) B117J B117M 18LTGN A3 B3 18GY B117L 18GY / B117 18GY / EMER EXIT BUZZER SPLICE (10204) A / B11-GAM 18WH / FUSE F83 (10307) CH3_94Q FUSE F49 (10305) CH3_94L / B12A 18LTBL / B117D 18GY B117A 18GY / B125F 18GY B125C 18GY / B117D 16GY B63C 16DKBL B130 18GY B125PB 18GY B130 18GY B117D 16GY B125PB 18GY B125C 18GY / B63-GM 18WH / B11-GAL 18WH / B117 18GY / EMER EXIT RELAY (1020) CH14_2A / DIODE D73 (10307) B1 A1 / B14W 18RD / B131-GS 16WH / B125D 18GY / B63-GA 14WH / Figure 582 / EMERGENCY EXIT BUZZER EFFECTS (CONT.)

14.3. EMERGENCY EXIT RELAY, P. 2
Figure 583 EMERGENCY EXIT RELAY

Components: ALARM (10299); COIL SIGNAL-ZVR RELAY (1009); CONTROLLER (1600); PLATFORM (1702); RELAY (1012-R4); SPLICE (1005)
Wires (circuit gauge+color): A117 18GY; A117C 18GY; A117E 18GY; A9FA 18GY; A9J 18GY; B117 18GY
See also sheets: CH14_01, CH3_03, CH3_58, CH6_22
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.3. EMERGENCY EXIT RELAY, P. 2 / EMERGENCY EXIT RELAY / CHAPTER 14 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 14JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J3 - RED BODY CONTROLLER (1600) CH6_22 / A9J 18GY / ELEC PANEL /PLATFORM (1702) 76 / A117E 18GY / EMER EXIT RELAY (1012-R4) / RED FLASHER / EMER EXIT BUZZER AND LTS / @A117 18GY / %A117 18GY / ZVR SPLICE (1005) CH3_58 / A9FA 18GY / A117C 18GY / COIL SIGNAL-ZVR RELAY (1009) CH3_03 / B117 18GY / DRIVERS ALARM (10299) CH14_01 / % W/RED OVERRIDE SPLICE W/HOT ALL TIME @ W/RED OVERRIDE SPLICE ONLY / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 583 / EMERGENCY EXIT RELAY

14.4. EMERGENCY EXIT RELAY (CONT.), P. 2A
Figure 584 EMERGENCY EXIT BUZZER EFFECTS (CONT.)

Components: BUZZER SPLICE (10204); J3 - RED BODY CONTROLLER (1600); PLATFORM (1702); RELAY (1020); SPLICE (1005); ZVR RELAYS (1009)
Wires (circuit gauge+color): A117 18GY; A117C 18GY; A117E 18GY; A9FA 18GY; A9J 18GY; B117 18GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.4. EMERGENCY EXIT RELAY (CONT.), P. 2A / CHAPTER 14 EMERGENCY EXIT RELAY (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090665 NO. RELEASE NO. 95885P 25MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J3 - RED BODY CONTROLLER (1600) / A9J 18GY / COIL SIGNAL ZVR RELAYS (1009) CH3_94A / A117C 18GY / 18GY B117 / 1 86 / 87A 4 A9FA 18GY / 85 2 / EMER EXIT RELAY (1020) / RED FLASHER / EMER EXIT BUZZER AND LTS / A117 18GY A117 18GY / ZVR SPLICE (1005) CH3_95M / A117E 18GY / ELEC PANEL/ PLATFORM (1702) / EMER EXIT BUZZER SPLICE (10204) CH14_1A / RED OVERRIDE SPLICE ONLY / RED OVERRIDE SPLICE W/HOT ALL TIME / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 584 / EMERGENCY EXIT BUZZER EFFECTS (CONT.)

14.5. KICK OUT WINDOW WITHOUT LIGHT SECT 1 TO 8 LEFT BODY, P. 3
Figure 585 KICK OUT WINDOW WITHOUT LIGHT SECT 1 TO 8 LEFT BODY

Components: BUZZER SPLICE (10204); L BODY (10400A/10400B); SPLICE (10419); SPLICE (10421); WINDOW SPLICE (10713)
Wires (circuit gauge+color): B126 18GY; E126-GA 18WH; E126-GB 16WH; E126-GC 16WH; E126-GD 16WH; E126-GE 16WH; E126-GF 16WH; E126-GH 16WH; E126-GJ 16WH; E126-GK 16WH; E126A 18GY; E126B 18GY; E126C 16GY; E126D 16GY; E126E 16GY; E126F 16GY; E126H 16GY; E126J 16GY; E126K 16GY; E126L 16GY
See also sheets: CH14_01, CH14_08, CH3_55
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.5. KICK OUT WINDOW WITHOUT LIGHT SECT 1 TO 8 LEFT BODY, P. 3 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1133 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / CHAPTER 14 KICK OUT WINDOW N/LIGHT SECTION 1 TO 8 W/LEFT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / *E126C 16GY @E126D 16GY #E126E 16GY %E126F 16GY W/12 WINDOW @E126D 16GY &E126H 16GY **E126J 16GY @@E126K 16GY ##E126L 16GY / KICK OUT WINDOW SECTION (*10424, @10425, #10426, %10427) B / KICK OUT WINDOW SPLICE (10713) CH14_08,09 / KICK OUT WINDOW SPLICE (10421) A / B126 18GY / E126A 18GY / KICK OUT WINDOW SECTION (&10428, **10429, @@10430, ##10431, @10425) B / KICK OUT WINDOW ALARM SW / KICK OUT WINDOW ALARM SW / E126B 18GY / EMER EXIT BUZZER SPLICE (10204) CH14_01,1A KICK OUT WINDOW SECTION (*10424,@10425, #10426, %10427) A / GROUND SPLICE (10419) CH3_55 / ELEC PANEL/ L BODY (10400A/10400B) C6 / KICK OUT WINDOW SECTION (&10428, **10429, @@10430, ##10431, @10425) A / Figure 585 / KICK OUT WINDOW WITHOUT LIGHT SECT 1 TO 8 LEFT BODY

14.6. KICK OUT WINDOW WITHOUT LIGHT SECT 9 TO 13 LEFT BODY, P. 4
Figure 586 KICK OUT WINDOW WITHOUT LIGHT SECT 9 TO 13 LEFT BODY

Components: BUZZER SPLICE (10204); K/O WINDOW (10514); L BODY (10400A/10400B); SPLICE (10419); SPLICE (10421); WINDOW SPLICE (10713)
Wires (circuit gauge+color): B126 18GY; E126-GA 18WH; E126-GD 16WH; E126-GL 16WH; E126-GM 16WH; E126-GN 16WH; E126-GP 16WH; E126-GR 16WH; E126A 18GY; E126B 18GY; E126C 18GY; E126E 16GY; E126M 16GY; E126N 16GY; E126P 16GY; E126R 16GY; E126T 16GY
See also sheets: CH14_01, CH14_08, CH14_13, CH3_55
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.6. KICK OUT WINDOW WITHOUT LIGHT SECT 9 TO 13 LEFT BODY, P. 4 / CHAPTER 14 KICK OUT WINDOW N/LIGHT SECTION 9 TO 13 W/LEFT BODY / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 14JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / KICKOUT WINDOW SPLICE (10421) A / E126C 18GY ##E126-GD 16WH *E126-GL *E126-GL 16WH 16WH @E126-GM 16WH #E126-GN 16WH %E126-GP 16WH / E126B 18GY ##E126E 16GY *E126M 16GY @E126N 16GY #E126P 16GY %E126R 16GY / KICK OUT WINDOW SECTION (*10432/@10433/ #10434/%10435, ##10426) / EMER EXIT BUZZER SPLICE (10204) CH14_01,1A KICK OUT WINDOW SECTION (*10432/@10433/ KICK OUT #10434/%10435, ##10426) WINDOW ALARM SW / B126 18GY / &E126T 16GY / KICK OUT WINDOW ALARM SW / KICK OUT WINDOW SECTION (&10436) B / &E126-GR 16WH / E126-GA E126-GA 18WH 18WH / * KICK OUT SECTION 9 @ KICK OUT SECTION 10 # KICK OUT SECTION 11 % KICK OUT SECTION 12 & KICK OUT SECTION 13 ## KICK OUT SECTION 03 / KICK OUT WINDOW SECTION (&10436) A / E126A 18GY / KICK OUT WINDOW SPLICE (10713) CH14_08,09 / ELEC PANEL/ L BODY (10400A/10400B) C6 / GROUND SPLICE (10419) CH3_55 / W/12 WINDOW / W/12 WINDOW / SPLICE REAR K/O WINDOW (10514) CH14_13 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 586 / KICK OUT WINDOW WITHOUT LIGHT SECT 9 TO 13 LEFT BODY

14.7. KICK OUT WINDOW WITH LIGHT SECT 1 TO 4 LEFT BODY, P. 5
Figure 587 KICK OUT WINDOW WITH LIGHT SECT 1 TO 4 LEFT BODY

Components: CLEARANCE LIGHT (10420); GROUND SPLICE (10419); SPLICE (10423)
Wires (circuit gauge+color): E143-GA 18WH; E143-GB 18WH; E143-GC 18WH; E143-GD 18WH; E143-GE 18WH; E143A 18DKBL; E143B 18DKBL; E143C 18DKBL; E143D 18DKBL; E143E 18DKBL
See also sheets: CH3_55, CH7_55
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.7. KICK OUT WINDOW WITH LIGHT SECT 1 TO 4 LEFT BODY, P. 5 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1133 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / CHAPTER 14 KICK OUT WINDOW W/LIGHT SECTION 1 TO 4 W/LEFT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / *E143-GB 18WH @E143-GC 18WH #E143-GD 18WH %E143-GE 18WH / *E143B 18DKBL @E143C 18DKBL #E143D 18DKBL %E143E 18DKBL / E143A 18DKBL / GROUND SPLICE (10419) CH3_55 / SPLICE DIRECTIONAL/ CLEARANCE LIGHT (10420) CH7_55 / EMER EXIT LT SPLICE (10423) A / EMER EXIT LT (*10439 / @10440 / #10441 / %10442) A / E143-GA 18WH / * KICK OUT SECTION 1 @ KICK OUT SECTION 2 # KICK OUT SECTION 3 % KICK OUT SECTION 4 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 587 / KICK OUT WINDOW WITH LIGHT SECT 1 TO 4 LEFT BODY

14.8. KICK OUT WINDOW WITH LIGHT SECT 5 TO 8 LEFT BODY, P. 6
Figure 588 KICK OUT WINDOW WITH LIGHT SECT 5 TO 8 LEFT BODY

Components: CL LT SPLICE (10420); SPLICE (10419); SPLICE (10423)
Wires (circuit gauge+color): E143-GA 18WH; E143-GF 18WH; E143-GH 18WH; E143-GJ 18WH; E143-GK 18WH; E143A 18DKBL; E143F 18DKBL; E143H 18DKBL; E143J 18DKBL; E143K 18DKBL
See also sheets: CH3_55, CH7_55
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.8. KICK OUT WINDOW WITH LIGHT SECT 5 TO 8 LEFT BODY, P. 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 14JAN21 / CHAPTER 14 KICK OUT WINDOW W/LIGHT SECTION 5 TO 8 W/LEFT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / EMER EXIT LT (*10443 / @10444 / #10445 / %10446) A / EMER EXIT LT SPLICE (10423) A / *E143F 18DKBL @E143H 18DKBL #E143J 18DKBL %E143K 18DKBL *E143-GF 18WH @E143-GH 18WH #E143-GJ 18WH %E143-GK 18WH / E143-GA 18WH / GROUND SPLICE (10419) CH3_55 / DIRECTIONAL/ CL LT SPLICE (10420) CH7_55 / E143A 18DKBL / * KICK OUT SECTION 5 @ KICK OUT SECTION 6 # KICK OUT SECTION 7 % KICK OUT SECTION 8 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 588 / KICK OUT WINDOW WITH LIGHT SECT 5 TO 8 LEFT BODY

14.9. KICK OUT WINDOW WITH LIGHT SECT 9 TO 13 LEFT BODY, P. 7
Figure 589 KICK OUT WINDOW WITH LIGHT SECT 9 TO 13 LEFT BODY

Components: CL LT SPLICE (10420); SPLICE (10419); SPLICE (10423)
Wires (circuit gauge+color): E143-GA 18WH; E143-GL 18WH; E143-GM 18WH; E143-GN 18WH; E143-GP 18WH; E143-GR 18WH; E143A 18DKBL; E143L 18DKBL; E143M 18DKBL; E143N 18DKBL; E143P 18DKBL; E143R 18DKBL
See also sheets: CH3_55, CH7_55
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.9. KICK OUT WINDOW WITH LIGHT SECT 9 TO 13 LEFT BODY, P. 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 14JAN21 / CHAPTER 14 KICK OUT WINDOW W/LIGHT SECTION 9 TO 13 W/LEFT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / EMER EXIT LT SPLICE (10423) A / GROUND SPLICE (10419) CH3_55 / EMER EXIT LT (**10451) A / *E143-GL 18WH @E143-GM 18WH #E143-GN 18WH %E143-GP 18WH / **E143R 18DKBL **E143-GR 18WH / EMER EXIT LT (*10447 / @10448 / #10449 / %10450) A / *E143L 18DKBL @E143M 18DKBL #E143N 18DKBL %E143P 18DKBL / * KICK OUT SECTION 9 @ KICK OUT SECTION 10 # KICK OUT SECTION 11 % KICK OUT SECTION 12 ** KICK OUT SECTION 13 / E143A 18DKBL / E143-GA 18WH / DIRECTIONAL/ CL LT SPLICE (10420) CH7_55 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 589 / KICK OUT WINDOW WITH LIGHT SECT 9 TO 13 LEFT BODY

14.10. KICK OUT WINDOW WITHOUT 3 IN RED LIGHT SECT 1 TO 6 RIGHT BODY, P. 8
Figure 590 KICK OUT WINDOW WITHOUT 3 IN RED LIGHT SECT 1 TO 6 RIGHT BODY

Components: GROUND SPLICE (10702); REAR CAP (10406); RIGHT BODY (10700); WINDOW SPLICE (10421); WINDOW SPLICE (10713)
Wires (circuit gauge+color): D126B 18GY; E126B 18GY; F126 16GY; F126-G 18WH; F126-GA 16WH; F126-GB 16WH; F126-GC 16WH; F126-GD 16WH; F126-GE 16WH; F126-GF 16WH; F126A 16GY; F126B 16GY; F126B 18GY; F126C 16GY; F126D 16GY; F126E 16GY; F126F 16GY
See also sheets: CH14_03, CH3_53
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.10. KICK OUT WINDOW WITHOUT 3 IN RED LIGHT SECT 1 TO 6 RIGHT BODY, P. 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 14JAN21 / CHAPTER 14 KICK OUT WINDOW N/3 IN RED LIGHT SECTION 1 TO 6 W/RIGHT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / @F126B 16GY W/ 12,13 WINDOW @F126 16GY *F126A 16GY #F126C 16GY %F126-GD 16WH &F126-GE 16WH **F126-GF 16WH F126-G 18WH / *F126-GA 16WH @F126-GB 16WH #F126-GC 16WH / KICK OUT WINDOW SECTION (*10715/@10716 /#10717) A / KICK OUT WINDOW ALARM SW / KICK OUT WINDOW SECTION *10715/@10416/ #A10417) / D126B 18GY / F126B 18GY / %F126D 16GY &F126E 16GY **F126F 16GY / KICK OUT WINDOW SECTION (%10718/&10719 /**10720) / KICK OUT WINDOW ALARM SW / E126B 18GY KICK OUT WINDOW SECTION (%10718/&10719 /**10720) A / KICK OUT WINDOW SPLICE (10713) A / * KICK OUT SECTION 1 @ KICK OUT SECTION 2 # KICK OUT SECTION 3 % KICK OUT SECTION 4 & KICK OUT SECTION 5 ** KICK OUT SECTION 6 / KICK OUT WINDOW SPLICE (10421) CH14_03,04 / GROUND SPLICE (10702) CH3_53 / LEFT BODY/ REAR CAP (10406) C9 / REAR CAP RIGHT BODY (10700) A5 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 590 / KICK OUT WINDOW WITHOUT 3 IN RED LIGHT SECT 1 TO 6 RIGHT BODY

14.11. KICK OUT WINDOW WITHOUT 3 IN RED LIGHT SECT 7 TO 13 RIGHT BODY, P. 9
Figure 591 KICK OUT WINDOW WITHOUT 3 IN RED LIGHT SECT 7 TO 13 RIGHT BODY

Components: GROUND SPLICE (10702); R BODY (10700); REAR CAP (10406); SPLICE (10713); WINDOW SPLICE (10421)
Wires (circuit gauge+color): D126B 18GY; E126B 18GY; F126-G 18WH; F126-GH 16WH; F126-GJ 16WH; F126-GK 16WH; F126-GL 16WH; F126-GM 16WH; F126-GN 16WH; F126-GP 16WH; F126B 18GY; F126H 16GY; F126J 16GY; F126K 16GY; F126L 16GY; F126M 16GY; F126N 16GY; F126P 16GY
See also sheets: CH14_03, CH3_53
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.11. KICK OUT WINDOW WITHOUT 3 IN RED LIGHT SECT 7 TO 13 RIGHT BODY, P. 9 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / *F126H 16GY @F126J 16GY #F126K 16GY / *F126-GH 16WH @F126-GJ 16WH #F126-GK 16WH %F126-GL 16WH &F126-GM 16WH **F126-GN 16WH / @@F126-GP 16WH F126-G 18WH / KICK OUT WINDOW SECTION (*10721/@10722 /#10723) B / KICK OUT WINDOW ALARM SW / KICK OUT WINDOW SPLICE (10713) / F126B 18GY / %F126L 16GY &F126M 16GY **F126N 16GY @@F126P 16GY / KICK OUT WINDOW SECTION (%10724/&10725/ **10726) B / KICK OUT WINDOW ALARM SW / GROUND SPLICE (10702) CH3_53 / KICK OUT WINDOW SPLICE (10421) CH14_03,04 / L BODY/ REAR CAP (10406) C9 E126B 18GY KICK OUT WINDOW SECTION (*10721/@10722/ #10723) A / D126B 18GY / KICK OUT WINDOW SECTION (%10724/&10725/ **10726) A / KICK OUT WINDOW SECTION (@@10727) A / KICK OUT WINDOW SECTION (@@10727B) B / KICK OUT WINDOW ALARM SW / REAR CAP/ R BODY (10700) A5 / Figure 591 / KICK OUT WINDOW WITHOUT 3 IN RED LIGHT SECT 7 TO 13 RIGHT BODY

14.12. KICK OUT WINDOW WITH 3 IN RED LIGHT SECT 1 TO 6 RIGHT BODY, P. 10
Figure 592 KICK OUT WINDOW WITH 3 IN RED LIGHT SECT 1 TO 6 RIGHT BODY

Components: SPLICE (10702); SPLICE (10704); SPLICE (10714)
Wires (circuit gauge+color): F143 18DKBL; F143-G 18WH; F143-GA 18WH; F143-GB 18WH; F143-GC 18WH; F143-GD 18DKBL; F143-GE 18DKBL; F143-GF 18DKBL; F143A 18DKBL; F143B 18DKBL; F143C 18DKBL; F143D 18DKBL; F143E 18DKBL; F143F 18DKBL
See also sheets: CH3_53, CH7_39
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.12. KICK OUT WINDOW WITH 3 IN RED LIGHT SECT 1 TO 6 RIGHT BODY, P. 10 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / CHAPTER 14 KICK OUT WINDOW W/3 IN RED LIGHT SECTION 1 TO 6 W/RIGHT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / EMER EXIT LT SPLICE (10714) A / EMER EXIT LT (%10733/&10734/ **10735) A / F143 18DKBL *F143A 18DKBL @F143B 18DKBL #F143C 18DKBL %F143D 18DKBL &F143E 18DKBL **F143F 18DKBL *F143-GA 18WH @F143-GB 18WH #F143-GC 18WH / %F143-GD 18DKBL &F143-GE 18DKBL **F143-GF 18DKBL / * KICK OUT SECTION 1 @ KICK OUT SECTION 2 # KICK OUT SECTION 3 % KICK OUT SECTION 4 & KICK OUT SECTION 5 ** KICK OUT SECTION 6 / COMBINATION SPLICE (10704) CH7_39 / EMER EXIT LT (*10730/@10731/#10732) A / F143-G 18WH / GROUND SPLICE (10702) CH3_53 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 592 / KICK OUT WINDOW WITH 3 IN RED LIGHT SECT 1 TO 6 RIGHT BODY

14.13. KICK OUT WINDOW WITH 3 IN RED LIGHT SECT 7 TO 13 RIGHT BODY, P. 11
Figure 593 KICK OUT WINDOW WITH 3 IN RED LIGHT SECT 7 TO 13 RIGHT BODY

Components: GROUND SPLICE (10702); SPLICE (10704); SPLICE (10714)
Wires (circuit gauge+color): F143 18DKBL; F143-GA 18WH; F143-GH 18WH; F143-GJ 18WH; F143-GK 18WH; F143-GL 18WH; F143-GM 18WH; F143-GN 18WH; F143-GP 18WH; F143H 18DKBL; F143J 18DKBL; F143K 18DKBL; F143L 18DKBL; F143M 18DKBL; F143N 18DKBL; F143P 18DKBL
See also sheets: CH3_53, CH7_39
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.13. KICK OUT WINDOW WITH 3 IN RED LIGHT SECT 7 TO 13 RIGHT BODY, P. 11 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / CHAPTER 14 KICK OUT WINDOW W/3 IN RED LIGHT SECTION 7 TO 13 W/RIGHT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / EMER EXIT LT (*10736/@10737/#10738) A / EMER EXIT LT SPLICE (10714) A / F143 18DKBL *F143H 18DKBL @F143J 18DKBL #F143K 18DKBL %F143L 18DKBL &F143M 18DKBL **F143N 18DKBL / @@F143P 18DKBL / *F143-GH 18WH @F143-GJ 18WH #F143-GK 18WH / %F143-GL 18WH &F143-GM 18WH **F143-GN 18WH / @@F143-GP 18WH / EMER EXIT LT (@@10742) / F143-GA 18WH / GROUND SPLICE (10702) CH3_53 / COMBINATION SPLICE (10704) CH7_39 / EMER EXIT LT (%10739/&10740/ **10741) / Figure 593 / KICK OUT WINDOW WITH 3 IN RED LIGHT SECT 7 TO 13 RIGHT BODY

14.14. KICK OUT WINDOWS - ANY SECT 4 TO 6 LEFT BODY, P. 12
Figure 594 KICK OUT WINDOWS - ANY SECT 4 TO 6 LEFT BODY

Components: KICKOUT WINDOW (10514); KICKOUT WINDOW (10515); KICKOUT WINDOW (10516)
Wires (circuit gauge+color): E126-GC 18WH; E126-GE 16WH; E126-GF 16WH; E126-GH 16WH; E126-GR 18WH; E126D 18GY; E126E 18GY; E126F 16GY; E126H 16GY; E126J 16GY
See also sheets: CH14_13, CH14_14
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.14. KICK OUT WINDOWS - ANY SECT 4 TO 6 LEFT BODY, P. 12 / CHAPTER 14 KICK OUT WINDOWS-ANY SECTION 4-6 W/LEFT BODY / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / *E126F 16GY @E126H 16GY / %E126J 16GY / E126D 18GY / E126-GR 18WH / * KICK OUT SECTION 4 @ KICK OUT SECTION 5 % KICK OUT SECTION 6 / KICK OUT WINDOW (*10427/ @10428/ %10429) A / SPLICE RR KICKOUT WINDOW (10514) CH14_13 / SPLICE RR KICKOUT WINDOW (10514) CH14_13 / KICK OUT WINDOW (*10427/ @10428/ %10429) B / *E126-GE 16WH @E126-GF 16WH / %E126-GH 16WH / SPLICE REAR KICKOUT WINDOW (10515) A / E126E 18GY / SPLICE RR KICKOUT WINDOW (10516) CH14_14 / E126-GC 18WH / SPLICE RR KICKOUT WINDOW (10516) CH14_14 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / KICK OUT WINDOW ALARM SW / Figure 594 / KICK OUT WINDOWS - ANY SECT 4 TO 6 LEFT BODY

14.15. KICK OUT WINDOWS - ANY SECT 7 TO 9 LEFT BODY, P. 13
Figure 595 KICK OUT WINDOWS - ANY SECT 7 TO 9 LEFT BODY

Components: SPLICE (10419); SPLICE (10421); WINDOW (10514); WINDOW (10515)
Wires (circuit gauge+color): E126-GD 18WH; E126-GJ 16WH; E126-GK 16WH; E126-GL 16WH; E126-GR 18WH; E126C 18GY; E126D 18GY; E126K 16GY; E126L 16GY; E126M 16GY
See also sheets: CH14_04, CH14_12, CH3_55
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.15. KICK OUT WINDOWS - ANY SECT 7 TO 9 LEFT BODY, P. 13 / CHAPTER 14 KICK OUT WINDOWS-ANY SECTION 7-9 W/LEFT BODY / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / *E126K 16GY @E126L 16GY / %E126M 16GY / E126D 18GY / E126-GR 18WH / * KICK OUT SECTION 7 @ KICK OUT SECTION 8 % KICK OUT SECTION 9 / KICK OUT WINDOW (*10430/ @10431/ %10432) A / SPLICE RR KICK OUT WINDOW (10515) CH14_12 / SPLICE RR KICK OUT WINDOW (10515) CH14_12 GROUND SPLICE (10419) CH3_55 / KICK OUT WINDOW (*10430/ @10431/ %10432) B / *E126-GJ 16WH @E126-GK 16WH / %E126-GL 16WH / SPLICE REAR KICK OUT WINDOW (10514) A / E126C 18GY / KICK OUT WINDOW SPLICE (10421) CH14_04 / E126-GD 18WH / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / KICK OUT WINDOW ALARM SW / Figure 595 / KICK OUT WINDOWS - ANY SECT 7 TO 9 LEFT BODY

14.16. KICK OUT WINDOWS - ANY SECT 10 TO 12 LEFT BODY, P. 14
Figure 596 KICK OUT WINDOWS - ANY SECT 10 TO 12 LEFT BODY

Components: KICKOUT WINDOW (10515); KICKOUT WINDOW (10516)
Wires (circuit gauge+color): E126-GC 18WH; E126-GM 16WH; E126-GN 16WH; E126-GP 16WH; E126E 18GY; E126N 16GY; E126P 16GY; E126R 16GY
See also sheets: CH14_12
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.16. KICK OUT WINDOWS - ANY SECT 10 TO 12 LEFT BODY, P. 14 / CHAPTER 14 KICK OUT WINDOWS-ANY SECTION 7-9 W/LEFT BODY / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SPLICE REAR KICKOUT WINDOW (10516) A / *E126N 16GY @E126P 16GY / %E126R 16GY / E126E 18GY / E126-GC 18WH / * KICK OUT SECTION 10 @ KICK OUT SECTION 11 % KICK OUT SECTION 12 / KICK OUT WINDOW (*10433/ @10434/ %10435) A / SPLICE FR KICKOUT WINDOW (10515) CH14_12 / SPLICE FR KICKOUT WINDOW (10515) CH14_12 / KICK OUT WINDOW (*10433/ @10434/ %10435) B / *E126-GM 16WH @E126-GN 16WH / %E126-GP 16WH / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / KICK OUT WINDOW ALARM SW / Figure 596 / KICK OUT WINDOWS - ANY SECT 10 TO 12 LEFT BODY

14.17. ROOF HATCHES WITH ALARM SECTION 1 TO 11 LEFT BODY, P. 15
Figure 597 ROOF HATCHES WITH ALARM SECTION 1 TO 11 LEFT BODY

Components: BUZZER SPLICE (10204); GROUND SPLICE (10419); HATCH (10457B); L BODY (10400A/10400B); SPLICE PACK (10472)
Wires (circuit gauge+color): B129 18GY; E129-GA 18WH; E129-GB 18WH; E129-GC 18WH; E129-GD 18WH; E129-GE 18WH; E129-GF 18WH; E129-GH 18WH; E129-GJ 18WH; E129-GK 18WH; E129-GL 18WH; E129-GM 18WH; E129-GN 18WH; E129A 18GY; E129B 18GY; E129C 18GY; E129D 18GY; E129E 18GY; E129F 18GY; E129H 18GY; E129J 18GY; E129K 18GY; E129L 18GY; E129M 18GY; E129N 18GY
See also sheets: CH14_01, CH3_55
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.17. ROOF HATCHES WITH ALARM SECTION 1 TO 11 LEFT BODY, P. 15 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / CHAPTER 14 ROOF HATCHES W/ALARM SECTION 1 TO 11 W/LEFT BODY ELEC PANEL/ L BODY (10400A/10400B) C12 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ROOF HATCH SPLICE PACK (10472) A / **E129-GH 18WH @@E129-GJ 18WH ##E129-GK 18WH %%E129-GL 18WH &&E129-GM 18WH &%E129-GN 18WH / 129-G 16WH / B129 18GY / EMER EXIT BUZZER SPLICE (10204) CH14_01,1A / 129 16GY / E129-GA 18WH / GROUND SPLICE (10419) CH3_55 / ROOF HATCH ALARM SW / ROOF HATCH SECTION (*10457, @10458, #10459, %10460, &10461, **10462, @@10463, ##10464, %%10465, &&10466, &%10467) / ROOF HATCH (10457B) / Figure 597 / ROOF HATCHES WITH ALARM SECTION 1 TO 11 LEFT BODY

14.18. ROOF HATCHES WITH ALARM SECTION 11 TO 13 LEFT BODY, P. 16
Figure 598 ROOF HATCHES WITH ALARM SECTION 11 TO 13 LEFT BODY

Components: HATCH (10457B); L BODY (10400A/10400B); SPLICE (10204); SPLICE (10419); SPLICE PACK (10472)
Wires (circuit gauge+color): B129 18GY; E129-GA 18WH; E129-GN 18WH; E129-GP 18WH; E129-GR 18WH; E129A 18GY; E129N 18GY; E129P 18GY; E129R 18GY
See also sheets: CH14_01, CH3_55
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.18. ROOF HATCHES WITH ALARM SECTION 11 TO 13 LEFT BODY, P. 16 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / CHAPTER 14 ROOF HATCHES W/ALARM SECTION 11 TO 13 W/LEFT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ROOF HATCH SECT (*10467, @10468, #10469) 1 / B129 18GY / * FOR SECTION 11 @ FOR SECTION 12 # FOR SECTION 13 / *E129-GN 18WH @E129-GP 18WH #E129-GR 18WH / ROOF HATCH SPLICE PACK (10472) / GROUND SPLICE (10419) CH3_55 / ROOF HATCH (10457B) 1 129 16GY / 129-G 16WH / ELEC PANEL/ L BODY (10400A/10400B) / *E129N 18GY @E129P 18GY #E129R 18GY / E129-GA 18WH / ROOF HATCH ALARM SW / E129A 18GY / EMER EXIT BUZZER SPLICE (10204) CH14_01,1A / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 598 / ROOF HATCHES WITH ALARM SECTION 11 TO 13 LEFT BODY

14.19. ROOF HATCHES WITH ALARM AND STARTER INTERLOCK SECT 1 TO 4 AND 9
Figure 599 ROOF HATCHES WITH ALARM AND STARTER INTERLOCK SECT 1 TO 4 AND 9 TO

Components: EMER DOOR (10454); HATCH (10157B); L BODY (10400A/10400B); SPLICE (10422); SPLICE PACK (10382)
Wires (circuit gauge+color): B133F 18LTGN; E133A 18LTGN; E133C 18LTGN; E133D 18LTGN; E133E 18LTGN; E133F 18LTGN; E133H 18LTGN; E133N 18LTGN; E133P 18LTGN; E133R 18LTGN; E133T 18LTGN
See also sheets: CH14_19, CH15_25
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.19. ROOF HATCHES WITH ALARM AND STARTER INTERLOCK SECT 1 TO 4 AND 9 TO 12 LEFT BODY, P. 17 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / CHAPTER 14 ROOF HATCHES W/ALARM W/STARTER INTERLOCK SECTION 1 TO 4 AND 9 TO 12 W/LEFT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ROOF HATCH *10457,@10458, #10459,%10460, &10465,**10466, ROOF @@10467 HATCH ##10468) (10157B) 3 3 / *E133D 18LTGN @E133E 18LTGN #E133F 18LTGN %E133H 18LTGN &E133N 18LTGN **E133P 18LTGN @@E133R 18LTGN ##E133T 18LTGN / STARTER INTERLOCK SPLICE (10422) / STARTER INTERLOCK SW / 133 18LTGN / B133F 18LTGN / E133C 18LTGN / BODY GROUND / * FOR SECTION 1 & FOR SECTION 9 @ FOR SECTION 2 ** FOR SECTION 10 # FOR SECTION 3 @@ FOR SECTION 11 % FOR SECTION 4 ## FOR SECTION 12 / STARTER INTERLOCK SPLICE PACK (10382) CH15_25 / E133A 18LTGN / L SIDE EMER DOOR (10454) CH14_19,19A / ELEC PANEL/ L BODY (10400A/10400B) C11 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 599 / ROOF HATCHES WITH ALARM AND STARTER INTERLOCK SECT 1 TO 4 AND 9 TO 12 LEFT BODY

14.20. ROOF HATCHES WITH ALARM AND STARTER INTERLOCK SECT 5 TO 8 AND
Figure 600 ROOF HATCHES WITH ALARM AND STARTER INTERLOCK SECT 5 TO 8 AND 13 LEFT

Components: HATCH (10457B); L BODY (10400A/10400B); SPLICE (10422); SPLICE (10472); SPLICE PACK (10382)
Wires (circuit gauge+color): B133F 18LTGN; E129-GF 16WH; E129-GH 16WH; E129-GJ 16WH; E129-GK 16WH; E129F 18GY; E129H 18GY; E129J 18GY; E129K 18GY; E133A 18LTGN; E133J 18LTGN; E133K 18LTGN; E133L 18LTGN; E133M 18LTGN
See also sheets: CH15_25
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.20. ROOF HATCHES WITH ALARM AND STARTER INTERLOCK SECT 5 TO 8 AND 13 LEFT BODY, P. 18 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / CHAPTER 14 ROOF HATCHES W/ALARM W/STARTER INTERLOCK SECT 5 TO 8 AND 13 W/LEFT BODY / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / STARTER INTERLOCK SPLICE (10422) A / *E133J 18LTGN @E133K 18LTGN #E133L 18LTGN %E133M 18LTGN / E133A 18LTGN / ROOF HATCH (*10461, @10462, #10463, %10464, 3 133 18LTGN / ROOF HATCH (10457B) 3 / *E129F 18GY @E129H 18GY #E129J 18GY %E129K 18GY / 129 16GY / *E129-GF 16WH @E129-GH 16WH #E129-GJ 16WH %E129-GK 16WH / 129-G 16WH / * FOR SECTION 5 @ FOR SECTION 6 # FOR SECTION 7 % FOR SECTION 8 / STARTER INTERLOCK SPLICE PACK (10382) CH15_25 / STARTER NTERLOCK SW / ROOF HATCH SW / BODY GROUND / ELEC PANEL/ L BODY (10400A/10400B) C11 / B133F 18LTGN / ROOF HATCH SPLICE (10472) / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 600 / ROOF HATCHES WITH ALARM AND STARTER INTERLOCK SECT 5 TO 8 AND 13 LEFT BODY

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 641 | printed page 601 | section 14.21
14.21. LEFT SIDE EMERGENCY DOOR, P. 19
Figure 601 LEFT SIDE EMERGENCY DOOR

Components: BUZZER (10204); DIODE B6-J (10303); DOOR (10454*); DOOR SW (10798); DOOR SW (10799); FUSE A1-J (10305); FUSE B6-R (10303); L BODY (10400); OPTION (10380); REAR CAP (10405); SED ALARM (10455**); SED LT (10456*/##10456); SPLICE (10419); SPLICE (10422); SW BOX (10177); VANDAL LOCK (10797)
Wires (circuit gauge+color): B117E 18GY; B12J 18LTBL; B143 18DKBL; B14J 18RD; D12C 18LTBL; D130C 18GY; E12A 18BK; E12B 18BK; E12B 18LTBL; E12C 18BK; E12C 18LTBL; E12D 18BK; E12D 18DKBL; E130-GA 18WH; E130B 18GY; E130C 18GY; E130D 18GY; E130E 18GY; E133C 18LTGN; E143-GV 18WH; E143V 18DKBL
See also sheets: CH14_01, CH14_17, CH14_20, CH14_28, CH3_14, CH3_15, CH3_55, CH7_66
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.21. LEFT SIDE EMERGENCY DOOR, P. 19 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / LEFT SIDE EMERGENCY DOOR / CHAPTER CHAPTER CHAPTER 14 14 14 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / L BODY/ REAR CAP #E12C (10405) 18LTBL A1 #E12A 18BK E12C 18BK E12C 18LTBL / ELEC PANEL/ L BODY (10400) C8 / 130-G 18WH / SIDE EMER DOOR VANDAL LOCK (10797) A @133A 18LTGN / E130E 18GY / REAR DOOR SW BOX (10177) CH14_20,21 / SIDE EMER DOOR SW (10799) A / SIDE EMER DOOR (10454*) A / SIDE EMER SIDE EMER DOOR SW DOOR SW (10798) A / SED ALARM (10455**) A / SED LT (10456*/##10456) A A **E143V 18DKBL / B117E 18GY / DIODE B6-J (10303) CH14_28 FUSE B6-R (10303) CH3_14 EMER EXIT BUZZER (10204) CH14_01 / E12D 18BK / E12B 18BK E12B 18LTBL #E130C 18GY E130B 18GY / E130C 18GY / 130 18GY / STARTER INTERLOCK SPLICE (10422) CH14_17 / **E143-GV 18WH / D130C 18GY / D12C 18LTBL / B12J 18LTBL / STARTER INTERLOCK SW / @E133C 18LTGN / E130D 18GY / E130-GA 18WH / @133 18LTGN / %B143 18DKBL / 18DKBL E12D / &B143 18DKBL / FUSE A1-J (10305) CH3_15 CL LT OPTION (10380) CH7_66 / GROUND SPLICE (10419) CH3_55 / B14J 18RD / * A - SECTION 1-2 B - SECTION 2-3 C - SECTION 3-4 D - SECTION 4-5 E - SECTION 5-6 F - SECTION 6-7 G - SECTION 7-8 H - SECTION 8-9 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 601 / LEFT SIDE EMERGENCY DOOR

14.22. LEFT SIDE EMERGENCY DOOR (CONT.), P. 19A
Figure 602 LEFT SIDE EMERGENCY DOOR (CONT.)

Components: ALARM (10299); BOX (10177); BUZZ DIODE (10444); BUZZER (10204); CL LT REALY (10308); DIODE D61 (10306); DOOR (10454*); DOOR SW (10798); DOOR SW (10799); ELEC PANEL (1702); FUSE F49 (10305); FUSE F51 (10305); FUSE F83 (10307); INDICATION (1556); OPTION (10380); REAR CAP (10405); RELAY COIL (10364); SED ALARM (10455**); SED LT (10456*/##10456); SPLICE (10419); SPLICE (10422); VANDAL LOCK (10797)
Wires (circuit gauge+color): A117A 18GY; B117E 18GY; B12A 18LTBL; B12B 18LTBL; B12C 18LTBL; B12C 18LTGN; B12J 18LTBL; B12JAC 18LTBL; B12W 18LTBL; B12X 18LTBL; B143 18DKBL; B14J 18RD; B58A 16BN; B58D 16BN; D12C 18LTBL; D130C 18GY; E12A 18BK; E12B 18BK; E12B 18LTBL; E12C 18BK; E12C 18LTBL; E12D 18BK; E12D 18DKBL; E130-GA 18WH; E130B 18GY; E130C 18GY; E130D 18GY; E130E 18GY; E133C 18LTGN; E143-GV 18WH; E143V 18DKBL
See also sheets: CH14_01, CH14_17, CH14_20, CH14_28, CH18_55, CH3_29, CH3_55
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.22. LEFT SIDE EMERGENCY DOOR (CONT.), P. 19A / CHAPTER CHAPTER CHAPTER 14 14 14 LEFT SIDE EMERGENCY DOOR (CONT.) / MJV0488 19NOV21 ADDED CIRC B12JAC IN CAV C8 AT R/D 10400B. / L BODY/ REAR CAP (10405) #E12C 18LTBL A1 #E12A 18BK E12C 18BK E12C 18LTBL / ELEC PANEL/ L BODY @@)(10400A/10400B) C8 / 130-G 18WH / SIDE EMER DOOR STARTER VANDAL LOCK INTERLOCK SW (10797) A @133A 18LTGN / E130E 18GY / REAR DOOR SW BOX (10177) CH14_20, 21,19 / SIDE EMER DOOR SW (10799) A / SIDE EMER DOOR (10454*) A / SIDE EMER DOOR SW (10798) A / SED ALARM (10455**) A / SED LT (10456*/##10456) A A **E143V 18DKBL / B117E 18GY / E12D 18BK / E12B 18BK E12B 18LTBL #E130C 18GY E130B 18GY / E130C 18GY / 130 18GY / **E143-GV 18WH / D130C 18GY / D12C 18LTBL / B12J 18LTBL / SIDE EMER DOOR SW / BODY GROUND / @E133C 18LTGN / E130D 18GY / E130-GA 18WH / @133 18LTGN / %B143 18DKBL / 18DKBL E12D / B12A 18LTBL / &B143 18DKBL / GROUND SPLICE (10419) CH3_55 / B58D 16BN / B58A 16BN / CL LT OPTION (10380) / CL LT REALY (10308) CH7_66A / B14J 18RD B12JAC 18LTBL / %B12W 18LTBL / %%B12X 18LTBL / * A - SECTION 1-2 B - SECTION 2-3 C - SECTION 3-4 D - SECTION 4-5 E - SECTION 5-6 F - SECTION 6-7 G - SECTION 7-8 H - SECTION 8-9 / PLATFORM/ ELEC PANEL (1702) 50 %B12C 18LTGN / A117A 18GY / EMER EXIT OPEN INDICATION (1556) CH14_28 / STARTER INTERLOCK SPLICE (10422) CH14_17 / B12C 18LTBL B12B 18LTBL / Figure 602 / LEFT SIDE EMERGENCY DOOR (CONT.)

14.23. RIGHT SIDE EMERGENCY EXIT DOOR WITH ACCESSORY FEED, P. 20
Figure 603 RIGHT SIDE EMERGENCY EXIT DOOR WITH ACCESSORY FEED

Components: EMER EXIT LT (10142); L BODY/REAR CAP (10405); R BODY (10700); REAR DOOR SW BOX (10177); SED (10771); SED ALARM (10455); SPLICE (10161); SPLICE (10767)
Wires (circuit gauge+color): D12A 18LTBL; D12B 18LTBL; D12C 18LTBL; D12D 18LTBL; D130A 18GY; D130B 18GY; D130C 18GY; D58-GN 16WH; E12C 18BK; E130C 18GY; F12A 16LTBL; F12C 16LTBL; F130C 18GY
See also sheets: CH14_19, CH14_22, CH3_46
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.23. RIGHT SIDE EMERGENCY EXIT DOOR WITH ACCESSORY FEED, P. 20 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / CHAPTER 14 RIGHT SIDE EMERGENCY EXIT DOOR W/ACCESSORY FEED / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ***D12B 18LTBL REAR CAP/ R BODY (10700) C1 / L BODY/REAR CAP (10405) B6 %%%D130C 18GY / ***D12D 18LTBL / %%%D130A 18GY ###D130C 18GY @@@D12A 18LTBL ***D12A 18LTBL / E130C 18GY E12C 18BK / EMER EXIT LT (10142) A / @@@D12B 18LTBL / &&D12C ***D12C 18LTBL 18LTBL / SED ALARM (10455) CH14_19 / %%%D130B 18GY / @@@D12C 18LTBL / REAR EMER BUZZER / REAR DOOR SW BOX (10177) / R REAR CAP GND SPLICE (10161) CH3_46 / D58-GN 16WH / ACCESSORY SPLICE (10767) CH14_22 / F130C 18GY / *F12C 16LTBL *F12A 16LTBL / SED (10771) CH14_22 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 603 / RIGHT SIDE EMERGENCY EXIT DOOR WITH ACCESSORY FEED

14.24. RIGHT SIDE EMERGENCY EXIT DOOR WITH ACCESSORY FEED (CONT.), P. 21
Figure 604 RIGHT SIDE EMERGENCY EXIT DOOR WITH ACCESSORY FEED (CONT.)

Components: EMER EXIT LT (10142); L BODY/REAR CAP (10405); R BODY (10700); REAR DOOR SW BOX (10177); SED (10771); SED LT (10773G); SPLICE (10161); SPLICE (10767)
Wires (circuit gauge+color): D12A 18LTBL; D12B 18LTBL; D12C 18LTBL; D12D 18LTBL; D130A 18GY; D130B 18GY; D130C 18GY; D58-GN 16WH; E12C 18BK; E130C 18GY; F12A 16LTBL; F12C 16LTBL; F12C 18LTBL; F130C 18GY
See also sheets: CH14_19, CH14_22, CH14_27, CH3_46
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.24. RIGHT SIDE EMERGENCY EXIT DOOR WITH ACCESSORY FEED (CONT.), P. 21 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090665 NO. RELEASE NO. 95885P 15JAN21 / CHAPTER 14 RIGHT SIDE EMERGENCY EXIT DOOR W/ACCESSORY FEED (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR CAP / R BODY (10700) C1 %%%D130A F130C 18GY 18GY / L BODY/REAR CAP (10405) B6 %%%D130C 18GY @@@D12C 18LTBL / ***D12D 18LTBL D58-GN 16WH / @@@D12A 18LTBL ***D12A 18LTBL / E130C 18GY E12C 18BK / EMER EXIT LT (10142) A / @@@D12B 18LTBL / &&D12C 18LTBL ***D12C 18LTBL / ***D12B 18LTBL / L SIDE EMER DOOR CH14_19 / %%%D130B 18GY / REAR EMER BUZZER / REAR DOOR SW BOX (10177) 3 / ## SECTION 7-8 / R REAR CAP GND SPLICE (10161) CH3_46 / ACCESSORY SPLICE (10767) A / F12C 16LTBL F12A 16LTBL / SED (10771) CH14_22 / SED LT (10773G) CH14_27 / && W/ EMER EXIT LT ONLY @@@ W/ KICK OUT WINDOW ONLY *** W/ KICK OUT WINDOW & EMER EXIT LT %%% R SIDE EMER EXIT DOOR / W/ 12,13 WINDOW / ##F12C 18LTBL / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 604 / RIGHT SIDE EMERGENCY EXIT DOOR WITH ACCESSORY FEED (CONT.)

14.25. RIGHT SIDE EMERGENCY EXIT DOOR, P. 22
Figure 605 RIGHT SIDE EMERGENCY EXIT DOOR

Components: ALARM (10772*); DOOR (10771); DOOR LT (10771); L BODY (10405); R BODY (10700); SED LT (10773G); SPLICE (10767)
Wires (circuit gauge+color): D12C 18LTBL; D130C 18GY; D133B 18LTGN; F12A 16LTBL; F12A 18BK; F12A 18LTBL; F12B 18BK; F12B 18LTBL; F12C 16LTBL; F12C 18LTBL; F12D 18LTBL; F12E 18LTBL; F12U 18LTBL; F12V 18LTBL; F12W 18LTBL; F12X 18LTBL; F130A 18GY; F130B 18GY; F130B 18WH; F130C 18GY; F130E 18GY; F130F 18GY; F130J 18GY; F130K 18GY; F130L 18GY; F130M 18GY; F130N 18GY; F130P 18GY; F133D 18LTGN; F133T 18LTGN
See also sheets: CH14_20, CH14_23, CH14_27
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.25. RIGHT SIDE EMERGENCY EXIT DOOR, P. 22 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / CHAPTER 14 RIGHT SIDE EMERGENCY EXIT DOOR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SIDE ALARM (10772*) A / REAR CAP/ R BODY (10700) / F130F 18GY F130E 18GY F130J 18GY F130A 18GY F130N 18GY F130L 18GY F130B 18WH / F130C 18GY / SIDE EMER DOOR LT (10771) CH14_23 / ACCESSORY SPLICE (10767) / F133T 18LTGN F133D 18LTGN / SED LT (10773G) CH14_27 18LTBL F12C / SECTION 3-4 / SECTION 4-13 / SECTION 1-2 / SECTION 10-11 SECTION 8-9 / F12A 16LTBL F12C 16LTBL / SECTION 1-2 / D130C 18GY / D12C 18LTBL / D133B 18LTGN / REAR CAP/ L BODY (10405) CH14_20 / SIDE EMER DOOR (10771) CH14_23 / Figure 605 / RIGHT SIDE EMERGENCY EXIT DOOR

14.26. RIGHT SIDE EMERGENCY EXIT DOOR (CONT.), P. 23
Figure 606 RIGHT SIDE EMERGENCY EXIT DOOR (CONT.)

Components: DOOR (10771*); DOOR LT (10772); GROUND SPLICE (10702); L BODY (10405); REAR CAP (10700); SED SW (10798); SED SW (10799); VANDAL LOCK (10797)
Wires (circuit gauge+color): D133B 18LTGN; F130-G 18WH; F130-GA 18WH; F130-GB 18WH; F130-GC 18WH; F130-GD 18WH; F130A 18GY; F130E 18GY; F130F 18GY; F130J 18GY; F130L 18GY; F130N 18GY; F133A 18LTGN; F133B 18LTGN; F133C 18LTGN; F133D 18LTGN; F133E 18LTGN; F133F 18LTGN; F133H 18LTGN; F133J 18LTGN; F133K 18LTGN; F133L 18LTGN; F133M 18LTGN; F133T 18LTGN
See also sheets: CH14_22, CH3_53
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.26. RIGHT SIDE EMERGENCY EXIT DOOR (CONT.), P. 23 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090665 NO. RELEASE NO. 95885P 15JAN21 / CHAPTER 14 RIGHT SIDE EMERGENCY EXIT DOOR (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION / SIDE EMER DOOR (10771*) A / SED VANDAL LOCK STARTER (10797) INTERLOCK SW A 133A 18LTGN / SED SW (10798) A / 130 18GY / SIDE EMER DOOR LT (10772) CH14_22 / SED SW (10799) A / BODY GROUND / 133 18LTGN / R BODY/ REAR CAP (10700) C3 / GROUND SPLICE (10702) CH3_53 / 130-G 18WH / D133B 18LTGN / REAR CAP/ L BODY (10405) CH14_22 / Figure 606 / RIGHT SIDE EMERGENCY EXIT DOOR (CONT.)

14.27. RIGHT SIDE EMERGENCY EXIT DOOR (CONT.), P. 24
Figure 607 RIGHT SIDE EMERGENCY EXIT DOOR (CONT.)

Components: BUZZER SPLICE (10204); GROUND SPLICE (10160); L BODY (10401A/10401B); REAR CAP (10406); SPLICE (10386); SW BOX (10177)
Wires (circuit gauge+color): B117F 18GY; D11-GG 16WH; D117 18GY; E117 18GY
See also sheets: CH14_01, CH3_45
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.27. RIGHT SIDE EMERGENCY EXIT DOOR (CONT.), P. 24 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090665 NO. RELEASE NO. 95885P 15JAN21 / CHAPTER 14 RIGHT SIDE EMERGENCY EXIT DOOR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR DOOR SW BOX (10177) 2 / ALARM SW / D11-GG 16WH / ELEC PANEL/ L BODY (10401A/10401B) A5 B117F E117 18GY 18GY / L BODY/ REAR CAP (10406) C10 D117 18GY / EMER EXIT BUZZER SPLICE (10204) CH14_01,1A REAR DOOR SPLICE (10386) CH16_26A,38 / REAR CAP GROUND SPLICE (10160) CH3_45 / B117F 18GY / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 607 / RIGHT SIDE EMERGENCY EXIT DOOR (CONT.)

14.28. RIGHT SIDE EMERGENCY DOOR WITH 3 IN RED LIGHT TIED TO CLEARANCE LIGHT WITHOUT KICK OUT WINDOW, P. 25
Figure 608 RIGHT SIDE EMERGENCY DOOR WITH 3 IN RED LIGHT TIED TO CLEARANCE LIGHT

Components: EMER LT (10773***); SPLICE (10702); SPLICE (10704)
Wires (circuit gauge+color): F143-GP 18WH; F143-GR 18WH; F143-GS 18WH; F143-GT 18WH; F143-GU 18WH; F143-GV 18WH; F143-GW 18WH; F143-GX 18WH; F143-GY 18WH; F143-GZ 18WH; F143AA 18DKBL; F143AL 18DKBL; F143AM 18DKBL; F143GAA 18WH; F143GAL 18WH; F143GAM 18WH; F143P 18DKBL; F143R 18DKBL; F143S 18DKBL; F143T 18DKBL; F143U 18DKBL; F143V 18DKBL; F143W 18DKBL; F143X 18DKBL; F143Y 18DKBL
See also sheets: CH3_53, CH7_39
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.28. RIGHT SIDE EMERGENCY DOOR WITH 3 IN RED LIGHT TIED TO CLEARANCE LIGHT WITHOUT KICK OUT WINDOW, P. 25 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / CHAPTER 14 RIGHT SIDE EMERGENCY DOOR W/3 IN RED LIGHT TIDE TO CLEARENCE LIGHT N/ KICK OUT WINDOW / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SIDE EMER LT (10773***) / COMBINATION SPLICE (10704) CH7_39 L / GROUND SPLICE (10702) CH3_53 C / Figure 608 / RIGHT SIDE EMERGENCY DOOR WITH 3 IN RED LIGHT TIED TO CLEARANCE LIGHT WITHOUT KICK OUT WINDOW

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 649 | printed page 609 | section 14.29
14.29. RIGHT SIDE EMERGENCY DOOR WITH 3 IN RED LIGHT TIED TO CLEARANCE LIGHT WITH KICK OUT WINDOW, P. 26
Figure 609 RIGHT SIDE EMERGENCY DOOR WITH 3 IN RED LIGHT TIED TO CLEARANCE LIGHT

Components: LT SPLICE (10714); SED LT (10773%%); SPLICE (10702); SPLICE (10704)
Wires (circuit gauge+color): F143 18DKBL; F143-G 18WH; F143-GA 18WH; F143AB 18DKBL; F143AC 18DKBL; F143AD 18DKBL; F143AE 18DKBL; F143AF 18DKBL; F143AH 18DKBL; F143AJ 18DKBL; F143AK 18DKBL; F143AN 18DKBL; F143AP 18DKBL; F143AR 18DKBL; F143AS 18DKBL; F143AT 18DKBL; F143GAB 18WH; F143GAC 18WH; F143GAD 18WH; F143GAE 18WH; F143GAF 18WH; F143GAH 18WH; F143GAJ 18WH; F143GAK 18WH; F143GAL 18WH; F143GAN 18WH; F143GAP 18WH; F143GAR 18WH; F143GAS 18WH; F143GAT 18WH
See also sheets: CH3_53, CH7_39
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.29. RIGHT SIDE EMERGENCY DOOR WITH 3 IN RED LIGHT TIED TO CLEARANCE LIGHT WITH KICK OUT WINDOW, P. 26 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / CHAPTER 14 RIGHT SIDE EMERGENCY DOOR W/3 IN RED LIGHT TIDE TO CLEARENCE LIGHT W/ KICK OUT WINDOW A F B / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SED LT (10773%%) A / F143 18DKBL / EMER EXIT LT SPLICE (10714) / COMBINATION SPLICE (10704) CH7_39 / W/9,10 WINDOW / **F143GAE 18WH @@F143GAF 18WH ##F143GAH 18WH **F143GAJ 18WH *@F143GAK 18WH *&F143GAL 18WH &&F143GAH 18WH **F143GAJ 18WH *@F143GAK 18WH F143-G 18WH / M G / Figure 609 / RIGHT SIDE EMERGENCY DOOR WITH 3 IN RED LIGHT TIED TO CLEARANCE LIGHT WITH KICK OUT WINDOW

14.30. RIGHT SIDE EMERGENCY DOOR WITH 3IN RED LIGHT TIED TO IGNITION
Figure 610 RIGHT SIDE EMERGENCY DOOR WITH 3IN RED LIGHT TIED TO IGNITION SECT 7 TO 8

Components: SED LT (10773G); SPLICE (10702); SPLICE (10767)
Wires (circuit gauge+color): F12-G 18WH; F12C 18LTBL
See also sheets: CH14_22, CH3_53
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.30. RIGHT SIDE EMERGENCY DOOR WITH 3IN RED LIGHT TIED TO IGNITION SECT 7 TO 8, P. 27 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / CHAPTER 14 RIGHT SIDE EMERGENCY DOOR W/3IN RED LIGHT TIED TO IGNITION SECTION 7 TO 8 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ACCESSORY SPLICE (10767) CH14_22 / GROUND SPLICE (10702) CH3_53 / SED LT (10773G) A / F12-G 18WH / F12C 18LTBL / W/12 WINDOWS / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 610 / RIGHT SIDE EMERGENCY DOOR WITH 3IN RED LIGHT TIED TO IGNITION SECT 7 TO 8

14.31. EMERGENCY EXIT INDICATOR LIGHT IN CLUSTER, P. 28
Figure 611 EMERGENCY EXIT INDICATOR LIGHT IN CLUSTER

Components: BUZZER SPLICE (10204); DIODE B6-J (10303); DIODE D61 (10306); DRIVER ALARM (11629A); DRIVER ALARM (11629B); FUSE F49 (10305); INDICATION (1556); L BODY (10400A/B); PLATFORM (1702)
Wires (circuit gauge+color): A117A 18GY; A117B 18GY; B11-GAL 16WH; B11-GAM 18WH; B117 18GY; B117SD 18GY; B12A 18LTBL; B12B 18LTBL; B12C 18LTBL; B12J 18LTBL; B12W 18LTBL
See also sheets: CH14_01, CH14_19, CH3_16
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.31. EMERGENCY EXIT INDICATOR LIGHT IN CLUSTER, P. 28 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / CHAPTER 14 EMERGENCY EXIT INDICATOR LIGHT IN CLUSTER / MJV0488 19NOV21 ADDED CIRC B117SD IN B CAV 52 OF R/D 1702. / &B12C 18LTBL @B12A 18LTBL %B12C 18LTBL &B117 18GY #B117SD 18GY / ^A117A 18GY ^A117B 18GY / EMER EXIT OPEN INDICATION (1556) 1A / ELEC PANEL/ PLATFORM (1702) 50 / NORTH CAROLINA DRIVER ALARM (11629A) A / FUSE F49 (10305) CH3_94L FUSE B9-E #(10302) CH3_16 EMER EXIT BUZZER SPLICE (10204) CH14_1A EMER EXIT BUZZER SPLICE (10204) CH14_01 / @B12C 18LTBL / ELEC PANEL/ L BODY (10400A/B) CH14_19A ELEC PANEL/ PLATFORM (1702) CH14_19A ELEC PANEL/ L BODY #(10400) CH14_19 FUSE B9-E #(10302) CH3_16 / NORTH CAROLINA DRIVER ALARM (11629B) / *B12W 18LTBL / *B11-GAL 16WH / DIODE B6-J (10303) / *B12B 18LTBL / *B11-GAM 18WH / *B12A 18LTBL / *B12J 18LTBL / EMER EXIT BUZZER SPLICE ^(10204) CH14_01,1A / &B12C 18LTBL / DIODE D61 (10306) / &B12W 18LTBL / B12B 18LTBL / B12J 18LTBL / Figure 611 / EMERGENCY EXIT INDICATOR LIGHT IN CLUSTER

14.32. EMERGENCY EXIT INDICATOR LIGHT IN CLUSTER, P. 29
Figure 612 EMERGENCY EXIT INDICATOR LIGHT IN CLUSTER

Components: CIRCUITS (10009); FR CAP (10000); INTERLOCK (10042); INTERLOCK (10043); INTERLOCK (11142); INTERLOCK (11143); SPLICE PACK (10382); VANDAL LOCK SW (10086)
Wires (circuit gauge+color): B133H 18LTGN; C11-GB 16WH; C133 16LTGN; C133-GB 16WH
See also sheets: CH15_25, CH3_43
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 14.32. EMERGENCY EXIT INDICATOR LIGHT IN CLUSTER, P. 29 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090665 NO. 95885P 15JAN21 / STARTER INTERLOCK / CHAPTER CHAPTER CHAPTER 14 14 14 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/ FR CAP (10000) B6 B133H 18LTGN / STARTER INTERLOCK SPLICE PACK (10382) CH15_25 / @C133 16LTGN @C11-GB 16WH / STARTER INTERLOCK VANDAL LOCK SW (10086) B / (COM) STARTER INTERLOCK (11143) A A / (NC)STARTER INTERLOCK (11142) A A / (NC) STARTER INTERLOCK (10042) A A / (COM) STARTER INTERLOCK (10043) A / GROUND CIRCUITS (10009) CH3_43 / #C133-GB 16WH / #C133 16LTGN / %C133 16LTGN / %C133-GB 16WH / @ W/MICRO LIMIT SW # W/AIR DOOR % W/ENHANCE DOOR / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 612 / EMERGENCY EXIT INDICATOR LIGHT IN CLUSTER

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 653 | printed page 613 | section
WHEEL CHAIR LIFT DOOR SYSTEM (CHAPTER 15)
Figure 613 LIFT WITH AIR BRAKE WITH KEY ON / OFF WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

Components: BODY CONTROLLER (1601); FUSE B12-A (10301); GROUND SPLICE (10335A); L BODY (10401A/B); PLATFORM (1702); PLATFORM (1703); PLATFORM /ELEC PANEL (1703); R BODY (10700); REAR CAP (10405); RELAY (10312-R1); RELAY (10312-R4); RELAY (10312-R5); RELAY (11532A); RELAY COIL (10369); SEALED ENG (11500); SPLICE (10335A); SPLICE (10370)
Wires (circuit gauge+color): A122J 18GY; B122-G 18WH; B122-GA 18WH; B122A 18GY; B122D 18WH; B122E 16GY; B122F 16GY; B122H 18GY; B122J 16GY; B122J 18GY; B122K 18GY; B122L 18GY; B122M 18GY; B122N 16BN; B122N 18GY; B122P 18GY; B122R 18GY; B13 18PK; B13A 18PK; B13B 18PK; B44 18GY; B44C 18GY; D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122-GY 16GY; D122A 16GY; D122B 16GY; D122C 16GY; E122-GA 16WH; E122-GB 16WH; E122-GC 16WH; E122A 16GY; E122B 16GY; E122C 16GY; Y122 16GY
See also sheets: CH15_03, CH15_08, CH15_12, CH3_12, CH3_30, CH3_36
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / WHEEL CHAIR LIFT DOOR SYSTEM (CHAPTER 15) / 15.1. LIFT WITH AIR BRAKE WITH KEY ON / OFF WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 1 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / CHAPTER 15 LIFT W/AIR BRAKE W/KEY ON/OFF W/2017/2021 ISB/B6.7 DIESEL ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B12 E122-GC 16WH E122A 16GY E122B 16GY E122C 16GY / B122A 18GY / LIFT SPLICE (10370) / B44 18GY / ELEC PANEL /PLATFORM (1702) CH15_08 ELEC PANEL /PLATFORM (1703) CH15_08 / L BODY/ REAR CAP (10405) B10 E122-GA 16WH / B122-GA 18WH B122R 18GY B122P 18GY B122N 16BN / ELEC PANEL/ L BODY (10401A/B) B12 / GROUND SPLICE (10335A) CH3_36 PLATFORM /ELEC PANEL (1703) CH15_08 / D122-GA 16WH D122-GY B11 16GY D122-GB 16WH D122-GC 16WH D122A 16GY D122B 16GY D122C 16GY / REAR CAP / R BODY (10700) CH15_12,13,14, 15,16,17,18,19, 20,21,22,23 / B44A A8GY / B122K 18GY / ACCESSARY SPLICE RELAY COIL (10369) CH3_30 ELEC PANEL/ PLATFORM (1702) CH15_08 / E122-GB 16WH / B122D 18WH / #B13A 18PK LIFT INTERLOCK RELAY (10312-R4) 86 / FUSE B12-A (10301) CH3_12 / B122H 18GY B122J 16GY / B122F 16GY / LIFT 30 INTERLOCK RELAY (10312-R5) / #B13B 18PK / B44C 18GY / B122E 16GY / B122J 18GY / ELEC PANEL/ SEALED ENG (11500) B7 / @B122L 18GY / B122M 18GY / @B122N 18GY / @B122M 18GY / Y122 16GY / LIFT RELAY (11532A) CH15_03 / GROUND SPLICE (10335A) CH3_36 / B122-G 18WH / WHEELCHAIR LIFT SOLENOID / J4 BLUE BODY CONTROLLER (1601) / # W/KEY ON/OFF @ W/LIFT PWR NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / ELEC PANEL/ PLATFORM (1702) 37 / A122J 18GY / LIFT LT RELAY (10312-R1) / #B13 18PK / Figure 613 / LIFT WITH AIR BRAKE WITH KEY ON / OFF WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

15.2. LIFT WITH AIR BRAKE WITH KEY ON / OFF WITH INDICATOR LIGHT WITH
Figure 614 LIFT WITH AIR BRAKE WITH KEY ON / OFF WITH INDICATOR LIGHT WITH 2017 ISB /

Components: BODY CONTROLLER (1601); FUSE B12-A (10301); GROUND SPLICE (10335A); INDICATOR (10371); L BODY (10401A/B); LIFT SW (10281); PLATFORM (1702); PLATFORM (1703); PLATFORM /ELEC PANEL (1703); R BODY (10700); REAR CAP (10405); RELAY (10312-R1); RELAY (10312-R4); RELAY (10312-R5); RELAY (11532A); SEALED ENG (11500); SPLICE (10335A); SPLICE (10370)
Wires (circuit gauge+color): A122J 18GY; B122-G 18WH; B122-GA 18WH; B122A 18GY; B122D 18WH; B122E 16GY; B122F 16GY; B122H 18GY; B122J 16GY; B122J 18GY; B122K 18GY; B122L 18GY; B122M 18GY; B122N 16BN; B122N 18GY; B122P 18GY; B122R 18GY; B122T 16GY; B122T 18GY; B122V 16GY; B13 18PK; B13A 18PK; B13B 18PK; B44 18GY; B44A 18GY; B44C 18GY; D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122-GY 16GY; D122A 16GY; D122B 16GY; D122C 16GY; E122-GA 16WH; E122-GB 16WH; E122-GC 16WH; E122A 16GY; E122B 16GY; E122C 16GY; Y122 16GY
See also sheets: CH15_03, CH15_08, CH15_12, CH3_12, CH3_30, CH3_36, CH5_05
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.2. LIFT WITH AIR BRAKE WITH KEY ON / OFF WITH INDICATOR LIGHT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 2 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / CHAPTER 15 LIFT W/AIR BRAKE W/KEY ON/OFF W/INDICATOR LT W/2017/2021 ISB/B6.7 DIESEL ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B12 E122-GC 16WH E122A 16GY E122B 16GY E122C 16GY / B44A 18GY B122A 18GY / LIFT SPLICE (10370) / B44 18GY / L BODY/ REAR CAP (10405) B10 E122-GA 16WH / B122-GA 18WH B122R 18GY B122P 18GY B122N 16BN / ELEC PANEL/ L BODY (10401A/B) B12 / GROUND SPLICE (10335A) CH3_36 PLATFORM /ELEC PANEL (1703) CH15_08 / D122-GA 16WH &D122-GY 16GY D122-GB 16WH D122-GC 16WH D122A 16GY D122B 16GY D122C 16GY / REAR CAP / R BODY (10700) CH15_12,13,14, 15,16,17,18,19, 20,21,22,23 / B122K 18GY / FLASH LT INDICATOR (10371) CH5_05 ACCESSARY SPLICE RELAY COIL (10369) CH3_30 / E122-GB 16WH / LIFT INTERLOCK RELAY (10312-R4) 86 30 / B122H 18GY B122J 16GY / B122F 16GY / 30 LIFT INTERLOCK RELAY (10312-R5) GROUND SPLICE (10335A) CH3_36 / #B13A 18PK / #B13 18PK / #B13B 18PK / ELEC PANEL /PLATFORM (1702) CH15_08 / B122E 16GY / B122J 18GY / B122-G 18WH / WHEELCHAIR E1 LIFT SOLENOID / # W/KEY ON/OFF & W/LIFT PWR @ N/LIFT SW % W/LIFT SW / ELEC PANEL/ PLATFORM (1702) 37 / A122J 18GY / LIFT LT RELAY (10312-R1) / B122V 16GY B122T 16GY / FUSE B12-A (10301) CH3_12 / ELEC PANEL/ SEALED ENG (11500) B7 / B122M 18GY / #@B122N 18GY / #@B122M 18GY / Y122 16GY / LIFT RELAY (11532A) CH15_03 / #@B122L 18GY / B44C 18GY / %B122T 18GY @B122T 18GY / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 614 / LIFT WITH AIR BRAKE WITH KEY ON / OFF WITH INDICATOR LIGHT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

15.3. LIFT SWITCH EFFECTS WITH AIR AND HYDRAULIC BRAKE, P. 3
Figure 615 LIFT SWITCH EFFECTS WITH AIR AND HYDRAULIC BRAKE

Components: ENGINE (11500); LIFT RELAY (11532A); LIFT SPLICE (10370); LIFT SW (10281); RELAY (10312-R4); SOLENOID (11512); SPLICE (10329)
Wires (circuit gauge+color): B122M 18GY; B122T 18GY; B122U 18WH; B62-GAD 18WH; B62AD 18DKBL; B62BN 18DKBL; Y122 16GY; Y122A 16GY
See also sheets: CH15_01, CH15_02, CH3_29, CH8_30
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.3. LIFT SWITCH EFFECTS WITH AIR AND HYDRAULIC BRAKE, P. 3 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / CHAPTER 15 LIFT SW EFFECTS W/AIR AND HYDRAULIC BRAKE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B62-GAD 18WH B62AD 18DKBL / Y122 16GY / @B122U 18WH / *B122T 18GY @B122T 18GY / Y122A 16GY ELEC PANEL/ SEALED ENGINE (11500) / LIFT SW (10281) 5 / LIFT SOLENOID (11512) / B122M 18GY / SW ILLUMINATION SPLICE (10329) CH8_30 / B62BN 18DKBL / ACCESSORY SPLICE RELAY COIL (10364) CH3_29 / 2RED 90A CIRCUIT BRAKER / LIFT RELAY (11532A) / &Y122 16GY / &Y122A 16GY / 90A CIRCUIT BRAKER / LIFT SPLICE (10370) CH15_02 / LIFT INTERLOCK RELAY (10312-R4) CH15_01,02, 04,05,06,07 / * N/LIFT SW @ W/LIFT SW & W/ PWR RELAY SIGNAL / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 615 / LIFT SWITCH EFFECTS WITH AIR AND HYDRAULIC BRAKE

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 656 | printed page 616 | section 15.4
15.4. LIFT WITH HYDRAULIC BRAKE WITH KEY ON / OFF WITH 2017 ISB / 2021
Figure 616 LIFT WITH HYDRAULIC BRAKE WITH KEY ON / OFF WITH 2017 ISB / 2021 B6.7 DIESEL

Components: BODY CONTROLLER (1601); ELEC PANEL (1703); FR CAP (10000); FUSE B12-A (10301); GROUND SPLICE (10335A); L BODY (10401A/B); PLATFORM (1702); PLATFORM (1703); PLATFORM/ (1703); R BODY (10700); REAR CAP (10405); RELAY (10312-R1); RELAY (10312-R4); RELAY (10312-R5); RELAY (11532A); RELAY COIL (10369); SEALED ENG (11500); SPLICE (10335A); SPLICE (10370)
Wires (circuit gauge+color): A122J 18GY; B122-G 18WH; B122-GA 18WH; B122A 18GY; B122AA 16WH; B122D 18WH; B122E 16GY; B122F 16GY; B122H 18GY; B122J 16GY; B122J 18GY; B122K 18GY; B122L 18GY; B122M 18GY; B122N 16BN; B122N 18GY; B122P 18GY; B122R 18GY; B122Z 16GY; B13 18PK; B13A 18PK; B13B 18PK; B44 18GY; B44A 18GY; B44B 18GY; B44C 18GY; B44D 18GY; D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122-GY 16GY; D122A 16GY; D122B 16GY; D122C 16GY; E122-GA 16WH; E122-GB 16WH; E122-GC 16WH; E122A 16GY; E122B 16GY; E122C 16GY; Y122 16GY
See also sheets: CH13_58, CH15_03, CH15_09, CH15_12, CH15_29, CH3_12, CH3_30, CH3_36
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.4. LIFT WITH HYDRAULIC BRAKE WITH KEY ON / OFF WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 4 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / CHAPTER 15 LIFT W/HYDRAULIC BRAKE W/KEY ON/OF W/2017/2021 ISB/B6.7 DIESEL ENGINE ELEC PANEL/ L BODY (10401A/B) B12 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / E122-GB 16WH B12 E122-GC 16WH E122A 16GY E122B 16GY E122C 16GY *B13A 18PK / B122A 18GY / LIFT SPLICE (10370) / L BODY/ REAR CAP (10405) B10 E122-GA 16WH / B122-GA 18WH B122R 18GY B122P 18GY B122N 16BN / GROUND SPLICE (10335A) CH3_36 PLATFORM/ ELEC PANEL (1703) CH15_09 FUSE B12-A (10301) CH3_12 / D122-GA 16WH @D122-GY 16GY B11 D122-GB 16WH D122-GC 16WH D122A 16GY D122B 16GY D122C 16GY / LIFT LT RELAY (10312-R1) 86 / REAR CAP / R BODY (10700) CH15_12,13, 14,15,16, 17,18,19,20, 21,22,23 / B44A 18GY / ACCESSORY SPLICE RELAY COIL (10369) CH3_30 / LIFT INTERLOCK RELAY (10312-R4) 86 / B122H 18GY B122J 16GY / B122F 16GY / LIFT 30 INTERLOCK RELAY (10312-R5) GROUND SPLICE B122-G (10335A) 18WH CH3_36 ELEC PANEL/ SEALED ENG (11500) B7 Y122 16GY / *B13 18PK / *B13B 18PK / B44C 18GY B44D 18GY / B44B 18GY / ELEC PANEL /PLATFORM (1703) CH13_58 / B122E 16GY / B122J 18GY / @B122L @B122M 18GY 18GY / @B122N 18GY / LIFT RELAY (11532A) CH15_03 / WHEELCHAIR LIFT SOLENOID / * W/KEY ON/OFF @ W/LIFT PWR / ELEC PANEL/ PLATFORM (1702) 37 / A122J 18GY / B122Z 16GY / B122M 18GY / B44 18GY / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 616 / LIFT WITH HYDRAULIC BRAKE WITH KEY ON / OFF WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

15.5. LIFT WITH HYDRAULIC BRAKE WITH KEY ON / OFF WITH INDICATOR LIGHT
Figure 617 LIFT WITH HYDRAULIC BRAKE WITH KEY ON / OFF WITH INDICATOR LIGHT WITH

Components: CONTROLLER (1601); ELEC PANEL (1703); FUSE B12-A (10301); GROUND SPLICE (10335A); INDICATOR (10371); L BODY (10401A/B); PLATFORM (1702); PLATFORM (1703); PLATFORM/ (1703); R BODY (10700); REAR CAP (10405); RELAY (10312-R1); RELAY (10312-R4); RELAY (10312-R5); RELAY (11532A); SEALED ENG (11500); SPLICE (10335A); SPLICE (10370)
Wires (circuit gauge+color): A122J 18GY; B122-G 18WH; B122-GA 18WH; B122A 18GY; B122D 18WH; B122E 16GY; B122F 16GY; B122H 18GY; B122J 16GY; B122J 18GY; B122K 18GY; B122L 18GY; B122M 18GY; B122N 16BN; B122N 16GY; B122N 18GY; B122P 18GY; B122R 18GY; B122T 16GY; B13 18PK; B13A 18PK; B13B 18PK; B44 18GY; B44B 18GY; B44C 18GY; B44D 18GY; D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122-GY 16GY; D122A 16GY; D122B 16GY; D122C 16GY; E122-GA 16WH; E122-GB 16WH; E122-GC 16WH; E122A 16GY; E122B 16GY; E122C 16GY; Y122 16GY
See also sheets: CH05_05, CH13_58, CH15_03, CH15_09, CH15_12, CH3_12, CH3_30, CH3_36
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.5. LIFT WITH HYDRAULIC BRAKE WITH KEY ON / OFF WITH INDICATOR LIGHT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 5 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / CHAPTER 15 LIFT W/HYDRAULIC BRAKE W/KEY ON/OFF W/INDICATOR LIGHT W/2017/2021 ISB/B6.7 DIESEL ENGINE ELEC PANEL/ L BODY (10401A/B) B12 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / LIFT LT RELAY (10312-R1) 85 / E122-GB 16WH B12 E122-GC 16WH E122A 16GY E122B 16GY E122C 16GY / B122A 18GY / LIFT SPLICE (10370) A / B44 18GY / ELEC PANEL/ PLATFORM (1703) CH13_58 ELEC PANEL PLATFORM/ (1703) CH15_09 B122D 18WH / L BODY/ REAR CAP (10405) B10 E122-GA 16WH / B122-GA 18WH B122R 18GY B122P 18GY B122N 16BN B122N 16GY B122T 16GY / GROUND SPLICE (10335A) CH3_36 PLATFORM/ ELEC PANEL (1703) CH15_09 / D122-GA 16WH #D122-GY 16GY B11 D122-GB 16WH D122-GC 16WH D122A 16GY D122B 16GY D122C 16GY / REAR CAP / R BODY (10700) CH15_12,13, 14,15,16, 17,18,19,20, 21,22,23 / B44A A8GY / FLASH LT INDICATOR (10371) CH05_05 ACCESSORY SPLICE RELAY COILS (10369) CH3_30 / B122H 18GY B122J 16GY / B122F 16GY / *B13A 18PK / *B13 18PK / *B13B 18PK *B44C 18GY B44D 18GY / B44B 18GY / B122E 16GY / B122J 18GY / B122-G 18WH ELEC PANEL/ SEALED ENG (11500) B7 Y122 16GY / #B122L #B122M 18GY 18GY / B122M 18GY / #B122N 18GY / LIFT RELAY (11532A) CH15_03 / LIFT INTERLOCK RELAY (10312-R5) GROUND SPLICE (10335A) CH3_36 / WHEELCHAIR LIFT SOLENOID / J4 BLUE BODY CONTROLLER (1601) / * W/KEY ON/OFF # W/LIFT PWR NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / ELEC PANEL/ PLATFORM (1702) 37 / A122J 18GY / LIFT INTERLOCK RELAY (10312-R4) / FUSE B12-A (10301) CH3_12 / B122K 18GY / ELEC PANEL /PLATFORM (1703) CH13_58 / Figure 617 / LIFT WITH HYDRAULIC BRAKE WITH KEY ON / OFF WITH INDICATOR LIGHT WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

15.6. LIFT WITH HYDRAULIC BRAKE WITH KEY ON WITH F-2018 PROPANE / GASOLINE ENGINE, P. 6
Figure 618 LIFT WITH HYDRAULIC BRAKE WITH KEY ON WITH F-2018 PROPANE / GASOLINE

Components: CONTROLLER (1601); FUSE B12-A (10301); GROUND SPLICE (10335A); L BODY (10401A/B); PLATFORM (1702); PLATFORM (1703); PLATFORM/ELEC PANEL (1703); R BODY (10700); REAR CAP (10405); RELAY (10312-R1); RELAY (10312-R5); RELAY (11532A); RELAY COILS (10369); SEALED ENG (11500); SPLICE (10335A); SPLICE (10370)
Wires (circuit gauge+color): A122J 18GY; B122-G 18WH; B122-GA 18WH; B122A 18GY; B122D 16GY; B122D 18WH; B122E 16GY; B122F 16GY; B122H 18GY; B122J 18GY; B122K 18GY; B122L 18GY; B122M 18GY; B122N 16BN; B122N 18GY; B122P 18GY; B122P 18PK; B122R 18GY; B13 18PK; B13A 18PK; B44 18GY; B44A 18GY; B44B 18GY; B44C 18GY; B44D 18GY; D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122-GY 16GY; D122A 16GY; D122B 16GY; D122C 16GY; E122-GA 16WH; E122-GB 16WH; E122-GC 16WH; E122A 16GY; E122B 16GY; E122C 16GY; Y122 16GY
See also sheets: CH13_58, CH15_03, CH15_11, CH15_12, CH3_12, CH3_30, CH3_36
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.6. LIFT WITH HYDRAULIC BRAKE WITH KEY ON WITH F-2018 PROPANE / GASOLINE ENGINE, P. 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / CHAPTER 15 LIFT W/HYDRAULIC BRAKE W/KEY ON W/F-2018-PROPANE/GASOLINE-ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / LIFT LIGHT RELAY (10312-R1) 85 / E122-GB 16WH B12 E122-GC 16WH E122A 16GY E122B 16GY E122C 16GY / B122A 18GY / LIFT SPLICE (10370) / B44 18GY / ELEC PANEL/ PLATFORM (1703) CH13_58 ELEC PANEL/ PLATFORM (1703) CH15_11 B122D 18WH / L BODY/ REAR CAP (10405) B10 E122-GA 16WH / B122-GA 18WH B122R 18GY B122P 18GY B122N 16BN / ELEC PANEL/ L BODY (10401A/B) B12 / GROUND SPLICE (10335A) CH3_36 PLATFORM/ELEC PANEL (1703) CH15_11 / D122-GA 16WH @D122-GY 16GY B11 D122-GB 16WH D122-GC 16WH D122A 16GY D122B 16GY D122C 16GY / REAR CAP / R BODY (10700) CH15_12,13, 14,15,16, 17,18,19,20, 21,22,23 / #B44A 18GY / B122K 18GY / LIFT INTERLOCK RELAY (10312- R4) 86 / *B122H 18GY B122F 16GY / 30 LIFT INTERLOCK RELAY (10312-R5) / &&B122-G 18WH B44C B44B 18GY 18GY B44D 18GY / &B13A 18PK / B13 18PK B13 18PK &B122-G 18WH / &B122P 18PK / ACCESSORY SPLICE RELAY COILS (10369) CH3_30 GROUND SPLICE (10335A) CH3_36 ELEC PANEL /PLATFORM (1703) CH13_58 / B122E 16GY / B122J 18GY / ELEC PANEL/ SEALED ENG (11500) B7 Y122 16GY / @B122L 18GY @B122M 18GY / B122M 18GY / @B122N 18GY / WHEELCHAIR E1 LIFT SOLENOID / J4 BLUE BODY CONTROLLER (1601) / @ W/LIFT PWR & W/KEY ON/OFF && W/KEY ON * W/AIR BRAKE / ELEC PANEL/ PLATFORM (1702) 37 / A122J 18GY / B122D 16GY / FUSE B12-A (10301) CH3_12 / LIFT RELAY (11532A) CH15_03 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 618 / LIFT WITH HYDRAULIC BRAKE WITH KEY ON WITH F-2018 PROPANE / GASOLINE ENGINE

15.7. LIFT WITH HYDRAULIC BRAKE WITH KEY ON WITH INDICATOR LIGHT WITH
Figure 619 LIFT WITH HYDRAULIC BRAKE WITH KEY ON WITH INDICATOR LIGHT WITH F-2018

Components: CONTROLLER (1601); FUSE B12-A (10301); GROUND SPLICE (10335A); INDICATOR (10371); L BODY (10401A/B); PLATFORM (1702); PLATFORM (1703); PLATFORM/ELEC PANEL (1703); R BODY (10700); REAR CAP (10405); RELAY (10312-R1); RELAY (10312-R5); RELAY (11532A); RELAY COILS (10369); SEALED ENG (11500); SPLICE (10335A); SPLICE (10370)
Wires (circuit gauge+color): A122J 18GY; B122-G 18WH; B122-GA 18WH; B122A 18GY; B122D 16GY; B122D 18WH; B122E 16GY; B122F 16GY; B122H 18GY; B122J 18GY; B122K 18GY; B122L 18GY; B122M 18GY; B122N 16BN; B122N 18GY; B122P 18GY; B122P 18PK; B122R 18GY; B122T 16GY; B13 18PK; B13A 18PK; B44 18GY; B44B 18GY; B44C 18GY; B44D 18GY; D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122-GY 16GY; D122A 16GY; D122B 16GY; D122C 16GY; E122-GA 16WH; E122-GB 16WH; E122-GC 16WH; E122A 16GY; E122B 16GY; E122C 16GY; Y122 16GY
See also sheets: CH05_05, CH13_58, CH15_03, CH15_11, CH15_12, CH3_12, CH3_30, CH3_36
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.7. LIFT WITH HYDRAULIC BRAKE WITH KEY ON WITH INDICATOR LIGHT WITH F-2018 PROPANE / GASOLINE ENGINE, P. 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / CHAPTER 15 LIFT W/HYDRAULIC BRAKE W/KEY ON W/INDICATOR LT W/F-2018-PROPANE/GASOLINE-ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / LIFT LT RELAY (10312-R1) 85 / D122-GA 16WH @D122-GY 16GY B11 E122-GB D122-GB 16WH 16WH B12 E122-GC D122-GC 16WH 16WH C1 E122A D122A 16GY 16GY E122B D122B 16GY 16GY E122C D122C 16GY 16GY / B122A 18GY / LIFT SPLICE (10370) / B44 18GY / ELEC PANEL/ PLATFORM (1703) CH13_58 / L BODY/ REAR CAP (10405) B10 E122-GA 16WH / B122-GA 18WH B122R 18GY B122P 18GY B122N 16BN / ELEC PANEL/ L BODY (10401A/B) B12 / GROUND SPLICE (10335A) CH3_36 PLATFORM/ELEC PANEL (1703) CH15_11 / B44A A8GY / B122K 18GY / ELEC PANEL/ PLATFORM (1703) CH15_11 B122D 18WH / B122D 16GY / B122F 16GY / LIFT INTER-LOCK RELAY (10312 -R4) 86 / *B122H 18GY / 85 &B122P 18PK / B13 18PK B13 18PK &&B122-G 18WH B44C 18GY B44D 18GY 86 / B44B 18GY / B122E 16GY / B122J 18GY / @B122L @B122M 18GY 18GY / B122M 18GY / @B122N 18GY / LIFT RELAY (11532A) CH15_03 / J4 BLUE BODY CONTROLLER (1601) WHEELCHAIR LIFT SOLENOID / @ W/LIFT PWR & W/KEY ON/OFF && W/KEY ON * W/AIR BRAKE / ELEC PANEL/ PLATFORM (1702) 37 / A122J 18GY / B122N 16BN B122T 16GY / FUSE B12-A (10301) CH3_12 / REAR CAP / R BODY (10700) CH15_12,13, 14,15,16, 17,18,19,20, 21,22,23 / &B13A 18PK / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 619 / LIFT WITH HYDRAULIC BRAKE WITH KEY ON WITH INDICATOR LIGHT WITH F-2018 PROPANE / GASOLINE ENGINE

15.8. WHEELCHAIR LIFT INTERLOCK WITH AIR PARK BRAKE WITH KEY OFF WITH
Figure 620 WHEELCHAIR LIFT INTERLOCK WITH AIR PARK BRAKE WITH KEY OFF WITH LCT &

Components: ASSEMBLY CONN (1014F); BRAKE WHEEL CHAIR RELAY (1010-R3); CONTROLLER (1602); ELEC PANEL (1703/@1703C/1703); ENGINE/PLATFORM (1701); LEFT BODY (10401); LIFT RELAY (1010-R1); LIFT SPLICE (10370); PLATFORM/ELEC PANEL (1702); REFERENCE (1005); RELAY (10312-R5); RELAYS (1009); SHIFT INHIBIT RELAY (1011-R2); SOLENOID (4905); SPLICE (1003B)
Wires (circuit gauge+color): A122FA 18GY; A44C 18GY; A44C-G 18WH; A44D 18GY; A44E 18GY; A44F 18GY; A9CA 18GY; B122K 18GY; B122R 18GY; B44A 18GY; B44C 18GY; K44C 18GY
See also sheets: CH12_02, CH13_54, CH13_58, CH15_01, CH3_03, CH3_33, CH3_58
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.8. WHEELCHAIR LIFT INTERLOCK WITH AIR PARK BRAKE WITH KEY OFF WITH LCT & EATON XMSN WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 22JAN21 / CHAPTER 15 WHEELCHAIR LIFT INTERLOCK W/AIR PARK BRAKE W/KEY OFF W/ LCT & EATON XMSN W/2017/2021 ISB/B6.7 DIESEL ENG / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J5-TAN BODY CONTROLLER (1602) / WHEELCHAIR LIFT DOOR DIODE ASSEMBLY CONN (1014F) B / NEXT GEN HYDRULIC PARK BRAKE WHEEL CHAIR RELAY (1010-R3) CH13_58 SHIFT INHIBIT RELAY (1011-R2) CH12_02 / LIFT SPLICE (10370) CH15_01,02 / WHEEL CHAIR F13 DOOR SWITCH / A122FA 18GY A89CF 18VT A89CE 18VT / A89CB 18VT / WHEEL CHAIR LIFT RELAY 87A (1010-R1) / PLATFORM/ ELEC PANEL (1703/@1703C/1703) A7 B122K 18GY / A89CC 18VT / A9CA 18GY / &A44C-G 18WH / COIL SIGNAL ZVR RELAYS (1009) CH3_03 / ZERO VOLT (1005) CH3_58 / K44C 18GY / AIR PARK BRAKE SOLENOID (4905) CH13_54 / A44C 18GY / A44C-G 18WH ENGINE/PLATFORM (1701) / B122R 18GY / ELEC PANEL/ LEFT BODY (10401) CH15_01,02 GROUND SPLICE (1003B) CH3_33 / A89CD 18VT / @A44E 18GY / GROUND SPLICE (1003B) CH3_33 / @ W/1703C CAP CONNECTION & N/ WHEELCHAIR LIFT INTERLOCK / A44D 18GY / PARK BRAKE SW FOR WHEEL CHAIR (168M) / PLATFORM/ELEC PANEL (1702) 23 B44C 18GY / A44F 18GY / B44A 18GY / LIFT SPLICE (10370) CH15_01,02 / LIFT INTERLOCK RELAY (10312-R5) CH15_01,02 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 620 / WHEELCHAIR LIFT INTERLOCK WITH AIR PARK BRAKE WITH KEY OFF WITH LCT & EATON XMSN WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

15.9. WHEELCHAIR LIFT INTERLOCK WITH AIR PARK BRAKE WITH LCT & WTEC
Figure 621 WHEELCHAIR LIFT INTERLOCK WITH AIR PARK BRAKE WITH LCT & WTEC XMSN WITH

Components: ASSEMBLY CONN (1014F); CHAIR RELAY (1010-R3); CONTROLLER (1602); ELEC PANEL (1703/*1703C/1703); ENGINE (1701); LEFT BODY (10401); LIFT RELAY (1010-R1); REFERENCE (1005); RELAY (1011-R2); SOLENOID (4905); SPLICE (1003B); SPLICE (10370); ZVR RELAYS (1009)
Wires (circuit gauge+color): A122FA 18GY; A44C 18GY; A44C-G 18WH; A44E 18GY; A9CA 18GY; B122K 18GY; B122R 18GY; K44C 18GY
See also sheets: CH12_02, CH13_54, CH13_58, CH15_04, CH3_03, CH3_33, CH3_58
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.9. WHEELCHAIR LIFT INTERLOCK WITH AIR PARK BRAKE WITH LCT & WTEC XMSN WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE, P. 9 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 22JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J5-TAN BODY CONTROLLER (1602) WHEEL CHAIR F13 DOOR SWITCH / GROUND SPLICE (1003B) CH3_33 WHEELCHAIR LIFT DOOR DIODE ASSEMBLY CONN (1014F) B / A89CF 18VT A89CE 18VT / A89CB 18VT / 30 WHEEL CHAIR LIFT RELAY (1010-R1) 87A / A89CC 18VT / A9CA 18GY / A44C-G 18WH / GROUND SPLICE (1003B) CH3_33 COIL SIGNAL ZVR RELAYS (1009) CH3_03 / ZERO VOLT (1005) CH3_58 / PLATFORM/ ELEC PANEL (1703/*1703C/1703) A7 / *A44E 18GY / A89CD 18VT / A122FA 18GY / NEXT GEN HYDRULIC PARK BRAKE WHEEL CHAIR RELAY (1010-R3) CH13_58 SHIFT INHABIT RELAY (1011-R2) CH12_02 / PLATFORM/ ENGINE (1701) 52 / A44C 18GY / K44C 18GY / @A44C-G 18WH / B122K 18GY / LIFT SPLICE SPLICE (10370) CH15_04,05 / B122R 18GY / ELEC PANEL/ LEFT BODY (10401) CH15_04.05 / AIR PARK BRAKE SOLENOID (4905) CH13_54 / * W/1703C CAP CONNECTIONS @ N/ WHEELCHAIR LIFT INTERLOCK / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 621 / WHEELCHAIR LIFT INTERLOCK WITH AIR PARK BRAKE WITH LCT & WTEC XMSN WITH 2017 ISB / 2021 B6.7 DIESEL ENGINE

15.10. INTENTIONALLY LEFT BLANK, P. 10
Figure 622 INTENTIONALLY LEFT BLANK

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.10. INTENTIONALLY LEFT BLANK, P. 10 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090666 95885P 22JAN21 / INTENTIONALLY LEFT BLANK / CHAPTER 15 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / INTENTIONALLY LEFT BLANK / Figure 622 / INTENTIONALLY LEFT BLANK

15.11. WHEELCHAIR LIFT INTERLOCK WITH AIR PARK & HYDRAULIC BRAKE WITH
Figure 623 WHEELCHAIR LIFT INTERLOCK WITH AIR PARK & HYDRAULIC BRAKE WITH LCT XMSN

Components: ASSEMBLY CONN (1014F); CHAIR RELAY (1010-R3); CONTROLLER (1602); ELEC PANEL (1703/*1703C/1703); FUSE A3-A (1016); INTERLOCK RELAY (1010-R5); LEFT BODY (10401); LIFT RELAY (1010-R1); REFERENCE (1005); RELAY (1011-R2); SOLENOID (1012A); SPLICE (1003B); SPLICE (10370); ZVR RELAYS (1009)
Wires (circuit gauge+color): A122FA 18GY; A44C-G 18WH; A44E 18GY; A44H 18GY; A44J 18GY; A44K 18GY; A9CA 18GY; B122K 18GY; B122R 18GY; B44-GB 18WH; B44-GC 18WH; B44-GD 18WH; B44C 18GY
See also sheets: CH12_02, CH13_58, CH15_06, CH3_03, CH3_05, CH3_33, CH3_58
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.11. WHEELCHAIR LIFT INTERLOCK WITH AIR PARK & HYDRAULIC BRAKE WITH LCT XMSN WITH F-2018 PROPANE / GASOLINE ENGINE, P. 11 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 22JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J5-TAN BODY CONTROLLER (1602) WHEEL CHAIR F13 DOOR SWITCH / WHEELCHAIR LIFT DOOR DIODE ASSEMBLY CONN (1014F) B / A89CF 18VT A89CE 18VT / A89CB 18VT / 30 WHEEL CHAIR LIFT RELAY (1010-R1) 87A / A89CC 18VT / A9CA 18GY / A44C-G 18WH / COIL SIGNAL ZVR RELAYS (1009) CH3_03 / ZERO VOLT (1005) CH3_58 / PLATFORM/ ELEC PANEL (1703/*1703C/1703) A7 B122K 18GY / *A44E 18GY / A89CD 18VT / A122FA 18GY / NEXT GEN HYDRULIC PARK BRAKE WHEEL CHAIR RELAY (1010-R3) CH13_58 SHIFT INHIBIT RELAY (1011-R2) CH12_02 / 30 AIR PARK BRAKE INTERLOCK RELAY (1010-R5) 87A / A44K 18GY / B44C 18GY / A44J 18GY / FUSE A3-A (1016) CH3_05 / * W/1703C CAP CONNECTIONS @ N/LIFT INTERLOCK / AIR PARK BRAKE SOLENOID (1012A) / A44H 18GY / LIFT SPLICE SPLICE (10370) CH15_06,07 / ELEC PANEL/ LEFT BODY (10401) CH15_06,07 / GROUND SPLICE (1003B) CH3_33 / B122R 18GY / GROUND SPLICE (1003B) CH3_33 J4-BLUE BODY CONTROLLER (1602) / @B44-GB 18WH / @B44-GD 18WH / @B44-GC 18WH / B44-GC 18WH / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 623 / WHEELCHAIR LIFT INTERLOCK WITH AIR PARK & HYDRAULIC BRAKE WITH LCT XMSN WITH F-2018 PROPANE / GASOLINE ENGINE

15.12. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION
Figure 624 SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 1 TO 2, 3

Components: LIFT DOOR (10774A); R BODY (10700); R BODY/LIFT DOOR (10774C); REAR CAP (10405); SPLICE PACK (10422); TOGGLE SW (10782); VANDAL LOCK (10796)
Wires (circuit gauge+color): D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122-GY 16GY; D122A 16GY; D122B 16GY; D122C 16GY; D122D 16GY; D133B 18LTGN; D133D 18LTGN; F122-GA 16WH; F122-GA 18WH; F122-GB 16WH; F122-GB 18WH; F122-GC 16WH; F122-GC 18WH; F122A 16GY; F122A 18GY; F122AC 16GY; F122B 16GY; F122B 18GY; F122C 16GY; F122C 18GY; F122D 16GY; F133D 18LTGN; F133M 18LTGN
See also sheets: CH15_01, CH15_25, CH15_26, CH15_27
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.12. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 1 TO 2, 3 TO 4, P. 12 / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR CAP/ R BODY (10700) C4 / *F122A 16GY *F122-GC 16WH / *F122B 16GY *F122C 16GY *F122D 16GY *F133D 18LTGN #F133D 18LTGN R BODY/LIFT DOOR (10774C) A %F122-GA 122-GA 16WH 18WH / *F122-GA 16WH / D122-GA 16WH / D122-GB 16WH *D122-GY 16GY D122A 16GY D122-GC 16WH / D122B 16GY D122C 16GY D122D 16GY &D133D 18LTGN D133B 18LTGN / L BODY/ REAR CAP (10405) CH15_27 STARTER INTERLOCK SPLICE PACK (10422) CH15_25 / *F122-GB 16WH / R BODY/ LIFT DOOR (10774A) A / %F122B 16GY %F122C 16GY %F122AC 16GY W/8,9,10,11 WDO %F133D 18LTGN / %F122-GB 16WH %F122A 16GY %F122-GC 16WH / 122-GA 18WH 122-GB 18WH / 122A 18GY %%122-GC 18WH @@122-GC 18WH 122B 18GY @@122C 18GY 122D 18GY 133 16LTGN / 122-GB 18WH 122A 18GY %%122-GC 18WH @@122-GC 18WH **122B 18GY 122B 18GY @@122C 18GY 122D 18GY / 133 16LTGN / LIFT LT TOGGLE SW (10782) CH15_27 / LIFT DOOR SW/SPLICE CH15_26 / %F133M 18LTGN / L BODY/ REAR CAP (10405) CH15_01,02, 04,05,06,07, 31,34,35,38 / LIFT DOOR SW/SPLICE CH15_26 / LIFT LT TOGGLE SW (10782) CH15_27 LIFT DOOR VANDAL LOCK (10796) CH15_25 / #F122-GB 18WH / #F122A 18GY #F122-GC 18WH / #F122B 18GY #F122C 18GY #F122AC 16GY / #F122-GA 18WH / W/12,13 WDO / Figure 624 / SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 1 TO 2, 3 TO 4

15.13. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION
Figure 625 SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 2 TO 3

Components: R BODY/L DOOR (10774B); REAR CAP (10405); REAR CAP/R BODY (10700); SPLICE PACK (10422); TOGGLE SW (10782); VANDAL LOCK (10796)
Wires (circuit gauge+color): D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122-GY 16GY; D122A 16GY; D122B 16GY; D122C 16GY; D122D 16GY; D133B 18LTGN; D133D 18LTGN; F122-GA 16WH; F122-GB 16WH; F122-GC 16WH; F122-GW 16WH; F122-GX 16WH; F122-GY 16WH; F122A 16GY; F122B 16GY; F122C 16GY; F122D 16GY; F122W 16GY; F122X 16GY; F122Y 16GY; F133D 18LTGN
See also sheets: CH15_01, CH15_25, CH15_26, CH15_27, CH15_40
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.13. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 2 TO 3, P. 13 / CHAPTER 15 SINGLE LIFT DOOR INTERLOCK TO BRAKE AND XMSN IN SECTION 2 TO 3 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / MJV0488 19NOV21 ADDED EFFECTS OF W/ON V BATT. / REAR CAP/R BODY (10700) C4 / D122-GC 16WH / D122A 16GY / D122-GB 16WH *D122-GY 16GY / D122-GA 16WH / D122C 16GY / D122B 16GY / 122-GA 18WH / 122-GB 18WH / 122A 18GY / %%122-GC 18WH @@122-GC 18WH / 122B 18GY / @@122C 18GY / D122D 16GY / 122D 18GY / @F133D 18LTGN %F122Y 16GY / D133D 18LTGN D133B 18LTGN / 133 16LTGN / R BODY/L DOOR (10774B) / LIFT DOOR SW/SPLICE CH15_26 / L BODY / REAR CAP (10405) CH15_01,02,04, 05,06,07,31, 34,35,38 / L BODY/ REAR CAP (10405) CH15_27 STARTER INTERLOCK SPLICE PACK (10422) CH15_25 / LIFT LT TOGGLE SW (10782) CH15_27 LIFT DOOR VANDAL LOCK (10796) CH15_25 / # W/12 WINDOW * W/8,9,10,11 WINDOW @ W/8,9,11 WINDOW % W/10 WINDOW **W/10,11 WINDOW %%N/LT AND BUZZER @@W/LT AND BUZZER ^ W/LIFT W/DOOR SWITCH W/ON V BATT / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / ^D122B 16GY ^D122C 16GY / ^D122-GC 16WH / ^D122-GB 16WH / L BODY/ REAR CAP (10405) CH15_40 / Figure 625 / SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 2 TO 3

15.14. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION
Figure 626 SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 4 TO 5

Components: INTERLOCK (10422); LIFT DOOR (10774D); R BODY (10700); REAR CAP (10405); TOGGLE SW (10782); VANDAL LOCK (10796B)
Wires (circuit gauge+color): D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122-GY 16GY; D122A 16GY; D122B 16GY; D122C 16GY; D122D 16GY; D133B 18LTGN; D133D 18LTGN; F122-GA 16WH; F122-GB 16WH; F122-GC 16WH; F122-GD 16WH; F122-GE 16WH; F122-GF 16WH; F122A 16GY; F122AD 16GY; F122B 16GY; F122C 16GY; F122D 16GY; F122E 16GY; F122F 16GY; F133D 18LTGN; F133N 18LTGN
See also sheets: CH15_01, CH15_25, CH15_26, CH15_27
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.14. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 4 TO 5, P. 14 / CHAPTER 15 SINGLE LIFT DOOR INTERLOCK TO BRAKE AND XMSN IN SECTION 4 TO 5 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR CAP/ R BODY (10700) C4 / C7 D122-GC 16WH / @F122A 16GY *F122D 16GY / *F122E 16GY @F122B 16GY / D122-GA 16WH / D122-GB 16WH *D122-GY 16GY / D122A 16GY / D122B 16GY / D122C 16GY / #F122D 16GY ##F122AD 16GY *F133N 18LTGN @F133D 18LTGN / &D133D 18LTGN / D122D 16GY / D133B 18LTGN / LIFT DOOR VANDAL LOCK (10796B) CH15_25 / *F122-GE 16WH @F122-GB 16WH / @F122-GC 16WH *F122-GF 16WH / #F122C 16GY ##F122F 16GY / R BODY/ LIFT DOOR (10774D) / *F122-GD 16WH @F122-GA 16WH / 122-GB 18WH / 122-GA 18WH / 122D 18GY / 133 16LTGN / 122A 18GY / %%122-GC 18WH / @@122-GC 18WH 122B 18GY / @@122C 18GY / LIFT DOOR SW/SPLICE CH15_26 / & W/REAR AND LIFT DOOR * W/12,13 WDO @ W/5,9,10,11 WDO # W/5,9,10,11,13 WDO ## W/12 WDO %% N/LT SPLICE & BUZZER @@ W/LT SPLICE & BUZZER / LIFT LT TOGGLE SW (10782) CH15_27 / L BODY/ REAR CAP (10405) CH15_01,02, 04,05,06,07, 31,34,35,38 / L BODY / REAR CAP (10405) CH15_27 / SPLICE PACK STARTER INTERLOCK (10422) CH15_25 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 626 / SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 4 TO 5

15.15. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION
Figure 627 SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 4 TO 5, 5

Components: LIFT DOOR (10774E); R BODY (10700); REAR CAP (10405); SPLICE PACK (10422); TOGGLE SW (10782); VANDAL LOCK (10796)
Wires (circuit gauge+color): D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122-GY 16GY; D122A 16GY; D122B 16GY; D122C 16GY; D122D 16GY; D133B 18LTGN; D133D 18LTGN; F122-GA 16WH; F122-GB 16WH; F122-GC 16WH; F122-GH 16WH; F122-GJ 16WH; F122-GK 16WH; F122A 16GY; F122AE 16GY; F122B 16GY; F122C 16BN; F122C 16GY; F122D 16BK; F122D 16GY; F122H 16GY; F122J 16GY; F122K 16GY; F133D 18LTGN; F133P 18LTGN
See also sheets: CH15_01, CH15_25, CH15_26, CH15_27
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.15. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 4 TO 5, 5 TO 6, P. 15 / CHAPTER 15 SINGLE LIFT DOOR INTERLOCK TO BRAKE AND XMSN IN SECTION 4 TO 5, 5 TO 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR CAP/ R BODY (10700) C4 / D122D 16GY / *F122-GA 16WH #F122-GH 16WH / *F122-GC 16WH #F122-GK 16WH / R BODY/ LIFT DOOR (10774E) A 122-GA 18WH / *F122A 16GY #F122H 16GY / D122-GA 16WH / *F122B 16GY #F122J 16GY **F122C 16GY @F122K 16GY @@F122C 16BN **F122D 16GY @F122AE 16GY @@F122D 16BK *F133D 18LTGN #F133P 18LTGN / D122A 16GY / 122-GB 18WH / 122D 18GY / ##122-GC 18WH 122B 18GY / LIFT DOOR SW/SPLICE CH15_26 / %%122-GC 18WH / @@122C 18GY / C7 D122-GC 16WH / D122-GB 16WH *D122-GY 16GY / D122C 16GY / &D133D 18LTGN / D133B 18LTGN / D122B 16GY / *F122-GB 16WH #F122-GJ 16WH / LIFT LT TOGGLE SW (10782) CH15_27 / 133 16LTGN / 122A 18GY / L BODY/ REAR CAP (10405) CH15_01,02, 04,05,06,07, 31,34,35,38 / LIFT DOOR VANDAL LOCK (10796) CH15_25 / L BODY/ REAR CAP (10405) CH15_27 / STARTER INTERLOCK SPLICE PACK (10422) CH15_25 / Figure 627 / SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 4 TO 5, 5 TO 6

15.16. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION
Figure 628 SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 6 TO 7

Components: LIFT DOOR (10774F); R BODY (10700); REAR CAP (10405); SPLICE PACK (10422); TOGGLE SW (10782); VANDAL LOCK (10796)
Wires (circuit gauge+color): D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122-GY 16GY; D122A 16GY; D122B 16GY; D122C 16GY; D122D 16BK; D133B 18LTGN; D133D 18LTGN; F122-GA 16WH; F122-GB 16WH; F122-GC 16WH; F122-GL 16WH; F122-GM 16WH; F122-GN 16WH; F122A 16GY; F122AF 16GY; F122B 16GY; F122C 16GY; F122D 16GY; F122L 16GY; F122M 16GY; F122N 16GY; F133D 18LTGN; F133R 18LTGN
See also sheets: CH15_01, CH15_25, CH15_26, CH15_27
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.16. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 6 TO 7, P. 16 / CHAPTER 15 SINGLE LIFT DOOR INTERLOCK TO BRAKE AND XMSN IN SECTION 6 TO 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / #F122-GL 16WH *F122-GA 16WH / *F122A 16GY #F122L 16GY / #F122M 16GY *F122B 16GY / *F122-GB 16WH #F122-GM 16WH / **F122N 16GY @F122C 16GY #F133R 18LTGN *F133D 18LTGN / LIFT DOOR SW/SPLICE CH15_26 / 122-GA 18WH / 122-GB 18WH / 122A 18GY / %%122-GC 18WH @@122-GC 18WH 122B 18GY / @@122C 18BN / *F122-GC 16WH #F122-GN 16WH / D122-GA 16WH / D122-GB 16WH ##D122-GY 16GY / D122A 16GY / D122-GC 16WH / D122B 16GY / D122C 16GY / 133 16LTGN / 122D 18GY / **F122AF 16GY @F122D 16GY / &D133D 18LTGN / D122D 16BK / D133B 18LTGN / REAR CAP/ R BODY (10700) / LIFT LT TOGGLE SW (10782) CH15_27 / R BODY/ LIFT DOOR (10774F) / LIFT DOOR VANDAL LOCK (10796) CH15_25 / STARTER INTERLOCK SPLICE PACK (10422) CH15_25 / L BODY/ REAR CAP (10405) CH15_27 / L BODY/ REAR CAP (10405) CH15_01,02, 04,05,06,07, 31,34,35,38 / Figure 628 / SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 6 TO 7

15.17. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION
Figure 629 SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 7 TO 8

Components: LIFT DOOR (10774G); R BODY (10700); REAR CAP (10405); SPLICE PACK (10422); TOGGLE SW (10782); VANDAL LOCK (10796)
Wires (circuit gauge+color): D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122-GY 16GY; D122A 16GY; D122B 16GY; D122C 16GY; D122D 16GY; D133B 18LTGN; D133D 18LTGN; F122-GA 16WH; F122-GB 16WH; F122-GC 16WH; F122-GP 16WH; F122-GR 16WH; F122-GS 16WH; F122A 16GY; F122AH 16GY; F122B 16GY; F122C 16GY; F122D 16GY; F122P 16GY; F122R 16GY; F122S 16GY; F133D 18LTGN; F133S 18LTGN
See also sheets: CH15_01, CH15_25, CH15_26, CH15_27
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.17. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 7 TO 8, P. 17 / CHAPTER 15 SINGLE LIFT DOOR INTERLOCK TO BRAKE AND XMSN IN SECTION 7 TO 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A A / REAR CAP/ R BODY (10700) C4 / *F122-GA 16WH #F122-GP 16WH *F122-GB 16WH #F122-GR 16WH *F122A 16GY #F122P 16GY *F122-GC 16WH #F122-GS 16WH / *F122B 16GY #F122R 16GY @F122C 16GY **F122S 16GY #F133S 18LTGN *F133D 18LTGN / R BODY/ LIFT DOOR (10774G) / 122-GA 18WH / 122-GB 18WH / 122A 18GY / %%122-GC 18WH @@122-GC 18WH / 122B 18GY / @@122C 18GY / D122-GA 16WH / D122-GB 16WH *D122-GY 16GY D122A 16GY / D122-GC 16WH / D122B 16GY / D122C 16GY / 122D 18GY / @F122D 16GY / **F122AH 16GY / 133 16LTGN / &D133D 18LTGN / D122D 16GY / D133B 18LTGN / LIFT DOOR SW/SPLICE CH15_26 / LIFT LT TOGGLE SW (10782) CH15_27 / L BODY / REAR CAP (10405) CH15_01,02, 04,05,06,07, 31,34,35,38 / LIFT DOOR VANDAL LOCK (10796) CH15_25 / STARTER INTERLOCK SPLICE PACK (10422) CH15_25 / L BODY / REAR CAP (10405) CH15_27 / Figure 629 / SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 7 TO 8

15.18. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION
Figure 630 SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 8 TO 9

Components: R BODY/LIFT DOOR (10774H); REAR CAP (10405); REAR CAP/R BODY (10700); STARTER INTERLOCK (10422); TOGGLE SW (10782); VANDAL LOCK (10796)
Wires (circuit gauge+color): D122-GA 16WH; D122-GB 16WH; D122-GY 16GY; D122A 16GY; D122B 16GY; D122C 16GY; D122D 16GY; D122GC 16WH; D133B 18LTGN; D133D 18LTGN; F122-GA 16WH; F122-GB 16WH; F122-GC 16WH; F122-GT 16WH; F122-GU 16WH; F122-GV 16WH; F122A 16GY; F122B 16GY; F122C 16GY; F122D 16GY; F122T 16GY; F122U 16GY; F133D 18LTGN; F133T 18LTGN
See also sheets: CH15_01, CH15_25, CH15_26, CH15_27
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.18. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 8 TO 9, P. 18 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / CHAPTER 15 SINGLE LIFT DOOR INTERLOCK TO BRAKE AND XMSN IN SECTION 8 TO 9 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR CAP/R BODY (10700) C4 / R BODY/LIFT DOOR (10774H) A 122-GA *F122-GA 16WH 18WH #F122-GT 16WH / *F122-GB 16WH #F122-GU 16WH / *F122A 16GY / #F122T 16GY *F122-GC 16WH #F122-GV 16WH / *F122B 16GY #F122U 16GY **F122C 16GY / LIFT LT TOGGLE SW (10782) CH15_27 LIFT DOOR VANDAL LOCK (10796) CH15_25 / D122GC 16WH / D122-GB 16WH *D122-GY 16GY D122A 16GY / D122-GA 16WH / D122C 16GY / D122B 16GY / L BODY/ REAR CAP (10405) CH15_27 / D122D 16GY / **F122D 16GY / &D133D 18LTGN D133B 18LTGN / *F133D 18LTGN #F133T 18LTGN / 122-GB 18WH / 122A 18GY / %%122-GC 18WH @@122-GC 18WH 122B 18GY / @@122C 18GY / 122D 18GY / 133 16LTGN / L BODY/ REAR CAP (10405) CH15_01,02, 04,05,06,07, 31,34,35,38 / SPLICE PACK STARTER INTERLOCK (10422) CH15_25 / & W/REAR AND LIFT DOOR * W/9,10 WDO # W/13 WDO ** W/9,10,13 WDO %% N/LT SPLICE & BUZZER @@ W/LT SPLICE & BUZZER / LIFT DOOR SW/SPLICE CH15_26 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 630 / SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 8 TO 9

15.19. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION
Figure 631 SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 9 TO 10

Components: R BODY/LIFT DOOR (10774J); REAR CAP (10405); REAR CAP/R BODY (10700); SPLICE PACK (10422); TOGGLE SW (10782); VANDAL LOCK (10796)
Wires (circuit gauge+color): D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122-GY 16GY; D122A 16GY; D122B 16GY; D122C 16GY; D122D 16GY; D133B 18LTGN; D133D 18LTGN; F122-GA 16WH; F122-GB 16WH; F122-GC 16WH; F122A 16GY; F122B 16GY; F122C 16GY; F122D 16GY; F133D 18LTGN
See also sheets: CH15_01, CH15_25, CH15_26, CH15_27
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.19. SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 9 TO 10, P. 19 / CHAPTER 15 SINGLE LIFT DOOR INTERLOCK TO BRAKE AND XMSN IN SECTION 9 TO 10 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR CAP/R BODY (10700) C4 / R BODY/LIFT DOOR (10774J) A 122-GA 18WH / D122-GC 16WH / D122A 16GY / D122-GB 16WH *D122-GY 16GY / D122-GA 16WH / D122C 16GY / F122-GA 16WH / D122B 16GY / LIFT LT TOGGLE SW (10782) CH15_27 LIFT DOOR VANDAL LOCK (10796) CH15_25 / D133B 18LTGN / F122D 16GY / &D133D 18LTGN / F133D 18LTGN / 122D 18GY / 133 16LTGN / L BODY/ REAR CAP (10405) CH15_27 STARTER INTERLOCK SPLICE PACK (10422) CH15_25 / D122D 16GY / F122-GB 16WH / F122A 16GY / F122-GC 16WH / F122B 16GY / F122C 16GY / 122-GB 18WH / %%122-GC 18WH @@122-GC 18WH 122B 18GY / @@122C 18GY / 122A 18GY / LIFT DOOR SW/SPLICE CH15_26 / L BODY/ REAR CAP (10405) CH15_01,02, 04,05,06,07, 31,34,35,38 / & W/REAR AND LIFT DOOR * W/LIFT PWR %% N/LT SPLICE & BUZZER @@ W/LT SPLICE & BUZZER / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 631 / SINGLE LIFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 9 TO 10

15.20. SINGLE LEFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION
Figure 632 SINGLE LEFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 10 TO 11

Components: INTERLOCK (10422); R BODY/LIFT DOOR (10774K); REAR CAP (10405); REAR CAP/R BODY (10700); TOGGLE SW (10782); VANDAL LOCK (10796)
Wires (circuit gauge+color): D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122-GY 16GY; D122A 16GY; D122B 16GY; D122C 16GY; D122D 16GY; D133B 18LTGN; D133D 18LTGN; F122-GA 16WH; F122-GB 16WH; F122-GC 16WH; F122A 16GY; F122B 16GY; F122C 16BN; F122D 16BK; F133D 18LTGN
See also sheets: CH15_01, CH15_25, CH15_26, CH15_27
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.20. SINGLE LEFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 10 TO 11, P. 20 / CHAPTER 15 SINGLE LIFT DOOR INTERLOCK TO BRAKE AND XMSN IN SECTION 10 TO 11 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR CAP/R BODY (10700) C4 / F122-GA 16WH / F122-GB 16WH / F122A 16GY / F122-GC 16WH / F122B 16GY / F122C 16BN / D122-GC 16WH / D122-GB 16WH *D122-GY 16GY D122A 16GY / D122-GA 16WH / D122C 16GY / D122B 16GY / 122-GA 18WH / 122-GB 18WH / 122A 18GY / %%122-GC 18WH @@122-GC 18WH / 122B 18GY / @@122C 18GY / F122D 16BK / D122D 16GY / 122D 18GY 133 16LTGN / F133D 18LTGN / D133B 18LTGN &D133D 18LTGN / R BODY/LIFT DOOR (10774K) / LIFT DOOR SW/SPLICE CH15_26 / L BODY/ REAR CAP (10405) CH15_01,02, 04,05,06,07, 31,34,35,38 / L BODY/ REAR CAP (10405) CH15_27 SPLICE PACK STARTER INTERLOCK (10422) CH15_25 / LIFT LT TOGGLE SW (10782) CH15_27 LIFT LIFT DOOR DOOR VANDAL VANDAL LOCK LOCK (10796) (10796) CH15_25 CH15_25 / & W/REAR AND LIFT DOOR * W/LIFT PWR %% W/LT SPLICE & BUZZER @@ N/LT SPLICE & BUZZER / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 632 / SINGLE LEFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 10 TO 11

15.21. SINGLE LEFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION
Figure 633 SINGLE LEFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 11 TO 12

Components: R BODY/LIFT DOOR (10774L); REAR CAP (10405); REAR CAP/R BODY (10700); SPLICE PACK (10422); TOGGLE SW (10782); VANDAL LOCK (10796)
Wires (circuit gauge+color): D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122-GY 16GY; D122A 16GY; D122B 16GY; D122C 16GY; D122D 16GY; D133B 18LTGN; D133D 18LTGN; F122-GP 16WH; F122-GT 16WH; F122-GV 16WH; F122A 16GY; F122AK 16GY; F122B 16GY; F122C 16GY; F122T 18LTGN
See also sheets: CH15_01, CH15_25, CH15_26, CH15_27
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.21. SINGLE LEFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 11 TO 12, P. 21 / CHAPTER 15 SINGLE LIFT DOOR INTERLOCK TO BRAKE AND XMSN IN SECTION 11 TO 12 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR CAP/R BODY (10700) C4 / F122-GT 16WH / F122-GV 16WH / F122C 16GY / F122-GP 16WH / F122A 16GY / F122B 16GY / D122-GC 16WH / D122-GB 16WH *D122-GY 16GY D122A 16GY / D122-GA 16WH / D122C 16GY / D122B 16GY / 122-GA 18WH / 122-GB 18WH / 122A 18GY / %%122-GC 18WH @@122-GC 18WH / 122B 18GY / @@122C 18GY / F122AK 16GY / D122D 16GY / 122D 18GY 133 16LTGN / F122T 18LTGN / D133B 18LTGN &D133D 18LTGN / R BODY/LIFT DOOR (10774L) / LIFT DOOR SW/SPLICE CH15_26 / L BODY/ REAR CAP (10405) CH15_01,02, 04,05,06,07, 31,34,35,38 / L BODY/ REAR CAP (10405) CH15_27 STARTER INTERLOCK SPLICE PACK (10422) CH15_25 / LIFT LT TOGGLE SW (10782) CH15_27 LIFT DOOR VANDAL LOCK (10796) CH15_25 / & W/REAR AND LIFT DOOR * W/LIFT PWR %% W/ LT SPLICE & BUZZER @@ N/ LT SPLICE & BUZZER / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 633 / SINGLE LEFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 11 TO 12

15.22. SINGLE LEFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION
Figure 634 SINGLE LEFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 12 TO 13

Components: R BODY/LIFT DOOR (10774M); REAR CAP (10405); REAR CAP/R BODY (10700); SPLICE PACK (10422); TOGGLE SW (10782); VANDAL LOCK (10796)
Wires (circuit gauge+color): D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122-GY 16GY; D122A 16GY; D122B 16GY; D122C 16GY; D122D 16GY; D133B 18LTGN; D133D 18LTGN; F122-GT 16WH; F122-GU 16WH; F122-GV 16WH; F122C 16GY; F122D 16GY; F122T 16GY; F122T 18LTGN; F122U 16GY
See also sheets: CH15_01, CH15_25, CH15_26, CH15_27
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.22. SINGLE LEFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 12 TO 13, P. 22 / CHAPTER 15 SINGLE LIFT DOOR INTERLOCK TO BRAKE AND XMSN IN SECTION 12 TO 13 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR CAP/R BODY (10700) C4 / F122-GT 16WH / F122-GU 16WH / F122T 16GY / F122-GV 16WH / F122U 16GY / F122C 16GY / D122-GC 16WH / D122-GB 16WH *D122-GY 16GY D122A 16GY / D122-GA 16WH / D122C 16GY / D122B 16GY / 122-GA 18WH / 122-GB 18WH / 122A 18GY / %%122-GC 18WH @@122-GC 18WH / 122B 18GY / @@122C 18GY / F122D 16GY / D122D 16GY / 122D 18GY / F122T 18LTGN / D133B 18LTGN &D133D 18LTGN / 133 16LTGN / R BODY/LIFT DOOR (10774M) / LIFT DOOR SW/SPLICE CH15_26 / L BODY/ REAR CAP (10405) CH15_01,02, 04,05,06,07, 31,34,35,38 / LIFT LT TOGGLE SW (10782) CH15_27 LIFT DOOR VANDAL LOCK (10796) CH15_25 / L BODY/ REAR CAP (10405) CH15_27 STARTER INTERLOCK SPLICE PACK (10422) CH15_25 / & W/REAR AND LIFT DOOR * W/LIFT PWR %% W/LT SPLICE & BUZZER @@ N/LT SPLICE & BUZZER / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 634 / SINGLE LEFT DOOR INTERLOCK TO BRAKE AND TRANSMISSION IN SECTION 12 TO 13

15.23. 48 INCH ALTERNATE ENTRANCE DOOR INTERLOCK TO BRAKE AND XMSN IN
Figure 635 48 INCH ALTERNATE ENTRANCE DOOR INTERLOCK TO BRAKE AND XMSN IN SECTION

Components: MIRAGE LIFT DOOR (10807A/*10807B); REAR CAP (10405); REAR CAP/R BODY (10700)
Wires (circuit gauge+color): D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122A 16GY; D122B 16GY; D122C 16GY; F122AJ 16GY; F122AK 16GY; F122AL 16GY; F122AM 16GY; F122AN 16GY; F122AP 16GY; F122GAC 16WH; F122GAD 16WH; F122GAE 16WH
See also sheets: CH15_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.23. 48 INCH ALTERNATE ENTRANCE DOOR INTERLOCK TO BRAKE AND XMSN IN SECTION 7 TO 8, 8 TO 9, P. 23 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / CHAPTER 15 48 INCH ALTERNATE ENTRANCE DOOR INTERLOCK TO BRAKE AND XMSN IN SECTION 7 TO 8, 8 TO 9 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / F122GAC 16WH / F122GAD 16WH / F122AJ 16GY / F122GAE 16WH / F122AK 16GY / F122AL 16GY / MIRAGE LIFT DOOR (10807A/*10807B) / REAR CAP/R BODY (10700) / D122-GC 16WH / D122A 16GY / D122-GB 16WH / D122-GA 16WH / D122B 16GY / L BODY / REAR CAP (10405) CH15_01,02, 04,05,06,07, 31,34,35,38 / F122AM 16GY F122AN 16GY F122AP 16GY / D122C 16GY / * W/ SECTION 8-9, W/12 & 13 WDO ONLY / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 635 / 48 INCH ALTERNATE ENTRANCE DOOR INTERLOCK TO BRAKE AND XMSN IN SECTION 7 TO 8, 8 TO 9

15.24. PUPIL WARNING LIGHTS ACTIVATED BY LIFT DOOR OPEN, P. 24
Figure 636 PUPIL WARNING LIGHTS ACTIVATED BY LIFT DOOR OPEN

Components: FUSE B12-A (10301); LIFT SPLICE (10370); LIGHT RELAY (10311-R2); PWL RELAY (10308-R3); SPLICE (10402); ZVR SPLICE (10350A)
Wires (circuit gauge+color): B123CK 18LTGN; B123D 18LTGN; B123E 18LTGN; B44 18GY; B63-G 16WH; B9F 18LTGN
See also sheets: CH3_12, CH3_60, CH6_22, CH8_56
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.24. PUPIL WARNING LIGHTS ACTIVATED BY LIFT DOOR OPEN, P. 24 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / CHAPTER 15 PUPIL WARNING LIGHTS ACTIVATED BY LIFT DOOR OPEN / MJV0488 19NOV21 CIRC B123CK WAS B123C B AT CAV E OF R/D 10370. / @B9F 18LTGN / B123E 18LTGN / PWL RELAY (10308-R3) / PWL OVERRIDE SPLICE (10402) CH6_22 / B44 18GY / B123CK 18LTGN B123D 18LTGN / ZVR SPLICE (10350A) CH3_60 / LIFT SPLICE (10370) A / FUSE B12-A (10301) CH3_12 / @ W/DOOR OPEN ONLY / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / B63-G 16WH / REAR DOME LIGHT RELAY (10311-R2) CH8_56 / Figure 636 / PUPIL WARNING LIGHTS ACTIVATED BY LIFT DOOR OPEN

15.25. LIFT DOOR WITH STARTER INTERLOCK, P. 25
Figure 637 LIFT DOOR WITH STARTER INTERLOCK

Components: BUZZER RELAY (10310-R4); DIODE B3-X (10304); ELEC PANEL (10400); ELEC PANEL (1702); ENGINE (1701); FR CAP (10000); FUSE A1-E (10305); INTERLOCK (10422); INTERRUPT (1008M/1008F); INTERRUPT (10106/10106A); LIFT DOOR/R BODY (10774#); R BODY (10700); R BODY/LIFT DOOR (10774); REAR CAP (10405); RELAY (1010-R2); RELAY (10313-R2); SPLICE PACK (10382); STARTER INTERRUPT (1008F/1008M); VANDAL LOCK (10312-R6); VANDAL LOCK (10796)
Wires (circuit gauge+color): A17B 16PK; A17CB 18PK; B117K 18LTGN; B133A 16LTGN; B133D 18LTGN; B133E 18LTGN; B133F 18LTGN; B133H 18LTGN; B133T 18LTGN; B17 18LTGN; B17B 18LTGN; B17C 18LTGN; D133B 16LTGN; D133B 18LTGN; D133C 16LTGN; D133D 16LTGN; D133D 18LTGN; E133A 18LTGN; E133B 18LTGN; F122T 18LTGN; F122Y 16GY
See also sheets: CH14_29, CH15_12, CH15_13, CH15_21, CH16_19, CH16_26, CH19_40, CH3_19, CH4_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.25. LIFT DOOR WITH STARTER INTERLOCK, P. 25 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / CHAPTER 15 LIFT DOOR WITH STARTER INTERLOCK / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / L BODY/ REAR CAP (10405) B7 E133B 18LTGN / %D133C 16LTGN REAR CAP/ D133D R BODY 16LTGN (10700) %D133D F133* 18LTGN 18LTGN / %D133B 16LTGN @D133B 18LTGN / 133 16LTGN / L BODY/ ELEC PANEL (10400) C11 E133A B133F 18LTGN 18LTGN / SPLICE PACK STARTER INTERLOCK (10422) A / ##B133D 18LTGN / B17C 18LTGN / STARTER INTERRUPT (1008F/1008M) A A17B B17 16PK 18LTGN / STARTER INTERRUPT (1008M/1008F) A A17CB B17B 18PK 18LTGN / FUSE A1-E (10305) CH3_19 / DIODE B3-X (10304) B133E B117K 18LTGN 40 36 18LTGN / LIFT DOOR VANDAL LOCK (10796) A / **D133B 16LTGN / ##B133H 18LTGN B133A 16LTGN / STARTER INTERLOCK RELAY (10313-R2) / A B C D E / %%B133T 18LTGN / ALTERNATE ENTRANCE DOOR VANDAL LOCK (10312-R6) CH19_40 / %%B133D 18LTGN / % W/REAR AND LIFT DOOR VANDAL LOCK @ W/LIFT DOOR VANDAL LOCK ** W/REAR DOOR VANDAL LOCK ## N/LOCKING COMPARTMENT %% W/LOCKING COMPARTMENT / STARTER INTERLOCK SPLICE PACK (10382) / PLATFORM/ ENGINE (1701) CH4_01,02 / LIFT DOOR/R BODY (10774#) CH15_12,13,14, 15,16,17,18, 19,20,21,22 / F122Y 16GY F122T 18LTGN / THERMAL OVERCRANK PROTECTION RELAY (1010-R2) CH4_01 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 637 / LIFT DOOR WITH STARTER INTERLOCK

15.26. LIFT DOOR SWITCH CONNECTION, P. 26
Figure 638 LIFT DOOR SWITCH CONNECTION

Components: BUZZER (10784); BUZZER SW (10834B); DOOR SW (10790); DOOR SW (10791); DOOR SW (10792); DOOR SW (10794); LIFT DOOR (10774A/C/D/E/F/G/H/J/K); LIFT DOOR LT (10795); LIFT DOOR SW (10793); PACK (10787); SPLICE (10780)
See also sheets: CH15_12, CH15_27, CH15_28, CH15_38
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.26. LIFT DOOR SWITCH CONNECTION, P. 26 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / CHAPTER 15 / LIFT DOOR SW CONNECTION / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / **122-GE 18WH ##122-GE 16WH 122-GF 18WH &122-GF 18WH &122-GG 18WH 122-GG 18WH %122-GM 18WH / ***122-GL 18WH / @@122-GC 18WH / @122-GM 18WH / LIFT DOOR BUZZER (10784) A / LIFT DOME LT (10788B) CH15_28 / LIFT DOOR SW (10790) * LIFT 1 DOOR SW 4 LIFT DOOR SW (10794) / 122-GA 122-GB %%122-GC 122B 18GY 18WH 18WH 122A 18GY 18WH / @122G 18GY ***122E 18GY %122G 18GY @@122C 18GY / ^122F 18GY / LIFT LIFT DOOR DOOR LTS LTS (10781/ (10781/ 122-GP 10789) 10789) 16WH CH15_38 CH15_27 / LIFT DOOR SW (10792) / LIFT SPLICE (10780) E D / LIFT DOOR SW (10791) / 2 5 / @@122-GE 18WH / ^122-GH 18WH / LIFT DOOR BUZZER SW (10834B) A / **122L 18GY ^122 18GY &122 18GY &122F 18GY / DIODE PACK (10787) CH15_28 / 3 6 / R BODY / LIFT DOOR (10774A/C/D/E/F/G/H/J/K) CH15_12,13,14,15,16,17, 18,19,20,21,22 / @@122-GD 18WH / LIFT DOOR LT (10781/ 10789) CH15_27 / LIFT DOOR SW (10793) / LIFT DOOR LT (10781/ 10789) CH15_38 / &122-GH 18WH / Figure 638 / LIFT DOOR SWITCH CONNECTION

15.27. LIFT EXTERIOR LIGHT, P. 27
Figure 639 LIFT EXTERIOR LIGHT

Components: DOME LT (10785); DOOR LT (10781); DOOR LT (10789); FUSE B12-A (10301); L BODY (10401); LIFT DOOR (10774#); LIFT DOOR LT (10795); LIFT SPLICE (10370); LIFT SPLICE (10780); R BODY (10700); REAR CAP (10405); SPLICE (10780); TOGGLE SW (10782); TOGGLE SW (10783)
Wires (circuit gauge+color): B122E 16GY; B122S 16GY; B44 18GY; D122D 16GY; E122D 16GY
See also sheets: CH15_12, CH15_26, CH3_12
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.27. LIFT EXTERIOR LIGHT, P. 27 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / CHAPTER 15 / LIFT EXTERIOR LIGHT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 122K 122K 18GY 18GY 122-GK 18WH / REAR CAP/ R BODY (10700) CH15_12,13,14, 15,16,17,18,19, 20,21,22 R BODY/ LIFT DOOR (10774#) CH15_12,13,14, 15,16,17,18,19, 20,21,22 LIFT LT TOGGLE SW (10782) A / LIFT SPLICE (10780) CH15_26 / ELEC PANEL/ L BODY (10401) C6 E122D B122S 16GY 16GY / D122D 16GY / LIGHT, EXTERIOR LIFT DOOR ACTIVATED - MOUNTED BELOW LIFT DOOR IN SKIRT / LIGHT, EXTERIOR LIFT DOOR ACTIVATED - MOUNTED HI ON LIFT DOOR POST / L BODY/ REAR CAP (10405) C4 / CEILING MOUNTED DOME LT (10785) / LOWER POST LIFT DOOR LT (10795) / 122D 18GY / 122J 18GY / LIFT SPLICE (10780) CH15_26 / 122E 18GY 122-GJ 18WH / 122-GH 18WH / SKIRT LIFT DOOR LT (10781) 1 / 122 18GY / 122-GG 18WH / UPPER LIFT DOOR LT (10789) 1 / 122F 18GY 122-GF 18WH / LIFT SPLICE (10370) / LIFT SPLICE (10780) CH15_26 / FUSE B12-A (10301) CH3_12 / B44 18GY / LIFT LT TOGGLE SW (10783) / B122E 16GY / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 639 / LIFT EXTERIOR LIGHT

15.28. LIFT INTERIOR LIGHT, P. 28
Figure 640 LIFT INTERIOR LIGHT

Components: DIODE PACK (10787); DOOR LT (10831); DOOR LT (10832); DOOR LT (10833); LIFT SPLICE (10780); STD DOME LT (10786B)
See also sheets: CH15_26
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.28. LIFT INTERIOR LIGHT, P. 28 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / CHAPTER 15 / LIFT INTERIOR LT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / LIFT SPLICE (10780) CH15_26 MID LIFT DOOR LT (10833) 2 / LIFT SPLICE (10780) CH15_26 / 122F 18GY / LIFT DOME LT (10788B) B / ***122-GL 18WH %122-GL 18WH / %122-GM 18WH / %122E 18GY / @122E 18GY / ***122E 18GY / %122-GN 18WH / %122H 18GY / MID LIFT DOOR LT (10831) 1 / DIODE PACK (10787) / MID LIFT DOOR LT (10832) @122H 1 18GY / @122-GP 18WH / @122-GN 18WH / @122-GM 18WH / %122G 18GY / @122G 18GY / 63 18DKBL / @122M 18GY / *** LIFT DOOR ACTIVATED - MTD IN DOOR HEADER @ LIFT DOOR ACTIVATED W/ TWO EXTERIOR LTS % LIFT DOOR ACTIVATED W/ EXTERIOR LTS / @122-GL 18WH / INPUT FROM STD DOME LT (10786B) / LIFT SPLICE (10780) CH15_26 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 640 / LIFT INTERIOR LIGHT

15.29. LIFT DOOR INDICATOR, P. 29
Figure 641 LIFT DOOR INDICATOR

Components: CIRCUIT (10010); FR CAP (10000); LIFT DOOR INDICATOR (10032B); LIFT DOOR INDICATOR (1033B); LIFT INDICATOR LT (10032A); LIFT INDICATOR LT (10033A); LIFT SPLICE (10370)
Wires (circuit gauge+color): B122AA 16WH; B122Z 16GY; C122 16DKBL; C122 16GY; C122-G 16WH; C122A 16DKBL; C122G 16WH
See also sheets: CH15_04, CH15_39, CH3_44
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.29. LIFT DOOR INDICATOR, P. 29 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / CHAPTER 15 / LIFT DOOR INDICATOR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / *C122-G 16WH #C122-G 16WH *C122 16GY #C122 16GY / @C122 16DKBL @C122-G 16WH / LIFT SPLICE (10370) CH15_04 / GROUND CIRCUIT (10010) CH3_44 / &B122AA 16WH &B122Z 16GY ^B122AA 16WH ^B122Z 16GY / ELEC PANEL/ FR CAP (10000) / LIFT DOOR LT (*11026/#11027) / LIFT DOOR INDICATOR (10032B) A / LIFT DOOR INDICATOR (1033B) / LIFT INDICATOR LT (10032A) A / C122A 16DKBL C122G 16WH / GROUND CIRCUIT (10010) CH3_44 / LIFT INDICATOR LT (10033A) / LIFT SPLICE (10370) CH15_39 / Figure 641 / LIFT DOOR INDICATOR

15.30. DRIVER DOME LIGHT, P. 30
Figure 642 DRIVER DOME LIGHT

Components: ELEC PANEL (10000); GROUND SPLICE (10009); LIFT SPLICE (10370); LIGHT (10072)
Wires (circuit gauge+color): B122AA 16WH; C63 18DKBL; C63-G 18WH
See also sheets: CH15_04, CH3_43
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.30. DRIVER DOME LIGHT, P. 30 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0946 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18JAN21 / CHAPTER 15 / DRIVERS DOME LIGHT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / DRIVERS DOME LIGHT (10072) A / FR CAP/ ELEC PANEL (10000) D7 / C63 C63 18DKBL 18DKBL / B122AA 16WH C63-G 18WH / LIFT SPLICE (10370) CH15_04 GROUND SPLICE (10009) CH3_43 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 642 / DRIVER DOME LIGHT

15.31. LIFT WITH AIR BRAKE AND HYDRAULIC BRAKE WITH KEY ON, P. 31
Figure 643 LIFT WITH AIR BRAKE AND HYDRAULIC BRAKE WITH KEY ON

Components: CONTROL UNIT (1601); ELEC PANEL (1703); FUSE F31 (10303); GROUND SPLICE (10335A); INDICATOR (10371); LIFT SOLENOID (11512); LIFT SPLICE (10370); LIFT SW (10281); LOCK RELAY (10310); PLATFORM (1702); PLATFORM (1703); R BODY (10700); REAR CAP (10405); RELAY (10312); RELAY COIL (10364); RELAY COIL (10369); SEALED ENG (11500); SPLICE (10329)
Wires (circuit gauge+color): A122AR 18GY; B122-G 18WH; B122-GA 18WH; B122A 18GY; B122D 18WH; B122E 16GY; B122F 16GY; B122H 18GY; B122J 18GY; B122K 18GY; B122M 18GY; B122N 16BN; B122P 18GY; B122R 18GY; B122T 18GY; B122TB 18GY; B122U 18WH; B122V 16GY; B13 18PK; B44 18GY; B44A 18GY; B62-GAD 18WH; B62AD 18DKBL; B62BN 18DKBL; D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122A 16GY; D122B 16GY; D122C 16GY; E122-GA 16WH; E122-GB 16WH; E122-GC 16WH; E122A 16GY; E122B 16GY; E122C 16GY; Y122 16GY; Y122A 16GY
See also sheets: CH15_12, CH15_32, CH15_40, CH3_29, CH8_30
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.31. LIFT WITH AIR BRAKE AND HYDRAULIC BRAKE WITH KEY ON, P. 31 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 17MAR21 / CHAPTER 15 LIFT W/ AIR BRAKE AND HYD BRAKE W/ KEY ON / MJV0488 19NOV21 ADDED CIRC B122TB IN R/D 11500. / 85 A1 B1 B122D 18WH / LIFT LT RELAY (10312) 86 / A2 30 / @B122U 18WH B62-GAD 18WH B62AD 18DKBL B62BN 18DKBL / %B122V 16GY B13 18PK B4 86 / A4 30 LIFT INTERLOCK RELAY (10312) / PLATFORM/ ELEC PANEL (1703) 85 CH15_32 A3 / PLATFORM/ ELEC PANEL FUSE F31 (1703) (10303) CH15_32 CH3_94H / E122-GA 16WH E122-GB 16WH #E122A 16GY E122C 16GY E122B 16GY E122-GC 16WH / C5 C4 / C1 C3 / ELEC PANEL/ SEALED ENG (11500) B7 B122M 18GY / 8 2 / LIFT 2RED LIFT SOLENOID (11512) Y122 1 16GY / LIFT SPLICE (10370) A / @B122T 18GY J4-BLUE BODY ELEC PANEL/ CONTROL UNIT PLATFORM 37 (1601) (1702) WHEEL CHAIR A122AR LIFT SOLENOID 18GY / B122J 18GY / LIFT SW (10281) / Y122A 16GY / L BODY/ REAR CAP (10405) B10 / C2 B12 / B11 C1 / D122-GA 16WH D122-GB 16WH #D122A 16GY D122C 16GY D122B 16GY D122-GC 16WH B122-GA 18WH / ELEC PANEL/ L BODY 10401A/10401B B12 / REAR CAP / R BODY (10700) CH15_12,13,14, 15,16,17,18,19, 20,21,22,23 / @@B122H 18GY / ##B44A 18GY B122P 18GY B122A 18GY *B122T 18GY / #B122R 18GY / **B122F 16GY / B122E 16GY 18GY B44 / ELEC PANEL/ PLATFORM (1703) CH13_58A / GROUND SPLICE (10335A) CH3_95G FLASHING LIFT INDICATOR (10371) CH3_95G ACCESSORY SPLICE RELAY COIL (10369) CH3_30A / GROUND SPLICE (10335A) CH3_95G / B122N 16BN / B122K 18GY / &B122-G 18WH / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / AED VANDAL LOCK RELAY (10310) CH15_40 / B122TB 18GY / Figure 643 / LIFT WITH AIR BRAKE AND HYDRAULIC BRAKE WITH KEY ON

15.32. LIFT WITH AIR BRAKE AND HYDRAULIC BRAKE WITH KEY ON (CONT.), P. 32
Figure 644 LIFT WITH AIR BRAKE AND HYDRAULIC BRAKE WITH KEY ON (CONT.)

Components: BRAKE SOLENOID (4905); CONTROLLER (1602); DIODE ASSEMBLY CONN (1014F); ELEC PANEL (1703); ENGINE/PLATFORM (1701); GROUND SPLICE (1003B); L BODY (10401A); LIFT RELAY (1019); LIFT SPLICE (10370); REFERENCE (1005); RELAYS (1009); SHIFT INHIBIT RELAY (1026)
Wires (circuit gauge+color): A122F 18GY; A44C 18GY; A44C-G 18WH; A9CA 18GY; B122K 18GY; B122R 18GY; K44C 18GY
See also sheets: CH15_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.32. LIFT WITH AIR BRAKE AND HYDRAULIC BRAKE WITH KEY ON (CONT.), P. 32 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090666 NO. RELEASE NO. 95885P 17MAR21 / CHAPTER 15 LIFT W/ AIR BRAKE AND HYD BRAKE W/ KEY ON (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J5-TAN BODY CONTROLLER (1602) / WHEELCHAIR LIFT DOOR DIODE ASSEMBLY CONN (1014F) B / NEXT GEN HYDRULIC PARK BRAKE WHEEL CHAIR RELAY (1010) CH13_58A SHIFT INHIBIT RELAY (1026) CH12_15B,2A / LIFT SPLICE (10370) CH15_31,33 / WHEEL CHAIR F13 DOOR SW / A89CE 18VT / A89CB 18VT / 1 86 / PLATFORM / ELEC PANEL (1703) A7 B122K 18GY / A89CC 18PL / 5 A9CA 18GY / WHEEL CHAIR LIFT RELAY (1019) / @A44C-G 18WH / COIL SIGNAL ZVR RELAYS (1009) CH3_94A / K44C 18GY / A122F 18GY A89CF 18VT / A44C 18GY / ENGINE/PLATFORM (1701) / B122R 18GY / ELEC PANEL / L BODY (10401A) CH15_31,33 / A89CD 18VT / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / @ N/WHEELCHAIR LIFT INTERLOCK / AIR PARK BRAKE SOLENOID (4905) CH13_54A / ZERO VOLT (1005) CH3_95M / GROUND SPLICE (1003B) CH3_95C / Figure 644 / LIFT WITH AIR BRAKE AND HYDRAULIC BRAKE WITH KEY ON (CONT.)

15.33. WHEEL CHAIR LIFT INTERLOCK WITH AIR PARK & WITH HYDRAULIC BRAKE
Figure 645 WHEEL CHAIR LIFT INTERLOCK WITH AIR PARK & WITH HYDRAULIC BRAKE WITH LCT

Components: CONTROLLER (1602); DIODE ASSY CONN (1014F); ELEC PANEL (1703/1703C/1703); FUSE F24 (1011); FUSE F7 (1011); GEN 5 TCM (7150); GROUND SPLICE (1003B); L BODY (10401A); L BODY (10401B); LIFT RELAY (1019); PLATFORM/ENGINE (1701); REFERENCE (1005); RELAY (1015); RELAY (1026); SOLENOID (4905); SPLICE (10370); ZVR RELAYS (1009)
Wires (circuit gauge+color): A101 18TN; A103A 18TN; A122F 18GY; A15A 18RD; A44C 18GY; A44C-G 18WH; A44E 18GY; A9CA 18GY; B122K 18GY; B122R 18GY; K44 18GY; K44C 18GY
See also sheets: CH15_31, CH15_34, CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.33. WHEEL CHAIR LIFT INTERLOCK WITH AIR PARK & WITH HYDRAULIC BRAKE WITH LCT XMSN WITH F-2018 PROPANE / GASOLINE ENGINE, P. 33 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18MAR21 / CHAPTER 15 WHEEL CHAIR LIFT INTERLOCK W/AIR PARK & W/HYDRAULIC BRAKE W/LCT XMSN W/F-2018-PROPANE/GASOLINE-ENG PLATFORM/ENGINE (1701) 27 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J5-TAN BODY CONTROLLER (1602) WHEEL CHAIR F13 DOOR SWITCH / WHEELCHAIR LIFT DOOR DIODE ASSY CONN (1014F) B / A122F 18GY A89CF 18VT A89CE 18VT / A89CB 18VT / 1 86 / 30 WHEEL CHAIR LIFT RELAY (1019) 87A / A89CC 18PL / A9CA 18GY / @A44C-G 18WH / COIL SIGNAL ZVR RELAYS (1009) CH3_94A / ZERO VOLT (1005) CH3_95M / PLATFORM/ ELEC PANEL (1703/1703C/1703) A7 / *A44E 18GY / A89CD 18VT / NEXT GEN HYDRULIC PARK BRAKE WHEEL CHAIR RELAY (1010) CH13_58A / 3 30 SHIFT INHIBIT RELAY 87A (1026) / 1 86 / A101 18TN / @A44C 18GY / A15A 18RD / FUSE F7 (1011) CH3_94 / K92#101 18LTBL / K44C 18GY / #A44C-G 18WH / GROUND SPLICE (1003B) CH3_95C / A103A 18TN / ECONOMY MODE SW RELAY (1015) CH12_1A / # N/WHEELCHAIR LIFT INTERLOCK W/AIR PARK BRAKE @ W/WHEELCHAIR LIFT INTERLOCK W/LCT XMSN * W/1703C CAP CONNECTIONS & W/ 9 WINDOW / AIR PARK BRAKE SOLENOID (4905) / K44 18GY / @A44C 18GY / FUSE F24 (1011) CH3_94C / B122K 18GY / B122K 18GY / LIFT SPLICE SPLICE (10370) CH15_31,32,34 / B122R 18GY / &B122R 18GY / ELEC PANEL/ L BODY (10401A) CH15_31,32,33 ELEC PANEL/ L BODY (10401B) CH15_34 / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / GEN 5 TCM (7150) CH12_10A / Figure 645 / WHEEL CHAIR LIFT INTERLOCK WITH AIR PARK & WITH HYDRAULIC BRAKE WITH LCT XMSN WITH F-2018 PROPANE / GASOLINE ENGINE

15.34. WHEEL CHAIR LIFT WITH AIR BRAKE WITH KEY ON / OFF WITH DIESEL &
Figure 646 WHEEL CHAIR LIFT WITH AIR BRAKE WITH KEY ON / OFF WITH DIESEL & WITH F-2018

Components: CONTROL UNIT (1601); ELEC PANEL (1702); ELEC PANEL (1703); FUSE F31 (10303); GROUND SPLICE (10335A); INDICATOR (10371); LIFT LIGHT (10312); PLATFORM /ELEC PANEL (1703); R BODY (10700); REAR CAP (10405); RELAY (10312); RELAY COIL (10369); SPLICE (10370)
Wires (circuit gauge+color): A122AR 18GY; A122J 18GY; A44D 18GY; A44F 18GY; B122-G 18WH; B122-GA 18WH; B122A 18GY; B122D 18WH; B122E 16GY; B122F 16GY; B122H 18GY; B122J 18GY; B122K 18GY; B122L 18GY; B122N 16BN; B122P 18GY; B122R 18GY; B122V 16GY; B13 18PK; B44 18GY; B44C 18GY; D122-GA 16WH; D122-GB 16WH; D122-GC 16WH; D122A 16GY; D122B 16GY; D122C 16GY; E122-GA 16WH; E122-GB 16WH; E122-GC 16WH; E122A 16GY; E122B 16GY; E122C 16GY
See also sheets: CH15_12, CH15_31, CH15_32, CH5_05
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.34. WHEEL CHAIR LIFT WITH AIR BRAKE WITH KEY ON / OFF WITH DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE, P. 34 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18MAR21 / CHAPTER 15 WHEEL CHAIR LIFT W/AIR BRAKE W/KEY ON/OFF W/DIESEL & W/F-2018-PROPANE/GASOLINE ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 85 A1 B122D 18WH / B122E 16GY **B122F 16GY LIFT LIGHT B2 (10312) 86 / A2 30 / %A122J 18GY @A122AR 18GY %A44F 18GY @A44F 18GY / @@B122H 18GY LIFT INTERLOCK RELAY B4 (10312) 86 / A4 30 / PLATFORM/ ELEC PANEL (1703) 85 CH15_32 A3 / PARK BRAKE SW FOR WHEEL CHAIR (168M) / B12 E122-GC 16WH E122A 16GY E122B 16GY E122C 16GY / B122A 18GY / B1 B122N 16BN / B122P 18GY / B13 18PK B13 18PK LIFT INTERLOCK RELAY E4 (10312) C4 86 30 / LIFT SPLICE (10370) / B44 18GY / %A44D 18GY @A44D B44C 18GY 18GY NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / PLATFORM/ ELEC PANEL (1702) 37 / B3 B122L 18GY B122J 18GY / B122-G 18WH / B122-GA 18WH B122R 18GY / PLATFORM /ELEC PANEL (1703) CH15_31 FUSE F31 (10303) CH3_94H / J4-BLUE BODY CONTROL UNIT (1601) / WHEEL CHAIR LIFT SOLENOID / GROUND SPLICE (10335A) CH3_95G / REAR CAP / R BODY (10700) CH15_12,13, 14,15,16,17, 18,19,20,21, 22,23 / B44A A8GY / ACCESSORY SPLICE RELAY COIL (10369) CH3_30A / B122K 18GY / FLASHING LIFT INDICATOR (10371) CH5_05 / *B122V 16GY / * W/FLASHING INDICATOR % W/F-2018-PROPANE/GASOLINE- ENGINE ONLY @ W/DIESEL ENGINES ONLY ** W/HYD BRAKE @@ W/AIR BRAKE / Figure 646 / WHEEL CHAIR LIFT WITH AIR BRAKE WITH KEY ON / OFF WITH DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE

15.35. WHEEL CHAIR LIFT WITH HYDRAULIC BRAKE WITH KEY ON / OFF WITH
Figure 647 WHEEL CHAIR LIFT WITH HYDRAULIC BRAKE WITH KEY ON / OFF WITH DIESEL &

Components: COILS (10369); CONNECTION (1014F); CONTROL UNIT (1601); ELEC PANEL (1702/1702); ELEC PANEL (1703/1703); FR CAP (10000); FUSE F31 (10303); GROUND SPLICE (10335A); INDICATOR (10371); INTERLOCK (10312); L BODY (10401B/10401); PANEL (1703); PLATFORM (1701); PLATFORM (1702); PLATFORM (1703); R BODY (10700); REAR CAP (10405/10405); RELAY (10312); SEALED ENGINE (11500); SPLICE (10370)
Wires (circuit gauge+color): A122AR 18GY; A122H 18GY; A122J 18GY; A44C 18GY; B122-G 18WH; B122-GA 18WH; B122A 18GY; B122AA 16WH; B122D 18WH; B122E 16GY; B122F 16GY; B122H 18GY; B122J 18GY; B122K 18GY; B122L 18GY; B122M 18GY; B122N 16BN; B122P 18GY; B122R 18GY; B122V 16GY; B13 18PK; B13A 18PK; B44 18GY; B44A 18GY; B44B 18GY; B44C 18GY; D122-GC 16WH; D122A 16GY; D122B 16GY; D122C 16GY; E122-GC 16WH; E122A 16GY; E122B 16GY; E122C 16GY
See also sheets: CH15_12, CH15_31, CH15_32, CH15_33, CH15_34, CH15_39, CH5_05
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.35. WHEEL CHAIR LIFT WITH HYDRAULIC BRAKE WITH KEY ON / OFF WITH DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE, P. 35 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 85 A1 B1 B122D 18WH B122N 16BN / @B122F 16GY LIFT LIGHT RELAY B2 (10312) 86 / A2 30 / LIFT INTERLOCK B4 (10312) A4 86 30 / 85 A3 / B12 E122-GC 16WH / GROUND SPLICE (10335A) CH3_95G PLATFORM/ ELEC PANEL (1703/1703) A7 A89CE 18VT A44C 18GY / B13A 18PK / @B44C 18GY E4 C4 86 / #B13 18PK / WHEEL CHAIR E1 LIFT SOLENOID / @@B122H 18GY / B122L 18GY / B122-GA 18WH B122-G 18WH / B122J 18GY / E122B 16GY / E122A 16GY E122C 16GY / REAR CAP/ R BODY (10700) CH15_12,13,14, 15,16,17,18,19, 20,21,22,23 / J-4 BODY CONTROL UNIT (1601) / WHEELCHAIR LIFT DOOR DIODE ASSEMBLY CONNECTION (1014F) CH15_32,33 ENG/ PLATFORM (1701) CH15_33 FUSE F31 (10303) CH3_94H / D122B 16GY / D122-GC 16WH / ##B122M 18GY / LIFT INTERLOCK (10312) / B122A 18GY B122P 18GY / LIFT SPLICE (10370) H / FLASHING LIFT INDICATOR (10371) CH5_05 ACCESSORY SPLICE RELAY COILS (10369) CH3_30A / B122E 16GY / ELEC PANEL/ SEALED ENGINE (11500) CH15_31 / D122A 16GY D122C 16GY / B122K 18GY / ELEC PANEL/ PLATFORM (1702) CH15_34 / @@B44C 18GY / *B122V 16GY / PLATFORM/ELEC PANEL (1703) CH13_58A / B44 18GY #/%B44A 18GY @B44A 18GY B122AA 16WH / @B44B 18GY / ELEC PANEL/ FR CAP (10000) CH15_39 / ELEC PANEL/ PLATFORM (1703) CH13_32A / A12 B122R 18GY / Figure 647 / WHEEL CHAIR LIFT WITH HYDRAULIC BRAKE WITH KEY ON / OFF WITH DIESEL & WITH F-2018 PROPANE / GASOLINE ENGINE

15.36. PUPIL WARNING LIGHTS ACTIVATED BY LIFT DOOR OPEN, P. 36
Figure 648 PUPIL WARNING LIGHTS ACTIVATED BY LIFT DOOR OPEN

Components: CONTROLLER (1602); ELEC PANEL/PLATFORM (1702); FUSE F31 (10303); LIFT SPLICE (10370); LT RELAY (10311); MASTER FLASHER SW (10236); PWR RELAY (10308); RELAY COILS (10364); SPLICE (10330); SPLICE (10350A); SPLICE (10402)
Wires (circuit gauge+color): B123A 18LTGN; B123B 18LTGN; B123C 18LTGN; B123D 18LTGN; B123E 18LTGN; B123F 18LTGN; B44 18GY; B62-GAC 18WH; B62AC 18DKBL; B63-G 16WH; B9F 18LTGN; B9H 18GY
See also sheets: CH3_29, CH6_22, CH8_31, CH8_56
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.36. PUPIL WARNING LIGHTS ACTIVATED BY LIFT DOOR OPEN, P. 36 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18MAR21 / CHAPTER 15 PUPIL WARNING LIGHTS ACTIVATED BY LIFT DOOR OPEN / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PWR RELAY (10308) F2 G2 30 86 / MASTER F16 FLASHER SW / J5-TAN BODY CONTROLLER (1602) / B9H 18GY @B9F 18LTGN / B123E 18LTGN / PWR OVERRIDE SPLICE (10402) CH6_22 / #B123A 18LTGN / ELEC PANEL/PLATFORM (1702) 60 / MASTER FLASHER SW (10236) 7 / B62AC 18DKBL / SW ILLUMINATION SPLICE (10330) CH8_31 / A89KK 180R / B44 18GY / B123C 18LTGN B123D 18LTGN / #B123B 18LTGN / 85 F1 / 87 87A G1 / ZVR SPLICE (10350A) CH3_95N / B62-GAC 18WH / ACCESSORY SPLICE RELAY COILS (10364) CH3_29 / B123F 18LTGN / LIFT SPLICE (10370) A / FUSE F31 (10303) CH3_94H / # W/MASTER FLASHER SW @ N/MASTER FLASHER SW NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / B63-G 16WH / REAR DOME LT RELAY (10311) CH8_56 / Figure 648 / PUPIL WARNING LIGHTS ACTIVATED BY LIFT DOOR OPEN

15.37. LIFT DOOR WITH STARTER INTERLOCK, P. 37
Figure 649 LIFT DOOR WITH STARTER INTERLOCK

Components: BUZZER RELAY (10310); DIODE D82 (10307); ELEC PANEL (10400); ENG (1701); FR CAP (10000); FUSE F43 (10304); INTERLOCK (10310); INTERLOCK (10382); INTERLOCK (10422); INTERRUPT (10106/10106A); KEY SW (1100); LIFT DOOR / R BODY (10774#); R BODY (10700); REAR CAP (10405); RELAY (10310); STARTER INTERRUPT (1008F/1008M); STARTER INTERRUPT (1008M/1008F); VANDAL LOCK (10796); VANDAL LOCK (1702)
Wires (circuit gauge+color): A17 16PK; A17B 16PK; B117K 18LTGN; B133A 16LTGN; B133D 18LTGN; B133E 18LTGN; B133F 18LTGN; B133H 18LTGN; B133T 18LTGN; B17 18LTGN; B17B 18LTGN; B17C 18LTGN; B17C 18PK; D133B 16LTGN; D133B 18LTGN; D133C 16LTGN; D133D 16LTGN; D133D 18LTGN; E133A 18LTGN; E133B 18LTGN
See also sheets: CH14_25, CH16_30, CH19_55, CH4_07
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.37. LIFT DOOR WITH STARTER INTERLOCK, P. 37 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18MAR21 / CHAPTER 15 LIFT DOOR WITH STARTER INTERLOCK / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / LIFT DOOR / R BODY (10774#) H / L BODY/ REAR CAP (10405) B7 E133B 18LTGN / %D133C 16LTGN REAR CAP/ D133D R BODY 16LTGN (10700) %D133D F133* 18LTGN 18LTGN / %D133B 16LTGN @D133B 18LTGN / L BODY/ ELEC PANEL (10400) C11 E133A B133F 18LTGN 18LTGN SPLICE PACK STARTER INTERLOCK (10382) / SPLICE PACK STARTER INTERLOCK (10422) A / ##B133D 18LTGN / C4 30 / B17C 18PK B17C 18LTGN E4 86 / STARTER INTERRUPT (1008F/1008M) A A17B B17 16PK 18LTGN / STARTER INTERRUPT (1008M/1008F) A A17 B17B 16PK 18LTGN / 85 C3 %%B133T 18LTGN / 87A D3 / FUSE F43 (10304) CH3_94K / B133E 18LTGN / DIODE D82 (10307) B4 A4 B117K 18LTGN / LIFT DOOR VANDAL LOCK (10796) A / **D133B 16LTGN / ##B133H 18LTGN @@B133A 16LTGN / STARTER INTERLOCK (10310) / A B C D E / STARTER INTERLOCK RELAY (10310) CH19_55 / %%B133D 18LTGN / PLATFORM/ ENG (1701) CH4_07, 08,09 / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / KEY SW (1100) CH4_07, 08,09 / Figure 649 / LIFT DOOR WITH STARTER INTERLOCK

15.38. LIFT EXTERIOR LIGHT, P. 38
Figure 650 LIFT EXTERIOR LIGHT

Components: DOME LT (10785); DOOR LT (10781); DOOR LT (10789); DOOR LT (10795); FUSE F31 (10303); L BODY (10401); LIFT DOOR (10774#); LIFT SPLICE (10370); LIFT SPLICE (10780); R BODY (10700); REAR CAP (10405); SPLICE (10780); TOGGLE SW (10782); TOGGLE SW (10783)
Wires (circuit gauge+color): B122S 16BN; B44 18GY; D122D 16GY; E122D 16GY
See also sheets: CH15_12, CH15_26
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.38. LIFT EXTERIOR LIGHT, P. 38 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18MAR21 / CHAPTER 15 / LIFT EXTERIOR LT / MJV0488 10JUN21 INITIAL PRODUCTION RELEASE. / 122K 18GY 122-GK 18WH / R BODY/ LIFT DOOR (10774#) CH15_12,13,14, 15,16,17,18,19, 20,21,22 LIFT LT TOGGLE SW (10782) A / LIFT SPLICE (10780) CH15_26 / L BODY/ ELEC PANEL/ REAR CAP L BODY (10405) (10401) C6 C4 E122D B122S D122D 16BN 16GY 16GY / REAR CAP/ R BODY (10700) CH15_12,13, 14,15,16,17, 18,19,20,21,22 / 122-GG 18WH LIGHT, EXTERIOR LIFT DOOR ACTIVATED - MTD BELOW LIFT DOOR IN SKIRT / LIGHT, EXTERIOR LIFT DOOR ACTIVATED - MTD HI ON LIFT DOOR POST / LIGHTS, TOGGLE SW ACTIVATED - EXTERIOR MTD ACROSS FROM DOOR HANDLE ON POST & INTERIOR ON CEILING. / CEILING MOUNTED DOME LT (10785) / LOWER POST LIFT DOOR LT (10795) / 122D 18GY / 122J 18GY / LIFT SPLICE (10780) CH15_26 / 122E 18GY 122-GJ 18WH / 122-GH 18WH / SKIRT LIFT DOOR LT (10781) 1 / 122 18GY / UPPER LIFT DOOR LT (10789) 1 / 122F 18GY 122-GF 18WH / LIFT SPLICE (10370) / LIFT SPLICE (10780) CH15_26 / FUSE F31 (10303) CH3_94H / B44 18GY / LIFT LT TOGGLE SW (10783) / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 650 / LIFT EXTERIOR LIGHT

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 691 | printed page 651 | section 15.39
15.39. LIFT DOOR INDICATOR, P. 39
Figure 651 LIFT DOOR INDICATOR

Components: CIRCUIT (10010); FR CAP (10000); LIFT DOOR INDICATOR (10032B); LIFT DOOR INDICATOR (1033B); LIFT DOOR LT (11026/11027); SPLICE (10370)
Wires (circuit gauge+color): B122AA 16WH; B122Z 16GY; C122 16DKBL; C122 16GY; C122-G 16WH
See also sheets: CH3_44
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.39. LIFT DOOR INDICATOR, P. 39 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 95885P 18MAR21 / CHAPTER 15 / LIFT DOOR INDICATOR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/ FR CAP LIFT DOOR LT (10000) (11026/11027) *C122-G 16WH #C122-G 16WH *C122 16GY #C122 16GY / C122-G 16WH / LIFT SPLICE (10370) L / GROUND CIRCUIT (10010) CH3_44 / *W/AC #N/AC / B122AA 16WH B122Z 16GY / C122 16DKBL / LIFT DOOR INDICATOR (10032B) A / LIFT DOOR INDICATOR (1033B) / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 651 / LIFT DOOR INDICATOR

15.40. LIFT WITH DOOR SWITCH WITH ON V BATT, P. 40
Figure 652 LIFT WITH DOOR SWITCH WITH ON V BATT

Components: ENG (11500); FUSE F31 (10303); INDICATOR (10371); L BODY (10401B/10401); LOCK RELAY (10310); R BODY (10700); REAR CAP (10405/10405); RELAY (10312); SPLICE (10335A); SPLICE (10370)
Wires (circuit gauge+color): B122-GA 18WH; B122-GB 18WH; B122-GC 18WH; B122A 18GY; B122C 18GY; B122CA 18GY; B122D 18WH; B122E 16GY; B122F 16GY; B122N 16GY; B122P 18GY; B122T 18GY; B122TA 18GY; B122TB 18GY; B122V 16GY; D122-GB 16WH; D122-GC 16WH; D122B 16GY; D122C 16GY; E122-GB 16WH; E122-GC 16WH; E122B 16GY; E122C 16GY
See also sheets: CH15_13, CH15_31, CH5_05
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 15.40. LIFT WITH DOOR SWITCH WITH ON V BATT, P. 40 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090666 NO. 96289K 10OCT21 / CHAPTER 15 LIFT WITH DOOR SWITCH W/ON V BATT / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / 85 A1 / B122F 16GY LIFT LT RELAY B2 (10312) 86 / A2 30 / B122T 18GY STEP WARMER RELAY G3 (10312) 86 / 85 F4 / B12 E122-GC 16WH E122-GB B11 16WH / B122TB 18GY / B122-GA 18WH / ELEC PANEL/ L BODY/ L BODY REAR CAP (10405/10405) (10401B/10401) / E122B 16GY / E122C 16GY / REAR CAP/ R BODY (10700) CH15_13 / AED VANDAL LOCK RELAY (10310) G4 G3 86 / 85 H4 / FUSE F31 (10303) CH3_94H / F3 30 / D122B 16GY / D122-GC 16WH D122-GB 16WH / B122CA 18GY B122-GB 18WH / LIFT SPLICE (10370) / B122E 16GY / B122D 18WH / B122V 16GY / FLASHING LIFT INDICATOR (10371) CH5_05 / B122A 18GY / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / D122C 16GY / B122TA 18GY / ELEC PANEL/ SEALED ENG (11500) CH15_31 FLASHING LIFT INDICATOR (10371) CH5_05 / B122C 18GY / B122P 18GY / B122N 16GY / GROUND SPLICE (10335A) CH3_95G / B122-GC 18WH / Figure 652 / LIFT WITH DOOR SWITCH WITH ON V BATT

Figure 653 PANEL MOUNTED DOOR CONTROLS - WITH LEFT WITH 2 AND 3 POSITION ROTARY

Components: CONTROLLER (1602); PLATFORM (1702); PLATFORM (1703); SPLICE (10329); SPLICE CONN (1006); SWITCH (10236); ZVR SPLICE (10350A)
Wires (circuit gauge+color): A120SK 16LTGN; A123F 18GY; A123J 18GY; B120F 18LTGN; B120H 18LTGN; B123T 18GY; B62-GAC 18WH; B62AC 18DKBL; B62AD 18DKBL; B62AE 18DKBL; B9A 18GY; B9C 18GY; B9D 18GY
See also sheets: CH3_60, CH6_15, CH6_22, CH8_30
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / ENTRY DOOR (CHAPTER 16) / 16.1. PANEL MOUNTED DOOR CONTROLS - WITH LEFT WITH 2 AND 3 POSITION ROTARY SWITCH, P. 1 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 PANEL MOUNTED DOOR CONTROLS - W/LEFT W/2 AND 3 POSITION ROTARY SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B120F 18LTGN / B62AD 18DKBL / !/*B9D 18GY / B120H 18LTGN / ZVR SPLICE (10350A) CH3_60 / B62AE 18DKBL / DOOR CONTROL ^(10200) / B62AC 18DKBL / ELEC PANEL/ PLATFORM (1703) A4 / SW ILLUM SPLICE (10329) CH8_30 / &A120SK 16LTGN / #A123J 18GY / ELEC PANEL/ PLATFORM (1702) 59 / ^B9C 18GY !B9C 18GY B9A 18GY / @B123T 18GY / MASTER FLASHER SWITCH (10236) CH6_15 / J5-TAN BODY CONTROLLER (1602) / B62-GAC 18WH / %A123F 18GY / RED OVERHEAD SPLICE CONN (1006) CH6_22 / DOOR CONTROL OPEN INPUT / THREE POSITION SWITCH MIDDLE POSITION / ^B9D 18GY / ZVR SPLICE (10350A) CH3_95N / Figure 653 / PANEL MOUNTED DOOR CONTROLS - WITH LEFT WITH 2 AND 3 POSITION ROTARY SWITCH

16.2. PANEL MOUNTED DOOR CONTROLS - WITH RIGHT WITH 2 AND 3 POSITION ROTARY SWITCH, P. 2
Figure 654 PANEL MOUNTED DOOR CONTROLS - WITH RIGHT WITH 2 AND 3 POSITION ROTARY

Components: CONTROLLER (1602); DOOR CONTROL SW (3201); FLASHER SWITCH (1137); PANEL LIGHTS (1002B); SPLICE CONN (1006); ZVR SPLICE (1005A)
Wires (circuit gauge+color): A120-GM 18WH; A120SK 18LTGN; A123A 18GY; A123B 18GY; A123H 18GY; A62L 18DKBL; A62LB 18DKBL; A62M 18DKBL; A62N 18DKBL; A9W 18GY; A9WA 18GY
See also sheets: CH3_59, CH6_19, CH6_22, CH8_26
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.2. PANEL MOUNTED DOOR CONTROLS - WITH RIGHT WITH 2 AND 3 POSITION ROTARY SWITCH, P. 2 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 PANEL MOUNTED DOOR CONTROLS - W/RIGHT W/2 AND 3 POSITION ROTARY SWITCH / MJV0488 19NOV21 ADDED CIRC A62LB IN CAV 8 & 9. / *A123B 18GY / @A9W 18GY / A120SK 18LTGN / ZVR SPLICE (1005A) CH3_59 / A62N 18DKBL / DOOR CONTROL SW (3201) / A62M 18DKBL / RIGHT SWITCH PANEL LIGHTS (1002B) CH8_26 / A9WA 18GY / &A123H 18GY / RIGHT MASTER FLASHER SWITCH (1137) CH6_19 / J5-TAN BODY CONTROLLER (1602) / A120-GM 18WH / #A123A 18GY / RED OVRD SPLICE CONN (1006) CH6_22 / DOOR CONTROL OPEN INPUT / THREE POSITION SWITCH MIDDLE POSITION / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / %%A62L 18DKBL / ##A62LB 18DKBL / Figure 654 / PANEL MOUNTED DOOR CONTROLS - WITH RIGHT WITH 2 AND 3 POSITION ROTARY SWITCH

16.3. PANEL MOUNTED DOOR CONTROLS - WITH LEFT WITH 3 POSITION TOGGLE SWITCH, P. 3
Figure 655 PANEL MOUNTED DOOR CONTROLS - WITH LEFT WITH 3 POSITION TOGGLE SWITCH

Components: J5-TAN BODY CONTROLLER (1602); LOCK RELAY (10312-R6); OPEN SIGNAL (11600C); PLATFORM (1702); PLATFORM (1703); RELAY (10311-R6); RELAY (10312-R3); RELAY COILS (10364); SIGNAL (11600D); SPLICE (10335B); ZVR (11600A); ZVR (11600B); ZVR SPLICE (10350A)
Wires (circuit gauge+color): A120SK 16LTGN; A123J 18GY; B120-G 18WH; B120-GA 18WH; B120A 18LTGN; B120B 18LTGN; B120C 18LTGN; B123C 18LTGN; B123T 18GY; B123T 18LTGN; B123V 18GY; B9A 18GY
See also sheets: CH3_29, CH3_37, CH3_60, CH6_16, CH6_17
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.3. PANEL MOUNTED DOOR CONTROLS - WITH LEFT WITH 3 POSITION TOGGLE SWITCH, P. 3 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 PANEL MOUNTED DOOR CONTROLS - W/LEFT W/3 POSITION TOGGLE SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / C...O CARLING K301-27 / RIGHT SIDE / LEFT SIDE / C...O CARLING K301-27 / ELEC PANEL/ PLATFORM A4 (1703) A120SK 16LTGN / F15 F8 CONTROL INPUT POSITION MIDDLE POSITION OPEN SWITCH DOOR THREE / 18LTGN 120C 18GY 9A / 120-GA 18WH / B120C 18LTGN / 9A 18GY / 120-G 18WH / B120-GA 18WH / B9A 18GY / DOOR SW ZVR A (11600B) / ELEC PANEL/ PLATFORM (1702) 59 / DOOR SW A ZVR (11600A) / DOOR SW OPEN SIGNAL (11600C) / DOOR SW OVERRIDE A SIGNAL (11600D) / B120-G 18WH / GROUND SPLICE (10335B) CH3_37 / ZVR SPLICE (10350A) CH3_60 / AED RELAY (10312-R3) 86 30 30 / A123J 18GY / B123T 18GY / B120B 18LTGN / ACC SPLICE RELAY COILS (10364) CH3_29 FLASHER SYSTEM RELAY (10311-R6) CH6_16 AED VANDAL LOCK RELAY (10312-R6) CH6_17 / B120A 18LTGN / B123V 18GY / B123C 18LTGN / B123T 18LTGN / Figure 655 / PANEL MOUNTED DOOR CONTROLS - WITH LEFT WITH 3 POSITION TOGGLE SWITCH

16.4. PANEL MOUNTED DOOR CONTROLS - WITH 3 POSITION TOGGLE SWITCH WITH AMBER CANCEL, P. 4
Figure 656 PANEL MOUNTED DOOR CONTROLS - WITH 3 POSITION TOGGLE SWITCH WITH AMBER

Components: AED RELAY (10312-R3); ALARM RELAY (10310-R6); AMBER CANCEL (11760); CONTROLLER (1602); ELEC PANEL (1702); PLATFORM (1703); RELAY (10311-R6); RELAY COILS (10364); SPLICE (10335B); SPLICE (10399); W/AMBER CANCEL (11770); ZVR SPLICE (10350B)
Wires (circuit gauge+color): A120SK 16LTGN; A123J 18GY; B120-G 18WH; B120A 16LTBL; B120B 16LTBL; B120C 16LTBL; B123-GB 18WH; B123-GC 18WH; B123-GD 18WH; B123RW 18GY; B123T 18GY; B123V 18GY; B62-GA 18WH; B62A 18DKBL; B9A 18GY; B9B 18GY; B9C 18GY; B9D 18GY
See also sheets: CH3_29, CH3_37, CH3_60, CH6_16, CH7_63
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.4. PANEL MOUNTED DOOR CONTROLS - WITH 3 POSITION TOGGLE SWITCH WITH AMBER CANCEL, P. 4 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 PANEL MOUNTED DOOR CONTROLS - W/3 POSITION TOGGLE SWITCH W/AMBER CANCEL / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B9C 18GY B123V 18GY B9B 18GY 30 / 87 87A / FLASHER SYSTEM RELAY (10311-R6) CH6_16 ZVR SPLICE (10350B) CH3_60 / CHILD SAFETY ALARM RELAY (10310-R6) / 87 87A / AED RELAY (10312-R3) / B120C 16LTBL / B123RW 18GY B120B 16LTBL / B120A 16LTBL / ACC SPLICE RELAY COILS (10364) CH3_29 / GROUND SPLICE B120-G (10335B) 18WH CH3_37 B9A ZVR SPLICE 18GY (10350B) CH3_60 ELEC PANEL/ PLATFORM (1703) A4 / PLATFORM/ ELEC PANEL (1702) B123T 18GY / JS-TAN BODY CONTROLLER (1602) / 3-POSITION TOGGLE W/AMBER CANCEL (11770) A / B123-GD 18WH / B9D 18GY / A123J 18GY / A120SK 16LTGN / AMBER CANCEL (11760) / B62-GA 18WH / B62A 18DKBL / B123-GC 18WH B123-GB 18WH / SW ILLUM SPLICE (10399) CH7_63 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 656 / PANEL MOUNTED DOOR CONTROLS - WITH 3 POSITION TOGGLE SWITCH WITH AMBER CANCEL

16.5. PANEL MOUNTED DOOR CONTROLS - WITH 2 POSITION TOGGLE SWITCH WITH AMBER CANCEL WITH RRX, MASTER SWITCH, P. 5
Figure 657 PANEL MOUNTED DOOR CONTROLS - WITH 2 POSITION TOGGLE SWITCH WITH AMBER

Components: AMBER CANCEL (11760); CONTROLLER (1601); CONTROLLER (1602); LT RELAY (10309-R1); PLATFORM (1702); RELAY (10311-R5); RELAY (10311-R6); RELAY (10312-R2); RELAY COILS (10369); SPLICE (10335B); SPLICE (10399); ZVR SPLICE (10350A)
Wires (circuit gauge+color): A120AP 18LTGN; A89KK 18OR; B11-G 18WH; B11-GA 18WH; B120A 18LTGN; B120B 18LTGN; B120L 18LTGN; B123-GL 18WH; B123L 18LTGN; B123T 18LTGN; B62 18DKBL; B62-G 18WH; B9S 18GY; B9T 18GY; B9X 18GY
See also sheets: CH16_11, CH3_30, CH3_37, CH3_60, CH6_17, CH7_63
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.5. PANEL MOUNTED DOOR CONTROLS - WITH 2 POSITION TOGGLE SWITCH WITH AMBER CANCEL WITH RRX, MASTER SWITCH, P. 5 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 PANEL MOUNTED DOOR CONTROLS - W/2 POSITION TOGGLE SWITCH W/AMBER CANCEL W/RRX, MASTER SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 30 FLASHER SYSTEM RELAY (10311-R6) / 87 87A / 87 87A / BOOSTER PUMP RELAY (10311-R5) / AMBER CANCEL (11760) / B62-G 18WH / B62 18DKBL / B11-G 18WH B11-GA 18WH / SW ILLUM SPLICE (10399) CH7_63 GROUND SPLICE (10335B) CH3_37 / B9X 18GY / ELEC PANEL/ PLATFORM (1702) 60 A89KK 18OR / JS-TAN BODY CONTROLLER (1602) / FLASHER SYSTEM RELAY (10312-R2) CH6_17 / ZVR SPLICE (10350A) CH3_60 / B120A 18LTGN / B120B 18LTGN / B9S 18GY / 18GY B9T / B123L 18LTGN / B123T 18LTGN / B123-GL 18WH / A120AP 18LTGN / B120L 18LTGN / J4-BLUE BODY CONTROLLER (1601) / ACC SPLICE RELAY COILS (10369) CH3_30 / DOOR LT RELAY (10309-R1) CH16_11 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 657 / PANEL MOUNTED DOOR CONTROLS - WITH 2 POSITION TOGGLE SWITCH WITH AMBER CANCEL WITH RRX, MASTER SWITCH

16.6. PANEL MOUNTED DOOR CONTROLS - WITH LEFT SIDE REDUNDANT DOOR, P.
Figure 658 PANEL MOUNTED DOOR CONTROLS - WITH LEFT SIDE REDUNDANT DOOR

Components: J5-TAN BODY CONTROLLER (1602); PLATFORM (1702); PLATFORM (1703); REDUNDANT DOOR SWITCH (10365); SPLICE (10329); SPLICE (10350A)
Wires (circuit gauge+color): A120E 16LTGN; A120F 18LTGN; B120D 18LTGN; B120E 18LTGN; B62-GAB 18WH; B62AB 18DKBL; B9B 18GY
See also sheets: CH3_60, CH8_30
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.6. PANEL MOUNTED DOOR CONTROLS - WITH LEFT SIDE REDUNDANT DOOR, P. 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 PANEL MOUNTED DOOR CONTROLS - W/LEFT SIDE REDUNDANT DOOR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / *B9B 18GY / B120E 18LTGN B120D 18LTGN / ZERO VOLT SPLICE (10350A) CH3_60 ZERO VOLT SPLICE (10350A) CH3_95N / REDUNDANT DOOR SWITCH (10365) 8 / B62AB 18DKBL B62-GAB 18WH / SWITCH ILLUMINATION SPLICE (10329) CH8_30 / ELEC PANEL/ PLATFORM (1702) 61 / A120E 16LTGN ELEC PANEL/ PLATFORM (1703) / J5-TAN BODY CONTROLLER (1602) REDUNDANT DOOR CLOSE CONTROL THREE POSITION SWITCH MIDDLE POSITION / A120F 18LTGN / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / #B9B 18GY / # W/VEHICLES BUILT AFTER 8/4/2017 & BEFORE 01/08/2020 * W/VEHICLES BUILT AFTER 01/08/2020 / Figure 658 / PANEL MOUNTED DOOR CONTROLS - WITH LEFT SIDE REDUNDANT DOOR

16.7. PANEL MOUNTED DOOR CONTROLS - WITH RIGHT SIDE REDUNDANT DOOR, P. 7
Figure 659 PANEL MOUNTED DOOR CONTROLS - WITH RIGHT SIDE REDUNDANT DOOR

Components: CONTROLLER (1602); DOOR SWITCH (3203); PANEL LIGHT (1002B); REFERANCE SPLICE (1005A)
Wires (circuit gauge+color): A120E 16LTGN; A120F 18LTGN; A120FA 18LTGN; A62-GN 18WH; A62N 18DKBL; A9Z 18GY
See also sheets: CH3_59, CH8_26
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.7. PANEL MOUNTED DOOR CONTROLS - WITH RIGHT SIDE REDUNDANT DOOR, P. 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 PANEL MOUNTED DOOR CONTROLS - W/RIGHT SIDE REDUNDANT DOOR / MJV0488 19NOV21 ADDED CIRC A120FA IN CAV 1 OF R/D 3203. / A9Z 18GY / #A120FA 18LTGN A120E 16LTGN / ZERO VOLT REFERANCE SPLICE (1005A) CH3_59 / REDUNDANT DOOR SWITCH (3203) 8 / A62N 18DKBL A62-GN 18WH / @A120F 18LTGN / RIGHT SWITCH PANEL LIGHT (1002B) CH8_26 / REDUNDANT DOOR F8 OPEN CONTROL / J5-TAN BODY CONTROLLER (1602) REDUNDANT DOOR F9 CLOSE SIGNAL / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / @ N/0508108 - NOT MTA FUSE BLOCK # W/0508108 - MTA FUSE BLOCK / Figure 659 / PANEL MOUNTED DOOR CONTROLS - WITH RIGHT SIDE REDUNDANT DOOR

16.8. FRONT ENTRANCE DOOR - WITH MANUAL DOOR CONTROL WITHOUT AIR / ELECTRIC DOOR, P. 8
Figure 660 FRONT ENTRANCE DOOR - WITH MANUAL DOOR CONTROL WITHOUT AIR / ELECTRIC

Components: COILS (10364); CONTROLLER (1602); ELEC PANEL (1702); FUSE B12-B (10301); FUSE B9-R (10302); KEY SWITCH (1146); LT RELAY (10309-R3); PLATFORM (1703); RELAY (10309-R1); SIGNAL (1145A); SPLICE (10335B); SPLICE (10389); ZVR SPLICE (10350A)
Wires (circuit gauge+color): A120C 16LTGN; A120D 16LTGN; A120JA 16LTGN; A120SK 16LTGN; B120-GK 18WH; B120-GL 18WH; B120-GM 18WH; B120J 18LTGN; B120JB 16LTGN; B120JC 16LTGN; B120K 18LTGN; B120L 18LTGN; B120M 18LTGN; B120N 18LTGN; B12C 18LTGN; B131A 16DKBL; B131BC 16DKBL; B9C 18GY
See also sheets: CH16_15, CH3_07, CH3_16, CH3_29, CH3_37, CH3_60, CH8_22
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.8. FRONT ENTRANCE DOOR - WITH MANUAL DOOR CONTROL WITHOUT AIR / ELECTRIC DOOR, P. 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 FRONT ENTRANCE DOOR - W/MANUAL DOOR CONTROL N/AIR/ELECTRIC DOOR / MJV0488 19NOV21 CIRC B131BC WAS B131B B AT R/D 10389. / 85 B120M 18LTGN B120-GM 18WH / 30 STEP WELL LT RELAY (10309-R3) / 87 87A / FUSE B9-R (10302) CH3_16 / B131BC 16DKBL / A (3202B) / MANUAL DOOR SWITCH B / (3202A) A A120C 16LTGN / A120D 16LTGN / DOOR CONTROL RELAY (10309-R1) 85 / 87 87A / B120-GL 18WH B120-GK 18WH / GROUND SPLICE (10335B) CH3_37 / B12C 18LTGN / DOOR OPTION SPLICE (10389) CH8_22 / A120SK 16LTGN / J5-TAN BODY CONTROLLER (1602) / PLATFORM/ ELEC PANEL (1702) 73 / B131A 16DKBL / ACCESSARY SPLICE RELAY COILS (10364) CH3_29 / B120K 18LTGN / A120JA 16LTGN / B120J 18LTGN / FUSE B12-B (10301) CH3_07 / B120JB 16LTGN / B120JC 16LTGN / VANDAL LOCK KEY SWITCH (1146) CH16_15 DOOR OPEN SIGNAL (1145A) CH16_15 / B120L 18LTGN / B120N 18LTGN / B9C 18GY / ZVR SPLICE (10350A) CH3_60 / ELEC PANEL/ PLATFORM (1703) / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 660 / FRONT ENTRANCE DOOR - WITH MANUAL DOOR CONTROL WITHOUT AIR / ELECTRIC DOOR

16.9. FRONT ENTRANCE DOOR - WITH AIR DOOR, P. 9
Figure 661 FRONT ENTRANCE DOOR - WITH AIR DOOR

Components: DIODE B6-K (10303); DOOR CONTROL (10047); FRONT CAP (10000); FRONT CAP (1702); FRONT CAP/ELEC PANEL (10000); FUSE B9-R (10302); J5-BLUE BODY CONTROLLER (1601); PLATFORM (1702); RELAY (10309-R1); RELAY (10309-R2); RELAY (10309-R3); RELAY (10311-R1); SPLICE (10335B); SPLICE (10337); SPLICE (10389); SYSTEM RELAY (10312-R2)
Wires (circuit gauge+color): A120AP 18LTGN; A120EE 18LTGN; B120-GC 18WH; B120-GK 18WH; B120-GL 18WH; B120-GS 18WH; B120-GT 18WH; B120K 18LTGN; B120KA 18LTGN; B120KB 18LTGN; B120KC 18LTGN; B120KD 18LTGN; B120L 18LTGN; B120S 18LTGN; B120T 18LTGN; B120U 18LTGN; B120V 18LTGN; B120W 18LTGN; B120WA 18LTGN; B120X 18LTGN; B120Y 18LTGN; B123N 18LTGN; B131A 16DKBL; B131BC 16DKBL; C120 16LTGN; C120-G 16WH; C120-GA 16WH; C120A 16LTGN
See also sheets: CH16_25, CH3_16, CH3_37, CH3_41, CH6_17, CH8_14, CH8_22
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.9. FRONT ENTRANCE DOOR - WITH AIR DOOR, P. 9 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 FRONT ENTRANCE DOOR - W/AIR DOOR / MJV0488 19NOV21 CIRC B131BC WAS B131B B AT R/D 10389. / %B120K 18LTGN %B120T 18LTGN %B120S 18LTGN *B120V 18LTGN DOOR CONTROL RELAY (10309-R1) 86 30 / 85 B120-GT 18WH / DOOR CONTROL RELAY (10309-R2) 86 30 30 / 30 30 / ELEC PANEL/ PLATFORM (1702) 55 54 / B120-GS 18WH *B120K 18LTGN #B120KB 18LTGN *B120T 18LTGN / AIR DOOR SOLENOID / 1 2 3 4 / J5-BLUE BODY CONTROLLER (1601) / E9 DOOR CLOSE ELECTRIC CONTROL / E13 DOOR OPEN CONTROL ELECTRIC / A120EE 18LTGN / A120AP 18LTGN / RELAY (10312-R2) CH6_17 FLASHER SYSTEM 18LTGN B120L / 16LTGN 16LTGN C120A C120 / C120-G 16WH / C120-GA 16WH / *B120S 18LTGN / B131BC 16DKBL / DOOR OPTION SPLICE (10389) CH8_22 / B120T 18LTGN B120U 18LTGN / PANEL CAP/ELEC (10000) CH16_25 FRONT / @B120X 18LTGN / GROUND SPLICE (10337) CH3_41 DIODE B6-K (10303) 22 18 / B120-GL 18WH / B120-GC 18WH / *B120L 18LTGN / #B120KC 18LTGN / #B120KA 18LTGN / @B120Y 18LTGN / *B120W 18LTGN / %B120WA 18LTGN / 18LTGN B123N / #B120KD 18LTGN / Figure 661 / FRONT ENTRANCE DOOR - WITH AIR DOOR

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 702 | printed page 662 | section 16.10
16.10. FRONT ENTRANCE DOOR - WITH AIR DOOR (CONT.), P. 9A
Figure 662 FRONT ENTRANCE DOOR - WITH AIR DOOR (CONT.)

Components: DIODE D64 (10306); DOOR CONTROL (10047); FRONT CAP (10000); FRONT CAP (1702); FRONT CAP/ELEC PANEL (10000); FUSE F58 (10305); J5-BLUE BODY CONTROLLER (1601); LIGHT RELAY (10309); PLATFORM (1702); RELAY (10311); RELAY 1 (10309); RELAY 2 (10309); SPLICE (10335B); SPLICE (10337); SPLICE (10389)
Wires (circuit gauge+color): A120AP 18LTGN; A120EE 18LTGN; B120-GC 18WH; B120-GK 18WH; B120-GS 18WH; B120GL 18WH; B120K 18LTGN; B120KA 18LTGN; B120KB 18LTGN; B120KC 18LTGN; B120KD 18LTGN; B120L 18LTGN; B120S 18LTGN; B120T 18LTGN; B120U 18LTGN; B120W 18LTGN; B120WA 18LTGN; B120X 18LTGN; B131A 16DKBL; B131B 16DKBL; C120 16LTGN; C120-G 16WH; C120-GA 16WH; C120A 16LTGN
See also sheets: CH16_17, CH6_23, CH6_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.10. FRONT ENTRANCE DOOR - WITH AIR DOOR (CONT.), P. 9A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090667 NO. RELEASE NO. 95885P 26MAR21 / CHAPTER 16 FRONT ENTRANCE DOOR- W/AIR DOOR (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / STEP WELL LIGHT RELAY (10309) H2 G2 86 30 30 / DOOR CONTROL RELAY 1 (10309) A2 C2 86 30 / 18LTGN B120S 87A / 85 A1 / D2 30 30 / 87A E1 / 85 D1 B120KC 18LTGN / DOOR CONTROL RELAY 2 (10309) F2 86 / 85 G1 / C1 B120X 18LTGN / ELEC PANEL/ PLATFORM (1702) 55 / B120K 18LTGN / AIR DOOR SOLENOID / DOOR OPTION SPLICE (10389) CH8_23A GROUND SPLICE (10335B) CH3_95H / B120-GK 18WH / 1 2 3 4 / J5-BLUE BODY CONTROLLER (1601) NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / E9 DOOR CLOSE ELECTRIC CONTROL / E13 DOOR OPEN CONTROL ELECTRIC / A120EE 18LTGN / A120AP 18LTGN / B120L 18LTGN / 16LTGN C120A 16LTGN C120 / C120-G 16WH / C120-GA 16WH / B131A 16DKBL / B131B 16DKBL / FRONT CAP/ ENTRANCE DOOR CONTROL (10047) / PANEL CAP/ELEC (10000) CH16_17 FRONT / B120-GS 18WH B120KB 18LTGN / B120W 18LTGN / *B120W 18LTGN / GROUND SPLICE (10337) CH3_95L DIODE D64 (10306) CH6_24 DIODE D64 (10306) CH6_23 / * W/SINGLE CYCLE FLR CANCEL % W/RRX CANCEL / B120GL 18WH / B120-GC 18WH %B120WA 18LTGN / B120KA 18LTGN B120KD 18LTGN / Figure 662 / FRONT ENTRANCE DOOR - WITH AIR DOOR (CONT.)

16.11. FRONT ENTRANCE DOOR - WITH AIR DOOR WITH LOW SIDE DRIVER, P. 10
Figure 663 FRONT ENTRANCE DOOR - WITH AIR DOOR WITH LOW SIDE DRIVER

Components: DOOR CONTROL (10047); FORM (1702); FRONT CAP (10000); FRONT CAP/ELEC PANEL (10000); FUSE B9-R (10302); J5-BLUE BODY CONTROLLER (1601); RELAY (10309-R1); RELAY (10309-R2); RELAY (10309-R3); SPLICE (10337); SPLICE (10389); SWITCH (1145)
Wires (circuit gauge+color): A120AP 18LTGN; A120EE 18LTGN; A120H 12LTGN; B120-GC 18WH; B120AM 18LTGN; B120AN 18LTGN; B120AP 18LTGN; B120M 18LTGN; B120N 18LTGN; B120P 18LTGN; B120S 18LTGN; B120T 18LTGN; B120U 18LTGN; B120V 18LTGN; B120W 18LTGN; B120X 18LTGN; B131A 16DKBL; B131BC 16DKBL; C120 16LTGN; C120-G 16WH; C120-GA 16WH; C120A 16LTGN
See also sheets: CH16_25, CH3_16, CH3_41, CH8_22
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.11. FRONT ENTRANCE DOOR - WITH AIR DOOR WITH LOW SIDE DRIVER, P. 10 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 FRONT ENTRANCE DOOR - W/AIR DOOR W/LOW SIDE DRIVER / MJV0488 19NOV21 CIRC B131BC WAS B131B B AT R/D 10389. / STEPWELL LT RELAY (10309-R3) 85 / DOOR CONTROL RELAY (10309-R1) 86 30 / 30 30 / 30 30 / FUSE B9-R (10302) CH3_16 / B120N 18LTGN B120AM 18LTGN B120M 18LTGN / AIR DOOR SOLENOID / ELEC PANEL/ FRONT CAP A7 (10000) / 1 2 3 3 / J5-BLUE BODY CONTROLLER (1601) / E9 DOOR CLOSE ELECTRIC CONTROL / E13 DOOR OPEN ELECTRIC CONTROL / A120AP 18LTGN A120EE 18LTGN / 16LTGN C120A 16LTGN C120 / C120-G 16WH / C120-GA 16WH / B131A 16DKBL / 18LTGN B120P / B131BC 16DKBL / DOOR OPTION SPLICE (10389) CH8_22 / FRONT CAP/ ENTRANCE DOOR CONTROL (10047) / 18LTGN B120T 18LTGN B120U / PANEL CAP/ELEC (10000) CH16_25 FRONT / B120X 18LTGN / DUME VALVE SWITCH (1145) CH16_25 / DOOR CONTROL RELAY (10309-R2) / B120-GC 18WH / GROUND SPLICE (10337) CH3_41 / B120AP 18LTGN / B120W 18LTGN / 12LTGN A120H / B120S 18LTGN / B120AN 18LTGN / B120V 18LTGN / ELEC PANEL/ PLAT- FORM (1702) / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 663 / FRONT ENTRANCE DOOR - WITH AIR DOOR WITH LOW SIDE DRIVER

16.12. FRONT ENTRANCE DOOR - WITH AIR DOOR WITH LOW SIDE DRIVER (CONT.), P. 10A
Figure 664 FRONT ENTRANCE DOOR - WITH AIR DOOR WITH LOW SIDE DRIVER (CONT.)

Components: DOOR CONTROL (10047); FRONT CAP (10000); FRONT CAP/ELEC PANEL (10000); FUSE F58 (10305); J5-BLUE BODY CONTROLLER (1601); LIGHT RELAY (10309); PLATFORM (1702); RELAY 1 (10309); RELAY 2 (10309); SPLICE (10337); SPLICE (10389); SWITCH (1145)
Wires (circuit gauge+color): A120AP 18LTGN; A120EE 18LTGN; A120H 18LTGN; B120-GC 18WH; B120AM 18LTGN; B120AN 18LTGN; B120AP 18LTGN; B120M 18LTGN; B120N 18LTGN; B120P 18LTGN; B120T 18LTGN; B120U 18LTGN; B120W 18LTGN; B120X 18LTGN; B131A 16DKBL; B131BC 16DKBL; C120 16LTGN; C120-G 16WH; C120-GA 16WH; C120A 16LTGN
See also sheets: CH16_25
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.12. FRONT ENTRANCE DOOR - WITH AIR DOOR WITH LOW SIDE DRIVER (CONT.), P. 10A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 26MAR21 / CHAPTER 16 FRONT ENTRANCE DOOR- W/AIR DOOR W/LOW SIDE DRIVER (CONT) / CHAPTER B 96289K CH8_23A FOR CIRC B131BC. / MJV0488 19NOV21 / STEP WELL LIGHT RELAY (10309) / A2 30 / DOOR CONTROL RELAY 1 (10309) 85 A1 / C2 86 / D2 30 30 / DOOR CONTROL RELAY 2 (10309) 87A E1 / 85 D1 / F2 86 / G2 30 30 / 85 G1 / H2 86 / FUSE F58 (10305) CH3_94M / ELEC PANE /PLATFORM (1702) / B120AM 18LTGN B120M 18LTGN B120W 18LTGN / AIR DOOR SOLENOID / ELEC PANEL/ FRONT CAP A7 (10000) / 1 2 3 4 / J5-BLUE BODY CONTROLLER (1601) NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / E9 DOOR CLOSE ELECTRIC CONTROL / E13 DOOR OPEN ELECTRIC CONTROL / A120AP 18LTGN A120EE 18LTGN / 16LTGN C120A 16LTGN C120 / C120-G 16WH / C120-GA 16WH / B131A 16DKBL / 18LTGN B120P / B131BC 16DKBL / DOOR OPTION SPLICE (10389) CH8_23A / FRONT CAP/ ENTRANCE DOOR CONTROL (10047) / 18LTGN B120T 18LTGN B120U / PANEL CAP/ELEC (10000) CH16_25 FRONT / B120X 18LTGN B120AP 18LTGN / DUME VALVE SWITCH (1145) CH16_25 / B120-GC 18WH / GROUND SPLICE (10337) CH3_95L / B120N 18LTGN / B120AN 18LTGN / 18LTGN A120H / Figure 664 / FRONT ENTRANCE DOOR - WITH AIR DOOR WITH LOW SIDE DRIVER (CONT.)

16.13. FRONT ENTRANCE DOOR - WITH AIR DOOR WITHOUT STEP-WELL LIGHT RELAY, P. 11
Figure 665 FRONT ENTRANCE DOOR - WITH AIR DOOR WITHOUT STEP-WELL LIGHT RELAY

Components: BOOSTER PUMP RELAY (10311-R5); DOOR CONTROL (10047); ENT DOOR CAV7 (1351); FR CAP (10000); FR CAP (1702); FRONT CAP (10000); FRONT CAP/ELEC PANEL (10000); J5-BLUE BODY CONTROLLER (1601); LT RELAY (10309-R1); LT RELAY (10309-R2); PLATFORM (1702); SPLICE (10335B); SPLICE (10337)
Wires (circuit gauge+color): A120AP 18LTGN; A120EE 18LTGN; A120EH 20LTGN; B120-GC 18WH; B120-GK 18WH; B120-GS 18WH; B120-GT 18WH; B120A 18LTGN; B120B 18LTGN; B120L 18LTGN; B120S 18LTGN; B120TB 18LTGN; B120U 18LTGN; B120W 18LTGN; B120X 18LTGN; B120Y 18LTGN; C120 16LTGN; C120-G 16WH; C120-GA 16WH; C120A 16LTGN
See also sheets: CH16_05, CH16_14, CH16_17, CH16_25, CH17_30, CH3_37, CH3_41
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.13. FRONT ENTRANCE DOOR - WITH AIR DOOR WITHOUT STEP-WELL LIGHT RELAY, P. 11 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 FRONT ENTRANCE DOOR - W/AIR DOOR N/STEP-WELL LT RELAY / MJV0488 19NOV21 CIRC B120TB WAS B120T B AT CAV A7 OF R/D 10000. / DOOR LT RELAY (10309-R1) 86 30 / 87A B120X 18LTGN / 85 B120-GS 18WH / BOOSTER PUMP RELAY (10311-R5) CH16_05 DOOR LT RELAY (10309-R2) 86 30 30 / 85 B120Y 18LTGN / ELEC PANEL/ PLATFORM (1702) / AIR DOOR SOLENOID / ELEC PANEL/ FRONT CAP A7 (10000) / 2 3 1 4 / J5-BLUE BODY CONTROLLER (1601) / E9 DOOR CLOSE ELECTRIC CONTROL / E13 DOOR OPEN CONTROL ELECTRIC / A120EE 18LTGN / A120AP 18LTGN / 18LTGN B120L / 16LTGN C120A 16LTGN C120 / C120-G 16WH / C120-GA 16WH / 18LTGN B120S / STOP ARM CAV1 ENT DOOR CAV7 (1351) CH17_30 FRONT CAP/ ENTRANCE DOOR CONTROL (10047) / ELEC PANEL/ FR CAP B120TB 18LTGN B120U 18LTGN (1702) CH16_17 ELEC PANEL/ FR CAP (10000) CH16_14 / PANEL CAP/ELEC (10000) CH16_25 FRONT / B120-GT 18WH B120-GK 18WH / B120W 18LTGN / B120-GC 18WH / GROUND SPLICE (10337) CH3_41 / GROUND SPLICE (10335B) CH3_37 / B120B 18LTGN / B120A 18LTGN / A120EE 18LTGN / A120EH 20LTGN / @B120W 18LTGN / @ W/SW MOUNTED ABOVE ENTR DOOR / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 665 / FRONT ENTRANCE DOOR - WITH AIR DOOR WITHOUT STEP-WELL LIGHT RELAY

16.14. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR, P. 12
Figure 666 FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR

Components: B9-B (10302); DIODE B6-K (10303); DOOR CONTROL (10047); FR CAP (10000); FUSE B12-B (10301); PLATFORM (1702); RELAY (10309-R); RELAY (10309-R2); RELAY (10309-R3); RELAY (10312-R2); SIGNAL (10357); SPLICE (10335B); SPLICE (10389); SWITCH (10060)
Wires (circuit gauge+color): B120-GK 18WH; B120-GL 18WH; B120-GS 18WH; B120-GT 16WH; B120-GU 16WH; B120-GV 16WH; B120-GW 18WH; B120J 16LTGN; B120K 18LTGN; B120L 18LTGN; B120S 18LTGN; B120T 16LTGN; B120T 18LTGN; B120U 18LTGN; B120V 16LTGN; B120W 16LTGN; B120WA 18LTGN; B12C 16LTGN; B131A 16DKBL; B131BC 16DKBL; B1A 16LTGN; C120 16LTGN; C120-G 16WH; C120-GA 16WH; C120A 16LTGN; C120B 18LTGN; C120C 18LTGN
See also sheets: CH16_19, CH3_07, CH3_16, CH3_37, CH6_16, CH8_22
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.14. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR, P. 12 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 FRONT ENTRANCE DOOR - W/ELECTRIC DOOR / MJV0488 19NOV21 CIRC B131BC WAS B131B B AT R/D 10389. / STEPWELL LIGHT RELAY (10309-R3) FRONTCAP/ ENTRANCE DOOR CONTROL (10047) / DOOR CONTROL RELAY (10309-R) 86 30 / 85 B120-GW 18WH / 30 30 / DOOR CONTROL RELAY (10309-R2) 86 / *B120T 18LTGN @B120T 16LTGN / DOOR OPEN NC CONTACTS A / DOOR MOTOR / FLASHER SYSTEM ELEC PANEL/ RELAY PLATFORM (10312-R2) (1702) CH6_16 CH16_19 / B120V 16LTGN B120J 16LTGN B120-GS 18WH B120-GK 18WH FUSE B9-B (10302) CH3_16 / DOOR OPEN NC CONTACTS A / B120L 18LTGN / C120-GA C120-G 16LTGN 16WH 16WH C120 C120A 16LTGN / 120-G 16WH 16LTGN 120 / B120-GT B120-GU 16WH 18LTGN 16WH B120U / 120-GA 16WH / FUSE B12-B (10301) CH3_07 GROUND SPLICE (10335B) CH3_37 ELEC PANEL/ B1 FR CAP (10000) / B120-GV 18LTGN B120T 16WH / 16LTGN 120A / 30 30 / B120W 16LTGN / *B120S @B120S 18LTGN 18LTGN / 16DKBL B131A / B120-GL 18WH / DOOR OPTION SPLICE (10389) CH8_22 / DOOR SIGNAL (10357)) / @B1A 16LTGN / 16LTGN *B120K 18LTGN @B120K 18LTGN B12C / GROUND STUD (28) / *B120WA 18LTGN / B120WA 18LTGN / B6-K (10303) DIODE / C120B 18LTGN C120C 18LTGN / OVERHEAD DOOR SWITCH (10060) / B131BC 16DKBL / Figure 666 / FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR

16.15. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR (CONT.), P. 12A
Figure 667 FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR (CONT.)

Components: CONTROLLER (1601); DOOR CONTROL (10047); FRONT CAP (10000); FUSE F32 (10303); PLATFORM (1702); RELAY (10309); RELAY 1 (10309); RELAY 2 (10309)
Wires (circuit gauge+color): A120AP 16LTGN; A120AP 18LTGN; A120AS 18LTGN; A120AT 18LTGN; A120EE 16LTGN; A120EE 18DKBL; A120EE 18LTGN; A120EF 18LTGN; B120-GL 18WH; B120-GS 18WH; B120-GT 16WH; B120-GU 16WH; B120J 16LTGN; B120K 16LTGN; B120K 18LTGN; B120L 18LTGN; B120S 16LTGN; B120S 18LTGN; B120T 18LTGN; B120U 18LTGN; B120V 16LTGN; C120 16LTGN; C120-G 16WH; C120-GA 16WH; C120A 16LTGN
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.15. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR (CONT.), P. 12A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090667 NO. RELEASE NO. 95885P 26MAR21 / CHAPTER 16 FRONT ENTRANCE DOOR-W/ELECTRIC DOOR (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / STEP WELL LIGHT RELAY (10309) CH8_23A / A2 30 / 87A B1 / 85 A1 / DOOR CONTROL RELAY 1 (10309) 86 / DOOR CONTROL RELAY 2 (10309) F2 D2 86 30 30 / 87A E1 / 85 D1 / ELEC PANEL/ 55 54 PLATFORM (1702) / FUSE F32 (10303) CH3_94H / J4-BLUE BODY CONTROLLER (1601) / E9 E13 DOOR CLOSE DOOR OPEN ELECTRIC ELECTRIC CONTROL CONTROL / #A120AP *A120EE #A120EE @A120EE 16LTGN *A120AP 18LTGN 16LTGN 18DKBL 18LTGN B120J 16LTGN / B120S 18LTGN B120S 16LTGN / B120K 18LTGN B120-GL 18WH B120K 16LTGN / B120-GS 18WH / FRONTCAP/ ENTRANCE DOOR CONTROL (10047) DOOR OPEN NC CONTACTS A / DOOR MOTOR / ELEC PANEL/ FRONT CAP B2 (10000) / B120V 16LTGN / DOOR OPEN NC CONTACTS A / 18LTGN B120L / C120-GA C120-G 16WH 16LTGN 16LTGN 16WH C120 C120A / 120-GA 16WH 120-G 16WH 16LTGN 120 / B120-GU B120-GT 16WH B120T 18LTGN 16WH / 18LTGN B120U / 16LTGN 120A / * RIGHT AIR / ELECT DOOR N/VANDAL LOCK # W/SIGNAL KEY OFF @ W/ZONAR / #A120AS 18LTGN / @A120EF #A120AT 18LTGN 18LTGN / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 667 / FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR (CONT.)

16.16. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH LOW SIDE DRIVER, P. 13
Figure 668 FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH LOW SIDE DRIVER

Components: B12-B (10301); DOOR CONTROL (10047); FR CAP (10000); FUSE B12-L (10301); FUSE B9-R (10302); PLATFORM (1702); RELAY (10309-R1); RELAY (10309-R2); RELAY (10309-R3); SPLICE (10389)
Wires (circuit gauge+color): B120-GT 16WH; B120-GU 16WH; B120AJ 16LTGN; B120AK 16LTGN; B120J 16LTGN; B120N 18LTGN; B120P 16LTGN; B120R 16LTGN; B120S 16LTGN; B120T 16LTGN; B120U 16LTGN; B120W 16LTGN; B120X 16LTGN; B120Y 16LTGN; B120Z 16LTGN; B131A 16DKBL; B131BC 16DKBL; C120 16LTGN; C120-G 16WH; C120-GA 16WH; C120A 16LTGN
See also sheets: CH16_19, CH3_07, CH3_16, CH3_19, CH8_22
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.16. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH LOW SIDE DRIVER, P. 13 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 FRONT ENTRANCE DOOR - W/ELECTRIC DOOR W/LOW SIDE DRIVER / MJV0488 19NOV21 CIRC B131BC WAS B131B B AT R/D 10389. / DOOR CONTROL RELAY (10309-R2) 86 30 / ELEC PANEL /FR CAP (10000) A8 / B120U 16LTGN B120T 16LTGN B120-GT 16WH B120-GU 16WH B120N 18LTGN / 86 STEPWELL LIGHT RELAY (10309-R3) / B131A 16DKBL / B120AJ 16LTGN B120R 16LTGN / FUSE B9-R (10302) CH3_16 / DOOR CONTROL RELAY (10309-R1) / 16LTGN 120A / DOOR OPEN NC CONTACTS A / 120-G 16WH / 16LTGN 120GA 16WH 120 / DOOR OPEN NC CONTACTS / DOOR MOTOR / FR CAP/ ENTRANCE DOOR CONTROL (10047) %C120A 2 16LTGN %C120 16LTGN %C120-GA 16WH %C120-G 16WH / B131BC 16DKBL / DOOR OPTION SPLICE (10389) CH8_22 / B120Z 16LTGN / B120P 16LTGN / B120AK 16LTGN / ELEC PANEL/ PLATFORM (1702) CH16_19 / B120S 16LTGN / B120X 16LTGN B120W 16LTGN / B120Y 16LTGN / 16LTGN B120J / FUSE B12-B (10301) CH3_07 / FUSE B12-L (10301) CH3_19 / % W/ELECTRIC DOOR / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 668 / FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH LOW SIDE DRIVER

16.17. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH KEY OFF SWITCH, P. 14
Figure 669 FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH KEY OFF SWITCH

Components: DOOR CONTROL (10047); DOOR LT RELAY (10309-R2); ELAY (10309-R3); FR CAP (10000); FUSE B12-B (10309); FUSE B9-R (10302); LOCK RELAY (10312-R6); OVERHEAD DOOR SWITCH (10060); PLATFORM (1702/1702); RELAY (10309-R2); RELAY COILS (10369); SPLICE (10335B); SPLICE (10389)
Wires (circuit gauge+color): B120-GK 18WH; B120-GL 18WH; B120-GS 18WH; B120-GT 16WH; B120-GU 16WH; B120-GV 16WH; B120-GW 18WH; B120AV 16LTGN; B120J 16LTGN; B120JC 16LTGN; B120K 16LTGN; B120L 18LTGN; B120S 16LTGN; B120T 16LTGN; B120T 18LTGN; B120U 18LTGN; B120V 16LTGN; B120W 16LTGN; B120W 18LTGN; B12Z 16LTBL; B131A 16DKBL; B131BC 16DKBL; B14AF 16RD; B9T-G 16GY; C120 16LTGN; C120-G 16WH; C120-GA 16WH; C120A 16LTGN; C120B 18LTGN; C120C 18LTGN
See also sheets: CH16_11, CH16_15, CH3_07, CH3_16, CH3_30, CH3_37, CH8_22
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.17. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH KEY OFF SWITCH, P. 14 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 16 FRONT ENTRANCE DOOR - W/ELECTRIC DOOR W/KEY OFF SWITCH / MJV0488 19NOV21 CIRC B131BC WAS B131B B AT R/D 10389. / AED VANDAL GROUND LOCK RELAY STUD (10312-R6) (28/37) / DOOR LT RELAY (10309-R2) CH16_11 B9T-G 16GY / B120AV 16LTGN B14AF 16RD / ELEC PANEL @C120C 18LTGN @C120B /FR CAP 18LTGN (10000) / B120-GV B120-GV 16WH 16WH B120T 18LTGN B120-GT 16WH B120U 18LTGN B120-GU 16WH / B120V 16LTGN / B120L 18LTGN / 86 STEPWELL LIGHT ELAY (10309-R3) / ACC SPLICE RELAY COILS (10369) CH3_30 / B120T 16LTGN DOOR CONTROL RELAY (10309-R2) / 85 B120-GL 18WH / B120-GS 18WH / B120W 16LTGN B120K 16LTGN / GROUND SPLICE (10335B) CH3_37 / DOOR CONTROL RELAY (10309- R1) / B12Z 16LTBL B120JC 16LTGN / 16LTGN 120A / DOOR OPEN NC CONTACTS A / 120-G 16WH / 16LTGN 120GA 16WH 120 / DOOR OPEN NC CONTACTS / DOOR MOTOR / FR CAP/ ENTRANCE DOOR CONTROL (10047) 2 %C120A 16LTGN %C120 16LTGN %C120-GA 16WH %C120-G 16WH / ELECTRIC PANEL/ PLATFORM (1702/1702) CH16_15 / OVERHEAD DOOR SWITCH (10060) / B120J 16LTGN / B120-GW 18WH / B120S 16LTGN / 18LTGN B120W / B120-GK 18WH / Figure 669 / FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH KEY OFF SWITCH

16.18. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH KEY OFF SWITCH
Figure 670 FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH KEY OFF SWITCH (CONT.)

Components: BODY CONTROLLER (1601); DIODE (1031); FUSE B12-B (10301); FUSE F32 (10303); KEY SWITCH (1146); LOCK RELAY (10310); LOCK RELAY (10312-R6); PACK (1003A); PLATFORM (1702/1702); RELAY (10309); RELAY (10309-R1); RELAY (10309-R3); SIGNAL (1145A); SIGNAL (1145B); SPLICE PACK (1003A)
Wires (circuit gauge+color): A120AP 16LTGN; A120AS 18LTGN; A120AT 18LTGN; A120AV 16LTGN; A120B 18LTGN; A120EE 16LTGN; A120JA 16LTGN; A120JB 16LTGN; A120JC 16LTGN; A133-G 18WH; A133B 16LTBL; A133B 16LTGN; A133C 16LTGN; B120AV 16LTGN; B120J 18LTGN; B120K 16LTGN; B120K 18LTGN; B120L 18LTGN; B120S 16LTGN; B120W 16LTGN; B14AF 16RD
See also sheets: CH16_08, CH16_14, CH16_19, CH16_35, CH3_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.18. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH KEY OFF SWITCH (CONT.), P. 15 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 FRONT ENTRANCE DOOR - W/ELECTRIC DOOR W/KEY OFF SWITCH (CONT.) / MJV0488 19NOV21 ADDED CIRC A120B & R/D 1031. / ELEC PANEL/ PLATFORM (1702/1702) 34 / A120JA 16LTGN #A120EE 16LTGN A120EE 16LTGN / A120AP 16LTGN / A120JB 16LTGN #A133B 16LTGN A133B 16LTBL / A133C 16LTGN / A120JC 16LTGN / DOOR OPEN SIGNAL (1145A) A / BODY CONTROLLER (1601) DOOR OPEN E13 COMMAND / A120AT 18LTGN A120AS 18LTGN / DOOR CLOSE COMMAND / VANDAL LOCK KEY SWITCH (1146) / *A133-G 18WH / AED VANDAL LOCK RELAY (10310) CH16_35,39 AED VANDAL LOCK RELAY (10312-R6) CH16_14 / *B120AV 16LTGN / *B120K 16LTGN / *B120L 18LTGN / *B14AF 16RD / A120AV 16LTGN / DOOR OPEN SIGNAL (1145B) / *B120W 16LTGN / *B120S 16LTGN / *B120J 18LTGN / FUSE B12-B (10301) CH16_08 / &B120AV 16LTGN / FUSE F32 (10303) CH3_94H / &B120J 18LTGN / &B14AF 16RD / &B120K 18LTGN / &B120L 18LTGN / * W/0508108 - MTA FUSE BLOCK & N/0508108 - NOT MTA FUSE BLOCK # W/CROSSING GATE N/ZONAR OR PWL / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK. / &A133-G 18WH / #A120B 18LTGN / CROSSING GATE DIODE (1031) CH5_10B / Figure 670 / FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH KEY OFF SWITCH (CONT.)

16.19. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH RELEASE STARTER INTERLOCK, P. 16
Figure 671 FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH RELEASE STARTER

Components: DIODE B6-K (10303); DOOR CONTROL (10047); FR CAP (10000); FUSE B12-B (10301); FUSE B9-R (10302); PLATFORM (1702); RELAY (10309-R2); RELAY (10309-R3); RELAY (10312-R2); SIGNAL (10357); SPLICE (10335B); SPLICE (10389); SWITCH (10060)
Wires (circuit gauge+color): B120-GK 18WH; B120-GL 18WH; B120-GS 18WH; B120-GT 16WH; B120-GU 16WH; B120-GV 16WH; B120-GW 18WH; B120J 16LTGN; B120K 18LTGN; B120L 18LTGN; B120S 18LTGN; B120T 16LTGN; B120T 18LTGN; B120U 18LTGN; B120V 16LTGN; B120V 18LTGN; B120W 16LTGN; B120W 18LTGN; B120Y 16LTGN; B123N 18LTGN; B12C 16LTGN; B131A 16DKBL; B131BC 16DKBL; B1A 16LTGN; C120 16LTGN; C120-G 16WH; C120-GA 16WH; C120A 16LTGN; C120B 18LTGN; C120C 18LTGN
See also sheets: CH16_19, CH3_07, CH3_16, CH3_37, CH6_17, CH8_22
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.19. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH RELEASE STARTER INTERLOCK, P. 16 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 FRONT ENTRANCE DOOR - W/ELECTRIC DOOR W/RELEASE STARTER INTERLOCK / MJV0488 19NOV21 CIRC B131BC WAS B131B B AT R/D 10389. / DOOR CONTROL RELAY (10309-R2) 86 30 / ELEC PANEL #C120C 18LTGN /FR CAP #C120B 18LTGN (10000) / B120-GV B120-GV 16WH 16WH B120T 18LTGN B120-GT 16WH B120U 18LTGN B120-GU 16WH / STEPWELL LIGHT RELAY (10309-R3) 86 30 / 85 B120-GL 18WH / B120W 16LTGN / B131A 16DKBL / GROUND STUD (28) / DOOR OPEN NC CONTACTS FUSE B9-R (10302) CH3_16 / 16LTGN 120A / DOOR OPEN NC CONTACTS A / 120-G 16WH / 16LTGN 120GA 16WH 120 / DOOR MOTOR / FR CAP/ ENTRANCE DOOR CONTROL (10047) 2 %C120A 16LTGN %C120 16LTGN %C120-GA 16WH %C120-G 16WH / OVERHEAD DOOR SWITCH (10060) / B131BC 16DKBL / DOOR OPTION SPLICE (10389) CH8_22 GROUND SPLICE (10335B) CH3_37 / B12C 16LTGN / B120J 16LTGN / 16LTGN B120V / ELEC PANEL/ PLATFORM (1702) CH16_19 / B120S 18LTGN / B120-GK 18WH / DOOR SIGNAL (10357) / B1A 16LTGN / B120-GS 18WH / 22 B123N 18LTGN / B6-K (10303) DIODE / B120K 18LTGN / B120T 16LTGN / B120Y 16LTGN / B120J 16LTGN / # W/AIR DOOR W/OVERHEAD SWITCH % N/CANCEL @ W/CANCEL / Figure 671 / FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH RELEASE STARTER INTERLOCK

16.20. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH SINGLE CYCLE FLASHER CANCEL, P. 17
Figure 672 FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH SINGLE CYCLE FLASHER

Components: DIODE B6-K (10303); DOOR CONTROL (10047); FR CAP (10000); FUSE B12-B (10301); FUSE B9-R (10302); PLATFORM (1702); RELAY (10309-R2); RELAY (10309-R3); RELAY (10312-R2); SIGNAL (10357); SPLICE (10335B); SPLICE (10389); SWITCH (10060)
Wires (circuit gauge+color): B120-GK 18WH; B120-GL 18WH; B120-GS 18WH; B120-GT 16WH; B120-GU 16WH; B120-GV 16WH; B120-GW 18WH; B120J 16LTGN; B120K 18LTGN; B120L 18LTGN; B120S 18LTGN; B120T 16LTGN; B120T 18LTGN; B120U 18LTGN; B120V 16LTGN; B120V 18LTGN; B120W 16LTGN; B120W 18LTGN; B123N 18LTGN; B12C 16LTGN; B131A 16DKBL; B131BC 16DKBL; B1A 16LTGN; C120 16LTGN; C120-G 16WH; C120-GA 16WH; C120A 16LTGN; C120B 18LTGN; C120C 18LTGN
See also sheets: CH16_19, CH3_07, CH3_16, CH3_37, CH6_17, CH8_22
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.20. FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH SINGLE CYCLE FLASHER CANCEL, P. 17 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 FRONT ENTRANCE DOOR - W/ELECTRIC DOOR W/SINGLE CYCLE FLASHER CANCEL / MJV0488 19NOV21 CIRC B131BC WAS B131B B AT R/D 10389. / DOOR CONTROL RELAY (10309-R2) 86 30 / B120T 16LTGN / ELEC PANEL @C120C 18LTGN @C120B /FR CAP 18LTGN (10000) / B120-GV 16WH B120T 18LTGN B120-GT 16WH B120U 18LTGN B120-GU 16WH / STEPWELL LIGHT RELAY (10309-R3) 86 30 / 85 B120-GL 18WH / B120W 16LTGN / B131A 16DKBL / FLASHER B120W 18LTGN SYSTEM RELAY (10312-R2) CH6_17 B120V 18LTGN DOOR CONTROL RELAY (10309- R1) B120-GW 18WH B120L 18LTGN FUSE B12-B (10301) CH3_07 / GROUND STUD (28) / DOOR OPEN NC CONTACTS FUSE B9-R (10302) CH3_16 / 16LTGN 120A / DOOR OPEN NC CONTACTS A / 120-G 16WH / 16LTGN 120GA 16WH 120 / DOOR MOTOR / FR CAP/ ENTRANCE DOOR CONTROL (10047) 2 %C120A 16LTGN %C120 16LTGN %C120-GA 16WH %C120-G 16WH / OVERHEAD DOOR SWITCH (10060) / B131BC 16DKBL / DOOR OPTION SPLICE (10389) CH8_22 / B12C 16LTGN / B120J 16LTGN / 16LTGN B120V / ELEC PANEL/ PLATFORM (1702) CH16_19 / B120S 18LTGN / B120-GK 18WH / GROUND SPLICE (10335B) CH3_37 / DOOR SIGNAL (10357) / B1A 16LTGN / B120-GS 18WH / B6-K (10303) DIODE 18 / 22 B123N 18LTGN / B120K 18LTGN / @ W/AIR DOOR W/OVERHEAD SW % N/CANCEL / NOTE: R/D 28 & 27 ARE RING TERMINALS AND NOT BE AVAILBLE IN CONN COMPOSITE. NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 672 / FRONT ENTRANCE DOOR - WITH ELECTRIC DOOR WITH SINGLE CYCLE FLASHER CANCEL

16.21. VANDAL LOCKS ON RIGHT WITH AIR DOOR WITH ZONAR, P. 18
Figure 673 VANDAL LOCKS ON RIGHT WITH AIR DOOR WITH ZONAR

Components: ELEC PANEL/PLATFORM (1703); FRONT CAP (10000/10000); FUSE B12-B (10301); FUSE F32 (10303); GROUND SPLICE (1003A); KEY SWITCH (1146); PLATFORM (1702/1702); SPLICE (1003A); VANDAL LOCK (10059)
Wires (circuit gauge+color): A133-G 18WH; A133A 18LTGN; A133B 18LTGN; A133C 18LTGN; B133A 18LTGN; B133J 18LTGN; B133K 18LTGN; C81A 18LTGN; C81B 18LTGN
See also sheets: CH3_07, CH3_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.21. VANDAL LOCKS ON RIGHT WITH AIR DOOR WITH ZONAR, P. 18 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 VANDAL LOCKS ON RIGHT W/AIR DOOR W/ZONAR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/ FRONT CAP B3 (10000/10000) / 2 4 1 3 / VANDAL LOCK KEY SWITCH (1146) 2 / B133K 18LTGN / FUSE F32 (10303) CH3_94H FUSE B12-B (10301) CH3_07 GROUND SPLICE (1003A) CH3_95B GROUND SPLICE (1003A) CH3_32 / B133J 18LTGN / #A133-G 18WH ELEC PANEL/PLATFORM (1703) B2 / A133C 18LTGN / VANDAL LOCK (10059) / 18LTGN 18LTGN C81A C81B / ELEC PANEL/ PLATFORM (1702/1702) 20 / #B133A 18LTGN / A133A 18LTGN *A133-G 18WH / VANDAL LOCK KEY SWITCH / A133B 18LTGN / VANDAL LOCK SOLENOID / *B133A 18LTGN / * W/VEHICLES BUILT AFTER 8/4/2017 & BEFORE 01/08/2020 # W/VEHICLES BUILT AFTER 01/08/2020 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 673 / VANDAL LOCKS ON RIGHT WITH AIR DOOR WITH ZONAR

16.22. VANDAL LOCKS ON RIGHT WITH ELECTRIC DOOR WITH ZONAR, P. 19
Figure 674 VANDAL LOCKS ON RIGHT WITH ELECTRIC DOOR WITH ZONAR

Components: CONTROLLER (1601); ELEC PANEL (1702); KEY SWITCH (1146); PACK (1003A); RELAY (10309-R1); RELAY (10309-R2); SPLICE (1003); SPLICE (10382)
Wires (circuit gauge+color): A120AP 16LTGN; A120AS 18LTGN; A120AT 18LTGN; A120EE 16LTGN; A133 16LTGN; A133-G 18WH; A133-GA 16WH; A133A 16LTGN; A133B 18LTBL; A133C 16LTGN; B120AJ 16LTGN; B120AK 16LTGN; B120K 18LTGN; B120L 18LTGN; B120S 16LTGN; B12C 16LTGN; B133A 16LTGN
See also sheets: CH15_25, CH16_12, CH16_13, CH3_31, CH3_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.22. VANDAL LOCKS ON RIGHT WITH ELECTRIC DOOR WITH ZONAR, P. 19 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 VANDAL LOCKS ON RIGHT W/ELECTRIC DOOR W/ZONAR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PLATFORM/ ELEC PANEL 20 (1702) / A133-G 18WH A133A 16LTGN A133C 16LTGN A133B 18LTBL / J4-BLUE BODY CONTROLLER (1601) / 18LTGN B120L 18LTGN B120K / 16LTGN B12C / DOOR CONTROL RELAY (10309-R1) CH16_12,16,17 DOOR CONTROL RELAY (10309-R2) CH16_13 / 16LTGN B133A / STARTER INTERLOCK SPLICE (10382) CH15_25 GROUND SPLICE (1003) CH3_31, 95A / VANDAL LOCK STARTER INTERLOCK @(1146A) A / A133-GA 16WH VANDAL LOCK STARTER INTERLOCK @(1146B) @ W/CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / A133 16LTGN / MANUAL RELEASE VANDAL LOCK KEY SWITCH / A120AT 18LTGN / A120AS 18LTGN / VANDAL LOCK KEY SWITCH (1146) / A120AP 16LTGN A120EE 16LTGN / GROUND SPLICE PACK (1003A) CH3_32 / B120AJ 16LTGN / DOOR CONTROL RELAY (10309-R1) CH16_13 / B120S 16LTGN / B120AK 16LTGN / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 674 / VANDAL LOCKS ON RIGHT WITH ELECTRIC DOOR WITH ZONAR

16.23. VANDAL LOCKS ON RIGHT WITH MANUAL DOOR, P. 20
Figure 675 VANDAL LOCKS ON RIGHT WITH MANUAL DOOR

Components: FUSE B12-B (10301); KEY SWITCH (1146); PLATFORM (1702); SPLICE (1003A); VANDAL SOLENOID (1147)
Wires (circuit gauge+color): A133A 18LTGN; A133B 18LTGN; A133B-G 18WH; A133C 18LTGN; B133-G 18WH; B133A 18LTGN
See also sheets: CH3_07, CH3_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.23. VANDAL LOCKS ON RIGHT WITH MANUAL DOOR, P. 20 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 VANDAL LOCKS ON RIGHT W/MANUAL DOOR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/ PLATFORM (1702) 20 / 2 4 1 3 / 1 MANUAL DOOR VANDAL SOLENOID (1147) / VANDAL LOCK KEY SWITCH (1146) 2 / FUSE B12-B (10301) CH3_07 / B133A 18LTGN / A133A 18LTGN / VANDAL LOCK KEY SWITCH / A133B 18LTGN / A133C 18LTGN / GROUND SPLICE (1003A) CH3_32 / A133B-G 18WH / #B133-G 18WH / GROUND SPLICE (1003A) CH3_32 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 675 / VANDAL LOCKS ON RIGHT WITH MANUAL DOOR

16.24. ALTERNATE ENTRANCE DOOR WITH RIGHT WITH VANDAL LOCK KEY SWITCH, P. 21
Figure 676 ALTERNATE ENTRANCE DOOR WITH RIGHT WITH VANDAL LOCK KEY SWITCH

Components: ELEC PANEL/PLATFORM (1703); ENT DOOR CAV7 (1351); FUSE B6-T (10303); KEY SWITCH (1146); LEFT BODY (10401A/B/10401); PLATFORM (1702); REAR BODY (10700); REAR CAP (10405); SPLICE (1003A)
Wires (circuit gauge+color): A133-G 18WH; A133A 18LTGN; A133B 18LTGN; A133C 18LTGN; B133L 18LTGN; B133M 18LTGN; B133N 18LTGN; D81A 18LTGN; D81B 18LTGN; E81A 18LTGN; E81B 18LTGN; F81A 18LTGN; F81B 18LTGN
See also sheets: CH17_30, CH3_14, CH3_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.24. ALTERNATE ENTRANCE DOOR WITH RIGHT WITH VANDAL LOCK KEY SWITCH, P. 21 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 ALTERNATE ENTRANCE DOOR W/RIGHT W/VANDAL LOCK KEY SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELECT PANEL/ LEFT BODY B11 B10 (10401A/B/10401) / 2 4 1 3 / VANDAL LOCK KEY SWITCH (1146) 2 / VANDAL LOCK AED *(10770C) #(10770D) @(10770E) &(10770F) %(10770G) 2 / B133M 18LTGN / VANDAL LOCK SOLENOID / FUSE B6-T (10303) CH3_14 GROUND SPLICE (1003A) CH3_32 / B133N 18LTGN / A133-G 18WH ELEC PANEL/PLATFORM (1703) B2 / A133C 18LTGN / REAR CAP/ REAR BODY (10700) / 18LTGN 18LTGN E81B E81A / ELEC PANEL/ PLATFORM (1702) 20 / 81A 18LTGN 81B 18LTGN / * W/8,9,12,13 WDO # W/10,13 WDO @ W/10,11 WDO & W/11,12,13 WDO % W/13 WDO / F81A 18LTGN F81B 18LTGN / 18LTGN 18LTGN D81B D81A / LEFT BODY/ REAR CAP (10405) / B133L 18LTGN / A133A 18LTGN / VANDAL LOCK KEY SWITCH / A133B 18LTGN A133B 18LTGN / STOP ARM CAV1 ENT DOOR CAV7 (1351) CH17_30 / Figure 676 / ALTERNATE ENTRANCE DOOR WITH RIGHT WITH VANDAL LOCK KEY SWITCH

16.25. ALTERNATE ENTRANCE DOOR WITH LEFT & RIGHT WITH AIR WITH DUMP VALVE, P. 22
Figure 677 ALTERNATE ENTRANCE DOOR WITH LEFT & RIGHT WITH AIR WITH DUMP VALVE

Components: AED STEP LT (11517); BLOCK (11507); DOOR (10479); ENTRANCE DOOR (10203); FUSE B12-K (10301); FUSE F44 (10304); ILLUMINATION SPLICE (10399); LEFT BODY (10401A/B/10401); PWL OVERRIDE SPLICE (10402); REAR CAP (10405); RIGHT BODY (10700); SEALED ENGINE (11500); SPLICE (10482); ZVR SPLICE (10350A)
Wires (circuit gauge+color): B120AA 18LTGN; B120AB 18LTGN; B120AC 18LTGN; B120AD 18LTGN; B120AE 18LTGN; B131D 18DKBL; B62-GBL 18WH; B62BL 18DKBL; B89L 18OR; B9K 18GY; D120A 18LTGN; D120B 18LTGN; D120C 18LTGN; E120-GA 18WH; E120A 18LTGN; E120B 18LTGN; E120C 18LTGN; E120E 18LTGN; E120F 18LTGN; E120H 18LTGN; Y131-GD 16WH; Y131D 16DKBL
See also sheets: CH16_24, CH3_18, CH3_48, CH3_57, CH3_60, CH6_22, CH7_63
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.25. ALTERNATE ENTRANCE DOOR WITH LEFT & RIGHT WITH AIR WITH DUMP VALVE, P. 22 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 ALTERNATE ENTRANCE DOOR W/LEFT & RIGHT W/AIR W/DUMP VALVE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/ LEFT BODY B4 B4 (10401A/B/10401) / AED STEP LT (11517) STEP LT 1 Y131D 16DKBL Y131-GD 16WH / E120B 18LTGN / D120A 18LTGN / REAR CAP/ RIGHT BODY (10700) CH16_24,37 NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / D120B 18LTGN / 18LTGN D120C / B120AE 18LTGN *B120AA 18LTGN #B120AA 18LTGN B120AC 18LTGN / E120C 18LTGN / E120A 18LTGN / ALTERNATE ENTRANCE DOOR (10203) 8 / GROUND SPLICE (10482) CH3_57 / B62BL 18DKBL B62-GBL 18WH B89L 18OR #/@B9K 18GY / @B9K 18GY B131D 18DKBL / FUSE F44 (10304) CH3_94K FUSE B12-K (10301) CH3_18 / SWITCH ILLUMINATION SPLICE (10399) CH7_63 PWL OVERRIDE SPLICE (10402) CH6_22 ZVR SPLICE (10350A) CH3_95N ZVR SPLICE (10350A) CH3_60 / GROUND SPLICE BLOCK (11507) CH3_48 / ELEC PANEL/ SEALED ENGINE (11500) A2 / *B120AB 18LTGN / LEFT BODY/ REAR CAP (10405) / @E120E 18LTGN @E120-GA 18WH @E120F 18LTGN @E120H 18LTGN / @ W/AIR DOOR N/6 WDO # W/VEHICLES BUILT AFTER 8/4/2017 & BEFORE 01/08/2020 * W/VEHICLES BUILT AFTER 01/08/2020 / ALTERNATE ENTRANCE DOOR (10479) / #B120AB 18LTGN *B120AD 18LTGN / Figure 677 / ALTERNATE ENTRANCE DOOR WITH LEFT & RIGHT WITH AIR WITH DUMP VALVE

16.26. ALTERNATE ENTRANCE DOOR WITH LEFT WITH ELECTRIC WITH MASTER
Figure 678 ALTERNATE ENTRANCE DOOR WITH LEFT WITH ELECTRIC WITH MASTER SWITCH

Components: AED STEP LT (11517); DOOR (10479); ELECTRIC (10203A); FR CAP (10000); FUSE B12-K (10301); LEFT BODY (10401B/10401); OPTION (10380); REAR CAP (10405); REAR CAP/RIGHT BODY (10700); RELAY (10310-R3); RELAY (10312-R3); RELAY (10312-R6); SEALED ENGINE (11500); SPLICE (10336); SPLICE (10399); SPLICE (10402); SPLICE (11507); SWITCH (10236)
Wires (circuit gauge+color): B120 18LTGN; B120-AB 16LTGN; B120-GD 18WH; B120-GE 18WH; B120-GG 18WH; B120-GH 16WH; B120-GJ 16LTGN; B120-GK 18WH; B120AA 18LTGN; B120AC 16LTGN; B120AD 18LTGN; B120AE 18LTGN; B120AF 16LTGN; B120AH 16LTGN; B120AK 16LTGN; B120AL 16LTGN; B123B 18OR; B131C 18DKBL; B131D 18DKBL; B62-GBL 18WH; B62BL 18LTBL; B89L 18OR; D120A 18LTGN; D120B 18LTGN; D120C 18LTGN; D120D 18LTGN; E120-GB 16LTGN; E120-GC 16LTGN; E120A 18LTGN; E120B 18LTGN; E120C 18LTGN; E120D 18LTGN; E120K 16LTGN; E120L 16LTGN; Y131-GD 16WH; Y131D 16DKBL
See also sheets: CH16_24, CH3_18, CH3_40, CH3_48, CH6_15, CH6_22, CH7_63, CH7_66
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.26. ALTERNATE ENTRANCE DOOR WITH LEFT WITH ELECTRIC WITH MASTER SWITCH WITH 9, P. 23 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 ALTERNATE ENTRANCE DOOR W/LEFT W/ELECTRIC W/MASTER SWITCH W/9 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / *E120-GB 16LTGN *E120-GC 16LTGN *E120K 16LTGN *E120L 16LTGN / * W/ELECTRIC DOOR N/6 WDO / 18LTGN D120B / 18LTGN 18LTGN E120D E120C / 18LTGN 18LTGN D120D D120C / B123B 18OR / LEFT AED ELECTRIC (10203A) 8 / 18LTGN D120A / 18DKBL B131D / E120B 18LTGN / 3 4 1 / B120-GH 16WH / B120AE 18LTGN / AED STEP LT (11517) / B89L 18OR / REAR CAP/RIGHT BODY (10700) CH16_24 NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / STEP LT / ELEC PANEL/ FR CAP (10000) CH16_24 ELEC PANEL/ B5 LEFT BODY (10401B/10401) / B120AA 18LTGN / SWITCH ILLUMINATION SPLICE (10399) CH7_63 PWL OVERRIDE SPLICE (10402) CH6_22 MASTER FLASHER SWITCH (10236) CH6_15 / ELEC PANEL/ SEALED ENGINE (11500) GROUND SPLICE (11507) CH3_48 / E120A 18LTGN / Y131-GD 16DKBL Y131D 16WH / B120AH 16LTGN / B62BL 18LTBL B62-GBL 18WH / B120 18LTGN / B120AF 16LTGN / B120-GJ 16LTGN GROUND SPLICE ALTERNATE ENTRANCE (10336) DOOR CH3_40 (10479) / LEFT BODY/ REAR CAP (10405) / B120-GK 18WH / 30 30 / B120AD 18LTGN B120-AB 16LTGN AED RELAY (10312-R3) 86 / 30 30 / B120AK 16LTGN AED VANDAL LOCK RELAY (10312-R6) 86 / B120-GG 18WH TEMP SENSOR RELAY (10310-R3) 86 30 30 / CLEARANCE LIGHT OPTION (10380) CH7_66 / B131C 18DKBL / B120AL 16LTGN / FUSE B12-K (10301) CH3_18 / B120AC 16LTGN / B120-GF 18WHH B120-GD 18WH / B120-GE 18WH / Figure 678 / ALTERNATE ENTRANCE DOOR WITH LEFT WITH ELECTRIC WITH MASTER SWITCH WITH 9

16.27. DUMP VALVE EFFECTS - WITH ALTERNATE ENTRANCE DOOR WITH AIR / ELECTRIC, P. 24
Figure 679 DUMP VALVE EFFECTS - WITH ALTERNATE ENTRANCE DOOR WITH AIR / ELECTRIC

Components: BLOCK (10009); DUMP VALVE (10041); ELEC PANEL (10401B); FRONT CAP (10000); REAR CAP (10405); RIGHT BODY (10700); SPLICE (10701)
Wires (circuit gauge+color): B120 18LTGN; C120-GC 18WH; C120C 18LTGN; D120A 18LTGN; D120B 18LTGN; D120C 18LTGN; D120D 18LTGN; F120-G 18WH; F120A 18LTGN; F120B 18BK; F120B 18LTGN; F120C 18LTGN; F120D 18LTGN; F120E 18LTGN; F120F 18LTGN; F120H 18LTGN; F120J 18LTGN
See also sheets: CH16_22, CH16_23, CH3_43, CH3_52
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.27. DUMP VALVE EFFECTS - WITH ALTERNATE ENTRANCE DOOR WITH AIR / ELECTRIC, P. 24 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 DUMP VALVE EFFECTS - W/ALTERNATE ENTRANCE DOOR W/AIR/ELECTRIC / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / AIR DOOR SOLENOID **(10769C) #(10769D) ##(10769E) @(10769F) *(10769G) OPEN / 2 1 3 / DUMP VALVE SWITCH AUTO **(10778C) #(10778D) ##(10778E) @(10778F) *(10778G) @@(10778F) / F120C 18LTGN *F120B 18BK F120B 18LTGN / RED CLOSED BLK BLK / @@F120E 18LTGN F120D 18LTGN / F120A 18LTGN / REAR CAP / RIGHT BODY (10700) B9 / D120D 18LTGN / D120C 18LTGN / D120B 18LTGN / D120A 18LTGN / * W/13 WDO @ W/11,13 WDO **W/8,9,12,13 WDO # W/10,13 WDO ##W/10,11 WDO @@W/12 WDO / GROUND SPLICE (10701) CH3_52 / LEFT BODY/ REAR CAP (10405) CH16_22,23 / C120C 18LTGN C120-GC 18WH / ALT ENTRANCE DUMP VALVE (10041) 1 / B120 18LTGN / LEFT BODY/ ELEC PANEL (10401B) CH16_23 GROUND SPLICE BLOCK (10009) CH3_43 / ELEC PNL/ FRONT CAP (10000) C7 / F120-G 18WH F120-G 18WH / @@F120F 18LTGN / LEFT BODY/ REAR CAP (10405) CH16_23 / 2P 1P 3P / AIR DOOR SOLENOID @@(10769F) OPEN / RED CLOSED BLK BLK / F120H 18LTGN / F120J 18LTGN / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 679 / DUMP VALVE EFFECTS - WITH ALTERNATE ENTRANCE DOOR WITH AIR / ELECTRIC

16.28. DUMP VALVE EFFECTS - WITH AIR DOOR WITH INTERIOR AND EXTERIOR, P. 25
Figure 680 DUMP VALVE EFFECTS - WITH AIR DOOR WITH INTERIOR AND EXTERIOR

Components: CONTROL (10047); ELEC PANEL (10000); FUSE B12-L (10301); FUSE F45 (10304); PLATFORM (1702); RELAY (10309); RELAY (10309-R3); RELAY 2 (10309); RELAY 2 (10309-R2); SWITCH (1145); SWITCH (1148); SWITCH (1148A)
Wires (circuit gauge+color): A120F 18LTGN; A120FE 18LTGN; A120FF 18LTGN; A120FT 18LTGN; A120H 18LTGN; B120M 18LTGN; B120N 18LTGN; B120R 18LTGN; B120W 18LTGN; B120Y 18LTGN; C120-GA 16WH
See also sheets: CH16_09, CH16_10, CH3_19
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.28. DUMP VALVE EFFECTS - WITH AIR DOOR WITH INTERIOR AND EXTERIOR, P. 25 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 DUMP VALVE EFFECTS - W/AIR DOOR W/INTERIOR AND EXTERIOR / MJV0488 19NOV21 ADDED CIRC A120FT & B A120FF IN CAV 21 OF R/D 1702. / **B120R &B120R 18LTGN 18LTGN / ELEC PANEL/ 21 PLATFORM OUT SIDE AIR (1702) DOOR DUMP **A120FT SWITCH 18LTGN (1148A) A &A120F 18LTGN / 2 SC SC 1 / FRONT CAP/ ELEC PANEL (10000) B2 / DUMP VALVE SWITCH (1145) / FUSE F45 &(10304) CH3_94K FRONT CAP/ ENTRANCE DOOR CONTROL (10047) CH16_10A / **B120N 18LTGN / @A120H 18LTGN / @A120F 18LTGN / **B120W 18LTGN / C120-GA 16WH / STEP WELL LIGHT RELAY (10309) CH16_10A STEP WELL LIGHT RELAY (10309-R3) CH16_10 DOOR CONTROL RELAY 2 (10309-R2) CH16_09,11 DOOR CONTROL RELAY 2 (10309) CH16_9A / FUSE F45 (10304) CH3_94K FUSE B12-L (10301) CH3_19 / A120FE 18LTGN OUT SIDE AIR DOOR DUMP SWITCH (1148) A / *A120H 18LTGN / **B120W 18LTGN / **B120Y 18LTGN / #A120H 18LTGN / &A120F 18LTGN **A120FF 18LTGN / **B120M 18LTGN / &B120N 18LTGN / &B120W 18LTGN / *B120N 18LTGN / &B120W 18LTGN / Figure 680 / DUMP VALVE EFFECTS - WITH AIR DOOR WITH INTERIOR AND EXTERIOR

16.29. REAR DOOR ACTIVATED OPTION, P. 26
Figure 681 REAR DOOR ACTIVATED OPTION

Components: DIODE B3-X (10304); DIODE B6-U (10303); FUSE A1-B (10305); RELAY (10310-R4); SPLICE (10204); SPLICE (10335B); SPLICE (10382); SPLICE (10386)
Wires (circuit gauge+color): B117-GL 18WH; B117H 18LTGN; B117J 18LTGN; B117JZ 16LTGN; B117K 18LTGN; B117L 18GY; B117M 18GY; B133E 18LTGN
See also sheets: CH14_01, CH15_25, CH3_19, CH3_37, CH8_06
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.29. REAR DOOR ACTIVATED OPTION, P. 26 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 29DEC20 / CHAPTER 16 REAR DOOR ACTIVATED OPTION / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B117L 18GY / BUZZER RELAY (10310-R4) / 18LTGN B117K / DIODE B6-U (10303) / B117J 18LTGN / B117M 18GY / B117H 18LTGN / FUSE A1-B (10305) CH3_19 / GROUND SPLICE (10335B) CH3_37 / B117-GL 18WH / EMER EXIT BUZZER SPLICE (10204) CH14_01 / B117JZ 16LTGN / DIODE B3-X (10304) / B133E 18LTGN / REAR DOOR SPLICE (10386) CH8_06 / STARTER INTERLOCK SPLICE (10382) CH15_25 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 681 / REAR DOOR ACTIVATED OPTION

16.30. REAR DOOR ACTIVATED OPTION (CONT.), P. 26A
Figure 682 REAR DOOR ACTIVATED OPTION (CONT.)

Components: BUZZER SPLICE (10204); DIODE D67 (10306); DIODE D82 (10307); FUSE F72 (10306); LEFT BODY (10401A/B); RELAY (10310); SPLICE (10335B); SPLICE (10386)
Wires (circuit gauge+color): B117-GL 18WH; B117F 18GY; B117H 18LTGN; B117J 18LTGN; B117JZ 16LTGN; B117K 18LTGN; B117L 18GY; B117M 18GY
See also sheets: CH14_24, CH15_37
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.30. REAR DOOR ACTIVATED OPTION (CONT.), P. 26A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090667 NO. RELEASE NO. 95885P 26MAR21 / CHAPTER 16 REAR DOOR ACTIVATED OPTION (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR DOOR SPLICE (10386) C / B4 30 / A3 86 / B117L 18GY / 85 A4 / 87A B3 / BUZZER RELAY (10310) / B117-GL 18WH / DIODE D67 (10306) A3 B3 / B117J 18LTGN / B117M 18GY / ELECTRICAL PANEL/ LEFT BODY (10401A/B) CH14_24 / B117F 18GY / B117K 18LTGN / DIODE D82 (10307) CH15_37 / FUSE F72 (10306) CH3_94N / GROUND SPLICE (10335B) CH3_95H / B117H 18LTGN / EMER EXIT BUZZER SPLICE (10204) CH14_1A / B117JZ 16LTGN / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 682 / REAR DOOR ACTIVATED OPTION (CONT.)

16.31. RIGHT ENTRANCE DOOR WITH MANUAL DOOR, P. 27
Figure 683 RIGHT ENTRANCE DOOR WITH MANUAL DOOR

Components: BODY CONTROLLER (1602); LIGHT RELAY (10309); PLATFORM (1702); PLATFORM (1703); RELAY 1 (10309); RELAY COIL (10364); SPLICE (10350A)
Wires (circuit gauge+color): A120C 16LTGN; A120D 16LTGN; A120SK 18LTGN; B120-GL 18WH; B120K 18LTGN; B120L 18LTGN; B120M 18LTGN; B12C 18LTGN; B9C 18GY
See also sheets: CH3_29
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.31. RIGHT ENTRANCE DOOR WITH MANUAL DOOR, P. 27 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 26MAR21 / CHAPTER 16 RIGHT ENTRANCE DOOR W/MANUAL DOOR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/ PLATFORM (1702) 73 / B120K 18LTGN / A120C 16LTGN A120D 16LTGN / C2 86 / 85 A1 / A2 30 / ZERO VOLT REFERANCE SPLICE (10350A) CH3_95N / B9C 18GY / DOOR CONTROL RELAY 1 (10309) / STEPWELL LIGHT RELAY (10309) CH8_23A / B120M 18LTGN / DOOR CONTROL F15 OPEN INPUT / B120-GL 18WH / (3202A) A / STEPWELL LIGHT RELAY (10309) CH8_23A / ELEC PANEL/ PLATFORM (1703) A4 / B12C 18LTGN / MANUAL DOOR SWITCH / ACCESSORY SPLICE RELAY COIL (10364) CH3_29 / A120SK 18LTGN / J5-TEN BODY CONTROLLER (1602) / B120L 18LTGN / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 683 / RIGHT ENTRANCE DOOR WITH MANUAL DOOR

16.32. RIGHT ALTERNATE ENTRANCE DOOR VANDAL LOCK KEY SWITCH, P. 28
Figure 684 RIGHT ALTERNATE ENTRANCE DOOR VANDAL LOCK KEY SWITCH

Components: BODY CONTROLLER (1601); FUSE F32 (10303); KEY SWITCH (1146); PLATFORM (1702); SPLICE (1003A); VANDAL SOLENOID (1147)
Wires (circuit gauge+color): A120AS 18LTGN; A120AT 18LTGN; A133-G 18WH; A133A 16LTGN; A133A 18LTGN; A133B 16LTGN; A133B 18LTGN; A133B-G 18WH; A133C 16LTGN; A133C 18LTGN; B120J 18LTGN; B133A 18LTGN
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.32. RIGHT ALTERNATE ENTRANCE DOOR VANDAL LOCK KEY SWITCH, P. 28 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 26MAR21 / CHAPTER 16 RIGHT ALTERNATE ENTRANCE DOOR VANDAL LOCK KEY SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/ PLATFORM (1702) 20 / 2 4 1 3 / 1 MANUAL DOOR VANDAL SOLENOID (1147) / VANDAL LOCK KEY SWITCH (1146) 2 / FUSE F32 (10303) CH3_94H / B133A 18LTGN / A133A 18LTGN / VANDAL LOCK KEY SWITCH / A133C 18LTGN A133B 16LTGN A133B 18LTGN / GROUND SPLICE (1003A) CH3_95B / A133B-G 18WH / A120AS 18LTGN A120AT 18LTGN / A133C 16LTGN / A133-G 18WH / GROUND SPLICE (1003A) CH3_95B / J4-BLUE BODY CONTROLLER (1601) / B120J 18LTGN / A133A 16LTGN / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 684 / RIGHT ALTERNATE ENTRANCE DOOR VANDAL LOCK KEY SWITCH

16.33. RIGHT ALTERNATE ENTRANCE DOOR VANDAL LOCK KEY SWITCH (CONT.), P. 29
Figure 685 RIGHT ALTERNATE ENTRANCE DOOR VANDAL LOCK KEY SWITCH (CONT.)

Components: BODY CONTROLLER (1601); ELEC PANEL/PLATFORM (1703); ENT DORR-CAV 7 (1351); FUSE F32 (10303); FUSE F84 (10307); KEY SWITCH (1146); PLATFORM (1702); REAR BODY (10700); REAR CAP (10405); SPLICE (1003A)
Wires (circuit gauge+color): A120AS 18LTGN; A120AT 18LTGN; A120EH 20LTGN; A133-G 18WH; A133A 18LTGN; A133B 16LTGN; A133B 18LTGN; A133C 16LTGN; A133C 18LTGN; B120J 18LTGN; B133L 18LTGN; B133M 18LTGN; B133N 18LTGN; D81A 18LTGN; D81B 18LTGN; E81A 18LTGN; E81B 18LTGN; F81A 18LTGN; F81B 18LTGN
See also sheets: CH17_30
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.33. RIGHT ALTERNATE ENTRANCE DOOR VANDAL LOCK KEY SWITCH (CONT.), P. 29 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 26MAR21 / CHAPTER 16 RIGHT ALTERNATE ENTRANCE DOOR VANDAL LOCK KEY SWITCH (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELECT PANEL/ LEFT BODY (10401A/B/ B11 B10 10401) / 2 4 1 3 / VANDAL LOCK KEY SWITCH (1146) 2 / VANDAL LOCK AED *(10770C) #(10770D) @(10770E) &(10770F) / B133M 18LTGN / VANDAL LOCK SOLENOID / FUSE F32 (10303) CH3_94H FUSE F84 (10307) CH3_94P GROUND SPLICE (1003A) CH3_95B / B133N 18LTGN / A133-G 18WH ELEC PANEL/PLATFORM (1703) B2 / A133C 18LTGN / REAR CAP/ REAR BODY (10700) / 18LTGN 18LTGN E81B E81A / ELEC PANEL/ PLATFORM (1702) 20 / F81A 18LTGN F81B 18LTGN / 18LTGN 18LTGN D81B D81A / LEFT BODY/ REAR CAP (10405) / B133L 18LTGN / A133A 18LTGN / VANDAL LOCK KEY SWITCH / A133B 18LTGN / E9 ELECTRIC DOOR CONTROL CLOSE / ELECTRIC DOOR E13 CONTROL OPEN / %A120AT 18LTGN %A120AS 18LTGN / %A133C 16LTGN / %A133B 16LTGN / STOP ARM-CAV 1 ENT DORR-CAV 7 (1351) CH17_30 J4-BLUE BODY CONTROLLER (1601) / %B120J 18LTGN / **A133B 18LTGN / A120EH 20LTGN / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 685 / RIGHT ALTERNATE ENTRANCE DOOR VANDAL LOCK KEY SWITCH (CONT.)

16.34. VANDAL LOCK FOR ELECTRIC ENTRANCE DOOR, P. 30
Figure 686 VANDAL LOCK FOR ELECTRIC ENTRANCE DOOR

Components: DOOR CONTROL RELAY (10309); ELEC PANEL (1702); ENT DOOR CAV 7 (1351); FUSE F32 (10303); GROUND SPLICE (1003); GROUND SPLICE (1003A); J4-BLUE BODY CONTROLLER (1601); KEY SWITCH (1146); SPLICE (10382); STARTER INTERLOCK (1146A); STARTER INTERLOCK (1146B); STEP LIGHT RELAY (10309); STOP ARM RELAY (10310)
Wires (circuit gauge+color): A120AP 18LTGN; A120AS 18LTGN; A120AT 18LTGN; A120EE 18LTGN; A120EH 20LTGN; A133 16LTGN; A133-G 18WH; A133-GA 16WH; A133A 16LTGN; A133B 16LTGN; A133C 16LTGN; B119B 18GY; B120K 18LTGN; B120L 18LTGN; B12C 16LTGN; B133A 16LTGN
See also sheets: CH15_37, CH16_39
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.34. VANDAL LOCK FOR ELECTRIC ENTRANCE DOOR, P. 30 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 26MAR21 / CHAPTER 16 VANDAL LOCK FOR ELECTRIC ENTRANCE DOOR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PLATFORM/ ELEC PANEL 20 (1702) / C B D A / A120AP A120EE 18LTGN 18LTGN / VANDAL LOCK KEY SWITCH (1146) / VANDAL LOCK KEY SWITCH / A133B 16LTGN / A133C 16LTGN / A133-G 18WH A133A 16LTGN / A120AT 18LTGN A89HK 18PL A120AS 18LTGN A120AP 18LTGN / ELECTRIC DOOR CONTROL CLOSED / STOP ARM-CAV 1 ENT DOOR CAV 7 (1351) / ELECTRIC DOOR CONTROL OPEN / 18LTGN 18LTGN B120L B120K / 16LTGN B119B 18GY B12C / GROUND SPLICE (1003A) CH3_95B / *B133A 16LTGN / VANDAL LOCK STARTER INTERLOCK (1146A) A / *A133 16LTGN / MANUAL RELEASE VANDAL LOCK KEY SWITCH / A120EH 20LTGN / A89HJ 20PL / 7 ELECTRIC DOOR CONTROL OPEN / J4-BLUE BODY CONTROLLER (1601) / 1 ELECTRIC DOOR CONTROL CLOSED / A89HH 18PL / Figure 686 / VANDAL LOCK FOR ELECTRIC ENTRANCE DOOR

16.35. LEFT ALTERNATE ENTRANCE DOOR-ELECTRIC WITHOUT MASTER SWITCH, P. 31
Figure 687 LEFT ALTERNATE ENTRANCE DOOR-ELECTRIC WITHOUT MASTER SWITCH

Components: AED STEP LT (11517); AED VANDAL LOCK (10310); DOOR (10479); ELECTRIC (10203A); FLASHER SYSTEM RELAY (10311); FUSE F44 (10304); LEFT BODY (10401B/10401); OPTION (10380); REAR CAP (10405); REAR CAP/RIGHT BODY (10700); RELAY (10310); SEALED ENGINE (11500); SPLICE (10336); SPLICE (10399); SPLICE (10402); SPLICE (11507); SWITCH (10236)
Wires (circuit gauge+color): B120-GD 18WH; B120-GE 18WH; B120-GF 18WH; B120-GG 18WH; B120-GH 16WH; B120-GJ 16LTGN; B120AA 18LTGN; B120AB 16LTGN; B120AC 16LTGN; B120AD 18LTGN; B120AE 18LTGN; B120AF 16LTGN; B120AH 16LTGN; B123B 18OR; B123C 18LTGN; B123T 18GY; B131C 18DKBL; B131D 18DKBL; B62-GBL 18WH; B62BL 18LTBL; B89L 18OR; D120A 18LTGN; D120B 18LTGN; D120C 18LTGN; D120D 18LTGN; E120-GB 16LTGN; E120-GC 16LTGN; E120A 18LTGN; E120B 18LTGN; E120C 18LTGN; E120D 18LTGN; E120K 16LTGN; E120L 16LTGN; Y131-GD 16WH; Y131D 16DKBL
See also sheets: CH16_32, CH16_33, CH3_48, CH6_22, CH6_23, CH6_24, CH7_63
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.35. LEFT ALTERNATE ENTRANCE DOOR-ELECTRIC WITHOUT MASTER SWITCH, P. 31 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 26MAR21 / CHAPTER 16 LEFT ALTERNATE ENTRANCE DOOR-ELECTRIC N/MASTER SWITCH FLASHER SYSTEM RELAY (10311) CH6_24 AED VANDAL LOCK (10310) CH6_23 FUSE F44 (10304) CH3_94K / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / *E120-GB 16LTGN *E120-GC 16LTGN *E120K 16LTGN *E120L 16LTGN / REAR CAP/RIGHT BODY (10700) * FOR 7 TO 13 WDO LENGTH CH16_33 NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / 18LTGN D120B / 18LTGN 18LTGN E120D E120C / 18LTGN D120D 18LTGN D120C / B123B 18OR / LEFT AED ELECTRIC (10203A) 8 / 18LTGN D120A / 18DKBL B131D / 18LTGN E120B / GROUND SPLICE (10336) CH3_95K / 3 4 1 / B120-GH 16WH / B120AE 18LTGN / AED STEP LT (11517) / B89L 18OR / FUSE F44 (10304) CH3_94K / STEP LT / B120AA 18LTGN / SWITCH ILLUMINATION SPLICE (10399) CH7_63 PWL OVERRIDE SPLICE (10402) CH6_22 MASTER FLASHER SWITCH (10236) CH16_32 / ELEC PANEL/ SEALED ENGINE (11500) GROUND SPLICE (11507) CH3_48 / E120A 18LTGN / 16DKBL Y131-GD Y131D 16WH / B120AH 16LTGN / B62BL 18LTBL B62-GBL 18WH / B120AF 16LTGN / ALTERNATE ENTRANCE DOOR (10479) / B120-GJ 16LTGN / ELEC PANEL/ LEFT BODY (10401B/10401) / LEFT BODY/ REAR CAP (10405) / B120-GD 18WH / 85 G1 / G2 30 30 / B120AD 18LTGN ALTERNATE ENTRANCE DOOR RELAY (10310) J2 86 / 87A H1 / G4 30 30 B120-GF 18WH 87A H3 / 85 G3 / B120-GE 18WH B120AC 16LTGN ALTERNATE ENTRANCE DOOR RELAY J4 (10310) 86 / E2 30 30 / 85 E1 / ALTERNATE ENTRANCE DOOR RELAY F2 (10310) 86 / B120-GG 18WH / B120AB 16LTGN / CLEARANCE LIGHT OPTION (10380) CH7_66A / B131C 18DKBL / B123T 18GY B123C 18LTGN / Figure 687 / LEFT ALTERNATE ENTRANCE DOOR-ELECTRIC WITHOUT MASTER SWITCH

16.36. LEFT ENTRANCE DOOR - ELECTRIC WITH MASTER SWITCH, P. 32
Figure 688 LEFT ENTRANCE DOOR - ELECTRIC WITH MASTER SWITCH

Components: CONTROLLER (1602); LEFT AED ELECTRIC (10203A); PLATFORM (1702); REFERANCE SPLICE (10350A); RELAY COIL (10364); SPLICE (10330); SWITCH (10236)
Wires (circuit gauge+color): A89KK 18OR; B123A 18LTGN; B123B 18OR; B123F 18LTGN; B62-GAC 18WH; B62AC 18DKBL; B9H 18GY
See also sheets: CH16_31, CH3_29, CH8_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.36. LEFT ENTRANCE DOOR - ELECTRIC WITH MASTER SWITCH, P. 32 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 26MAR21 / CHAPTER 16 LEFT ENTERANCE DOOR-ELECTRIC W/MASTER SW / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SWITCH ILLUMINATION SPLICE (10330) CH8_31 / B62-GAC 18WH / B9H 18GY / B123F 18LTGN / B123A 18LTGN / J5-TAN BODY CONTROLLER (1602) MASTER F16 FLASHER SWITCH ACCESSORY SPLICE RELAY COIL (10364) CH3_29 ZERO VOLT REFERANCE SPLICE (10350A) CH3_95N / B62AC 18DKBL / ELEC PANEL/ PLATFORM (1702) 60 / MASTER FLASHER SWITCH (10236) / A89KK 18OR / B123B 18OR / LEFT AED ELECTRIC (10203A) CH16_31 / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 688 / LEFT ENTRANCE DOOR - ELECTRIC WITH MASTER SWITCH

16.37. ALTERNATE ENTRANCE DOOR AIR WITH DUMP VALVE, P. 33
Figure 689 ALTERNATE ENTRANCE DOOR AIR WITH DUMP VALVE

Components: DUMP VALVE (10041); ELEC PANEL (10401A/B/10401); FRONT CAP (10000); GROUND SPLICE (10009); LH BODY (10405); REAR CAP (10405); RIGHT BODY (10700); SPLICE (10701)
Wires (circuit gauge+color): B120 18LTGN; C120-GC 18WH; C120C 18LTGN; D120A 18LTGN; D120B 18LTGN; D120C 18LTGN; D120D 18LTGN; E120D 18LTGN; F120-G 18WH; F120A 18LTGN; F120B 18BK; F120B 18LTGN; F120C 18LTGN; F120D 18LTGN; F120E 18LTGN; F120F 18LTGN
See also sheets: CH16_31, CH3_31, CH3_52
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.37. ALTERNATE ENTRANCE DOOR AIR WITH DUMP VALVE, P. 33 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 26MAR21 / CHAPTER 16 ALTERNATE ENTRANCE DOOR AIR W/DUMP VALVE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / AIR DOOR SOLENOID **(10769C) #(10769D) ##(10769E) @(10769F) @@(10769F) *(10769G) OPEN / 2 1 3 / DUMP VALVE AUTO SWITCH **(10778C) #(10778D) ##(10778E) @(10778F) *(10778G) / F120C 18LTGN F120B 18BK F120B 18LTGN / RED CLOSED BLK BLK GROUND SPLICE (10701) CH3_52 / @F120E 18LTGN F120D 18LTGN / F120A 18LTGN / REAR CAP / RIGHT BODY (10700) B9 / D120D 18LTGN / D120C 18LTGN / D120B 18LTGN / D120A 18LTGN / LEFT BODY/ REAR CAP (10405) CH16_31 / C120C 18LTGN C120-GC 18WH / ALT ENTRANCE DUMP VALVE (10041) 1 / B120 18LTGN GROUND SPLICE (10009) CH3_31 / REAR CAP/ LH BODY (10405) B5 E120D 18LTGN / LEFT BODY/ ELEC PANEL (10401A/B/10401) B5 / ELEC PNL/ FRONT CAP (10000) C7 / F120-G 18WH / @F120F 18LTGN / D120D 18LTGN / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 689 / ALTERNATE ENTRANCE DOOR AIR WITH DUMP VALVE

16.38. 3-POSITION TOGGLE SWITCH, P. 34
Figure 690 3-POSITION TOGGLE SWITCH

Components: AED RELAY (10310); J5-TAN BODY CONTROLLER (1602); OPEN SIGNAL (11600C); PLATFORM (1702); PLATFORM (1703); RELAY COILS (10364); SIGNAL (11600D); SPLICE (10335B); SYSTEM RELAY (10311); ZVR (11600A); ZVR (11600B); ZVR SPLICE (10350A)
Wires (circuit gauge+color): A120SK 16LTGN; A123J 18GY; B120-G 18WH; B120-GA 18WH; B120A 18LTGN; B120B 18LTGN; B120C 18LTGN; B123T 18GY; B9A 18GY
See also sheets: CH3_29, CH6_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.38. 3-POSITION TOGGLE SWITCH, P. 34 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 26MAR21 / CHAPTER 16 3-POSITION TOGGLE SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / C...O CARLING K301-27 / RIGHT SIDE / LEFT SIDE / C...O CARLING K301-27 / ELEC PANEL/ PLATFORM (1703) / F15 F8 INPUT CONTROL POSITION MIDDLE POSITION OPEN SWITCH DOOR THREE / J5-TAN BODY CONTROLLER (1602) / 18LTGN 120C 18GY 9A / # W/500K BAUD RATE- REGULATORY / 120-GA 18WH / 18LTGN B120C / 9A 18GY / A120SK 16LTGN / 120-G 18WH / B120-GA 18WH / B9A 18GY / DOOR SW ZVR A (11600B) / ELEC PANEL/ PLATFORM (1702) 59 / DOOR SW A ZVR (11600A) / DOOR SW OPEN SIGNAL (11600C) / DOOR SW OVERRIDE A SIGNAL (11600D) / B120-G 18WH / GROUND SPLICE (10335B) CH3_95H / ZVR SPLICE (10350A) CH3_95N / AED RELAY (10310) H1 G2 86 30 30 / 87 J2 / 85 G1 / A123J 18GY / B123T 18GY / B120A 18LTGN / ACC SPLICE RELAY COILS (10364) CH3_29 / B120B 18LTGN / FLASHER SYSTEM RELAY (10311) CH6_24 / Figure 690 / 3-POSITION TOGGLE SWITCH

16.39. ELECTRIC DOOR WITH KEY OFF SWITCH, P. 35
Figure 691 ELECTRIC DOOR WITH KEY OFF SWITCH

Components: COILS (10369); DOOR CONTROL (10047); FR CAP (10000); FUSE F32 (10303); GROUND SPLICE (10335B); LOCK RELAY (10310); OVERHEAD DOOR SWITCH (10060); PLATFORM (1702/1702); RELAY (10309)
Wires (circuit gauge+color): B120-GK 18WH; B120-GL 18WH; B120-GS 18WH; B120-GT 16WH; B120-GU 16WH; B120-GV 16WH; B120AV 16LTGN; B120J 16LTGN; B120JC 16LTGN; B120K 18LTGN; B120L 18LTGN; B120S 18LTGN; B120T 18LTGN; B120U 18LTGN; B120V 16LTGN; B12Z 16LTBL; B9T-G 16GY; C120 16LTGN; C120-G 16WH; C120-GA 16WH; C120A 16LTGN; C120B 18LTGN; C120C 18LTGN
See also sheets: CH16_15
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.39. ELECTRIC DOOR WITH KEY OFF SWITCH, P. 35 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 16 ELECTRIC DOOR W/KEY OFF SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J4 86 / G4 30 / AED VANDAL LOCK RELAY (10310) / 85 G3 / B9T-G 16GY / 87A H3 / 85 D1 / B12Z B12Z 16LTBL 16LTBL B120S 18LTGN F2 86 DOOR CONTROL RELAY (10309) / 87A F1 E1 / B120AV 16LTGN / ELEC PANEL /FR CAP @C120C 18LTGN @C120B 18LTGN (10000) / B120-GV B120-GV 16WH 16WH B120T 18LTGN B120-GT 16WH B120U 18LTGN B120-GU 16WH / 87A C1 B1 / B120L 18LTGN A2 / C2 86 / 85 A1 / B120V 16LTGN B120J 16LTGN B120K 18LTGN G2 / STEP LIGHT RELAY (10309) / GROUND STUD (1GND) CH3_95E ACCESSORY SPLICE RELAY COILS (10369) CH3_30A / H2 86 / 85 B120-GL G1 18WH B120-GK 18WH / 87A H1 / B120-GS 18WH / ELECTRIC PANEL/ PLATFORM (1702/1702) CH16_15 / FUSE F32 (10303) CH3_94H / DOOR CONTROL RELAY (10309) / B120JC 16LTGN / 16LTGN 120A / DOOR OPEN NC CONTACTS A / 120-G 16WH / 16LTGN 120GA 16WH 120 / DOOR OPEN NC CONTACTS / DOOR MOTOR / FR CAP/ ENTRANCE DOOR CONTROL (10047) 2 %C120A 16LTGN %C120 16LTGN %C120-GA 16WH %C120-G 16WH / % W/ELECTRIC DOOR @ W/AIR DOOR W/OVERHEAD SWITCH / OVERHEAD DOOR SWITCH (10060) / B120-GK 18WH / GROUND SPLICE 10335B) CH3_95H / Figure 691 / ELECTRIC DOOR WITH KEY OFF SWITCH

16.40. ALTERNATE ENTRANCE DOOR AIR WITH DUMP VALVE, P. 36
Figure 692 ALTERNATE ENTRANCE DOOR AIR WITH DUMP VALVE

Components: DUMP VALVE (10041); ELEC PANEL (10401); FRONT CAP (10000); GROUND SPLICE (10009); LH BODY (10405); REAR CAP (10405); RIGHT BODY (10700); SPLICE (10701)
Wires (circuit gauge+color): B120 18LTGN; C120-GC 18WH; C120C 18LTGN; D120A 18LTGN; D120B 18LTGN; D120C 18LTGN; D120D 18LTGN; E120D 18LTGN; F120-G 18WH; F120A 18LTGN; F120B 18BK; F120B 18LTGN; F120C 18LTGN; F120D 18LTGN; F120E 18LTGN; F120F 18LTGN
See also sheets: CH16_22, CH3_31, CH3_40
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.40. ALTERNATE ENTRANCE DOOR AIR WITH DUMP VALVE, P. 36 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 11MAR21 / CHAPTER 16 ALTERNATE ENTRANCE DOOR AIR W/DUMP VALVE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / AIR DOOR SOLENOID **(10769C) #(10769D) ##(10769E) @(10769F) @@(10769F) *(10769G) OPEN / 2 1 3 / DUMP VALVE AUTO SWITCH **(10778C) #(10778D) ##(10778E) @(10778F) *(10778G) / F120C 18LTGN F120B 18BK F120B 18LTGN / RED CLOSED BLK BLK GROUND SPLICE (10701) CH3_40 / @F120E 18LTGN F120D 18LTGN / F120A 18LTGN / REAR CAP / RIGHT BODY (10700) B9 / D120D 18LTGN / D120C 18LTGN / D120B 18LTGN / D120A 18LTGN / LEFT BODY/ REAR CAP (10405) CH16_22 / C120C 18LTGN C120-GC 18WH / ALT ENTRANCE DUMP VALVE (10041) 1 / B120 18LTGN GROUND SPLICE (10009) CH3_31 / REAR CAP/ LH BODY (10405) B5 E120D 18LTGN / LEFT BODY/ ELEC PANEL (10401) B5 / ELEC PNL/ FRONT CAP (10000) C7 / F120-G 18WH / @F120F 18LTGN / D120D 18LTGN / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 692 / ALTERNATE ENTRANCE DOOR AIR WITH DUMP VALVE

16.41. 3-POSITION TOGGLE SWITCH, P. 37
Figure 693 3-POSITION TOGGLE SWITCH

Components: AED RELAY (10310); J5-TAN BODY CONTROLLER (1602); OPEN SIGNAL (11600C); PLATFORM (1702); PLATFORM (1703); RELAY (10311-H3); RELAY COILS (10364); SIGNAL (11600D); SPLICE (10335B); ZVR (11600A); ZVR (11600B); ZVR SPLICE (10350A)
Wires (circuit gauge+color): A120SK 16LTGN; A123J 18GY; B120-G 18WH; B120-GA 18WH; B120A 18LTGN; B120B 18LTGN; B120C 18LTGN; B123T 18GY; B9A 18GY
See also sheets: CH3_07, CH3_28, CH3_48, CH6_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.41. 3-POSITION TOGGLE SWITCH, P. 37 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 11MAR21 / CHAPTER 16 3-POSITION TOGGLE SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / C...O CARLING K301-27 / RIGHT SIDE / LEFT SIDE / C...O CARLING K301-27 / ELEC PANEL/ PLATFORM (1703) / F15 F8 INPUT CONTROL POSITION MIDDLE POSITION OPEN SWITCH DOOR THREE / J5-TAN BODY CONTROLLER (1602) / 18LTGN 120C 18GY 9A / # W/500K BAUD RATE- REGULATORY / 120-GA 18WH / 18LTGN B120C / 9A 18GY / A120SK 16LTGN / 120-G 18WH / B120-GA 18WH / B9A 18GY / DOOR SW ZVR A (11600B) / ELEC PANEL/ PLATFORM (1702) 59 / DOOR SW A ZVR (11600A) / DOOR SW OPEN SIGNAL (11600C) / DOOR SW OVERRIDE A SIGNAL (11600D) / B120-G 18WH / GROUND SPLICE (10335B) CH3_28 / ZVR SPLICE (10350A) CH3_48 / AED RELAY (10310) H1 G2 86 30 30 / 87 J2 / 85 G1 / A123J 18GY / B123T 18GY / B120A 18LTGN / ACC SPLICE RELAY COILS (10364) CH3_07 / B120B 18LTGN / FLASHER SYSTEM RELAY (10311-H3) CH6_24 / Figure 693 / 3-POSITION TOGGLE SWITCH

16.42. REAR DOOR ACTIVATED OPTION, P. 38
Figure 694 REAR DOOR ACTIVATED OPTION

Components: BUZZER SPLICE (10204); DIODE D67 (10306); FUSE (10307-A4); FUSE F72 (10306); LEFT BODY (10401A/B); RELAY (10310); SPLICE (10335B); SPLICE (10386)
Wires (circuit gauge+color): B117-GL 18WH; B117F 18GY; B117H 18LTGN; B117J 18LTGN; B117JZ 16LTGN; B117K 18LTGN; B117L 18GY; B117M 18GY
See also sheets: CH14_01, CH14_24, CH3_16, CH3_28
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.42. REAR DOOR ACTIVATED OPTION, P. 38 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090667 NO. 95885P 11MAR21 / CHAPTER 16 REAR DOOR ACTIVATED OPTION / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR DOOR SPLICE (10386) C / B4 30 / A3 86 / B117L 18GY / 85 A4 / 87A B3 / BUZZER RELAY (10310) / B117-GL 18WH / DIODE D67 (10306) A3 B3 / B117J 18LTGN / B117M 18GY / ELEC PANEL/ LEFT BODY (10401A/B) CH14_24 / B117F 18GY / B117K 18LTGN / FUSE (10307-A4) CH3_94P / FUSE F72 (10306) CH3_16 / GROUND SPLICE (10335B) CH3_28 / B117H 18LTGN / EMER EXIT BUZZER SPLICE (10204) CH14_01 / B117JZ 16LTGN / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 694 / REAR DOOR ACTIVATED OPTION

16.43. ELECTRIC DOOR WITH KEY OFF SWITCH, P. 39
Figure 695 ELECTRIC DOOR WITH KEY OFF SWITCH

Components: COILS (10369); DOOR CONTROL (10047); ELAY (10309); FR CAP (10000); FUSE F32 (10303); GROUND SPLICE (10335B); LOCK RELAY (10310); OVERHEAD DOOR SWITCH (10060); PLATFORM (1702/1702); RELAY (10309)
Wires (circuit gauge+color): B120-GK 18WH; B120-GL 18WH; B120-GS 18WH; B120-GT 16WH; B120-GU 16WH; B120-GV 16WH; B120AV 16LTGN; B120J 16LTGN; B120JC 16LTGN; B120K 18LTGN; B120L 18LTGN; B120S 18LTGN; B120T 18LTGN; B120U 18LTGN; B120V 16LTGN; B12Z 16LTBL; B9T-G 16GY; C120 16LTGN; C120-G 16WH; C120-GA 16WH; C120A 16LTGN; C120B 18LTGN; C120C 18LTGN
See also sheets: CH16_15, CH16_30, CH3_08, CH3_25, CH3_28
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 16.43. ELECTRIC DOOR WITH KEY OFF SWITCH, P. 39 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 16 ELECTRIC DOOR W/KEY OFF SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / J4 86 / G4 30 / AED VANDAL LOCK RELAY (10310) / 85 G3 / B9T-G 16GY / 87A H3 / 85 D1 / B12Z B12Z 16LTBL 16LTBL B120S 18LTGN F2 86 DOOR CONTROL RELAY (10309) / 87A F1 E1 / B120AV 16LTGN / ELEC PANEL /FR CAP @C120C 18LTGN @C120B 18LTGN (10000) / B120-GV B120-GV 16WH 16WH B120T 18LTGN B120-GT 16WH B120U 18LTGN B120-GU 16WH / 87A C1 B1 / B120L 18LTGN A2 / C2 86 / 85 A1 / B120V 16LTGN B120J 16LTGN B120K 18LTGN G2 / STEP LIGHT ELAY (10309) / GROUND STUD (1GND) CH3_25 ACCESSORY SPLICE RELAY COILS (10369) CH3_08 / H2 86 / 87A H1 / B120-GS 18WH / FUSE F32 (10303) CH3_13A / DOOR CONTROL RELAY (10309) / B120JC 16LTGN / 16LTGN 120A / DOOR OPEN NC CONTACTS A / 120-G 16WH / 16LTGN 120GA 16WH 120 / DOOR OPEN NC CONTACTS / DOOR MOTOR / FR CAP/ ENTRANCE DOOR CONTROL (10047) 2 %C120A 16LTGN %C120 16LTGN %C120-GA 16WH %C120-G 16WH / ELECTRIC PANEL/ PLATFORM (1702/1702) CH16_30 ELECTRIC PANEL/ PLATFORM (1702/1702) CH16_15 ELECTRIC PANEL/ PLATFORM (1702/1702) CH16_30 / % W/ELECTRIC DOOR @ W/AIR DOOR W/OVERHEAD SWITCH / OVERHEAD DOOR SWITCH (10060) / Figure 695 / ELECTRIC DOOR WITH KEY OFF SWITCH

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 736 | printed page 696 | section
RADIO / PA / CELLULAR - GPS (CHAPTER 17)
Figure 696 RADIO WIRING WITH DASH MOUNTED 2 CHANNEL RADIO

Components: ELEC PANEL (10000); ELEC PANEL (10401A/B); ELEC PANEL (11500); FUSE B12-F (10301); FUSE B12-X (10301); FUSE F35 (10303); FUSE F6 (10301); GROUND SPLICE (1003A); GROUNDSPLICE (1003A); L BODY (10405); MUTE (1302); PA 2 CHANNEL (1301); PLATFORM (1702); REAR CAP (10700)
Wires (circuit gauge+color): A67A 18GY; A86-G 18WH; A86A 18LTGN; A86B 16LTGN; A86C 18LTGN; A86D 18LTGN; B86A 16LTGN; B86B 16LTGN; B86C 16LTGN; B86D 16LTGN; B86E 16LTGN; B86F 16LTGN; B86H 16LTGN; B86J 16LTGN; B86S 16LTGN; B86T 16LTGN; B86V 16LTGN; B86W 16LTGN
See also sheets: CH13_55, CH17_03, CH17_04, CH17_06, CH3_22
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / RADIO / PA / CELLULAR - GPS (CHAPTER 17) / 17.1. RADIO WIRING WITH DASH MOUNTED 2 CHANNEL RADIO, P. 1 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 RADIO WIRING W/DASH MOUNTED 2 CHANNEL RADIO / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ^9 &9P / ^A86-G 18WH / ^8 ^7 &8P &7P / E86A(-) 16LTGN / B12-F CH3_1E,12 (10301) FUSE CH3_94H D86B(+) 16LTGN F35 (10303) FUSE REAR CAP/ L BODY (10405) C8 / ELEC PANEL/ PLATFORM (1702) 18LTGN 18LTGN A86D A86C / # N/FR SPKR * W/FR SPKR @ W/BENDIX FUSION & N/0508108 - NOT MTA FUSE BLOCK ^ W/0508108 - MTA FUSE BLOCK / ^6 &6P / A86L(+) 18LTGN / ^5 ^2 ^1 &5P &2P &1P / A86L(-) 18LTGN 16LTGN 18LTGN A86B A86A / ^4 &4P / A86R(+) 18LTGN / ^3 &3P / E86B(+) 16LTGN L BODY/ ELEC PANEL (10401A/B) C12 / A86R(-) 18LTGN / 16LTGN #B86F / #B86E 16LTGN / D86A(-) 16LTGN / 16LTGN 16LTGN &B86A ^B86A 16LTGN ^B86B 16LTGN &B86B / ENG/ PANEL SEALED (11500) CH17_03 ELEC / 16LTGN *B86T 16LTGN #B86C / 16LTGN 16LTGN 16LTGN *B86S #B86D 16LTGN B86H B86J / 11,13,15,21,22,23 CH17_06,07,09, CAP BODY/ (10700) REAR R / RADIO/ PA 2 CHANNEL (1301) / CH13_55 SPLICE GROUNDSPLICE PANEL/ PLATFORM (1003A) CH3_95B (1003A) GROUND CH3_22 (1702) ELEC / PANEL CAB/ (10000) CH17_04 ELEC FR / CH17_06,07,08, 10,12,14,16, 17,18,19,20, PANEL (10401A/B) 24,25,26 BODY/ ELEC L / B12-X CH3_1L,23 (10301) FUSE / @A67A 18GY / RADIO MUTE (1302) / 16LTGN 16LTGN *B86V *B86W / F6 (10301) CH3_94D FUSE / CH17_04,05 PANEL CAB/ (10000) ELEC FR / &A86-G 18WH / Figure 696 / RADIO WIRING WITH DASH MOUNTED 2 CHANNEL RADIO

17.2. RADIO WIRING WITH OVERHEAD MOUNTED 2 CHANNEL RADIO, P. 2
Figure 697 RADIO WIRING WITH OVERHEAD MOUNTED 2 CHANNEL RADIO

Components: ELEC PANEL (10000); ELEC PANEL (10401); ELEC PANEL (11500); FUSE B12-F (10301); FUSE B12-X (10301); FUSE F35 (10303); FUSE F6 (10301); L BODY (10401A/B); RADIO (10259); REAR CAP (10405); REAR CAP (10700); SPLICE (10337)
Wires (circuit gauge+color): B86-G 16WH; B86A 16LTGN; B86B 16LTGN; B86C 16LTGN; B86D 16LTGN; B86E 16LTGN; B86F 16LTGN; B86H 16LTGN; B86J 16LTGN; B86T 16LTGN; B86V 16LTGN; B86W 16LTGN
See also sheets: CH17_03, CH17_04, CH17_06, CH3_12, CH3_23, CH3_41
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.2. RADIO WIRING WITH OVERHEAD MOUNTED 2 CHANNEL RADIO, P. 2 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 RADIO WIRING W/OVERHEAD MOUNTED 2 CHANNEL RADIO / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ^4 &4P / ^5 &5P / ^3 &3P / ^9 ^8 &9P &8P / ^6 &6P / E86A(-) 16LTGN / 16LTGN #B86F / 16LTGN 16LTGN 16LTGN 16LTGN &B86A 16LTGN ^B86B &B86B 16LTGN #B86C *B86T 16LTGN #B86D *86S / RADIO (10259) / L BODY / ELEC PANEL (10401) CH17_06,07,08, 10,12,14,16,17 18,19,20 / R BODY / REAR CAP (10700) CH17_06,07,09, 11,13,15,21,22 23,24,25,26 / ELEC PANEL/ L BODY C12 (10401A/B) / ^2 ^1 &2P &1P / 16LTGN 16LTGN B86J B86H / ^7 &7P / FR CAP/ ELEC PANEL (10000) CH17_04 / L BODY/ REAR CAP (10405) / 16LTGN #B86E / E86B(+) 16LTGN / D86B(+) 16LTGN / D86A(-) 16LTGN / SEALED ENG/ ELEC PANEL (11500) CH17_03 / FUSE B12-X FUSE B12-F (10301) (10301) CH3_23 CH3_12 / ^B86-G 16LTGN 16WH ^B86A / # N/FR SPKR * W/FR SPKR & N/0508108 - NOT MTA FUSE BLOCK ^ W/0508108 - MTA FUSE BLOCK / GROUND GROUND SPLICE SPLICE (10337) (10337) CH3_95L CH3_41 FUSE F6 FUSE F35 (10301) (10303) CH3_94D CH3_94H / 16LTGN 16LTGN *B86V *B86W / FR CAP/ ELEC PANEL (10000) CH17_04 / &B86-G 16WH / Figure 697 / RADIO WIRING WITH OVERHEAD MOUNTED 2 CHANNEL RADIO

17.3. RADIO WIRING WITH PA HORN SYSTEM, P. 3
Figure 698 RADIO WIRING WITH PA HORN SYSTEM

Components: ELEC PANEL (10000); ELEC PANEL (11500); ELEC PANEL/PLATFORM (1702); HOOD (11506); PA HORN (10027); RADIO (10259); STEPWELL (11527)
Wires (circuit gauge+color): B86H 16LTGN; B86J 16LTGN; B86K 16LTGN; B86L 16LTGN; B86M 16LTGN; B86N 16LTGN; C86 16LTGN; C86A 16LTGN; Y68 16LTGN; Y68A 16LTGN; Y86 16LTGN; Y86A 16LTGN
See also sheets: CH17_01, CH17_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.3. RADIO WIRING WITH PA HORN SYSTEM, P. 3 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 RADIO WIRING W/PA HORN SYSTEM / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PA HORN UNDER HOOD (11506) / 16LTGN *Y68 / SEALED ENG/ ELEC PANEL B12 (11500) / PA HORN (10027) / 16LTGN #Y86A 16LTGN #Y86 / PA HORN LOCATED IN FR CAP / * W/PA HORN UNDER STEPWELL # W/PA HORN UNDER HOOD / ELEC PANEL/PLATFORM (1702) CH17_01 RADIO (10259) CH17_02 / PA HORN LOCATED UNDER STEPWELL / PA HORN LOCATED UNDER HOOD / *Y68A 16LTGN / 16LTGN B86M / 16LTGN B86N / 16LTGN 16LTGN B86J B86H / 16LTGN 16LTGN C86A C86 / FR CAP/ ELEC PANEL (10000) / PA HORN UNDER STEPWELL (11527) / B86L 16LTGN / B86K 16LTGN / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 698 / RADIO WIRING WITH PA HORN SYSTEM

17.4. RADIO WIRING WITH DASH / OVERHEAD MOUNTED WITH FRONT SPEAKER, P.
Figure 699 RADIO WIRING WITH DASH / OVERHEAD MOUNTED WITH FRONT SPEAKER

Components: ELEC PANEL (10001); ELEC PANEL/L BODY (10401); ELEC PANEL/PLATFORM (1702); RADIO (10259)
Wires (circuit gauge+color): B86AA 16LTGN; B86C 16LTGN; B86D 16LTGN; B86P 16LTGN; B86R 16LTGN; B86S 16LTGN; B86T 16LTGN; B86V 16LTGN; B86W 16LTGN; B86X 16LTGN; B86Y 16LTGN; B86Z 16LTGN
See also sheets: CH17_01, CH17_02, CH17_05, CH17_06
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.4. RADIO WIRING WITH DASH / OVERHEAD MOUNTED WITH FRONT SPEAKER, P. 4 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 RADIO WIRING W/DASH/OVERHEAD MOUNTED W/FRONT SPEAKER / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / + RADIO CONN (+) (10053) / @C86RF- @C86RF+ 16LTGN 16LTGN / FR CAP/ ELEC PANEL (10001) / @C86LF- @C86LF+ 16LTGN 16LTGN / @ W/DUAL RADIO SPEAKERS IN BULKHEAD / ELEC PANEL/PLATFORM (1702) CH17_01 RADIO (10259) CH17_02 NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / + RADIO SPKR (+) (10055) / RADIO CONN (-) (10054) A / 16LTGN B86X / 16LTGN B86Y / 16LTGN 16LTGN B86V B86W / B86C 16LTGN B86D 16LTGN B86AA 16LTGN B86Z 16LTGN / 16LTGN B86R / 16LTGN B86P / 16LTGN B86S / 16LTGN B86T / RADIO SPKR (-) (10056) / ELEC PANEL/L BODY (10401) CH17_06,07,08,10,12,14, 16,17,18,19,20 / ELEC PANEL/L BODY (10401) CH17_05 / Figure 699 / RADIO WIRING WITH DASH / OVERHEAD MOUNTED WITH FRONT SPEAKER

17.5. RADIO WIRING WITH DASH / OVERHEAD MOUNTED WITH FRONT SPEAKER
Figure 700 RADIO WIRING WITH DASH / OVERHEAD MOUNTED WITH FRONT SPEAKER (CONT.)

Components: L BODY/ELEC PANEL (10401A/B); L BODY/REAR CAP (10405); PLATFORM (1702); REAR CAP/R BODY (10700)
Wires (circuit gauge+color): B86AA 16LTGN; B86Z 16LTGN; E86A 16LTGN; E86B 16LTGN
See also sheets: CH17_04, CH17_06
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.5. RADIO WIRING WITH DASH / OVERHEAD MOUNTED WITH FRONT SPEAKER (CONT.), P. 5 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 RADIO WIRING W/DASH/OVERHEAD MOUNTED W/FRONT SPEAKER (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / %E86A(-) 16LTGN @E86A 16LTGN / L BODY/REAR CAP (10405) / L BODY/ELEC PANEL C12 (10401A/B) / 16LTGN B86Z / B86AA 16LTGN / %E86B(+) 16LTGN 16LTGN @E86B / D86A(-) 16LTGN / D86B(+) 16LTGN / 11,13,21,22,23,24,25,26 BODY CH17_06,07,09, CAP/R (10700) REAR / ELEC PANEL/ PLATFORM (1702) CH17_04 / % W/5,6,7,8,9,10,11 WINDOW @ W/12,13 WINDOW NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 700 / RADIO WIRING WITH DASH / OVERHEAD MOUNTED WITH FRONT SPEAKER (CONT.)

17.6. RIGHT / LEFT SPEAKER WIRING FOR QUANTITY 2, P. 6
Figure 701 RIGHT / LEFT SPEAKER WIRING FOR QUANTITY 2

Components: ELEC PANEL (10401A/B); ELEC PANEL/PLATFORM (1702); L BODY (10405); RADIO (10259); REAR CAP (10700)
Wires (circuit gauge+color): B86C 16LTGN; B86D 16LTGN; E86A 16LTGN; E86B 16LTGN; E86C 16LTGN; E86D 16LTGN; F86 16LTGN; F86A 16LTGN
See also sheets: CH17_01, CH17_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.6. RIGHT / LEFT SPEAKER WIRING FOR QUANTITY 2, P. 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 RIGHT/LEFT SPEAKER WIRING FOR QUANTITY 2 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / R BODY/ REAR CAP A7 (10700) / SPKR(-) (*B-A, #B-A) / *F86B(+) *F86A(-) 16LTGN 16LTGN / SPKR(-) @(10494B-A) %(10755B-A) / L BODY/ ELEC PANEL D2 (10401A/B) / %E86B 16LTGN 16LTGN 16LTGN 16LTGN @E86D @E86C %E86A / R SIDE SPKR WIRING / SPKR(+) (*A-A, #A-A) / SPKR(+) @(10494A-A) %(10755A-A) / CAP/ BODY (10405) CH17_01,02,05 REAR L / 16LTGN 16LTGN B86C B86D / D86A(-) 16LTGN / D86B(+) 16LTGN / PANEL/PLATFORM (1702) CH17_01,04 (10259) CH17_02 RADIO ELEC / 16LTGN #F86 / #F86A 16LTGN / L SIDE SPKR WIRING / @ W/FOR 5-13 WINDOWS % W/SPKR WRG 2-FIRST WINDOWS SECTION-W/12 WINDOWS / Figure 701 / RIGHT / LEFT SPEAKER WIRING FOR QUANTITY 2

17.7. RIGHT / LEFT SPEAKER WIRING FOR QUANTITY 4, P. 7
Figure 702 RIGHT / LEFT SPEAKER WIRING FOR QUANTITY 4

Components: ELEC PANEL (10401); ELEC PANEL/PLATFORM (1702); L BODY (10405); RADIO (10259); REAR CAP (10700)
Wires (circuit gauge+color): B86C 16LTGN; B86D 16LTGN; E86E 16LTGN; E86F 16LTGN; E86G 16LTGN; F86B 16LTGN; F86C 16LTGN; F86D 16LTGN
See also sheets: CH17_01, CH17_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.7. RIGHT / LEFT SPEAKER WIRING FOR QUANTITY 4, P. 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 RIGHT/LEFT SPEAKER WIRING FOR QUANTITY 4 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / E86F 16LTGN / E86G 16LTGN / SPKR(+) *(A-A) / SPKR(-) *(B-A) / L BODY/ ELEC PANEL (10401) D2 / SPKR(+) #(A-A) / SPKR(-) #(B-A) / E86E 16LTGN / B86D 16LTGN / REAR CAP/ L BODY (10405) CH17_01,02.05 / @ 10775 - FOR 11 WINDOWS BUS 10747 - FOR 8-10 WINDOW BUS 10745 - FOR 5, 6 & 7 WINDOW BUS / L SIDE SPKR WRG / + - / B86C 16LTGN / D86B(+) 16LTGN D86A(-) 16LTGN / SPKR(+) (@A-A) / R BODY/ REAR CAP (10700) / SPKR(-) (B-A) / R SIDE SPKR WRG / SPKR(+) %(A-A) / %F86A(-) 16LTGN / SPKR(-) @(B-A) / #F86B 16LTGN @F86B(+) 16LTGN / %F86D 16LTGN / ELEC PANEL/PLATFORM (1702) CH17_01,04 RADIO (10259) CH17_02 / #F86C 16LTGN / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 702 / RIGHT / LEFT SPEAKER WIRING FOR QUANTITY 4

17.8. LEFT SPEAKER WIRING FOR QUANTITY 6, P. 8
Figure 703 LEFT SPEAKER WIRING FOR QUANTITY 6

Components: L BODY (10401); PLATFORM (1702); RADIO (10259)
Wires (circuit gauge+color): B86C 16LTGN; B86D 16LTGN; E86H 16LTGN; E86J 16LTGN; E86K 16LTGN; E86L 16LTGN; E86M 16LTGN; E86N 16LTGN; E86P 16LTGN
See also sheets: CH17_01, CH17_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.8. LEFT SPEAKER WIRING FOR QUANTITY 6, P. 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 LEFT SPEAKER WIRING FOR QUANTITY 6 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / E86M 16LTGN / E86N 16LTGN / SPKR(-) (*B-A) / ELEC PANEL/ L BODY (10401) D2 / E86J 16LTGN / SPKR(-) (#B-A) / SPKR(+) (#A-A) / E86K 16LTGN / E86H 16LTGN / E86P 16LTGN / B86D 16LTGN / B86C 16LTGN / ELEC PANEL/ PLATFORM (1702) CH17_01,04 RADIO (10259) CH17_02 / SPKR(+) (*A-A) / E86L 16LTGN / SPKR(-) (10494B-A) / SPKR(+) (10494A-A) / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 703 / LEFT SPEAKER WIRING FOR QUANTITY 6

17.9. RIGHT SPEAKER WIRING FOR QUANTITY 6, P. 9
Figure 704 RIGHT SPEAKER WIRING FOR QUANTITY 6

Components: ELEC BODY (10405); R BODY (10700)
Wires (circuit gauge+color): F86E 16LTGN; F86F 16LTGN; F86H 16LTGN; F86J 16LTGN; F86K 16LTGN; F86L 16LTGN; F86M 16LTGN
See also sheets: CH17_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.9. RIGHT SPEAKER WIRING FOR QUANTITY 6, P. 9 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 RIGHT SPEAKER WIRING FOR QUANTITY 6 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SPKR(+) @(A-A) / SPKR(-) @(B-A) / REAR CAP/ R BODY (10700) A7 / SPKR(+) #(A-A) / SPKR(-) #(B-A) / F86K 16LTGN / SPKR(-) *(B-A) / SPKR(+) *(A-A) / F86A(-) 16LTGN %F86J 16LTGN / F86L 16LTGN / F86B(+) 16LTGN %F86E 16LTGN / F86M 16LTGN / F86H 16LTGN / F86F 16LTGN / D86B(+) 16LTGN / REAR CAP/ ELEC BODY (10405) CH17_01,02,05 / D86A(-) 16LTGN / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 704 / RIGHT SPEAKER WIRING FOR QUANTITY 6

17.10. LEFT SPEAKER WIRING FOR QUANTITY 8, P. 10
Figure 705 LEFT SPEAKER WIRING FOR QUANTITY 8

Components: L BODY (10401); PLATFORM (1702); RADIO (10259)
Wires (circuit gauge+color): B86C 16LTGN; B86D 16LTGN; E86R 16LTGN; E86S 16LTGN; E86T 16LTGN; E86U 16LTGN; E86V 16LTGN; E86W 16LTGN; E86X 16LTGN; E86Y 16LTGN
See also sheets: CH17_01, CH17_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.10. LEFT SPEAKER WIRING FOR QUANTITY 8, P. 10 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 LEFT SPEAKER WIRING FOR QUANTITY 8 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / E86V 16LTGN / E86W 16LTGN / SPKR(+) #(A-A) / SPKR(-) #(B-A) / ELEC PANEL/ L BODY (10401) D2 / SPKR(+) (10494A-A) / SPKR(-) (10494B-A) / E86S 16LTGN / SPKR(-) %(B-A) / SPKR(+) %(A-A) / E86T 16LTGN / E86Y 16LTGN E86R 16LTGN / E86U 16LTGN / SPKR(-) *(B-A) / E86X 16LTGN / B86C 16LTGN B86D 16LTGN / ELEC PANEL/ PLATFORM (1702) CH17_01,04 RADIO (10259) CH17_02 / SPKR(+) *(A-A) / Figure 705 / LEFT SPEAKER WIRING FOR QUANTITY 8

17.11. RIGHT SPEAKER WIRING FOR QUANTITY 8, P. 11
Figure 706 RIGHT SPEAKER WIRING FOR QUANTITY 8

Components: L BODY (10405); R BODY (10700)
Wires (circuit gauge+color): F86N 16LTGN; F86P 16LTGN; F86R 16LTGN; F86S 16LTGN; F86T 16LTGN; F86U 16LTGN; F86V 16LTGN; F86W 16LTGN
See also sheets: CH7_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.11. RIGHT SPEAKER WIRING FOR QUANTITY 8, P. 11 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 RIGHT SPEAKER WIRING FOR QUANTITY 8 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / F86T 16LTGN / &F86N 16LTGN F86B(+) 16LTGN F86A(-) 16LTGN &F86S 16LTGN / F86W 16LTGN / REAR CAP/ R BODY (10700) A7 / F86P 16LTGN / F86U 16LTGN / F86V 16LTGN / F86R 16LTGN / D86B(+) 16LTGN D86A(-) 16LTGN / SPKR(+) %(A-A) / SPKR(+) #(A-A) / SPKR(+) @(A-A) / SPKR(-) @(B-A) / SPKR(-) %(B-A) / REAR CAP/ L BODY (10405) CH7_01,02,05 / SPKR(+) *(A-A) / SPKR(-) *(B-A) / SPKR(-) #(B-A) / Figure 706 / RIGHT SPEAKER WIRING FOR QUANTITY 8

17.12. LEFT SPEAKER WIRING FOR QUANTITY 10, P. 12
Figure 707 LEFT SPEAKER WIRING FOR QUANTITY 10

Components: L BODY (10401); PLATFORM (1702); RADIO (10259)
Wires (circuit gauge+color): B86C 16LTGN; B86D 16LTGN; E86AA 16LTGN; E86AB 16LTGN; E86AC 16LTGN; E86AD 16LTGN; E86AE 16LTGN; E86AF 16LTGN; E86AG 16LTGN; E86AH 16LTGN; E86AJ 16LTGN
See also sheets: CH17_01, CH17_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.12. LEFT SPEAKER WIRING FOR QUANTITY 10, P. 12 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 LEFT SPEAKER WIRING FOR QUANTITY 10 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / E86AE 16LTGN / SPKR(+) (#A-A) / SPKR(-) (#B-A) / ELEC PANEL/ L BODY (10401) D2 E86AA 16LTGN / SPKR(+) %(10496A-A) / SPKR(-) %(10496B-A) / SPKR(-) @(B-A) / SPKR(+) @(A-A) / E86AJ 16LTGN / E86AH 16LTGN / SPKR(-) %(10498B-A) / SPKR(+) %(10498A-A) / E86AD 16LTGN / SPKR(-) %(10494B-A) / E86AB 16LTGN / E86AG 16LTGN / E86AC 16LTGN / E86AF 16LTGN / B86C 16LTGN B86D 16LTGN / SPKR(+) %(10494A-A) / - + / ELEC PANEL/ PLATFORM (1702) CH17_01,04 RADIO (10259) CH17_02 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 707 / LEFT SPEAKER WIRING FOR QUANTITY 10

17.13. RIGHT SPEAKER WIRING FOR QUANTITY 10, P. 13
Figure 708 RIGHT SPEAKER WIRING FOR QUANTITY 10

Components: L BODY (10405); R BODY (10700)
Wires (circuit gauge+color): F86AA 16LTGN; F86AB 16LTGN; F86AC 16LTGN; F86AD 16LTGN; F86AE 16LTGN; F86AF 16LTGN; F86AG 16LTGN; F86AH 16LTGN; F86AJ 16LTGN
See also sheets: CH17_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.13. RIGHT SPEAKER WIRING FOR QUANTITY 10, P. 13 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 RIGHT SPEAKER WIRING FOR QUANTITY 10 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / F86AH 16LTGN / SPKR(+) */#(10747A-A) + / SPKR(-) */#(10747B-A) F86AD 16LTGN / REAR CAP/ R BODY (10700) A7 / SPKR(+) &(A-A) / SPKR(-) &(B-A) / F86AE 16LTGN / SPKR(-) %(B-A) / SPKR(+) %(A-A) / **F86AA 16LTGN F86B(+) 16LTGN F86A(-) 16LTGN **F86AJ 16LTGN / F86AG 16LTGN / SPKR(-) @(B-A) / SPKR(+) @(A-A) / SPKR(-) *(B-A) / F86AB 16LTGN / F86AF 16LTGN / F86AC 16LTGN / D86B(+) 16LTGN D86A(-) 16LTGN / REAR CAP/ L BODY (10405) CH17_01,02,5A / SPKR(+) *(A-A) / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 708 / RIGHT SPEAKER WIRING FOR QUANTITY 10

17.14. LEFT SPEAKER WIRING FOR QUANTITY 12, P. 14
Figure 709 LEFT SPEAKER WIRING FOR QUANTITY 12

Components: L BODY (10401A/B); RADIO (10259)
Wires (circuit gauge+color): B86C 16LTGN; B86D 16LTGN; E86BA 16LTGN; E86BB 16LTGN; E86BC 16LTGN; E86BD 16LTGN; E86BE 16LTGN; E86BF 16LTGN; E86BH 16LTGN; E86BJ 16LTGN; E86BK 16LTGN; F86BG 16LTGN
See also sheets: CH17_01, CH17_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.14. LEFT SPEAKER WIRING FOR QUANTITY 12, P. 14 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 LEFT SPEAKER WIRING FOR QUANTITY 12 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SPKR(+) ^(10494A-A) E86BB 16LTGN / SPKR(+) *(A-A) / SPKR(-) *(B-A) / ELEC PANEL/ L BODY (10401A/B) D2 / SPKR(+) (#A-A) / SPKR(-) (#B-A) / E86BH 16LTGN / SPKR(-) &(B-A) / SPKR(+) &(A-A) / E86BA 16LTGN E86BK 16LTGN / F86BG 16LTGN / SPKR(-) ^(10494B-A) E86BC 16LTGN / E86BD 16LTGN / E86BF 16LTGN / B86C 16LTGN B86D 16LTGN / SPKR(-) @(B-A) / SPKR(+) @(A-A) / E86BJ 16LTGN / SPKR(-) %(B-A) / SPKR(+) %(A-A) / E86BE 16LTGN NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / ELEC PANEL/ PLATFORM (1702) CH17_01,04 RADIO (10259) CH17_02 / Figure 709 / LEFT SPEAKER WIRING FOR QUANTITY 12

17.15. RIGHT SPEAKER WIRING FOR QUANTITY 12, P. 15
Figure 710 RIGHT SPEAKER WIRING FOR QUANTITY 12

Components: L BODY (10405); R BODY (10700)
Wires (circuit gauge+color): F86BA 16LTGN; F86BB 16LTGN; F86BC 16LTGN; F86BD 16LTGN; F86BE 16LTGN; F86BF 16LTGN; F86BG 16LTGN; F86BH 16LTGN; F86BJ 16LTGN; F86BK 16LTGN
See also sheets: CH17_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.15. RIGHT SPEAKER WIRING FOR QUANTITY 12, P. 15 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 RIGHT SPEAKER WIRING FOR QUANTITY 12 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SPKR(+) %(A-A) / SPKR(-) %(B-A) / REAR CAP/ R BODY (10700) A7 / + - / SPKR(-) #(B-A) / F86BJ 16LTGN / SPKR(-) @(B-A) / SPKR(+) @(A-A) / D86B(+) 16LTGN D86A(-) 16LTGN / SPKR(-) &(B-A) / SPKR(+) &(A-A) / SPKR(+) *(A-A) / SPKR(-) *(B-A) / F86BE 16LTGN / F86BF 16LTGN / F86BD 16LTGN / F86BB 16LTGN / F86BC 16LTGN / SPKR(-) **(B-A) / SPKR(+) **(A-A) / F86BG 16LTGN / ## FOR 12, 13 WINDOW BUS NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / SPKR(+) #(A-A) / - - / F86BH 16LTGN / REAR CAP/ L BODY (10405) CH17_01,02,05 / Figure 710 / RIGHT SPEAKER WIRING FOR QUANTITY 12

17.16. LEFT SPEAKER WIRING FOR 2 - 140 IN BEHIND STANCHION, P. 16
Figure 711 LEFT SPEAKER WIRING FOR 2 - 140 IN BEHIND STANCHION

Components: L BODY (10401A/B); PLATFORM (1702); RADIO (10259)
Wires (circuit gauge+color): B86C 16LTGN; B86CD 16LTBL; B86CG 16LTBL; B86CH 16LTBL; B86D 16LTGN; E86C 16LTGN; E86CA 16LTBL; E86CB 16LTBL; E86CC 16LTBL; E86D 16LTGN; F86 16LTBL
See also sheets: CH17_01, CH17_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.16. LEFT SPEAKER WIRING FOR 2 - 140 IN BEHIND STANCHION, P. 16 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 LEFT SPEAKER WIRING FOR 2 - 140 IN BEHIND STANCHION / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SPKR(+) %(A-A) / SPKR(-) %(B-A) / ELEC PANEL/ L BODY (10401A/B) D2 / SPKR(-) @(B-A) / SPKR(+) @(A-A) / B86C 16LTGN B86D 16LTGN / SPKR(-) (10497) (B-A) / SPKR(+) (10497) (A-A) / F86 16LTBL / B86CH 16LTBL / %E86D 16LTGN *E86CC 16LTBL #E86CA 16LTBL #E86CB 16LTBL E86C 16LTGN B86CG 16LTBL B86CD 16LTBL B86CG 16LTBL / - - / ELEC PANEL/ PLATFORM (1702) CH17_01,04 RADIO (10259) CH17_02 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 711 / LEFT SPEAKER WIRING FOR 2 - 140 IN BEHIND STANCHION

17.17. LEFT SPEAKER WIRING FOR 4 - 140 IN BEHIND STANCHION, P. 17
Figure 712 LEFT SPEAKER WIRING FOR 4 - 140 IN BEHIND STANCHION

Components: L BODY (10401A/B); PLATFORM (1702); RADIO (10259)
Wires (circuit gauge+color): B86C 16LTGN; B86D 16LTGN; E86CH 16LTBL; E86CJ 16LTBL; E86CK 16LTBL; E86CL 16LTBL; E86CM 16LTBL; E86CN 16LTBL; E86CP 16LTBL; E86E 16LTGN; E86G 16LTGN; F86F 16LTGN
See also sheets: CH17_01, CH17_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.17. LEFT SPEAKER WIRING FOR 4 - 140 IN BEHIND STANCHION, P. 17 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 LEFT SPEAKER WIRING FOR 4 - 140 IN BEHIND STANCHION / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SPKR(+) (10499A) / SPKR(-) (10499B) / ELEC PANEL/ L BODY (10401A/B) D2 B86C 16LTGN B86D 16LTGN / SPKR(-) %(B-A) / SPKR(+) %(A-A) / SPKR(-) (B-A) / SPKR(+) @(A-A) / SPKR(+) #(A-A) / SPKR(-) #(B-A) / @E86CK 16LTBL / F86F 16LTGN / E86CP 16LTBL / E86G 16LTGN / SPKR(-) *(B-A) / SPKR(+) *(A-A) / @E86CM 16LTBL / E86CL 16LTBL / * 10500 - FOR 12,13 WINDOW BUS % 10497 - FOR 12,13 WINDOW BUS / - - / E86CJ 16LTBL / ELEC PANEL/ PLATFORM (1702) CH17_01,04 RADIO (10259) CH17_02 / E86E 16LTGN / E86CN 16LTBL / E86CH 16LTBL / Figure 712 / LEFT SPEAKER WIRING FOR 4 - 140 IN BEHIND STANCHION

17.18. LEFT SPEAKER WIRING FOR 6 - 140 IN BEHIND STANCHION, P. 18
Figure 713 LEFT SPEAKER WIRING FOR 6 - 140 IN BEHIND STANCHION

Components: L BODY (10401A/B); PLATFORM (1702); RADIO (10259)
Wires (circuit gauge+color): B86C 16LTGN; B86D 16LTGN; E86H 16LTGN; E86J 16LTGN; E86K 16LTGN; E86L 16LTGN; E86M 16LTGN; E86N 16LTGN; E86P 16LTGN
See also sheets: CH17_01, CH17_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.18. LEFT SPEAKER WIRING FOR 6 - 140 IN BEHIND STANCHION, P. 18 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 LEFT SPEAKER WIRING FOR 6 - 140 IN BEHIND STANCHION / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SPKR(+) (10497A) / SPKR(-) (10497B) / ELEC PANEL/ L BODY (10401A/B) D2 B86C 16LTGN B86D 16LTGN / SPKR(-) (10501B) (10503B) / SPKR(+) (10501A) (10503A) / SPKR(+) (10500A) (10499A) / SPKR(-) (10500B) (10499B) / E86M 16LTGN / E86K 16LTGN / E86P 16LTGN E86H 16LTGN / 10501/10499 - FOR 12 WINDOW BUS 10503/10500 - FOR 13 WINDOW BUS 10497 - FOR 12,13 WINDOW BUS / - - / E86J 16LTGN / ELEC PANEL/ PLATFORM (1702) CH17_01,04 RADIO (10259) CH17_02 / E86L 16LTGN / E86N 16LTGN / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 713 / LEFT SPEAKER WIRING FOR 6 - 140 IN BEHIND STANCHION

17.19. LEFT SPEAKER WIRING FOR 8 - 140 IN BEHIND STANCHION, P. 19
Figure 714 LEFT SPEAKER WIRING FOR 8 - 140 IN BEHIND STANCHION

Components: L BODY (10401A/B); PLATFORM (1702); RADIO (10259)
Wires (circuit gauge+color): B86C 16LTGN; B86D 16LTGN; E86R 16LTGN; E86S 16LTGN; E86T 16LTGN; E86U 16LTGN; E86V 16LTGN; E86W 16LTGN; E86X 16LTGN; E86Y 16LTGN
See also sheets: CH17_01, CH17_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.19. LEFT SPEAKER WIRING FOR 8 - 140 IN BEHIND STANCHION, P. 19 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 LEFT SPEAKER WIRING FOR 8 - 140 IN BEHIND STANCHION / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SPKR(+) (10501A) / SPKR(-) (10501B) / ELEC PANEL/ L BODY (10401A/B) D2 B86C 16LTGN / SPKR(-) (10497B) / B86D 16LTGN / SPKR(-) (10503B) / SPKR(+) (10503A) / SPKR(+) (10499A) / SPKR(-) (10499B) / E86T 16LTGN / E86W 16LTGN / E86Y 16LTGN / E86R 16LTGN / - - / E86V 16LTGN / ELEC PANEL/ PLATFORM (1702) CH17_01,04 RADIO (10259) CH17_02 / E86S 16LTGN / E86X 16LTGN / E86U 16LTGN / W/12,13 WINDOW BUS ONLY / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / SPKR(+) (10497A) / Figure 714 / LEFT SPEAKER WIRING FOR 8 - 140 IN BEHIND STANCHION

17.20. LEFT SPEAKER WIRING FOR 4 - AFT OF THIRD ROW OF SEATS, P. 20
Figure 715 LEFT SPEAKER WIRING FOR 4 - AFT OF THIRD ROW OF SEATS

Components: L BODY (10401A/B); PLATFORM (1702); RADIO (10259)
Wires (circuit gauge+color): B86C 16LTGN; B86D 16LTGN; E86 16LTBL; E86 16LTGN
See also sheets: CH17_01, CH17_02
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.20. LEFT SPEAKER WIRING FOR 4 - AFT OF THIRD ROW OF SEATS, P. 20 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 LEFT SPEAKER WIRING FOR 4 - AFT OF THIRD ROW OF SEATS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SPKR(+) *(A-A) / SPKR(-) *(B-A) / ELEC PANEL/ L BODY (10401A/B) D2 / SPKR(-) **(B-A) / SPKR(+) **(A-A) / B86D 16LTGN / B86C 16LTGN / %E86(+) 16LTBL #E86A(+) 16LTBL @E86A(+) 16LTGN @E86B(-) 16LTGN #E86B(-) 16LTBL / @ W/13 WINDOW - 10495/10501 # W/11 WINDOW - 10499/10501 % W/12 WINDOW - 10495/10499 / * W/10495,10499 **W10501,10499 / @E86 16LTGN / ELEC PANEL/ PLATFORM (1702) CH17_01,04 RADIO (10259) CH17_02 / %/#E86 16LTBL / %E86(-) 16LTBL / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 715 / LEFT SPEAKER WIRING FOR 4 - AFT OF THIRD ROW OF SEATS

17.21. RIGHT SPEAKER WIRING FOR 2 - 140 IN BEHIND STANCHION, P. 21
Figure 716 RIGHT SPEAKER WIRING FOR 2 - 140 IN BEHIND STANCHION

Components: L BODY (10405); R BODY (10700)
Wires (circuit gauge+color): F86A 16LTGN; F86B 16LTGN
See also sheets: CH17_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.21. RIGHT SPEAKER WIRING FOR 2 - 140 IN BEHIND STANCHION, P. 21 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 RIGHT SPEAKER WIRING FOR 2 - 140 IN BEHIND STANCHION / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SPKR(+) @(A-A) / SPKR(-) @(B-A) / REAR CAP/ R BODY (10700) A7 / SPKR(-) (10751B) / SPKR(+) (10751A) / D86B(+) 16LTGN D86A(-) 16LTGN / **F86A(+) 16LTBL %F86B(+) 16LTBL &&F86A 16LTGN %F86A(-) 16LTBL **F86B(-) 16LTBL / @ 10748 - FOR 6,7,8 WINDOW BUS 10766 - FOR 9 WINDOW BUS 10749 - FOR 10 WINDOW BUS 10750 - FOR 11 WINDOW BUS 10752 - FOR 13 WINDOW BUS 10751 - FOR 12 WINDOW BUS / && W/12 WINDOW ** W/13 WINDOW / REAR CAP/ L BODY (10405) CH17_01,02,05 / &&F86B 16LTGN / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 716 / RIGHT SPEAKER WIRING FOR 2 - 140 IN BEHIND STANCHION

17.22. RIGHT SPEAKER WIRING FOR 4 - 140 IN BEHIND STANCHION, P. 22
Figure 717 RIGHT SPEAKER WIRING FOR 4 - 140 IN BEHIND STANCHION

Components: L BODY (10405); R BODY (10700)
Wires (circuit gauge+color): F86 16LTBL; F86A 16LTGN; F86B 16LTGN; F86BB 16LTGN; F86CB 16LTBL; F86CE 16LTBL; F86CM 16LTBL
See also sheets: CH17_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.22. RIGHT SPEAKER WIRING FOR 4 - 140 IN BEHIND STANCHION, P. 22 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 RIGHT SPEAKER WIRING FOR 4 - 140 IN BEHIND STANCHION / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SPKR(+) *(A-A) / SPKR(-) *(B-A) / REAR CAP/ R BODY (10700) A7 D86B(+) 16LTGN D86A(-) 16LTGN / SPKR(-) #(B-A) / SPKR(+) #(A-A) / @@F86A(+) 16LTBL &&F86A 16LTGN @F86A(+) 16LTBL %F86F(+) 16LTBL F86C(+) 16LTBL / F86D(-) 16LTBL %F86L(-) 16LTBL / REAR CAP/ L BODY (10405) CH17_01,02,05 / @F86D(-) 16LTGN &&F86BB 16LTGN @@F86B(-) 16LTBL / 16LTBL @F86CB 16LTBL %F86CM 16LTBL 16LTBL &&F86B 16LTGN 16LTBL F86CE @@F86 &F86 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 717 / RIGHT SPEAKER WIRING FOR 4 - 140 IN BEHIND STANCHION

17.23. RIGHT SPEAKER WIRING FOR 6 - 140 IN BEHIND STANCHION P. 23
Figure 718 RIGHT SPEAKER WIRING FOR 6 - 140 IN BEHIND STANCHION

Components: L BODY (10405); R BODY (10700)
Wires (circuit gauge+color): F86AA 16LTGN; F86AB 16LTGN; F86AC 16LTGN; F86B 16LTGN; F86BB 16LTGN; F86BC 16LTGN; F86BF 16LTGN; F86C 16LTGN; F86CN 16LTBL; F86CP 16LTBL; F86CT 16LTBL; F86CV 16LTBL; F86CW 16LTBL; F86H 16LTBL
See also sheets: CH17_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.23. RIGHT SPEAKER WIRING FOR 6 - 140 IN BEHIND STANCHION P. 23 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090668 NO. RELEASE NO. 95885P 04JAN21 / CHAPTER 17 RIGHT SPEAKER WIRING FOR 6 - 140 IN BEHIND STANCHION / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SPKR(+) #(A-A) / SPKR(-) (B-A) / REAR CAP/ R BODY (10700) A7 / SPKR(-) (B-A) / SPKR(+) %(A-A) / D86B(+) 16LTGN D86A(-) 16LTGN / SPKR(-) (B-A) / SPKR(+) *(A-A) / F86BF 16LTGN &F86H 16LTBL F86CN 16LTBL @F86BC 16LTGN &F86C(-) 16LTBL / &F86E(+) 16LTBL @F86AC 16LTGN F86CT 16LTBL &F86D(-) 16LTBL F86CP 16LTBL @F86C 16LTGN F86CV 16LTBL @F86AB 16LTGN &F86F(+) 16LTBL / @F86AA 16LTGN F86R(+) 16LTBL &F86A(+) 16LTBL &F86B(-) 16LTBL F86M(-) 16LTBL @F86BB 16LTGN / - - / F86CW 16LTBL @F86B 16LTGN / REAR CAP/ L BODY (10405) CH17_01,02,05 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 718 / RIGHT SPEAKER WIRING FOR 6 - 140 IN BEHIND STANCHION

17.24. RIGHT SPEAKER WIRING FOR 6 - 140 IN BEHIND STANCHION (CONT.), P. 24
Figure 719 RIGHT SPEAKER WIRING FOR 6 - 140 IN BEHIND STANCHION (CONT.)

Components: L BODY (10405); R BODY (10700)
Wires (circuit gauge+color): F86A 16LTGN; F86B 16LTGN; F86CW 16LTBL; F86CX 16LTBL; F86CY 16LTBL; F86CZ 16LTBL; F86DA 16LTBL; F86DB 16LTBL; F86DC 16LTBL
See also sheets: CH17_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.24. RIGHT SPEAKER WIRING FOR 6 - 140 IN BEHIND STANCHION (CONT.), P. 24 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090668 NO. RELEASE NO. 95885P 04JAN21 / CHAPTER 17 RIGHT SPEAKER WIRING FOR 6 - 140 IN BEHIND STANCHION (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SPKR(+) (10766A-A) / SPKR(-) (10766B-A) / REAR CAP/ R BODY (10700) A7 / SPKR(-) (10748B-A) / SPKR(+) (10748A-A) / D86B(+) 16LTGN D86A(-) 16LTGN / SPKR(-) (10749B-A) / SPKR(+) (10749A-A) / F86DA 16LTBL / F86DB 16LTBL / F86CZ 16LTBL / F86CW 16LTBL / - - / F86CY 16LTBL / REAR CAP/ L BODY (10405) CH17_01,02,05 / F86CX 16LTBL / F86DC 16LTBL / REAR CAP/ R BODY (10700) A7 / D86B(+) 16LTGN D86A(-) 16LTGN / F86A 16LTGN / F86B 16LTGN / REAR CAP/ L BODY (10405) CH17_01,02,05 / SPKR(+) (10557A-A) / SPKR(-) (10557B-A) / W/12 WINDOW - SPKR WIRING 2 W/FIRST WINDOW SECTION / W/10 WINDOW W/REAR LIFT / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 719 / RIGHT SPEAKER WIRING FOR 6 - 140 IN BEHIND STANCHION (CONT.)

17.25. RIGHT SPEAKER WIRING FOR 8 - 140 IN BEHIND STANCHION, P. 25
Figure 720 RIGHT SPEAKER WIRING FOR 8 - 140 IN BEHIND STANCHION

Components: L BODY (10405); R BODY (10700)
Wires (circuit gauge+color): F86A 16LTGN; F86AA 16LTGN; F86B 16LTGN; F86BB 16LTGN; F86C 16LTGN; F86E 16LTBL; F86E 16LTGN; F86F 16LTBL; F86F 16LTGN; F86G 16LTGN
See also sheets: CH17_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.25. RIGHT SPEAKER WIRING FOR 8 - 140 IN BEHIND STANCHION, P. 25 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 RIGHT SPEAKER WIRING FOR 8 - 140 IN BEHIND STANCHION / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR CAP/ R BODY (10700) A7 / + - / SPKR(-) #(B-A) / @F86G 16LTGN / SPKR(-) %(B-A) / SPKR(+) %(A-A) / D86B(+) 16LTGN D86A(-) 16LTGN / SPKR(+) *(A-A) / @F86E 16LTGN ^F86D(+) 16LTBL ^F86F 16LTBL / @F86C 16LTGN ^F86H(-) 16LTBL / ^F86C(+) 16LTBL @F86A 16LTGN / @F86B 16LTGN / SPKR(-) &(B-A) / SPKR(+) &(A-A) / ^F86A(+) 16LTBL @F86AA 16LTGN @F86BB 16LTGN ^F86B(-) 16LTBL / & 10751 - FOR 12 WINDOW BUS 10752 - FOR 13 WINDOW BUS / SPKR(+) #(A-A) / REAR CAP/ L BODY (10405) CH17_01,02,05 / ^F86E 16LTBL / ^F86J(-) 16LTBL / @F86F 16LTGN / SPKR(-) *(B-A) / Figure 720 / RIGHT SPEAKER WIRING FOR 8 - 140 IN BEHIND STANCHION

17.26. RIGHT SPEAKER WIRING FOR 4 - AFT OF THIRD ROW OF SEATS, P. 26
Figure 721 RIGHT SPEAKER WIRING FOR 4 - AFT OF THIRD ROW OF SEATS

Components: L BODY (10405); R BODY (10700)
Wires (circuit gauge+color): F86 16LTBL; F86 16LTGN
See also sheets: CH17_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.26. RIGHT SPEAKER WIRING FOR 4 - AFT OF THIRD ROW OF SEATS, P. 26 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 RIGHT SPEAKER WIRING FOR 4 - AFT OF THIRD ROW OF SEATS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / SPKR(+) *(A-A) / SPKR(-) (B-A) / REAR CAP/ R BODY (10700) A7 / SPKR(-) (B-A) / SPKR(+) %(A-A) / D86B(+) 16LTGN D86A(-) 16LTGN / * 10751 - 11,12 WINDOW 10754 - 13 WINDOW # 10748 - 11,12 WINDOW 10766 - 13 WINDOW @ W/11,12 WINDOW / REAR CAP/ L BODY (10405) CH17_01,02,05 / @F86A(+) 16LTGN #F86A(+) 16LTBL @F86B(-) 16LTGN #F86B(-) 16LTBL / @F86 16LTGN / #F86 16LTBL / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 721 / RIGHT SPEAKER WIRING FOR 4 - AFT OF THIRD ROW OF SEATS

Figure 722 AUDIO AND VIDEO PREWIRE EFFECTS

Components: CAMERA (10034); CAMERA (10035); FR CAP (10000); FUSE B12-D (10301); FUSE B3-H (10304); FUSE B3-K (10304); SPLICE (10009)
Wires (circuit gauge+color): B137 16LTBL; B137-GB 14WH; B137A 16LTBL; B137B 14LTBL; B86-GU 14WH; B86U 14LTGN; C137 16LTBL; C137-G 16WH
See also sheets: CH3_12, CH3_26, CH3_43
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.27. AUDIO AND VIDEO PREWIRE EFFECTS, P. 27 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 AUDIO AND VIDEO PREWIRE EFFECTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL / FR CAP (10000) / TWO WAY RADIO (+) (10260) / # W/ CAMERA SYSTEM IGN ACTIVATED & W/ HONEYWELL DDR SYSTEM / C137 16LTBL / CAMERA (10034) A / &B137 16LTBL C137-G 16WH / VIDEO SYSTEM / CAMERA (10035) A / B86-GU 14WH / B86U 14LTGN / TWO WAY RADIO PWR STRIP / TWO WAY RADIO (-) (10261) / B137-GB 14WH / B137B 14LTBL / FUSE B3-K (10304) CH3_26 / GROUND STUD (27) / VIDEO SYSTEM (-) (10263) / VIDEO SYSTEM (+) (10262) / VIDEO PWR STRIP / FLASHER PLATE GROUND (26/32) / &B137A 16LTBL / #B137 16LTBL / FUSE B12-D (10301) CH3_12 GROUND SPLICE (10009) CH3_43 / FUSE B3-K (10304) CH3_2G / FUSE B3-H (10304) CH3_26 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 722 / AUDIO AND VIDEO PREWIRE EFFECTS

Figure 723 AUDIO AND VIDEO PREWIRE EFFECTS (CONT.)

Components: ACCESSORY 1 (10260A); ACCESSORY 1 (10260B); ACCESSORY 2 (10261A); ACCESSORY 2 (10261B); ACCESSORY 3 (10262A); ACCESSORY 3 (10262B); ACCESSORY 4 (10263A); ACCESSORY 4 (10263B); FUSE B3-B (10304); FUSE B3-H (10304); FUSE B6-E (10303); FUSE B6-L (10303); FUSE B6-W (10303); FUSE B9-C (10302); FUSE B9-J (10302)
Wires (circuit gauge+color): B12RA 14LTGN; B12RB 14LTGN; B12RC 14LTGN; B12RD 14LTGN; B12UA 14LTBL; B12UB 14LTBL; B14UA 14RD; B14UB 14RD
See also sheets: CH3_09, CH3_10, CH3_13, CH3_14, CH3_15, CH3_16, CH3_26
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.28. AUDIO AND VIDEO PREWIRE EFFECTS (CONT.), P. 28 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090668 NO. RELEASE NO. 95885P 04JAN21 / CHAPTER 17 AUDIO AND VIDEO PREWIRE EFFECTS (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FUSE B6-W (10303) CH3_09,25 FUSE B3-B (10304) CH3_10 / B12RB 14LTGN / FUSE B3-H (10304) CH3_26 / ACCESSORY 1 (10260A) / B12RA 14LTGN / FUSE B6-L (10303) CH3_15 / B12RD 14LTGN / FUSE B9-J (10302) CH3_16 / B12RC 14LTGN / BATT AND ACCESSORY FEED / FUSE B6-L (10303) CH3_15 / B12UB 14LTBL / FUSE B9-J (10302) CH3_16 / B12UA 14LTBL / FUSE B9-C (10302) CH3_13 / B14UB 14RD / FUSE B6-E (10303) CH3_14 / B14UA 14RD / ACCESSORY PWR STRIP AND ACCESSORY FEED / ACCESSORY 2 (10261A) / ACCESSORY 3 (10262A) / ACCESSORY 4 (10263A) / ACCESSORY 1 (10260B) / ACCESSORY 2 (10261B) / ACCESSORY 3 (10262B) / ACCESSORY 4 (10263B) / B12RB 14LTGN / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 723 / AUDIO AND VIDEO PREWIRE EFFECTS (CONT.)

Figure 724 AUDIO AND VIDEO PREWIRE EFFECTS (CONT.)

Components: FUSE B3-K (10304); FUSE B6-E (10303); FUSE E (10303); FUSE K (10304); SEON PWR (11643); SEON PWR (11653); SEON SIGNALS (11644); STOP ARM EXTEND (10358B)
Wires (circuit gauge+color): B11 16WH; B11-GZ 16WH; B119V 18GN; B13 18PK; B13K 18PK; B14 16RD; B14AH 16RD
See also sheets: CH3_14, CH3_26
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.29. AUDIO AND VIDEO PREWIRE EFFECTS (CONT.), P. 29 / CHAPTER 17 AUDIO AND VIDEO PREWIRE EFFECTS (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090668 NO. RELEASE NO. 95885P 04JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B119V 18GN / B13K 18PK / B11-GZ 16WH / B14AH 16RD / SEON PWR (11643) / FUSE B6-E (10303) CH3_14 / STOP ARM EXTEND (10358B) / FUSE B3-K (10304) CH3_26 / SEON SIGNALS (11644) / GROUND STUD (40) / B13 18PK / B11 16WH / B14 16RD / SEON PWR (11653) / FUSE E (10303) CH3_14 / FUSE K (10304) CH3_26 / GROUND STUD (1GND) CH3-25 / DVR PREWIRE W/2 WAY RADIO / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 724 / AUDIO AND VIDEO PREWIRE EFFECTS (CONT.)

17.30. TELEMATIC EFFECTS WITH ZONAR V3 PREWIRE, P. 30
Figure 725 TELEMATIC EFFECTS WITH ZONAR V3 PREWIRE

Components: BODY CONTROLER (1601); DOOR LT RELAY (10309-R2); ELEC PANEL (1702); ENTRANCE DOOR-CAV 7 (1351); KEY SW (1146); LT RELAY (10309); RELAY (10310); RELAY (10310-R1)
Wires (circuit gauge+color): A120EE 18LTGN; A120EF 18LTGN; A120EH 20LTGN; A133B 18LTGN; B119B 18GY; B120K 18LTGN; B120S 18LTGN
See also sheets: CH16_11, CH16_21, CH16_29, CH9_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.30. TELEMATIC EFFECTS WITH ZONAR V3 PREWIRE, P. 30 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 04JAN21 / CHAPTER 17 TELEMATIC EFFECTS W/ZONAR V3 PREWIRE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / STOP ARM-CAV 1 ENTRANCE DOOR-CAV 7 (1351) / PLATFORM/ ELEC PANEL (1702) &A89HH 18PL 42 ^A89HH 18VT @A120EE 18LTGN / A89HJ 20VT @A120EH 20LTGN / @ N/VANDAL LOCK % W/VANDAL LOCK ^ W/CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK & W/CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK / ^B119B 18GY ^B120S 18LTGN / STOP ARM RELAY (10310) CH9_01 STOP ARM RELAY (10310-R1) CH9_01 DOOR LT RELAY (10309-R2) CH16_11 STEP WELL LT RELAY (10309) CH16_29 / %A120EH 20LTGN / %A120EE 18LTGN / J4-BLUE BODY CONTROLER (1601) / A89HK 18VT @A120EF 18LTGN %A120EF 18LTGN / %A133B 18LTGN / VANDAL LOCK KEY SW (1146) CH16_21 / &B119B 18GY / &B120K 18LTGN / Figure 725 / TELEMATIC EFFECTS WITH ZONAR V3 PREWIRE

17.31. TELEMATIC EFFECTS WITH ZONAR V3 PREWIRE (CONT.), P. 31
Figure 726 TELEMATIC EFFECTS WITH ZONAR V3 PREWIRE (CONT.)

Components: FUSE A3-T (1016); FUSE A6-F (1014); GROUND SPLICE (1004); ZONAR V3 PWR (1349)
Wires (circuit gauge+color): A11-GTS 20WH; A13TS 20PK; A14TS 20RD
See also sheets: CH3_01, CH3_06, CH3_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.31. TELEMATIC EFFECTS WITH ZONAR V3 PREWIRE (CONT.), P. 31 / CHAPTER 17 TELEMATIC EFFECTS W/ZONAR V3 PREWIRE (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090668 NO. RELEASE NO. 95885P 04JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A13TS 20PK / A11-GTS 20WH / A14TS 20RD / ZONAR V3 PWR (1349) / FUSE A6-F (1014) CH3_01 / FUSE A3-T (1016) CH3_06 / GROUND SPLICE (1004) CH3_31 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 726 / TELEMATIC EFFECTS WITH ZONAR V3 PREWIRE (CONT.)

17.32. FRONT CAMERA EFFECTS WITH 2017 ISB / 2021 B6.7, F-2018 PROPANE / GASOLINE ENGINE, P. 32
Figure 727 FRONT CAMERA EFFECTS WITH 2017 ISB / 2021 B6.7, F-2018 PROPANE / GASOLINE

Components: FR CAMERA (8585); HOOD HARNESS (8585A)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.32. FRONT CAMERA EFFECTS WITH 2017 ISB / 2021 B6.7, F-2018 PROPANE / GASOLINE ENGINE, P. 32 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 23JAN21 / CHAPTER 17 FRONT CAMERA EFFECTS W/2017/2021 ISB/B6.7 ENGINE, W/F-2018-PROPANE/GASOLINE-ENGINE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / [M137A] 24BL / PLATFORM/ FR CAMERA (8585) 3 / FR CAMERA/ HOOD HARNESS (8585A) 3 / [M137G] 24BK / [M137P] 24RD / [M137V] 24WH / Figure 727 / FRONT CAMERA EFFECTS WITH 2017 ISB / 2021 B6.7, F-2018 PROPANE / GASOLINE ENGINE

17.33. DASH MOUNTED 4-CHANNEL RADIO / PA, P. 33
Figure 728 DASH MOUNTED 4-CHANNEL RADIO / PA

Components: CHANNEL (1300); ELEC PANEL (10401); ELEC PANEL (10401A/B); FUSE F35 (10303); FUSE F6 (10301); L BODY (10405); PANEL (10000); PANEL (11500); PLATFORM (1702); REAR CAP (10700); SPLICE (1003A)
Wires (circuit gauge+color): A86-G 18WH; A86A 18LTGN; A86B 16LTGN; A86C 18LTGN; A86D 18LTGN; B86A 16LTGN; B86B 16LTGN; B86D 16LTGN; B86E 16LTGN; B86F 16LTGN; B86H 16LTGN; B86J 16LTGN; B86S 16LTGN; B86T 16LTGN; B96C 16LTGN
See also sheets: CH17_04, CH17_05, CH17_06
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.33. DASH MOUNTED 4-CHANNEL RADIO / PA, P. 33 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 09MAR21 / CHAPTER 17 DASH MOUNTED 4-CHANNEL RADIO-PA / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 11P 8P / ELEC PANEL/ PLATFORM (1702) / A86RR+ A86RR- 18LTGN A86LF- 18LTGN A86RF- 18LTGN A86RF+ 18LTGN 18LTGN A86LF+ 18LTGN A86LR- 18LTGN / 4P 12P 10P 9P / D86A(-) D86B(+) 16LTGN 16LTGN / E86B(+) E86A(-) 16LTGN 16LTGN / REAR CAP/ L BODY (10405) / 16LTGN 16LTGN B86F B86E / 16LTGN B86B / A86LR+ 18LTGN 16LTGN 18LTGN A86B A86A / CH17_06,07,09, CAP 11,13,15 BODY/ (10700) REAR R / 16LTGN B86A / 18LTGN A86D / 18LTGN A86C / RADIO/PA 4 CHANNEL (1300) / 16LTGN 16LTGN 16LTGN 16LTGN 16LTGN 16LTGN #B86D *B86S *B86T #B96C B86H B86J / F6 (10301) CH3_94D FUSE / L BODY/ ELEC PANEL (10401A/B) / (11500) CH17_04 SEALED PANEL ENG/ ELEC / CH17_06,07,08, PANEL 10,12,14 BODY/ (10401) ELEC L / CAB/ (10000) CH17_05 PANEL ELEC FR / # N/FR SPKR * W/FR SPKR / A86-G 18WH / (1003A) CH3_95B GROUND SPLICE / F35 (10303) CH3_94H FUSE / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 728 / DASH MOUNTED 4-CHANNEL RADIO / PA

Figure 729 TWO WAY RADIO AND VIDEO EFFECTS

Components: CAMERA (10034); CAMERA (10035); FR CAP (10000); FUSE F15 (10302); FUSE F18 (10302); FUSE F36 (10303); GROUND SPLICE (10009)
Wires (circuit gauge+color): B137 16LTBL; B137-GB 14WH; B137A 16LTBL; B137B 14LTBL; B86-GU 14WH; B86U 14LTGN; C137 16LTBL; C137-G 16WH
See also sheets: CH3_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.34. TWO WAY RADIO AND VIDEO EFFECTS, P. 34 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 09MAR21 / CHAPTER 17 TWO WAY RADIO AND VIDEO EFFECTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL / FR CAP (10000) / TWO WAY RADIO (+) (10260) / # W/ CAMERA SYSTEM IGN ACTIVATED & W/ HONEYWELL DPR SYSTEM NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / C137 16LTBL / CAMERA (10034) A / &B137 16LTBL C137-G 16WH / VIDEO SYSTEM / CAMERA (10035) A / B86-GU 14WH / B86U 14LTGN / TWO WAY RADIO / TWO WAY RADIO (-) (10261) / B137-GB 14WH / B137B 14LTBL / FUSE F18 (10302) CH3_94E / GROUND STUD (1GND) CH3_95E / VIDEO SYSTEM (-) (10263) / VIDEO SYSTEM (+) (10262) / VIDEO PWR STRIP / GROUND STUD (1GND) CH3_95E / &B137A 16LTBL / #B137 16LTBL / FUSE F18 (10302) CH3_94E / FUSE F36 (10303) CH3_94H GROUND SPLICE (10009) CH3_31 / FUSE F18 (10302) CH3_94E / B86U 14LTGN / FUSE F15 (10302) CH3_94E / Figure 729 / TWO WAY RADIO AND VIDEO EFFECTS

17.35. GPS PRE-WIRE AND VIDEO POWER EFFECTS, P. 35
Figure 730 GPS PRE-WIRE AND VIDEO POWER EFFECTS

Components: ELEC PANEL/PLATFORM (1702); ELEC PANEL/PLATFORM (1703); SIGNAL (10392); SIGNAL (10393); VCR PWR (1052)
Wires (circuit gauge+color): A137A 18LTBL; A137A-G 18WH; B145-G 16WH; B145H 16LTGN
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.35. GPS PRE-WIRE AND VIDEO POWER EFFECTS, P. 35 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 09MAR21 / CHAPTER 17 GPS PRE-WIRE AND VIDEO POWER EFFECTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A137A-G 18WH / GROUND SPLICE PACK #2 (1004) CH3_95A / VCR PWR (1052) / A137A 18LTBL / ELEC PANEL/PLATFORM (1702) 44 / B145-G 16WH / GPS SW SIGNAL (10392) A / ELEC PANEL/PLATFORM (1703) A13 / B145H 16LTGN / GPS SW SIGNAL (10393) A / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 730 / GPS PRE-WIRE AND VIDEO POWER EFFECTS

17.36. ACCESSORY POWER STRIP AND ACCESS FEED, P. 36
Figure 731 ACCESSORY POWER STRIP AND ACCESS FEED

Components: ACCESSORY 1 (10260A); ACCESSORY 1 (10260B); ACCESSORY 2 (10261A); ACCESSORY 2 (10261B); ACCESSORY 3 (10262A); ACCESSORY 3 (10262B); ACCESSORY 4 (10263A); ACCESSORY 4 (10263B); FUSE F15 (10302); FUSE F24 (10302); FUSE F37 (10304); FUSE F42 (10304); FUSE F52 (10305); FUSE F68 (10306); FUSE F75 (10307)
Wires (circuit gauge+color): B12RA 14LTGN; B12RB 14LTGN; B12RC 14LTGN; B12RD 14LTGN; B12UA 14LTBL; B12UB 14LTBL; B14UA 14RD; B14UB 14RD
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.36. ACCESSORY POWER STRIP AND ACCESS FEED, P. 36 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 09MAR21 / CHAPTER 17 ACCESSORY POWER STRIP AND ACCESS FEED / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FUSE F24 (10302) CH3_94F FUSE F75 (10307) CH3_94P / B12RB 14LTGN / FUSE F15 (10302) CH3_94E / ACCESSORY 1 (10260A) / B12RA 14LTGN / FUSE F68 (10306) CH3_94N / B12RD 14LTGN / FUSE F52 (10305) CH3_94M / B12RC 14LTGN / BATT AND ACCESSORY FEED / FUSE F68 (10306) CH3_94N / B12UB 14LTBL / FUSE F52 (10305) CH3_94M / B12UA 14LTBL / FUSE F42 (10304) CH3_94K / B14UB 14RD / FUSE F37 (10304) CH3_94J / B14UA 14RD / ACCESSORY PWR STRIP AND ACCESSORY FEED / ACCESSORY 2 (10261A) / ACCESSORY 3 (10262A) / ACCESSORY 4 (10263A) / ACCESSORY 1 (10260B) / ACCESSORY 2 (10261B) / ACCESSORY 3 (10262B) / ACCESSORY 4 (10263B) / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 731 / ACCESSORY POWER STRIP AND ACCESS FEED

17.37. DVR PREWIRE, P. 37
Figure 732 DVR PREWIRE

Components: FUSE F18 (10302); FUSE F18 (10302-H2); FUSE F37 (10304); FUSE F37 (10304-B1); SEON PWR (11643); SEON PWR (11653); SEON SIGNALS (11644); STOP ARM EXTEND (10358B)
Wires (circuit gauge+color): B11 16WH; B11-GZ 16WH; B119V 18GY; B13 18PK; B13K 18PK; B14 16RD; B14AH 16RD
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.37. DVR PREWIRE, P. 37 / CHAPTER 17 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 09MAR21 / DVR PREWIRE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B119V 18GY / B13K 18PK / B11-GZ 16WH / B14AH 16RD / SEON PWR (11643) / FUSE F37 (10304) CH3_94J / STOP ARM EXTEND (10358B) / FUSE F18 (10302) CH3_94E / SEON SIGNALS (11644) / GROUND STUD (1GND) CH3-95E / B13 18PK / B11 16WH / B14 16RD / SEON PWR (11653) / FUSE F37 (10304-B1) CH3_94J / FUSE F18 (10302-H2) CH3_94E / GROUND STUD (1GND) CH3-95E / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 732 / DVR PREWIRE

17.38. TELEMATIC ZONAR V3 PREWIRE WITHOUT DOOR SIGNAL, P. 38
Figure 733 TELEMATIC ZONAR V3 PREWIRE WITHOUT DOOR SIGNAL

Components: FUSE F13 (1011); FUSE F29 (1011); W/4100 W/500K (1029A); ZONAR V3 DATALINK (1350); ZONAR V3 PWR (1349)
Wires (circuit gauge+color): A11-GTS 20WH; A13TS 20PK; A14TS 20RD
See also sheets: CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.38. TELEMATIC ZONAR V3 PREWIRE WITHOUT DOOR SIGNAL, P. 38 / CHAPTER 17 TELEMATIC ZONAR V3 PREWIRE N/DOOR SIGNAL / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 95885P 09MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A5TS(+) 20YL A5TS(-) 20GN / J1939 + 1 / 6 J1939 - / ZONAR V3 DATALINK (1350) / A13TS 20PK / A11-GTS 20WH / A14TS 20RD / ZONAR V3 PWR (1349) / FUSE F13 (1011) CH3_94 / J1939 SPLICE W/4100 W/500K (1029A) / GROUND SPLICE PACK #2 (1004) CH3_95A / NOTE:CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / FUSE F29 (1011) CH3_94C / Figure 733 / TELEMATIC ZONAR V3 PREWIRE WITHOUT DOOR SIGNAL

17.39. RADIO & VIDEO PREWIRE LYTX CAMERA EVENT RECORDER, P. 39
Figure 734 RADIO & VIDEO PREWIRE LYTX CAMERA EVENT RECORDER

Components: FUSE F24 (10302); FUSE F37 (10304); PREWIRE (14602)
Wires (circuit gauge+color): B11-GZ 16WH; B13K 18PK; B14AH 16RD
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.39. RADIO & VIDEO PREWIRE LYTX CAMERA EVENT RECORDER, P. 39 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 96289K 23SEP21 / CHAPTER 17 RADIO & VIDEO PREWIRE LYTX EVENT RECORDER / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / B11-GZ 16WH / FUSE F37 (10304) CH3_94J / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / B13K 18PK / B14AH 16RD / FUSE F24 (10302) CH3_94F / LYTX CAMERA PREWIRE (14602) / GROUND STUD (1GND) CH3_95E / Figure 734 / RADIO & VIDEO PREWIRE LYTX CAMERA EVENT RECORDER

17.40. BATTERY AND ACCESSORY FEED POWER STRIP, P. 40
Figure 735 BATTERY AND ACCESSORY FEED POWER STRIP

Components: ACCESSORY 1 (10260A); ACCESSORY 2 (10261A); ACCESSORY 3 (10262A); ACCESSORY 4 (10263A); BATTERY 1 (10262B); BATTERY 2 (10263B); FUSE F15 (10302); FUSE F18 (10302); FUSE F24 (10302); FUSE F34 (10303); FUSE F42 (10304); FUSE F52 (10305)
Wires (circuit gauge+color): B12RA 14LTBL; B12RB 14LTBL; B12RC 14LTBL; B12RD 14LTBL; B14UA 14RD; B14UB 14RD
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 17.40. BATTERY AND ACCESSORY FEED POWER STRIP, P. 40 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090668 NO. 96289K 23SEP21 / CHAPTER 17 BATTERY AND ACCESSORY FEED POWER STRIP / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / FUSE F24 (10302) CH3_94F / B12RB 14LTBL / FUSE F52 (10305) CH3_94M / ACCESSORY 1 (10260A) / B12RA 14LTBL / FUSE F15 (10302) CH3_94E / B12RD 14LTBL / FUSE F18 (10302) CH3_94E / B12RC 14LTBL / FUSE F34 (10303) CH3_94H / B14UB 14RD / FUSE F42 (10304) CH3_94K / B14UA 14RD / ACCESSORY 2 (10261A) / ACCESSORY 3 (10262A) / ACCESSORY 4 (10263A) / BATTERY 1 (10262B) / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / BATTERY 2 (10263B) / Figure 735 / BATTERY AND ACCESSORY FEED POWER STRIP

Figure 736 CHILD MONITOR SYSTEM

Components: CHILD MONITOR (11642); CHILD SEAFTY ALARM RELAY (10310-R6); ELEC PANEL/FR CAP (10000); FUSE B9-A (10302); FUSE B9-G (10302); GROUND SPLICE (10336); INDICATER LT (14601); POST TRIP NO. (10044A); PTI RELAY (10309-R4); PTI RELAY (10309-R5); PTI RELAY (10309-R6); RR CAP (10405); SPLICE (10335B); STOP ARM (10358B); STOP LIGHT RELAY (10309-R3); SW ILLUM SPLICE (10331); SWITCH (10480); SWITCH (10481); SWITCH OUTPUT (11641)
Wires (circuit gauge+color): B117A 18GY; B119 18GY; B120B 18LTGN; B125 18GY; B125-G 18WH; B125-GD 18WH; B125A 18GY; B125B 18GY; B125D 18GY; B125E 18GY; B125F 18GY; B125FA 18GY; B125FB 18GY; B125FC 18GY; B12AA 18LTBL; B12AB 18LTBL; B12AC 18LTBL; C125 16GY; D125A 16GY; D125B 16GY; E125A 16GY; E125B 16GY
See also sheets: CH18_02, CH18_06, CH18_25, CH3_12, CH3_16, CH3_38, CH3_39, CH8_23, CH8_32, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / CHILD REMINDER SYSTEM (CHAPTER 18) / 18.1. CHILD MONITOR SYSTEM, P. 1 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. CHILD MONITOR (11642) / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 04JAN21 / CHAPTER 18 / CHILD MONITOR SYSTEM / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / DEACTIVATE 4 / HORN OUT 6 / B125D 18GY B125 18GY / B119 18GY / ARM ARM / GROUND SPLICE (10335B) CH3_38 B125-GD 18WH / B125A 18GY / B125B 18GY / B125F 18GY / * W/CHILD MONITOR SYSTEM # W/CHILD MONITOR W/+9 FRONT WINDOW @ W/PTI ACTIVE INDICATER LT % W/CCM ENTRANCE DOOR & EMER EXIT ACTIVATED / L BODY/ RR CAP (10405) D3 / E125A 16GY / D125B 16GY / E125B 16GY / D125A 16GY / GROUND SPLICE (10336) CH3_39 / PTI RESET SWITCH (10481) / PTI RESET SWITCH (10480) / B125E 18GY / B125FB 18GY B125FC 18GY / B125FA 18GY / ELEC PANEL/FR CAP (10000) C12 *B120B C125 18LTGN 16GY %B117A 18GY / POST TRIP NO. (10044A) CH18_06 CHILD SEAFTY ALARM RELAY (10310-R6) CH18_25 FUSE B9-G (10302) CH3_16 STOP LIGHT RELAY (10309-R3) CH8_23 / %B12AA 18LTBL / CHILD MONITER DOOR SWITCH OUTPUT (11641) / %B12AC 18LTBL %B12AB 18LTBL / @B125 18GY / SW ILLUM SPLICE (10331) CH8_32 / PTI ACTIVE INDICATER LT (14601) A / @B125-G 18WH / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 736 / CHILD MONITOR SYSTEM

18.2. CHILD MONITOR SYSTEM (CONT.), P. 2
Figure 737 CHILD MONITOR SYSTEM (CONT.)

Components: FUSE B9-A (10302); FUSE B9-B (10302); FUSE B9-W (10302); MONITOR (11642); PLATFORM (1703); PTI RELAY (10309-R4); PTI RELAY (10309-R5); PTI RELAY (10309-R6)
Wires (circuit gauge+color): B125E 18GY; B125EA 18GY; B125EB 18GY; B125EC 18GY; B125F 18GY; B125FA 18GY; B125FB 18GY; B125FC 18GY; B53 16GY; B53D 16GY; B85 16GY; B85B 16GY; B85C 16GY
See also sheets: CH18_01, CH3_08, CH3_11, CH3_12, CH7_60
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.2. CHILD MONITOR SYSTEM (CONT.), P. 2 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 04JAN21 / CHAPTER 18 CHILD MONITOR SYSTEM (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PTI RELAY (10309-R4) 87A / 85 B125FB 18GY / B125EC 18GY / B85C 16GY / B85B 16GY B53B 16YL B53A 16YL B53F 16YL B53C 16YL / PTI RELAY (10309-R6) 87A / B125FA 18GY B53J 16YL / B125EB 18GY / B125FC 18GY / PTI RELAY (10309-R5) / ELEC PANEL/ PLATFORM (1703) CH7_60 / ELEC PANEL/ PLATFORM (1703) CH7_60 / B125E 18GY / B125F 18GY / B85 16GY / B125EA 18GY / B53D 16GY / B53 16GY / FUSE B9-A (10302) CH3_12 / CHILD MONITOR (11642) CH18_01 FUSE B9-W (10302) CH3_08 / FUSE B9-B (10302) CH3_11 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 737 / CHILD MONITOR SYSTEM (CONT.)

18.3. CHILD MONITOR SYSTEM (CONT.), P. 3
Figure 738 CHILD MONITOR SYSTEM (CONT.)

Components: DIODE B3-P (10304); DOME LIGHT OUT (11640); FUSE B6-N (10303); OUTPUT (10202); RELAY (10311-R2); RELAY (10311-R3); SPLICE (10204)
Wires (circuit gauge+color): B117 18GY; B117A 18GY; B125L 18GY; B125LA 18GY; B125LB 18GY; B125M 16GY; B125N 16GY; B125NA 16GY; B125NB 16GY; B125NC 16GY; B63S 16DKBL; B63T 16DKBL
See also sheets: CH14_01, CH3_17, CH8_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.3. CHILD MONITOR SYSTEM (CONT.), P. 3 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 04JAN21 / CHAPTER 18 CHILD MONITOR SYSTEM (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR DOME LT RELAY (10311-R2) 87A / B125LB 18GY / DOME LIGHT 2 OUT / CHILD MONITOR DOME LIGHT OUT (11640) / B63S 16DKBL / FRONT DOME LT RELAY (10311-R3) 87A / B125NC 16GY / DOME LIGHT OUTPUT (10202) CH8_35,36 / B63T 16DKBL / B125NB 16GY / DIODE B3-P (10304) 30 / #B117A 18GY / #B117 18GY / EMER EXIT BUZZER SPLICE (10204) CH14_01 / # W/EMERGENCY EXIT ACTIVATED W/DOME LT / B125M 16GY / B125N 16GY / B125NA 16GY / B125LA 18GY / B125L 18GY / FUSE B6-N (10303) CH3_17 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK / Figure 738 / CHILD MONITOR SYSTEM (CONT.)

Figure 739 CHILD MONITOR SYSTEM (CONT.)

Components: DIODE B3-P (10304); DOME LIGHT OUT (11640); FUSE B6-N (10303); LT RELAY (10311-R1); OUTPUT (10202); RELAY (10311-R2); RELAY (10311-R3); SPLICE (10335B); SPLICE (10389)
Wires (circuit gauge+color): B125-GK 18WH; B125-GL 18WH; B125-GM 18WH; B125L 18GY; B125P 18GY; B125PA 18GY; B125R 18GY; B125RA 18GY; B125S 18GY; B63N 16DKBL; B63NA 16DKBL; B63NAB 16DKBL; B63NAC 16DKBL; B63NB 16DKBL; B63S 16DKBL; B63T 16DKBL
See also sheets: CH3_17, CH3_38, CH8_22, CH8_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.4. CHILD MONITOR SYSTEM (CONT.), P. 4 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 04JAN21 / CHAPTER 18 CHILD MONITOR SYSTEM (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR ROW DOME LT RELAY (10311-R1) 87A / B125L 18GY / CHILD MONITOR DOME LIGHT OUT (11640) / B125P 18GY / REAR DOME LT RELAY (10311-R2) / B63NAB 16DKBL / DOME LIGHT OUTPUT (10202) CH8_35,36 / B63S 16DKBL / B63NAC 16DKBL B125PA 18GY / DIODE B3-P (10304) 8 / B125RA 18GY / DOOR OPTION SPLICE (10389) CH8_22 / NOTE: ALL CIRCUITS ARE USED FOR CHILD MONITER SYSTEM W/ENTRANCE DOOR ACTIVATED NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / B63N 16DKBL / B63NA 16DKBL / B125-GM 18WH / B125-GL 18WH / FUSE B6-N (10303) CH3_17 / B125R 18GY / FRONT DOME LT RELAY (10311-R3) 87A / B125S 18GY / B63NB 16DKBL / B63T 16DKBL / B125-GK 18WH / GROUND SPLICE (10335B) CH3_38 / Figure 739 / CHILD MONITOR SYSTEM (CONT.)

18.5. CHILD MONITOR SYSTEM (CONT.), P. 4A
Figure 740 CHILD MONITOR SYSTEM (CONT.)

Components: FUSE F26 (10303); FUSE F40 (10304); FUSE F41 (10304); MONITOR (11642); PLATFORM (1703); RELAY (10309)
Wires (circuit gauge+color): B125E 18GY; B125EA 18GY; B125EB 18GY; B125F 18GY; B125FA 18GY; B125FB 18GY; B53 16GY; B53BA 18GY; B85 16GY; B85B 16GY; B85C 16GY
See also sheets: CH18_46
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.5. CHILD MONITOR SYSTEM (CONT.), P. 4A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 26MAR21 / CHAPTER 18 CHILD MONITOR SYSTEM (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / C4 86 / A4 30 / PTI RELAY (10309) 87A C3 B3 B85 16GY / 85 A3 / B125EA 18GY / FUSE F40 (10304) CH3_94J / B125E 18GY / 85 D3 / F4 86 / 87A F3 E3 / B85C 16GY / B53 16GY / B125FB 18GY / B85B 16GY B53B 16YL B53A 16YL B53F 16YL B53C 16YL / PTI RELAY (10309) 87A J3 H3 B53J 16YL / J4 86 / 85 G3 / FUSE F26 (10303) CH3_94G / FUSE F41 (10304) CH3_94K / B125F 18GY / CHILD MONITOR (11642) CH18_4D / B125FA 18GY B125EB 18GY / PTI RELAY (10309) / ELEC PANEL/ PLATFORM (1703) CH18_46 / ELEC PANEL/ PLATFORM (1703) CH7_60A / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / B53BA 18GY / Figure 740 / CHILD MONITOR SYSTEM (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 781 | printed page 741 | section 18.6
18.6. CHILD MONITOR SYSTEM (CONT.), P. 4B
Figure 741 CHILD MONITOR SYSTEM (CONT.)

Components: DIODE D79 (10307); DOME LIGHT OUT (11640); DOOR SWITCH INPUT (11641); FRONT CAP (10000); FUSE F80 (10307); OUTPUT (10202); POST TRIP COM (10045A); POST TRIP NO (10044A); RELAY (10311); SPLICE (10010); SPLICE (10204)
Wires (circuit gauge+color): B117 18GY; B117A 18GY; B120B 18LTGN; B125L 18GY; B125LA 18GY; B125M 16GY; B125N 16GY; B125NB 16GY; B125PA 18GY; B63S 16DKBL; B63T 16DKBL; C125 16GY; C125-G 16WH
See also sheets: CH14_01, CH3_44
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.6. CHILD MONITOR SYSTEM (CONT.), P. 4B / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 27MAR21 / CHAPTER 18 CHILD MONITOR SYSTEM (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B125N 16GY D2 C2 86 30 / REAR DOME RELAY (10311) 87A D1 / 85 C1 / #B125L 18GY / #B125PA 18GY B125LA 18GY / GROUND SPLICE (10010) CH3_44 FUSE F80 (10307) CH3_94Q / #B125M 16GY / DOME LIGHT 2 OUT / CHILD MONITOR DOME LIGHT OUT (11640) / B63S 16DKBL / 85 E1 / B125NB 16GY F2 86 / FRONT DOME RELAY (10311) 87A F1 / E2 30 / DOME LIGHT OUTPUT (10202) / B63T 16DKBL / DOOR SWITCH 2 / CHILD MONITOR DOOR SWITCH INPUT (11641) / B120B 18LTGN / DIODE D79 (10307) B3 / #B117A 18GY / #B117 18GY / EMER EXIT BUZZER SPLICE (10204) CH14_01 / #EMERGENCY EXIT ACTIVATED W/DOME LT W/9 / C125 16GY / POST TRIP NO (10044A) A / C125-G 16WH POST TRIP COM (10045A) / ELEC PANEL/ FRONT CAP (10000) / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 741 / CHILD MONITOR SYSTEM (CONT.)

18.7. CHILD MONITOR SYSTEM (CONT.), P. 4C
Figure 742 CHILD MONITOR SYSTEM (CONT.)

Components: DIODE D76 (10307); DOME LIGHT OUT (11640); FUSE F80 (10307); LIGHT RELAY (10311); OUTPUT (10202); RELAY (10311); SPLICE (10335B); SPLICE (10389)
Wires (circuit gauge+color): B125-GK 18WH; B125-GL 18WH; B125L 18GY; B125P 18GY; B125PA 18GY; B125R 18GY; B125RA 18GY; B131AB 18DKBL; B63N 16DKBL; B63NA 16DKBL; B63NB 16DKBL; B63S 16DKBL; B63T 16DKBL
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.7. CHILD MONITOR SYSTEM (CONT.), P. 4C / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 27MAR21 / CHAPTER 18 CHILD MONITOR SYSTEM (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / C2 30 / B125P 18GY D2 86 / 85 C1 / B125-GL 18WH / 87A D1 / B63S 16DKBL / 85 E1 / F2 86 / 87A F1 / E2 30 / DOME LIGHT OUTPUT (10202) CH8_36A,36B / B63T 16DKBL / 87A B1 / B63N 16DKBL B63NA 16DKBL B2 A2 86 30 / 85 A1 / R ROW DOME RELAY (10311) / B125L 18GY / CHILD MONITOR DOME LIGHT OUT (11640) / DOME LIGHT 2 OUT / FUSE F80 (10307) CH3_94Q / GROUND SPLICE (10335B) CH3_95H / B125-GK 18WH / B125PA 18GY / 16DKBL B63NB / RR DOME LIGHT RELAY (10311) / FR DOME LIGHT RELAY (10311) / B125R 18GY / DIODE D76 (10307) B2 / B125RA 18GY / DOOR OPTION SPLICE (10389) CH8_23A / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / B131AB 18DKBL / DIODE D76 (10307) CH8_23A / Figure 742 / CHILD MONITOR SYSTEM (CONT.)

18.8. CHILD MONITOR SYSTEM (CONT.), P. 4D
Figure 743 CHILD MONITOR SYSTEM (CONT.)

Components: CHILD MONITOR (11642); FUSE F40 (10304); FUSE F54 (10305); GROUND SPLICE (10334); GROUND SPLICE (10336); PTI RELAY (10309); REAR CAP (10405); SPLICE (10335B); STOP ARM (10358B); SWITCH (10480); SWITCH (10481)
Wires (circuit gauge+color): B119 18GY; B11GD 16WH; B11GE 18WH; B125 18GY; B125-GD 18WH; B125A 18GY; B125B 18GY; B125D 18GY; B125F 18GY; B13AA 18PK; B14AA 18RD; B53BA 18GY; D125A 16GY; D125B 16GY; E125A 16GY; E125B 16GY
See also sheets: CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.8. CHILD MONITOR SYSTEM (CONT.), P. 4D / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 27MAR21 / CHAPTER 18 CHILD MONITOR SYSTEM (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CHILD MONITOR (11642) / DEACTIVATE 4 / HORN OUT 6 / &B14AA 18RD B125D 18GY / B125 18GY &B13AA 18PK / B119 18GY / STOP ARM (10358B) CH9_03 / ARM ARM / B125-GD 18WH / B125A 18GY / B125B 18GY / B125F 18GY &B53BA 18GY / PTI RELAY (10309) CH18_4A,44 / FUSE F40 (10304) CH3_94J FUSE F40 (10304) CH3_94J FUSE F54 (10305) CH3_94L FUSE F40 (10304) CH3_94K / LEFT BODY/ REAR CAP (10405) D3 / E125A 16GY / D125B 16GY / ELEC PANEL/ LEFT BODY (@10401A/#10401B /10401) C7 / E125B 16GY / D125A 16GY / GROUND SPLICE (10335B) CH3_95H / PTI RESET SWITCH (10481) / PTI RESET SWITCH A (10480) / &B11GE 18WH / &B11GD 16WH / Figure 743 / CHILD MONITOR SYSTEM (CONT.)

18.9. THEFT MATE PREWIRE SYSTEM, P. 5
Figure 744 THEFT MATE PREWIRE

Components: EXTEND (10358B); FUSE B12-J (10301); FUSE B9-A (10302); L BODY (10400); LEFT BODY (10401); LT RELAY (10311-R2); OUTPUT (11649); OUTPUT (11650); OUTPUT (11651); RED DOT (11642A); RELAY (10309-R4); SPLICE (10335B); YEL DOT (11647)
Wires (circuit gauge+color): B119 18GY; B125-G 18WH; B125AD 18GY; B125AE 18GY; B125AF 18GY; B125B 18GY; B125E 18GY; B125HA 18GY; B125N 18GY; B125P 18GY; B125R 18GY; B14CMA 18RD; B70D 18RD
See also sheets: CH18_07, CH18_37, CH3_12, CH3_19, CH3_38, CH7_23, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.9. THEFT MATE PREWIRE SYSTEM, P. 5 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 04JAN21 / THEFT MATE PREWIRE SYSTEM / CHAPTER 18 / MJV0488 19NOV21 CIRC B125HA WAS B125H B AT CAV 3 OF R/D 11642A. / 5 6 / CHILD CHECK-MATE SYSTEMS EP-2 PLUS / 1 2 3 / B14CMA 18RD / THEFT MATE RED DOT (11642A) / B125-G 18WH / FUSE B9-A (10302) CH3_12 / GROUND SPLICE (10335B) CH3_38 / B125HA 18GY / B119 18GY / B125E 18GY / FUSE B12-J (10301) CH3_19 / STOP ARM EXTEND (10358B) CH9_03 / ELEC PANEL/ LEFT BODY (10401) CH18_37 / B125B 18GY / 1 2 3 / THEFT MATE 5 YEL DOT (11647) / B125AD 18GY / B125AE 18GY / B125AF 18GY / THEFT MATE DIGITAL 1 OUTPUT (11649) / THEFT MATE DIGITAL 2 OUTPUT (11650) / RR DOME LT RELAY (10311-R2) CH18_07 FR DOME LT RELAY (10311-R2) CH18_07 ELEC PANEL/ L BODY (10400) CH7_23,24, 29,30,31 THEFT MATE DIGITAL 3 OUTPUT (11651) / PTI RELAY (10309-R4) CH18_07,10 / B125N 18GY / B125P 18GY B125R 18GY / B70D 18RD / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 744 / THEFT MATE PREWIRE

Figure 745 THEFT MATE PREWIRE SYSTEM (CONT.)

Components: EXTEND (10358B); FRONT DOME (10311); FUSE F40 (10304); FUSE F45 (10304); FUSE F48 (10304); L BODY (10400); LEFT BODY (10401); OUTPUT (11649); OUTPUT (11650); OUTPUT (11651); RED DOT (11642A); RELAY (10309); SPLICE (10335B); YEL DOT (11647)
Wires (circuit gauge+color): B119 18GY; B125-G 18WH; B125AD 18GY; B125AE 18GY; B125AF 18GY; B125B 18GY; B125E 18GY; B125H 18GY; B125N 18GY; B13DJ 12BK; B14CMA 18RD; B70C 18RD; B70D 18RD
See also sheets: CH7_29, CH7_31, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.10. THEFT MATE PREWIRE SYSTEM (CONT.), P. 5A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 27MAR21 / THEFT MATE PREWIRE SYSTEM / CHAPTER 18 / MJV0488 19NOV21 REMOVED @ AND # REFERENCES. / 5 6 / CHILD CHECK-MATE SYSTEMS EP-2 PLUS / 1 2 3 / THEFT MATE RED DOT (11642A) FUSE F40 (10304) B14CMA (B14N) 18RD A2 5A B2 / B125-G 18WH FUSE F48 (10304) B13DJ B125H 12BK 18GY G4 H4 3A / BATT STUD (0PWR) CH3_94J GROUND SPLICE (10335B) CH3_95H FUSE F45 (10304) CH3_94K STOP ARM EXTEND (10358B) CH9_03 PTI HORN RELAY (10309) CH18_7A / B119 18GY / B125E 18GY / ELEC PANEL/ LEFT BODY (10401) CH18_37A / B125B 18GY / 1 2 3 / THEFT MATE 5 YEL DOT (11647) / B125AD 18GY / B125AE 18GY / B125AF 18GY / THEFT MATE DIGITAL 1 OUTPUT (11649) / THEFT MATE DIGITAL 2 OUTPUT (11650) / THEFT MATE DIGITAL 3 OUTPUT (11651) / B125N 18GY / PTI RELAY FRONT DOME (10311) CH18_7A / *B70D 18RD / %B70C 18RD / ELEC PANEL/ L BODY (10400) CH7_29,30,31 ELEC PANEL/ L BODY (10400) CH7_31 / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / % STOP/TAIL/TURN LT W/CHK W/THEFT * STOP/TAIL/TURN LT N/CHK W/THEFT / Figure 745 / THEFT MATE PREWIRE SYSTEM (CONT.)

Figure 746 THEFT MATE PREWIRE SYSTEM (CONT.)

Components: FRONT CAP (10000); FRONT CAP (10001); FUSE B9-G (10302); FUSE F51 (10305); FUSE F54 (10305); LED OUTPUT (11652); MOTION GN DOT (11641A); MOTION SENSOR (10057A); OUTPUT (11641); POST TRIP COM (10045A); POST TRIP NO (10044A); SPLICE (10010); VIO DOT (11648)
Wires (circuit gauge+color): B120B 18LTGN; B125AA 18BK; B125AB 18LTGN; B125AC 18RD; B125AH 20GY; B125C 18GY; B125CMD 18GY; B12HJ 10BK; C125 16GY; C125-G 16WH; C125AA 18BK; C125AB 18LTGN; C125AC 18RD; C125AD 18BK; C125AE 18BK
See also sheets: CH18_01, CH3_16, CH3_44
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.11. THEFT MATE PREWIRE SYSTEM (CONT.), P. 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 04JAN21 / CHAPTER 18 THEFT MATE PREWIRE SYSTEM (CONT.) / MJV0488 19NOV21 COLOR BK WAS PK IN CIRCUIT C125AE. / CHILD CHECK-MATE SYSTEMS / EP-2 PLUS / &B125C 18GY FUSE F54 (10305) H2 G2 3A / GROUND SPLICE (10010) CH3_44 / B125AH 20GY / THEFT MATE LED OUTPUT (11652) / 1 2 / C125AA 18BK / #B125AA #B125AB 18LTGN 18BK / #B125AC 18RD / C125AB 18LTGN / C125AC 18RD / 2 3 / THEFT MATE MOTION GN DOT (11641A) / ELEC PANEL/ FRONT CAP (10001) / CHILD CHECK MOTION SENSOR (10057A) / 1 2 / 1 2 3 / 1 2 / + - / RD BK / ELEC PANEL/ POST TRIP NO C12 FRONT CAP (10044A) (10000) A C125 16GY / C125-G 16WH POST TRIP COM (10045A) / @B125CMD 18GY / THEFT MATE SIGNAL VIO DOT (11648) / C125AD 18BK / C125AE 18BK / FUSE B9-G (10302) CH3_16 FUSE F51 (10305) CH3_94L / *B120B 18LTGN / CHILD MONITOR DOOR SWITCH OUTPUT (11641) CH18_01 / &&B125C 18GY / B12HJ 10BK / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK. / @ W/THEFT MATE PREWIRE SYSTEM # N/SNOOZE * W/CHILD MONITOR SYSTEM & W/0508108 - MTA FUSE BLOCK && N/0508108 - NOT MTA FUSE BLOCK / Figure 746 / THEFT MATE PREWIRE SYSTEM (CONT.)

18.12. THEFT MATE PREWIRE SYSTEM (CONT.), P. 7
Figure 747 THEFT MATE PREWIRE SYSTEM (CONT.)

Components: BODY CONTROLLER (1603); CHASSIS (1700); FUSE B9-B (10302); FUSE B9-H (10302); LIGHT RELAY (10311-R2); LIGHT RELAY (10311-R3); OUTPUT (10202); PLATFORM (1703); PTI RELAY (10309-R4); RED DOT (11642A); YEL DOT (11647)
Wires (circuit gauge+color): A125A 16GY; A125B 16GY; A85 16GY; A85A 16GY; B125AK 16GY; B125BB 16GY; B125E 18GY; B125F 18GY; B125FA 18GY; B125H 16GY; B125J 16GY; B125K 16GY; B125L 16GY; B125M 16GY; B125N 18GY; B125P 18GY; B125R 18GY; B125RB 18GY; B63S 16LTBL; B63T 16LTBL; M11-G 10WH; M11-G 14WH; M85-GA 16GY; M85-GA 16WH; M85-GC 16WH; M85-GD 16WH; M85-GE 16WH; M85A 16GY; M85J 16GY; M85K 16GY; M85L 16GY
See also sheets: CH18_05, CH2_36, CH3_08, CH3_11, CH3_50, CH8_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.12. THEFT MATE PREWIRE SYSTEM (CONT.), P. 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 18 THEFT MATE PREWIRE SYSTEM (CONT.) / B125J 16GY 86 / REAR DOME LIGHT RELAY (10311-R2) / 85 B125P 18GY / B125N 18GY / B125L 16GY / 87A B63S 16LTBL B63T 16LTBL / FRONT DOME LIGHT RELAY (10311-R3) 87A / DOME LIGHT OUTPUT (10202) CH8_35,36 / THEFT MATE YEL DOT (11647) CH18_05 / 87A B125AK 16GY / B125FA 18GY / ELEC PANEL/ PLATFORM (1703) %A85A 16GY B8 @A125B 16GY / B125BB 16GY / B125R 18GY B125M 16GY B125RB 18GY / FUSE B9-B (10302) CH3_11 / B125F 18GY / THEFT MATE RED DOT (11642A) CH18_05 / B125E 18GY / PTI RELAY (10309-R4) / B125H 16GY / B125K 16GY / FUSE B9-H (10302) CH3_08 / %A85 16GY @A125A 16GY J1-12WAY BODY CONTROLLER (1603) ELECTRIC E HORN / PLATFORM/ FORWARD CHASSIS (1700) / @A85 16GY M85A 16GY / HORN (*8310/ &8310A) A / M85-GD 16WH / M85J 16GY M85-GC 16WH ELECTRIC HORN#1 (8311) A M85K 16GY B / M85L 16GY / M85-GE 16WH / ELECTRIC HORN # 2 (8312) A B / M11-G M11-G 14WH 10WH / &M85-GA 16GY M85-GA 16WH / GND UPPER DASH STUD GROUND STUD (2GG) (2GA) CH2_36 CH3_50 / @ W/BUS SCAN/CHILD CHECKMATE % W/PTI/THEFMATE/CHILD CHECKMATE / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 747 / THEFT MATE PREWIRE SYSTEM (CONT.)

18.13. THEFT MATE PREWIRE SYSTEM (CONT.), P. 7A
Figure 748 THEFT MATE PREWIRE SYSTEM (CONT.)

Components: CONTROLLER (1603); FRONT DOME (10311); FUSE F26 (10303); FUSE F41 (10304); FWD CHASIS (1700); OUTPUT (10202); PLATFORM (1703); REAR DOME (10311); RED DOT (11642A); RELAY (10309); YEL DOT (11647)
Wires (circuit gauge+color): A125A 16GY; A125B 16GY; B125A 16GY; B125B 16GY; B125E 18GY; B125F 18GY; B125FA 18GY; B125J 16GY; B125K 16GY; B125L 16GY; B125N 18GY; B125NB 16GY; B125P 18GY; B14H 14BK; B14N 12BK; B63S 16LTBL; B63T 16LTBL
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.13. THEFT MATE PREWIRE SYSTEM (CONT.), P. 7A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 26MAR21 / THEFT MATE PREWIRE (CONT) / CHAPTER 18 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B125K 16GY D2 C2 86 30 / PTI RELAY FRONT DOME (10311) 87A D1 / 85 C1 / B125N 18GY / B125L 16GY / BATT FEED (0PWR) CH3_94G / B63S 16LTBL / 85 E1 / B125NB 16GY F2 86 / PTI RELAY REAR DOME (10311) 87A F1 / DOME LIGHT OUTPUT (10202) / B125P 18GY / B63T 16LTBL / FUSE F26 (10303) B14H B125J 14BK E1 F1 16GY 15A / THEFT MATE YEL DOT (11647) CH18_5A,48 / 87A B3 B125A 16GY / 85 A3 / PTI HORN RELAY (10309) C4 A4 86 30 / B125FA 18GY / ELEC PANEL/ PLATFORM (1703) B8 / A125B 16GY / B125B 16GY / FUSE F41 (10304) B14N B125F 12BK 18GY E2 F2 10A / BATT FEED (0PWR) CH3_94J / THEFT MATE RED DOT (11642A) CH18_5A,48 / B125E 18GY / PLATFORM/ FWD CHASIS (1700) CH18_13A / A125A 16GY / ELECTRIC E HORN / J1-12 WAY BODY CONTROLLER (1603) / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 748 / THEFT MATE PREWIRE SYSTEM (CONT.)

18.14. THEFT MATE PREWIRE SYSTEM WITH SNOOZE, P. 8
Figure 749 THEFT MATE PREWIRE SYSTEM WITH SNOOZE

Components: FUSE B6-N (10303); LIGHT RELAY (10311-R2); LIGHT RELAY (10311-R3); OUTPUT (10202); YELDOT (11647)
Wires (circuit gauge+color): B14CA 14RD; B14DA 18RD; B14E 14RD; B14FA 18RD; B14G 14RD; B63A 18DKBL; B63B 18DKBL; B63C 18DKBL; B63D 14DKBL; B63E 14DKBL
See also sheets: CH18_11, CH3_17, CH8_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.14. THEFT MATE PREWIRE SYSTEM WITH SNOOZE, P. 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 04JAN21 / CHAPTER 18 THEFT MATE PREWIRE SYSTEM W/SNOOZE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 87 87 87A / 86 86 / B63B 18DKBL / B14E 14RD B14G 14RD B14DA 18RD / B14CA 14RD / B63D 14DKBL / B14FA 18RD / 86 86 / 87 87 87A / B63C 18DKBL B63E 14DKBL / B63A 18DKBL / THEFT MATE YELDOT (11647) CH18_11 / REAR DOME LIGHT RELAY (10311-R2) / FRONT DOME LIGHT RELAY (10311-R3) / DOME LIGHT OUTPUT (10202) CH8_35,36 / FUSE B6-N (10303) CH3_17 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK / Figure 749 / THEFT MATE PREWIRE SYSTEM WITH SNOOZE

18.15. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 9
Figure 750 THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.)

Components: BUZZER SPLICE (10204); DOME LIGHT (10230); FR CAP (10000); FUSE B9-A (10302); GROUND SPLICE (10010); GROUND SPLICE (10336); POST TRIP COMM (10045); POST TRIP NO (10044); PTI RELAY (10309-R4); RED DOT (11642A); RELAY (10308-R5); RELAY (10313-R6); SIGNAL VIDEO DOT (11648-2)
Wires (circuit gauge+color): B125-GA 16WH; B125-GE 18WH; B125A 18GY; B125C 18GY; B125HH 18GY; B125HHA 18GY; B130 18GY; B130A 18GY; B130MD 18GY; B14 18RD; B14HA 18RD; B14HB 18RD; B14X 18RD; B63DV 16DKBL; C125 16GY; C125-G 16WH
See also sheets: CH14_01, CH18_10, CH18_11, CH18_12, CH3_12, CH3_39, CH3_44, CH8_13
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.15. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 9 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 04JAN21 / CHAPTER 18 THEFT MATE PREWIRE SYSTEM W/SNOOZE (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 87 87 87A / 86 86 / B125-GE 18WH / B14X 18RD / B14 18RD / B14HB 18RD / 86 86 / 87 87 87A / B125HH 18GY / B125HHA 18GY / CHILD MONITOR RELAY (10313-R6) 85 / B125-GA 16WH / GROUND SPLICE (10336) CH3_39 THEFT MATE SIGNAL VIDEO DOT (11648-2) CH18_12 / B14HA 18RD / CHILD MONITOR RELAY (10308-R5) / FUSE B9-A (10302) CH3_12 / B130A 18GY / B125C 18GY / B130MD 18GY / ELEC PANEL/ FR CAP (10000) C12 / POST TRIP NO (10044) A C125 16GY / POST TRIP COMM (10045) A C125-G 16WH / GROUND SPLICE (10010) CH3_44 / PTI RELAY (10309-R4) CH18_10 / B130 18GY / EMER EXIT BUZZER SPLICE (10204) CH14_01 / B125A 18GY / THEFT MATE RED DOT (11642A) CH18_11 / STD/FRONT DOME LIGHT (10230) CH8_13 / B63DV 16DKBL / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 750 / THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.)

18.16. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 10
Figure 751 THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.)

Components: FUSE B9-B (10302); FUSE B9-W (10302); PLATFORM (1703); RED DOT (11642A); RELAY (10309-R4); RELAY (10309-R5); RELAY (10309-R6); RELAY (10313-R6); SPLICE (10336)
Wires (circuit gauge+color): B125-GA 16WH; B125A 18GY; B125E 18GY; B125HHA 18GY; B125HLA 18GY; B125HRA 18GY; B14C 14RD; B14CZ 14RD; B14FX 14RD; B14H 14RD; B53B-G 18WH; B53C-G 18WH; B85A-G 18WH; B85D 14GY; B85E 14GY; B85X 14GY
See also sheets: CH18_05, CH18_09, CH3_08, CH3_11, CH3_39, CH7_60
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.16. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 10 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 04JAN21 / CHAPTER 18 THEFT MATE PREWIRE SYSTEM W/SNOOZE (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 87 87 87A / 86 86 / B85A-G 18WH B14CZ 14RD / FUSE B9-W (10302) CH3_08 / B125A 18GY / B125HHA 18GY / CHILD MONITOR RELAY (10313-R6) CH18_09 / B85E 14GY / B14H 14RD / B85D 14GY / B125HLA 18GY / 86 86 / 87 87 87A / B53B-G 18WH / B14C 14RD / 87 87 87A / B53C-G 18WH / 86 86 / B125HRA 18GY / B125-GA 16WH / GROUND SPLICE (10336) CH3_39 / B85X 14GY / FUSE B9-B (10302) CH3_11 / B14FX 14RD / B53E 16YL / B53D 16YL / B53H 16YL / B53G 14YL / ELEC PANEL/ PLATFORM (1703) CH7_60 / ELEC PANEL/ PLATFORM (1703) CH7_60 / ELEC PANEL/ PLATFORM (1703) CH7_60 / PTI RELAY (10309-R4) / PTI RELAY (10309-R5) / PTI RELAY (10309-R6) / THEFT MATE RED DOT (11642A) CH18_05 / B125E 18GY / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 751 / THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.)

18.17. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 11
Figure 752 THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.)

Components: BRAKE CCM (9556); FUSE B12-K (10301); FUSE B9-A (10302); LEFT BODY (10401); LIGHT RELAY (10311-R2); LIGHT RELAY (10311-R3); OUTPUT (11649); OUTPUT (11650); PLATFORM (1702); REAR CAP (10405); RED DOT (11642A); RELAY (10313-R6); SNOOZE ON (11337); SPLICE (10336); YEL DOT (11647)
Wires (circuit gauge+color): A14PK 18RD; A44 18GY; B101 18TN; B125-G 18WH; B125-GA 16WH; B125AE 18GY; B125AF 18GY; B125D 18GY; B125HH 18GY; B13A 18PK; B14 18RD; B14A 18RD; B14F 18RD; B60B 18OR; B63A 18DKBL; B63B 18DKBL; B63C 18DKBL; E125A 16GY
See also sheets: CH18_08, CH18_09, CH18_23, CH18_37, CH18_39, CH3_12, CH3_18, CH3_39
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.17. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 11 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 05JAN21 / CHAPTER 18 THEFT MATE PREWIRE SYSTEM W/SNOOZE (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 5 6 / CHILD CHECK-MATE SYSTEMS EP-2 PLUS / 1 2 3 / THEFT MATE RED DOT (11642A) / B125-G 18WH / GROUND SPLICE (10336) CH3_39 / B13A 18PK ELEC PANEL/ LEFT BODY (10401) C7 / B60B 18OR / B125HH 18GY / FUSE B12-K (10301) CH3_18 / CA 2018 SNOOZE ON (11337) CH18_23 CHILD MONITOR RELAY (10313-R6) CH18_09 / LEFT BODY/ REAR CAP (10405) CH18_37 / B125D 18GY / 1 2 3 / THEFT MATE 5 YEL DOT (11647) / B125AE 18GY / B125AF 18GY / THEFT MATE DIGITAL 1 OUTPUT (11649) / THEFT MATE DIGITAL 2 OUTPUT (11650) / B14A 18RD / ELEC PANEL/ PLATFORM (1702) 45 *A14PK B14F 18RD 18RD / B14 18RD / FUSE B9-A (10302) CH3_12 / AIR PARK BRAKE CCM (9556) CH18_39 / B125-GA 16WH / E125A 16GY / B63A 18DKBL / B101 18TN / ELEC PANEL/ PLATFORM (1702) 44 / B63B 18DKBL / REAR DOME LIGHT RELAY (10311-R2) CH18_08 / B63C 18DKBL / FRONT DOME LIGHT RELAY (10311-R3) CH18_08 / AIR PARK BRAKE CCM (9556) CH18_39 / *A44 18GY / *
W/F-2018-PROPANE/GASOLINE-ENGINE / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 752 / THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.)

Figure 753 THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.)

Components: FR CAP (10000); FRONT CAP (10001); FUSE B9-G (10302); LED OUTPUT (11652); MOTION GN DOT (11641A); MOTION SENSOR (10057A); VIO DOT (11648)
Wires (circuit gauge+color): B125C 18GY; B125H 18GY; B125MA 18GY; B125MB 18GY; B125MC 18GY; B12A 18LTBL; B130MD 18GY; C125AA 18BK; C125AB 18LTGN; C125AC 18RD; C125AD 18BK; C125AE 18PK
See also sheets: CH18_09
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.18. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 12 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 05JAN21 / CHAPTER 18 THEFT MATE PREWIRE SYSTEM W/SNOOZE (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CHILD CHECK-MATE SYSTEMS / EP-2 PLUS / 1 2 / C125AA 18BK / B125MA B125MB 18GY 18GY / B125MC 18GY / C125AB 18LTGN / C125AC 18RD / 2 3 / THEFT MATE MOTION GN DOT (11641A) / ELEC PANEL/ FRONT CAP (10001) / CHILD CHECK MOTION SENSOR (10057A) / 1 2 / 1 2 3 / 1 2 / + - / RD BK / THEFT MATE SIGNAL VIO DOT (11648) / C125AD 18BK / C125AE 18PK / B125H 18GY / B125C 18GY / ELEC PANEL/ FR CAP (10000) CH18_09 / B12A 18LTBL / FUSE B9-G (10302) CH3_XX / B130MD 18GY / THEFT MATE LED OUTPUT (11652) / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 753 / THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.)

18.19. CHILD CHECK MATE SYSTEM, P. 13
Figure 754 CHILD CHECK MATE SYSTEM

Components: BODY CONTROLLER (1603); BUZZER SPLICE (10204); CHASSIS (1700); ELEC PANEL (1703); ELEC PANEL/LEFT BODY (10401); EXTEND (10358B); FUSE B9-A (10302); FUSE B9-G (10302); GROUND SPLICE (10335B); L BODY (10400); MODULE (10212); RELAY (10309-R4)
Wires (circuit gauge+color): A85 16GY; A85A 16GY; B119 18GY; B125 18GY; B125-G 18WH; B125B 18GY; B125C 18GY; B125D 18GY; B125E 18GY; B125F 18GY; B125FA 16GY; B125H 16GY; B125J 18GY; B70C 18RD; B85 16GY; B85A 16GY; M11-G 10WH; M11-G 14WH; M85-GA 16GY; M85-GA 16WH; M85-GC 16WH; M85-GD 16WH; M85-GE 16WH; M85A 16GY; M85J 16GY; M85K 16GY; M85L 16GY
See also sheets: CH14_01, CH18_14, CH2_36, CH3_12, CH3_16, CH3_38, CH3_50, CH7_21, CH7_60, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.19. CHILD CHECK MATE SYSTEM, P. 13 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHILD CHECK MATE SYSTEM / CHAPTER 18 / MJV0488 19NOV21 CIRC B125FA WAS B125F B AT R/D 10309-R4. / B125B 18GY / PLATFORM/ ELEC PANEL (1703) B8 / 1 6 5 4 3 2 / CHILD CHECK-MATE SYSTEMS INC / AND CHECK! / B125D 18GY B125E 18GY / B125-G B125 18GY 18WH / B125C 18GY EXTEND (10358B) CH9_03 ARM PANEL/ BODY (10400) CH7_21,27 STOP L ELEC / %B119 18GY B70C 18RD / GROUND SPLICE (10335B) CH3_38 / FUSE B9-G (10302) CH3_16 / PTI RELAY (10309-R4) 86 86 30 / EMERGENCY EXIT BUZZER SPLICE (10204) CH14_01 ELEC PANEL/LEFT BODY (10401) CH18_14 / 85 B85 16GY / B125F 18GY / B125FA 16GY B85A 16GY / J1-12WAY BODY CONTROLLER (1603) ELECTRIC HORN E / PLATFORM/ FORWARD CHASSIS (1700) / M85A 16GY HORN (*8310/ @8310A) A / CHECK MATE MODULE (10212) / A85A 16GY / M85J 16GY M85-GC 16WH / M85L 16GY / M85-GE 16WH / ELECTRIC HORN#1 (8311) A M85K 16GY B M85-GD 16WH / ELECTRIC HORN # 2 (8312) A B / A85 16GY / &M85-GA 16WH / &M11-G &M11-G 10WH 14WH / GROUND STUD GROUND (2GA) STUD (2GG) CH3_50 CH2_36 NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / 87 87 87A / B125J 18GY / #M85-GA #M85-GA 16WH 16GY / B85A 16GY / PLATFORM/ ELEC PANEL (1703) CH7_60 / B125H 16GY / FUSE B9-A (10302) CH3_12 / Figure 754 / CHILD CHECK MATE SYSTEM

18.20. CHILD CHECK MATE SYSTEM (CONT.), P. 13A
Figure 755 CHILD CHECK MATE SYSTEM (CONT.)

Components: BODY CONTROLLER (1603); BUZZER SPLICE (10204); CHASSIS (1700); ELEC PANEL (1703); ELEC PANEL/LEFT BODY (10401A/B/10401); FUSE F40 (10304); FUSE F54 (10305); GROUND SPLICE (10335B); MODULE (10212); PTI RELAY (10309)
Wires (circuit gauge+color): A125A 16GY; A125B 16GY; A85 16GY; B119 18GY; B125 18GY; B125-G 18WH; B125B 16GY; B125B 18GY; B125C 18GY; B125D 18GY; B125E 18GY; B125F 18GY; B125H 16GY; B125J 18GY; B70C 18RD; B85A 16GY; B85B 16GY; M11-G 10WH; M11-G 14WH; M85-GA 16WH; M85-GC 16WH; M85-GD 16WH; M85-GE 16WH; M85A 16GY; M85J 16GY; M85K 16GY; M85L 16GY
See also sheets: CH18_04, CH7_18, CH7_21, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.20. CHILD CHECK MATE SYSTEM (CONT.), P. 13A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 26MAR21 / CHAPTER 18 CHILD CHECK MATE SYSTEM (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B125D 18GY B125H 16GY / B3 87A / B125B 18GY / PLATFORM/ ELEC PANEL (1703) B7 / 30 86 C4 A4 PTI RELAY (10309) / #B119 18GY %B70C 18RD B125E 18GY ARM EXTEND(10358B) CH9_03 SPLICE CH7_18,18A CH7_21,27 STOP LT STOP A3 85 / 1 6 5 4 3 2 / CHILD CHECK-MATE SYSTEMS INC / AND CHECK! / B125-G B125 18GY 18WH / B125C 18GY / GROUND SPLICE (10335B) CH3_95H / * W/DISC STYLE HORN SIGNAL & W/HORN ABOVE FRAME SIGNAL @ N/POST TRIP INSPECTION % W/STOP/TAIL/TURN LT # W/ARMED BY PUPIL WARN LT / EMERGENCY EXIT BUZZER SPLICE (10204) CH14_1A ELEC PANEL/LEFT BODY (10401A/B/10401) CH18_04 CH18_37A / FUSE F40 (10304) CH3_94J J1-12WAY BODY CONTROLLER (1603) ELECTRIC HORN E / B85B 16GY / B85A 16GY / B125B 16GY B125F 18GY / B125J 18GY / PLATFORM/ FORWARD CHASSIS (1700) / M85A 16GY HORN (*8310/ &8310A) A / CHECK MATE MODULE (10212) / A125B 16GY / @A85 16GY / M85J 16GY M85-GC 16WH / M85L 16GY / M85-GE 16WH NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / ELECTRIC HORN#1 (8311) A M85K 16GY B M85-GD 16WH / ELECTRIC HORN # 2 (8312) A B / A125A 16GY / M85-GA 16WH / M11-G M11-G 14WH 10WH / UPPER DASH GROUND STUD (2GA) / PTI HORN RELAY CH3_94L / FUSE F54 (10305) CH3_94L / Figure 755 / CHILD CHECK MATE SYSTEM (CONT.)

18.21. CHILD CHECK MATE SYSTEM WITH PTI DEACTIVATION SWITCH IN LIGHT BAR, P. 14
Figure 756 CHILD CHECK MATE SYSTEM WITH PTI DEACTIVATION SWITCH IN LIGHT BAR

Components: CHECKMATE (10339); FUSE B9-B (10302); FUSE F41 (10304); GROUND SPLICE (10160); MODULE (10212); REAR CAP (10405); REAR SWITCH (10513/10513A); SWITCH (10178A); SWITCH (10178B)
Wires (circuit gauge+color): B125 18GY; B125A 18GY; B125B 18GY; B125C 18GY; D125-G 16WH; D125A 16GY; D125B 16GY; E125A 16GY; E125B 16GY
See also sheets: CH18_13, CH18_18, CH3_11, CH3_45
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.21. CHILD CHECK MATE SYSTEM WITH PTI DEACTIVATION SWITCH IN LIGHT BAR, P. 14 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 CHILD CHECK MATE SYSTEM W/PTI DEACTIVATION SWITCH IN LT BAR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CA 2018 CHECKMATE (10339) CH18_18,22, 22A FUSE B9-B (10302) CH3_11 FUSE F41 (10304) CH3_94K CHECKMATE MODULE (10212) CH18_13,13A / ELEC PANEL/ LEFT BODY LEFT BODY / (@10401A/%10401B REAR CAP /10401) (10405) C7 D3 / !B125A 18GY !!B125A 18GY / B125B 18GY / E125A 16GY / E125B 16GY GROUND SPLICE (10160) CH3_45 / PTI STOP REAR SWITCH (10513/10513A) A *D125A 16GY #D125A 16GY / D125B 16GY / D125-G 16WH / MITTER TRANS / PTI STOP SWITCH / B125C 18GY / B125 18GY / SC SC / STOP and check! / PTI DEACTIVATION SWITCH (10178A) / &D125B 16GY / &D125A 16GY / PTI DEACTIVATION SWITCH (10178B) / Figure 756 / CHILD CHECK MATE SYSTEM WITH PTI DEACTIVATION SWITCH IN LIGHT BAR

18.22. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR AND WITH LIFT, P. 15
Figure 757 CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR AND

Components: CHECKMATE OR (11341); FUSE B6-N (10303); LIGHT RELAY (10311-R2); OUTPUT (10202)
Wires (circuit gauge+color): B125DM 18GY; B125DMA 18GY; B125DMB 18GY; B14DM 14RD; B14DMA 18RD; B14DMB 14RD; B14DMC 14RD; B14DMD 18RD; B63C 14DKBL; B63D 14DKBL
See also sheets: CH3_17
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.22. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR AND WITH LIFT, P. 15 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 CHILD CHECK MATE SYSTEM W/SNOOZE W/EMERGENCY EXIT ACTUATOR W/LIFT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 86 86 / 87 87 87A / B125DMA 18GY B14DMD 18RD / B14DMB 14RD B14DMC 14RD B14DMA 18RD / B14DM 14RD / B63C 14DKBL / 86 86 / 87 87 87A / B125DMB 18GY B63D 14DKBL / B125DM 18GY / REAR DOME LIGHT RELAY (10311-R2) / FUSE B6-N (10303) CH3_17 / CA 2018 CHECKMATE OR (11341) / DOME LIGHT OUTPUT (10202) ch8_35,36 / FRONT DOME LIGHT RELAY (10311-R2) / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 757 / CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR AND WITH LIFT

18.23. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR
Figure 758 CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR AND WITH

Components: FUSE B9-B (10302); FUSE B9-W (10302); PLATFORM (1703); PTI RELAY (10309-R4); PTI RELAY (10309-R5); PTI RELAY (10309-R6); RELAY (10313-R6); SPLICE (10336)
Wires (circuit gauge+color): B125-GA 10WH; B125A 18GY; B125HHA 18GY; B125HLA 18GY; B125HRA 18GY; B14H 14RD; B14HL 14RD; B14HR 14RD; B14K 14RD; B14X 14RD; B53-GHA 18WH; B53-GHB 18WH; B85-GH 18WH; B85S 14GY; B85T 14GY
See also sheets: CH18_17, CH3_08, CH3_11, CH3_39, CH7_60
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.23. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR AND WITH LIFT (CONT.), P. 16 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 CHILD CHECK MATE SYSTEM W/SNOOZE W/EMERGENCY EXIT ACTUATOR W/LIFT (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 87 87 87A / 86 86 / B85-GH 18WH / FUSE B9-W (10302) CH3_08 / B125A 18GY / B125HHA 18GY / CHILD MONITOR RELAY (10313-R6) CH18_17 / B85T 14GY / B14H 14RD / B14K 14RD / B85S 14GY / B125HLA 18GY / 86 86 / 87 87 87A / B53-GHA 18WH / B14HL 14RD / 87 87 87A / B53-GHB 18WH / 86 86 / B125HRA 18GY / B125-GA 10WH / GROUND SPLICE (10336) CH3_39 / B14X 14RD / FUSE B9-B (10302) CH3_11 / B14HR 14RD / B53E 16YL / B53C 16YL / B53F 16YL / B53D 14YL / ELEC PANEL/ PLATFORM (1703) CH7_60 / ELEC PANEL/ PLATFORM (1703) CH7_60 / PTI RELAY (10309-R4) / PTI RELAY (10309-R5) / PTI RELAY (10309-R6) / ELEC PANEL/ PLATFORM (1703) CH7_60 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 758 / CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR AND WITH LIFT (CONT.)

18.24. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR
Figure 759 CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR AND WITH

Components: BUZZER SPLICE (10204); CHECK MATE VL (11340); CHECKMATE (10339); FRONT CAP (10000); FUSE B9-A (10302); LIFT SPLICE (10370); POST TRIP COM (10045); POST TRIP NO (10044); PTI RELAY (10309-R4); RELAY (10308-R5); RELAY (10310-R2); RELAY (10313-R4); RELAY (10313-R6); SPLICE (10010); SPLICE (10336)
Wires (circuit gauge+color): B122 18GY; B122A 18GY; B125-GA 10WH; B125-GE 14WH; B125-GL 14WH; B125C 18GY; B125HH 18GY; B125HHA 18GY; B12AB 18LTBL; B130 18GY; B130A 18GY; B130MD 18GY; B14 18RD; B14EE 18RD; B14HA 18RD; B14HB 18RD; B14L 18RD; C125 16GY; C125-G 16WH
See also sheets: CH14_01, CH15_31, CH18_16, CH18_18, CH3_12, CH3_39, CH3_44
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.24. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR AND WITH LIFT (CONT.), P. 17 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 CHILD CHECK MATE SYSTEM W/SNOOZE W/EMERGENCY EXIT ACTUATOR W/LIFT (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B14L 18RD / B14 18RD / B125-GA 10WH / FUSE B9-A (10302) CH3_12 GROUND SPLICE (10336) CH3_39 / B122A 18GY / PTI RELAY (10309-R4) CH18_16 / B122 18GY / CHILD MONITOR RELAY (10313-R6) 85 / B125HHA 18GY / CHILD MONITOR RELAY (10308-R5) 85 B130 18GY / B14HA 18RD / B125HH 18GY / B14HB 18RD B14EE 18RD / LIFT SPLICE (10370) CH15_31 / B125C 18GY / B12AB 18LTBL B130MD 18GY / B125-GE 14WH / GROUND SPLICE (10336) CH3_39 / CA 2018 CHECK MATE VL (11340) / CHILD CHECKMATE RELAY (10310-R2) CH18_18 / GROUND SPLICE (10010) CH3_44 / ELEC PANEL/ POST TRIP NO C12 FRONT CAP (10044) (10000) A C125 16GY / C125-G 16WH POST TRIP COM (10045) / B125-GL 14WH / B125-GA 10WH / B130A 18GY / CA 2018 CHECKMATE (10339) CH18_18 / EMER EXIT BUZZER SPLICE (10204) CH14_01 / CHILD CHECK RELAY (10313-R4) / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 759 / CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR AND WITH LIFT (CONT.)

18.25. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR
Figure 760 CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR AND WITH

Components: BRAKE CCM (9556); CHECKMATE (10339); CHECKMATE GN (11342); CHECKMATE VL (11340); FUSE B12-K (10301); FUSE B9-A (10302); FUSE B9-G (10302); L BODY (10401); PLATFORM (1702); RELAY (10310-R2); RELAY (10313-R6); SNOOZE ON (11337); SPLICE (10336)
Wires (circuit gauge+color): A44 16GY; B101 18TN; B12 18LTBL; B12-G 18WH; B125 18GY; B125-GA 10WH; B125-GM 18WH; B125HH 18GY; B12A 18LTBL; B12AA 18LTBL; B12AB 18LTBL; B13 18PK; B14 18RD; B14A 18RD; B60 18OR
See also sheets: CH18_14, CH18_17, CH18_23, CH18_39, CH3_12, CH3_16, CH3_18, CH3_39
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.25. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR AND WITH LIFT (CONT.), P. 18 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 CHILD CHECK MATE SYSTEM W/SNOOZE W/EMERGENCY EXIT ACTUATOR W/LIFT (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 18LTBL B12 86 / CHILD CHECKMATE RELAY (10310-R2) 87A / B12A 18LTBL / B12AB 18LTBL / FUSE B9-G (10302) CH3_16 / CA 2018 CHECKMATE VL (11340) CH18_17 / B12-G 18WH / 18LTBL B12AA / GROUND SPLICE (10336) CH3_39 / B60 18OR / B125HH 18GY / FUSE B9-A (10302) CH3_12 / B14A 18RD / ELEC PANEL/ L BODY (10401) CH18_14,37 / CA 2018 CHECKMATE (10339) / B13 18PK / CHILD MONITOR RELAY (10313-R6) CH18_17 / FUSE B12-K (10301) CH3_18 / B125 18GY / CA 2018 SNOOZE ON (11337) CH18_23 / B125-GA 10WH / B125-GM 18WH / B14 18RD / B101 18TN / CA 2018 CHECKMATE GN (11342) / ELEC PANEL/ PLATFORM (1702) 44 / A44 16GY / AIR PARK BRAKE CCM (9556) CH18_39 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 760 / CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR AND WITH LIFT (CONT.)

18.26. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT LIFT, P. 19
Figure 761 CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT

Components: BRAKE CCM (9556); CHECKMATE GN (11342); CHECKMATE OR (11341); FUSE B6-N (10303); LIGHT RELAY (10311-R2); LIGHT RELAY (10311-R3); OUTPUT (10202); PLATFORM (1702)
Wires (circuit gauge+color): A44 16GY; B101 18TN; B63 18DKBL; B63A 16DKBL; B63B 16DKBL; B63C 16DKBL; B63D 16DKBL; B63E 14RD; B63F 14RD; B63G 14RD; B63H 14RD; B63J 14RD
See also sheets: CH18_39, CH3_17
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.26. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT LIFT, P. 19 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 CHILD CHECK MATE SYSTEM W/SNOOZE W/EMERGENCY EXIT ACTUATOR N/ LIFT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 87 87 87A / 86 86 / B63A 16DKBL B63H 14RD / B63G 14RD B63J 14RD B63F 14RD / B63E 14RD / B63C 16DKBL / 86 86 / 87 87 87A / B63B 16DKBL B63D 16DKBL / B63 18DKBL / CA 2018 CHECKMATE OR (11341) / REAR DOME LIGHT RELAY (10311-R2) / FRONT DOME LIGHT RELAY (10311-R3) / DOME LIGHT OUTPUT (10202) ch8_35,36 / FUSE B6-N (10303) CH3_17 / B101 18TN / CA 2018 CHECKMATE GN (11342) / ELEC PANEL/ PLATFORM (1702) 44 / A44 16GY / AIR PARK BRAKE CCM (9556) CH18_39 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 761 / CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT LIFT

18.27. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR
Figure 762 CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT

Components: CHECK MATE (10339); FUSE B9-A (10302); FUSE B9-B (10302); FUSE B9-W (10302); PLATFORM (1703); PTI RELAY (10309-R4); PTI RELAY (10309-R5); PTI RELAY (10309-R6)
Wires (circuit gauge+color): B14 18RD; B14A 18RD; B14B 18RD; B14H 14RD; B14K 14RD; B53A 14RD; B53B 14RD; B53G 18RD; B53H 18RD; B85 18GY; B85CK 18GY; B85ER 18GY; B85FU 18GY; B85S 14GY; B85T 14GY; B85X 14RD
See also sheets: CH18_22, CH3_08, CH3_11, CH3_12, CH7_36, CH7_60
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.27. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT LIFT (CONT.), P. 20 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 CHILD CHECK MATE SYSTEM W/SNOOZE W/EMERGENCY EXIT ACTUATOR N/ LIFT (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PTI RELAY (10309-R4) / B14B B14B 18RD 18RD / B14A 18RD / B14 18RD / CA 2018 CHECK MATE (10339) CH18_22 / FUSE B9-A (10302) CH3_12 ELECTRICAL PANEL /PLATFORM (1703) CH7_36 / B85T 14GY / B85FU 18GY / B85 18GY / ELECTRICAL PANEL /PLATFORM (1703) CH7_60 / B85S 14GY B53E 16YL B53C 16YL / B14H 14RD / B14K 14RD / FUSE B9-W (10302) CH3_08 / PTI RELAY (10309-R5) / PTI RELAY (10309-R6) / B53F 16YL / B53D 14YL / B53G 18RD / B85CK 18GY / B53A 14RD / B53H 18RD / B85ER 18GY B53B B53B 14RD 14RD B85X 14RD NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / FUSE B9-B (10302) CH3_11 / CA 2018 CHECK MATE (10339) CH18_22 / Figure 762 / CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT LIFT (CONT.)

18.28. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR
Figure 763 CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT

Components: BUZZER SPLICE (10204); CHECKMATE VL (11340); DIODE B6-J (10303); DIODE D61 (10306); FRONT CAP (10000); FUSE B9-G (10302); FUSE F54 (10305-H2); POST TRIP COM (10045A); POST TRIP NO (10044A); RELAY (10310-R2); SPLICE (10010)
Wires (circuit gauge+color): B12 18LTBL; B125C 18GY; B12AB 18LTBL; B130 18GY; B130A 18GY; C125 16GY; C125-G 16WH
See also sheets: CH14_01, CH3_16, CH3_44
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.28. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT LIFT (CONT.), P. 21 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 CHILD CHECK MATE SYSTEM W/SNOOZE W/EMERGENCY EXIT ACTUATOR N/ LIFT (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B130A 18GY / B12 18LTBL / CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. CA 2018 CHECKMATE VL (11340) / FUSE B9-G (10302) CH3_16 / DIODE B6-J (10303) 17 21 / B130 18GY / EMERGENCY EXIT BUZZER SPLICE (10204) CH14_01 / B125C 18GY / GROUND SPLICE (10010) CH3_44 / C125 16GY / POST TRIP NO (10044A) A / C125-G 16WH POST TRIP COM (10045A) / ELEC PANEL/ FRONT CAP (10000) / B125C 18GY / CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. CA 2018 CHECKMATE VL (11340) / EMERGENCY EXIT BUZZER SPLICE (10204) CH14_1A / B130 18GY / B130A 18GY / B12 18LTBL / FUSE F54 (10305-H2) CH3_94L / DIODE D61 (10306) / GROUND SPLICE (10010) CH3_44 / ELEC PANEL/ POST TRIP NO FRONT CAP C12 (10044A) (10000) A C125 16GY / C125-G 16WH POST TRIP COM (10045A) / B12AB 18LTBL / CHILD CHECKMATE RELAY (10310-R2) CH18_42C / Figure 763 / CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT LIFT (CONT.)

18.29. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR
Figure 764 CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT

Components: CHECKMATE (10339); ELEC PANEL/L BODY (10401A/B/10401); FUSE B12-K (10301); GROUND SPLICE (10336); PTI RELAY (10309-R4); REAR CAP (10405); SNOOZE ON (11337)
Wires (circuit gauge+color): B125 18GY; B125-G 18WH; B125-GA 14WH; B13 18PK; B14A 18RD; B60 18OR; B85 18GY; B85FU 18GY; E125A 16GY
See also sheets: CH18_14, CH18_20, CH18_23, CH3_18, CH3_39
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.29. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT LIFT (CONT.), P. 22 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 CHILD CHECK MATE SYSTEM W/SNOOZE W/EMERGENCY EXIT ACTUATOR N/ LIFT (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B14A 18RD / CA 2018 CHECKMATE (10339) / B13 18PK / PTI RELAY (10309-R4) CH18_20 / GROUND SPLICE (10336) CH3_39 / B125-G 18WH / FUSE B12-K (10301) CH3_18 / B125 18GY / B60 18OR / CA 2018 SNOOZE ON (11337) CH18_23 / B85FU 18GY / B85 18GY / PTI RELAY (10309-R4) CH18_20 / ELEC PANEL/L BODY (10401A/B/10401) C7 / E125A 16GY / L BODY/ REAR CAP (10405) CH18_14 / B125-GA 14WH / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 764 / CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT LIFT (CONT.)

18.30. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR
Figure 765 CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT

Components: CHECKMATE (10339); ELEC PANEL/L BODY (10401A/B/10401); FUSE F44 (10304); HAZZARD ASSERT (11338); PTI RELAY (10309); REAR CAP (10405); RELAY (10312); SNOOZE ON (11337)
Wires (circuit gauge+color): B125 18GY; B125-G 18WH; B125-GM 18WH; B125HH 18GY; B13 18PK; B14A 18RD; B60 18OR; B85 18GY; C125A 16GY
See also sheets: CH18_14, CH18_23, CH18_43
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.30. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT LIFT (CONT.), P. 22A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 27MAR21 / CHAPTER 18 CHECKMATE W/SNOOZE W/EMER ACTUATOR N/LIFT (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / @B14A 18RD / *B14A 18RD / CA 2018 CHECKMATE (10339) / B13 18PK / STEP WARMER RELAY (10312) CH18_42B / PTI RELAY (10309) CH18_43 STEP WARMER RELAY (10312) CH18_42B INPOWER HAZZARD ASSERT (11338) CH18_23 FUSE F44 (10304) CH3_94K / *B125-GM 18WH / @B125-G 18WH / B125 18GY / B60 18OR / L BODY/ REAR CAP (10405) CH18_14 CA 2018 SNOOZE ON (11337) CH18_23 STEP WARMER RELAY (10312) CH18_42B PTI RELAY (10309) CH18_43 / *B125HH 18GY / @B85 18GY / ELEC PANEL/L BODY (10401A/B/10401) C7 / C125A 16GY / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / * W/SNOOZE N/LIFT @ W/SNOOZE W/LIFT / Figure 765 / CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT LIFT (CONT.)

18.31. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR
Figure 766 CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT

Components: ASSERT (11338); BODY CONTROLLER (1603); CA 2018 CHECKMATE (10339); CA 2018 CHECKMATE (11337); CONNECTER C (10025C); FUSE B9-W (10302); FUSE F26 (10303-F1); LT SPLICE (11601); PTI RELAY (10309); SEON SIGNALS (11644); SPLICE (10336); SPLICE BLOCK (11502); THEFT MATE RED DOT (11642A)
Wires (circuit gauge+color): B125-G 18WH; B125-GA 14WH; B125-GA 16WH; B14H 14RD; B14K 14RD; B14P 14RD; B14P 16RD; B14XA 16RD; B56H 16OR; B57C 16LTGN; B57H 16LTGN; B57H 16OR; B60 18OR; B60-G 16WH; B60A 18OR; B60B 18OR; B60H 18OR; B89 18OR
See also sheets: CH18_45, CH3_08, CH3_39, CH7_28, CH7_34
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.31. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT LIFT (CONT.), P. 23 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. CA 2018 CHECKMATE (11337) / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 CHILD CHECK MATE SYSTEM W/SNOOZE W/EMERGENCY EXIT ACTUATOR N/ LIFT (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B89 18OR / *B60B 18OR W/CHECKMATE & LIFT @B60 18OR @B60H 18OR *B60A 18OR / STOP ARM WARNING LT SPLICE (11601) CH9_2A THEFT MATE RED DOT (11642A) CH18_45 CA 2018 CHECKMATE (10339) CH18_22A,42C / *B14XA 16RD #B14P 16RD @B14P 14RD B60-G 16WH / FUSE F26 (10303-F1) CH3_94G FUSE B9-W (10302) CH3_08 / &B14H 14RD / INPOWER HAZARD ASSERT (11338) / *B125-GA 16WH @B125-G 18WH #B125-GA 14WH / @B57H 16OR / B57H 16LTGN **B56C 16YL @B56H 16OR B56H 16YL / CCM/TM GND SPLICE BLOCK (11502) CH18_45E LT MONITOR CONNECTER C (10025C) CH7-20 J1-12 WAY BODY CONTROLLER (1603) CH7_34 / *B60-G 16WH / **B57C 16LTGN / SEON SIGNALS (11644) CH7_28 / &&B14H 14RD / &&B14K 14RD / GROUND SPLICE (10336) CH3_39 / PTI RELAY (10309) CH18_42A / Figure 766 / CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACTUATOR WITHOUT LIFT (CONT.)

18.32. CHILD CHECKMATE SYSTEM WITH ENTRANCE DOOR WITH EMERGENCY EXIT ACT, P. 24
Figure 767 CHILD CHECKMATE SYSTEM WITH ENTRANCE DOOR WITH EMERGENCY EXIT ACT

Components: FUSE B9-A (10302); FUSE B9-B (10302); FUSE B9-W (10302); MONITOR (11642); PLATFORM (1703); RELAY (10309-R4); RELAY (10309-R5); RELAY (10309-R6)
Wires (circuit gauge+color): B14AB 18RD; B14AC 18RD; B14AD 18RD; B14AE 18RD; B14BA 14RD; B14BB 16RD; B14BC 14RD; B14CA 14RD; B53BA 18GY; B53BB 18GY; B53BC 18GY; B53BD 18GY; B85AA 14GY; B85AB 14GY
See also sheets: CH18_26, CH3_08, CH3_11, CH3_12, CH7_60
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.32. CHILD CHECKMATE SYSTEM WITH ENTRANCE DOOR WITH EMERGENCY EXIT ACT, P. 24 / CHAPTER 18 CHILD CHECKMATE SYSTEM W/ENTRANCE DOOR W/EMERGENCY EXIT ACTUATOR / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PTI RELAY (10309-R4) / FUSE B9-A (10302) CH3_12 / B85AA 14GY / B53BC 18GY / CHILD MONITOR (11642) CH18_26 FUSE B9-W (10302) CH3_08 / B14AE 18RD / ELEC PANEL/ PLATFORM (1703) CH7_60 / PTI RELAY (10309-R5) 86 / PTI RELAY (10309-R6) 86 30 / B53AB 16YL / B53AA 14YL / B53BD 18GY / B14BB 16RD / B14AC 18RD / B85AB 14GY / B53AD 16YL / B53AC 16YL / B53BB 18GY / B14BA 14RD / B14CA 14RD B14AD 18RD / B14BC 14RD / B14AB 18RD / B53BA 18GY / FUSE B9-B (10302) CH3_11 / ELEC PANEL/ PLATFORM (1703) CH7_60 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 767 / CHILD CHECKMATE SYSTEM WITH ENTRANCE DOOR WITH EMERGENCY EXIT ACT

18.33. CHILD CHECKMATE SYSTEM WITH ENTRANCE DOOR WITH EMERGENCY
Figure 768 CHILD CHECKMATE SYSTEM WITH ENTRANCE DOOR WITH EMERGENCY EXIT ACT

Components: ALARM RELAY (10310-R6); BUZZER SPLICE (10204); DIODE B3-D (10304); DOOR SWITCH OUTPUT (11641); FR CAP (10000); FUSE B9-A (10302); LT OUTPUT (11640); LT RELAY (10311-R1); NC RELAY (11303); RELAY (10309-R3); SPLICE (10334); SPLICE (10336); TIMER RELAY (10313-R3)
Wires (circuit gauge+color): B117A 18GY; B117B 18GY; B117C 18GY; B117CC 18GY; B117D 16GY; B117E 16GY; B11GA 16WH; B11GB 16WH; B11GC 16WH; B11GCC 16WH; B11GD 16WH; B11GF 16WH; B131AB 18DKBL; B131AC 16DKBL; B131AD 16DKBL; B14AB 18RD; B14AF 18RD; B14AG 16RD; B63AA 18DKBL; B63AB 18DKBL; B63AC 18DKBL
See also sheets: CH14_01, CH18_01, CH18_26, CH18_30, CH18_35, CH3_12, CH3_34, CH3_39, CH8_23
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.33. CHILD CHECKMATE SYSTEM WITH ENTRANCE DOOR WITH EMERGENCY EXIT ACT (CONT.), P. 25 / CHAPTER 18 CHILD CHECKMATE SYSTEM W/ENTRANCE DOOR W/EMERGENCY EXIT ACTUATOR(CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CHILD SAFETY ALARM RELAY (10310-R6) / FUSE B9-A (10302) CH3_12 / B117B 18GY / B117E 16GY B11GF 16WH / GROUND SPLICE (10334) CH3_34 / B14AF 18RD / CHILD MONITOR DOOR SWITCH OUTPUT (11641) CH18_01 / B131AC 16DKBL / B117D 16GY / B11GCC 16WH / B14AG 16RD / B117A 18GY / B131AB 18DKBL / B11GB 16WH / B11GA 16WH / B14AB 18RD / B11GD 16WH / REAR ROW DOME LT RELAY (10311-R1) / TWO MIN TIMER NC RELAY (11303) / GROUND SPLICE (10336) CH3_39 / B117CC 18GY / STEP LIGHT RELAY (10309-R3) CH8_23 ELEC PANEL/ FR CAP (10000) CH18_35 DIODE B3-D (10304) CH18_26 CHILD DOME LT OUTPUT (11640) / B117C 18GY / B131AD 16DKBL / B63AC 18DKBL / B63AA 18DKBL / B63AB 18DKBL / 2 MIN TIMER RELAY (10313-R3) CH18_30 / EMER EXIT BUZZER SPLICE (10204) CH14_01,1A / B11GC 16WH / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 768 / CHILD CHECKMATE SYSTEM WITH ENTRANCE DOOR WITH EMERGENCY EXIT ACT (CONT.)

18.34. CHILD CHECKMATE SYSTEM WITH ENTRANCE DOOR WITH EMERGENCY
Figure 769 CHILD CHECKMATE SYSTEM WITH ENTRANCE DOOR WITH EMERGENCY EXIT ACT

Components: CHILD MONITOR (11642); DIODE B3-D (10304); DOME LT RELAY (10311-R1); FUSE B12-K (10301); FUSE B9-A (10302); GROUND SPLICE (10334); PTI RELAY (10309-R4); SPLICE (10389); STOP ARM EXTEND (10358B)
Wires (circuit gauge+color): B119 18GY; B11GD 16WH; B11GE 18WH; B131AA 18DKBL; B131AB 18DKBL; B131AD 16DKBL; B13AA 18PK; B14AA 18RD; B14AB 18RD; B53BA 18GY; B53BC 18GY
See also sheets: CH18_24, CH18_25, CH3_12, CH3_18, CH3_34, CH8_22, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.34. CHILD CHECKMATE SYSTEM WITH ENTRANCE DOOR WITH EMERGENCY EXIT ACT (CONT.), P. 26 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 CHILD CHECKMATE SYSTEM W/ENTRANCE DOOR W/EMERGENCY EXIT ACTUATOR (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CHILD MONITOR (11642) / B14AA 18RD / B119 18GY / FUSE B9-A (10302) CH3_12 / B13AA 18PK / FUSE B12-K (10301) CH3_18 / STOP ARM EXTEND (10358B) CH9_03 / GROUND SPLICE (10334) CH3_34 / B11GD 16WH / B11GE 18WH / PTI RELAY (10309-R4) CH18_24 / B53BA 18GY / B14AB 18RD / B53BC 18GY / DIODE B3-D (10304) 8 / B131AA 18DKBL / B131AB 18DKBL / DOOR OPTION SPLICE (10389) CH8_22 REAR ROW DOME LT RELAY (10311-R1) CH18_25 / B131AD 16DKBL / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 769 / CHILD CHECKMATE SYSTEM WITH ENTRANCE DOOR WITH EMERGENCY EXIT ACT (CONT.)

18.35. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT, P. 27
Figure 770 CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT

Components: BRAKE CCM (9556); FUSE B12-K (10301); LEFT BODY (10401B); LT RELAY (10311-R3); MATE RELAY (10310-R2); OUTPUT (11649); OUTPUT (11650); PLATFORM (1702); RED DOT (11642A); RELAY (10313-R6); SNOOZE ON (11337); SPLICE BLOCK (11503); SPLICE PACK (11502); YEL DOT (11647)
Wires (circuit gauge+color): A44 18GY; B101 18TN; B125-G 18WH; B125AE 18GY; B125AF 18GY; B125D 18GY; B125HH 18GY; B13A 18PK; B14A 18RD; B60B 18OR; B63A 18DKBL; B63B 18DKBL; B63C 18DKBL
See also sheets: CH18_23, CH18_30, CH18_31, CH18_32, CH18_33, CH18_37, CH18_39, CH3_18
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.35. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT, P. 27 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 CHILD CHECKMATE/THEFT MATE SYSTEM W/SNOOZE W/LIFT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CHILD CHECK-MATE SYSTEMS EP-2 PLUS / 1 2 / 3 5 / B14A 18RD / THEFT MATE RED DOT (11642A) / B125-G 18WH / B13A 18PK / B60B 18OR / B125HH 18GY / ELEC PANEL/ LEFT BODY (10401B) CH18_37 / B125D 18GY / 1 2 3 / THEFT MATE YEL DOT 4 (11647) / B125AE 18GY / B125AF 18GY / THEFT MATE DIGITAL 1 OUTPUT (11649) / THEFT MATE DIGITAL 2 OUTPUT (11650) / CHILD CHECK MATE RELAY (10310-R2) CH18_31 FRONT DOME LT RELAY (10311-R3) CH18_31 / A44 18GY / AIR PARK BRAKE CCM (9556) CH18_39 / ELEC PANEL/ PLATFORM (1702) 44 / B101 18TN / B63B 18DKBL / 18DKBL B63A / B63C 18DKBL / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 770 / CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT

18.36. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT
Figure 771 CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT (CONT.)

Components: FRONT CAP (10000); FRONT CAP (10001); FUSE B9-G (10302); INPUT SIGNAL (11504); LED OUTPUT (11652); MOTION GN DOT (11641A); MOTION SENSOR (10057A); POST TRIP COM (10045A); POST TRIP NO (10044A); RELAY (10308-R5); SPLICE (10010); TIMER RELAY (10313_R3); VIO DOT (11648)
Wires (circuit gauge+color): B122DD 18GY; B125C 18GY; B125H 18GY; B125MA 18GY; B125MB 18GY; B125MC 18GY; B12A 18LTBL; B130A 18GY; B130MD 18GY; C125 16GY; C125-G 16WH; C125AA 18BK; C125AB 18LTGN; C125ABD 18BK; C125AC 18RD; C125AE 18PK
See also sheets: CH18_30, CH3_16, CH3_44
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.36. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT (CONT.), P. 28 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 CHILD CHECKMATE/THEFT MATE SYSTEM W/SNOOZE W/LIFT (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CHILD CHECK-MATE SYSTEMS / EP-2 PLUS / B12A 18LTBL / GROUND SPLICE (10010) CH3_44 / B125H 18GY / THEFT MATE LED OUTPUT (11652) / 1 2 / C125AA 18BK / C125AB 18LTGN / C125AC 18RD / 2 3 / THEFT MATE MOTION GN DOT (11641A) / ELEC PANEL/ FRONT CAP (10001) / CHILD CHECK MOTION SENSOR (10057A) / 1 2 / 1 2 3 / 1 2 / + - / RD BK / ELEC PANEL/ C12 FRONT CAP (10000) C125 16GY / POST TRIP NO (10044A) A / C125-G 16WH POST TRIP COM (10045A) / THEFT MATE SIGNAL VIO DOT (11648) / B125MC 18GY / B125MB 18GY / B125MA 18GY / C125ABD 18BK / C125AE 18PK / FUSE B9-G (10302) CH3_16 / CHILD MONITOR RELAY (10308-R5) CH18_30 2 MIN TIMER RELAY (10313_R3) CH18_30 / CCM/TM DOOR INPUT SIGNAL (11504) / B125C 18GY / B122DD 18GY / B130MD 18GY / B130A 18GY / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 771 / CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT (CONT.)

18.37. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT
Figure 772 CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT (CONT.)

Components: BLOCK (11502); FUSE B9-B (10302); FUSE B9-W (10302); PLATFORM (1703); PTI RELAY (10309-R4); PTI RELAY (10309-R5); PTI RELAY (10309-R6); RELAY (10313-R6)
Wires (circuit gauge+color): B125A 18GY; B125HHA 18GY; B125HLA 18GY; B125HRA 18GY; B14C 14RD; B14CZ 14RD; B14FX 14RD; B14H 14RD; B53B-G 18WH; B53C-G 18WH; B85A-G 18WH; B85D 14GY; B85E 14GY; B85X 14GY
See also sheets: CH18_30, CH18_32, CH3_08, CH3_11, CH7_60
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.37. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT (CONT.), P. 29 / CHAPTER 18 CHILD CHECKMATE/THEFT MATE SYSTEM W/SNOOZE W/LIFT (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PTI RELAY (10309-R4) 85 / CHILD MONITOR RELAY (10313-R6) CH18_30 / B85D 14GY / B85A-G 18WH B14CZ 14RD / FUSE B9-W (10302) CH3_08 / B125A 18GY / ELEC PANEL/ PLATFORM (1703) CH7_60 / PTI RELAY (10309-R6) 85 / B53H 16YL / B53G 14YL / B53C-G 18WH / B14FX 14RD / B125HRA 18GY / B85E 14GY / B53E 16YL / B53D 16YL / B53B-G 18WH / B14C 14RD / B125HLA 18GY / B85X 14GY / B125HHA 18GY / B14H 14RD / PTI RELAY (10309-R5) / FUSE B9-B (10302) CH3_11 / CCM/TM GROUND SPLICE BLOCK (11502) CH18_32 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 772 / CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT (CONT.)

18.38. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT
Figure 773 CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT (CONT.)

Components: BLOCK (11502); BLOCK (11503); BUZZER SPLICE (10204); IP SIGNAL (11504); LIFT SPLICE (10370); LT OUTPUT (11640); PTI RELAY (10309-R4); RED DOT (11642A); RELAY (10308-R5); RELAY (10313-R3); RELAY (10313-R6); SIGNAL (11504); SPLICE BLOCK (11502); SPLICE BLOCK (11503)
Wires (circuit gauge+color): B122DA 18GY; B122DC 18GY; B122DD 18GY; B125-GE 18WH; B125A 18GY; B125HH 18GY; B125HHA 18GY; B130 18GY; B130A 18GY; B14DB 18RD; B14HA 18RD; B14HB 18RD; B14X 18RD; B63AB 18DKBL
See also sheets: CH14_01, CH18_25, CH18_27, CH18_28, CH18_29, CH18_32, CH18_33
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.38. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT (CONT.), P. 30 / CHAPTER 18 CHILD CHECKMATE/THEFT MATE SYSTEM W/SNOOZE W/LIFT (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 2 MIN TIMER RELAY (10313-R3) / CCM/TM POWER SPLICE BLOCK (11503) CH18_33 / B122DC 18GY / B122DA 18GY / B14DB 18RD / CCM/TM GROUND SPLICE BLOCK (11502) CH18_32 / B130A 18GY / B130 18GY / B125-GE 18WH / B14X 18RD / B122DD 18GY / B14HA 18RD B14HB 18RD / B125HH 18GY / B125HHA 18GY / B125A 18GY / CHILD MONITOR RELAY (10313-R6) / CHILD MONITOR RELAY (10308-R5) / THEFT MATE RED DOT (11642A) CH18_27 PTI RELAY (10309-R4) CH18_29 / CCM/TM DOOR IP SIGNAL (11504) CH18_28 / LIFT SPLICE (10370) CH15_XX CHILD DOME LT OUTPUT (11640) CH18_25 / CCM/TM POWER SPLICE BLOCK (11503) CH18_33 / CCM/TM DOOR IP SIGNAL (11504) CH18_28 / CCM/TM POWER SLPICE BLOCK (11503) CH18_33 / EMER EXIT BUZZER SPLICE (10204) CH14_01 CCM/TM GROUND SPLICE BLOCK (11502) CH18_32 / B63AB 18DKBL / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 773 / CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT (CONT.)

18.39. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT
Figure 774 CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT (CONT.)

Components: FUSE B6-N (10303); LIGHT RELAY (10311-R3); OUTPUT (10202); RELAY (10310-R2); YEL DOT (11647)
Wires (circuit gauge+color): B14CA 14RD; B14DA 18RD; B14E 14RD; B14FA 18RD; B14G 14RD; B63A 18DKBL; B63B 18DKBL; B63C 18DKBL; B63D 14DKBL; B63E 14DKBL
See also sheets: CH18_27, CH3_17, CH8_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.39. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT (CONT.), P. 31 / CHAPTER 18 CHILD CHECKMATE/THEFT MATE SYSTEM W/SNOOZE W/LIFT (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CHILD CHECKMATE RELAY (10310-R2) / FUSE B6-N (10303) CH3_17 / B63D 14DKBL / B63B 18DKBL / B14DA 18RD / DOME LT OUTPUT (10202) CH8_35.36 / B14E 14RD B14FA 18RD / B63C 18DKBL / B63E 14DKBL / B63A 18DKBL / FRONT DOME LIGHT RELAY (10311-R3) / THEFT MATE YEL DOT (11647) CH18_27 / B14CA 14RD / B14G 14RD / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 774 / CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT (CONT.)

18.40. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT
Figure 775 CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT (CONT.)

Components: CHILD MONITOR RELAY (10308-R5); GROUND SPLICE (10335B); GROUND SPLICE (10336); HAZARD ASSERT (11338); PTI RELAY (10309-R4); PTI RELAY (10309-R5); PTI RELAY (10309-R6); RED DOT (11642A); RELAY (10313-R3); SPLICE BLOCK (11502)
Wires (circuit gauge+color): B122DC 18GY; B125-G 18WH; B125-GA 16WH; B125-GA 18GY; B125-GB 18GY; B125-GE 18WH; B53B-G 18WH; B60-G 16WH; B85A-G 18WH
See also sheets: CH18_23, CH18_27, CH18_29, CH18_30, CH18_34, CH18_36, CH3_38, CH3_39
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.40. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT (CONT.), P. 32 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 CHILD CHECKMATE/THEFT MATE SYSTEM W/SNOOZE W/LIFT (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CCM/TM GROUND SPLICE BLOCK (11502) / B125-GA 16WH / B60-G 16WH / B85A-G 18WH / B53B-G 18WH / B53C-G 18GH / B125-GE 18WH / B122DC 18GY / B125-G 18WH / %B125-G 18WH / %B125-GA 18GY / %B125-GB 18GY / PTI RELAY (10309-R4) CH18_29 / PTI RELAY (10309-R5) CH18_29 / PTI RELAY (10309-R6) CH18_29 / CHILD MONITOR RELAY (10308-R5) CH18_30 / 2 MIN TIMER RELAY (10313-R3) CH18_30 / % W/CHILD CHECK MAKE/THEFT MATE W/EMERGENCY EXIT ACTUATOR DOME LT / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 775 / CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT (CONT.)

18.41. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT
Figure 776 CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT (CONT.)

Components: BRAKE CCM (9556); CHILD MONITOR RELAY (10308-R5); CHILD MONITOR RELAY (10313-R6); FUSE B9-A (10302); MIN TIMER RELAY (10313-R3); PLATFORM (1702); SPLICE BLOCK (11503); THEFT MATE RED DOT (11642A)
Wires (circuit gauge+color): A4PK 18RD; B14 18RD; B14A 18RD; B14DB 18RD; B14F 18RD; B14HA 18RD; B14HB 18RD; B14X 18RD
See also sheets: CH18_27, CH18_30, CH18_39, CH3_12
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.41. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT (CONT.), P. 33 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 CHILD CHECKMATE/THEFT MATE SYSTEM W/SNOOZE W/LIFT (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CCM/TM POWER SPLICE BLOCK (11503) / B14 18RD / B14A 18RD / B14HB 18RD / B14X 18RD / B14DB 18RD / B14F 18RD / FUSE B9-A (10302) CH3_12 / THEFT MATE RED DOT (11642A) CH18_27 / B14HA 18RD / CHILD MONITOR RELAY (10313-R6) CH18_30 / CHILD MONITOR RELAY (10308-R5) CH18_30 / 2 MIN TIMER RELAY (10313-R3) CH18_30 / AIR PARK BRAKE CCM (9556) CH18_39 / A4PK 18RD / ELEC PANEL/ PLATFORM (1702) 45 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 776 / CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE WITH LIFT (CONT.)

18.42. CHILD CHECKMATE / THEFT MATE SYSTEM WITH EMERGENCY EXIT ACT WITH DOME LIGHT, P. 34
Figure 777 CHILD CHECKMATE / THEFT MATE SYSTEM WITH EMERGENCY EXIT ACT WITH DOME

Components: CHASSIS (1700); CONTROLLER (1603); ELEC PANEL (10401); ELEC PANEL (1703); EXTEND (10358B); FUSE B12-J (10301); FUSE B9-A (10302); FUSE B9-B (10302); OUTPUT 1 (11649); OUTPUT 2 (11650); OUTPUT 3 (11651); RED DOT (11642A); RELAY (10309-R4); RELAY (10313-R6); SPLICE PACK (11502); YEL DOT (11647)
Wires (circuit gauge+color): A125A 16GY; A125B 16GY; B119 18GY; B125-GA 18GY; B125A 16GY; B125AD 18GY; B125AE 18GY; B125AF 18GY; B125B 16GY; B125B 18GY; B125E 18GY; B125F 18GY; B125FA 18GY; B125HA 18GY; B125N 18GY; B125P 18GY; B125R 18GY; B14CMA 18RD; M11-G 10WH; M11-G 14WH; M85-GA 16WH; M85-GC 16WH; M85-GD 16WH; M85-GE 16WH; M85A 16GY; M85J 16GY; M85K 16GY; M85L 16GY
See also sheets: CH18_32, CH18_36, CH18_37, CH2_36, CH3_11, CH3_12, CH3_19, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.42. CHILD CHECKMATE / THEFT MATE SYSTEM WITH EMERGENCY EXIT ACT WITH DOME LIGHT, P. 34 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 CHILD CHECKMATE/THEFT MATE SYSTEM W/EMERGENCY EXIT ACTUATOR W/DOME LT / MJV0488 19NOV21 CIRC B125HA WAS B125H B AT CAV 3 OF R/D 11642A. / CHILD CHECK-MATE SYSTEMS EP-2 PLUS / 1 2 3 5 / THEFT MATE RED DOT (11642A) B14CMA 18RD / B125-GA 18GY B125HA 18GY / B119 18GY / B125B 18GY / B125E 18GY B125FA 18GY / 1 2 3 / THEFT MATE 4 YEL DOT (11647) / 5 B125N 18GY / B125AE 18GY THEFT MATE DIGITAL OUTPUT 1 (11649) / B125AF 18GY THEFT MATEDIGITAL OUTPUT 2 (11650) / CHILD MONITOR RELAY B125P (10313-R6) 18GY CH18_36 THEFT MATE DIGITAL OUTPUT 3 (11651) / B125AD 18GY / PTI RELAY (10309-R4) / B125R 18GY / B125F 18GY / B125A 16GY / B125B 16GY / PLATFORM/ FORWARD CHASSIS (1700) / A125B 16GY / HORN (*8310/&8310A) A M85A M85J 16GY 16GY M85-GA M85-GC 16WH 16WH / M85-GD 16WH / ELECTRIC HORN#1 (8311) A M85K 16GY B / M85L 16GY / M85-GE 16WH / ELECTRIC HORN # 2 (8312) A B / A125A 16GY / M11-G 14WH M11-G 10WH / UPPER DASH GROUND STUD (2GA) CH2_36 / PLATFORM/ ELEC PANEL (1703) B7 / * W/DISC STYLE HORN SIGNAL & W/HORN ABOVE FRAME SIGNAL / Figure 777 / CHILD CHECKMATE / THEFT MATE SYSTEM WITH EMERGENCY EXIT ACT WITH DOME LIGHT

18.43. CHILD CHECKMATE / THEFT MATE SYSTEM WITH EMERGENCY EXIT ACT
Figure 778 CHILD CHECKMATE / THEFT MATE SYSTEM WITH EMERGENCY EXIT ACT WITH DOME

Components: ALARM RELAY (10310-R6); FRONT CAP (10000); FRONT CAP (10001); FUSE B9-G (10302); FUSE XX (10305); LED OUTPUT (11652); MOTION GN DOT (11641A); MOTION SENSOR (10057A); POST TRIP COM (10045A); POST TRIP NO (10044A); SPLICE (10010); STEP LIGHT REL (10309-XX); VIO DOT (11648)
Wires (circuit gauge+color): B117B 18GY; B117C 18GY; B125AA 18BK; B125AB 18LTGN; B125AC 18RD; B125AH 20GY; B125C 18GY; B125CMD 18GY; C125 16GY; C125-G 16WH; C125AA 18BK; C125AB 18LTGN; C125ABD 18BK; C125AC 18RD; C125AE 18PK
See also sheets: CH18_25, CH3_16, CH3_44
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.43. CHILD CHECKMATE / THEFT MATE SYSTEM WITH EMERGENCY EXIT ACT WITH DOME LIGHT (CONT.), P. 35 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 CHILD CHECKMATE/THEFT MATE SYSTEM W/EMERGENCY EXIT ACTUATOR W/DOME LT (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CHILD CHECK-MATE SYSTEMS / EP-2 PLUS / @B125C 18GY / GROUND SPLICE (10010) CH3_44 / B125AH 20GY / THEFT MATE LED OUTPUT (11652) / 1 2 / C125AA 18BK / B125AA 18BK / B125AB 18LTGN / B125AC 18RD / C125AB 18LTGN / C125AC 18RD / 2 3 / THEFT MATE MOTION GN DOT (11641A) / ELEC PANEL/ FRONT CAP (10001) / CHILD CHECK MOTION SENSOR (10057A) / 1 2 / 1 2 3 / 1 2 / + - / RD BK / ELEC PANEL/ POST TRIP NO C12 FRONT CAP (10044A) (10000) A C125 16GY / C125-G 16WH POST TRIP COM (10045A) FUSE B9-G (10302) CH3_16 FUSE XX (10305) CH3_16 / B125CMD 18GY / THEFT MATE SIGNAL VIO DOT (11648) / C125ABD 18BK / C125AE 18PK / @B117C 18GY / B117B 18GY / STEP LIGHT REL (10309-XX) CH8_XX CHILD SAFETY ALARM RELAY (10310-R6) CH18_25 / #B117C 18GY / #B125C 18GY / Figure 778 / CHILD CHECKMATE / THEFT MATE SYSTEM WITH EMERGENCY EXIT ACT WITH DOME LIGHT (CONT.)

18.44. CHILD CHECKMATE / THEFT MATE SYSTEM WITH EMERGENCY EXIT ACT
Figure 779 CHILD CHECKMATE / THEFT MATE SYSTEM WITH EMERGENCY EXIT ACT WITH DOME

Components: BLOCK (11502); FUSE B9-A (10302); FUSE B9-H (10302); OUTPUT (10202); RELAY (10308-R5); RELAY (10310-R2); RELAY (10313-R6); SPLICE (10204); YET DOT (11647)
Wires (circuit gauge+color): B125-GB 18WH; B125J 16GY; B125K 16GY; B125L 16GY; B125M 16GY; B125N 18GY; B125P 18GY; B125PA 18GY; B125PB 18GY; B125S 16GY; B125T 18GY; B14CMB 18RD; B63S 16LTBL; B63T 16LTBL
See also sheets: CH14_01, CH18_32, CH18_34, CH3_08, CH3_12, CH8_35, CH8_36
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.44. CHILD CHECKMATE / THEFT MATE SYSTEM WITH EMERGENCY EXIT ACT WITH DOME LIGHT (CONT.), P. 36 / CHAPTER 18 CHILD CHECKMATE/THEFT MATE SYSTEM W/EMERGENCY EXIT ACTUATOR W/DOME LT (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CHILD MONITOR RELAY (10313-R6) / B125M 16GY / B125N 18GY / B125L 16GY B63T 16LTBL / FUSE B9-H (10302) CH3_08 / B125PA 18GY / B125PB 18GY / B125-GB 18WH / B14CMB 18RD / B125T 18GY B63S 16LTBL / CHILD CHECKMATE RELAY (10310-R2) / CHILD MONITOR RELAY (10308-R5) / DOME LT OUTPUT (10202) CH8_36 / DOME LT OUTPUT (10202) CH8_35 / FUSE B9-A (10302) CH3_12 / EMER EXIT BUZZER SPLICE (10204) CH14_01 / CCM/TM GROUND SPLICE BLOCK (11502) CH18_32 / B125P 18GY / THEFMATE YET DOT (11647) CH18_34 / B125J 16GY / B125K 16GY B125S 16GY / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 779 / CHILD CHECKMATE / THEFT MATE SYSTEM WITH EMERGENCY EXIT ACT WITH DOME LIGHT (CONT.)

18.45. LEAVE NO STUDENT BEHIND WITH BATTERY FEED BUZZ, P. 37
Figure 780 LEAVE NO STUDENT BEHIND WITH BATTERY FEED BUZZ

Components: CHECK MATE (10339); DIODE B3-C (10304); ELEC PANEL (1703); FUSE A1-F (10305); REAR CAP (10405); RED DOT (11642A); RELAY (10309-R4); SPLICE (10204); SPLICE (10335B); SWITCH (10480); SWITCH (10481)
Wires (circuit gauge+color): B125 18GY; B125A 18GY; B125B 18GY; B125C 18GY; B125D 18GY; B125E 18GY; B125F 18GY; B125H 18GY; D125A 16GY; D125B 16GY; E125A 16GY; E125B 16GY
See also sheets: CH14_01, CH18_05, CH18_18, CH18_38, CH3_17, CH3_38
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.45. LEAVE NO STUDENT BEHIND WITH BATTERY FEED BUZZ, P. 37 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 LEAVE NO STUDENT BEHIND W/BATTERY FEED BUZZ / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 86 %B125H %B125B 18GY 18GY / PTI RELAY (10309-R4) 85 30 / %B125D 18GY / %B125E 18GY / FUSE A1-F (10305) CH3_17 / DIODE B3-C (10304) / B125C 18GY / EMERGENCY EXIT BUZZER SPLICE (10204) CH14_01 PLATFORM/ ELEC PANEL (1703) CH18_38 / B125B 18GY / PTI RESET SWITCH (10481) / LEFT BODY/ REAR CAP (10405) D3 / E125A 16GY / PTI RESET SWITCH A (10480) / *D125B 16GY / ELEC PANEL/ LEFT BODY (@10401A/#10401B /10401) C7 / E125B 16GY / *D125A 16GY / B125A 18GY / GROUND SPLICE (10335B) CH3_38 / B125D 18GY / @B125B 18GY #B125D 18GY / %B125F 18GY / THEFT MATE RED DOT (11642A) CH18_05,11, 27,34 / &B125 18GY / CA 2018 CHECK MATE (10339) CH18_18 / Figure 780 / LEAVE NO STUDENT BEHIND WITH BATTERY FEED BUZZ

18.46. LEAVE NO STUDENT BEHIND WITH BATTERY FEED BUZZ (CONT.), P. 37A
Figure 781 LEAVE NO STUDENT BEHIND WITH BATTERY FEED BUZZ (CONT.)

Components: DIODE D73 (10307); ELEC PANEL (1703); FUSE F65 (10306); LT RELAY (10309); REAR CAP (10405); RED DOT (11642A); RELAY (10309); SPLICE (10204); SPLICE (10335B); SWITCH (10480); SWITCH (10481)
Wires (circuit gauge+color): B117BA 18GY; B125 18GY; B125A 18GY; B125B 18GY; B125C 18GY; B125D 18GY; B125E 18GY; B125F 18GY; B125H 18GY; D125A 16GY; D125B 16GY; E125A 16GY; E125B 16GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.46. LEAVE NO STUDENT BEHIND WITH BATTERY FEED BUZZ (CONT.), P. 37A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 27MAR21 / CHAPTER 18 LEAVE NO STUDENT BEHIND (CONT.) / MJV0488 19NOV21 ADDED CIRC B117BA IN R/D 10307. / 87A B3 / PTI ISOLATION RELAY (10309) A3 A4 86 30 / 85 C3 C4 B125H 18GY / B125D 18GY / B125E 18GY / B125F B125D 18GY 18GY / FUSE F65 (10306) CH3_94N / DIODE D73 (10307) / A1 &B117BA 18GY / B125C 18GY / STEPWELL LT RELAY (10309) CH8_23A EMERGENCY EXIT BUZZER SPLICE (10204) CH14_1A PLATFORM/ ELEC PANEL (1703) CH18_38A / B125B 18GY / PTI RESET SWITCH (10481) / LEFT BODY/ REAR CAP (10405) D3 / E125A 16GY / PTI RESET SWITCH A (10480) / D125B 16GY / ELEC PANEL/ LEFT BODY (@10401A/#10401B /10401) C7 / E125B 16GY / D125A 16GY / B125A 18GY / THEFT MATE RED DOT (11642A) CH18_5A,48 CA 2018 CHECKMATE (10339 CH18_42C GROUND SPLICE (10335B) CH3_95H / %B125B 18GY / @ W/BATTERY FEED BUZZ N/+9 # W/BATTERY FEED BUZZ W/+9 % W/THEFTMATE PREWIRE & W/CCM ENTRANCE DOOR & EMERGENCY EXIT ACTIVATED / B125 18GY / Figure 781 / LEAVE NO STUDENT BEHIND WITH BATTERY FEED BUZZ (CONT.)

18.47. POST TRIP INSPECTION EFFECTS WITHOUT CRS, P. 38
Figure 782 POST TRIP INSPECTION EFFECTS WITHOUT CRS

Components: DIODE B3-C (10304); J3 - RED BODY CONTROLLER (1600); PLATFORM (1703); RELAY (1012-R6); SPLICE (1005); ZVR RELAYS (1009)
Wires (circuit gauge+color): A125H 18GY; A125J 18GY; A125K 18GY; A125L 18GY; B125B 18GY
See also sheets: CH18_37, CH3_03, CH3_58
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.47. POST TRIP INSPECTION EFFECTS WITHOUT CRS, P. 38 / CHAPTER 18 POST TRIP INSPECTION EFFECTS N/CHILD REMINDER SYSTEM / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PTI RELAY (1012-R6) / POST TRIP A2 INSPECTION INPUT / J3 - RED BODY CONTROLLER (1600) / COIL SIGNAL ZVR RELAYS (1009) CH3_03 / A125L 18GY / A125J 18GY / A125K 18GY / ELEC PANEL/ PLATFORM (1703) A10 / DIODE B3-C (10304) CH18_37 / A125H 18GY / B125B 18GY / ZVR SPLICE (1005) CH3_58 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 782 / POST TRIP INSPECTION EFFECTS WITHOUT CRS

18.48. POST TRIP INSPECTION EFFECTS WITHOUT CRS (CONT.), P. 38A
Figure 783 POST TRIP INSPECTION EFFECTS WITHOUT CRS (CONT.)

Components: DIODE D73 (10307); J3 - RED BODY CONTROLLER (1600); PLATFORM (1703); RELAY (1021); SPLICE (1005); ZVR RELAYS (1009)
Wires (circuit gauge+color): A125H 18GY; A125J 18GY; A125K 18GY; A125L 18GY; B125B 18GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.48. POST TRIP INSPECTION EFFECTS WITHOUT CRS (CONT.), P. 38A / CHAPTER 18 POST TRIP INSPECTION EFFECTS N/ CHILD REMINDER SYSTEM (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 27MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / POST TRIP INSPECTION RELAY (1021) / 85 2 / 3 30 / 87A 4 / 1 86 / POST TRIP A2 INSPECTION INPUT / J3 - RED BODY CONTROLLER (1600) / COIL SIGNAL ZVR RELAYS (1009) CH3_94A / A125L 18GY / A125J 18GY / A125K 18GY ELEC PANEL/ PLATFORM (1703) / DIODE D73 (10307) CH18_37A / A125H 18GY / B125B 18GY / ZVR SPLICE (1005) CH3_95M / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 783 / POST TRIP INSPECTION EFFECTS WITHOUT CRS (CONT.)

18.49. POST TRIP INSPECTION EFFECTS WITH SNOOZE, P. 39
Figure 784 POST TRIP INSPECTION EFFECTS WITH SNOOZE

Components: BRAKE CCM (9556); CHECKMATE GN (11342); ELEC PANEL (1702); GROUND SPLICE (1003); RED DOT (11642A); SPLICE BLOCK (11503); YEL DOT (11647)
Wires (circuit gauge+color): A14PK 18RD; A44 16GY; A44 18GY; A44-G 16WH; B101 18TN; B14A 18RD; B14F 18RD
See also sheets: CH18_11, CH18_18, CH18_33, CH3_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.49. POST TRIP INSPECTION EFFECTS WITH SNOOZE, P. 39 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 POST TRIP INSPECTION EFFECTS W/SNOOZE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / @A44-G 16WH / AIR PARK BRAKE CCM (9556) / GROUND SPLICE (1003) CH3_31 / @A44 16GY / PLATFORM/ ELEC PANEL (1702) 44 / B101 18TN / CA 2018 CHECKMATE GN (11342) CH18_18,19 / %A44 18GY / PLATFORM/ ELEC PANEL (1702) 44 / %A14PK 18RD / AIR PARK BRAKE CCM (9556) / THEFT MATE YEL DOT (11647) CH18_11,27 / B101 18TN / % W/THEFTMATE W/SNOOZE W/PROPANE & GASOLINE ENGINE / @ W/CHECKMATE W/SNOOZE W/PARKING BRAKE INPUT / B14F 18RD / B14A 18RD / THEFT MATE RED DOT (11642A) CH18_11 / CCM/TM POWER SPLICE BLOCK (11503) (CH18_33 / B14F 18RD / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 784 / POST TRIP INSPECTION EFFECTS WITH SNOOZE

18.50. POST TRIP INSPECTION EFFECTS WITH SNOOZE (CONT.), P. 39A
Figure 785 POST TRIP INSPECTION EFFECTS WITH SNOOZE (CONT.)

Components: BRAKE CCM (9556); CHECKMATE GN (11342); ELEC PANEL (1702); GROUND SPLICE (1003); RED DOT (11642A); STUD (4037Z); YEL DOT (11647)
Wires (circuit gauge+color): A44 16GY; A44 18GY; A44-G 16WH; A44-G 18WH; B101 18TN; B14A 18RD; B14F 18RD; B14PK 18RD; B44 18GY
See also sheets: CH3_95
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.50. POST TRIP INSPECTION EFFECTS WITH SNOOZE (CONT.), P. 39A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 27MAR21 / CHAPTER 18 POST TRIP INSPECTION EFFECTS W/SNOOZE (CONT.) / MJV0488 10JUN21 INITIAL PRODUCTION RELEASE. / A44-G 16WH PLATFORM/ ELEC PANEL (1702) 44 / AIR PARK BRAKE CCM (9556) / GROUND SPLICE (1003) CH3_95A / A44 16GY / B101 18TN / CA 2018 CHECKMATE GN (11342) / A44 18GY / PLATFORM/ ELEC PANEL (1702) 44 / A44-G 18WH / AIR PARK BRAKE CCM (9556) / GROUND STUD (4037Z) CH3_95 THEFT MATE YEL DOT (11647) CH18_39A / B101 18TN / *B44 18GY / *B14PK 18RD / B14F 18RD / B14A 18RD / THEFT MATE RED DOT (11642A) CH18_41C / * W/ THEFTMATE PREWIRE W/SNOOZE NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 785 / POST TRIP INSPECTION EFFECTS WITH SNOOZE (CONT.)

18.51. CHILD SAFETY ALARM, P. 40
Figure 786 CHILD SAFETY ALARM

Components: ALARM (11545); ALARM - (11547); ALARM MODULE (11627); ALARM RELAY (10310-R5); ALARM RELAY (10310-R6); AMBER PWL SPLICE (10360A); CSA SPEAKER (11628); FUSE B6-W (10303); OVERRIDE SPLICE (10402); SEALED ENG (11500); SPLICE (10336); TALK BUS (10357A); ZVR SPLICE (10350B)
Wires (circuit gauge+color): B119S 18GY; B120C 18LTGN; B125-GS 18WH; B125-GT 18WH; B125-GU 18WH; B125-GV 18WH; B125-GW 18WH; B125A 18GY; B125S 18GY; B125T 18GY; B125U 18GY; B125U-G 18WH; B125V 18GY; B125W 18GY; B125X 18GY; B89N 18OR; B9P 18GY; Y125W 18GY; Y125X 18GY
See also sheets: CH3_09, CH3_40, CH3_60, CH6_02, CH6_22
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.51. CHILD SAFETY ALARM, P. 40 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 05JAN21 / CHAPTER 18 / CHILD SAFETY ALARM / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / AMBER PWL SPLICE (10360A) CH6_02 / CHILD SAFETY ALARM RELAY (10310-R5) / CHILD SAFETY ALARM MODULE (11627) / B119S 18GY / B125-GT 18WH / B125S 18GY / GROUND SPLICE (10336) CH3_40 / B125-GS 18WH / B9P 18GY / B125A 18GY / CHILD SAFETY ALARM RELAY (10310-R6) PWL OVERRIDE SPLICE (10402) CH6_22 FUSE B6-W (10303) CH3_09,25 / ZVR SPLICE (10350B) CH3_60 / #B125U 18GY / ELEC PANEL/ SEALED ENG (11500) B9 / #B125U-G 18WH / GROUND SPLICE (10336) CH3_40 CSA SPEAKER (11628) / @B125X 18GY @B125W 18GY / + - / #Y125W 18GY / CHILD SAFETY ALARM (11545) 1 / #Y125X 18GY CHILD SAFETY ALARM + (11546) A / + - / %Y125W 18GY / %Y125X 18GY CHILD SAFETY ALARM - (11547) / # W/BASIC CSA @ W/SPEAKER CSA % W/DUAL TONE CSA / B125-GU 18WH / DOOR SIGNAL TALK BUS (10357A) A / B120C 18LTGN / B125V 18GY / 87A B89N 18OR B125T 18GY / B125-GV 18WH / B125-GW 18WH / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 786 / CHILD SAFETY ALARM

18.52. CHILD SAFETY ALARM (CONT.), P. 40A
Figure 787 CHILD SAFETY ALARM (CONT.)

Components: ALARM (11545); ALARM - (11547); ALARM MODULE (11627); ALARM RELAY (10308); AMBER PWL SPLICE (10360A); CSA SPEAKER (11628); FUSE F24 (10302); FUSE F40 (10304-B2); GROUND SPLICE (10336); OVERRIDE SPLICE (10402); PTI RELAY (10309); SEALED ENG (11500); SPLICE (10204); SPLICE (10336); SPLICE (10350B); SPLICE BLOCK (11502); TALK BUS (10357A)
Wires (circuit gauge+color): B119S 18GY; B120C 18LTGN; B125-GB 18GY; B125-GS 18WH; B125-GT 18WH; B125-GU 18WH; B125-GV 18WH; B125A 18GY; B125PA 18GY; B125PB 18GY; B125S 18GY; B125T 18GY; B125U 18GY; B125U-G 18WH; B125V 18GY; B125W 18GY; B125X 18GY; B14CMB 18RD; B89N 18OR; B9P 18GY; Y125W 18GY; Y125X 18GY
See also sheets: CH18_51, CH6_02, CH6_22
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.52. CHILD SAFETY ALARM (CONT.), P. 40A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 27MAR21 / CHAPTER 18 CHILD SAFETY ALARM (CONT.) / MJV0488 19NOV21 ADDED CIRC B125-GB IN R/D 10308. / CSA(1) 6B / CSA(7) 2A / CSA(2) 4B / ZVR SPLICE (10350B) CH3_95H FUSE F24 (10302) CH3_95F AMBER PWL SPLICE (10360A) CH6_02 / CSA(6) 2B / CSA(5) 3B / CHILD SAFETY ALARM RELAY (10308) / CHILD SAFETY ALARM MODULE (11627) / 86 F4 / B125-GU 18WH E3 85 / 30 E4 *B125PA 18GY / F3 87 / B125-GV 18WH / B125A 18GY B119S 18GY / B125-GT 18WH / B125S 18GY / GROUND SPLICE (10336) CH3_95K EMER EXIT BUZZER SPLICE (10204) CH14_1A CCM/TM GROUND SPLICE BLOCK (11502) CH18_45E PTI RELAY (10309) CH18_51 / B125-GS 18WH / B9P 18GY B125T 18GY / CHILD SAFETY ALARM RELAY (10308) / CSA(-) 6A / #B125U 18GY / ELEC PANEL/ SEALED ENG (11500) B9 / #B125U-G 18WH / GROUND SPLICE (10336)CH3_95K CSA SPEAKER (11628) / 1 3 / + - / #Y125W 18GY / #Y125X 18GY / + - / %Y125W 18GY / %Y125X 18GY / CHILD SAFETY ALARM (11545) / CHILD SAFETY ALARM + (11546) / CHILD SAFETY ALARM - (11547) / B120C 18LTGN / DOOR SIGNAL TALK BUS (10357A) FUSE F40 (10304-B2) CH3_94J PWL OVERRIDE SPLICE (10402) CH6_22 / 30 G4 / H3 87 / G3 85 / 86 H4 / B125V 18GY / *B14CMB 18RD / B89N 18OR / *B125PB 18GY *B125-GB 18GY / Figure 787 / CHILD SAFETY ALARM (CONT.)

18.53. THEFT MATE PREWIRE SYSTEM WITH SNOOZE, P. 41
Figure 788 THEFT MATE PREWIRE SYSTEM WITH SNOOZE

Components: FUSE F80 (10307); LIGHT RELAY (10311); OUTPUT (10202); YELDOT (11647)
Wires (circuit gauge+color): B14CA 14RD; B14DA 18RD; B14E 14RD; B14FA 18RD; B14G 14RD; B63A 18DKBL; B63B 18DKBL; B63C 18DKBL; B63D 14DKBL; B63E 14DKBL
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.53. THEFT MATE PREWIRE SYSTEM WITH SNOOZE, P. 41 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 27MAR21 / CHAPTER 18 THEFTMATE PREWIRE W/SNOOZE / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 87 87 87A D1 / 85 C1 / D2 86 86 / C2 30 / B63B 18DKBL / B14E 14RD B14G 14RD B14DA 18RD / B14CA 14RD / B63D 14DKBL / B14FA 18RD / E2 30 / F2 86 86 / 87 87 87A F1 / 85 E1 / B63C 18DKBL B63E 14DKBL / B63A 18DKBL / THEFT MATE YELDOT (11647) CH18_41D / REAR DOME LIGHT RELAY (10311) / FRONT DOME LIGHT RELAY (10311) / DOME LIGHT OUTPUT (10202) / FUSE F80 (10307) CH3_94Q / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 788 / THEFT MATE PREWIRE SYSTEM WITH SNOOZE

18.54. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 41A
Figure 789 THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.)

Components: BUZZER SPLICE (10204-G); FR CAP (10000); FUSE F40 (10304-B2); GROUND SPLICE (10010-B); GROUND SPLICE (10336-C); POST TRIP COMM (10045); POST TRIP NO (10044); PTI RELAY (10309-C4); RED DOT (11642A-6); RELAY (10312); SIGNAL VIDEO DOT (11648-2)
Wires (circuit gauge+color): B125-GA 16WH; B125-GE 18WH; B125A 18GY; B125C 18GY; B125HH 18GY; B125HHA 18GY; B130 18GY; B130A 18GY; B130MD 18GY; B14 18RD; B14HA 18RD; B14HB 18RD; B14X 18RD; C125 16GY; C125-G 16WH
See also sheets: CH3_44
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.54. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 41A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 27MAR21 / CHAPTER 18 THEFTMATE PREWIRE W/SNOOZE (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 87 87 87A F2 / 85 G1 / G2 86 86 / F1 30 / B125-GE 18WH / B14X 18RD / B14 18RD / B14HA 18RD B130 18GY / B125HHA 18GY / G4 30 / G3 86 86 / 87 87 87A F3 / 85 F4 / B14HB 18RD B125HH 18GY / B125-GA 16WH / GROUND SPLICE (10336-C) CH3_95J THEFT MATE SIGNAL VIDEO DOT (11648-2) CH18_41D / STEP WARMER RELAY (10312) / EMER EXIT BUZZER SPLICE (10204-G) CH14_1A FUSE F40 (10304-B2) CH3_94J / B125A 18GY / PTI RELAY (10309-C4) CH18_41B / B130A 18GY / B125C 18GY / B130MD 18GY / ELEC PANEL/ FR CAP (10000) C12 / POST TRIP NO (10044) A C125 16GY / POST TRIP COMM (10045) A C125-G 16WH / GROUND SPLICE (10010-B) CH3_44 / THEFT MATE RED DOT (11642A-6) CH18_41C / STEP WARMER RELAY (10312) / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 789 / THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.)

18.55. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 41B
Figure 790 THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.)

Components: FUSE (10303-F1); FUSE (10304-F2); PLATFORM (1703); RED DOT (11642A); RELAY (10309); RELAY (10312); SPLICE (10336)
Wires (circuit gauge+color): B125-GA 16WH; B125A 18GY; B125E 18GY; B125HHA 18GY; B125HLA 18GY; B125HRA 18GY; B14C 14RD; B14CZ 14RD; B14FX 14RD; B14H 14RD; B53B-G 18WH; B53C-G 18WH; B85A-G 18WH; B85D 14GY; B85E 14GY; B85X 14GY
See also sheets: CH18_05, CH3_39
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.55. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 41B / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 22MAR21 / CHAPTER 18 THEFT MATE PREWIRE SYSTEM W/SNOOZE (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B125A 18GY C4 / B85A-G 18WH B14CZ 14RD / FUSE (10303-F1) CH3_94G / B125HHA 18GY / CHILD MONITOR RELAY (10312) CH18_45C / B85E 14GY / B14H 14RD / B85D 14GY / B125HLA 18GY F4 / D3 B53B-G 18WH / B14C 14RD / B53C-G 18WH / B125HRA 18GY J4 / B125-GA 16WH / GROUND SPLICE (10336) CH3_39 / B85X 14GY / FUSE (10304-F2) CH3_94K / B14FX 14RD / B53E 16YL / B53D 16YL / B53H 16YL / B53G 14YL / ELEC PANEL/ PLATFORM (1703) CH7_60A / ELEC PANEL/ PLATFORM (1703) CH7_60A / ELEC PANEL/ PLATFORM (1703) CH7_60A / PTI RELAY (10309) / PTI RELAY (10309) / PTI RELAY (10309) / THEFT MATE RED DOT (11642A) CH18_05 / B125E 18GY / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 790 / THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.)

18.56. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 41C
Figure 791 THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.)

Components: BRAKE CCM (9556); FUSE F40 (10304-B2); FUSE F44 (10304-F3); PLATFORM (1702); RED DOT (11642A); RELAY (10312-F3); SNOOZE ON (11337-C); SPLICE (10336)
Wires (circuit gauge+color): B125-G 18WH; B125-GA 16WH; B125HH 18GY; B13A 18PK; B14 18RD; B14A 18RD; B14F 18RD; B14PK 18RD; B60B 18OR
See also sheets: CH18_23
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.56. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 41C / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 27MAR21 / CHAPTER 18 THEFTMATE PREWIRE W/SNOOZE (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B125-G 18WH / B14A 18RD / THEFT MATE RED DOT (11642A) / B125-GA 16WH / GROUND SPLICE (10336) CH3_95J / B14F 18RD / ELEC PANEL/ PLATFORM (1702) 45 / B14 18RD / FUSE F40 (10304-B2) CH3_94J / B13A 18PK / B60B 18OR / B125HH 18GY / FUSE F44 (10304-F3) CH3_94K / CA 2018 SNOOZE ON (11337-C) CH18_23 / STEP WARMER RELAY (10312-F3) CH18_41A / *B14PK 18RD / AIR PARK BRAKE CCM (9556) CH18_39A / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 791 / THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.)

18.57. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 41D
Figure 792 THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.)

Components: BRAKE CCM (9556); DIGITAL 2 OUT (11650); DIGITAL OUT (11649); FUSE F54 (10305-H2); LED OUTPUT (11652); LIGHT RELAY (10311); PLATFORM (1702); RELAY (10312); SIG VIO DOT (11648); YEL DOT (11647)
Wires (circuit gauge+color): A44 18GY; B101 18TN; B125AE 18GY; B125AF 18GY; B125H 18GY; B12A 18LTBL; B130A 18GY; B130MD 18GY; B63A 18DKBL; B63B 18DKBL; B63C 18DKBL
See also sheets: CH18_41
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.57. THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.), P. 41D / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 27MAR21 / CHAPTER 18 THEFTMATE PREWIRE W/SNOOZE (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B63A 18DKBL / B101 18TN / THEFT MATE YEL DOT (11647) / B63B 18DKBL / AIR PARK BRAKE CCM (9556) CH18_39A REAR DOME LIGHT RELAY (10311) CH18_41 / ELEC PANEL/ PLATFORM (1702) 44 / B63C 18DKBL / FRONT DOME LIGHT RELAY (10311) CH18_41 / B125AE 18GY / THEFT MATE DIGITAL OUT (11649) / B125AF 18GY / THEFT MATE DIGITAL 2 OUT (11650) / THEFT MATE LED OUTPUT (11652) / B125H 18GY / B130MD 18GY / B130A 18GY / STEP WARMER RELAY (10312) CH18_41A / B12A 18LTBL / THEFT MATE SIG VIO DOT (11648) / A44 18GY / FUSE F54 (10305-H2) CH3_94L / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 792 / THEFT MATE PREWIRE SYSTEM WITH SNOOZE (CONT.)

18.58. CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT, P. 42
Figure 793 CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT

Components: CHECKMATE OR (11341); FUSE F80 (10307); LIGHT RELAY (10311); OUTPUT (10202)
Wires (circuit gauge+color): B125DM 18GY; B125DMA 18GY; B125DMB 18GY; B14DM 14RD; B14DMA 18RD; B14DMB 14RD; B14DMC 14RD; B14DMD 18RD; B63 18DKBL; B63C 14DKBL; B63D 14DKBL
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.58. CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT, P. 42 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 27MAR21 / CHAPTER 18 CHECKMATE W/SNOOZE W/EMERGENCY ACTUATOR W/LIFT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / C2 30 / D2 86 86 / 85 C1 / 87 87 87A D1 / B125DMA 18GY B14DMD 18RD / B14DMB 14RD B14DMC 14RD B14DMA 18RD / B14DM 14RD / B63C 14DKBL / E2 30 / F2 86 86 / 87 87 87A F1 / 85 E1 / B125DMB 18GY B63D 14DKBL / @B125DM 18GY / REAR DOME LIGHT RELAY (10311) / FRONT DOME LIGHT RELAY (10311) / DOME LIGHT OUTPUT (10202) / FUSE F80 (10307) CH3_94Q / CA 2018 CHECKMATE OR (11341) / @ W/LIFT * N/LIFT / *B63 18DKBL / REAR DOME LIGHT RELAY (10311) CH18_43A / Figure 793 / CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT

18.59. CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT (CONT.), P. 42A
Figure 794 CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT (CONT.)

Components: FUSE (10304-F2); FUSE F26 (10303); PLATFORM (1703); PTI RELAY (10309); RELAY (10312); SPLICE (10336)
Wires (circuit gauge+color): B125-GA 10WH; B125A 18GY; B125HHA 18GY; B125HLA 18GY; B125HRA 18GY; B14H 14RD; B14HL 14RD; B14HR 14RD; B14K 14RD; B14X 14RD; B53-GHA 18WH; B53-GHB 18WH; B85-GH 18WH; B85S 14GY; B85T 14GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.59. CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT (CONT.), P. 42A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 20MAR21 / CHAPTER 18 CHILD CHECK MATE SYSTEM W/SNOOZE W/EMERGENCY EXIT ACT W/LIFT (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B125A 18GY C4 / A3 B85-GH 18WH / FUSE F26 (10303) CH3_94G / B125HHA 18GY / STEP WARMER RELAY (10312) CH18_42B / B85T 14GY / B14H 14RD / B14K 14RD / B85S 14GY / B125HLA 18GY F4 / D3 B53-GHA 18WH / B14HL 14RD / G3 B53-GHB 18WH / B125HRA 18GY / J4 86 / B125-GA 10WH / GROUND SPLICE (10336) CH3_95J / B14X 14RD / FUSE (10304-F2) CH3_94K / B14HR 14RD / B53E 16YL / B53C 16YL / B53F 16YL / B53D 14YL / ELEC PANEL/ PLATFORM (1703) CH7_60A / ELEC PANEL/ PLATFORM (1703) CH7_60A / PTI RELAY (10309) / PTI RELAY (10309) / PTI RELAY (10309) / ELEC PANEL/ PLATFORM (1703) CH7_60A / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 794 / CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT (CONT.)

18.60. CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT (CONT.), P. 42B
Figure 795 CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT (CONT.)

Components: BUZZZER SPLICE (10204); CHAKE MATE (10309); CHECK MATE (10339); CHECK MATE VL (11340); CHECKMATE (10339); DIODE D61 (10306); FRONT CAP (10000); FUSE F31 (10303); FUSE F40 (10304); FUSE F54 (10305); POST TRIP COM (10045); POST TRIP NO (10044); PTI RELAY (10309); RELAY (10312); SPLICE (10010); SPLICE (10336-C); SPLICE (10370)
Wires (circuit gauge+color): B12 18LTBL; B122 18GY; B122A 18GY; B125-GA 10WH; B125-GE 14WH; B125-GL 14WH; B125-GM 18WH; B125A 18GY; B125C 18GY; B125HH 18GY; B125HHA 18GY; B130 18GY; B130A 18GY; B130MD 18GY; B14 18RD; B14A 18RD; B14EE 18RD; B14HA 18RD; B14HB 18RD; B14L 18RD; B44 18GY; C125 16GY; C125-G 16WH
See also sheets: CH18_21, CH3_15, CH3_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.60. CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT (CONT.), P. 42B / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 08APR21 / CHAPTER 18 CHECKMATE W/SNOOZE W/EMERGENCY ACTUATOR W/LIFT (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / STEP WARMER RELAY (10312) 85 / B14L 18RD J2 86 / H1 30 / 87A H2 J1 B122 18GY FUSE F54 (10305) CH3_15 / B14A 18RD / B14 18RD / CA 2018 CHECK MATE (10339) CH18_22A FUSE F40 (10304) CH3_94J L / B122A 18GY B44 18GY / B125-GL 14WH / B125-GA 10WH / EMER EXIT BUZZZER SPLICE (10204) CH14_1A / LIFT SPLICE (10370) / F1 30 B125C 18GY 87A F2 / B14EE 18RD G2 86 / B130 18GY / G4 30 / G3 86 / 87A F3 / B125-GE 14WH / B130A 18GY / B14HA 18RD B14HB 18RD / B125HHA 18GY B125A 18GY / @C125-G 16WH POST TRIP COM (10045) CA 2018 CHAKE MATE (10309) CH18_22A PTI RELAY (10309) CH18_42A / GROUND SPLICE (10336-C) CH3_95J / B125-GM 18WH / CA 2018 CHECKMATE (10339) CH18_22A / STEP WARMER RELAY (10312) / B12 18LTBL B130MD 18GY / STEP WARMER RELAY (10312) / B125HH 18GY / CA 2018 CHECK MATE VL (11340) / GROUND SPLICE (10010) CH3_32 / ELEC PANEL/ POST TRIP NO C12 FRONT CAP (10044) (10000) A @C125 16GY / FUSE F31 (10303) CH3_94H / B125C 18GY / DIODE D61 (10306) CH18_21 / @ THEFTMAL N/SNOOZE NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 795 / CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT (CONT.)

18.61. CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT (CONT.), P. 42C
Figure 796 CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT (CONT.)

Components: BRAKE CCM (9556); CHECKMATE (10339); CHECKMATE GN (11342); CHECKMATE VL (11340); FUSE F40 (10304); FUSE F44 (10304); FUSE F54 (10305); L BODY (10401); PLATFORM (1702); PTI RELAY (10309); RELAY (10310-R2); SNOOZE ON (11337); SPLICE (10336)
Wires (circuit gauge+color): A44 16GY; B101 18TN; B12 18LTBL; B12-G 18WH; B125 18GY; B125-GA 10WH; B125-GM 18WH; B12AA 18LTBL; B12AB 18LTBL; B13 18PK; B14 18RD; B14A 18RD; B60 18OR; B85 18GY
See also sheets: CH18_21, CH18_23, CH18_43
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.61. CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT (CONT.), P. 42C / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090669 NO. RELEASE NO. 95885P 27MAR21 / CHAPTER 18 CHILD CHECK MATE SYSTEM W/SNOOZE W/EMERGENCY EXIT ACTUATOR W/LIFT (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 18LTBL B12 D2 86 / 85 C1 / C2 30 / CHILD CHECKMATE RELAY (10310-R2) 87A D1 B12AA 18LTBL / B12AB 18LTBL / FUSE F54 (10305) CH3_94L / CA 2018 CHECKMATE VL (11340) CH18_21 / B12-G 18WH / GROUND SPLICE (10336) CH3_XX / B60 18OR / FUSE F40 (10304) CH3_94J / B14A 18RD / ELEC PANEL/ L BODY (10401) CH18_37A / CA 2018 CHECKMATE (10339) / B13 18PK / FUSE F44 (10304) CH3_94K / B125 18GY / CA 2018 SNOOZE ON (11337) CH18_23 / B125-GA 10WH / B125-GM 18WH / B14 18RD / B101 18TN / CA 2018 CHECKMATE GN (11342) / ELEC PANEL/ PLATFORM (1702) 44 / A44 16GY / AIR PARK BRAKE CCM (9556) CH18_39A / @B85 18GY / PTI RELAY (10309) CH18_43 / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 796 / CHECKMATE WITH SNOOZE, EMERGENCY ACT, AND LIFT (CONT.)

18.62. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACT WITHOUT LIFT, P. 43
Figure 797 CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACT WITHOUT LIFT

Components: CHECK MATE (10339); FUSE (10303-F1); FUSE (10304-B2); FUSE (10304-F2); PLATFORM (1703); PTI RELAY (10309)
Wires (circuit gauge+color): B14 18RD; B14A 18RD; B14B 18RD; B14H 14RD; B14K 14RD; B53A 14RD; B53B 14RD; B53G 18RD; B53H 18RD; B85 18GY; B85CK 18GY; B85ER 18GY; B85FU 18GY; B85S 14GY; B85T 14GY; B85X 14RD
See also sheets: CH7_36
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.62. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACT WITHOUT LIFT, P. 43 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 20MAR21 / CHAPTER 18 CHILD CHECK MATE SYSTEM W/SNOOZE W/EMERGENCY EXIT ACTUATOR N/ LIFT (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PTI RELAY (10309) / B14B 18RD C4 / B14A 18RD / B14 18RD / CA 2018 CHECK MATE (10339) CH18_22A FUSE (10304-B2) CH3_94J / B85T 14GY / B85FU 18GY / B85 18GY / ELECTRICAL PANEL /PLATFORM (1703) CH7_60A / B85S 14GY B53E 16YL B53C 16YL / B14H 14RD / C3 B14K 14RD / ELECTRICAL PANEL /PLATFORM (1703) CH7_36 / FUSE (10303-F1) CH3_94G / PTI RELAY (10309) / PTI RELAY (10309) / B53F 16YL / B53D 14YL / B53G 18RD / B85CK 18GY / B53A 14RD / B53H 18RD / B85ER 18GY B53B B53B 14RD 14RD B85X 14RD NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / FUSE (10304-F2) CH3_94G / CA 2018 CHECK MATE (10339) CH18_22A, 42C / Figure 797 / CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACT WITHOUT LIFT

18.63. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACT
Figure 798 CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACT WITHOUT LIFT

Components: CHECKMATE OR (11341); FUSE F80 (10307-F3); LIGHT RELAY (10311); OUTPUT (10202)
Wires (circuit gauge+color): B63 18DKBL; B63A 16DKBL; B63B 16DKBL; B63C 16DKBL; B63D 16DKBL; B63E 14RD; B63F 14RD; B63G 14RD; B63H 14RD; B63J 14RD
See also sheets: CH18_42
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.63. CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACT WITHOUT LIFT (CONT.), P. 43A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 09APR21 / CHAPTER 18 CHECKMATE W/SNOOZE W/EMERGENCY ACTUATOR N/LIFT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 87 87 87A D1 / 85 C1 / D2 86 86 / C2 30 / B63A 16DKBL B63H 14RD / B63G 14RD B63J 14RD B63F 14RD / B63E 14RD / B63C 16DKBL / E2 30 / F2 86 86 / 87 87 87A F1 / 85 E1 / B63B 16DKBL B63D 16DKBL / B63 18DKBL / CA 2018 CHECKMATE OR (11341) CH18_42 / REAR DOME LIGHT RELAY (10311) / FRONT DOME LIGHT RELAY (10311) / DOME LIGHT OUTPUT (10202) / FUSE F80 (10307-F3) CH3_94Q / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 798 / CHILD CHECK MATE SYSTEM WITH SNOOZE, EMERGENCY EXIT ACT WITHOUT LIFT (CONT.)

18.64. CHILD CHECKMATE SYSTEM WITH ENTRANCE DOOR AND EMERGENCY EXIT ACT, P. 44
Figure 799 CHILD CHECKMATE SYSTEM WITH ENTRANCE DOOR AND / EMERGENCY EXIT ACT

Components: CHILD MONITOR (11642); FUSE (10303-F1); FUSE (10304-F2); PLATFORM (1703); RELAY (10309)
Wires (circuit gauge+color): B125F 18GY; B14AC 18RD; B14AD 18RD; B14BA 14RD; B14BB 16RD; B14CA 14RD; B53BA 18GY; B53BB 18GY; B53BC 18GY; B85AA 14GY; B85AB 14GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.64. CHILD CHECKMATE SYSTEM WITH ENTRANCE DOOR AND EMERGENCY EXIT ACT, P. 44 / CHAPTER 18 CHILD CHECKMATE SYSTEM W/ENTRANCE DOOR W/EMERGENCY EXIT ACTUATOR / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 20MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PTI RELAY (10309) / B85AB 14GY A4 / B85AA 14GY / B53BC 18GY / FUSE (10303-F1) CH3_94G / ELEC PANEL/ PLATFORM (1703) CH7_60A / PTI RELAY F4 (10309) D4 / F3 E3 / B53AB PTI 16YL RELAY (10309) G4 / B14AC 18RD J4 / B53AA 14YL / B53BA 18GY B125F 18GY B14BB 16RD / B53AD 16YL / B53AC 16YL / B53BB 18GY B14BA 14RD / B14CA 14RD B14AD 18RD / FUSE (10304-F2) CH3_94K / ELEC PANEL/ PLATFORM (1703) CH7_60A / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / CHILD MONITOR (11642) CH18_4D / Figure 799 / CHILD CHECKMATE SYSTEM WITH ENTRANCE DOOR AND / EMERGENCY EXIT ACT

18.65. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT, P. 45
Figure 800 CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT

Components: BRAKE CCM (9556); FUSE F3 (30304); LEFT BODY (10401B); LT RELAY (10311-R3); OUTPUT (11649); OUTPUT (11650); PLATFORM (1702); RED DOT (11642A); RELAY (10312); SNOOZE ON (11337); SPLICE BLOCK (11503); SPLICE PACK (11502); YEL DOT (11647)
Wires (circuit gauge+color): A44 18GY; B101 18TN; B125-G 18WH; B125AE 18GY; B125AF 18GY; B125D 18GY; B125HH 18GY; B13A 18PK; B14A 18RD; B60B 18OR; B63A 18DKBL; B63B 18DKBL; B63C 18DKBL
See also sheets: CH18_23
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.65. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT, P. 45 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 20MAR21 / CHAPTER 18 CHILD CHECKMATE/THEFT MATE SYSTEM W/SNOOZE W/LIFT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CHILD CHECK-MATE SYSTEMS EP-2 PLUS / 1 2 / 3 5 / B14A 18RD / THEFT MATE RED DOT (11642A) / B125-G 18WH / CCM/TM POWER SPLICE BLOCK (11503) CH18_45F CCM/TM GND SPLICE PACK (11502) CH18_45E / B13A 18PK / B60B 18OR / B125HH 18GY / FUSE F3 (30304) CH3_94K CA 2018 SNOOZE ON (11337) CH18_23 CHILD MONITOR RELAY (10312) CH18_45C / ELEC PANEL/ LEFT BODY (10401B) CH18_37A / B125D 18GY / 1 2 3 / THEFT MATE YEL DOT 4 (11647) / B125AE 18GY / B125AF 18GY / THEFT MATE DIGITAL 1 OUTPUT (11649) / THEFT MATE DIGITAL 2 OUTPUT (11650) / FRONT DOME LT RELAY (10311-R3) CH18_45D / A44 18GY / AIR PARK BRAKE CCM (9556) CH18_39A / ELEC PANEL/ PLATFORM (1702) 44 / B101 18TN / B63B 18DKBL / 18DKBL B63A / B63C 18DKBL / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 800 / CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT

18.66. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.), P. 45A
Figure 801 CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.)

Components: FRONT CAP (10000); FRONT CAP (10001); FUSE B9-G (10305); INPUT SIGNAL (11504); LED OUTPUT (11652); MOTION GN DOT (11641A); MOTION SENSOR (10057A); POST TRIP COM (10045A); POST TRIP NO (10044A); RELAY (10312); SPLICE (10010); TIMER RELAY (10311); VIO DOT (11648)
Wires (circuit gauge+color): B122DD 18GY; B125C 18GY; B125H 18GY; B125MA 18GY; B125MB 18GY; B125MC 18GY; B12A 18LTBL; B130A 18GY; B130MD 18GY; C125 16GY; C125-G 16WH; C125AA 18BK; C125AB 18LTGN; C125ABD 18BK; C125AC 18RD; C125AE 18PK
See also sheets: CH3_44
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.66. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.), P. 45A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 27MAR21 / CHAPTER 18 CHILD CHECKMATE/THEFT MATE SYSTEM W/SNOOZE W/LIFT (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CHILD CHECK-MATE SYSTEMS / EP-2 PLUS / B12A 18LTBL / GROUND SPLICE (10010) CH3_44 / B125H 18GY / THEFT MATE LED OUTPUT (11652) / 1 2 / C125AA 18BK / C125AB 18LTGN / C125AC 18RD / 2 3 / THEFT MATE MOTION GN DOT (11641A) / ELEC PANEL/ FRONT CAP (10001) / CHILD CHECK MOTION SENSOR (10057A) / 1 2 / 1 2 3 / 1 2 / + - / RD BK / ELEC PANEL/ C12 FRONT CAP (10000) C125 16GY / POST TRIP NO (10044A) A / C125-G 16WH POST TRIP COM (10045A) / THEFT MATE SIGNAL VIO DOT (11648) / B125MC 18GY / B125MB 18GY / B125MA 18GY / C125ABD 18BK / C125AE 18PK / FUSE B9-G (10305) CH3_94L / CHILD MONITOR RELAY (10312) CH18_45C 2 MIN TIMER RELAY (10311) CH18_45C / CCM/TM DOOR INPUT SIGNAL (11504) / B125C 18GY / B122DD 18GY / B130MD 18GY / B130A 18GY / Figure 801 / CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.)

18.67. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.), P. 45B
Figure 802 CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.)

Components: FUSE (10303-F1); FUSE (10304-F2); PLATFORM (1703); RED DOT (11642A); RELAY (10309); RELAY (10312); SPLICE (10336)
Wires (circuit gauge+color): B125-GA 16WH; B125A 18GY; B125E 18GY; B125HHA 18GY; B125HLA 18GY; B125HRA 18GY; B14C 14RD; B14CZ 14RD; B14FX 14RD; B14H 14RD; B53B-G 18WH; B53C-G 18WH; B85A-G 18WH; B85D 14GY; B85E 14GY; B85X 14GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.67. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.), P. 45B / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 20MAR21 / CHAPTER 18 THEFT MATE PREWIRE SYSTEM W/SNOOZE (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B125A 18GY C4 / B85A-G 18WH B14CZ 14RD / FUSE (10303-F1) CH3_94G / B125HHA 18GY / CHILD MONITOR RELAY (10312) CH18_45C / B85E 14GY / B14H 14RD / B85D 14GY / B125HLA 18GY F4 / D3 B53B-G 18WH / B14C 14RD / G3 B53C-G 18WH / B125HRA 18GY J4 / B125-GA 16WH / GROUND SPLICE (10336) CH3_95J / B85X 14GY / FUSE (10304-F2) CH3_94K / B14FX 14RD / B53E 16YL / B53D 16YL / B53H 16YL / B53G 14YL / ELEC PANEL/ PLATFORM (1703) CH7_60A / ELEC PANEL/ PLATFORM (1703) CH7_60A / PTI RELAY (10309) / PTI RELAY (10309) / PTI RELAY (10309) / THEFT MATE RED DOT (11642A) CH18_5A / B125E 18GY / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / ELEC PANEL/ PLATFORM (1703) CH7_60A / Figure 802 / CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.)

18.68. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.), P. 45C
Figure 803 CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.)

Components: BLOCK (11502); BLOCK (11503); BUZZER SPLICE (10204); DOME LIGHT OUT (11640); IP SIGNAL (11504); PTI RELAY (10309); RED DOT (11642A); RELAY (10311); RELAY (10312); SIGNAL (11504); SPLICE BLOCK (11502); SPLICE BLOCK (11503)
Wires (circuit gauge+color): B122DC 18GY; B122DD 18GY; B125-GE 18WH; B125A 18GY; B125HH 18GY; B125HHA 18GY; B130 18GY; B130A 18GY; B14DB 18RD; B14HA 18RD; B14HB 18RD; B14X 18RD; B63AA 18DKBL
See also sheets: CH18_45
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.68. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.), P. 45C / CHAPTER 18 CHILD CHECKMATE/THEFT MATE SYSTEM W/SNOOZE W/LIFT (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 20MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 2 MIN TIMER RELAY (10311) / B122DD 18GY G2 30 / H2 86 / 85 G1 / CCM/TM POWER SPLICE BLOCK (11503) CH18_45F / B122DC 18GY / B14DB 18RD / CCM/TM GROUND SPLICE BLOCK (11502) CH18_45E / B14HA 18RD B14HB 18RD F4 30 / G4 86 / 85 F3 / B130A 18GY F2 30 / G2 86 / 85 F1 / B130 18GY / B125-GE 18WH / B14X 18RD / B125HH 18GY / B125HHA 18GY / B125A 18GY / CHILD MONITOR RELAY (10312) / CHILD MONITOR RELAY (10312) / THEFT MATE RED DOT (11642A) CH18_45 PTI RELAY (10309) CH18_41B,45B / CCM/TM DOOR IP SIGNAL (11504) CH18_45A / CCM/TM POWER SPLICE BLOCK (11503) CH18_45F / CCM/TM DOOR IP SIGNAL (11504) CH18_45A / CCM/TM POWER SLPICE BLOCK (11503) CH18_45F / EMER EXIT BUZZER SPLICE (10204) CH14_1A CCM/TM GROUND SPLICE BLOCK (11502) CH18_45E / B63AA 18DKBL / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / CHILD CHILD MONITOR MONITOR DOME DOME LIGHT LIGHT OUT OUT (11640) (11640) / DOME DOME LIGHT LIGHT 2 2 OUT OUT / Figure 803 / CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.)

18.69. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.), P. 45D
Figure 804 CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.)

Components: FUSE F3 (10307); LIGHT RELAY (10311); LIGHT RELAY (10311-R3); OUTPUT (10202); YEL DOT (11647)
Wires (circuit gauge+color): B14CA 14RD; B14DA 18RD; B14E 14RD; B14FA 18RD; B14G 14RD; B63A 18DKBL; B63B 18DKBL; B63C 18DKBL; B63D 14DKBL; B63E 14DKBL
See also sheets: CH18_45
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.69. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.), P. 45D / CHAPTER 18 CHILD CHECKMATE/THEFT MATE SYSTEM W/SNOOZE W/LIFT (CONT.) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 20MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / REAR DOME LIGHT RELAY (10311) / C2 30 / D2 86 / 85 C1 / FUSE F3 (10307) CH3_94Q / B63D 14DKBL / B63B 18DKBL / B14DA 18RD / DOME LT OUTPUT (10202) CH8_36B / E2 30 / F2 86 / 85 E1 / B14E 14RD B14FA 18RD / B63C 18DKBL / B63E 14DKBL / B63A 18DKBL / FRONT DOME LIGHT RELAY (10311-R3) / THEFT MATE YEL DOT (11647) CH18_45 / B14CA 14RD / B14G 14RD / DOME LT OUTPUT (10202) CH8_36A / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 804 / CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.)

18.70. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.), P. 45E
Figure 805 CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.)

Components: ALARM RELAY (10308); CHILD MONITOR RELAY (10312); GROUND SPLICE (10335B); GROUND SPLICE (10336); HAZARD ASSERT (11338); PTI RELAY (10309); RED DOT (11642A); RELAY (10311); SPLICE BLOCK (11502); THEFT MATE RED DOT (11642A)
Wires (circuit gauge+color): B122DC 18GY; B125-G 18WH; B125-GA 16WH; B125-GA 18GY; B125-GB 18GY; B125-GE 18WH; B53B-G 18WH; B60-G 16WH; B85A-G 18WH
See also sheets: CH18_23, CH18_45, CH18_48, CH18_49
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.70. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.), P. 45E / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 20MAR21 / CHAPTER 18 CHILD CHECKMATE/THEFT MATE SYSTEM W/SNOOZE W/LIFT (CONT.) / MJV0488 19NOV21 ADDED CHAPTER REFERENCES CH18_49,40A. / CCM/TM GROUND SPLICE BLOCK (11502) / B125-GA 16WH / B60-G 16WH / B85A-G 18WH / B53B-G 18WH / B53C-G 18GH / B125-GE 18WH / B122DC 18GY / #B125-GB 18GY B125-G 18WH / GROUND SPLICE (10336) CH3_95J GROUND SPLICE (10335B) CH3_95H IN POWER HAZARD ASSERT (11338) CH18_23 / %B125-G 18WH / %B125-GA 18GY / THEFT MATE RED DOT (11642A)CH18_48 / THEFT MATE RED DOT (11642A)CH18_49 CHILD SAFETY ALARM RELAY (10308)CH18_40A THEFT MATE RED DOT (11642A)CH18_45 CHILD MONITOR RELAY (10312) CH18_45C / %B125-GB 18GY / PTI RELAY (10309) CH18_45B / PTI RELAY (10309) CH18_45B / PTI RELAY (10309) CH18_45B / CHILD MONITOR RELAY (10312) CH18_45C / 2 MIN TIMER RELAY (10311) CH18_45C / # W/THEFT MATE W/EMERGENCY ACTIVATED DOME W/R ROW DOME LT % W/CHILD CHECK MATE/THEFT MATE W/EMERGENCY ACTIVATED DOME LT / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / #B125-GA 18GY / Figure 805 / CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.)

18.71. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.), P. 45F
Figure 806 CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.)

Components: BRAKE CCM (9556); CHILD MONITOR RELAY (10312); FUSE B2 (10304); MIN TIMER RELAY (10311-H2); MIN TIMER RELAY (10312-G2); PLATFORM (1702); SPLICE BLOCK (11503); THEFT MATE RED DOT (11642A)
Wires (circuit gauge+color): A4PK 18RD; B14 18RD; B14A 18RD; B14DB 18RD; B14F 18RD; B14HA 18RD; B14HB 18RD; B14X 18RD
See also sheets: CH18_45
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.71. CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.), P. 45F / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 20MAR21 / CHAPTER 18 CHILD CHECKMATE/THEFT MATE SYSTEM W/SNOOZE W/LIFT (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / CCM/TM POWER SPLICE BLOCK (11503) / B14 18RD / B14A 18RD / B14HB 18RD / B14X 18RD / B14DB 18RD / B14F 18RD / FUSE B2 (10304) CH3_94J / THEFT MATE RED DOT (11642A) CH18_45 / B14HA 18RD / CHILD MONITOR RELAY (10312) CH18_45C / 2 MIN TIMER RELAY (10312-G2) CH18_45C / 2 MIN TIMER RELAY (10311-H2) CH18_45C / AIR PARK BRAKE CCM (9556) CH18_39A / A4PK 18RD / ELEC PANEL/ PLATFORM (1702) 45 / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 806 / CHILD CHECKMATE / THEFT MATE SYSTEM WITH SNOOZE AND LIFT (CONT.)

18.72. BUS SCAN, P. 46
Figure 807 BUS SCAN

Components: BODY CONTROLLER (1603); BUS SCAN MODULE (10211); BUS SCAN PILOT LIGHT (10324); CHASSIS (1700); ELEC PANEL (1703); FUSE F40 (10304); FUSE F54 (10305); GROUND SPLICE (10335B); LEFT BODY (10401A/B); PILOT LIGHT (10325); PTI RELAY (10309)
Wires (circuit gauge+color): A125A 16GY; A125B 16GY; A85 16GY; A85A 16GY; B125 18GY; B125-G 16WH; B125-GA 18WH; B125-GB 16WH; B125A 18GY; B125C 18GY; B125D 16GY; B125E 18GY; B125F 16GY; B125H 16GY; B125J 18GY; B125K 18GY; B85 16GY; B85A 16GY; B85C 16GY; B85E 14GY; B85T 14GY; M11-G 10WH; M11-G 14WH; M85-GA 16WH; M85-GC 16WH; M85-GD 16WH; M85-GE 16WH; M85A 16GY; M85J 16GY; M85K 16GY; M85L 16GY
See also sheets: CH18_47
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.72. BUS SCAN, P. 46 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 27MAR21 / BUS SCAN / CHAPTER 18 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 8 8 / B125-G 16WH / 7 RELAY COM CONT / B125C 18GY / FUSE F54 (10305) CH3_94L FUSE F40 (10304) CH3_94J ELEC PANEL/ LEFT BODY (10401A/B) CH18_47 / BUS-SCAN PILOT LIGHT / B125K 18GY / GROUND SPLICE (10335B) CH3_95H / B125D 16GY / B125 18GY B125E 18GY / 5 HORN SENSE / BUS SCAN MODULE (10211) / BUS SCAN PILOT LIGHT (10325) A B125-GB 16WH / B125A 18GY B125-GA 18WH / 1 GROUND / 2 IGNITION / B125F 16GY / RELAY NO CONT / BUS SCAN PILOT LIGHT (10324) A / A3 85 / 30 A4 B85A 16GY B85C 16GY / 86 PTI RELAY (10309) PTI RELAY (10309) CH18_4A PTI RELAY (10309) CH18_42A PTI RELAY (10309) CH18_42A / B85 16GY B3 87A / PLATFORM/ ELEC PANEL #A85 (1703) 16GY B7 A125A 16GY A125B 16GY #A85A 16GY PLATFORM/ FORWARD CHASSIS (1700) / B125J 18GY / B125H 16GY / J1-12WAY BODY CONTROLLER (1603) ELECTRIC HORN E / HORN (%8310/@8310A) A M85J 16GY / UPPER DASH GROUND STUD (2GA) / M85-GA 16WH / M85A 16GY / M11-G M11-G 14WH 10WH / M85-GC 16WH / M85L 16GY / M85-GE 16WH / ELECTRIC HORN#2 (8312) / ELECTRIC HORN#1 (8311) / M85K 16GY M85-GD 16WH / * N/POST TRIP INSPECTION # PTI W/CHILD REMINDER SYSTEM % W/DISC STYLE HORN SIGNAL @ W/HORN ABOVE FRAME SIGNAL / A B / A B / B85E 14GY / B85T 14GY / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / *A85 16GY / Figure 807 / BUS SCAN

18.73. BUS SCAN W/ PTI DEACTIVATION SW IN BULKHEAD, P. 47
Figure 808 BUS SCAN W/ PTI DEACTIVATION SW IN BULKHEAD

Components: LEFT BODY (10401A/B-10401); MODULE (10211); REAR CAP (10405); SPLICE (10335B); SWITCH (10178A); SWITCH (10178B-A)
Wires (circuit gauge+color): B125A 18GY; B125B 18GY; D125A 16GY; D125B 16GY; E125A 16GY; E125B 16GY
See also sheets: CH18_46
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.73. BUS SCAN W/ PTI DEACTIVATION SW IN BULKHEAD, P. 47 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 27MAR21 / CHAPTER 18 BUS SCAN W/PTI DEACTIVATION SW IN BULKHEAD / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/ LEFT BODY (10401A/B-10401) C7 / B125A 18GY / B125B 18GY / LEFT BODY/ REAR CAP (10405) D3 / SC SC / STOP and check! / PTI DEACTIVATION SWITCH (10178A) / D125B 16GY / D125A 16GY / E125B 16GY / E125A 16GY / PTI DEACTIVATION SWITCH (10178B-A) / BUS SCAN MODULE (10211) CH18_46 GROUND SPLICE (10335B) CH3_95H / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 808 / BUS SCAN W/ PTI DEACTIVATION SW IN BULKHEAD

18.74. CHILD CHECKMATE / THEFT MATE SYSTEM WITH EMERGENCY EXIT ACT AND DOME LIGHT, P. 48
Figure 809 CHILD CHECKMATE / THEFT MATE SYSTEM WITH EMERGENCY EXIT ACT AND DOME

Components: CHASSIS (1700); CONTROLLER (1603); ELEC PANEL (10401); ELEC PANEL (1703); EXTEND (10358B); FUSE F40 (10304); FUSE F41 (10304); FUSE F48 (10304); OUTPUT 1 (11649); OUTPUT 2 (11650); OUTPUT 3 (11651); RED DOT (11642A); RELAY (10309-R4); SPLICE PACK (11502); YEL DOT (11647)
Wires (circuit gauge+color): A125A 16GY; A125B 16GY; B119 18GY; B125-GA 18GY; B125A 16GY; B125AD 18GY; B125AE 18GY; B125AF 18GY; B125B 16GY; B125B 18GY; B125E 18GY; B125F 18GY; B125FA 18GY; B125H 18GY; B125N 18GY; B14CMA 18RD; M11-G 10WH; M11-G 14WH; M85-GA 16WH; M85-GC 16WH; M85-GD 16WH; M85-GE 16WH; M85A 16GY; M85J 16GY; M85K 16GY; M85L 16GY
See also sheets: CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.74. CHILD CHECKMATE / THEFT MATE SYSTEM WITH EMERGENCY EXIT ACT AND DOME LIGHT, P. 48 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 95885P 27MAR21 / CHAPTER 18 CHILD CHECKMATE/THEFT MATE SYSTEM W/EMERGENCY EXIT ACTUATOR W/DOME LT / MJV0488 10JUN21 INITIAL PRODUCTION RELEASE. / CHILD CHECK-MATE SYSTEMS EP-2 PLUS / 1 2 3 5 / THEFT MATE RED DOT (11642A) B14CMA 18RD / B125-GA 18GY B125H 18GY B119 18GY / B125B 18GY / 85 B125E A3 18GY B125FA 18GY / 1 2 3 / THEFT MATE 4 YEL DOT (11647) / 5 B125N 18GY / B125AE 18GY THEFT MATE DIGITAL OUTPUT 1 (11649) / B125AF 18GY THEFT MATEDIGITAL OUTPUT 2 (11650) / PTI RELAY FRONT DOME 10311 CH18_7A THEFT MATE DIGITAL OUTPUT 3 (11651) / B125AD 18GY / A4 30 / C4 86 / PTI RELAY (10309-R4) / 87A B3 B125A 16GY / B125F 18GY / B125B 16GY / PLATFORM/ FORWARD CHASSIS (1700) / A125B 16GY / HORN (*8310/&8310A) A M85A M85J 16GY 16GY M85-GA M85-GC 16WH 16WH / M85-GD 16WH / ELECTRIC HORN#1 (8311) A M85K 16GY B / M85L 16GY / M85-GE 16WH / ELECTRIC HORN # 2 (8312) A B / A125A 16GY / M11-G 14WH M11-G 10WH / UPPER DASH GROUND STUD (2GA) / PLATFORM/ ELEC PANEL (1703) B7 / * W/DISC STYLE HORN SIGNAL & W/HORN ABOVE FRAME SIGNAL / Figure 809 / CHILD CHECKMATE / THEFT MATE SYSTEM WITH EMERGENCY EXIT ACT AND DOME LIGHT

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 850 | printed page 810 | section 18.75
18.75. THEFT MATE WITH EMERGENCY EXIT ACT DOME LIGHT AND REAR ROW DOME LIGHT, P. 49
Figure 810 THEFT MATE WITH EMERGENCY EXIT ACT DOME LIGHT AND REAR ROW DOME LIGHT

Components: BLOCK (11502); EXTEND (10358B); FUSE F40 (10304); FUSE F45 (10304); FUSE F48 (10304); OUTPUT (11649); OUTPUT (11650); OUTPUT (11651); PTI RELAY (10309); RED DOT (11642A); YEL DOT (11647)
Wires (circuit gauge+color): B119 18GY; B125-GA 18GY; B125AD 18GY; B125AE 18GY; B125AF 18GY; B125E 18GY; B125H 18PK; B125N 18GY; B13DJ 12BK; B14CMA 18RD
See also sheets: CH18_51, CH9_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.75. THEFT MATE WITH EMERGENCY EXIT ACT DOME LIGHT AND REAR ROW DOME LIGHT, P. 49 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 96289K 22SEP21 / CHAPTER 18 THEFT MATE W/EMERGENCY EXIT ACT DOME LT W/REAR ROW DOME LT / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / 5 6 / CHILD CHECK-MATE SYSTEMS EP-2 PLUS / 1 2 3 / THEFT MATE RED DOT (11642A) FUSE F40 (10304) B14CMA (B14N) 18RD A2 5A B2 / B125-GA 18GY FUSE F48 (10304) B13DJ B125H 12BK 18PK G4 H4 3A / BATT STUD (0PWR) CH3_94J CCM/TM GROUND SPLICE BLOCK (11502) CH18_45E FUSE F45 (10304) CH3_94K STOP ARM EXTEND (10358B) CH9_03 PTI RELAY (10309) CH18_51 / B119 18GY / B125E 18GY / 1 2 3 / THEFT MATE 5 YEL DOT (11647) / B125AD 18GY / B125AE 18GY / B125AF 18GY / THEFT MATE DIGITAL 1 OUTPUT (11649) / THEFT MATE DIGITAL 2 OUTPUT (11650) / THEFT MATE DIGITAL 3 OUTPUT (11651) / B125N 18GY / PTI RELAY (10309) CH18_51 / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 810 / THEFT MATE WITH EMERGENCY EXIT ACT DOME LIGHT AND REAR ROW DOME LIGHT

18.76. THEFT MATE WITH EMERGENCY EXIT ACT DOME LIGHT AND REAR ROW
Figure 811 THEFT MATE WITH EMERGENCY EXIT ACT DOME LIGHT AND REAR ROW DOME LIGHT

Components: FRONT CAP (10000); FRONT CAP (10001); FUSE F51 (10305); FUSE F54 (10305); LED OUTPUT (11652); MOTION GN DOT (11641A); MOTION SENSOR (10057A); POST TRIP COM (10045A); POST TRIP NO (10044A); SPLICE (10010); VIO DOT (11648)
Wires (circuit gauge+color): B125AA 18BK; B125AB 18LTGN; B125AC 18RD; B125AH 20GY; B125C 18GY; B125CMD 18GY; B12HJ 10BK; C125 16GY; C125-G 16WH; C125AA 18BK; C125AB 18LTGN; C125AC 18RD; C125AD 18BK; C125AE 18BK
See also sheets: CH3_44
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.76. THEFT MATE WITH EMERGENCY EXIT ACT DOME LIGHT AND REAR ROW DOME LIGHT (CONT.), P. 50 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 96289K 22SEP21 / CHAPTER 18 THEFT MATE W/EMERGENCY EXIT ACT DOME LT W/REAR ROW DOME LT (CONT.) / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / CHILD CHECK-MATE SYSTEMS / EP-2 PLUS / GROUND SPLICE (10010) CH3_44 / B125AH 20GY / THEFT MATE LED OUTPUT (11652) / 1 2 / C125AA 18BK / B125AA B125AB 18LTGN 18BK / B125AC 18RD / C125AB 18LTGN / C125AC 18RD / 2 3 / THEFT MATE MOTION GN DOT (11641A) / ELEC PANEL/ FRONT CAP (10001) / CHILD CHECK MOTION SENSOR (10057A) / 1 2 / 1 2 3 / 1 2 / + - / RD BK / ELEC PANEL/ POST TRIP NO C12 FRONT CAP (10044A) (10000) A C125 16GY / C125-G 16WH POST TRIP COM (10045A) / B125CMD 18GY / THEFT MATE SIGNAL VIO DOT (11648) / C125AD 18BK / C125AE 18BK / FUSE F54 (10305) H2 G2 3A / B125C 18GY / B12HJ 10BK / FUSE F51 (10305) CH3_94L / NOTE: CONNECTIONS FOR VEHICLE N/0508108 - NOT MTA FUSE BLOCK. / Figure 811 / THEFT MATE WITH EMERGENCY EXIT ACT DOME LIGHT AND REAR ROW DOME LIGHT (CONT.)

18.77. THEFT MATE WITH EMERGENCY EXIT ACT DOME LIGHT AND REAR ROW
Figure 812 THEFT MATE WITH EMERGENCY EXIT ACT DOME LIGHT AND REAR ROW DOME LIGHT

Components: ALARM RELAY (10308); DOME LT (10230); DOME LT (10233); ELEC PANEL (10401A); FUSE F26 (10303); FUSE F41 (10304); OUTPUT (10202); PLATFORM (1703); RED DOT (11642); RELAY (10309); YEL DOT (11647)
Wires (circuit gauge+color): B125A 16GY; B125B 16GY; B125E 18GY; B125F 18GY; B125FA 18GY; B125J 16GY; B125K 16GY; B125L 16GY; B125M 16GY; B125N 18GY; B125P 18GY; B125PA 18GY; B63D 16LTBL; B63RW 16DKBL; B63T 16LTBL; B63X 16DKBL
See also sheets: CH18_49, CH18_52
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.77. THEFT MATE WITH EMERGENCY EXIT ACT DOME LIGHT AND REAR ROW DOME LIGHT (CONT.), P. 51 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 96289K 22SEP21 / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / PTI RELAY (10309) / B125B 16GY A4 30 / C4 86 / 85 A3 / 87A B3 / B125E 18GY B125FA 18GY / DOME LT OUTPUT (10202) CH8_36A STD/FR DOME LT (10230) CH8_14A / D4 30 / F4 86 / PTI RELAY (10309) 85 D3 / 87A E3 / G4 30 / J4 86 / PTI RELAY (10309) 85 G3 / 87A H3 / B63RW 16DKBL / B63X 16DKBL / B125N 18GY B125K 16GY / B125J 16GY / B63T 16LTBL / B63D 16LTBL / B125PA 18GY B125P 18GY / B125L 16GY B125M 16GY / CHILD SAFETY ALARM RELAY (10308) CH18_40A / ELEC PANEL/ PLATFORM (1703) CH18_52 / THEFT MATE RED DOT (11642) CH18_49 / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / B125A 16GY / L BODY/ ELEC PANEL (10401A) CH8_9B / REAR ROW DOME LT (10233) CH8_9B / FUSE F26 (10303) CH3_94G / THEFT MATE YEL DOT (11647) CH18_49 / FUSE F26 (10303) CH3_94G / FUSE F41 (10304) CH3_94K / B125F 18GY / Figure 812 / THEFT MATE WITH EMERGENCY EXIT ACT DOME LIGHT AND REAR ROW DOME LIGHT (CONT.)

18.78. THEFT MATE WITH EMERGENCY EXIT ACT DOME LIGHT AND REAR ROW
Figure 813 THEFT MATE WITH EMERGENCY EXIT ACT DOME LIGHT AND REAR ROW DOME LIGHT

Components: CHASSIS (1700); CONTROLLER (1603); ELEC PANEL (1703); PLATFORM (1703)
Wires (circuit gauge+color): A125A 16GY; A125B 16GY; B125A 16GY; B125B 16GY; M11-G 10WH; M11-G 14WH; M85 16GY; M85-GA 16WH; M85-GC 16WH; M85-GD 16WH; M85-GE 16WH; M85J 16GY; M85K 16GY; M85L 16GY
See also sheets: CH18_51
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.78. THEFT MATE WITH EMERGENCY EXIT ACT DOME LIGHT AND REAR ROW DOME LIGHT (CONT.), P. 52 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 96289K 22SEP21 / CHAPTER 18 THEFT MATE W/EMERGENCY EXIT ACT DOME LT W/REAR ROW DOME LT (CONT.) / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / B125B 16GY / PLATFORM/ FORWARD 16 CHASSIS (1700) / J1-12WAY BODY CONTROLLER (1603) / A125B 16GY / HORN (*8310/&8310A) A M85J M85 16GY 16GY / M85K 16GY M85-GD 16WH / ELECTRIC HORN#1 (8311) / M85-GC 16WH / M85L 16GY / M85-GE 16WH / A B / A B / ELECTRIC HORN # 2 (8312) / A125A 16GY / M11-G 14WH M11-G 10WH / M85-GA 16WH / UPPER DASH GROUND STUD (2GA) / PLATFORM/ ELEC PANEL (1703) / * W/DISC STYLE HORN SIGNAL & W/HORN ABOVE FRAME SIGNAL / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / ELECTRIC E HORN / B125A 16GY / ELEC PANEL/ PLATFORM (1703) CH18_51 ELEC PANEL/ PLATFORM (1703) CH18_51 / W/CITY HORN / Figure 813 / THEFT MATE WITH EMERGENCY EXIT ACT DOME LIGHT AND REAR ROW DOME LIGHT (CONT.)

18.79. DOME LIGHT ACTIVATED BY ENTRANCE DOOR WITH REAR ROW DOME, P. 53
Figure 814 DOME LIGHT ACTIVATED BY ENTRANCE DOOR WITH REAR ROW DOME

Components: DIODE D76 (10307); DIODE D79 (10307); DOME LIGHT OUT (11640); FUSE F80 (10307); LIGHT RELAY (10311); LT RELAY (10311); OUTPUT (10202); RELAY (10311); SPLICE (10204); SPLICE (10335B); SPLICE (10389)
Wires (circuit gauge+color): B63A 18DKBL; B63B 18DKBL; B63C 16DKBL; B63D 16DKBL; B63E 16DKBL; B63F 18DKBL; B63GA 18WH; B63H 18DKBL; B63K 18DKBL; B63S 16DKBL; B63T 16DKBL
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.79. DOME LIGHT ACTIVATED BY ENTRANCE DOOR WITH REAR ROW DOME, P. 53 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 96289K 22SEP21 / CHAPTER 18 DOME LT ACTIVATED BY ENTRANCE DOOR W/REAR ROW DOME / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / C2 30 / B63K 18DKBL D2 86 / 85 C1 / B63GA 18WH / 87A D1 / B63S 16DKBL / 85 E1 / F2 86 / 87A F1 / E2 30 / DOME LIGHT OUTPUT (10202) CH8_36A,36B / B63T 16DKBL / 87A B1 / B63D 16DKBL B63E 16DKBL A2 B2 86 30 / 85 A1 / REAR ROW DOME RELAY (10311) / B63A 18DKBL / CHILD MONITOR DOME LIGHT OUT (11640) DOME LIGHT 2 OUT / FUSE F80 (10307) CH3_94Q / GROUND SPLICE (10335B) CH3_95H / RR DOME LT RELAY (10311) / FR DOME LIGHT RELAY (10311) / B63H 18DKBL / DIODE D76 (10307) B2 / B63F 18DKBL / DOOR OPTION SPLICE (10389) CH8_23A / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / EMER EXIT BUZZER SPLICE (10204) CH14_1A / DIODE D79 (10307) B3 / B63B 18DKBL / B63C 16DKBL / Figure 814 / DOME LIGHT ACTIVATED BY ENTRANCE DOOR WITH REAR ROW DOME

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 855 | printed page 815 | section 18.80
18.80. EMERGENCY EXIT / ENTRANCE DOOR ACTIVATED DOME WITH REAR ROW DOME, P. 54
Figure 815 EMERGENCY EXIT / ENTRANCE DOOR ACTIVATED DOME WITH REAR ROW DOME

Components: DIODE D70 (10306); DIODE D79 (10307); DOME LT (10230); DOME SW (10233); FUSE F26 (10303); FUSE F48 (10304); L BODY (10401A); LT RELAY (10311); OUTPUT (10202); RELAY (10311); SPLICE (10204); SPLICE (10335A); SPLICE (10389)
Wires (circuit gauge+color): B11-G 18WH; B11-GA 18WH; B117D 18GY; B13A 18PK; B14M 6RD; B63-GM 18WH; B63D 12DKBL; B63MJ 18DKBL; B63P 14DKBL; B63P 18DKBL; B63R 14DKBL; B63T 16DKBL; B63U 18DKBL; B63UA 18DKBL; B63UB 18DKBL; B63WA 16DKBL; B63WB 16DKBL
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.80. EMERGENCY EXIT / ENTRANCE DOOR ACTIVATED DOME WITH REAR ROW DOME, P. 54 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 96289K 23SEP21 / CHAPTER 18 EMERGENCY EXIT/ENTRANCE DOOR ACTIVATED DOME W/REAR ROW DOME / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / E2 30 / F1 86 FR DOME LT RELAY (10311) / 85 E1 / B14M 6RD (B14M) / B63T 16DKBL / 2 MIN TIMER RELAY (10311) 85 H1 / J2 86 / 87A G1 / H2 30 / DOME LIGHT OUTPUT (10202) CH8_36A,36B / B63D 12DKBL / 87A C2 / %B63P 14DKBL B63WA 16DKBL / 85 C1 / D2 86 / D1 30 / REAR DOME LT RELAY (10311) / B11-G 18WH / STD/FR DOME LT (10230) CH8_13A REAR ROW DOME SW (10233) CH8_9A / FUSE F26 (10303) CH3_94G / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / DIODE D70 (10306) A4 / B63UA 18DKBL / B63UB 18DKBL / 18DKBL B63P / 85 A1 / B63MJ 18DKBL B2 86 EMERGENCY EXIT ACTIVATION RELAY (10311) / % W/2 MIN TIMER / B11-GA 18WH / B63WB 16DKBL %B63R 14DKBL / B63U 18DKBL / B63U 18DKBL / DIODE D79 (10307) A3 / B117D 18GY / B63-GM 18WH / EMERGENCY EXIT BUZZER SPLICE (10204) CH14_1A / GROUND SPLICE (10335A) CH3_95G / ELEC PANEL/ L BODY (10401A) CH8_9A / B13A 18PK / FUSE F48 (10304) CH3_94K / STD/FR DOME LT (10230) CH8_13A / DOOR OPTIO SPLICE (10389) CH8_23A / Figure 815 / EMERGENCY EXIT / ENTRANCE DOOR ACTIVATED DOME WITH REAR ROW DOME

18.81. EMERGENCY EXIT ACCESSORY FEED WITH MECHANICAL BUZZER, P. 55
Figure 816 EMERGENCY EXIT ACCESSORY FEED WITH MECHANICAL BUZZER

Components: DIODE (10444); REAR CAP (10405)
Wires (circuit gauge+color): B12JAB 18LTBL; B12JAC 18LTBL; E12C 18LTBL
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 18.81. EMERGENCY EXIT ACCESSORY FEED WITH MECHANICAL BUZZER, P. 55 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090669 NO. 96289K 23SEP21 / CHAPTER 18 EMERGENCY EXIT ACCESSORY FEED W/MECH BUZZER / MJV0488 19NOV21 INITIAL PRODUCTION RELEASE. / NC BUZZER DIODE (10444) / A A / ELEC PANEL/ L BODY (10400B/ 10400) C8 / B12JAB 18LTBL B12JAC 18LTBL / E12C 18LTBL / L BODY/ REAR CAP (10405) CH14_19A / NOTE: CONNECTIONS FOR VEHICLES N/0508108-NOT MTA FUSE BLOCK. / Figure 816 / EMERGENCY EXIT ACCESSORY FEED WITH MECHANICAL BUZZER

Figure 817 BOOSTER PUMP W/ ESPAR HEATER W/ TIMER

Components: BE/CE (11536/11537); BOOSTER PUMP SW (10255); EMISSIONS (11502); ENGINE (11500); FUSE A1-C (10305); FUSE B3-G (10304); FUSE B6-B (10303); FWD CHASSIS (1700); HTR W/TIMER (9996); PLATFORM (1702); PLATFORM (1703); PRE 2010 EMISSIONS (11524); RELAY (10311-R4); RELAY (10311-R5); SPLICE (10331); SPLICE (10335A); TIMER (1053)
Wires (circuit gauge+color): A74A 16LTGN; A74H 18LTGN; A74L 16LTGN; A74L 18LTGN; A74P 18LTGN; B62-GC 18WH; B62C 18DKBL; B74-G 18WH; B74AB 12LTGN; B74B 14LTGN; B74BB 12LTGN; B74CA 16LTGN; B74D 12LTGN; B74D 16LTGN; B74E 16LTGN; B74F-G 18WH; B74H 16LTGN; B74J 16LTGN; B74K 16LTGN; B74L 16LTGN; B74M 12LTGN; B74N 16LTGN; B74P 16LTGN; B74R-G 18WH; B74S 14LTGN; B74T 16LTGN; Y74 12LTGN; Y74-G 12WH
See also sheets: CH19_10, CH19_12, CH19_13, CH19_17, CH3_09, CH3_10, CH3_18, CH3_35, CH3_47, CH8_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / HEATERS / AIR CONDITIONING / ACCESSORIES (CHAPTER 19) / 19.1. BOOSTER PUMP W/ ESPAR HEATER W/ TIMER, P. 1 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 BOOSTER PUMP W/ESPAR HEATER W/TIMER / MJV0488 19NOV21 CIRC B74CA,B74BB, B 96289K B74AB WERE B74C,B74B,B74A AT R/D 10255. / BOOSTER PUMP RELAY (10311-R5) 85 / BOOSTER PUMP SW (10255) / 12LTGN B74AB / B74CA 16LTGN / 12LTGN B74M 87A / &B74BB 12LTGN #B74D 12LTGN / B74N 16LTGN B74T 16LTGN / 12LTGN Y74 / B62C 18DKBL B62-GC 18WH / GROUND SPLICE (10335A) CH3_35 / B74F-G 18WH / ELEC PANEL/ SEALED A4 ENGINE (11500) / Y74-G 12WH / BOOSTER PUMP PRE 2010 EMISSIONS (11524)/ 2010 EMISSIONS (11502) BOOSTER PUMP MOTOR / BOOSTER PUMP RELAY (10311-R4) / SW ILLUM SPLICE (10331) CH8_32 ESPAR COOLANT HTR W/TIMER (9996) CH19_12 ESPAR MULTIMAX TIMER (1053) CH19_13 / ELEC PANEL/ PLATFORM A74H (1702) 18LTGN 17 B74L A74L 16LTGN 16LTGN 16 B74H A74H 16LTGN 18LTGN ELEC PANEL/ PLATFORM (1703) B15 / 16LTGN B74K / B74B 14LTGN B74S 14LTGN Y74 12LTGN / #B74E 16LTGN / B74-G 18WH / FUSE B3-G (10304) CH3_10,25 / B74P 16LTGN / FUSE A1-C (10305) CH3_18 / 16LTGN B74D / & W/STANDARD & ESPAR HTR # W/ESPAR HTR W/TIMER / SEALED ENG GROUND (OGND) CH3_47 NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / A74P 18LTGN A74L 18LTGN A74A 16LTGN / PLATFORM/ FWD CHASSIS (1700) CH19_13 PLATFORM/ FWD CHASSIS (1700) CH19_12 WEBASTO SMART TIMER (8331) CH19_17 / BOOSTER PUMP HIGH OUTPUT BE/CE (11536/11537) CH19_10 / B74J 16LTGN / FUSE B6-B (10303) CH3_09 / B74R-G 18WH / W/ESPAR HTR W/TIMER / Figure 817 / BOOSTER PUMP W/ ESPAR HEATER W/ TIMER

19.2. BOOSTER PUMP W/ FRONT MOUNTED HEATER W/ TIMER IN ELECTRICAL PANEL OR OVERHEAD DRIVER COMPARTMENT, P. 2
Figure 818 BOOSTER PUMP W/ FRONT MOUNTED HEATER W/ TIMER IN ELECTRICAL PANEL OR

Components: B6-B (10303); BOOSTER PUMP SW (10255); EMISSIONS (11535); FUSE B3-G (10304); FUSE B6-B (10303); HIGH OUTPUT (11536); PLATFORM (1702); PLATFORM (1703); PRE 2010 EMISSIONS (11524); RELAY (10311-R5); SEALED ENG (11500); SPLICE (10331); SPLICE (10335A)
Wires (circuit gauge+color): B62-GA 18WH; B62-GC 18WH; B62A 18DKBL; B62C 18DKBL; B74 16LTGN; B74-G 16WH; B74-GB 14WH; B74-GC 16WH; B74AB 12LTGN; B74B 14LTGN; B74BB 12LTGN; B74C 16LTGN; B74D 16LTGN; B74D 18LTGN; B74E 16LTGN; B74F 14LTGN; B74G 12LTGN; B74H 12LTGN; B74J 16LTGN; B74K 12LTGN; B74L 18LTGN; B74M 16LTGN; B74N-G 14WH; B74P 14LTGN; B74R 16LTGN; B74S 16LTGN; Y74 12LTGN; Y74-G 12WH
See also sheets: CH19_10, CH19_18, CH2_35, CH3_09, CH3_10, CH3_35, CH8_20
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.2. BOOSTER PUMP W/ FRONT MOUNTED HEATER W/ TIMER IN ELECTRICAL PANEL OR OVERHEAD DRIVER COMPARTMENT, P. 2 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 BOOSTER PUMP W/FRONT MOUNTED HEATER W/TIMER IN ELECTRICAL PANEL OR OVERHEAD DRIVER COMPARTMENT / MJV0488 19NOV21 CIRC B74BB,B74AB WERE B74B,B74A AT R/D 10255. / #B74-GB 14WH BOOSTER PUMP RELAY (10311-R5) 85 / BOOSTER PUMP SW (10255) / 12LTGN 12LTGN #B74H B74AB / 12LTGN #B74G / 12LTGN #B74K / #B74D 16LTGN / 12LTGN Y74 / *B62C 18DKBL #B62A 18DKBL #B62-GA 18WH *B62-GC 18WH / FUSE B6-B (10303) CH3_09 / FUSE B3-G (10304) CH3_10 / #B74N-G 14WH #B74C 16LTGN / Y74 12LTGN Y74-G 12WH / SEALED ENG GROUND (OGND) CH3_35 / BOOSTER PUMP MOTOR / BOOSTER PUMP RELAY (10311- R4) / BOOSTER PUMP PRE 2010 EMISSIONS (11524)/ 2010 EMISSIONS (11535) / 14LTGN B74B / 14LTGN B74F / 16LTGN 16LTGN #B74J *B74S / ELEC PANEL/ SEALED ENG (11500) / GROUND SPLICE (10335A) CH3_35 / 3 1 / WEBASTO SMART TEMP TIMER (*11623A/ #14510A) / 18LTGN #B74L *B74D 18LTGN / #B74E 16LTGN / #B74M 16LTGN / B74-G 16WH / SW ILLUM SPLICE (10331) CH8_20 / FUSE GROUND B6-B STUD (10303) (#39/*42) CH3_09 CH2_35 / BOOSTER PUMP HIGH OUTPUT (11536) CH19_10 / ELEC PANEL/ PLATFORM (1702) CH19_18 / ELEC PANEL/ PLATFORM (1703) CH19_18 / * W/TIMER IN ELECTRICAL PANEL # W/TIMER IN OVERHEAD DRIVER COMPARTMENT NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / 16LTGN *B74 / #B74-GC 16WH / 14LTGN #B74P / #B74R 16LTGN / *B74BB 12LTGN / Figure 818 / BOOSTER PUMP W/ FRONT MOUNTED HEATER W/ TIMER IN ELECTRICAL PANEL OR OVERHEAD DRIVER COMPARTMENT

19.3. BOOSTER PUMP W/ FR MOUNTED HEATER W/ SMART TIMER, P. 3
Figure 819 BOOSTER PUMP W/ FR MOUNTED HEATER W/ SMART TIMER

Components: BOOSTER PUMP SW (10255); ELEC PANEL/PLATFORM (1702-17); EMISSIONS (11535); ENGINE (11500); FUSE B3-G (10304); FUSE B6-B (10303); HIGH OUTPUT (11536); PLATFORM (1702); PLATFORM (1703); PRE 2010 EMISSIONS (11524); RELAY (10311-R4); RELAY (10311-R5); SPLICE (10331); SPLICE (10335A); TEMP TIMER (11623A)
Wires (circuit gauge+color): B62-GC 18WH; B62C 18DKBL; B74 12LTGN; B74-G 16WH; B74-GB 14WH; B74-GC 16WH; B74AB 12LTGN; B74B 14LTGN; B74BB 12LTGN; B74C 16LTGN; B74D 16LTGN; B74E 16LTGN; B74F 14LTGN; B74H 14LTGN; B74J 16LTGN; B74K 16LTGN; B74L 18LTGN; B74M 12LTGN; B74N-G 14WH; B74P 14LTGN; B74P 16RD; B74R 16LTGN; Y74 12LTGN; Y74-G 12WH
See also sheets: CH19_10, CH19_18, CH3_09, CH3_10, CH3_35, CH3_47, CH8_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.3. BOOSTER PUMP W/ FR MOUNTED HEATER W/ SMART TIMER, P. 3 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 BOOSTER PUMP W/FRONT MOUNTED HEATER W/SMART TIMER / MJV0488 19NOV21 CIRC B74BB,B74AB B WERE B74B,B74A AT R/D 10255. / BOOSTER PUMP RELAY (10311-R5) 85 / BOOSTER PUMP SW (10255) / 12LTGN 14LTGN B74AB B74H / 12LTGN B74 / BOOSTER PUMP RELAY (10311-R4) 85 / 12LTGN B74M / B74D 16LTGN / 12LTGN Y74 / B62C 18DKBL B62-GC 18WH / FUSE B3-G (10304) CH3_10 / B74N-G 14WH B74C 16LTGN / Y74 12LTGN Y74-G 12WH 2 / SEALED ENG GROUND (OGND) CH3_47 / BOOSTER PUMP MOTOR / GROUND SPLICE (10335A) CH3_35 BOOSTER PUMP PRE 2010 EMISSIONS (11524)/ 2010 EMISSIONS (11535) / B74-GC 16WH / 14LTGN B74F / 16LTGN B74J / ELEC PANEL/ SEALED ENGINE (11500) / 3 1 / SMART TEMP TIMER (11623A) / 18LTGN B74L / B74E 16LTGN / B74K 16LTGN / B74-G 16WH / SW ILLUM SPLICE (10331) CH8_32 / GROUND STUD (34) / FUSE B6-B (10303) CH3_09 ELEC PANEL/PLATFORM (1702-17) CH19_18 BOOSTER PUMP HIGH OUTPUT (11536) CH19_10 / ELEC PANEL/ PLATFORM (1702) CH19_18 / ELEC PANEL/ PLATFORM (1703) CH19_18 / % W/SWITCH ONLY / B74P 14LTGN / B74R 16LTGN / %B74BB 12LTGN / B74B 14LTGN %B74P 16RD / B74-GB 14WH / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 819 / BOOSTER PUMP W/ FR MOUNTED HEATER W/ SMART TIMER

19.4. BOOSTER PUMP W/ FR MOUNTED HEATER W/ TIMER RIGHT DRIVER, P. 4
Figure 820 BOOSTER PUMP W/ FR MOUNTED HEATER W/ TIMER RIGHT DRIVER

Components: BOOSTER PUMP SW (10255); ELEC PANEL/PLATFORM (1703); EMISSIONS (11535); FUSE B3-G (10304); FUSE B6-B (10303); HIGH OUTPUT (11536); PLATFORM (1702); PRE 2010 EMISSIONS (11524); RELAY (10311); RELAY (10311-R4); SEALED ENG (11500); SPLICE (10331); SPLICE (10335A)
Wires (circuit gauge+color): B62-GC 18WH; B62C 18DKBL; B74 14LTGN; B74-G 16WH; B74-GA 16WH; B74-GB 16WH; B74AB 12LTGN; B74CA 12LTGN; B74D 14LTGN; B74E 14LTGN; B74J 16LTGN; B74K 16LTGN; B74L 16LTGN; B74M 16LTGN; B74N 12LTGN; B74P 16LTGN; B74U 14LTGN; B74V 16LTGN; Y74 12LTGN; Y74-G 12WH
See also sheets: CH19_10, CH19_17, CH3_09, CH3_10, CH3_35, CH3_47, CH8_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.4. BOOSTER PUMP W/ FR MOUNTED HEATER W/ TIMER RIGHT DRIVER, P. 4 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 BOOSTER PUMP W/FRONT MOUNTED HEATER W/TIMER RIGHT DRIVER / MJV0488 19NOV21 CIRC B74CA,B74AB WERE B74C,B74A AT R/D 10255. / BOOSTER PUMP SW (10255) / B74AB 12LTGN / 12LTGN B74CA / 85 B74-GB 16WH / 14LTGN B74D / 12LTGN B74N / B74J 16LTGN / 12LTGN Y74 / B62C 18DKBL B62-GC 18WH / BOOSTER PUMP RELAY (10311) / GROUND SPLICE (10335A) CH3_35 FUSE B6-B (10303) CH3_09 / B74-GA 16WH B74U 14LTGN B74L 16LTGN / ELEC PANEL/ SEALED ENG (11500) / Y74-G 12WH / SEALED ENG GROUND (OGND) CH3_47 NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / BOOSTER PUMP MOTOR / BOOSTER PUMP RELAY (10311-R4) / SW ILLUM SPLICE (10331) CH8_32 / BOOSTER PUMP PRE 2010 EMISSIONS (11524)/ 2010 EMISSIONS (11535) / 14LTGN B74E / B74-G 16WH 14LTGN B74 / ELEC PANEL/ PLATFORM (1702) CH19_17 / ELEC PANEL/PLATFORM (1703) CH19_17 / FUSE B3-G (10304) CH3_10 / 16LTGN B74P / 16LTGN B74M / BOOSTER PUMP HIGH OUTPUT (11536) CH19_10 / Y74 12LTGN / B74V 16LTGN / B74K 16LTGN / Figure 820 / BOOSTER PUMP W/ FR MOUNTED HEATER W/ TIMER RIGHT DRIVER

19.5. BOOSTER PUMP W/ FR MOUNTED HEATER W/ WHITE TIMER, P. 5
Figure 821 BOOSTER PUMP W/ FR MOUNTED HEATER W/ WHITE TIMER

Components: BE/CE (11536/11537); BOOSTER PUMP SW (10255); COMMON (11621); EMISSIONS (11502); FUSE B3-G (10304); FUSE B6-B (10303); GROUND (11625); OUTPUT (11622); PLATFORM (1703); POWER IN (11624); PRE 2010 EMISSIONS (11524); RELAY (10311); RELAY (10311-R4); SEALED ENG (11500); SPLICE (10331); SPLICE (10335A)
Wires (circuit gauge+color): B62-GC 18WH; B62C 18DKBL; B74-G 18WH; B74-GA 16WH; B74-GB 18WH; B74AB 12LTGN; B74B 14LTGN; B74CA 16LTGN; B74D 14LTGN; B74E 16LTGN; B74F-G 18WH; B74H 16LTGN; B74J 16LTGN; B74K 16LTGN; B74L 16LTGN; B74M 12LTGN; B74P 16LTGN; B74R 16LTGN; B74S 16LTGN; B74T-G 18WH; B74U 14LTGN; B74V 16LTGN; Y74 12LTGN; Y74-G 12WH
See also sheets: CH19_10, CH19_17, CH3_09, CH3_10, CH3_35, CH3_47, CH8_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.5. BOOSTER PUMP W/ FR MOUNTED HEATER W/ WHITE TIMER, P. 5 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 BOOSTER PUMP W/FRONT MOUNTED HEATER W/WHITE TIMER / MJV0488 19NOV21 CIRC B74CA,B74AB WERE B74C,B74A AT R/D 10255. / BOOSTER PUMP RELAY (10311) 85 / D4 30 / BOOSTER PUMP SW (10255) / B74AB 12LTGN / B74CA 16LTGN / BOOSTER PUMP RELAY (10311-R4) 85 / 14LTGN B74D / 12LTGN B74M / B74V 16LTGN / 12LTGN Y74 / B62C 18DKBL B62-GC 18WH / FUSE B6-B (10303) CH3_09 / B74F-G 18WH ELEC PANEL/ SEALED ENG (11500) / Y74 12LTGN Y74-G 12WH / SEALED ENG GROUND (OGND) CH3_47 NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / BOOSTER PUMP MOTOR / SW ILLUM SPLICE (10331) CH8_32 / BOOSTER PUMP PRE 2010 EMISSIONS (11524)/ 2010 EMISSIONS (11502) / B74U 14LTGN / 16LTGN B74E / ELEC PANEL/ PLATFORM (1703) CH19_17 / FUSE B3-G (10304) CH3_10 / 16LTGN B74P / 16LTGN B74R / 16LTGN B74S / B74L 16LTGN BOOSTER PUMP HIGH OUTPUT BE/CE (11536/11537)) CH19_10 / TIMER POWER IN (11624) / TIMER COMMON (11621) / B74-GB 18WH / B74-G 18WH / TIMER OUTPUT (11622) / GROUND SPLICE (10335A) CH3_35 / B74-GA 16WH / TIMER GROUND (11625) / B74H 16LTGN / B74J 16LTGN / B74T-G 18WH / 16LTGN B74K / B74B 14LTGN / Figure 821 / BOOSTER PUMP W/ FR MOUNTED HEATER W/ WHITE TIMER

19.6. BOOSTER PUMP W/ ACTIVATED BY HEATER SWITCH, P. 6
Figure 822 BOOSTER PUMP W/ ACTIVATED BY HEATER SWITCH

Components: BOOSTER PUMP SW (10255); EMISSIONS (11502); FUSE B3-G (10304); PRE 2010 EMISSIONS (11524); RELAY (10311-R4); RELAY SPLICE (10361); SEALED ENG (11500); SPLICE (10331); SPLICE (10335A)
Wires (circuit gauge+color): B62-GC 18WH; B62C 18DKBL; B74-GT 16WH; B74AB 12LTGN; B74R 12LTGN; B74S 12LTGN; B74T 16LTGN; Y74 12LTGN; Y74-G 12WH
See also sheets: CH19_25, CH3_10, CH3_35, CH3_47, CH8_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.6. BOOSTER PUMP W/ ACTIVATED BY HEATER SWITCH, P. 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 BOOSTER PUMP W/ACTIVATED BY HEATER SWITCH / MJV0488 19NOV21 CIRC B74AB WAS B74A AT R/D 10255. / BOOSTER PUMP SW (10255) / 12LTGN B74AB / 12LTGN Y74 / B62C 18DKBL B62-GC 18WH / ELEC PANEL/ SEALED ENG (11500) / Y74-G 12WH / SEALED ENG GROUND (OGND) CH3_47 / BOOSTER PUMP MOTOR / BOOSTER PUMP RELAY (10311-R4) / SW ILLUM SPLICE (10331) CH8_32 / BOOSTER PUMP PRE 2010 EMISSIONS (11524)/ 2010 EMISSIONS (11502) / FUSE B3-G (10304) CH3_10 / %B74T 16LTGN / %B74R 12LTGN / 12LTGN %B74S / %B74-GT 16WH / GROUND SPLICE (10335A) CH3_35 / PUMP SPLICE BOOSTER (10361) CH19_25 RELAY / % W/ACTIVATED BY HTR SW / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 822 / BOOSTER PUMP W/ ACTIVATED BY HEATER SWITCH

19.7. BOOSTER PUMP W/ COOLANT HEATER WIRED SEPARATELY W/ TIMER, P. 7
Figure 823 BOOSTER PUMP W/ COOLANT HEATER WIRED SEPARATELY W/ TIMER

Components: BE/CE (11536/11537); BOOSTER PUMP SW (10255); ELEC PANEL (1703); EMISSIONS (11502); FUSE B3-G (10304); FUSE B6-B (10303); FUSE F14 (10302); FUSE F29 (10303); FWD CHASSIS (1700); PLATFORM (1702); PRE 2010 EMISSIONS (11524); SEALED ENG (11500); SPLICE (10331); TIMER (1053)
Wires (circuit gauge+color): A74H 18LTGN; A74L 16LTGN; A74P 18LTGN; B62-GC 18WH; B62C 18DKBL; B74A 12LTGN; B74AB 12LTGN; B74B 12LTGN; B74BB 12LTGN; B74C 16LTGN; B74D 16LTGN; Y74 12LTGN; Y74-G 12WH
See also sheets: CH19_10, CH19_13, CH3_09, CH3_10, CH8_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.7. BOOSTER PUMP W/ COOLANT HEATER WIRED SEPARATELY W/ TIMER, P. 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 BOOSTER PUMP W/COOLANT HEATER WIRED SEPARATELY W/TIMER / MJV0488 19NOV21 CIRC B74AB,B74BB WERE B74A,B74B AT R/D 10255. / BOOSTER PUMP SW (10255) / *B74AB 12LTGN #B74B 12LTGN / 12LTGN &Y74 / &B62C 18DKBL &B62-GC 18WH / ELEC PANEL/ A4 SEALED ENG (11500) / &Y74-G 12WH / SEALED ENG GROUND (OGND) / BOOSTER PUMP MOTOR / SW ILLUM SPLICE (10331) CH8_32 / BOOSTER PUMP PRE 2010 EMISSIONS (11524)/ 2010 EMISSIONS (11502) / FUSE F14 (10302) CH3_94E FUSE B3-G (10304) CH3_10 / BOOSTER PUMP HIGH OUTPUT BE/CE (11536/11537)) CH19_10 / &Y74 12LTGN / ELEC PANEL/ PLATFORM (1702) 17 / FUSE F29 (10303) CH3_94H FUSE B6-B *B74C (10303) 16LTGN CH3_09 PLATFORM/ ELEC PANEL (1703) / &B74D 16LTGN / &A74L 16LTGN / ESPAR MULTIMAX TIMER (1053) CH19_13 / PLATFORM/ FWD CHASSIS (1700) CH19_13 / &A74H 18LTGN / &A74P 18LTGN / * W/0508108 - MTA FUSE BLOCK # N/0508108 - NOT MTA FUSE BLOCK & W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / 12LTGN #B74A / #B74C 16LTGN / *B74BB 12LTGN / Figure 823 / BOOSTER PUMP W/ COOLANT HEATER WIRED SEPARATELY W/ TIMER

19.8. BOOSTER PUMP W/ COOLANT HEATER W/ TIMER AND LOW VOLTAGE DISC, P.
Figure 824 BOOSTER PUMP W/ COOLANT HEATER W/ TIMER AND LOW VOLTAGE DISC

Components: BOOSTER PUMP SW (10255); COMMON (11621); EMISSIONS (11502); FUSE B3-G (10304); FUSE B6-B (10303); FUSE B6-E (10303); FWD CHASSIS (1700); GROUND (11620); OUTPUT (11622); PLATFORM (1703/1703); PRE 2010 EMISSIONS (11524); PUSH BUTTON (11631); PWR IN (11619); SEALED ENG (11500); SPLICE (10331); SPLICE (10335A)
Wires (circuit gauge+color): A74P 18LTGN; B62-GC 18WH; B62C 18DKBL; B74 12RD; B74-G 18WH; B74-GA 18WH; B74-GB 18WH; B74-GC 18WH; B74AB 12LTGN; B74B 16RD; B74C 18RD; B74D 16RD; B74E 18RD; B74F 14LTGN; B74H 12LTGN; B74J 16LTGN; B74K 16LTGN; B74L 16LTGN; B74M 18LTGN; Y74 12LTGN; Y74-G 12WH
See also sheets: CH19_13, CH3_09, CH3_10, CH3_14, CH3_35, CH3_47, CH8_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.8. BOOSTER PUMP W/ COOLANT HEATER W/ TIMER AND LOW VOLTAGE DISC, P. 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 BOOSTER PUMP W/COOLANT HEATER W/TIMER AND LOW VOLTAGE DISC / MJV0488 19NOV21 CIRC B74AB WAS B74A AT R/D 10255. / BOOSTER PUMP SW (10255) / B74AB 12LTGN 14LTGN B74F / BOOSTER PUMP RELAY (10311- R4) 85 / 12LTGN B74H / B74M 18LTGN / 12LTGN Y74 BOOSTER PUMP PRE 2010 EMISSIONS (11524)/ 2010 EMISSIONS (11502) BOOSTER PUMP 2010 CE (11535) / B62C 18DKBL B62-GC 18WH / FUSE B6-E (10303) CH3_14 / ELEC PANEL/ SEALED ENG (11500) / Y74-G 12WH / SEALED ENG GROUND (OGND) CH3_47 NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / BOOSTER PUMP MOTOR / SW ILLUM SPLICE (10331) CH8_32 / 12RD B74 / FUSE B3-G (10304) CH3_10 / B74C 18RD / B74D 16RD / B74E 18RD B74B 16RD / TIMER PWR IN (11619) / TIMER COMMON (11621) / B74-GC 18WH / B74-G 18WH / TIMER OUTPUT (11622) / GROUND SPLICE (10335A) CH3_35 / B74-GA 18WH / TIMER GROUND (11620) / ELEC PANEL/ PLATFORM (1703/1703) B15 B74L A74P 16LTGN 18LTGN / B74J 16LTGN B74K 16LTGN B74-GB 18WH / FUSE B6-B (10303) CH3_09,94H / 2 1 / COOLANT HEATER PUSH BUTTON (11631) / 3 4 / PLATFORM/ FWD CHASSIS (1700) CH19_13 / Figure 824 / BOOSTER PUMP W/ COOLANT HEATER W/ TIMER AND LOW VOLTAGE DISC

19.9. BOOSTER PUMP W/ ESPAR HEATER W/ TIMER PREWIRE, P. 9
Figure 825 BOOSTER PUMP W/ ESPAR HEATER W/ TIMER PREWIRE

Components: BOOSTER PUMP SW (10255); EMISSIONS (11535); FUSE B3-G (10304); FUSE B6-B (10303); HIGH OUTPUT (11536); PLATFORM (1702-16); PLATFORM (1703-B15); PRE 2010 EMISSIONS (11524); RELAY (10311-R5); SEALED ENG (11500); SPLICE (10331); SPLICE (10335A); TIMER PREWIRE (1053)
Wires (circuit gauge+color): B62-GC 18WH; B62C 18DKBL; B74-G 18WH; B74-GA 18WH; B74-GB 18WH; B74-GC 18WH; B74-GF 18WH; B74AB 12LTGN; B74B 16RD; B74CA 16LTGN; B74D 16LTGN; B74E 14LTGN; B74H 18LTGN; B74J 18LTGN; B74K 16RD; B74L 16RD; B74M 12LTGN; B74P 16LTGN; B74U 16RD; B74V 18LTGN; B75C 18LTGN; Y74 12LTGN; Y74-G 12WH
See also sheets: CH19_10, CH19_12, CH19_18, CH3_09, CH3_10, CH3_35, CH3_47, CH8_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.9. BOOSTER PUMP W/ ESPAR HEATER W/ TIMER PREWIRE, P. 9 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 BOOSTER PUMP W/ESPAR HEATER W/TIMER PREWIRE / MJV0488 19NOV21 CIRC B74CA,B74AB WERE B74C,B74A AT R/D 10255. / BOOSTER PUMP RELAY (10311-R5) 85 / BOOSTER PUMP SW (10255) / 12LTGN 16LTGN B74AB B74D / B74CA 16LTGN / 12LTGN B74M / B74V 18LTGN / 12LTGN Y74 / B62C 18DKBL B62-GC 18WH / FUSE B3-G (10304) CH3_10 / B74-GF 18WH B74U 16RD / Y74 12LTGN Y74-G 12WH 2 / SEALED BOOSTER PUMP ENG HIGH OUTPUT GROUND (11536) (OGND) CH19_10 CH3_47 / BOOSTER PUMP MOTOR / BOOSTER PUMP RELAY (10311- R4) / BOOSTER PUMP PRE 2010 EMISSIONS (11524)/ 2010 EMISSIONS (11535) / B74-GC 18WH / 14LTGN B74E / 16LTGN B74P / ELEC PANEL/ SEALED ENG A4 (11500) / GROUND SPLICE (10335A) CH3_35,95G / 2 1 / ESPAR MULTIMAX TIMER PREWIRE (1053) / 18LTGN B75C / B74H 18LTGN / B74L 16RD / B74-GA 18WH / SW ILLUM SPLICE (10331) CH8_32 / ELEC PANEL/ PLATFORM (1702-16) CH19_12 / ELEC PANEL/ PLATFORM (1703-B15) CH19_18 / B74K 16RD / B74J 18LTGN / B74B 16RD / FUSE B6-B (10303) CH3_09 / B74-G 18WH / B74-GB 18WH / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 825 / BOOSTER PUMP W/ ESPAR HEATER W/ TIMER PREWIRE

19.10. BOOSTER PUMP WITH 2010 HIGH OUTPUT, P. 10
Figure 826 BOOSTER PUMP WITH 2010 HIGH OUTPUT

Components: BOOSTER PUMP RELAY (10311); BOOSTER PUMP RELAY (10311-R4); BOOSTER PUMP SW (10255); ELEC PANEL (11500); O/P BE (11537); O/P CE (11536); O/P FUSE (11538)
Wires (circuit gauge+color): B74B 12LTGN; B74BB 12LTGN; B74K 12LTGN; B74M 12LTGN; B74N 12LTGN; Y74 12LTGN; Y74-G 12WH; Y74A 12RD; Y74B 12RD
See also sheets: CH19_01, CH19_02, CH19_04, CH19_07, CH19_42, CH19_43, CH19_44, CH3_47
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.10. BOOSTER PUMP WITH 2010 HIGH OUTPUT, P. 10 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 BOOSTER PUMP W/2010 HIGH OUTPUT W/BE/CE BUS / MJV0488 19NOV21 ADDED CIRC B74BB IN CAV A4 AT R/D 11500. / SEALED ENG/ ELEC PANEL (11500) A4 / *B74N 12LTGN #B74B 12LTGN / BOOSTER PUMP HIGH O/P BE (11537) BOOSTER PUMP HIGH O/P CE (11536) / &Y74 12LTGN / &Y74A 12RD / &Y74-G 12WH / SEALED ENG GROUND (0GND) CH3_47 / BOOSTER PUMP HIGH O/P FUSE (11538) B A 30A / &Y74B 12RD / *B74M 12LTGN *B74K 12LTGN / #B74K 12LTGN / #B74N 12LTGN #B74M 12LTGN / # N/0508108 - NOT MTA FUSE BLOCK * W/0508108 - MTA FUSE BLOCK & W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / *B74BB 12LTGN / Figure 826 / BOOSTER PUMP WITH 2010 HIGH OUTPUT

19.11. BOOSTER PUMP ACTIVATED BY DRIVER HEATER SWITCH, P. 11
Figure 827 BOOSTER PUMP ACTIVATED BY DRIVER HEATER SWITCH

Components: DIODE PACK (10363); DRIVERS HTR SW (10229); FUSE B9-L (10302); FUSE F1 (10301); HEATER (10367); RELAY SPLICE (10361); SPLICE (10327)
Wires (circuit gauge+color): B62-GA 18WH; B62A 18DKBL; B75 12LTGN; B75-G 12WH; B75A 12LTGN; B75AB 16LTGN; B75AD 16LTGN; B75B 12LTGN
See also sheets: CH19_25, CH3_08, CH8_29
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.11. BOOSTER PUMP ACTIVATED BY DRIVER HEATER SWITCH, P. 11 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 BOOSTER PUMP ACTIVATED BY DRIVER HEATER SWITCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / DRIVERS HTR SW (10229) / SW ILLUM SPLICE (10327) CH8_29 / DRIVERS HEATER C (10367) / B62-GA 18DKBL 18WH B62A / 12LTGN 12LTGN &B75 #B75A / 12LTGN B75B / FUSE F1 (10301) CH3_94D FUSE B9-L (10302) CH3_08 / GROUND STUD (16) GROUND STUD (OGND) CH3_95D / @ W/HTR SW # N/HTR SW * N/0508108 - NOT MTA FUSE BLOCK & W/0508108 - MTA FUSE BLOCK / @B75AB 16LTGN / *B75-G 12WH / @B75AD 16LTGN / BOOSTER PUMP RELAY SPLICE (10361) CH19_25 / DRIVERS HTR DIODE PACK (10363) / @B75A 12LTGN / 12LTGN *B75 / &B75-G 12WH / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 827 / BOOSTER PUMP ACTIVATED BY DRIVER HEATER SWITCH

19.12. ESPAR COOLANT HEATER W/ ESPAR 7-DAY TIMER / WHITE TIMER W/ DIESEL, P. 12
Figure 828 ESPAR COOLANT HEATER W/ ESPAR 7-DAY TIMER / WHITE TIMER W/ DIESEL

Components: AUX FUEL TANK (9006); BOOSTER PUMP RELAY (10311); BOOSTER PUMP SW (10255); FUSE A6-G (1014); FUSE F32 (1011); HTR (9005); HTR W/TIMER (9996); IGN SPLICE PACK (1014A); PLATFORM (1702); PLATFORM (1703); RELAY (10311); RELAY (10311-R5); SPLICE (1003B); SPLICE PACK (9995)
Wires (circuit gauge+color): A74 18LTGN; A74-GA 18WH; A74-GB 18WH; A74-GC 18WH; A74A 18DKBL; A74B 18LTGN; A74H 18LTGN; A74L 18LTGN; A74P 18LTGN; A75 10LTGN; A75 12LTGN; A75C 18LTGN; B74C 16LTGN; B74D 16LTGN; B74E 16LTGN; B74F 16LTGN; B74L 16LTGN; B74P 16LTGN; M75 10LTGN; M75A 18LTGN; M75C 16DKBL
See also sheets: CH19_01, CH19_14, CH19_15, CH19_42, CH19_46, CH3_01, CH3_28, CH3_33, CH3_94, CH8_27
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.12. ESPAR COOLANT HEATER W/ ESPAR 7-DAY TIMER / WHITE TIMER W/ DIESEL, P. 12 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 ESPAR COOLANT HEATER W/ESPAR 7-DAY TIMER/WHITE TIMER W/DIESEL / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / M75 10LTGN / M75A 18LTGN / M75C 16DKBL / #A75 12LTGN / *A74 18LTGN / @A74L 18LTGN / 18LTGN @A74P / @A75C 18LTGN &/@A74-GA 18WH #/@A74-GA 18WH &/@A74-GB 18WH @A74-GB 18WH &/@A74B 18LTGN #/@A74B 18LTGN / &/@A74-GC 18WH #A74-GC 18WH / @A74A 18DKBL / ESPAR COOLANT HTR (9005) CH19_14 ESPAR COOLANT HTR WITH AUX FUEL TANK (9006) CH19_15 / GROUND SPLICE (1003B) CH3_95C GROUND SPLICE (1003B) CH3_33 / ELEC PANEL/ PLATFORM (1703) B15 / ELEC PANEL/ PLATFORM (1702) 17 @A74H 18LTGN / 2 11 / &B74D 16LTGN #B74P 16LTGN &B74P 16LTGN &B74L 16LTGN #B74L 16LTGN &B74C 16LTGN / BOOSTER PUMP RELAY (10311-R5) CH19_01 / #B74P 16LTGN / &A75 10LTGN / &B74P 16LTGN / &B74F 16LTGN / BOOSTER PUMP RELAY (10311) CH19_42 / &B74E 16LTGN / Figure 828 / ESPAR COOLANT HEATER W/ ESPAR 7-DAY TIMER / WHITE TIMER W/ DIESEL

19.13. ESPAR COOLANT HEATER W/ ESPAR W/ MULTIMAX TIMER W/ DIESEL, P. 13
Figure 829 ESPAR COOLANT HEATER W/ ESPAR W/ MULTIMAX TIMER W/ DIESEL

Components: CHASSIS (1700); ELEC PANEL (1702); ESPAR MULTIMAX TIMER (1053); FUSE A6-G (1014); HTR (9005); PLATFORM/ELEC PANEL (1703); PUSH BUTTON (11631); RELAY (10311); SPLICE (1003B); TANK (9006); TIMER PREWIRE (1053)
Wires (circuit gauge+color): A74-GA 16WH; A74H 18LTGN; A74L 16LTGN; A74P 18LTGN; A75 12RD; A75C 18LTGN; B74H 16LTGN; B74L 16LTGN; B74P 16LTGN; B75C 18LTGN; M75 10LTGN; M75A 18LTGN; M75C 16DKBL
See also sheets: CH19_01, CH19_08, CH19_09, CH19_14, CH19_15, CH3_01, CH3_33
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.13. ESPAR COOLANT HEATER W/ ESPAR W/ MULTIMAX TIMER W/ DIESEL, P. 13 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 ESPAR COOLANT HEATER W/ESPAR W/ MULTIMAX TIMER W/DIESEL / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / B74H A74H 16LTGN 18LTGN PLATFORM/ELEC PANEL (1703) B15 / PLATFORM/ ELEC PANEL (1702) 17 / ESPAR MULTIMAX TIMER (1053) / GROUND SPLICE (1003B) CH3_33 / ESPAR COOLANT HTR (9005) CH19_14 ESPAR COOLANT TANK (9006) CH19_15 / A74L 16LTGN / PLATFORM/FORWARD CHASSIS (1700) 52 / A74P 18LTGN / A75C 18LTGN / FUSE A6-G (1014) CH3_01 / M75A 18LTGN M75C 16DKBL / M75 10LTGN / A75 12RD / B74L 16LTGN / B74P 16LTGN / BOOSTER PUMP RELAY (10311) CH19_01,07 / A74-GA 16WH / B75C 18LTGN / ESPAR MULTIMAX TIMER PREWIRE (1053) CH19_09 COOLANT HTR PUSH BUTTON (11631) CH19_08 / B74L 16LTGN / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 829 / ESPAR COOLANT HEATER W/ ESPAR W/ MULTIMAX TIMER W/ DIESEL

19.14. ESPAR COOLANT HEATER W/ RSM TANK AND W/ 12 KW RSM TANK, P. 14
Figure 830 ESPAR COOLANT HEATER W/ RSM TANK AND W/ 12 KW RSM TANK

Components: FUEL PUMP (9001); HTR (9003); HTR (9005); PLATFORM/FWD CHASSIS (1700); SPLICE (6740)
Wires (circuit gauge+color): M75 10LTGN; M75-G 10WH; M75-GA 10WH; M75-GB 18WH; M75A 18LTGN; M75B 18LTGN; M75C 16DKBL; R75 10RD; R75-GA 10WH; R75B 14LTGN; R75C 14DKBL
See also sheets: CH19_12, CH3_50
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.14. ESPAR COOLANT HEATER W/ RSM TANK AND W/ 12 KW RSM TANK, P. 14 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 ESPAR COOLANT HEATER W/RSM TANK AND W/12 KW RSM TANK / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ESPAR HTR 1 FUEL PUMP (9001) / M75-G 10WH / M75-GA 10WH / 14LTGN R75B / R75A 14YL / ESPAR COOLANT HTR (9005) / GROUND SPLICE (6740) CH3_50 / R75-GA 10WH / 18LTGN M75A / 18LTGN M75B / ESPAR COOLANT HTR (9003) / M75-GB 18WH / 10LTGN M75 / 10RD R75 / 16DKBL M75C / 14DKBL R75C / PLATFORM/FWD CHASSIS (1700) CH19_12,13 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 830 / ESPAR COOLANT HEATER W/ RSM TANK AND W/ 12 KW RSM TANK

19.15. ESPAR COOLANT HEATER W/ AUXILIARY AND RSM FUEL TANK, P. 15
Figure 831 ESPAR COOLANT HEATER W/ AUXILIARY AND RSM FUEL TANK

Components: FUEL TANK (9006); GROUND SPLICE (6740); PLATFORM/FWD CHASSIS (1700)
Wires (circuit gauge+color): M75 10LTGN; M75-GC 10WH; M75-GD 10WH; M75-GE 18WH; M75A 18LTGN; M75B 18LTGN; M75C 16DKBL; R75 10RD; R75-GD 10WH; R75-GE 18WH; R75B 14LTGN; R75BB 18BK; R75C 14DKBL
See also sheets: CH19_12, CH3_50
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.15. ESPAR COOLANT HEATER W/ AUXILIARY AND RSM FUEL TANK, P. 15 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 ESPAR COOLANT HEATER W/AUXILIARY AND RSM FUEL TANK / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ESPAR COOLANT HTR WITH AUX FUEL TANK (9006) / ESPAR COOLANT HTR AUX FUELTANK REAR WHEELS @(9007) ESPAR COOLANT HTR AFTER BTR #(9007A) ESPAR COOLANT HTR %(9003) *(9003) / M75B 18LTGN / R75-GE 18WH ESPAR FUEL PUMP @(9008) ESPAR FUEL PUMP AFTER BTR #(9004A) ESPAR AUX FUEL MOUNT FUEL PUMP %(9004) *(9004) / SPLICE GROUND (6740) CH3_50 / M75-GC 10WH / M75-GE 18WH / M75-GD 10WH / 18LTGN M75A / R75A 14YL / R75-GD 10WH / 14LTGN R75B / R75BB 18BK / 14DKBL R75C / 16DKBL M75C / 10RD R75 / 10LTGN M75 / PLATFORM/FWD CHASSIS (1700) CH19_12,13 / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 831 / ESPAR COOLANT HEATER W/ AUXILIARY AND RSM FUEL TANK

19.16. COOLANT HEATER EFFECTS, P. 16
Figure 832 COOLANT HEATER EFFECTS

Components: AFT AIR TANK (9009); FUEL PUMP (9001); FWD CHASSIS (1700); SPLICE (6740)
Wires (circuit gauge+color): M75 10LTGN; M75-G 10WH; M75-GA 10WH; M75-GB 18WH; M75A 18LTGN; M75B 18LTGN; M75C 16LTGN
See also sheets: CH19_17, CH3_50
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.16. COOLANT HEATER EFFECTS, P. 16 / CHAPTER 19 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / COOLANT HEATER EFFECTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / M75-GA 10WH / GROUND SPLICE (6740) CH3_50 / 18LTGN M75A / ESPAR HTR FUEL PUMP (9001) / 18LTGN M75B / M75-G 10WH / M75-GB 18WH / 16LTGN M75C / 10LTGN M75 / PLATFORM/ FWD CHASSIS (1700) CH19_17,18 / COOLANT HTR MTD AFT AIR TANK (9009) / COOLANT HTR W/RSM FUEL TANK W/MOUNTED FWD CHASSIS DIESEL / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 832 / COOLANT HEATER EFFECTS

Figure 833 COOLANT HEATER EFFECTS (CONT.)

Components: CHASSIS (1700); ELEC PANEL (1702); ELEC PANEL (1703); FUSE A1-C (10303); FUSE A6-G (1014); GROUND SPLICE (10335A); MOUNTED AFT AIR TANK (9009); PACK (1003); RELAY (10311); WEBASTO SMART TIMER (8331)
Wires (circuit gauge+color): A74 16LTGN; A74-GA 16WH; A74A 16LTGN; A74B 16LTGN; A74C 16LTGN; A74D 14LTGN; B74E 18LTGN; B74L 16LTGN; B74M 16LTGN; B74N 16LTGN; B74P 16LTGN; M75 16LTGN; M75A 18LTGN; M75C 16LTGN
See also sheets: CH19_01, CH19_04, CH19_16, CH3_01, CH3_31, CH3_35
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.17. COOLANT HEATER EFFECTS (CONT.), P. 17 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090670 NO. RELEASE NO. 95885P 21DEC20 / CHAPTER 19 COOLANT HEATER EFFECTS (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A74A 16LTGN / @B74E PLATFORM/ 18LTGN ELEC PANEL %B74N (1703) 16LTGN B14 #B74M 16LTGN B74P 16LTGN PLATFORM/FWD CHASSIS (1700) 52 / WEBASTO SMART TIMER (8331) / BOOSTER PUMP RELAY (10311) CH19_04 GROUND SPLICE PACK (1003) CH3_31 / COOLANT HTR MOUNTED AFT AIR TANK (9009) CH19_16 / A74C 16LTGN A74B 16LTGN / FUSE A6-G (1014) CH3_01 / A74 16LTGN / M75A 18LTGN M75C 16LTGN M75 16LTGN PLATFORM/ ELEC PANEL (1702) 31 / A74D 14LTGN / A74-GA 16WH / W/WEBASTO HTR W/TIMER R DRIVER BOOST, DIESEL / B74L 16LTGN / GROUND SPLICE (10335A) CH3_35 FUSE A1-C (10303) CH19_01 BOOSTER PUMP RELAY (10311) CH19_04,05 / @ W/WEBASTO FUEL FIRED HTR W/TIMER % W/BOOSTER PUMP W/ESPAR HTR W/TIMER # W/BOOSTER PUMP W/FR HTR W/TIMER R DRIVER / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 833 / COOLANT HEATER EFFECTS (CONT.)

19.18. COOLANT HEATER EFFECTS (CONT.), P. 18
Figure 834 COOLANT HEATER EFFECTS (CONT.)

Components: AFT AIR TANK (9009); AIR TANK (9009); CHASSIS (1700); ELEC PANEL (1702); FUSE A6-G (1014); FUSE B6-B (10303); PLATFORM (1702); PLATFORM (1703); PUMP RELAY (10311); TEMP TIMER (11623A); TEMP TIMER (14510A); TIMER (11623A); WEBASTO HTR (10101); WEBASTO SMARTEMP TIMER (8331)
Wires (circuit gauge+color): A74 12LTGN; A74-G 16WH; A74A 16LTGN; A74B 16LTGN; A74C 16LTGN; A74D 16LTGN; A74H 12LTGN; A74P 16RD; B74B 18LTGN; B74C 16LTGN; B74C 18LTGN; B74D 18LTGN; B74J 16LTGN; B74L 18LTGN; B74S 16LTGN; M75 10LTGN; M75A 18LTGN; M75C 16LTGN
See also sheets: CH19_02, CH19_03, CH19_16, CH19_19, CH3_01, CH3_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.18. COOLANT HEATER EFFECTS (CONT.), P. 18 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090670 NO. RELEASE NO. 95885P 21DEC20 / CHAPTER 19 COOLANT HEATER EFFECTS (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PLATFORM/ ELEC PANEL (1702) 17 / M75A 18LTGN M75C 16LTGN / PLATFORM/FWD CHASSIS (1700) 52 / A74C 16LTGN A74D 16LTGN FUSE A6-G (1014) CH3_01 A74-G 16WH / A74P 16RD / COOLANT HTR MOUNTED AFT AIR TANK (9009) CH19_16 / A74H 12LTGN / WEBASTO SMARTEMP TIMER (8331) / GROUND SPLICE PACK#4 (1003) CH3_31 / M75 10LTGN / W/FR HTR CONTROL BY TIMER/BOOSTER PUMP BY SW, DIESEL / PLATFORM/FWD CHASSIS (1700) 44 / M75 10LTGN / M75A 18LTGN / B74J 16LTGN / B74C 18LTGN B74L 18LTGN / A74 12LTGN / M75C 16LTGN / BOOSTER PUMP RELAY (10311) CH19_02,03 WEBASTO HTR (10101) CH19_19 WEBASTO SMART TEMP TIMER (11623A) CH19_02 / COOLANT HTR MOUNTED AFT AIR TANK (9009) CH19_16 / B74C 16LTGN / WEBASTO HTR (10101) CH19_19 FUSE B6-B (10303) CH19_03 / ELEC PANEL/ PLATFORM (1703) B15 / A74B 16LTGN / ELEC PANEL/ PLATFORM (1702) 16 / A74A 16LTGN / W/WEBASTO HTR W/TIMER OVERHEAD DRIVER COMPARTMENT BOOSTER PUMP,DIESEL / B74B 18LTGN / B74L 18LTGN / B74B 18LTGN B74S 16LTGN / B74D 18LTGN / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 834 / COOLANT HEATER EFFECTS (CONT.)

Figure 835 COOLANT HEATER EFFECTS (CONT.)

Components: FUSE B6-B (10303); FWD CHASSIS (1700); PLATFORM (1702); PLATFORM (1703); TEMP TIMER (8331); WEBASTO HTR (10101)
Wires (circuit gauge+color): A74A 16LTGN; A74B 16LTGN; A74P 16RD; B74A 12LTGN; B74A-G 12WH; B74B 18LTGN; B74C 18LTGN; B74D 18LTGN
See also sheets: CH19_18, CH3_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.19. COOLANT HEATER EFFECTS (CONT.), P. 19 / CHAPTER 19 WEBASTO 45K FUEL FIRED HEATER / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090670 NO. RELEASE NO. 95885P 02APR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / WEBASTO HTR (10101) / B74B 18LTGN B74D 18LTGN / B74C 18LTGN / FUSE B6-B (10303) CH3_01 / B74A 12LTGN / B74A-G 12WH / GROUND STUD (30) / WEBASTO FUEL FIRED HTR W/TIMER, DIESEL / ELEC PANEL/ PLATFORM (1703) B15 A74B 16LTGN / ELEC PANEL/ PLATFORM (1702) 16 A74A 16LTGN A74P 16RD / WEBASTO SMART TEMP TIMER (8331) CH19_18 / PLATFORM/ FWD CHASSIS (1700) CH19_18 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 835 / COOLANT HEATER EFFECTS (CONT.)

Figure 836 COOLANT HEATER EFFECTS (CONT.)

Components: FUSE B6-B (10303); PACK (1003); PLATFORM/ELEC PANEL (1702); WEBASTO HEATER (10101); WEBASTO HTR (10101); WEBASTO SMART TEMP (14510); WEBASTO SMART TIMER (11632); WEBASTO SMART TIMER (8331)
Wires (circuit gauge+color): A74-GA 16WH; A74B 16RD; A74C 18LTGN; A74D 18LTGN; B74-GA 12WH; B74-GA 16WH; B74A 12RD; B74A-G 12WH; B74B 16LTGN; B74B 16RD; B74C 18LTGN; B74D 18LTGN
See also sheets: CH3_09, CH3_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.20. COOLANT HEATER EFFECTS (CONT.), P. 20 / CHAPTER 19 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090670 NO. RELEASE NO. 95885P 21DEC20 / COOLANT HEATER EFFECTS (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 1 3 / WEBASTO SMART TEMP (14510) / 1 2 / 3 5 6 / B74B 16LTGN B74C 18LTGN B74D 18LTGN B74A 12RD / WEBASTO HEATER (10101) / GROUND STUD (36) / B74-GA 12WH / FUSE B6-B (10303) CH3_09 B74-GA 16WH / A74B 16RD / PLATFORM/ELEC PANEL (1702) 31 / A74-GA 16WH / GROUND SPLICE PACK (1003) CH3_31 / WEBASTO SMART TIMER (8331) / A74C 18LTGN / A74D 18LTGN / W/WEBASTO HTR W/SMART TIMER R DRIVER, DIESEL / B74B 16LTGN / B74C 18LTGN / B74D 18LTGN FUSE B6-B (10303) CH3_09 / 1 3 / WEBASTO SMART TIMER (11632) / 1 2 / 3 5 6 / B74B 16RD B74C 18LTGN B74D 18LTGN B74A 12RD / WEBASTO HTR (10101) / GROUND STUD (33) / B74A-G 12WH / FUSE B6-B (10303) CH3_09 B74-GA 16WH / WEBASTO HTR (10101) / W/WEBASTO FUEL FIRED HTR W/SMART TIMER, DIESEL / WEBASTO HTR W/SMART TIMER OVERHEAD, DIESEL / GROUND STUD (35) / B74-GA 12WH / B74A 12RD / Figure 836 / COOLANT HEATER EFFECTS (CONT.)

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 877 | printed page 837 | section 19.21
19.21. LEFT FRONT PASSENGER HEATER, P. 21
Figure 837 LEFT FRONT PASSENGER HEATER

Components: AUX HTR FAN1-HI (11100-A); AUX HTR FAN1-LO (11101-A); AUX HTR FAN2-HI (11103-A); AUX HTR FAN2-LO (11104-A); AUX HTR GND (11102-A); DIODE PACK (11638); FUSE B6-H (10303); FUSE F3 (10301); HTR (10247); HTR 2 SW (10243B); HTR SW (10243A); RELAY SPLICE (10361); SPLICE (10331)
Wires (circuit gauge+color): AH75-G 12WH; AH75A 12RD; AH75B 12BK; AH75C 12RD; AH75D 12BK; B62-GK 18WH; B62-GL 18WH; B62K 18DKBL; B62L 18DKBL; B75-GB 12WH; B75AA 14LTGN; B75AB 14LTGN; B75ABB 14LTGN; B75AC 14LTGN; B75ACA 14LTGN; B75AD 14LTGN; B75AE 16LTGN; B75AL 12LTGN; B75AR 16LTGN; B75C 14LTGN; B75K 12LTGN; B75K 14LTGN; B75L 12LTGN; B75LA 12LTGN; B75M 14LTGN; B75N 14LTGN
See also sheets: CH19_25, CH3_09, CH8_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.21. LEFT FRONT PASSENGER HEATER, P. 21 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 LEFT FRONT PASSENGER HEATER / MJV0488 19NOV21 ADDED B75ACA,B75LA, B75ABB IN R/D 10243A. / &B75LA 12LTGN #B75L 12LTGN B62-GK 18DKBL 18WH B62K / L FR HTR SW (10243A) / FAN2-LO FAN2-HI FAN1-HI GND (11104-A) (11103-A) (11102-A) (11100-A) HTR HTR HTR HTR AUX AUX AUX AUX RD BK RD WH / SW ILLUM SPLICE (10331) CH8_32 / L FR HTR 2 SW (10243B) / FAN1-LO (11101-A) HTR AUX BK / L AUX HTR (10247) / #B75-GB 12WH &B75-GB 12WH / #B75AC #B75AL 12LTGN &B75AL 12LTGN 14LTGN @B75AD 14LTGN &B75ACA 14LTGN / *B62-GL 18DKBL *B62L 18WH / 14LTGN B75C / 14LTGN *B75N 14LTGN *B75M / SW ILLUM SPLICE (10331) CH8_32 / AH75C AH75-G 12RD 12WH / AH75A 12RD / AH75D 12BK / AH75B 12BK / FUSE F3 (10301) CH3_94D FUSE B6-H (10303) CH3_09 %B75AE 16LTGN / GROUND STUD (21) GROUND STUD (1GND) CH3_95E / 1 LF HTR DIODE PACK (11638) 2 / 16LTGN B75AR / %B75K 12LTGN / %B75L 12LTGN / BOOSTER PUMP RELAY SPLICE (10361) CH19_25 / 14LTGN *B75K / @B75AA 14LTGN / #B75AB 14LTGN / &B75ABB 14LTGN / Figure 837 / LEFT FRONT PASSENGER HEATER

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 878 | printed page 838 | section 19.22
19.22. LEFT REAR PASSENGER HEATER, P. 22
Figure 838 LEFT REAR PASSENGER HEATER

Components: AUX HRT FAN1-HI (11100-A); AUX HTR (10248); AUX HTR FAN1-LO (11101-A); AUX HTR FAN2-HI (11103-A); AUX HTR FAN2-LO (11104-A); AUX HTR GND (11102-A); FUSE B12-W (10301); FUSE F5 (10301); L REAR HTR 2 SW (10244B); L REAR HTR SW (10244A); PACK (11637); RELAY SPLICE (10361); SPLICE (10332)
Wires (circuit gauge+color): AH75-G 12WH; AH75A 12RD; AH75B 12BK; AH75C 12RD; AH75D 12BK; B62-GM 18WH; B62-GN 18WH; B62M 18DKBL; B62N 18DKBL; B75-GA 12WH; B75AF 16LTGN; B75AP 16LTGN; B75BA 14LTGN; B75BB 14LTGN; B75BC 14LTGN; B75BD 14LTGN; B75D 12LTGN; B75D 14LTGN; B75E 14LTGN; B75F 12LTGN; B75H 14LTGN; B75J 14LTGN; B75L 12LTGN; B75P 12LTGN
See also sheets: CH19_25, CH3_10, CH8_33
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.22. LEFT REAR PASSENGER HEATER, P. 22 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / LEFT REAR PASSENGER HEATER / CHAPTER 19 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / *B75F 12LTGN 18DKBL B62-GM B62M 18WH / L REAR HTR SW (10244A) / SW ILLUM SPLICE (10332) CH8_33 / L REAR HTR 2 SW (10244B) / L REAR AUX HTR (10248) / &B75-GA B75-GA 12WH 12WH / 12LTGN 12LTGN @B75BD 14LTGN &B75P #B75P @B75D 14LTGN @B75BA 14LTGN 14LTGN B75E / *B62-GN *B62N 18DKBL 18WH / 14LTGN 14LTGN *B75H *B75J / SW ILLUM SPLICE (10332) CH8_33 / FUSE F5 (10301) CH3_94D FUSE B12-W (10301) CH3_10 %B75AF 16LTGN / GROUND STUD GROUND STUD (22) (OGND) CH3_95E / L FR AUX HTR / %B75D %B75D 12LTGN 12LTGN / %B75AP 16LTGN / BOOSTER PUMP RELAY SPLICE (10361) CH19_25 / %B75L 12LTGN / 1 LR HTR PACK (11637) 2 / @B75BC 14LTGN / @B75BB 14LTGN / Figure 838 / LEFT REAR PASSENGER HEATER

19.23. RIGHT FRONT PASSENGER HEATER, P. 23
Figure 839 RIGHT FRONT PASSENGER HEATER

Components: AUX HRT FAN1-HI (11100-A); AUX HTR (10249); AUX HTR FAN1-LO (11101-A); AUX HTR FAN2-HI (11103-A); AUX HTR FAN2-LO (11104-A); AUX HTR GND (11102-A); DIODE PACK (11636); FUSE B12-G (10301); FUSE F3 (10301); FUSE F5 (10301); FUSE F7 (10301); R FR HTR 2 SW (10245B); R FR HTR SW (10245A); RELAY SPLICE (10361); SPLICE (10332)
Wires (circuit gauge+color): AH75-G 12WH; AH75A 12RD; AH75B 12BK; AH75C 12RD; AH75D 12BK; B62-GP 18WH; B62-GR 18WH; B62P 18DKBL; B62R 18DKBL; B75-GC 12WH; B75AG 16LTGN; B75AN 16LTGN; B75CA 14LTGN; B75CB 14LTGN; B75CC 14LTGN; B75CD 14LTGN; B75L 12LTGN; B75R 12LTGN; B75S 12LTGN; B75S 14LTGN; B75T 12LTGN; B75T 14LTGN; B75U 12LTGN; B75V 14LTGN; B75W 14LTGN
See also sheets: CH19_25, CH3_07, CH8_33
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.23. RIGHT FRONT PASSENGER HEATER, P. 23 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 RIGHT FRONT PASSENGER HEATER / MJV0488 19NOV21 ADDED FUSE F3 & F5 (10301). / R FR HTR SW (10245A) / SW ILLUM SPLICE (10332) CH8_33 / B62-GP 18DKBL 18WH B62P / R FR HTR 2 SW (10245B) / &B75-GC #B75-GC 12WH 12WH / RI FR AUX HTR (10249) / ##B75R 12LTGN %%B75R 12LTGN 12LTGN 12LTGN &B75R #B75R 14LTGN B75T / *B62-GR *B62R 18DKBL 18WH / @B75CA 14LTGN 12LTGN B75T / 14LTGN 14LTGN *B75V *B75W / SW ILLUM SPLICE (10332) CH8_33 / %B75AN 16LTGN / FUSE F3 (10301) CH3_94D FUSE F5 (10301) CH3_94D FUSE F7 (10301) CH3_94D FUSE B12-G (10301) CH3_07 B75AG 16LTGN / GROUND STUD GROUND (1GND) STUD CH3_95E (23) / RI FR AUX HTR / *B75U 12LTGN / %B75S 12LTGN / BOOSTER PUMP RELAY SPLICE (10361) CH19_25 / RF HTR DIODE PACK (11636) / %B75L 12LTGN / @B75CB 14LTGN / @B75CD 14LTGN / *B75S 14LTGN @B75CC 14LTGN / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 839 / RIGHT FRONT PASSENGER HEATER

19.24. RIGHT REAR PASSENGER HEATER, P. 24
Figure 840 RIGHT REAR PASSENGER HEATER

Components: AUX HRT FAN1-HI (11100-A); AUX HTR (10250); AUX HTR FAN1-LO (11101-A); AUX HTR FAN2-HI (11103-A); AUX HTR FAN2-LO (11104-A); AUX HTR GND (11102-A); DIODE PACK (11626); FUSE F10 (10301); R REAR HTR 2 SW (10246B); R REAR HTR SW (10246A); RELAY SPLICE (10361); SPLICE (10331); SPLICE (10332)
Wires (circuit gauge+color): AH75-G 12WH; AH75A 12RD; AH75B 12BK; AH75C 12RD; AH75D 12BK; B62-GS 18WH; B62-GT 18WH; B62S 18DKBL; B62T 18DKBL; B75-GA 12WH; B75-GD 12WH; B75AA 12LTGN; B75AAC 12LTGN; B75AH 16LTGN; B75AJ 12LTGN; B75AK 16LTGN; B75AM 12LTGN; B75DA 14LTGN; B75DB 14LTGN; B75DC 14LTGN; B75DD 14LTGN; B75L 12LTGN; B75X 12LTGN; B75Y 12LTGN; B75Y 14LTGN; B75Z 12LTGN; B75Z 14LTGN
See also sheets: CH19_25, CH3_07, CH8_32, CH8_33
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.24. RIGHT REAR PASSENGER HEATER, P. 24 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 RIGHT REAR PASSENGER HEATER / MJV0488 19NOV21 ADDED CIRC B75AAC IN B R/D 10246A. / SW ILLUM SPLICE (10332) CH8_33 ^/#B75AJ 12LTGN &/#B75AJ 12LTGN / R REAR HTR SW (10246A) / 2 ^B75AA 12LTGN *B75AAC 12LTGN B62-GS 18DKBL 18WH B62S / R REAR HTR 2 SW (10246B) / R REAR AUX HTR (10250) / R REAR AUX HTR / @B75DD 14LTGN 14LTGN @B75DA 14LTGN B75Y 12LTGN #B75Z 14LTGN B75Z / *B62-GT 18DKBL *B62T 18WH / #/*B75AB 12/14LTGN / 12/14LTGN #/*B75AC / SW ILLUM SPLICE (10331) CH8_32 / AH75-G 12WH / GROUND GROUND STUD STUD (*24/#25) (1GND) (@41) CH3_95E / %B75Y 12LTGN %B75L 12LTGN / 12LTGN &B75X 12LTGN #B75AM 12LTGN ^B75X &@/#B75AM 12LTGN / FUSE F10 (10301) CH3_94D FUSE F7 ^(10301) CH3_94D FUSE B12-G &(10301) CH3_07 FUSE B12-U &(10301) CH3_07 / AH75-G 12WH / &B75-GA ^B75-GA 12WH 12WH / %B75AK 16LTGN 1 RR HTR DIODE PACK (11626) 2 / %B75AH 16LTGN / BOOSTER PUMP RELAY SPLICE (10361) CH19_25 / @B75DC 14LTGN / @B75DB 14LTGN / ^B75-GD 12WH &B75-GD 12WH / Figure 840 / RIGHT REAR PASSENGER HEATER

19.25. BOOSTER PUMP RELAY SPLICE, P. 25
Figure 841 BOOSTER PUMP RELAY SPLICE

Components: BOOSTER PUMP RELAY (10311); BOOSTER PUMP RELAY (10311-R4); DIODE PACK (10363); LF HTR DIODE PACK (11638); LR HTR DIODE PACK (11637); RELAY SPLICE (10361); RF HTR DIODE PACK (11636); RR HTR DIODE PACK (11626)
Wires (circuit gauge+color): B74T 16LTGN; B75AD 16LTGN; B75AH 16LTGN; B75AN 16LTGN; B75AP 16LTGN; B75AR 16LTGN; B75T 16LTGN
See also sheets: CH19_06, CH19_11, CH19_21, CH19_22, CH19_23, CH19_24, CH19_46
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.25. BOOSTER PUMP RELAY SPLICE, P. 25 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / BOOSTER PUMP RELAY SPLICE / CHAPTER 19 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / &B74T 16LTGN #B75AD 16LTGN / BOOSTER PUMP RELAY SPLICE (10361) / #B75AR 16LTGN / #B75AP 16LTGN / #B75AN 16LTGN / #B75AH 16LTGN / RF HTR DIODE PACK (11636) CH19_23 RR HTR DIODE PACK (11626) CH19_24 / *B75T 16LTGN / * N/0508108 - NOT MTA FUSE BLOCK & W/0508108 - MTA FUSE BLOCK # W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / Figure 841 / BOOSTER PUMP RELAY SPLICE

19.26. DEFOG FAN EFFECTS, P. 26
Figure 842 DEFOG FAN EFFECTS

Components: DRIVERS FAN (10284); ELEC PANEL (1702/1702); FAN SW (1135); FAN SW (1136A); FR CAP (10000); FUSE B12-T (10301); FUSE B3-T (10304); FUSE F12 (10301); FUSE F4 (10301); GROUND SPLICE (1003A); PANEL LT SPLICE (1002A)
Wires (circuit gauge+color): A62E 18DKBL; A62E-G 18WH; A76AA 14LTGN; A76AB 14LTGN; A76AD 14LTGN; A76AE 14LTGN; A76AF 14LTGN; A76AH 14LTGN; B76C 14LTGN; B76D 14LTGN; B76DHI 14LTGN; B76DLO 16LTGN
See also sheets: CH19_28, CH19_31, CH3_10, CH3_32, CH8_25
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.26. DEFOG FAN EFFECTS, P. 26 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 / DEFOG FAN EFFECTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A76AB 14LTGN / A76AD 14LTGN / A76AE 14LTGN / A62E 18DKBL / A62E-G 18WH / DRIVERS FAN (10284) CH19_28 / B76DHI 14LTGN / B76DLO 16LTGN / FUSE F12 (10301) CH3_94D FUSE B3-T (10304) CH3_10 / L HAND DEFOG FAN SW (1135) 2 / PANEL LT SPLICE (1002A) CH8_25 / GROUND SPLICE (1003A) CH3_32,95B / PLATFORM/ ELEC PANEL (1702/1702) 3 / WITH/RIGHT ONLY R HAND DEFOG FAN SW (1136A) 2 / #B76C 14LTGN / WITH/LEFT ONLY / A76AF 14LTGN / #B76D 14LTGN / PLATFORM/ ELEC PANEL (1702/1702) 2 / A62E 18DKBL / B76DLO 16LTGN / ELEC PANEL/ FR CAP (10000) CH19_31,32 / A76AA 14LTGN / A76AH 14LTGN / B76DHI 14LTGN / FUSE F4 (10301) CH3_94D FUSE B12-T (10301) CH3_10 / A62E-G 18WH / PANEL LT SPLICE (1002A) CH8_25 / *B76C 14LTGN / *B76D 14LTGN / Figure 842 / DEFOG FAN EFFECTS

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 883 | printed page 843 | section 19.27
19.27. DEFOG FAN EFFECTS (CONT.), P. 27
Figure 843 DEFOG FAN EFFECTS (CONT.)

Components: DEFOG FAN SW (1135A); DEFOG FAN SW (1136); ELEC PANEL (1702); ELEC PANEL/FR CAP (10000); FR CAP (10000); FUSE B12-T (10301); FUSE B3-T (10304); FUSE F12 (10301); FUSE F4 (10301); GROUND SPLICE (1003A); SPLICE (1002A)
Wires (circuit gauge+color): A62D 18DKBL; A62E 18DKBL; A62E-G 18WH; A62F 18DKBL; A62F-G 18WH; A62G-G 18WH; A76AA 14LTGN; A76AB 14LTGN; A76AD 14LTGN; A76AE 14LTGN; A76AF 14LTGN; A76AH 14LTGN; B76C 14LTGN; B76CHI 14LTGN; B76CLO 16LTGN; B76D 14LTGN; B76DHI 14LTGN; B76DLO 16LTGN
See also sheets: CH19_28, CH19_31, CH3_10, CH3_32, CH8_25
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.27. DEFOG FAN EFFECTS (CONT.), P. 27 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090670 NO. RELEASE NO. 95885P 21DEC20 / CHAPTER 19 DEFOG FAN EFFECTS (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PLATFORM/ ELEC PANEL (1702) / A76AA 14LTGN A76AF 14LTGN A76AH 14LTGN / R HAND DEFOG FAN SW (1136) / *B76D 14LTGN #B76D 14LTGN B76DLO 16LTGN B76DHI 14LTGN / ELEC PANEL/FR CAP (10000) CH19_28,29,30 / A62F 18DKBL A62G-G 18WH / FUSE F4 (10301) CH3_94D FUSE B12-T (10301) CH3_10 ELEC PANEL/ FR CAP (10000) CH19_31,32 / L HAND DEFOG FAN SW (1135A) / A76AB 14LTGN A76AD 14LTGN A76AE 14LTGN / A62D 18DKBL A62E-G 18WH / PANEL LT SPLICE (1002A) CH8_25 / GROUND SPLICE (1003A) CH3_32,95B / A62E 18DKBL / A62F-G 18WH / #/@B76C 14LTGN / @B76CLO 16LTGN @B76CHI 14LTGN / FUSE F12 (10301) CH3_94D FUSE B3-T (10304) CH3_10 / W/L AND R ONLY / *B76C 14LTGN / * N/0508108 - NOT MTA FUSE BLOCK # W/0508108 - MTA FUSE BLOCK / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 843 / DEFOG FAN EFFECTS (CONT.)

19.28. DEFOG FAN SWITCH W/ DRIVER FAN AND BLOWERS, P. 28
Figure 844 DEFOG FAN SWITCH W/ DRIVER FAN AND BLOWERS

Components: ELEC PANEL (1702); FAN SW (1135); FAN SW (1135A); FR CAP (10000); S FAN (10284); SPLICE PACK (10360B)
Wires (circuit gauge+color): A74AD 14LTGN; A76AE 14LTGN; B76-GC 14WH; B76-GE 14WH; B76-GF 14WH; B76CHI 14LTGN; B76CLO 16LTGN; B76D-G 14WH; B76DHI 14LTGN; B76DLO 16LTGN; B76EHI 14LTGN; B76ELO 14LTGN; B76ELO 16LTGN; B76FHI 14LTGN; B76FLO 16LTGN
See also sheets: CH19_26, CH19_29, CH3_42, CH9_27
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.28. DEFOG FAN SWITCH W/ DRIVER FAN AND BLOWERS, P. 28 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 DEFOG FAN SWITCH W/DRIVERS FAN AND BLOWERS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PLATFORM/ ELEC PANEL (1702) 69 / *B76CHI 14LTGN / *B76CLO 16LTGN %B76DLO 16LTGN / A76AE 14LTGN / A74AD 14LTGN / #B76CHI 14LTGN *B76EHI 14LTGN #B76ELO 14LTGN *B76ELO 16LTGN / *B76FLO 16LTGN / *B76FHI 14LTGN / *B76-GF 14WH / *B76-GC 14WH / DRIVER'S FAN (10284) / ELEC PANEL/ FR CAP (10000) CH19_29 / ORANGE - HIGH SPEED RED - LOW SPEED BLACK - MOTOR FRAME-GROUND / L DEFOG FAN SW (1135) CH19_26 L HAND DEFOG FAN SW (1135A) CH9_27 / %B76D-G 14WH / %B76DHI 14LTGN / % W/BULKHEAD FAN * W/DRIVERS FAN # W/CENTER BLOWER / #B76-GC 14WH *B76-GE 14WH / O GROUND SPLICE PACK (10360B) CH3_42 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 844 / DEFOG FAN SWITCH W/ DRIVER FAN AND BLOWERS

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 885 | printed page 845 | section 19.29
19.29. DEFOG FAN LEFT SWITCH OUTPUT, P. 29
Figure 845 DEFOG FAN LEFT SWITCH OUTPUT

Components: ELEC PANEL (1702); FR CAP (10000)
Wires (circuit gauge+color): B76-GA 14WH; B76-GC 14WH; B76-GE 14WH; B76CHI 14LTGN; B76CLO 16LTGN; B76EHI 14LTGN; B76ELO 16LTGN; C76-GA 14WH; C76-GA 18LTGN; C76-GA 18WH; C76-GE 18WH; C76-GH 18WH; C76A 14LTGN; C76A 18LTGN; C76B 16LTGN; C76B 18LTGN; C76E 18LTGN; C76F 18LTGN; C76H 18LTGN; C76J 18LTGN
See also sheets: CH19_27, CH19_28, CH3_42
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.29. DEFOG FAN LEFT SWITCH OUTPUT, P. 29 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 DEFOG FAN LEFT SWITCH OUTPUT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / C76-GA 14WH / B76EHI 14LTGN B76ELO 16LTGN / *B76-GE 14WH B76-GC 14WH ##B76-GA 14WH *B76-GE 14WH B76-GC 14WH ##B76-GA 14WH / DEFOG FAN / * W/FAR LEFT # W/CTR L % W/CTR BLOWER N/DRIVER @ W/CTR R & FAR R ## W/CTR L & BULKHEAD & W/0508108 - MTA FUSE BLOCK ^ N/0508108 - NOT MTA FUSE BLOCK / FAR L DEFOG FAN (*10011) CTR L DEFOG FAN (#10012) A / CTR BLOWER (%10015) 1 WH / CTR R DEFOG FAN (@10013) A / DEFOG FAN / #C76-GH 18WH / C76B 18LTGN C76-GA 18LTGN / C76A 18LTGN / C76A 18LTGN / *C76E 18LTGN #C76H 18LTGN *C76F 18LTGN #C76J 18LTGN *C76-GE 18WH / C76-GA 18WH / C76B 18LTGN / C76A 14LTGN C76B 16LTGN / C76A 18LTGN C76B 18LTGN C76-GA 18WH / PLATFORM/ ELEC PANEL (1702) CH19_28 / B76CHI 14LTGN / B76CLO 16LTGN / O GROUND SPLICE PACK (&10360B) CH3_42 / PLATFORM/ ELEC PANEL (1702) CH19_27,28 / W/FAR L & CTR L, CTR R/FAR R / ELEC PANEL/ FR CAP (10000) / GROUND STUD ^(0GND) CH3_95D / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 845 / DEFOG FAN LEFT SWITCH OUTPUT

19.30. DEFOG FAN LEFT SWITCH OUTPUT (CONT.), P. 30
Figure 846 DEFOG FAN LEFT SWITCH OUTPUT (CONT.)

Components: DRVR OVHD COMPT (10085); FR CAP/ELEC PANEL (10000); PLATFORM (1702); SPLICE PACK (10360B)
Wires (circuit gauge+color): B76-GC 14WH; B76CHI 14LTGN; B76CLO 16LTGN; C76-G 18WH; C76A 18LTGN; C76B 18LTGN
See also sheets: CH19_27, CH3_42
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.30. DEFOG FAN LEFT SWITCH OUTPUT (CONT.), P. 30 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090670 NO. RELEASE NO. 95885P 21DEC20 / CHAPTER 19 DEFOG FAN LEFT SWITCH OUTPUT (CONT.) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / DEFOG FAN UNDER DRVR OVHD COMPT (10085) OR / C76A 18LTGN / #B76CHI 14LTGN / FR CAP/ELEC PANEL (10000) / C76B 18LTGN / C76-G 18WH / *B76-GC 14WH / ELEC PANEL/ PLATFORM (1702) CH19_27 / #B76CLO 16LTGN / O GROUND SPLICE PACK (10360B) CH3_42 / WITH/LEFT OF DRIVER W/MOUNTED ON OVERHEAD COMPT / &B76-GC 14WH / GROUND STUD (0GND) CH3_95D / & N/0508108 - NOT MTA FUSE BLOCK * W/0508108 - MTA FUSE BLOCK # W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / Figure 846 / DEFOG FAN LEFT SWITCH OUTPUT (CONT.)

19.31. DEFOG FAN RIGHT SWITCH OUTPUT, P. 31
Figure 847 DEFOG FAN RIGHT SWITCH OUTPUT

Components: CTR BLOWER (10015); DEFOG FAN (10011); DEFOG FAN (10012); DEFOG FAN (10014); ELEC PANEL (1702); FR CAP (10000); SPLICE PACK (10360B)
Wires (circuit gauge+color): B76-GD 14WH; B76DHI 14LTGN; B76DLO 16LTGN; C76-GC 14WH; C76-GC 18WH; C76-GE 18WH; C76-GH 18WH; C76C 14LTGN; C76C 18LTGN; C76D 16LTGN; C76D 18LTGN; C76E 18LTGN; C76F 18LTGN; C76H 18LTGN; C76J 18LTGN
See also sheets: CH19_26, CH3_42
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.31. DEFOG FAN RIGHT SWITCH OUTPUT, P. 31 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 DEFOG FAN RIGHT SWITCH OUTPUT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/ FR CAP D3 (10000) / FAR L DEFOG FAN (10011) C / OR DEFOG FAN / RD OR CTR BLOWER (10015)@ 3 / **C76D 18LTGN / C76H 18LTGN / C76F 18LTGN / CTR R DEFOG 18LTGN C76C FAN #(10013) DEFOG FAN A OR RD / 18LTGN C76D / C76-GC 18WH / RD OR BLOWER / L CTR DEFOG FAN (10012)* C / DEFOG FAN / C76-GC 18WH C76D 18LTGN C76C 18LTGN / **C76-GC 18WH %C76-GC 18WH %C76D 18LTGN %C76C 18LTGN / C76J 18LTGN / C76-GE 18WH C76-GH 18WH / **C76C 18LTGN / FAR R DEFOG FAN (10014) C / RD OR DEFOG FAN / C76E 18LTGN / B76DLO 16LTGN / B76DHI 14LTGN / GROUND STUD (OGND) CH3_95D O GROUND SPLICE PACK (10360B) CH3_42 / PLATFORM/ ELEC PANEL (1702) CH19_26,27 &B76-GD 14WH ^B76-GD 14WH / Figure 847 / DEFOG FAN RIGHT SWITCH OUTPUT

19.32. DEFOG FAN RIGHT SWITCH OUTPUT (CONT.), P. 32
Figure 848 DEFOG FAN RIGHT SWITCH OUTPUT (CONT.)

Components: DEFOG FAN (10012); DEFOG FAN (10013); DEFOG FAN (10014); ELEC PANEL (1702); FR CAP (10000); SPLICE PACK (10360B)
Wires (circuit gauge+color): B76-GD 14WH; B76DHI 14LTGN; B76DLO 16LTGN; C76-GC 18WH; C76-GE 18WH; C76-GH 18LTGN; C76-GH 18WH; C76C 18LTGN; C76D 18LTGN; C76E 18LTGN; C76F 18LTGN; C76H 18LTGN; C76J 18LTGN
See also sheets: CH19_26, CH3_42
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.32. DEFOG FAN RIGHT SWITCH OUTPUT (CONT.), P. 32 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090670 NO. RELEASE NO. 95885P 21DEC20 / CHAPTER 19 / DEFOG FAN RIGHT SWITCH OUTPUT (CONT.) PLATFORM/ ELEC PANEL (1702) CH19_26,27 &B76-GD 14WH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/ FR CAP D3 (10000) / CTR R DEFOG FAN (10013) C / OR DEFOG FAN / @C76D 18LTGN / @C76-GH 18WH *C76J 18LTGN @C76H @C76H 18LTGN 18LTGN *C76H 18LTGN / %C76-GH 18LTGN @C76F 18LTGN %C76J 18LTGN / RD OR DEFOG FAN / %C76H 18LTGN L CTR DEFOG FAN (10012) C C76-GE 18WH C76F 18LTGN C76E 18LTGN / @C76J 18LTGN / @C76-GC 18WH / @C76C 18LTGN / FAR R DEFOG FAN (10014) C / RD OR DEFOG FAN / @C76E 18LTGN / @C76-GE 18WH / B76DLO 16LTGN / B76DHI 14LTGN / GROUND STUD (0GND) CH3_95D 0 GROUND SPLICE PACK (10360B)) CH3_42 / ^B76-GD 14WH / *C76-GH 18WH C76-GC 18WH C76D 18LTGN C76C 18LTGN / NOTE: CONNECTIONS COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / Figure 848 / DEFOG FAN RIGHT SWITCH OUTPUT (CONT.)

19.33. STEP TREAD HEATER EFFECTS, P. 33
Figure 849 STEP TREAD HEATER EFFECTS

Components: FUSE B3-W (10304); HTR (11528); HTR (11529); HTR SW (10228); RELAY (10305-R1); RELAY COIL (10364); SEALED ENG (11500); SPLICE (10327); SPLICE (10335A)
Wires (circuit gauge+color): B132 12GY; B132-GC 18WH; B132A 12GY; B132B 18GY; B132C 18GY; B62-GH 18WH; B62H 18DKBL; Y132 12GY; Y132-G 12WH; Y132-GA 12WH; Y132-GB 12WH; Y132A 12GY; Y132B 12GY
See also sheets: CH3_10, CH3_29, CH3_35, CH3_47, CH8_29
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.33. STEP TREAD HEATER EFFECTS, P. 33 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 STEP TREAD HEATER EFFECTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / HTR ELEMENT / B132 12GY / ACCESSORY SPLICE RELAY COIL (10364) CH3_29 / B132B 18GY / B132C 18GY / B62-GH 18WH / B62H 18DKBL / ELEC PANEL/ SEALED ENG D3 (11500) / BOTTOM STEP HTR (11528) 1 2 / *Y132 12GY #Y132A 12GY *Y132-G 12WH #Y132-GA 12WH / SW ILLUM SPLICE (10327) CH8_29 / SECOND STEP HTR (11529) 1 2 / SEALED ENG GROUND (0GND) CH3_47 / #Y132 12GY / * W/BOTTOM STEP WARMER # W/BOTTOM AND SECOND STEP WARMER / HTR ELEMENT / BOTTOM STEP HTR SW (10228) / #Y132B 12GY #Y132-GB 12WH / #Y132-G 12WH / B132-GC 18WH / GROUND SPLICE (10335A) CH3_35 / FUSE B3-W (10304) CH3_10,25 / B132A 12GY / STEP WARMER RELAY (10305-R1) / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 849 / STEP TREAD HEATER EFFECTS

19.34. CONVECTION HEATER EFFECTS , P. 34
Figure 850 CONVECTION HEATER EFFECTS

Components: FUSE B6-H (10303); FUSE F3 (10301); HTR (10254); HTR SW (10253); SPLICE (10332)
Wires (circuit gauge+color): B62-GBJ 18WH; B62BJ 18DKBL; B74-G 18WH; B74A 18LTGN; B74B 18LTGN
See also sheets: CH3_09, CH8_33
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.34. CONVECTION HEATER EFFECTS , P. 34 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CONVECTION HEATER EFFECTS / CHAPTER 19 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / #B62-GBJ 18WH / &B74-G 18WH *B74-G 18WH / CONVECTION HTR SW (10253) 2 / GROUND STUD (29) / #B62BJ 18DKBL / *B74A 18LTGN #B74B 18LTGN / CONVECTION HTR (10254) / SW ILLUM SPLICE (10332) CH8_33 / HTR ELEMENT / FUSE F3 (10301) CH3_94D FUSE B6-H (10303) CH3_09 / &B74A 18LTGN / GROUND STUD (1GND) CH3_95E / & N/0508108 - NOT MTA FUSE BLOCK * W/0508108 - MTA FUSE BLOCK # W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / Figure 850 / CONVECTION HEATER EFFECTS

19.35. STEPWELL HEATER EFFECTS, P. 35
Figure 851 STEPWELL HEATER EFFECTS

Components: FUSE B9-M (10302); FUSE F2 (10301); GROUND SPLICE PACK (1003); PLATFORM/ELEC PANEL (1702); SPLICE (10328); STEPWELL HTR (1913); STEPWELL HTR SW (10258)
Wires (circuit gauge+color): A132 14GY; A132A 14GY; A132A-G 14WH; B132A 12GY; B132B 12GY; B132C 12GY; B62-GJ 18WH; B62J 18DKBL
See also sheets: CH3_23, CH3_31, CH8_28
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.35. STEPWELL HEATER EFFECTS, P. 35 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 / STEPWELL HEATER EFFECTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / FUSE F2 (10301) CH3_94D FUSE B9-M (10302) CH3_23 PLATFORM/ELEC PANEL (1702) 5 / STEPWELL HTR SW (10258) / #A132A-G 14WH / GROUND SPLICE PACK # 4 (1003) CH3_31 / *B62J 18DKBL *B62-GJ 18WH / *B132B 12GY *B132C 12GY / *A132A 14GY *A132 14GY / #B132A 12GY / STEPWELL HTR (1913) / SW ILLUM SPLICE (10328) CH8_28 / &B132A 12GY / & N/0508108 - NOT MTA FUSE BLOCK # W/0508108 - MTA FUSE BLOCK * W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / GROUND SPLICE PACK (1003) CH3_95A / &A132A-G 14WH / Figure 851 / STEPWELL HEATER EFFECTS

19.36. HEATED AIR SEAT EFFECTS, P. 36
Figure 852 HEATED AIR SEAT EFFECTS

Components: AIR SEAT (10391); FUSE B6-W (10303); FUSE B6-X (10303); HEATED AIR SEAT (10358); HEATED AIR SEAT (10368); SPLICE (10336)
Wires (circuit gauge+color): B105 16LTGN; B105 16WH; B105-G 16WH; B105A 16LTGN
See also sheets: CH3_09, CH3_26, CH3_39
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.36. HEATED AIR SEAT EFFECTS, P. 36 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 / HEATED AIR SEAT EFFECTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / AIR SEAT (10391) / GROUND SPLICE (10336) CH3_39 / B105-G 16WH / FUSE B6-X (10303) CH3_26 / B105 16WH / W/SELF CONTAINED AIR SEAT / B105-G 16WH / HEATED AIR SEAT (10368) / B105 16LTGN / GROUND SPLICE (10336) CH3_39 / W/HEATED AIR SEAT / FUSE B6-W (10303) CH3_09,25 / B105-G 16WH / GROUND SPLICE (10336) CH3_39 / B105 16LTGN / FUSE B6-X (10303) CH3_26 / W/SELF CONTAINED HEATED AIR SEAT / SELF CONTAINED HEATED AIR SEAT (10358) / B105A 16LTGN / FUSE B6-W (10303) CH3_09,25 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 852 / HEATED AIR SEAT EFFECTS

Figure 853 AIR COMPRESSOR EFFECTS

Components: AIR COMPRESSOR (11518); ELEC PANEL (11500)
Wires (circuit gauge+color): Y146 12GY; Y146-G 12WH
See also sheets: CH3_47
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.37. AIR COMPRESSOR EFFECTS, P. 37 / CHAPTER 19 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / AIR COMPRESSOR EFFECTS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / AIR COMPRESSOR (11518) / SEALED ENG/ ELEC PANEL (11500) A6 / Y146 12GY / Y146-G 12WH / SEALED ENG GROUND (0GND) CH3_47 / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 853 / AIR COMPRESSOR EFFECTS

19.38. ENGINE SPEED CONTROL W/ AIR CONDITIONING, P. 38
Figure 854 ENGINE SPEED CONTROL W/ AIR CONDITIONING

Components: A/C DIODE (6201); A/C RELAY (10308-R4); CONTROLLER (1600); ELEC PANEL (1702); PANEL ENG (11500); RAMP UP (4204); RAMP UP (4205); SPLICE (10350A); SPLICE (10355A)
Wires (circuit gauge+color): A77AA 18LTGN; A77AB 18LTGN; A77AC 18LTGN; A77R 18LTGN; B77-G 18WH; B77B 18LTGN; B77C 18LTGN; B77D 18LTGN
See also sheets: CH19_39, CH3_35, CH3_60
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.38. ENGINE SPEED CONTROL W/ AIR CONDITIONING, P. 38 / CHAPTER 19 ENG SPEED CONTROL W/ AIR CONDITIONING / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / AC I/P FOR ENGINE SPEED B7 RAMP / &A77R 18LTGN / &A77AA 18LTGN / &A77AB 18LTGN / AC BOARD FOR ENG RAMP UP (4204) AC BOARD FOR ENG RAMP UP (4205) / @B77B 18LTGN #B77B 18LTGN / B77C 18LTGN / J3-RED BODY CONTROLLER (1600) / &A77AC 18LTGN / PLATFORM / ELEC PANEL (1702) / ENG RAMP UP WITH A/C DIODE (6201) / @A77AB 18LTGN / @A77AC 18LTGN / B77-G 18WH / B77D 18LTGN / ZVR SPLICE (10350A) CH3_60 / A/C RELAY (10308-R4) / GROUND SPLICE (10355A) CH3_35 / %B77B 18LTGN / SEALED/ELEC PANEL ENG (11500) CH19_39 / *B77B 18LTGN / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 854 / ENGINE SPEED CONTROL W/ AIR CONDITIONING

19.39. ENGINE SPEED CONTROL W/ AIR CONDITIONING (CONT.), P. 39
Figure 855 ENGINE SPEED CONTROL W/ AIR CONDITIONING (CONT.)

Components: A/C IGN SOURCE (11533); A/C RELAY (10308); DIODE (11540); ENG (11500); FUSE B12-K (10301); FUSE B3-R (10304); RAMP UP (11543); RAMP UP (11544); SOURCE (11541); SOURCE (11542)
Wires (circuit gauge+color): B77A 18LTGN; B77B 18LTGN; Y77 16LTGN; Y77 18LTGN; Y77B 18LTGN; Y77C 18LTGN; Y77D 18LTGN; Y77E 16LTGN; Y77F 16LTGN
See also sheets: CH19_38, CH3_18, CH3_23
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.39. ENGINE SPEED CONTROL W/ AIR CONDITIONING (CONT.), P. 39 / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090670 NO. RELEASE NO. 95885P 21DEC20 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / Y77 16LTGN / @Y77B 18LTGN / A/C IGN SOURCE (11533) / ELEC PANEL/ SEALED ENG (11500) / @ W/AC W/RELOC BOARDS W/IDLE RAMP # N/RELOC BOARDS * W/NOISE ABATMENT ADAPTER W/AUTO IDLE RAMP % W/RELOC BOARDS / Y77E 16LTGN / @Y77 18LTGN / Y77F 16LTGN / %/#B77A 18LTGN / %B77B 18LTGN / *B77A 18LTGN / FUSE B12-K (10301) CH3_18 / FUSE B3-R (10304) CH3_23 / A/C RELAY (10308) CH19_38 / AC IGN SOURCE (11542) / @Y77D 18LTGN / AC ENG RAMP UP (11544) / @Y77C 18LTGN / AC ENG RAMP UP (11543) / ENG RAMP UP WITH A/C DIODE (11540) / AC IGN SOURCE (11541) / NOTE: CONNECTIONS FOR VEHICLES W/0508108 - MTA FUSE BLOCK. / Figure 855 / ENGINE SPEED CONTROL W/ AIR CONDITIONING (CONT.)

19.40. OVERHEAD LOCKING COMPARTMENT, P. 40
Figure 856 OVERHEAD LOCKING COMPARTMENT

Components: ALARM (10051); ALARM (11230); BUZZER (10051A); BUZZER (10051B); COMPARTMENT (10038); COMPARTMENT (10039); COMPARTMENT (10050); COMPARTMENT (10398); FR CAP (10000); FUSE A1-A (10305); FUSE A1-E (10305); LOCK RELAY (10312-R6); RELAY (10313-R2); SAFETY COMPARTMENT (10049); SPLICE (10009); SPLICE (10336); SPLICE (10382)
Wires (circuit gauge+color): B133-GR 18WH; B133B 18LTGN; B133C 18LTGN; B133D 18LTGN; B133H 18LTGN; B133P 18LTGN; B133R 18LTGN; B133T 18LTGN; B133U 18LTGN; C133 16LTGN; C133-G 16WH; C133-GA 16WH; C133-GC 16WH; C133A 16LTGN; C133B 16LTGN; C133C 16LTGN; C133D 16LTGN
See also sheets: CH15_25, CH3_18, CH3_19, CH3_40, CH3_43
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.40. OVERHEAD LOCKING COMPARTMENT, P. 40 / CHAPTER 19 OVERHEAD LOCKING COMPARTMENT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / %B133H 18LTGN / B133R 18LTGN 18LTGN B133P / OVERHEAD LOCKING COMPARTMENT (10398) A / B133-GR 18WH / LOCKING COMPARTMENT ALARM (11230) A 148 16GY / 148-G 16WH / 148C 16GY (11229B) A 148-GA 16WH / (11228B) A / ELEC PANEL/ FR CAP (10000) B6 / %B133C 18LTGN / %B133T 18LTGN %B133B 18LTGN / 148-GB 16WH / %C133D 16LTGN / C133-G 16WH / BUZZER (10051B) / STARTER INTERLOCK RELAY (10313-R2) CH15_25 / (11229A) 148A 16GY / %B133D 18LTGN / %B133U 18LTGN / AED VANDAL LOCK RELAY (10312-R6) / #C133 16LTGN / #C133C 16LTGN / BUZZER (10051A) / GROUND SPLICE (10009) CH3_43 / 148B 16GY / Figure 856 / OVERHEAD LOCKING COMPARTMENT

19.41. POWER VENT FRONT AND REAR W/ ALARM W/ ROOF HATCH, P. 41
Figure 857 POWER VENT FRONT AND REAR W/ ALARM W/ ROOF HATCH

Components: FUSE B12-H (10301); FUSE B12-V (10301); FUSE F11 (10301); FUSE F8 (10301); GND SPLICE (10473); L BODY (10401A/B/10401); ROOF HATCH (10457-10464); ROOF HATCH (10459-10469); SPLICE (10329); VENT SW (10226); VENT SW (10227)
Wires (circuit gauge+color): B62-GY 18WH; B62-GZ 18WH; B62Y 18DKBL; B62Z 18DKBL; B76A 16LTGN; B76AHI 16LTGN; B76ALO 16LTGN; B76B 16LTGN; B76BHI 16LTGN; B76BLO 16LTGN; E76-GA 16WH; E76-GB 16WH; E76A 16LTGN; E76B 16LTGN; E76C 16LTGN; E76D 16LTGN
See also sheets: CH3_23, CH3_56, CH8_30
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.41. POWER VENT FRONT AND REAR W/ ALARM W/ ROOF HATCH, P. 41 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 21DEC20 / CHAPTER 19 POWER VENT FRONT AND REAR W/ALARM W/ROOF HATCH / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PWR VENT GND SPLICE (10473) CH3_56 / FUSE F8 (10301) CH3_94D ELEC PANEL/ FUSE B12-H ^B76A L BODY (10301) 16LTGN (10401A/B/10401) CH3_23 B6 #B76ALO 16LTGN / #B76AHI 16LTGN #B62Y 18DKBL #B62-GY 18WH / REAR PWR VENT SW (10227) 2 / #B76BLO 16LTGN / ^B76B 16LTGN / #B76BHI 16LTGN #B62Z 18DKBL #B62-GZ 18WH / * FOR FR ROOF HATCH 10457 - SECT1 10458 - SECT2 10459 - SECT3 10460 - SECT4 10461 - SECT5 10462 - SECT6 10463 - SECT7 10464 - SECT8 / FR PWR VENT SW (10226) 2 / SW ILLUM SPLICE (10329) CH8_30 / ROOF HATCH (10457-10464)* 4 / E76A 16LTGN / E76B 16LTGN E76-GA 16WH / E76C 16LTGN / E76D 16LTGN / E76-GB 16WH / ROOF HATCH (10459-10469)# / 76-G 16WH / 76B 16LTGN / 76A 16LTGN / 76A 16LTGN 76B 16LTGN / 76-G 16WH / REAR ROOF HATCH 1 TO 8 LO 1 2 HI GND 3 / FR ROOF HATCH 1 TO 8 LO HI GND / 1 2 3 / FUSE F11 (10301) CH3_94D FUSE B12-V (10301) CH3_23 / SW ILLUM SPLICE (10329) CH8_30 / &B76A 16LTGN / &B76B 16LTGN / & N/0508108 - NOT MTA FUSE BLOCK ^ W/0508108 - MTA FUSE BLOCK # W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / Figure 857 / POWER VENT FRONT AND REAR W/ ALARM W/ ROOF HATCH

19.42. BOOSTER PUMP W/ ESPAR HEATER W/ TIMER, P. 42
Figure 858 BOOSTER PUMP W/ ESPAR HEATER W/ TIMER

Components: BOOSTER PUMP SW (10255); ELEC PANEL/PLATFORM (1702); ELEC PANEL/PLATFORM (1703); EMISSIONS (11502); FUSE F14 (10302); FUSE F29 (10303); FUSE F46 (10304); FWD CHASSIS (1700); HTR W/TIMER (9997); PRE 2010 EMISSIONS (11524); RELAY (10311); SEALED ENG (11500); SPLICE (10331); SPLICE (10335A); TIMER PREWIRE (1053)
Wires (circuit gauge+color): A74H 18LTGN; A74L 16LTGN; A74N 18LTGN; A74P 18LTGN; B62-GC 18WH; B62C 18DKBL; B74-G 18WH; B74A 12LTGN; B74B 12LTGN; B74B 14LTGN; B74B 16RD; B74C 16LTGN; B74D 12LTGN; B74D 16LTGN; B74E 16LTGN; B74F 18LTGN; B74H 16LTGN; B74J 16LTGN; B74K 16LTGN; B74L 16LTGN; B74M 12LTGN; B74N 16LTGN; B74P 16LTGN; Y74 12LTGN; Y74-G 12WH
See also sheets: CH19_56, CH19_57, CH3_35, CH8_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.42. BOOSTER PUMP W/ ESPAR HEATER W/ TIMER, P. 42 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 04MAR21 / CHAPTER 19 BOOSTER PUMP W/ESPAR HEATER W/TIMER / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / BOOSTER PUMP RELAY (10311) 85 D3 / B74P 16LTGN F4 86 / 87A E3 B74E 16LTGN / D4 30 / BOOSTER PUMP SW (10255) / 12LTGN B74A / 16LTGN B74C / C4 86 / B74N 16LTGN B74J 16LTGN A4 30 / 85 A3 / 12LTGN B74M 87A B3 / 12LTGN &B74B 12LTGN B74D / 12LTGN Y74 / B62C 18DKBL #B74D 16LTGN B62-GC 18WH ELEC PANEL/PLATFORM (1702) 17 16 / GROUND SPLICE (10335A) CH3_95G / B74L 16LTGN B74F 18LTGN ELEC PANEL/ SEALED ENG (11500) / FUSE F29 (10303) CH3_94H / Y74-G 12WH / BOOSTER PUMP PRE 2010 EMISSIONS (11524)/ 2010 EMISSIONS (11502) BOOSTER PUMP MOTOR / BOOSTER PUMP RELAY (10311) / SW ILLUM SPLICE (10331) CH8_32 / B74P 16LTGN ELEC PANEL/PLATFORM (1703) B15 / B74-G 14LTGN 18WH B74B B74B 16RD / B74K 16LTGN / FUSE F14 (10302) CH3_94E / B74H 16LTGN / FUSE F46 (10304) CH3_94K / SEALED ENG GROUND (OGND) & W/STANDARD & ESPAR HTR CH3_35 # W/ESPAR HEATER W/TIMER NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / A74N 18LTGN / A74L 16LTGN A74H 18LTGN / A74P 18LTGN / PLATFORM/ FWD CHASSIS (1700) CH19_56 / ESPAR MULTIMAX TIMER PREWIRE (1053) CH19_56 / WEBASTO COOLANT HTR W/TIMER (9997) CH19_57 / W/ESPAR HTR W/TIMER / Figure 858 / BOOSTER PUMP W/ ESPAR HEATER W/ TIMER

19.43. BOOSTER PUMP W/ 17K FRONT HEATER W/ SMARTEMP TIMER IN ELECTRICAL PANEL OR OVERHEAD, P. 43
Figure 859 BOOSTER PUMP W/ 17K FRONT HEATER W/ SMARTEMP TIMER IN ELECTRICAL PANEL

Components: BOOSTER PUMP SW (10255); EMISSIONS (11535); FUSE F14 (10302); FUSE F29 (10303); HIGH OUTPUT (11536); PLATFORM (1702); PLATFORM (1703); PRE 2010 EMISSIONS (11524); RELAY (10311); SEALED ENG (11500); SPLICE (10331); SPLICE (10335A)
Wires (circuit gauge+color): B62-GA 18WH; B62A 18DKBL; B74-G 16WH; B74-GB 14WH; B74-GC 16WH; B74A 12LTGN; B74B 14LTGN; B74B 16RD; B74C 16LTGN; B74D 16LTGN; B74E 16LTGN; B74F 14LTGN; B74G 12LTGN; B74H 12LTGN; B74J 16LTGN; B74K 12LTGN; B74K 16LTGN; B74L 18LTGN; Y74 12LTGN; Y74-G 12WH
See also sheets: CH19_10, CH19_59, CH3_47, CH8_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.43. BOOSTER PUMP W/ 17K FRONT HEATER W/ SMARTEMP TIMER IN ELECTRICAL PANEL OR OVERHEAD, P. 43 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 04MAR21 / CHAPTER 19 BOOSTER PUMP W/17K FRONT HEATER W/SMARTEMP TIMER IN ELECTRICAL PANEL OR OVERHEAD / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / D4 30 / BOOSTER PUMP RELAY (10311) 85 D3 / F4 86 / 87A E3 / BOOSTER PUMP SW (10255) / 12LTGN B74A 12LTGN B74H / *B74C/ 12LTGN #B74G / B74D 16LTGN C4 A4 86 30 / 85 A3 / 87A B3 / *B74M/ #B74K 12LTGN / 12LTGN Y74 / B62A 18DKBL B62-GA 18WH / B74-GB 14WH B74-GC 16WH B74C 16LTGN ELEC PANEL/ SEALED ENG (11500) / FUSE F14 (10302) CH3_94E / Y74 12LTGN Y74-G 12WH / SEALED ENG GROUND (OGND) CH3_47 / BOOSTER PUMP MOTOR / BOOSTER PUMP RELAY (10311) / BOOSTER PUMP PRE 2010 EMISSIONS (11524)/ 2010 EMISSIONS (11535) / 14LTGN B74B B74B 16RD / 14LTGN B74F / 16LTGN B74J / GROUND SPLICE (10335A) CH3_95G / 4 3 / WEBASTO SMART TEMP TIMER (*11623A/#14510A) / 18LTGN B74L / B74E 16LTGN / B74K 16LTGN / B74-G 16WH / SW ILLUM SPLICE (10331) CH8_32 / GROUND STUD (1GND) CH3_95E / BOOSTER PUMP HIGH OUTPUT (11536) CH19_10 / ELEC PANEL/ PLATFORM (1702) CH19_59 / ELEC PANEL/ PLATFORM (1703) CH19_59 / *TIMER IN ELECTRICAL PANEL #TIMER IN OVERHEAD / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / FUSE F29 (10303) CH3_94H / Figure 859 / BOOSTER PUMP W/ 17K FRONT HEATER W/ SMARTEMP TIMER IN ELECTRICAL PANEL OR OVERHEAD

19.44. BOOSTER PUMP W/ 17K FRONT HEATER W/ SMARTEMP TIMER MOUNTED RIGHT OF DRIVER, P. 44
Figure 860 BOOSTER PUMP W/ 17K FRONT HEATER W/ SMARTEMP TIMER MOUNTED RIGHT

Components: BOOSTER PUMP SW (10255); ELEC PANEL/PLATFORM (1703); EMISSIONS (11535); FUSE F14 (10302); FUSE F29 (10303); HIGH OUTPUT (11536); PLATFORM (1702); PRE 2010 EMISSIONS (11524); RELAY (10311); SEALED ENG (11500); SPLICE (10331); SPLICE (10335A)
Wires (circuit gauge+color): B62-GC 18WH; B62C 18DKBL; B74 14LTGN; B74-G 16WH; B74-GA 16WH; B74A 12LTGN; B74C 12LTGN; B74D 12LTGN; B74E 14LTGN; B74J 16LTGN; B74K 16LTGN; B74L 16LTGN; B74M 16LTGN; B74N 12LTGN; B74P 16LTGN; Y74 12LTGN; Y74-G 12WH
See also sheets: CH19_10, CH19_58, CH3_47, CH8_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.44. BOOSTER PUMP W/ 17K FRONT HEATER W/ SMARTEMP TIMER MOUNTED RIGHT OF DRIVER, P. 44 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 04MAR21 / CHAPTER 19 BOOSTER PUMP W/17K FRONT HEATER W/SMARTEMP TIMER MOUNTED RIGHT OF DRIVER / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 87 F3 / 85 D3 / F4 86 / 87A E3 / 16LTGN B74P D4 D4 30 / BOOSTER PUMP SW (10255) / 12LTGN B74A / 12LTGN B74C / B74J 16LTGN C4 A4 86 30 / 85 A3 / 87A B3 / 12LTGN B74D / 12LTGN B74N / 12LTGN Y74 / B62C 18DKBL B62-GC 18WH / BOOSTER PUMP RELAY (10311) / GROUND SPLICE (10335A) CH3_95G / B74L 16LTGN / FUSE F29 (10303) CH3_94H / B74-GA 16WH B74K 16LTGN / ELEC PANEL/ SEALED ENG (11500) / Y74-G 12WH / SEALED ENG GROUND (OGND) CH3_47 / BOOSTER PUMP MOTOR / BOOSTER PUMP RELAY (10311) / SW ILLUM SPLICE (10331) CH8_32 / BOOSTER PUMP PRE 2010 EMISSIONS (11524)/ 2010 EMISSIONS (11535) / 14LTGN B74-G 16WH B74 / 14LTGN B74E / ELEC PANEL/PLATFORM (1703) CH19_58 / FUSE F14 (10302) CH3_94E / 16LTGN B74M / BOOSTER PUMP HIGH OUTPUT (11536) CH19_10 / Y74 12LTGN / ELEC PANEL/ PLATFORM (1702) CH19_58 / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 860 / BOOSTER PUMP W/ 17K FRONT HEATER W/ SMARTEMP TIMER MOUNTED RIGHT OF DRIVER

19.45. BOOSTER PUMP W/ FRONT MOUNTED HEATER W/ WHITE TIMER, P. 45
Figure 861 BOOSTER PUMP W/ FRONT MOUNTED HEATER W/ WHITE TIMER

Components: BE/CE (11536/11537); BOOSTER PUMP SW (10255); COMMON (11621); EMISSIONS (11502); FUSE F14 (10302); FUSE F29 (10303); GROUND (11620); OUTPUT (11622); PLATFORM (1703); PRE 2010 EMISSIONS (11524); PWR IN (11619); RELAY (10311); SEALED ENG (11500); SPLICE (10331); SPLICE (10335A)
Wires (circuit gauge+color): B62-GC 18WH; B62C 18DKBL; B74 14LTGN; B74-G 18WH; B74-GA 16WH; B74-GB 18WH; B74A 12LTGN; B74C 12LTGN; B74D 12LTGN; B74E 16LTGN; B74F 16LTGN; B74H 16LTGN; B74J 16LTGN; B74K 16LTGN; B74L 16LTGN; B74N 12LTGN; B74P 16LTGN; B74R 16LTGN; B74S 16LTGN; Y74 12LTGN; Y74-G 12WH
See also sheets: CH19_10, CH19_58, CH3_47, CH8_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.45. BOOSTER PUMP W/ FRONT MOUNTED HEATER W/ WHITE TIMER, P. 45 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 04MAR21 / CHAPTER 19 BOOSTER PUMP W/FRONT MOUNTED HEATER W/WHITE TIMER / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / BOOSTER PUMP RELAY (10311) 85 D3 / F4 86 / 87A E3 / D4 D4 30 / BOOSTER PUMP SW (10255) / 12LTGN B74A / 12LTGN B74C / B74J 16LTGN C4 A4 86 30 / 85 A3 / 87A B3 / 12LTGN B74D / 12LTGN B74N / 12LTGN Y74 / B62C 18DKBL B62-GC 18WH / FUSE F29 (10303) CH3_94H / B74F 16LTGN ELEC PANEL/ SEALED ENG (11500) B74K 16LTGN / Y74 12LTGN Y74-G 12WH / SEALED ENG GROUND (OGND) CH3_47 NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / BOOSTER PUMP MOTOR / BOOSTER PUMP RELAY (10311) / SW ILLUM SPLICE (10331) CH8_32 / BOOSTER PUMP PRE 2010 EMISSIONS (11524)/ 2010 EMISSIONS (11502) / 14LTGN B74 / 16LTGN B74E / ELEC PANEL/ PLATFORM (1703) CH19_58 / FUSE F14 (10302) CH3_94E / 16LTGN B74P / 16LTGN B74R / 16LTGN B74S / B74L 16LTGN BOOSTER PUMP HIGH OUTPUT BE/CE (11536/11537)) CH19_10 / TIMER PWR IN (11619) / TIMER COMMON (11621) / B74-GB 18WH / B74-G 18WH / 16LTGN B74H / TIMER OUTPUT (11622) / GROUND SPLICE (10335A) CH3_95G / B74-GA 16WH / TIMER GROUND (11620) / Figure 861 / BOOSTER PUMP W/ FRONT MOUNTED HEATER W/ WHITE TIMER

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 902 | printed page 862 | section 19.46
19.46. BOOSTER PUMP, P. 46
Figure 862 BOOSTER PUMP

Components: BOOSTER PUMP SW (10255); EMISSIONS (11502); FUSE F14 (10302); FUSE F29 (10303); PLATFORM (1702); PLATFORM (1703); PRE 2010 EMISSIONS (11524); RELAY (10311); RELAY SPLICE (10361); SEALED ENG (11500); SPLICE (10331); SPLICE (10335A)
Wires (circuit gauge+color): B62-GC 18WH; B62C 18DKBL; B74-G 18WH; B74-GT 16WH; B74A 12LTGN; B74B 14LTGN; B74B 16RD; B74C 16LTGN; B74D 12LTGN; B74E 16LTGN; B74F 16LTGN; B74H 12LTGN; B74R 12LTGN; B74S 12LTGN; B74T 16LTGN; Y74 12LTGN; Y74-G 12WH
See also sheets: CH19_12, CH19_25, CH3_47, CH8_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.46. BOOSTER PUMP, P. 46 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 04MAR21 / CHAPTER 19 / BOOSTER PUMP / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / BOOSTER PUMP SW (10255) / 12LTGN B74A / C4 86 / A4 30 / 85 A3 / 12LTGN @B74H 12LTGN %B74S 87A B3 / 12LTGN %B74R 12LTGN @B74D / @B74F 16LTGN @B74E 16LTGN / 12LTGN Y74 / B62C 18DKBL B62-GC 18WH / FUSE F29 (10303) CH3_94H / A4 ELEC PANEL/ SEALED ENG (11500) / Y74-G 12WH / SEALED ENG GROUND (OGND) CH3_47 / BOOSTER PUMP MOTOR / BOOSTER PUMP RELAY (10311) / SW ILLUM SPLICE (10331) CH8_32 / BOOSTER PUMP PRE 2010 EMISSIONS (11524)/ 2010 EMISSIONS (11502) / @B74C 16LTGN / ELEC PANEL /PLATFORM (1703) CH19_12 ELEC PANEL /PLATFORM (1702) CH19_12 / FUSE F14 (10302) CH3_94E / %B74-GT 16WH @B74-G 18WH @B74B 14LTGN @B74B 16RD / %B74T 16LTGN / GROUND SPLICE (10335A) CH3_95G / @ W/FR RAIL MOUNTED HTR W/TIMER % W/ACTIVATED BY HTR SW NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / PUMP SPLICE BOOSTER (10361) CH19_25 RELAY / Figure 862 / BOOSTER PUMP

19.47. COOLANT HEATER WITH TIMER AND LOW VOLTAGE DISC, P. 47
Figure 863 COOLANT HEATER WITH TIMER AND LOW VOLTAGE DISC

Components: BOOSTER PUMP SW (10255); COMMON (11621); ELEC PANEL/PLATFORM (1703/1703); EMISSIONS (11502); FUSE F14 (10302); FUSE F29 (10303); FUSE F37 (10304); GROUND (11620); OUTPUT (11622); PRE 2010 EMISSIONS (11524); PUSH BUTTON (11631); PWR IN (11619); RELAY (10311); SEALED ENG (11500); SPLICE (10331); SPLICE (10335A); W/TIMER (9997)
Wires (circuit gauge+color): A74P 18LTGN; B62-GC 18WH; B62C 18DKBL; B74 12RD; B74-G 18WH; B74-GA 18WH; B74-GB 18WH; B74-GC 18WH; B74A 12LTGN; B74B 16RD; B74C 18RD; B74D 16RD; B74E 18RD; B74F 12LTGN; B74H 12LTGN; B74J 16LTGN; B74K 16LTGN; B74L 16LTGN; B74M 18LTGN; Y74 12LTGN; Y74-G 12WH
See also sheets: CH19_57, CH3_47, CH8_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.47. COOLANT HEATER WITH TIMER AND LOW VOLTAGE DISC, P. 47 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 04MAR21 / CHAPTER 19 COOLANT HEATER WITH TIMER AND LOW VOLTAGE DISC / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / BOOSTER PUMP SW (10255) / 12LTGN 12LTGN B74A B74F / B74M 18LTGN C4 A4 86 30 / BOOSTER PUMP RELAY (10311) 85 A3 / 87A B3 / 12LTGN B74H / 12LTGN Y74 / B62C 18DKBL B62-GC 18WH / FUSE F37 (10304) CH3_94J / ELEC PANEL/ SEALED ENG (11500) / Y74-G 12WH / SEALED ENG GROUND (OGND) CH3_47 NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / BOOSTER PUMP MOTOR / SW ILLUM SPLICE (10331) CH8_32 / BOOSTER PUMP PRE 2010 EMISSIONS (11524)/ 2010 EMISSIONS (11502) BOOSTER PUMP 2010 CE (11535) / 12RD B74 / FUSE F14 (10302) CH3_94E / B74C 18RD / B74D 16RD / B74E 18RD B74B 16RD / TIMER PWR IN (11619) / TIMER COMMON (11621) / B74-GC 18WH / B74-G 18WH / TIMER OUTPUT (11622) / GROUND SPLICE (10335A) CH3_95G / B74-GA 18WH / TIMER GROUND (11620) / ELEC PANEL/PLATFORM (1703/1703) B15 B74L A74P 16LTGN 18LTGN / B74J 16LTGN B74K 16LTGN B74-GB 18WH / FUSE F29 (10303) CH3_94H / 2 1 / COOLANT HTR PUSH BUTTON (11631) / 3 4 / WEBASTO COOLANT HTR W/TIMER (9997) CH19_57 / Figure 863 / COOLANT HEATER WITH TIMER AND LOW VOLTAGE DISC

19.48. STEP TREAD HEATER 1ST / STEP WARMER, P. 48
Figure 864 STEP TREAD HEATER 1ST / STEP WARMER

Components: FUSE F13 (10302); HTR (11528); HTR (11529); HTR SW (10228); RELAY (10312); RELAY COIL (10364); SEALED ENG (11500); SPLICE (10327); SPLICE (10335A)
Wires (circuit gauge+color): B132 12GY; B132-GC 18WH; B132A 12GY; B132B 18GY; B132C 18GY; B62-GH 18WH; B62H 18LTBL; Y132 12GY; Y132-G 12WH; Y132-GA 12WH; Y132-GB 12WH; Y132A 12GY; Y132B 12GY
See also sheets: CH3_29, CH3_35, CH8_29
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.48. STEP TREAD HEATER 1ST / STEP WARMER, P. 48 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 04MAR21 / CHAPTER 19 STEP TREAD HEATER 1ST/STEP WARMER / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / HTR ELEMENT / B132 12GY / ACCESSORY SPLICE RELAY COIL (10364) CH3_29 / B132B 18GY B132C 18GY / B62-GH 18WH / B62H 18LTBL / ELEC PANEL/ SEALED ENG (11500) / BOTTOM STEP HTR (11528) 1 2 / *Y132 12GY #Y132A 12GY *Y132-G 12WH / SW ILLUM SPLICE (10327) CH8_29 / SECOND STEP HTR (11529) 1 2 / #Y132-G 12WH SEALED ENG GROUND (0GND) CH3_35 / Y132 12GY / * BOTTOM STEP WARMER # BOTTOM AND SECOND STEP WARMER / HTR ELEMENT / BOTTOM STEP HTR SW (10228) / #Y132B 12GY #Y132-GB 12WH / #Y132-GA 12WH / B132-GC 18WH / GROUND SPLICE (10335A) CH3_95G / 85 G2 / J3 30 / G3 86 / FUSE F13 (10302) CH3_94E / B132A 12GY / STEP WARMER RELAY (10312) / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 864 / STEP TREAD HEATER 1ST / STEP WARMER

19.49. DEFOG FAN SWITCH W/ DRIVER FAN, P. 49
Figure 865 DEFOG FAN SWITCH W/ DRIVER FAN

Components: ELEC PANEL (1702); FAN SW (1135); FAN SW (1135A); FR CAP (10000); S FAN (10284)
Wires (circuit gauge+color): A74AD 14LTGN; A76AE 14LTGN; B76-GC 14WH; B76-GE 14WH; B76-GF 14WH; B76CHI 14LTGN; B76CLO 16LTGN; B76D-G 14WH; B76DHI 14LTGN; B76DLO 16LTGN; B76EHI 14LTGN; B76ELO 16LTGN; B76FHI 14LTGN; B76FLO 16LTGN
See also sheets: CH19_26, CH19_27, CH19_29
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.49. DEFOG FAN SWITCH W/ DRIVER FAN, P. 49 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 04MAR21 / CHAPTER 19 DEFOG FAN SWITCH W/DRIVERS FAN / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PLATFORM/ ELEC PANEL (1702) 69 / %B76DHI 14LTGN *B76CHI 14LTGN *B76CLO 16LTGN %B76DLO 16LTGN / A76AE 14LTGN A74AD 14LTGN / *B76EHI 14LTGN *B76ELO 16LTGN / *B76FLO 16LTGN / *B76FHI 14LTGN / GROUND STUD (0GND) CH3_95D / *B76-GE 14WH *B76-GF 14WH / *B76-GC 14WH %B76D-G 14WH / DRIVER'S FAN (10284) / ELEC PANEL/ FR CAP (10000) CH19_29 / ORANGE - HIGH SPEED RED - LOW SPEED BLACK - MOTOR FRAME-GROUND / L DEFOG FAN SW (1135) CH19_26 L HAND DEFOG FAN SW (1135A) CH19_27 / * DRIVER FAN % BULKHEAD FAN / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 865 / DEFOG FAN SWITCH W/ DRIVER FAN

19.50. DUAL A/C COMPRESSOR DISABLE #1 AND #2, P. 50
Figure 866 DUAL A/C COMPRESSOR DISABLE #1 AND #2

Components: AC COMPRESSOR CLUTCH (4202); AC COMPRESSOR CLUTCH (4203); BODY CONTROLLER (1601); SPLICE (1003B)
Wires (circuit gauge+color): A77-GA 18WH; A77-GB 18WH; A77S 18LTGN; A77T 18LTGN; A77U 14LTGN; A77V 14LTGN; A77Y 14LTGN; A77Z 14LTGN
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.50. DUAL A/C COMPRESSOR DISABLE #1 AND #2, P. 50 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 04MAR21 / CHAPTER 19 DUAL AC COMPRESSOR #1 AND #2 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / BODY BUILDER # 1 AC COMPRESSOR CLUTCH (4202) / AC COMPRESSOR CLUTCH #2 (4201) 2 1 30 86 / 18LTGN A77T / 18LTGN A77S / 14LTGN A77Y / 14LTGN A77U / GROUND SPLICE (1003B) CH3_95C / F14 #1 A/C DUAL / 14LTGN A77Z / F13 A/C #2 DUAL / A77-GB 18WH / 87A 3 / AC COMPRESSOR CLUTCH #1 (4200) 2 86 / 14LTGN A77V / BODY BUILDER # 2 AC COMPRESSOR CLUTCH (4203) / J4-BLUE BODY CONTROLLER (1601) / A77-GA 18WH / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / 85 5 / 87A 3 / 1 30 / Figure 866 / DUAL A/C COMPRESSOR DISABLE #1 AND #2

19.51. AIR COMPRESSOR, P. 51
Figure 867 AIR COMPRESSOR

Components: AIR COMPRESSOR (11518); ELEC PANEL (11500); FUSE F20 (10302); RELAY (10308); RELAY COIL (10364); SPLICE (10355B)
Wires (circuit gauge+color): B12 18LTBL; B146-G 18WH; B146A 12GY; B146B 12GY; Y146 12GY; Y146-G 12WH
See also sheets: CH3_29, CH3_47
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.51. AIR COMPRESSOR, P. 51 / CHAPTER 19 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 04MAR21 / AIR COMPRESSOR / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / AIR COMPRESSOR (11518) / SEALED ENG/ ELEC PANEL (11500) A6 / B146B 12GY / Y146 12GY / Y146-G 12WH / SEALED ENG GROUND (0GND) CH3_47 / D4 86 / C4 30 / B146-G 18WH / B12 18LTBL / B146A 12GY / AIR COMPRESSOR RELAY (10308) / ACCESSORY SPLICE RELAY COIL (10364) CH3_29 / GROUND SPLICE (10355B) CH3_95H / FUSE F20 (10302) CH3_94F / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 867 / AIR COMPRESSOR

IC Bus BE/CE Series Electrical Circuit Diagram Manual MY2016-2024, rev. 7 (March 2024)
PDF page 908 | printed page 868 | section 19.52
19.52. ENGINE SPEED CONTROL W/ AIR CONDITIONING W/ DIESEL & W/ F 2018 PROPANE / GASOLINE ENGINE, P. 52
Figure 868 ENGINE SPEED CONTROL W/ AIR CONDITIONING W/ DIESEL & W/ F 2018 PROPANE

Components: AC RELAY (10308); CONTROLLER (1600); ELEC PANEL (1702); PANEL ENG (11500); RAMP UP (4204); RAMP UP (4205); SPLICE (10355A); UP WITH A/C DIODE (6201); ZVR SPLICE (10350A)
Wires (circuit gauge+color): A77AA 18LTGN; A77AB 18LTGN; A77AC 18LTGN; A77R 18LTGN; B77-G 18WH; B77B 18LTGN; B77C 18LTGN; B77D 18LTGN
See also sheets: CH19_53
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.52. ENGINE SPEED CONTROL W/ AIR CONDITIONING W/ DIESEL & W/ F 2018 PROPANE / GASOLINE ENGINE, P. 52 / CHAPTER 19 ENGINE SPEED CONTROL W/AIR CONDITIONING W/DIESEL & W/F-2018-PROPANE/GASOLINE-ENGINE / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 05MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / AC I/P FOR ENGINE SPEED B7 RAMP / %A77R 18LTGN / #A77AA 18LTGN / #A77AB 18LTGN / AC BOARD FOR ENG RAMP UP (4204) AC BOARD FOR ENG RAMP UP (4205) / #B77B 18LTGN / B77C 18LTGN / J3-RED BODY CONTROLLER (1600) / #A77AC 18LTGN / PLATFORM / ELEC PANEL (1702) / ENG RAMP UP WITH A/C DIODE (6201) / @A77AB 18LTGN / @A77AC 18LTGN / ENG SPEED RAMP UP WITH AC ON & PARK BRAKE SET / B4 86 / A4 30 / 85 A3 / B77-G 18WH / B77D 18LTGN / ZVR SPLICE (10350A) CH3_95N / AC RELAY (10308) / GROUND SPLICE (10355A) CH3_95G / %B77B 18LTGN / SEALED/ELEC PANEL ENG (11500) CH19_53 / % W/RELOC BOARDS # N/RELOC BOARDS @ W/CE BUS W/PROPANE * W/NOISE ABATMENT ADAPTER / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 868 / ENGINE SPEED CONTROL W/ AIR CONDITIONING W/ DIESEL & W/ F 2018 PROPANE / GASOLINE ENGINE

19.53. ENGINE SPEED CONTROL W/ AIR CONDITIONING W/ DIESEL & W/ F 2018
Figure 869 ENGINE SPEED CONTROL W/ AIR CONDITIONING W/ DIESEL & W/ F 2018 PROPANE /

Components: A/C IGN SOURCE (11533); AC RELAY (10308); DIODE (11540); ENG (11500); FUSE F44 (10304); FUSE F9 (10301); RAMP UP (11543); RAMP UP (11544); SOURCE (11541); SOURCE (11542)
Wires (circuit gauge+color): B77A 18LTGN; B77B 18LTGN; Y77 16LTGN; Y77 18LTGN; Y77B 18LTGN; Y77C 18LTGN; Y77D 18LTGN; Y77E 16LTGN; Y77F 16LTGN
See also sheets: CH19_52
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.53. ENGINE SPEED CONTROL W/ AIR CONDITIONING W/ DIESEL & W/ F 2018 PROPANE / GASOLINE ENGINE (CONT.), P. 53 / CHAPTER 19 ENGINE SPEED CONTROL W/AIR CONDITIONING W/DIESEL & W/F-2018-PROPANE/GASOLINE-ENGINE (CONT) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 05MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / #Y77 16LTGN / Y77B 18LTGN / A/C IGN SOURCE (11533) / ELEC PANEL/ SEALED ENG (11500) / @ N/RELOC BOARDS N/IDLE RAMP # N/RELOC BOARDS % W/NOISE ABATMENT ADAPTER / Y77E 16LTGN / @Y77 18LTGN / Y77F 16LTGN / @B77A 18LTGN / B77B 18LTGN / %B77A 18LTGN / FUSE F44 (10304) CH3_94K / FUSE F9 (10301) CH3_94D / AC RELAY (10308) CH19_52 / AC IGN SOURCE (11542) / Y77D 18LTGN / AC ENG RAMP UP (11544) / Y77C 18LTGN / AC ENG RAMP UP (11543) / ENG RAMP UP WITH A/C DIODE (11540) / AC IGN SOURCE (11541) / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 869 / ENGINE SPEED CONTROL W/ AIR CONDITIONING W/ DIESEL & W/ F 2018 PROPANE / GASOLINE ENGINE (CONT.)

19.54. HEATED AIR SEAT, P. 54
Figure 870 HEATED AIR SEAT

Components: AIR SEAT (10391); FUSE F23 (10302); FUSE F24 (10302); HEATED AIR SEAT (10358); HEATED AIR SEAT (10368); SPLICE (10336)
Wires (circuit gauge+color): B105 16LTGN; B105 16WH; B105-G 16WH; B105A 16LTGN
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.54. HEATED AIR SEAT, P. 54 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 05MAR21 / CHAPTER 19 / HEATED AIR SEAT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / AIR SEAT (10391) / GROUND SPLICE (10336) CH3_95J / B105-G 16WH / FUSE F23 (10302) CH3_94F / B105 16WH / W/SELF CONTAINED AIR SEAT / B105-G 16WH / HEATED AIR SEAT (10368) / B105 16LTGN / GROUND SPLICE (10336) CH3_95J / W/HEATED AIR SEAT / FUSE F24 (10302) CH3_94F / B105-G 16WH / GROUND SPLICE (10336) CH3_95J / B105 16LTGN / FUSE F23 (10302) CH3_94F / W/SELF CONTAINED HEATED AIR SEAT SELF CONTAINED HEATED AIR SEAT (10358) / B105A 16LTGN / FUSE F24 (10302) CH3_94F / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 870 / HEATED AIR SEAT

19.55. OVERHEAD LOCKING COMPARTMENT, P. 55
Figure 871 OVERHEAD LOCKING COMPARTMENT

Components: ALARM (10051); ALARM (11230); BUZZER (10051A); BUZZER (10051B); COMPARTMENT (10398); FR CAP (10000); FUSE F43 (10304); FUSE F71 (10306); INTERLOCK (10310); RELAY (10310); SPLICE (10009); SPLICE (10336); SPLICE (10382)
Wires (circuit gauge+color): B133-GR 18WH; B133B 18LTGN; B133C 18LTGN; B133D 18LTGN; B133H 18LTGN; B133P 18LTGN; B133R 18LTGN; B133T 18LTGN; B133U 18LTGN; C133 16LTGN; C133-G 16WH; C133-GA 16WH; C133-GC 16WH; C133A 16LTGN; C133B 16LTGN; C133C 16LTGN; C133D 16LTGN
See also sheets: CH15_37, CH3_43
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.55. OVERHEAD LOCKING COMPARTMENT, P. 55 / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 05MAR21 / CHAPTER 19 OVERHEAD LOCKING COMPARTMENT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / %B133H 18LTGN / B133R 18LTGN 18LTGN B133P / OVERHEAD LOCKING COMPARTMENT (10398) A / B133-GR 18WH / LOCKING COMPARTMENT ALARM (11230) A 148 16GY / 148-G 16WH / 148C 16GY 11229B A 148-GA 16WH / 11228B A / ELEC PANEL/ FR CAP (10000) B6 / 87A J3 H3 / J4 86 / 85 G3 / G4 30 / %B133C 18LTGN / %B133T 18LTGN / 148-GB 16WH / %C133D 16LTGN / C133-G 16WH / BUZZER (10051B) / STARTER INTERLOCK RELAY (10310) CH15_37 / STARTER INTERLOCK (10310) / #C133 16LTGN / #C133C 16LTGN / BUZZER (10051A) / GROUND SPLICE (10009) CH3_43 / GROUND SPLICE (10336) CH3_95J / FUSE F71 FUSE F43 STARTER (10304) INTERLOCK (10306) CH3_94K SPLICE CH3_94N (10382) CH15_37 / 148A 16GY / 148B 16GY / %B133D 18LTGN / %B133U 18LTGN / %B133B 18LTGN / Figure 871 / OVERHEAD LOCKING COMPARTMENT

19.56. ESPAR COOLANT HEATER W/ ESPAR W/ MULTIMAX TIMER, P. 56
Figure 872 ESPAR COOLANT HEATER W/ ESPAR W/ MULTIMAX TIMER

Components: CHASSIS (1700); ESPAR MULTIMAX TIMER (1053); FUSE F32 (1011); HTR (9005); PLATFORM/ELEC PANEL (1702); PLATFORM/ELEC PANEL (1703); RELAY (10311); SPLICE (1003B); TANK (9006)
Wires (circuit gauge+color): A74-GA 16WH; A74H 18LTGN; A74L 16LTGN; A74P 18LTGN; A75 10RD; A75C 18LTGN; B74H 16LTGN; B74L 16LTGN; B74P 16LTGN; M75 10LTGN; M75A 18LTGN; M75C 16DKBL
See also sheets: CH19_14, CH19_15, CH19_42, CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.56. ESPAR COOLANT HEATER W/ ESPAR W/ MULTIMAX TIMER, P. 56 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 05MAR21 / CHAPTER 19 ESPAR COOLANT HEATER W/ESPAR W/MULTIMAX TIMER / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A74H B74H 18LTGN 16LTGN PLATFORM/ELEC PANEL (1703) B15 / PLATFORM/ELEC PANEL (1702) 17 / ESPAR MULTIMAX TIMER (1053) / GROUND SPLICE (1003B) CH3_95C / ESPAR COOLANT HTR (9005) CH19_14 ESPAR COOLANT TANK (9006) CH19_15 / A74L 16LTGN / PLATFORM/FORWARD CHASSIS (1700) 52 / A74P 18LTGN / A75C 18LTGN / FUSE F32 (1011) CH3_94 / M75A 18LTGN M75C 16DKBL / M75 10LTGN / A75 10RD / B74L 16LTGN / B74P 16LTGN / BOOSTER PUMP RELAY (10311) CH19_42,44 / A74-GA 16WH / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 872 / ESPAR COOLANT HEATER W/ ESPAR W/ MULTIMAX TIMER

19.57. WEBASTO SCHOLASTIC COOLANT HEATER W/ WEBASTO 7-DAY TIMER, P. 57
Figure 873 WEBASTO SCHOLASTIC COOLANT HEATER W/ WEBASTO 7-DAY TIMER

Components: FUSE F29 (10303); FUSE F46 (10304); HTR TIMER (9997); IGN SPLICE (1014); PLATFORM/ELEC PANEL (1702); PLATFORM/ELEC PANEL (1703); PUSH BUTTON (11631); RELAY (10311); SPLICE PARK (9995)
Wires (circuit gauge+color): A74A 18DKBL; A74B 18LTGN; A74C 18LTGN; A74D 18LTGN; A74H 18LTGN; A74L 18LTGN; A74N 18LTGN; A74P 18LTGN; B74J 16LTGN; B74K 16LTGN; B74L 16LTGN; B74N 16LTGN; B74P 16RD
See also sheets: CH19_47, CH3_64, CH8_27
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.57. WEBASTO SCHOLASTIC COOLANT HEATER W/ WEBASTO 7-DAY TIMER, P. 57 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 05MAR21 / CHAPTER 19 WEBASTO SCHOLASTIC COOLANT HEATER W/WEBASTO 7-DAY TIMER / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / WEBASTO COOLANT HTR TIMER (9997) / A74B 18LTGN / A74D 18LTGN / A74A 18DKBL / B74P 16RD PLATFORM/ELEC PANEL (1703) B14 / PANEL LT SPLICE PARK (9995) CH8_27 / A74N 18LTGN / A74C 18LTGN A74P 18LTGN / PLATFORM/ELEC PANEL (1702) 16 / A74H 18LTGN / A74L 18LTGN / B74N 16LTGN / B74J 16LTGN / FUSE F46 (10304) CH3_94K / BOOSTER PUMP RELAY (10311) CH3_64 / B74L 16LTGN / HTR COOLANT PUSH BUTTON (11631) CH19_47 / B74K 16LTGN / FUSE F29 (10303) CH3_94H / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / IGN SPLICE (1014) CH3_28A / Figure 873 / WEBASTO SCHOLASTIC COOLANT HEATER W/ WEBASTO 7-DAY TIMER

19.58. FUEL FIRED HEATER SMARTEMP TIMER RIGHT OF DRIVER, P. 58
Figure 874 FUEL FIRED HEATER SMARTEMP TIMER RIGHT OF DRIVER

Components: BOOSTER PUMP RELAY (10311); CHASSIS (1700); COOLANT HTR (9006); ELEC PANEL (1703); FUSE F32 (1011); PACK (1003); PLATFORM/ELEC PANEL (1702); RELAY (10311); WEBASTO SMART TIMER (8331)
Wires (circuit gauge+color): A74 16LTGN; A74-G 16WH; A74-GA 16WH; A74A 16LTGN; A74B 16LTGN; A74C 16LTGN; A74D 14LTGN; A74D 16LTGN; A74P 16RD; B74L 16LTGN; B74M 16LTGN; B74P 16LTGN; M75 16LTGN; M75A 18LTGN; M75C 16LTGN
See also sheets: CH19_15, CH19_42, CH19_44, CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.58. FUEL FIRED HEATER SMARTEMP TIMER RIGHT OF DRIVER, P. 58 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 05MAR21 / CHAPTER 19 FUEL FIRED HEATER SMARTEMP TIMER RIGHT OF DRIVER / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / A74A 16LTGN / PLATFORM/ ELEC PANEL (1703) B14 / WEBASTO SMART TIMER (8331) / GROUND SPLICE PACK (1003) CH3_95A / COOLANT HTR (9006) CH19_15 / PLATFORM/FORWARD CHASSIS (1700) 52 / A74C 16LTGN A74B 16LTGN / FUSE F32 (1011) CH3_94 / A74 16LTGN / M75A 18LTGN M75C 16LTGN / M75 16LTGN / A74D 14LTGN / A74-GA 16WH / PLATFORM/ELEC PANEL (1702) 31 / W/TIMER R OF DRIVER / B74L 16LTGN / BOOSTER PUMP RELAY (10311) CH19_44 / B74M 16LTGN B74P 16LTGN / BOOSTER PUMP RELAY (10311) CH19_44,45 / M75 16LTGN / PLATFORM/FORWARD CHASSIS (1700) 52 / A74C 16LTGN A74D 16LTGN / A74P 16RD / FUSE F32 (1011) CH3_94 / COOLANT HTR (9006) CH19_15 / A74D 14LTGN / WEBASTO SMART TIMER (8331) / BOOSTER PUMP RELAY (10311) CH19_42 GROUND SPLICE PACK (1003) CH3_95A / M75A 18LTGN M75C 16LTGN / A74-G 16WH / PLATFORM/ELEC PANEL (1702) 17 / W/TIMER R OF DRIVER W/ENG PREHEAT / B74L 16LTGN / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 874 / FUEL FIRED HEATER SMARTEMP TIMER RIGHT OF DRIVER

Figure 875 COOLANT HEATER EFFECTS (CONT.)

Components: AIR TANK (9009); CHASSIS (1700); ELEC PANEL/PLATFORM (1702); ELEC PANEL/PLATFORM (1703); FUSE F29 (10303); FUSE F32 (1011); MTD AFT AIR TANK (9009); PACK (1003); PLATFORM/ELEC PANEL (1702); PUMP RELAY (10311); WEBASTO SMARTEMP TIMER (8331)
Wires (circuit gauge+color): A74-GA 16WH; A74A 16LTGN; A74B 16LTGN; A74C 16LTGN; A74D 16LTGN; A74H 10LTGN; A74P 16RD; A75 10LTGN; B74C 16LTGN; B74J 16LTGN; B74L 18LTGN; M75 10LTGN; M75A 18LTGN; M75C 16LTGN
See also sheets: CH19_16, CH19_43, CH3_94
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.59. COOLANT HEATER EFFECTS (CONT.), P. 59 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090670 NO. RELEASE NO. 95885P 05MAR21 / CHAPTER 19 COOLANT HEATER EFFECTS (CONT) / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / PLATFORM/ELEC PANEL (1702) 17 / M75A 18LTGN M75C 16LTGN / PLATFORM/FORWARD CHASSIS (1700) 52 / A74C 16LTGN A74D 16LTGN / A74P 16RD / FUSE F32 (1011) CH3_94 / COOLANT HTR MTD AFT AIR TANK (9009) CH19_16 / A74H 10LTGN / WEBASTO SMARTEMP TIMER (8331) / GROUND SPLICE PACK (1003) CH3_95A / M75 10LTGN / A74-GA 16WH / FR HTR CONTROL BY TIMER/BOOSTER PUMP BY SW / PLATFORM/FORWARD CHASSIS (1700) 44 / M75 10LTGN / M75A 18LTGN / B74J 16LTGN / B74L 18LTGN / *A74/#A75 10LTGN / M75C 16LTGN / FUSE F32 (1011) CH3_94 / BOOSTER PUMP RELAY (10311) CH19_43 / COOLANT HTR MTD AFT AIR TANK (9009) CH19_16 / B74C 16LTGN / FUSE F29 (10303) CH3_94H / SMARTEMP TIMER IN OVERHEAD / ELECTRICAL PANEL (*11623A/#14510A) CH19_43 / ELEC PANEL/PLATFORM (1703) B15 / A74B 16LTGN / ELEC PANEL/PLATFORM (1702) 16 / A74A 16LTGN / # - ELECTRICAL PANEL MOUNTED TIMER * - OVERHEAD MOUNTED TIMER NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / WEBASTO SMARTEMP TIMER CIRCUITS PASS-THROUGH / Figure 875 / COOLANT HEATER EFFECTS (CONT.)

19.60. FREON COMPRESSOR CONNECTIONS, P. 60
Figure 876 FREON COMPRESSOR CONNECTIONS

Components: CLUTCH OUTPUT (4206); FREON COMPRESSOR (6200); GROUND SPLICE (6704M); THRU (1701/1701)
Wires (circuit gauge+color): A77G 18LTGN; K10-GB 16WH; K77A 16LTGN; K77A-G 16WH
See also sheets: CH11_09
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.60. FREON COMPRESSOR CONNECTIONS, P. 60 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 05MAR21 / CHAPTER 19 FREON COMPRESSOR CONNECTIONS / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / K77A 16LTGN / DASH PASS THRU (1701/1701) 61 / A77G 18LTGN / AC COMPRESSOR CLUTCH OUTPUT (4206) CH11_09 / K77A-G 16WH / K10-GB 16WH / UPPER GROUND STUD (2G) / GROUND SPLICE (6704M) / FREON COMPRESSOR (6200) / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 876 / FREON COMPRESSOR CONNECTIONS

19.61. WEBASTO 45K FUEL FIRED HEATER, P. 61
Figure 877 WEBASTO 45K FUEL FIRED HEATER

Components: DAY TIMER WEBASTO (11630); FUSE F29 (10303); GROUND SPLICE (10335A); ILLUM (10366); RELAY COILS (10369); WEBASTO HTR (10101)
Wires (circuit gauge+color): B14K 10BK; B74A 12RD; B74A-G 12WH; B74B 18LTGN; B74C 18LTGN; B74D 18LTGN; B74F 18WH; B74H 18WH; B74J 18WH; B74K 18DKBL; B74L 18PK
See also sheets: CH8_24
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.61. WEBASTO 45K FUEL FIRED HEATER, P. 61 / CHAPTER 19 WEBASTO 45K FUEL FIRED HEATER / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 05MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 7 DAY TIMER WEBASTO (11630) / 2 3 / 2 8 / B74B 18LTGN B74C 18LTGN B74D 18LTGN / WEBASTO HTR (10101) / B74K 18DKBL / B74L 18PK B74H 18WH B74J 18WH / PRIMARY SW ILLUM (10366) CH8_24 ACCESSORY SPLICE RELAY COILS (10369) CH3_30A GROUND SPLICE (10335A) CH3_95G / B74F 18WH / B74A 12RD / FUSE F29 (10303) B14K 10BK E2 F2 B74A-G 12WH / BATTERY FEED CH3_94H / GROUND STUD (1GND) / W/TIMER ABOVE DRIVER / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 877 / WEBASTO 45K FUEL FIRED HEATER

19.62. WEBASTO 45K FUEL FIRED HEATER (CONT.), P. 62
Figure 878 WEBASTO 45K FUEL FIRED HEATER (CONT.)

Components: FUSE F29 (10303); GROUND SPLICE (10335A); HTR W/TIMER (9997); PLATFORM (1702); PLATFORM (1703); SPLICE (10335A); TIMER 1 (11619A); TIMER 2 (11620A); TIMER 3 (11621A); TIMER 5 (11622A); WEBASTO HTR (10101)
Wires (circuit gauge+color): A74B 18LTGN; A74C 18LTGN; A74H 18LTGN; A74L 18LTGN; A74N 18LTGN; A74P 18LTGN; B74A 12LTGN; B74A-G 12WH; B74B 18LTGN; B74BA 18LTGN; B74BB 18LTGN; B74C 18LTGN; B74D 18LTGN; B74E 18LTGN
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.62. WEBASTO 45K FUEL FIRED HEATER (CONT.), P. 62 / CHAPTER 19 WEBASTO 45K FUEL FIRED HEATER (CONT) / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. W/ WHITE TIMER / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE080906700 NO. RELEASE NO. 95885P 05MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / WEBASTO HTR (10101) / B74B 18LTGN / FUSE F29 (10303) CH3_94H / B74C 18LTGN GROUND SPLICE (10335A) CH3_95G B74A 12LTGN B74A-G 12WH / TIMER 1 (11619A) TIMER 3 (11621A) TIMER 5 (11622A) TIMER 2 (11620A) / 12V IN / B74BA 18LTGN B74BB 18LTGN / B74E 18LTGN / GROUND STUD (1GND) CH3_95E / WEBASTO COOLANT HTR W/TIMER (9997) / WEBASTO HTR (10101) / B74B A74H 18LTGN 18LTGN A74L B74D 18LTGN 18LTGN ELEC PANEL/ PLATFORM (1703) B15 / FUSE F29 (10303) CH3_94H / B74C 18LTGN B74E 18LTGN / GROUND SPLICE (10335A) CH3_95G B74A 12LTGN / B74A-G 12WH / GROUND STUD (1GND) CH3_95E / ELEC PANEL/ PLATFORM (1702) 16 / A74P 18LTGN / A74N 18LTGN / W/ TIMER / A74B 18LTGN / A74C 18LTGN / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 878 / WEBASTO 45K FUEL FIRED HEATER (CONT.)

19.63. WEBASTO 45K FUEL FIRED HEATER WITH SMARTEMP TIMER, P. 63
Figure 879 WEBASTO 45K FUEL FIRED HEATER WITH SMARTEMP TIMER

Components: FUSE F29 (10303); PACK (1003); PLATFORM/ELEC PANEL (1702); WEBASTO HTR (10101); WEBASTO SMART TIMER (11632); WEBASTO SMART TIMER (8331); WEBASTO SMARTEMP (14510)
Wires (circuit gauge+color): A74-GA 16WH; A74B 16RD; A74C 18LTGN; A74D 18LTGN; B74-GA 12WH; B74-GA 16WH; B74A 12RD; B74A-G 12WH; B74B 16LTGN; B74B 16RD; B74C 18LTGN; B74D 18LTGN
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.63. WEBASTO 45K FUEL FIRED HEATER WITH SMARTEMP TIMER, P. 63 / CHAPTER 19 WEBASTO 45K FUEL FIRED HEATER (CONT) WITH SMARTEMP TIMER / MJV1111 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 05MAR21 / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / 1 3 / 1 2 / 3 5 6 / B74B 16LTGN B74C 18LTGN B74D 18LTGN B74A 12RD / WEBASTO HTR (10101) / GROUND STUD (1GND) CH3_95E / B74-GA 12WH / FUSE F29 (10303) CH3_94H B74-GA 16WH / A74B 16RD / PLATFORM/ELEC PANEL (1702) 31 / A74-GA 16WH / GROUND SPLICE PACK (1003) CH3_95A / WEBASTO SMART TIMER (8331) / A74C 18LTGN / A74D 18LTGN / W/SMART TIMER R DRIVER / B74B 16LTGN / B74C 18LTGN / B74D 18LTGN FUSE F29 (10303) CH3_94H / 1 3 / WEBASTO SMART TIMER (11632) / 1 2 / 3 5 6 / B74B 16RD B74C 18LTGN B74D 18LTGN B74A 12RD / WEBASTO HTR (10101) / B74A-G 12WH GROUND STUD (1GND) CH3_95E / FUSE F29 (10303) CH3_94H B74-GA 16WH / WEBASTO HTR (10101) / W/SMART TIMER IN ELECTRICAL PANEL / B74-GA 12WH GROUND STUD (1GND) CH3_95E / B74A 12RD / NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / Figure 879 / WEBASTO 45K FUEL FIRED HEATER WITH SMARTEMP TIMER

19.64. BOOSTER PUMP W/ FRONT HEATER W/ TIMER OVERHEAD DRIVER COMPARTMENT, P. 64
Figure 880 BOOSTER PUMP W/ FRONT HEATER W/ TIMER OVERHEAD DRIVER COMPARTMENT

Components: BE/CE (11536/11537); BOOSTER PUMP SW (10255); EMISSIONS (11502); FUSE F14 (10302); FUSE F29 (10303); HTR W/TIMER (9997); PLATFORM (1703); PRE 2010 EMISSIONS (11524); RELAY (10311); SEALED ENG (11500); SPLICE (10331); SPLICE (10335A); TEMP TIMER (14510A)
Wires (circuit gauge+color): A74P 18LTGN; B62-GA 18WH; B62A 18DKBL; B74-G 16WH; B74-GB 14WH; B74-GC 16WH; B74A 12LTGN; B74B 14LTGN; B74C 16LTGN; B74D 16LTGN; B74E 16LTGN; B74F 14LTGN; B74G 12LTGN; B74H 12LTGN; B74J 16LTGN; B74K 12LTGN; B74L 18LTGN; B74M 16LTGN; Y74 12LTGN; Y74-G 12WH
See also sheets: CH19_10, CH19_57, CH3_35, CH8_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 19.64. BOOSTER PUMP W/ FRONT HEATER W/ TIMER OVERHEAD DRIVER COMPARTMENT, P. 64 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090670 NO. 95885P 05APR21 / CHAPTER 19 BOOSTER PUMP W/ FR HTR W/TIMER OVERHEAD DRIVER COMPARTMENT / MJV0488 09JUN21 INITIAL PRODUCTION RELEASE. / BOOSTER PUMP RELAY (10311) 85 D3 B74-GB 14WH B74-GC 16WH ELEC PANEL/ SEALED ENG (11500) / F4 86 / 87A E3 B74M 16LTGN / D4 30 / BOOSTER PUMP SW (10255) / 12LTGN B74A / 12LTGN B74G / B74D 16LTGN C4 86 / A4 30 / 85 A3 / 87A B3 / 12LTGN B74H / 12LTGN B74K / 12LTGN Y74 / B62A 18DKBL B62-GA 18WH / FUSE F29 (10303) CH3_94E / FUSE F14 (10302) CH3_94E / B74C 16LTGN Y74 12LTGN Y74-G 12WH / SEALED ENG GROUND (OGND) CH3_35 NOTE: CONNECTIONS FOR VEHICLES N/0508108 - NOT MTA FUSE BLOCK. / BOOSTER PUMP MOTOR / BOOSTER PUMP RELAY (10311) / BOOSTER PUMP PRE 2010 EMISSIONS (11524)/ 2010 EMISSIONS (11502) / 14LTGN *B74B / 18LTGN A74P 16LTGN 14LTGN ELEC PANEL B74J B74F PLATFORM (1703) B15 B74L 18LTGN B74E B74E 16LTGN 16LTGN / WEBASTO SMART TEMP TIMER (14510A) / 4 3 / B74-G 16WH / SW ILLUM SPLICE (10331) CH8_32 / GROUND STUD (1GND) CH3_95E / WEBASTO COOLANT HTR W/TIMER (9997) CH19_57 / BOOSTER PUMP HIGH OUTPUT BE/CE (11536/11537)) CH19_10 / GROUND SPLICE (10335A) CH3_95G / Figure 880 / BOOSTER PUMP W/ FRONT HEATER W/ TIMER OVERHEAD DRIVER COMPARTMENT

CONNECTOR COMPOSITE (52-2505) (CHAPTER 20) | Figure 881 CONNECTOR COMPOSITES (%(52), %(168M), @(168N) | printed page 881

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	A62L	18	DKBL	0186203R2
B	A62-GL	18	WH	0161997R1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL	SEAL/SLV
A	PLUG	-	-	2025431C1	-
B	PLUG	-	-	2025431C1	-
C	A44D	18	GY	3594831C1	1661872C1
D	A44F	18	GY	3594831C1	1661872C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1#	A122AA	18	GY	3686943C1
1%	A122A	18	GY	3686943C1
2#	A122BE	18	GY	3686943C1
2%	A122B	18	GY	3686943C1

20.2. CONNECTOR COMPOSITES *(674), %(680), %(995), P. 2 | Figure 882 CONNECTOR COMPOSITES *(674), %(680), %(995) | printed page 882

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K95FA	20	TN	3626441C1
1	K95-GK	14	WH	3627568C1
2	K95J	20	TN	3626441C1
3	K95MC	20	TN	3626441C1
4	K14XA	14	GY	3627568C1
5	K95N	20	TN	3626441C1
6	K95M	20	TN	3626441C1
6	K97-GRS	20	WH	3626441C1
7	K95R	18	TN	3626441C1
8	K95P	18	TN	3626441C1
9	K95S	18	TN	3626441C1
10	K95-GH1	18	WH	3626441C1
11	K95-GH2	18	TN	3626441C1
12	K95XE	14	PK	3627568C1
13	K5K(+)	18	YL	3626441C1
14	K5K(-)	18	GN	3626441C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT FUSE BLOCK & ; W/2017/2021 ISB/B6.7 DIESEL ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	95MC	18	TN	3612255C1
2	14X	16	TN	3612255C1
3	95J	18	TN	3612255C1
4	95FA	18	TN	3612255C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A79D	16	GY	2025418C1
2	A79M-G	14	WH	2025419C1
3	A9BB	16	GY	2018946C1
4	-	-	-	-
5	A79	16	GY	2018946C1

20.3. CONNECTOR COMPOSITES @(1002A), P. 2A | Figure 883 CONNECTOR COMPOSITES @(1002A) | printed page 883

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A62ZA	18	DKBL	1661208C1
B	A62L	18	DKBL	1661208C1
C@	A62C	18	DKBL	1661208C1
C%	A92NE	18	DKBL	1661208C1
C#	A62J	18	DKBL	1661208C1
D	A62E	18	DKBL	1661208C1
E	A62GK	16	DKBL	1661209C1
F#	A62HA	18	DKBL	1661208C1
G	A62G	18	DKBL	1661208C1
H	A62H	18	DKBL	1661208C1
J	A62K	20	DKBL	1661208C1
K	A62A	14	DKBL	3566715C1

20.4. CONNECTOR COMPOSITES @(1002B), @(1003), P. 3 | Figure 884 CONNECTOR COMPOSITES @(1002B), @(1003) | printed page 884

CAV	CIRCUIT	GA	COLOR	TERMINAL
A!	A62GK	16	DKBL	3534165C1
A%	A62GK	16	DKBL	3534164C1
B	A62R	18	DKBL	3534164C1
C	A62S	18	DKBL	3534164C1
D	A62T	18	DKBL	3534164C1
E	A62P	18	DKBL	3534164C1
F*	A62M	18	DKBL	3534164C1
F#	A62N	18	DKBL	3534164C1
G	A62R-G	18	WH	3534164C1
H	A62S-G	18	WH	3534164C1
J	A62-GT	18	WH	3534164C1
K	A62-GP	18	WH	3534164C1
L*	A120-GM	18	WH	3534164C1
L#	A62-GN	18	WH	3534164C1
M%	A11-GK	16	WH	3534164C1
M!	A11-GK	16	WH	3534165C1

Legend: * W/R PANEL-MOUNTED ROTARY DOOR SWITCH ; # W/R SIDE REDUNDANT DOOR CONTROLS ; ! N/0508108 - NOT MTA FUSE BLOCK ; % W/0508108 - MTA FUSE BLOCK ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A11-G	12	WH	3566715C1
B	A133-GA	16	WH	1661209C1
C	A132A-G	14	WH	3566715C1
D*	A62-GL	18	WH	1661208C1
D#	A88-G	18	WH	1661208C1
E&	A74-GA	16	WH	1661209C1
E%	A74-G	16	WH	1661209C1
F@	A94-GE	18	WH	1661208C1
F!	A44K-GA	14	WH	3566715C1
G	A44-G	16	WH	1661209C1
H@	A101-G	16	WH	1661209C1
H^	A99-G	16	WH	1661209C1
J	A10LS	18	WH	1661208C1
K	A180-G	18	WH	1661208C1

Legend: * W/300 AMP AMMETER ; # W/LED CLOCK ; & W/WEBASTO HTR ; % W/FR HTR CONTROL ; ! W/F-2017-ISB-ENG N/MTA FUSE BLOCK ; ^ W/0508108 - MTA FUSE BLOCK ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

20.5. CONNECTOR COMPOSITES @(1003A), @(1003B), P. 4 | Figure 885 CONNECTOR COMPOSITES @(1003A), @(1003B) | printed page 885

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A11-GH	12	WH	3566715C1
B	A82-GA	16	WH	1661209C1
C*	A#169A	18	GY	1661208C1
C#	A92-G	18	WH	1661208C1
D	A11-GE	20	WH	1661208C1
E**	A62F-G	18	WH	1661208C1
E##	A62E-G	18	WH	1661208C1
F	A62-GC	18	WH	1661208C1
G	A86-G	18	WH	1661208C1
H&	A90D-G	18	WH	1661208C1
H%	A94-GE	18	WH	1661208C1
H^	A90-G	18	WH	1661208C1
J%%	A133B-G	18	WH	1661208C1
J&&	A133-G	18	WH	1661208C1
K@	A62-GE	18	WH	1661208C1
K!	A62-G	18	WH	1661208C1

Legend: * W/WTEC XMSN W/GEN 4 ; # W/LCT XMSN W/GEN 4 ; & W/HYDRAULIC BRAKES ; % W/BENDIX ABS-8 ; ^ W/REMOTE HAZARD SW ; ** W/L DEFOG FAN SW ; ## W/L AND RIGHT DEFOG FAN SW ; %% W/MANUAL DOOR ; && W/ELECTRIC DOOR

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A11-GG	12	WH	3566715C1
B	A89RK-G	18	WH	1661208C1
C	A44C-G	18	WH	1661208C1
D%	A10-GA	18	WH	1661208C1
D##	A11-GL	18	WH	1661208C1
E*	A44-GC	18	WH	1661208C1
E#	A44C-G	18	WH	1661208C1
F^	A77-G	18	WH	1661208C1
F^	A11-GL	18	WH	1661208C1
F##	A44K-G	14	WH	3566715C1
F!!	A77H	18	WH	1661208C1
G^	A77H	18	WH	1661208C1
G##	A82-GW	16	WH	1661209C1
H!!	A56-G	16	OR	1661209C1
J##	A77-GB	18	WH	1661208C1
K&	A74-GC	18	WH	1661208C1
K%	A74-GA	16	WH	1661209C1

Legend: # W/AIR PARK BRAKE INTERLOCK W/O WHEELCHAIR ; * W/AIR PARK BRAKE INTERLOCK N/LIFT ; & W/ESAPR 7-DAY TIMER ; % W/MULTI MAX TIMER ; ^ W/0508108 - MTA FUSE BLOCK ; NOT MTA FUSE BLOCK ; ## W/2017/2021 ISB/B6.7 DIESEL ENG N/0508108 - ; NOT MTA FUSE BLOCK ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE

20.6. CONNECTOR COMPOSITES @(1004), %%(1005), P. 5 | Figure 886 CONNECTOR COMPOSITES @(1004), %%(1005) | printed page 886

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A11-GA	12	WH	3566715C1
B!!	A26-G	18	WH	1661208C1
B##	A84-G	16	WH	1661209C1
B^	A26-G	18	WH	1661208C1
C	A62-GL	18	WH	1661208C1
D	A41A-G	18	WH	1661208C1
E	A11-GTS	20	WH	1661208C1
F#	A39C	16	GY	1661209C1
G	A17CC	18	WH	1661208C1
H##	A59-G	18	WH	1661208C1
J##	A137A-G	18	WH	1661208C1
K##	A144-GA	18	WH	1661208C1
K##	A144-G	18	WH	1661208C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A9C	18	GY	1661208C1
B	A9VL	18	GY	1661208C1
B#	A9A	18	GY	1661208C1
B##	A9AA	18	GY	1661208C1
C	A9K	18	GY	1661208C1
D	A9A	16	GY	1661209C1
E	A9BB	18	GY	1661208C1
F	A125J	18	GY	1661208C1
G	A9CA	18	GY	1661208C1
H%	A9VL	14	GY	3566715C1
H&	A9VF	18	GY	1661208C1
J@	A9HA	20	TN	1661208C1
J^	A9HA	18	GY	1661208C1
K	A9J	18	GY	1661208C1

Legend: * W/AIR BRAKES ; % W/PARKING BRAKE ALARM ; & W/NEXT GEN HYDRAULIC BRAKES ; @ W/LT STEERING WHEEL SW ; ^ N/LT STEERING WHEEL SW ; ## W/0508108 - MTA FUSE BLOCK ; # N/0508108 - NOT MTA FUSE BLOCK W/HYDRAULIC BRAKE ; %% W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

20.7. CONNECTOR COMPOSITES @(1005A), @(1006), P. 6 | Figure 887 CONNECTOR COMPOSITES @(1005A), @(1006) | printed page 887

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A9A	16	GY	1661209C1
B#	A9W	18	GY	1661208C1
B%	A9WD	18	GY	1661208C1
C	A9Y	18	GY	1661208C1
D	A9Z	18	GY	1661208C1
E	A9X	18	GY	1661208C1
F	A9W	18	GY	1661208C1
G	-	-	-	-
H	-	-	-	-
J	-	-	-	-
K	-	-	-	-

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A89AA	18	OR	1661208C1
B	A89DD	18	OR	1661208C1
C*	A123A	18	GY	1661208C1
C#	A123F	18	GY	1661208C1
D%	A89HB	18	OR	1661208C1
D&	A89H	18	OR	1661208C1
E	-	-	-	-
F	-	-	-	-
G	-	-	-	-

Legend: % W/0508108 - MTA FUSE BLOCK ; & N/0508108 - NOT MTA FUSE BLOCK ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * W/R SW PANEL ROTARY DOOR SW ; # W/L SW PANEL ROTARY DOOR SW

Figure 888 CONNECTOR COMPOSITES @(1008F), *(1008F), @(1008M), *(1008M)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.8. CONNECTOR COMPOSITES @(1008F), *(1008F), @(1008M), *(1008M), P. 7 / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090671 95504E 19FEB20 / MJV0488 13SEP21 ADDED R/D 1008F. ADDED NOTES FOR FUSE BLOCK. / CONNECTOR 1669834C1 BODY LOCK 1675053C1 / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK @ W/0508108 - MTA FUSE BLOCK / STARTER INTERRUPT *(1008F) (LOCATED AT L SIDE OF VEHICLE AT FLASHER PLATE) / STARTER INTERRUPT @(1008M) (LOCATED AT L SIDE OF VEHICLE AT FLASHER PLATE) / CONNECTOR 1669834C1 BODY LOCK 1675053C1 / * W/COMMON FOR W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK # W/0508108 - MTA FUSE BLOCK & N/0508108 - NOT MTA FUSE BLOCK / CONNECTOR 1664531C1 BODY LOCK 1675053C1 / STARTER INTERRUPT @(1008F) (LOCATED AT L SIDE OF VEHICLE AT FLASHER PLATE) / CONNECTOR 1664531C1 BODY LOCK 1675053C1 / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / STARTER INTERRUPT *(1008M) (LOCATED AT L SIDE OF VEHICLE AT FLASHER PLATE) / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A* A17B 16 PK 2033911C1 1652325C1 A@ A17BC 16 PK 2033911C1 1652325C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A@ B17 18 LTGN 2033911C1 1652325C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A* A17CB 18 BK 2033819C1 3517771C1 A# A17L 16 PK 2033819C1 1652325C1 A& A17 16 PK 2033819C1 1652325C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A@ B17B 18 LTGN 2033819C1 1652325C1 / Figure 888 / CONNECTOR COMPOSITES @(1008F), *(1008F), @(1008M), *(1008M)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A@	B17B	18	LTGN	2033819C1	1652325C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A*	A17B	16	PK	2033911C1	1652325C1
A@	A17BC	16	PK	2033911C1	1652325C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A@	B17	18	LTGN	2033911C1	1652325C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A*	A17CB	18	BK	2033819C1	3517771C1
A#	A17L	16	PK	2033819C1	1652325C1
A&	A17	16	PK	2033819C1	1652325C1

Figure 889 CONNECTOR COMPOSITES %(1009)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.9. CONNECTOR COMPOSITES %(1009), P. 8 / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090671 NO. RELEASE NO. 95504E 19FEB20 / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / G F E D C B / CONNECTOR 2006789C1 BODY LOCK 2006792C1 / COIL SIGNAL- ZVR RELAYS %(1009) (LOCATED AT L SIDE OF VEHICLE AT FLASHER PLATE) / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / Figure 889 / CONNECTOR COMPOSITES %(1009)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A12B	18	LTBL	1661208C1
B	A79P	16	PK	1661209C1
C	A117C	18	GY	1661208C1
D	A89CD	18	VT	1661208C1
E	A125H	18	GY	1661208C1
F	-	-	-	-
G	-	-	-	-

Figure 890 CONNECTOR COMPOSITES #(1010)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.10. CONNECTOR COMPOSITES #(1010), P. 9 / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090671 NO. RELEASE NO. 95504E 20FEB20 / MJV0488 13SEP21 ADDED R/D 1010. / CAV CIRCUIT GA COLOR TERMINAL 1 KA122F 18 GY 2025418C1 2 KA122B 18 GY 2025418C1 3 KA122D 18 GY 1659673C1 4 - - - - 5 KA122A 18 GY 1659673C1 / NEXT GEN HYDRAULIC PARK BRAKE WHEELCHAIR RELAY #(1010) / 2 4 1 5 3 CONNECTOR 2028683C1 BODY LOCK 2028684C1 / # N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENGINE & W/F-2018-PROPANE/GASOLINE ENGINE / Figure 890 / CONNECTOR COMPOSITES #(1010)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	KA122F	18	GY	2025418C1
2	KA122B	18	GY	2025418C1
3	KA122D	18	GY	1659673C1
4	-	-	-	-
5	KA122A	18	GY	1659673C1

Figure 891 CONNECTOR COMPOSITES &(1010), @(1010F)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.11. CONNECTOR COMPOSITES &(1010), @(1010F), P. 10 / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090671 NO. RELEASE NO. 95504E 20FEB20 / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / RELAY ZVR SPLICE DIODE ASSY CONN @(1010F) (LOCATED AT LEFT SIDE OF VEHICLE AT FLASHER PLATE) / CONNECTOR 0872291R1 / B A / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 87a 85 86 / 86 87a 85 / CAV CIRCUIT GA COLOR TERMINAL A# A12EB 16 LTBL 0188396R1 A% A12E 18 LTBL 0879630R1 B% A12B 18 LTBL 0879630R1 B# A12B 18 LTBL 0879630R1 / Figure 891 / CONNECTOR COMPOSITES &(1010), @(1010F)

CAV	CIRCUIT	GA	COLOR	TERMINAL
R1-30	A89CC	18	VT	3768007C1
R1-85	A89CD	18	VT	3768003C1
R1-86	A89CB	18	VT	3768003C1
R1-87	A9CA	18	GY	3768007C1

Legend: R1-87A - - - ; R2-30 A17C 18 LTGN 3768007C1 ; R2-85 A17CA 18 LTGN 3768003C1 ; R2-86 A17CC 18 WH 3768003C1 ; R2-87 A17CB 18 BK 3768007C1 ; R2-87A - - - ; R2-30 SC99J 16 TN 3768007C1 ; R2-85 SC99K 16 TN 3768004C1 ; R2-86 SC99-GB 16 WH 3768004C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	A12EB	16	LTBL	0188396R1
A%	A12E	18	LTBL	0879630R1
B%	A12B	18	LTBL	0879630R1
B#	A12B	18	LTBL	0879630R1

20.12. CONNECTOR COMPOSITES, %(1011), P. 11 | Figure 892 CONNECTOR COMPOSITES %(1011) | printed page 892

CAV	CIRCUIT	GA	COLOR	TERMINAL
R1-30	A82R	16	GY	3768007C1
R1-85	A82DC	16	GY	3768004C1
R1-86	A82C	18	GY	3768003C1
R1-87	A82DB	16	GY	3768007C1
R1-87	A82H	16	GY	3768004C1
87A	-	-	-	-
R2-30	A101	18	TN	3768007C1
R2-85	A89CF	18	VT	3768003C1
R2-86	A15A	18	RD	3768003C1
R2-87	A103	18	TN	3768003C1

Legend: R2-87A A103A 18 TN 3768003C1 ; R3-30 A9BB 16 GY 3768007C1 ; R3-85 A79M-G 14 WH 3768004C1 ; R3-86 A79D 16 GY 3768004C1 ; R3-87 A79 16 GY 3768007C1 ; R3-87A - - - ; R4-30 A82R 16 GY 3768007C1 ; R4-85 A82DD 16 GY 3768004C1 ; R4-86 A82D 18 GY 3768003C1

20.13. CONNECTOR COMPOSITES, %%%(1011), P. 11A
Figure 893 CONNECTOR COMPOSITES %%%(1011)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.13. CONNECTOR COMPOSITES, %%%(1011), P. 11A / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1172 CIRCUIT DIAGRAM, BE,CE BUS MODELS, PART AE08090671 NO. RELEASE NO. 96183U 26AUG21 / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / FUSE BLOCK %%%(1011) (LOCATED AT LEFT SIDE OF VEHICLE AT FLASHER PLATE) / CONNECTOR 1659650C1 BODY LOCK 0593387C1 / A B F26 A B F25 A B F24 A B F23 A B F22 A B F21 A B F20 A B F19 A B F18 A B F17 A B F16 A B F15 A B F14 / A E D C R6 B A E D C R5 B A E D C R4 B A E D C R3 B A E D C R2 B A E D C R1 B / B F35 A / A B F13 A B F12 A B F11 A B F10 A B F9 A B F8 A B F7 A B F6 A B F5 A B F4 A B F3 A B F2 A B F1 / A B F34 A B F33 A B F32 A B F31 A B F30 A B F29 A B F28 A B F27 / CHART CONTINUED ON SHEET_11B / RD GY / Figure 893 / CONNECTOR COMPOSITES %%%(1011)

Figure 894 CONNECTOR COMPOSITES %%%(1011)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.14. CONNECTOR COMPOSITES %%%(1011), P. 11B / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, PART AE08090671 NO. RELEASE NO. 96183U 26AUG21 / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / A B F26 A B F25 A B F24 A B F23 A B F22 A B F21 A B F20 A B F19 A B F18 A B F17 A B F16 A B F15 A B F14 / A E D C R6 B A E D C R5 B A E D C R4 B A E D C R3 B A E D C R2 B A E D C R1 B / A B F13 A B F12 A B F11 A B F10 A B F9 A B F8 A B F7 A B F6 A B F5 A B F4 A B F3 A B F2 A B F1 / B F35 A / A B F34 A B F33 A B F32 A B F31 A B F30 A B F29 A B F28 A B F27 / Figure 894 / CONNECTOR COMPOSITES %%%(1011)

20.15. CONNECTOR COMPOSITES %%%(1011), P. 11C
Figure 895 CONNECTOR COMPOSITES %%%(1011)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.15. CONNECTOR COMPOSITES %%%(1011), P. 11C / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / FUSE BLOCK %%%(1011) (LOCATED AT LEFT SIDE OF VEHICLE AT FLASHER PLATE) / A B F26 A B F25 A B F24 A B F23 A B F22 A B F21 A B F20 A B F19 A B F18 A B F17 A B F16 A B F15 A B F14 / A E D C R6 B A E D C R5 B A E D C R4 B A E D C R3 B A E D C R2 B A E D C R1 B / B F35 A / A B F13 A B F12 A B F11 A B F10 A B F9 A B F8 A B F7 A B F6 A B F5 A B F4 A B F3 A B F2 A B F1 / A B F34 A B F33 A B F32 A B F31 A B F30 A B F29 A B F28 A B F27 / Figure 895 / CONNECTOR COMPOSITES %%%(1011)

Figure 896 CONNECTOR COMPOSITES %%%(1011)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.16. CONNECTOR COMPOSITES %%%(1011), P. 11D / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, PART AE08090671 NO. RELEASE NO. 96183U 26AUG21 / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / CHART CONTINUED FROM SHEET_11C FUSE BLOCK %%%(1011) (LOCATED AT LEFT SIDE OF VEHICLE AT FLASHER PLATE) / CONNECTOR 1659650C1 BODY LOCK 0593387C1 / A B F26 A B F25 A B F24 A B F23 A B F22 A B F21 A B F20 A B F19 A B F18 A B F17 A B F16 A B F15 A B F14 / A E D C R6 B A E D C R5 B A E D C R4 B A E D C R3 B A E D C R2 B A E D C R1 B / B F35 A / A B F13 A B F12 A B F11 A B F10 A B F9 A B F8 A B F7 A B F6 A B F5 A B F4 A B F3 A B F2 A B F1 / A B F34 A B F33 A B F32 A B F31 A B F30 A B F29 A B F28 A B F27 / Figure 896 / CONNECTOR COMPOSITES %%%(1011)

20.17. CONNECTOR COMPOSITES %%%(1011), P. 11E
Figure 897 CONNECTOR COMPOSITES %%%(1011)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.17. CONNECTOR COMPOSITES %%%(1011), P. 11E / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, PART AE08090671 NO. RELEASE NO. 96183U 26AUG21 / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / CHART CONTINUED FROM SHEET_11C FUSE BLOCK %%%(1011) (LOCATED AT LEFT SIDE OF VEHICLE AT FLASHER PLATE) / CONNECTOR 1659650C1 BODY LOCK 0593387C1 / A B F26 A B F25 A B F24 A B F23 A B F22 A B F21 A B F20 A B F19 A B F18 A B F17 A B F16 A B F15 A B F14 / A E D C R6 B A E D C R5 B A E D C R4 B A E D C R3 B A E D C R2 B A E D C R1 B / B F35 A / A B F13 A B F12 A B F11 A B F10 A B F9 A B F8 A B F7 A B F6 A B F5 A B F4 A B F3 A B F2 A B F1 / A B F34 A B F33 A B F32 A B F31 A B F30 A B F29 A B F28 A B F27 / Figure 897 / CONNECTOR COMPOSITES %%%(1011)

Figure 898 CONNECTOR COMPOSITES %(1012)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.18. CONNECTOR COMPOSITES %(1012), P. 12 / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090671 NO. RELEASE NO. 95504E 20FEB20 / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / FUSE BLOCK 1012-A9 %(1012) (LOCATED IN PLATFORM HARNESS) / CONNECTOR 3768010C1 BODY LOCK 3768011C1 COVER 4197213C1 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 87a 86 85 / 86 87a 85 / 86 87a 85 / % W/0508108 - MTA FUSE BLOCK / Figure 898 / CONNECTOR COMPOSITES %(1012)

CAV	CIRCUIT	GA	COLOR	TERMINAL
R1-30	A64B	16	YL	3768007C1
R1-85	A64A	16	YL	3768004C1
R1-86	A64C	18	YL	3768003C1
R1-87	A64	12	YL	3768009C1

Legend: R1-87A - - - ; R2-30 A39D 14 OR 3768008C1 ; R2-85 A39C 16 GY 3768004C1 ; R2-86 A39A 16 GY 3768004C1 ; R2-87A A39B 16 GY 3768004C1 ; R2-87 - - - ; R3-30 A71D 18 LTBL 3768007C1 ; R3-85 A71A 18 OR 3768004C1 ; R3-85 A71E 18 OR 3768004C1

20.19. CONNECTOR COMPOSITES %(1012), P. 12A
Figure 899 CONNECTOR COMPOSITES %(1012)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.19. CONNECTOR COMPOSITES %(1012), P. 12A / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1172 CIRCUIT DIAGRAM, BE,CE BUS MODELS, PART AE08090671 NO. RELEASE NO. 96183U 28JUL21 / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / AIR PARK BRAKE SOLENOID %(1012) (LOCATED IN PLATFORM HARNESS) / CONNECTOR 0587568C91 / B A / AIR PARK BRAKE SOLENOID %(1012) (LOCATED IN PLATFORM HARNESS) / CONNECTOR 0587568C91 / % N/0508108 - NOT MTA FUSE BLOCK W/F-2018-PROPANE/GASOLINE-ENG / CAV CIRCUIT GA COLOR TERMINAL SLEEVE/SLV A A44H 18 GY 0587576C1 1652325C1 B* A44-GB 18 WH 0587576C1 1652325C1 B A44C 18 GY 0587576C1 1652325C1 / CAV CIRCUIT GA COLOR TERMINAL SLEEVE/SLV A A17 12 RD 3614762C1 3541256C1 B A17A 12 RD 3614762C1 3541256C1 / Figure 899 / CONNECTOR COMPOSITES %(1012)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A44H	18	GY	0587576C1
B*	A44-GB	18	WH	0587576C1
B	A44C	18	GY	0587576C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A17	12	RD	3614762C1
B	A17A	12	RD	3614762C1

20.20. CONNECTOR COMPOSITES %(1012A), %(1013), P. 13 | Figure 900 CONNECTOR COMPOSITES %(1012A), %(1013) | printed page 900

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	A44H	18	GY	587576C1	1652325C1
B*	A44-GB	18	WH	587576C1	1652325C1
B#	A44C	18	GY	587576C1	1652325C1

Legend: * W/AIR PARK BRAKE N/LIFT INTERLOCK ; # W/AIR PARK BRAKE W/LIFT INTERLOCK ; % W/0508108 - MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
R1-30	A13AA	12	PK	4185895C1
R1-85	A13A	16	PK	3768007C1
R1-86	A13-G	18	WH	3768007C1
R1-87	A14CA	12	RD	4185895C1
R2-30	A13BA	12	PK	4185895C1
R2-85	A13B	16	PK	3768007C1
R2-86	A13-GA	18	WH	3768007C1
R2-87	A14EA	12	RD	4185895C1

20.21. CONNECTOR COMPOSITES %(1013), %(1014), P. 13A | Figure 901 CONNECTOR COMPOSITES %(1013), %(1014) | printed page 901

CAV	CIRCUIT	GA	COLOR	TERMINAL
1%	A44J	18	GY	2025418C1
2@	A44-GD	18	WH	2025418C1
2#	A44-GC	18	WH	2025418C1
3%	A44	18	GY	1659673C1
4	-	-	-	-
5%	A44H	18	GY	1659673C1

Legend: PARK BRAKE INTERLOCK GROUND W/HYDRAULIC SERVICE BRAKE ; AND W/F-2018-PROPANE/GASOLINE-ENG ; PARK BRAKE INTERLOCK W/HYDRAULIC BRAKE ; GROUND W/F-2017-ISB-ENG ; - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG AND

CAV	CIRCUIT	GA	COLOR	TERMINAL
A%	A13D	18	PK	1661208C1
B#	A144D	16	GY	1661209C1
C%	A89A	18	OR	1661208C1
D%	A89F	18	PK	1661208C1
E%	A119M	18	GY	1661208C1
F*	A74B	18	LTGN	1661208C1
F!	A74D	18	LTGN	1661208C1

20.22. CONNECTOR COMPOSITES !(1014), P. 14 | Figure 902 CONNECTOR COMPOSITES !(1014) | printed page 902

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	A14CB	12	RD	3768156C1
2	SA14CB	12	RD	3768156C1
3	-	-	-	-
4	A14CC	12	RD	3768014C1
4	SA14CC	12	RD	3768018C1
5#	A119AC	18	GY	3768012C1
5@	A119A	16	GY	3768013C1
5%	A26	18	TN	3768012C1
5*	A119	16	GY	3768013C1
5^	A26B	18	TN	3768012C1
6	A39D	14	OR	3768014C1
7	A14BA	18	RD	3768012C1
8	SA28	20	TN	3768012C1
8	A28	18	TN	3768012C1
9	A14EB	12	RD	3768014C1
9	SA14EB	12	RD	3768018C1
10	A14EC	12	RD	3768157C1
10	SA14EC	12	RD	3768157C1
11	A14DA	12	RD	3768018C1
11	SA14DA	12	RD	3768018C1
12	-	-	-	-
13@@	A79A	16	RD	3768013C1
13**	A90C	18	GY	3768012C1
13	SA14HB	18	RD	3768012C1
14	A14TS	20	RD	3768012C1
15##	A75	12	LTGN	3768014C1
15%%	A75	12	RD	3768014C1
15*#	A74D	14	LTGN	3768014C1
15*%	A74	12	LTGN	3768014C1
15*@	A74H	12	LTGN	3768014C1
16	A15B	16	RD	3768013C1
16	A15	16	RD	3768013C1
17	A14DB	12	RD	3768014C1
17	SA14DB	12	RD	3768018C1
18	-	-	-	-
19	A14FA	12	RD	3768156C1
19	SA14FA	12	RD	3768156C1
20	-	-	-	-
21	A14CA	12	RD	3768014C1
21	SA14CA	12	RD	3768014C1
22	A98	18	VT	3768012C1
22	SH98A	18	VT	3768012C1
23	A14EA	12	RD	3768014C1
23	SA14EA	12	RD	3768014C1
24	A#170A	18	PK	3768012C1
24	SD92B	18	TN	3768012C1
25	A14FB	12	RD	3768014C1
25	SA14FB	12	RD	3768018C1
26	A14KA	12	RD	3768157C1
26	SA14KA	12	RD	3768157C1
27	-	-	-	-
28	A13AF	12	PK	3768014C1
29	A152W	18	GY	3768012C1
30	A64A	16	YL	3768014C1
30	A64B	16	YL	3768014C1
31	A59	16	GY	3768014C1
32	A152W	18	GY	3768012C1

Legend: 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 20FEB20 AE08090671 014

20.23. CONNECTOR COMPOSITES %(1014A), %(1014F), %(1015), P. 15 | Figure 903 CONNECTOR COMPOSITES %(1014A), %(1014F), %(1015) | printed page 903

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A13D	18	PK	1661208C1
B	-	-	-	-
C	A89A	18	OR	1661208C1
D	A89F	18	PK	1661208C1
E	A119M	18	GY	1661208C1
F	A74B	18	LTGN	1661208C1

Legend: G-H - - - ; J-K - - -

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	A89CB	18	VT	879630R1
B*	A122FA	18	GY	879630R1
C*	A89CE	18	VT	879632R1
A#	A89CB	18	VT	0333732C1
B#	A122F	18	GY	0333732C1
C*	A89CF	18	VT	879632R1
C#	A89CE	18	VT	0333736C1
C#	A89CF	18	VT	0333736C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; * W/0508108 - MTA FUSE BLOCK ; # N/0508108 - NOT MTA FUSE BLOCK ; W/F-2017-ISB-ENGINE AND W/F-2018-PROPANE/

CAV	CIRCUIT	GA	COLOR	TERMINAL
R1-30	A17A	12	RD	4185895C1
R1-85	A17SE	18	RD	3768007C1
R1-86	A10-GA	18	WH	3768007C1
R1-87	A17BZ	12	RD	4185895C1

Figure 904 CONNECTOR COMPOSITES %(1015), %(1016)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.24. CONNECTOR COMPOSITES %(1015), %(1016), P. 15A / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1172 CIRCUIT DIAGRAM, BE,CE BUS MODELS, PART AE08090671 NO. RELEASE NO. 96183U 28JUL21 / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / ECONOMY MODE SWITCH %(1015) (LOCATED AT LEFT SIDE OF VEHICLE AT FLASHER PLATE) / CONNECTOR 2028683C1 BODY LOCK 2028684C1 / BACK UP LIGHT CHECK RELAY %(1016) (LOCATED AT LEFT SIDE OF VEHICLE AT FLASHER PLATE) / CONNECTOR 2028683C1 BODY LOCK 2028684C1 / % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG AND W/F-2018-PROPANE/GASOLINE-ENG / 2 4 1 / 2 4 1 / Figure 904 / CONNECTOR COMPOSITES %(1015), %(1016)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1%	A92T	18	TN	2025418C1
2%	A92-G	18	WH	2025418C1
3@	A103	18	TN	1661709C1
3@	A103A	18	TN	1661709C1
3!	A103	18	TN	1659673C1
4	-	-	-	-
5#	A#142	16	TN	2018946C1
5*	A92#142	16	TN	2018946C1

20.25. CONNECTOR COMPOSITES @@(1016), P. 16 | Figure 905 CONNECTOR COMPOSITES @@(1016) | printed page 905

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	A13AC	12	PK	3768018C1
1#	A13AG	12	PK	3768018C1
2-4	-	-	-	-
5@	A44K	18	GY	3768012C1
5%	A44AB	16	VT	3768013C1
6^	A13EE	18	PK	3768012C1
6^^	A152Y	18	RD	3768012C1
7-8	-	-	-	-
9	A13AE	12	PK	3768018C1
10	-	-	-	-
11*	A13AD	12	PK	3768018C1
11#	A13AC	12	PK	3768018C1
12	-	-	-	-
13##	A#163AA	18	YL	3768012C1
13**	A#163	18	YL	3768012C1
14	A92	18	TN	3768012C1
15*%	A13DA	18	PK	3768012C1
15*^	A13AB	18	PK	3768012C1
16	A87A	18	GY	3768012C1
17	-	-	-	-
18	A13BB	12	PK	3768157C1
19-20	-	-	-	-
21	A99F	18	VT	3768012C1
22	A97UA	18	VT	3768012C1
23	A39A	16	GY	3768013C1
24^*	A71	16	OR	3768013C1
25-26	-	-	-	-
27	A13BC	12	PK	3768157C1
28	-	-	-	-
29^@	A95CA	18	PK	3768012C1
29^#	A13BF	18	PK	3768012C1
29#	A13FD	18	PK	3768012C1
30	A28A	18	TN	3768012C1
31@	A94BK	12	GY	3768014C1
31%	A90E	18	GY	3768012C1
31%%	A94BJ	18	GY	3768012C1
31%#	A94Y	18	GY	3768012C1
31@	A94BA	18	GY	3768012C1
31%	A90E	18	GY	3768012C1
32	A13TS	20	PK	3768012C1
33	-	-	-	-
34*	A148B	16	LTBL	3768154C1
34#	A12E	16	GY	3768154C1
35	-	-	-	-
36	A62	16	DKBL	3768013C1
37	A44M	16	GY	3768013C1
38%^	A12EB	16	LTBL	3768014C1
38%^	A12AA	16	LTBL	3768014C1
38@#	A12A	16	LTBL	3768013C1
39*	A12C	18	LTBL	3768012C1
39#	A12C	18	LTBL	3768012C1
40	A62Z	16	DKBL	3768013C1

Figure 906 CONNECTOR COMPOSITES %(1017)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.26. CONNECTOR COMPOSITES %(1017), P. 16A / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, PART AE08090671 NO. RELEASE NO. 96183U 23AUG21 / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG AND W/F-2018-PROPANE/GASOLINE-ENG / 2 4 1 / FOG LIGHT RELAY %(1017) (LOCATED AT LEFT SIDE OF VEHICLE AT FLASHER PLATE) / CONNECTOR 2028683C1 BODY LOCK 2028684C1 / CAV CIRCUIT GA COLOR TERMINAL 1% A64A 16 YL 2025418C1 2% A64C 18 YL 2025418C1 3% A64B 16 YL 1661709C1 4% - - - - 5% A64 12 YL 1661710C1 / Figure 906 / CONNECTOR COMPOSITES %(1017)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1%	A64A	16	YL	2025418C1
2%	A64C	18	YL	2025418C1
3%	A64B	16	YL	1661709C1
4%	-	-	-	-
5%	A64	12	YL	1661710C1

20.27. CONNECTOR COMPOSITES %(1018), %(1018B), %(1019), %(1020), P. 16B | Figure 907 CONNECTOR COMPOSITES %(1018), %(1018B), %(1019), %(1020) | printed page 907

CAV	CIRCUIT	GA	COLOR	TERMINAL
1%	A39C	16	GY	2025418C1
2%	A9A	16	GY	2025418C1
3*	A39D	16	GY	1661709C1
3#	A39D	16	GY	2018946C1
4	-	-	-	-
5*	A39B	16	GY	1661709C1
5#	A39B	16	GY	2018946C1
MTA	FUSE	BLOCK		

CAV	CIRCUIT	GA	COLOR	TERMINAL
1%	AV39C	16	GY	2025418C1
2%	AV39A	16	GY	2025418C1
3%	AV39D	14	OR	1661709C1
4*	GF39B	16	GY	2025418C1
5%	AV39B	16	GY	1661709C1

Legend: N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG AND

CAV	CIRCUIT	GA	COLOR	TERMINAL
1%	A89CD	18	VT	2025418C1
2%	A89CB	18	VT	2025418C1
3%	A89CC	18	PL	1659673C1
4	-	-	-	-
5%	A9CA	18	GY	1659673C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1%	A117C	18	GY	2025418C1
2*	A117E	18	GY	2025418C1
2#	A117E	16	GY	2025418C1
3%	A117	18	GY	1659673C1
4	-	-	-	-
5%	A9FA	18	GY	1659673C1

Legend: N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG AND

20.28. CONNECTOR COMPOSITES %(1021), %(1022), P. 16C
Figure 908 CONNECTOR COMPOSITES %(1021), %(1022)

20.28. CONNECTOR COMPOSITES %(1021), %(1022), P. 16C | Figure 908 CONNECTOR COMPOSITES %(1021), %(1022) | printed page 908

CAV	CIRCUIT	GA	COLOR	TERMINAL
1%	A125H	18	GY	2025418C1
2%	A125K	18	GY	2025418C1
3%	A125L	18	GY	1659673C1
4	-	-	-	-
5%	A125J	18	GY	1659673C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1%	A60B	16	OR	2025418C1
2%	A56-G	16	OR	3519441C1
2%	A57-G	16	OR	3519441C1
3%	A9T	18	GY	1659673C1
4	-	-	-	-
5%	A56A	18	OR	1659673C1

Legend: N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG AND

Figure 909 CONNECTOR COMPOSITES %(1023), %(1023A), %(1024A)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.29. CONNECTOR COMPOSITES %(1023), %(1023A), %(1024A), P. 17 / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090671 NO. RELEASE NO. 95504E 20FEB20 / MJV0488 13SEP21 REMOVED R/D 1017 & B ADDED R/D 1024A, FUSE DETAILS. / CONNECTOR 3515762C1 BODY LOCK 3515764C1 / D C B A / E F G H / D B A C / STOP LIGHT 1 PRESSURE SW %(1023A) (LOCATED NEAR BRAKE PEDAL) / CONNECTOR 1661777C1 BODY LOCK 1661873C1 / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / CONNECTOR CONNECTOR 1661777C1 1661777C1 BODY BODY LOCK LOCK 1661873C1 1661873C1 / D D B B A A C C / STOP LIGHT 2 PRESSURE SW %(1024A) (LOCATED NEAR BRAKE PEDAL) / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A A47 18 GY 1661261C1 B A48 18 GY 1661261C1 C - - - - D - - - - E - - - - F - - - - G - - - - H - - - - / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A-B PLUG - - 2025431C1 - C A70CA 16 GY 3594831C1 1661872C1 D A9VG 16 GY 3594831C1 1661872C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A-B PLUG - - 2025431C1 - C A70CB 16 GY 3594831C1 1661872C1 D A9VH 16 GY 3594831C1 1661872C1 / Figure 909 / CONNECTOR COMPOSITES %(1023), %(1023A), %(1024A)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A47	18	GY	1661261C1
B	A48	18	GY	1661261C1
C	-	-	-	-
D	-	-	-	-
E	-	-	-	-
F	-	-	-	-
G	-	-	-	-
H	-	-	-	-

20.30. CONNECTOR COMPOSITES %(1025), %(1026), %(1027), %(1027A), P. 17A | Figure 910 CONNECTOR COMPOSITES %(1025), %(1026), %(1027), %(1027A) | printed page 910

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A60C	16	OR	2025418C1
2	A57-G	16	OR	2025418C1
3	A9U	18	GY	1659673C1
4	-	-	-	-
5	A57A	18	OR	1659673C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1%	A15A	18	RD	2025418C1
2%	A89CF	18	VT	2025418C1
3%	A101	18	TN	1659673C1
4%	A103A	18	TN	2025418C1
4*	A103	18	TN	2025418C1
4#	A92G	18	GY	2025418C1
5#	A122F	18	TN	1659673C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A119	16	GY	2025418C1
2	A119-G	16	WH	2025418C1
3	A119D	16	GY	2018946C1
4	-	-	-	-
5	A119J	16	GY	2018946C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	A77D	18	LTGN	2025418C1
1#	A77E	14	LTGN	2025419C1
2	A77B	18	WH	2025418C1
3	A77A	18	WH	1659673C1
4	-	-	-	-
5	A77C	18	GY	1659673C1

Legend: - NOT MTA FUSE BLOCK W/F-2018-PROPANE/GASOLINE-ENG ; COMPRESSOR CONTROL N/RELOCATED BOARDS ; COMPRESSOR CONTROL W/RELOCATED BOARDS

20.31. CONNECTOR COMPOSITES %(1028), %(1029), %(1029A), P. 18 | Figure 911 CONNECTOR COMPOSITES %(1028), %(1029), %(1029A) | printed page 911

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A41	18	TN	0879630R1
B	A110	18	GY	0879630R1

CIRCUIT	GA	COLOR	TERMINAL
A5BB(-)	18	GN	3534164C1
A5D(-)	18	GN	3534164C1
A5B(-)	18	GN	3534164C1
A5B(-)	18	GN	3534164C1
-	-	-	-
A5D(-)	18	GN	3534164C1
A5D(+)	18	YL	3534164C1
-	-	-	-
A5B(+)	18	YL	3534164C1
A5B(+)	18	YL	3534164C1
A5D(+)	18	YL	3534164C1
A5BA(+)	18	YL	3534164C1
MTA FUSE		BLOCK	

CIRCUIT	GA	COLOR	TERMINAL
A5BC(-)	18	GN	3534164C1
A5BD(-)	18	GN	3534164C1
A5B(-)	18	GN	3534164C1
A5B(-)	18	GN	3534164C1
A5AH(-)	18	GN	3534164C1
A5TS(-)	20	GN	3535484C1
A5E(-)	18	GN	3534164C1
A5AG(-)	18	GN	3534164C1
A5E(+)	18	YL	3534164C1
A5AG(+)	18	YL	3534164C1
A5AH(+)	18	YL	3534164C1
A5TS(+)	20	YL	3535484C1
A5B(+)	18	YL	3534164C1
A5B(+)	18	YL	3534164C1
A5BD(+)	18	YL	3534164C1
ABC(+)	18	YL	3534164C1
MTA FUSE		BLOCK	

20.32. CONNECTOR COMPOSITES %(1030), %(1031), %(1031), P. 18A
Figure 912 CONNECTOR COMPOSITES %(1030), %(1031), %(1031)

20.32. CONNECTOR COMPOSITES %(1030), %(1031), %(1031), P. 18A | Figure 912 CONNECTOR COMPOSITES %(1030), %(1031), %(1031) | printed page 912

CIRCUIT	GA	COLOR	TERMINAL
A119K	18	GY	3519441C1
A119-GA	18	WH	2025418C1
A119J	16	GY	2018946C1
A119H	18	GY	2025418C1
A119K	18	GY	1659673C1

CIRCUIT	GA	COLOR	TERMINAL
A120A	18	LTGN	0879630R1
A120B	18	LTGN	0879630R1

CIRCUIT	GA	COLOR	TERMINAL
A44H	18	GY	0587576C1
A44-GB	18	GY	0587576C1

20.33. CONNECTOR COMPOSITES %(1033B), %(1043A), %(1044A), %(1051), P. 19 | Figure 913 CONNECTOR COMPOSITES %(1033B), %(1043A), %(1044A), %(1051) | printed page 913

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C122-G	16	WH	0239805R1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A79L	16	GY	0188396R1
B	A79N	16	GY	0188396R1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	A90D	18	GY	879630R1
A*	A90D	18	GY	0333732C1
B#	A90H	16	GY	0333732C1
B*	A90H	16	GY	0333732C1
C#	A90F	18	GY	879630R1
C*	A90F	18	GY	0333732C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; # W/0508108 - MTA FUSE BLOCK ; * N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1A	A122A	18	GY	1661224C1
1B	A122B	18	GY	1661224C1
2A	-	-	-	-
2B	-	-	-	-

20.34. CONNECTOR COMPOSITES %(1052), @(1053), @(1053), %(1060), P. 20 | Figure 914 CONNECTOR COMPOSITES %(1052), @(1053), @(1053), %(1060) | printed page 914

CIRCUIT	GA	COLOR	TERMINAL
A137A	18	LTBL	1661539C1
A137A-G	18	WH	1661539C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1#	A74L	16	LTGN	4160598C1
1%	A74L	16	LTGN	3573150C1
2#	A74H	18	LTGN	3548971C1
2%	A74H	18	LTGN	3573150C1
3#	A74-GA	16	WH	4160598C1
3%	A74-GA	16	WH	3573150C1
4-5	-	-	-	-
6#	A75C	18	LTGN	3548971C1
6%	A75C	18	LTGN	3573150C1

Legend: # W/0508108 - MTA FUSE BLOCK ; % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1#	B74L	16	RD	4160598C1
1%	A74L	16	RD	3573150C1
2#	B74H	18	LTGN	3548971C1
2%	A74H	18	LTGN	3573150C1
3#	B74-GA	18	WH	3548971C1
3%	A74-GA	18	WH	3573150C1
4-5	-	-	-	-
6#	B75CS	18	LTGN	3548971C1
6%	A75C	18	LTGN	3573150C1

Legend: # W/0508108 - MTA FUSE BLOCK ; % N/0508108 - NOT MTA FUSE BLOCK ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1A	A89ZX	18	OR	1661224C1
1B	A89ZX-G	18	WH	1661224C1
2A	A89RK	18	OR	1661224C1
2B*	A89RK-G	18	WH	3541250C1
2B*	A89ZX-G	18	WH	3541250C1

Legend: * W/PUPIL WARNING LIGHT INDICATORS ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

20.35. CONNECTOR COMPOSITES %(1060A), @(1062), %(1099), %(1099A), P. 21 | Figure 915 CONNECTOR COMPOSITES %(1060A), @(1062), %(1099), %(1099A) | printed page 915

CAV	CIRCUIT	GA	COLOR	TERMINAL
1A	A89ZX	18	OR	1661224C1
1B	A89ZX-G	18	WH	1661224C1
2A	A89RK	18	OR	1661224C1
2B	A89RK-G	18	WH	3541250C1
2B	A89ZX-G	18	WH	3541250C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1A#	A41A	16	TN	239805R1
1A%	A41A	16	TN	1661226C1
1B#	A41A-G	18	WH	1661224C1
1B%	A41A-G	18	WH	1661224C1
2A	-	-	-	-
2B	-	-	-	-

Legend: # W/0508108 - MTA FUSE BLOCK ; % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1A	A144C	16	GY	1661226C1
1B	A144-G	18	WH	1661224C1
2A	-	-	-	-
2B	-	-	-	-

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A144A	18	GY	1661539C1
2	A144-G	18	WH	1661539C1
3	A144B	18	GY	1661539C1
4*	A144-G	18	WH	1661537C1
4*	A144-GA	18	WH	1661537C1

Figure 916 CONNECTOR COMPOSITES %(1099C), %(1099D), %(1100)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.36. CONNECTOR COMPOSITES %(1099C), %(1099D), %(1100), P. 22 / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090671 NO. 95504E 21FEB20 / MJV0488 13SEP21 ADDED R/D 1099C,1099D,B 1100. / FIRE EXTINGUISHER %(1099C) (LOCATED IN PLATFORM HARNESS) / CONNECTOR 2206658C1 / % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG / FIRE EXTINGUISHER %(1099D) (LOCATED IN PLATFORM HARNESS) / CONNECTOR 2206658C1 / % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG / PVM PRESSURE SENSOR %(1100) (LOCATED IN ENGINE HARNESS) / CONNECTOR 4196881C1 / % W/F-2017-ISB-ENG,F-2021-B6.7-ENG / 3 2 1 / CAV CIRCUIT GA COLOR TERMINAL A A144D 16 GY 0239805R1 / CAV CIRCUIT GA COLOR TERMINAL A A144C 16 GY 0239805R1 / CAV CIRCUIT GA COLOR TERMINAL SLEEVE/SLV 1 K40C 18 GY 4147514C1 4147517C1 2 K40A 18 GY 4147514C1 4147517C1 3 K40B 18 GY 4147514C1 4147517C1 / Figure 916 / CONNECTOR COMPOSITES %(1099C), %(1099D), %(1100)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A144D	16	GY	0239805R1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A144C	16	GY	0239805R1

Legend: % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K40C	18	GY	4147514C1
2	K40A	18	GY	4147514C1
3	K40B	18	GY	4147514C1

20.37. CONNECTOR COMPOSITES @(1100), @(1100), %(1101), P. 23
Figure 917 CONNECTOR COMPOSITES @(1100), @(1100), %(1101)

20.37. CONNECTOR COMPOSITES @(1100), @(1100), %(1101), P. 23 | Figure 917 CONNECTOR COMPOSITES @(1100), @(1100), %(1101) | printed page 917

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A15	16	RD	1661209C1
B*	A17L	16	PK	1661209C1
B#	A149A	18	GY	1661208C1
C*	A12D	18	GY	1661208C1
C#	A149D	18	GY	1661208C1
D*	A13AD	18	GY	1661208C1
D#	A149AD	18	GY	1661208C1

CIRCUIT	GA	COLOR	TERMINAL
A15	16	RD	1661209C1
A17	16	PK	1661209C1
A149A	18	GY	1661208C1
A12	16	LTBL	1661209C1
A149D	18	GY	1661208C1
A12D	18	GY	1661208C1
A13AN	16	PK	1661209C1
A149AD	18	GY	1661208C1
A13AD	18	GY	1661208C1

Legend: @ N/0508108 - NOT MTA FUSE BLOCK ; * COMMON W/F-2017-ISB-ENG AND W/F-2018-

CAV	CIRCUIT	GA	COLOR	TERMINAL
A%	A11-GC	18	WH	1661261C1
B%	A12C	18	LTBL	1661261C1
C#	A62DM	18	DKBL	1661261C1
C@	A62D	18	DKBL	1661261C1
D%	A3E(+)	18	DKBL	1661261C1
E%	A3F(-)	18	GY	1661261C1
F	-	-	-	-

20.38. CONNECTOR COMPOSITES %(1101), %(1104), %(1104A), %(1104B), %(1105M), P. 24 | Figure 918 CONNECTOR COMPOSITES %(1101), %(1104), %(1104A), %(1104B), %(1105M) | printed page 918

CIRCUIT	GA	COLOR	TERMINAL
K59A	18	GY	4086472C1
K59B	18	GY	4086472C1
K59C	18	GY	4086472C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	PLUG	-	-	2025431C1	-
B	PLUG	-	-	2025431C1	-
C#	A79K	16	GY	3594831C1	1661872C1
C*	A44BB	18	GY	3594831C1	3568570C1
D*	A9B	18	GY	3594831C1	1661872C1
D#	A79P-G	16	WH	3594831C1	1661872C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; * W/BENDIX/WABCO AIR ABS 6/8 ; # W/BENDIX AIR ABS 8

CIRCUIT	GA	COLOR	TERMINAL
PLUG	-	-	2025431C1
PLUG	-	-	2025431C1
A9B	18	GY	1661875C1
A44BB	18	GY	1661875C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A44AA	18	GY	3555249C1
2	A90C-G	18	WH	3555249C1

20.39. CONNECTOR COMPOSITES %(1109), %(1109A), @(1135), P. 25 | Figure 919 CONNECTOR COMPOSITES %(1109), %(1109A), @(1135) | printed page 919

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	A79	18	GY	0587576C1	3517771C1
B	A9BB	18	GY	0587576C1	3517771C1
C	PLUG	-	-	0587579C1	-

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	A79C	16	RD	0587575C1	1652325C1
B	A79D	16	GY	0587575C1	1652325C1
C	A79E	16	GY	0587575C1	1652325C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2#	A76AB	14	LTGN	239805R1
2%	A76AB	14	LTGN	1661226C1
3#	A76AD	14	LTGN	239805R1
3%	A76AD	14	LTGN	1661226C1
4-5	-	-	-	-
6#	A76AE	14	LTGN	239805R1
6%	A76AE	14	LTGN	1661226C1
7#	A62E-G	18	WH	1661224C1
7%	A62E-G	18	WH	1661224C1
8#	A62E	18	DKBL	1661224C1
8%	A62E	18	DKBL	1661224C1
9	-	-	-	-
10	-	-	-	-

Legend: # W/0508108 - MTA FUSE BLOCK ; % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 21FEB20 AE08090671 025

20.40. CONNECTOR COMPOSITES @(1135A), @(1136), @(1136A), P. 26 | Figure 920 CONNECTOR COMPOSITES @(1135A), @(1136), @(1136A) | printed page 920

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2#	A76AB	14	LTGN	239805R1
2%	A76AB	14	LTGN	1661226C1
3#	A76AD	14	LTGN	239805R1
3%	A76AD	14	LTGN	1661226C1
4-5	-	-	-	-
6#	A76AE	14	LTGN	239805R1
6%	A76AE	14	LTGN	1661226C1
7#	A62E-G	18	WH	1661224C1
7%	A62E-G	18	WH	1661224C1
8#	A62D	18	DKBL	1661224C1
8%	A62D	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: # W/0508108 - MTA FUSE BLOCK ; % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Table: N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2#	A76AA	14	LTGN	239805R1
2%	A76AB	14	LTGN	1661226C1
3#	A76AF	14	LTGN	239805R1
3%	A76AD	14	LTGN	1661226C1
4-15	-	-	-	-
6#	A76AH	14	LTGN	239805R1
6%	A76AE	14	LTGN	1661226C1
7#	A62G-G	18	WH	1661224C1
7%	A62E-G	18	WH	1661224C1
8#	A62F	18	DKBL	1661224C1
8%	A62D	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: # W/0508108 - MTA FUSE BLOCK ; % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2#	A76AA	14	LTGN	239805R1
2%	A76AA	14	LTGN	1661226C1
3#	A76AF	14	LTGN	239805R1
3%	A76AF	14	LTGN	1661226C1
4-5	-	-	-	-
6#	A76AH	14	LTGN	239805R1
6%	A76AH	14	LTGN	1661226C1
7#	A62E-G	18	WH	1661224C1
7%	A62E-G	18	WH	1661224C1
8#	A62E	18	DKBL	1661224C1
8%	A62F	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: # W/0508108 - MTA FUSE BLOCK ; % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 21FEB20 AE08090671 026

20.41. CONNECTOR COMPOSITES %(1137), P. 26A
Figure 921 CONNECTOR COMPOSITES %(1137)

20.41. CONNECTOR COMPOSITES %(1137), P. 26A | Figure 921 CONNECTOR COMPOSITES %(1137) | printed page 921

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	A89A	18	OR	1661224C1
3-4	-	-	-	-
5	A123H	18	GY	3541250C1
5	A123K	18	GY	3541250C1
5	A89KK	18	OR	1661224C1
6	A9WD	18	GY	1661224C1
7	A62R-G	18	WH	1661224C1
8	A62R	18	DKBL	1661224C1
9-10	-	-	-	-

20.42. CONNECTOR COMPOSITES %(1138), %(1139), P. 27 | Figure 922 CONNECTOR COMPOSITES %(1138), %(1139) | printed page 922

CAV	CIRCUIT	GA	COLOR	TERMINAL
1-4	-	-	-	-
5	A9X	18	GY	1661224C1
6	A89H	18	OR	1661224C1
7	A62S-G	18	WH	1661224C1
8	A62S	18	DKBL	1661224C1
9-10	-	-	-	-

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2%	A89F	18	PK	1661224C1
3-4	-	-	-	-
5%	A9Y	18	GY	1661224C1
6#	A89HB	18	OR	1661224C1
6*	A89H	18	OR	1661224C1
7%	A62-GT	18	WH	1661224C1
8%	A62T	18	DKBL	1661224C1
9-10	-	-	-	-

20.43. CONNECTOR COMPOSITES %(1140), %(1145), %(1145), ##(1146), P. 28 | Figure 923 CONNECTOR COMPOSITES %(1140), %(1145), %(1145), ##(1146) | printed page 923

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	A119M	18	GY	1661224C1
3#	A119A	18	GY	1661224C1
3*	A119AR	18	GY	1661224C1
4-6	-	-	-	-
7	A62-GP	18	WH	1661224C1
8	A62P	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: # N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG ; * W/0508108 - MTA FUSE BLOCK ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A120F	18	LTGN	1661539C1
2*	A120H	18	LTGN	1661539C1
2#	A120FE	18	LTGN	1661539C1

Legend: * W/DUMP VALVE ; # W/DUMP SWITCH ; % N/0508108 - NOT MTA FUSE BLOCK ; W/F-2017-ISB-ENG &

CAV	CIRCUIT	GA	COLOR	TERMINAL
1#	A120FB	18	LTGN	1661539C1
1&	A120FF	18	LTGN	1661539C1
2#	A120H	18	LTGN	1661539C1
2&	A120FE	18	LTGN	1661539C1

Legend: % W/0508108 - MTA FUSE BLOCK ; # W/INTERIOR DOOR DUMP VALVE SWITCH ; & W/EXTERIOR AND INTERIOR DOOR DUMP VALVE

CAV	CIRCUIT	GA	COLOR	TERMINAL
1#	A133B	16	LTBL	1680205C1
1*	A133B	18	LTGN	1680205C1
1!	A133B	16	LT GN	1680205C1
2%	A120JB	16	LTGN	1680205C1
2@	A133A	18	LTGN	1680205C1
2^	A133A	16	LTGN	1680205C1
3	A133-G	18	WH	1680205C1
4-5	-	-	-	0453133C1
6@	A133C	18	LTGN	1680205C1
6^	A133C	16	LTGN	1680205C1

Legend: # W/ELEC DOOR ; * W/AIR DOOR ; % W/KEY OFF ENTRY DOOR SW ; @ W/VANDAL LOCK FOR MANUAL DOOR ; ^ W/EXTERIOR DOOR SW FEED ; ## W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOC

Figure 924 CONNECTOR COMPOSITES %(1146A), %(1146B), %(1147)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.44. CONNECTOR COMPOSITES %(1146A), %(1146B), %(1147), P. 29 / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090671 NO. 95504E 04JUN20 / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / VANDAL LOCK STARTER INTERRUPT %(1146B) (LOCATED AT DASH PANEL) / CONNECTOR 0239808R1 / CONNECTOR 0239808R1 / VANDAL LOCK STARTER INTERRUPT %(1146A) (LOCATED AT DASH PANEL) / * W/VANDAL LOCK FOR RIGHT ELECTRIC DOOR % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / CONNECTOR 1669030C1 / 1 2 / MANUAL DOOR VANDAL SOLENOID %(1147) (LOCATED AT DASH PANEL) / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A% A133 16 LTGN 0239805R1 / CAV CIRCUIT GA COLOR TERMINAL A% A133-GA 16 WH 0239805R1 / CAV CIRCUIT GA COLOR TERMINAL 1* A133B 18 LTGN 1661536C1 1* A133C 18 LTGN 1661536C1 2 A133B-G 18 WH 1661538C1 / Figure 924 / CONNECTOR COMPOSITES %(1146A), %(1146B), %(1147)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A%	A133	16	LTGN	0239805R1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A%	A133-GA	16	WH	0239805R1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	A133B	18	LTGN	1661536C1
1*	A133C	18	LTGN	1661536C1
2	A133B-G	18	WH	1661538C1

Legend: * W/VANDAL LOCK FOR RIGHT ELECTRIC DOOR ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

20.45. CONNECTOR COMPOSITES %(1232), *(1233), P. 30 | Figure 925 CONNECTOR COMPOSITES %(1232), *(1233) | printed page 925

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K92#101	18	LTBL	3509874C1	3532128C1
2	K92#103	18	YL	3509874C1	3532128C1
3	K92#105	18	OR	3509874C1	3532128C1
4	K92#109	18	GY	3509874C1	3532128C1
5	K92#110	18	PK	3509874C1	3532128C1
6	K92#117	18	LTBL	3509874C1	3532128C1
7	K92#122	18	YL	3509874C1	3532128C1
8	K92#123	18	LTGN	3509874C1	3532128C1
9	PLUG	-	-	3532129C1	-
10	K92#130	18	WH	3509874C1	3532128C1
11	K92#134	18	YL	3509874C1	3532128C1
12	K92#141	18	GY	3509874C1	3532128C1
13	K92#143	18	LTBL	3509874C1	3532128C1
14	K92#145	18	OR	3509874C1	3532128C1
15-16	PLUG	-	-	3532129C1	-
17	K92#113	18	WH	3509874C1	3532128C1
18	K92#163	18	YL	3509874C1	3532128C1
19	K92#164	18	LTBL	3509874C1	3532128C1
20	K71#165	18	TN	3509874C1	3532128C1
21	K92#169	18	GY	3509874C1	3532128C1
22	K92#170	18	PK	3509874C1	3532128C1
23	K92#111	18	OR	3509874C1	3532128C1
24	K92#112	18	PK	3509874C1	3532128C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE ; BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K92#158	18	LTGN	3613771C1
2	K92#171	18	YL	3613771C1
3	K92#151	18	WH	3613771C1
4	K92#152	18	LTGN	3613771C1
5	K31#154	18	TN	3613771C1
6	K5(+)	18	YL	3613771C1
7	K5(-)	18	GN	3613771C1
8	K92#102	18	YL	3613771C1
9	K92#104	18	YL	3613771C1
10-14	PLUG	-	-	3573076C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE

20.46. CONNECTOR COMPOSITES *(1234), P. 30A
Figure 926 CONNECTOR COMPOSITES *(1234)

20.46. CONNECTOR COMPOSITES *(1234), P. 30A | Figure 926 CONNECTOR COMPOSITES *(1234) | printed page 926

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K48#139	18	OR	4086474C1	3532128C1
2	K47#140	18	LTGN	4086474C1	3532128C1
3	K92#120	18	LTBL	4086474C1	3532128C1
4	K5#127	18	GN	4086474C1	3532128C1
5	K92#155	18	WH	4086474C1	3532128C1
6	K92#174	18	LTBL	4086474C1	3532128C1
7	K92#176	18	YL	4086474C1	3532128C1
8	PLUG	-	-	3532129C1	-
9	K92#142	18	WH	4086474C1	3532128C1
10-12	PLUG	-	-	3532129C1	-
13	K48#159	18	TN	4086474C1	3532128C1
14	K47#160	18	YL	4086474C1	3532128C1
15	K92#180	18	OR	4086474C1	3532128C1
16	K5#106	18	YL	4086474C1	3532128C1
17	K92#129	18	LTGN	4086474C1	3532128C1
18	K92#118	18	BK	4086474C1	3532128C1
19	K92#116	18	LTBL	4086474C1	3532128C1
20	K92#177	18	LTGN	4086474C1	3532128C1
21	K92#131	18	YL	4086474C1	3532128C1
22	K92#133	18	YL	4086474C1	3532128C1
23	K92#136	18	OR	4086474C1	3532128C1
24	K92#137	18	WH	4086474C1	3532128C1

20.47. CONNECTOR COMPOSITES %(1300), %(1301), %(1301), P. 31 | Figure 927 CONNECTOR COMPOSITES %(1300), %(1301), %(1301) | printed page 927

CAV	CIRCUIT	GA	COLOR	TERMINAL
1P	A86RR+	18	LTGN	1661538C1
2P	-	-	-	-
3P	A86RR-	18	LTGN	1661538C1
4P	A86RF+	18	LTGN	1661538C1
5P	-	-	-	-
6P	A86RF-	18	LTGN	1661538C1
7P	A86LR+	18	LTGN	1661538C1
8P	A86A	18	LTGN	1661538C1
9P	A86LR-	18	LTGN	1661538C1
10P	A86LF+	18	LTGN	1661538C1
11P	A86B	16	LTGN	1661538C1
12P	A86LF-	18	LTGN	1661538C1
13P	A86C	18	LTGN	1661538C1
14P	A86D	18	LTGN	1661538C1
15P	A86-G	18	WH	1661538C1

Legend: % N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A86A	18	LTGN	1661538C1
2	A86B	16	LTGN	1661538C1
3	A86R(-)	18	LTGN	1661538C1
4	A86R(+)	18	LTGN	1661538C1
5	A86L(-)	18	LTGN	1661538C1
6	A86L(+)	18	LTGN	1661538C1
7	A86C	18	LTGN	1661538C1
8	A86D	18	LTGN	1661538C1
9	A86-G	18	WH	1661538C1

Legend: % W/0508108 - MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A86A	18	LTGN	1661538C1
2	A86B	16	LTGN	1661538C1
3	A86R(-)	18	LTGN	1661538C1
4	A86R(+)	18	LTGN	1661538C1
5	A86L(-)	18	LTGN	1661538C1
6	A86L(+)	18	LTGN	1661538C1
7	A86C	18	LTGN	1661538C1
8	A86D	18	LTGN	1661538C1
9	A86-G	18	WH	1661538C1

Legend: % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG

20.48. CONNECTOR COMPOSITES %(1302), %(1349), %(1350), P. 32 | Figure 928 CONNECTOR COMPOSITES %(1302), %(1349), %(1350) | printed page 928

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A67A	18	GY	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A14TS	20	RD	3598294C1
2	A13TS	20	PK	3598294C1
3	A11-GTS	20	WH	3598294C1
4	-	-	-	-

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A14TS	20	RD	3598294C1
2	A13TS	20	PK	3598294C1
3	A11-GTS	20	WH	3598294C1

Legend: % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A5J(+)	20	YL	3598294C1
2-5	-	-	-	-
6	A5J(-)	20	GN	3598294C1
7-10	-	-	-	-

20.49. CONNECTOR COMPOSITES %(1350), %(1351), P. 32A
Figure 929 CONNECTOR COMPOSITES %(1350), %(1351)

20.49. CONNECTOR COMPOSITES %(1350), %(1351), P. 32A | Figure 929 CONNECTOR COMPOSITES %(1350), %(1351) | printed page 929

CAV	CIRCUIT	GA	COLOR	TERMINAL
1%	A5J(+)	20	YL	3598294C1
1#	A5TS(+)	20	YL	3598294C1
2-5	-	-	-	-
6%	A5J(-)	20	GN	3598294C1
6#	A5TS(-)	20	GN	3598294C1
7-10	-	-	-	-

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A20EH	20	LTGN	3598294C1
2-6	-	-	-	-
7	A89HJ	20	VT	3598294C1
8-12	-	-	-	-

20.50. CONNECTOR COMPOSITES %(1401), %(1402), %(1403), P. 32B
Figure 930 CONNECTOR COMPOSITES %(1401), %(1402), %(1403)

20.50. CONNECTOR COMPOSITES %(1401), %(1402), %(1403), P. 32B | Figure 930 CONNECTOR COMPOSITES %(1401), %(1402), %(1403) | printed page 930

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A59N	18	GY	1661875C1
B	A59P	18	GY	1661875C1
C	A59R	18	GY	1661875C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A59S	18	GY	1661875C1
B	A59T	18	GY	1661875C1
C	A59U	18	GY	1661875C1

Legend: % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A59V	18	GY	1661875C1
B	A59W	18	GY	1661875C1
C	A59X	18	GY	1661875C1

Legend: % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A59Y	18	GY	1661875C1
B	A59Z	18	GY	1661875C1
C	A59AA	18	GY	1661875C1

Legend: % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG

20.51. CONNECTOR COMPOSITES %(1404), #(1500), #(1501), P. 33 | Figure 931 CONNECTOR COMPOSITES %(1404), #(1500), #(1501) | printed page 931

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	A59B	18	GY	1661875C1	1661872C1
B	A59-G	18	WH	1661875C1	1661872C1
C	PLUG	-	-	2025431C1	-
D	PLUG	-	-	2025431C1	-
E	PLUG	-	-	2025431C1	-
F	PLUG	-	-	2025431C1	-
G	PLUG	-	-	2025431C1	-
H	A59C	18	GY	1661875C1	1661872C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A28-G	18	WH	2018639C1
2	A28	18	TN	2018639C1
3	-	-	-	-
4	A62	16	DKBL	2018639C1
5-6	-	-	-	-
7	A28A	18	TN	2018639C1
8@	A110	18	GY	2018639C1
8%	A110AD	18	GY	2018639C1
9-14	-	-	-	-

Legend: @ W/AMBIENT TEMP RESISTOR ; % W/AMBIENT TEMP SENSORS ; # W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	A62G	18	DKBL	0587576C1	1652325C1
B	A62-GC	18	WH	0587576C1	1652325C1

20.52. CONNECTOR COMPOSITES #(1505), P. 33A
Figure 932 CONNECTOR COMPOSITES #(1505)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.52. CONNECTOR COMPOSITES #(1505), P. 33A / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090671 NO. RELEASE NO. 96183U 08JUL21 / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / INSTRUMENT CLUSTER #(1505) (LOCATED AT INSTRUMENT CLUSTER) / CONNECTOR 2018590C1 / 12 11 10 9 8 7 6 / 5 4 / 3 2 1 / # W/0508108 - MTA FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL 1-8 - - - - 9 A41 18 TN 2018639C1 10 A50 18 YL 2018639C1 11 A5BT(-) 18 GN 2018639C1 12 A5BS(+) 18 YL 2018639C1 / Figure 932 / CONNECTOR COMPOSITES #(1505)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1-8	-	-	-	-
9	A41	18	TN	2018639C1
10	A50	18	YL	2018639C1
11	A5BT(-)	18	GN	2018639C1
12	A5BS(+)	18	YL	2018639C1

Figure 933 CONNECTOR COMPOSITES %(1531), %(1555), %(1556)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.53. CONNECTOR COMPOSITES %(1531), %(1555), %(1556), P. 34 / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090671 NO. RELEASE NO. 95504E 06MAR20 / MJV0488 13SEP21 REMOVED R/D 1505 AND FUSE DETAILS. / WARNING LIGHTS %(1555) (LOCATED AT INSTRUMENT CLUSTER) / CONNECTOR 2005835C1 BODY LOCK 2006503C1 / A B C D / H G F E / EMERGENCY EXIT INDICATOR %(1556) (LOCATED INSIDE CENTER DASH PANEL) / CONNECTOR 2206669C1 / SKIRT LIGHT %(1531) (LOCATED IN SEALED ENGINE HARNESS) / 1 2 / CONNECTOR 2206588C1 / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 Y131C 16 DKBL 3522190C1 3522193C1 2 Y131-GC 16 WH 3522190C1 3522193C1 / CAV CIRCUIT GA COLOR TERMINAL 1A A117A 18 GY 1661224C1 1B A117B 18 GY 1661224C1 2A - - - - 2B - - - - / CAV CIRCUIT GA COLOR TERMINAL A-C - - - - D A94-GE 18 WH 1661208C1 E A94Z 18 GY 1661208C1 F-H - - - - / Figure 933 / CONNECTOR COMPOSITES %(1531), %(1555), %(1556)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y131C	16	DKBL	3522190C1	3522193C1
2	Y131-GC	16	WH	3522190C1	3522193C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1A	A117A	18	GY	1661224C1
1B	A117B	18	GY	1661224C1
2A	-	-	-	-
2B	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

20.54. CONNECTOR COMPOSITES *@(1600), P. 35 | Figure 934 CONNECTOR COMPOSITES *@(1600) | printed page 934

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1*	A12D	18	GY	3539904C1
A1#	A149D	18	GY	3539904C1
A2	A125L	18	GY	3539904C1
A3*#	A79	18	GY	3539904C1
A3*&	A79	16	GY	3539904C1
A4	A52C	20	YL	3539905C1
A5%	A85B	18	GY	3539904C1
A5&	A85B	20	GY	3539905C1
A6^	A57	20	OR	3539905C1
A6@	A57B	18	OR	3539904C1
A7^	A56	20	OR	3539905C1
A7@	A56B	18	OR	3539904C1
A8**	A117	18	GY	3539904C1
A8!	A89AA	18	OR	3539904C1
A9	A82S	20	GY	3539905C1
A10	A82T	20	GY	3539905C1
A11	A82U	20	GY	3539905C1
A12##	A44CC	18	GY	3539904C1
A12&&	A44BB	18	GY	3539904C1
A12%%	A44BB	16	GY	3539904C1
A13**	A89AA	18	OR	3539904C1
A13!	A117	18	GY	3539904C1
A14	A102	20	YL	3539905C1
A15	A87-GB	18	GY	3539904C1
A16*	A13AD	18	GY	3539904C1
A16#	A149AD	18	GY	3539904C1
B1	A90B	16	GY	3539904C1
B2	A40	18	GY	3539904C1
B3	A40A	18	GY	3539904C1
B4-B5	-	-	-	-
B6	A90C	18	GY	3539904C1
B7	A77R	18	LTGN	3539904C1
B8	A36	18	TN	3539904C1
B9	-	-	-	-
B10	A90P	18	GY	3539904C1
B11	-	-	-	-
B12	-	-	-	-
B12*^	A119AR	18	GY	3539904C1
B12*%	A119AS	18	GY	3539904C1
B13	-	-	-	-
B14	-	-	-	-
B15	A95A	18	GY	3539904C1
B16%	A89C	18	GY	3539904C1
B16&	A89C	20	VT	3539905C1

Legend: * W/MUX FOR BC PROG ONLY ; # W/ENHANCED VCM FUNCTION ; & W/LIGHTED STEERING WHEEL SW ; % N/LIGHTED STEERING WHEEL SW ; ^ N/ADDITIONAL HAZARD SW ; @ W/ADDITIONAL HAZARD SW ; ! W/HOT ALL THE TIME RED OVERRIDE ; ** N/HOT ALL THE TIME RED OVERRIDE ; ## W/HYDRAULIC PARK BRAKE

20.55. CONNECTOR COMPOSITES ^(1600), P. 36 | Figure 935 CONNECTOR COMPOSITES ^(1600) | printed page 935

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1@	A12D	18	LTBL	3522073C1
A1#	A149D	18	GY	3522073C1
A1!	A12D	18	LTBL	3522073C1
A1%	A12D	18	GY	3522073C1
A2^	A125L	18	GY	3522073C1
A3^	A79	18	GY	3522073C1
A3^	A79	16	GY	3522073C1
A4^	A52C	20	YL	3534303C1
A5!!	A85B	18	GY	3522073C1
A5!#	A85B	20	GY	3534303C1
A6*	A57	20	OR	3534303C1
A6+	A57B	18	OR	3522073C1
A7*	A56	20	OR	3534303C1
A7+	A56B	18	OR	3522073C1
A8!%	A117	18	GY	3522073C1
A8!&	A89AA	18	OR	3522073C1
A9^	A82S	20	GY	3534303C1
A10^	A82T	20	GY	3534303C1
A11^	A82U	20	GY	3534303C1
A12**	A44CC	18	GY	3522073C1
A12*#	A44BB	18	GY	3522073C1
A12*!	A44BB	16	GY	3522073C1
A13!%	A89AA	18	OR	3522073C1
A13!&	A117	18	GY	3522073C1
A14^	A102	20	YL	3534303C1
A15^	A87-GB	18	GY	3522073C1
A16@	A13AD	16	PK	3522073C1
A16#	A149AD	18	GY	3522073C1
A16!	A13AD	16	PK	3522073C1
A16%	A13AD	18	GY	3522073C1
B1^	A90B	16	GY	3522073C1
B2^	A40	18	GY	3522073C1
B3^	A40A	18	GY	3522073C1
B4-B5	-	-	-	-
B6^	A90C	18	GY	3522073C1
B7^	A77R	18	LTGN	3522073C1
B8*%	A36	18	TN	3522073C1
B9	-	-	-	-
B10^	A90P	18	GY	3522073C1
B11	-	-	-	-
B12^	A119A	18	GY	3522073C1
B13-B14	-	-	-	-
B15*%	A95A	18	GY	3522073C1
B16!!	A89C	18	GY	3522073C1
B16!#	A89C	20	PL	3534303C1
BC PROG	ONLY	W/F-2017-ISB-ENG		
VCM	FUNCTIONS		W/F-2017-ISB-ENG	
BC PROG	ONLY			
VCM	FUNCTIONS			

Legend: NOT MTA FUSE BLOCK W/F-2017-ISB-ENG & ; WHEEL SWITCH ; WHEEL SWITCH ; HAZARD SWITCH ; HAZARD SWITCH ; TIME RED OVERRIDE ; TIME RED OVERRIDE ; PARK BRAKE ; BRAKE ALRAM

CAV	CIRCUIT	GA	COLOR	TERMINAL
E1*	A122AR	18	GY	3522073C1
E1#	A97RB	18	TN	3522073C1
E1@	A122J	18	GY	3522073C1
E2^	A89HH	18	PL	3522073C1
E2!	A89HK	18	PL	3522073C1
E3%	A64C	18	YL	3522073C1
E4%	A71C	18	OR	3522073C1
E5**	A39C	16	GY	3522073C1
E5##	A70A	18	OR	3522073C1
E6+	A82D	18	GY	3522073C1
E6&	A82B	18	GY	3522073C1
E7+	A82C	18	GY	3522073C1
E7&	A82A	18	GY	3522073C1
E8++	A92AB	18	TN	3522073C1
E8^^	A97RB	18	TN	3522073C1
E9!!	A120AS	18	LTGN	3522073C1
E9%%	A120AP	18	LTGN	3522073C1
E10-E11	-	-	-	-
E12%	A59L	18	GY	3522073C1
E13&	A120	18	LTGN	3522073C1
E13*&	A120AT	18	LTGN	3522073C1
E13*^	A120EE	18	LTGN	3522073C1
E13*%	A120EF	18	LTGN	3522073C1
E14%	A94Z	18	GY	3522073C1
E15%	A137A	18	LTBL	3522073C1
E16%	A59J	18	GY	3522073C1
F1	-	-	-	-
F2&	A92A	18	GY	3522073C1
F3*#	A44J	18	GY	3522073C1
F3*@	A59A	18	GY	3522073C1
F4-F6	-	-	-	-
F7%	A12A	18	GY	3522073C1
F7*!	A122H	18	GY	3522073C1
F8%	A59M	18	GY	3522073C1
F9&	A95B	18	GY	3522073C1
F10	-	-	-	-
F11%	A92T	18	TN	3522073C1
F12	-	-	-	-
F13&	A77S	18	LTGN	3522073C1
F14&	A77T	18	LTGN	3522073C1
F15	-	-	-	-
F16%	A90D	18	GY	3522073C1

20.57. CONNECTOR COMPOSITES !!(1601), P. 37 | Figure 937 CONNECTOR COMPOSITES !!(1601) | printed page 937

CAV	CIRCUIT	GA	COLOR	TERMINAL
E1*	A97RB	18	TN	3539904C1
E1#	A122J	18	GY	3539904C1
E2@	A89HH	18	VT	3539904C1
E2%	A89HK	18	VT	3539904C1
E3	A64C	18	YL	3539904C1
E4	A71C	18	OR	3539904C1
E5	A39C	16	GY	3539904C1
E6!	A82D	18	GY	3539904C1
E6^	A82B	18	GY	3539904C1
E7!	A82C	18	GY	3539904C1
E7^	A82A	18	GY	3539904C1
E8&	A92AB	18	TN	3539904C1
E8**	A97RB	18	TN	3539904C1
E9*#	A120AS	18	LTGN	3539904C1
E9*^	A120AP	18	LTGN	3539904C1
E10-E11	-	-	-	-
E12	A59L	18	GY	3539904C1
E13*#	A120AT	18	LTGN	3539904C1
E13*^	A120EE	18	LTGN	3539904C1
E13%	A120EF	18	LTGN	3539904C1
E14	A94Z	18	GY	3539904C1
E15	-	-	-	-
E16	A59J	18	GY	3539904C1
F1	-	-	-	-
F2	-	-	-	-
F3*&	A44J	18	GY	3539904C1
F3*%	A59A	18	GY	3539904C1
F4-F6	-	-	-	-
F7##	A12AY	18	GY	3539904C1
F7*%	A122H	18	GY	3539904C1
F8	A59M	18	GY	3539904C1
F9	A95B	18	GY	3539904C1
F10	A59K	18	GY	3539904C1
F11	A92T	18	TN	3539904C1
F12	-	-	-	-
F13-F15	-	-	-	-
F16	A90D	18	GY	3539904C1

20.58. CONNECTOR COMPOSITES !!(1602), P. 38 | Figure 938 CONNECTOR COMPOSITES !!(1602) | printed page 938

CAV	CIRCUIT	GA	COLOR	TERMINAL
E1	A3F(-)	18	GY	3539904C1
E2	A3E(+)	18	DKBL	3539904C1
E3&	A171MA	18	TN	3539904C1
E3*	A9AAP	18	GY	3539904C1
E4	-	-	-	-
E5	A9H	18	GY	3539904C1
E6^	A6H	18	GY	3539904C1
E6%	A6H	16	GY	3539904C1
E7	A9HT	16	GY	3539904C1
E8-E10	-	-	-	-
E11	A50	18	YL	3539904C1
E12	A119E	18	GY	3539904C1
E13	-	-	-	-
E14#	A90F	18	GY	3539904C1
E14@	A70CA	18	OR	3539904C1
E14%	A70CA	16	GY	3539904C1
E14#	A70F	18	RD	3539904C1
E15@	A70CB	18	OR	3539904C1
E15%	A70CB	16	GY	3539904C1
E16	A11-GAH	16	WH	3539904C1
F1	-	-	-	-
F2	A5BN(-)	18	GN	3539904C1
F3	A5BM(+)	18	YL	3539904C1
F4	-	-	-	-
F5	A5M(-)	18	GN	3539904C1
F6	A5M(+)	18	YL	3539904C1
F7	-	-	-	-
F8!	A123B	18	GY	3539904C1
F8**	A123J	18	GY	3539904C1
F8*&	A120E	16	LTGN	3539904C1
F9*&	A120FG	18	LTGN	3539904C1
F9*%	A120FA	18	LTGN	3539904C1
F10	-	-	-	-
F11	A89H	18	OR	3539904C1
F12	-	-	-	-
F13	A89CC	18	VT	3539904C1
F14*^	A44N	18	GY	3539904C1
F14&	A171LA	18	TN	3539904C1
F15*#	A120SK	16	LTGN	3539904C1
F15*@	A120SK	18	LTGN	3539904C1
F16%%	A123K	18	GY	3539904C1
F16%%	A89KK	18	OR	3539904C1

20.59. CONNECTOR COMPOSITES %(1602), P. 38A
Figure 939 CONNECTOR COMPOSITES %(1602)

20.59. CONNECTOR COMPOSITES %(1602), P. 38A | Figure 939 CONNECTOR COMPOSITES %(1602) | printed page 939

CAV	CIRCUIT	GA	COLOR	TERMINAL
E1%	AA3F(-)	18	GY	3522073C1
E2%	AA3E(+)	18	DKBL	3522073C1
E3*	AA9A	18	GY	3522073C1
E3&	HC9H	16	GY	3522073C1
E4	-	-	-	-
E5%	DR9H	18	GY	3522073C1
E6^	AN6H	18	GY	3522073C1
E6#	GN6H	16	GY	3522073C1
E7*	JY9H	16	GY	3522073C1
E7&	PR171MA	18	TN	3522073C1
E8	-	-	-	-
E9	-	-	-	-
E10	-	-	-	-
E11%	AA50	18	YL	3522073C1
E12%	AG119E	18	GY	3522073C1
E13	-	-	-	-
E14!	AP90F	18	GY	3522073C1
E14@	CH70CA	18	OR	3522073C1
E14#	GN70CA	16	GY	3522073C1
E14!!	JY70F	18	RD	3522073C1
E15@	CH70CB	18	OR	3522073C1
E15#	GN70CB	16	GY	3522073C1
E16%	CP11-GAH	16	WH	3522073C1
F1	-	-	-	-
F2*	BY5BN(-)	18	GN	3522073C1
F2*	CX5BK(-)	18	GN	3522073C1
F2&	CX5BJ(-)	18	GN	3522073C1
F3*	BY5BM(+)	18	YL	3522073C1
F3*	CX5BJ(+)	18	YL	3522073C1
F3&	CX5BJ(+)	18	YL	3522073C1
F4	-	-	-	-
F5%	RB5M(-)	18	GN	3522073C1
F6%	RB5M(+)	18	YL	3522073C1
F7	-	-	-	-
F8**	EY123B	18	GY	3522073C1
F8##	FB123J	18	GY	3522073C1
F8%%	FD120E	16	LTGN	3522073C1
F9%	FD120F	18	LTGN	3522073C1
F10	-	-	-	-
F11%	FE89H	18	OR	3522073C1
F12	-	-	-	-
F13%	BD89CC	18	PL	3522073C1
F14%	BP44N	18	GY	3522073C1
F14&	PR171LA	18	TN	3522073C1
F15!#	EZ120SK	16	LTGN	3522073C1
F15*#	HG120SK	18	LTGN	3522073C1
F16*%	BJ123K	18	GY	3522073C1
F16%	FG89KK	18	OR	3522073C1

20.60. CONNECTOR COMPOSITES %(1603), P. 38B | Figure 940 CONNECTOR COMPOSITES %(1603) | printed page 940

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	A57D	14	OR	3544877C1
A*	A57A	14	OR	3544877C1
B#	A56D	14	OR	3544877C1
B*	A56A	14	OR	3544877C1
C%	A89YY	14	OR	3544877C1
D%	A56C	14	YL	3544877C1
E%	A85	16	GY	3544876C1
E%	A125A	16	GY	3544876C1
F^	A89RH	14	OR	3544877C1
F&	A89RF	14	OR	3544877C1
G%	A89SS	14	OR	3544877C1
H%	A89LF	14	OR	3544877C1
J%	A89LB	14	OR	3544877C1
K%	A89JJ	14	OR	3544877C1
L%	A89RB	14	OR	3544877C1
M%	A57C	14	LTGN	3544877C1

20.61. CONNECTOR COMPOSITES !!(1603), P. 39 | Figure 941 CONNECTOR COMPOSITES !!(1603) | printed page 941

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	A57D	14	OR	3544877C1
A&	A57AA	14	OR	3544877C1
B*	A56D	14	OR	3544877C1
B&	A56AA	14	OR	3544877C1
C	A89YY	14	OR	3544877C1
D	A56C	14	YL	3544877C1
E^	A85	16	GY	3544876C1
E%	A125A	16	GY	3544876C1
F#	A89RH	14	OR	3544877C1
F@	A89RF	14	OR	3544877C1
G	A89SS	14	OR	3544877C1
H	A89LF	14	OR	3544877C1
J	A89LB	14	OR	3544877C1
K	A89JJ	14	OR	3544877C1
L	A89RB	14	OR	3544877C1
M	A57C	14	LTGN	3544877C1

Legend: * W/COWL MOUNTED DIRECTIONAL LIGHTS ; & N/COWL MOUNTED DIRECTIONAL LIGHTS ; ^ W/POST TRIP INSPECTION ; % W/BUS SCAN/CHILD CHECKMATE ; # W/RIGHT PUPIL WARNING LIGHT INDICATORS ; @ N/RIGHT PUPIL WARNING LIGHT INDICATORS ; !! W/0508108 - MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A82	16	GY	3544876C1
B*	A53C	14	YL	3544877C1
B&	A53B	14	YL	3544877C1
B^	A125D	14	YL	3544877C1
C	A52B	14	YL	3544877C1
D%	A70BC	16	OR	3544876C1
D#	A70LB	16	OR	3544876C1
E	A11-GAB	12	WH	3544877C1
F	A58C	14	BN	3544877C1
F!!	A58C	14	LT GN	3544877C1
G	A58	14	BN	3544877C1
H*	A53A	16	YL	3544876C1
H&	A53A	14	YL	3544877C1
H^	A125C	14	YL	3544877C1
J@	A89ZY	14	OR	3544877C1
J!	A89ZZ	14	OR	3544877C1
K	A52A	14	YL	3544877C1

Legend: * W/POST TRIP INSPECTION ; & N/POST TRIP INSPECTION ; ^ W/BUS SCAN/CHILD CHECKMATE ; % N/BRAKE MONITORING N/LIQUID SPRING ; # N/BRAKE MONITORING W/LIQUID SPRING ; @ W/RIGHT PUPIL WARNING LIGHT INDICATORS ; ! N/RIGHT PUPIL WARNING LIGHT INDICATORS ; ## W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT FUSE BLOCK

20.62. CONNECTOR COMPOSITES %(1606), P. 40
Figure 942 CONNECTOR COMPOSITES %(1606)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.62. CONNECTOR COMPOSITES %(1606), P. 40 / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090671 NO. RELEASE NO. 95504E 06MAR20 / MJV0488 13SEP21 ADDED R/D 1606 & REMOVED R/D 1651. / J6-18WAY BODY CONTROLLER %(1606) (LOCATED INSIDE RIGHT SIDE DASH PANEL) / CONNECTOR 3759005C1 / * W/2017/2021 ISB/B6.7 DIESEL ENG & W/F-2018-PROP/GAS-ENG % W/0508108 - MTA FUSE BLOCK / J6-18WAY BODY CONTROLLER %(1606) (LOCATED INSIDE RIGHT SIDE DASH PANEL) / CONNECTOR 3759005C1 / % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG & W/F-2018-PROPANE/GASOLINE-ENG * W/F-2017-ISB-ENG # W/F-2018-PROP/GAS-ENG / Figure 942 / CONNECTOR COMPOSITES %(1606)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	A148	16	GY	3544876C1
A&	A12	16	GY	3544876C1
B*	A148AN	16	GY	3544884C1
B&	A13AN	16	GY	3544884C1

Legend: C-F - - - ; G A5H(-) 18 GN 3544884C1 ; H A5H(+) 18 YL 3544884C1 ; I - - - ; K ; K A101-G 16 WH 3544876C1 ; L - - - ; M* A92#141 18 GY 3544884C1 ; N-R - - -

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	A148	16	GY	3544876C1
A#	A12	16	GY	3544876C1
B*	A148AN	16	GY	3544884C1
B#	A13AN	16	GY	3544884C1

Legend: C-F - - - ; A ; G# A5AB(-) 18 GN 3544884C1 ; H% A5H(+) 18 YL 3544884C1 ; H# A5AB(+) 18 YL 3544884C1 ; K ; K% A101-G 16 WH 3544876C1 ; L - - - ; M% A92#141 18 GY 3544884C1

20.63. CONNECTOR COMPOSITES %(1606), P. 40A
Figure 943 CONNECTOR COMPOSITES %(1606)

20.63. CONNECTOR COMPOSITES %(1606), P. 40A | Figure 943 CONNECTOR COMPOSITES %(1606) | printed page 943

CAV	CIRCUIT	GA	COLOR	TERMINAL
A%	A98-G	16	WH	1680206C1
B%	A98	18	VT	1680206C1
C*	A5AE(+)	18	YL	1680206C1
C%	A5BD(+)	18	YL	1680206C1
D*	A5AF(-)	18	GN	1680206C1
D%	A5BD(-)	18	GN	1680206C1
E	-	-	-	-
F&	A3BA(+)	18	DKBL	1680206C1
F@	A3B(+)	18	DKBL	1680206C1
F%	A3(+)	18	DKBL	1680206C1
G&	A3BA(-)	18	GY	1680206C1
G@	A3B(-)	18	GY	1680206C1
G%	A3(-)	18	GY	1680206C1
H	-	-	-	-
J	-	-	-	-

Legend: % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	A98-G	16	WH	1680206C1
A#	A98-G	16	WH	1651968C1
B*	A98	18	VT	1680206C1
B#	A98	18	VT	1651968C1
C*	A5M(+)	18	YL	1680206C1
C#	A5M(+)	18	YL	1651968C1
C#	A5BD(+)	18	YL	1651968C1
D*	A5M(-)	18	GN	1680206C1
D#	A5M(-)	18	GN	1651968C1
D#	A5BD(-)	18	GN	1651968C1
E	-	-	-	-
F%	A3(+)	18	DKBL	1680206C1
G*	A3(-)	18	GY	1680206C1
G#	A3(-)	18	GY	1651968C1
H&	A5BC(+)	18	YL	1680206C1
H#	A5AD(+)	18	YL	1651968C1
J&	A5BD(-)	18	GN	1680206C1
J#	A5AD(-)	18	GN	1651968C1

Legend: N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG

20.64. CONNECTOR COMPOSITES %(1651), P. 40B
Figure 944 CONNECTOR COMPOSITES %(1651)

20.64. CONNECTOR COMPOSITES %(1651), P. 40B | Figure 944 CONNECTOR COMPOSITES %(1651) | printed page 944

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A98-G	16	WH	1680206C1
B	A98	18	VT	1680206C1
C	A5MA(+)	18	YL	3754236C1
D	A5MA(-)	18	GN	3754236C1
E	-	-	-	-
F	A3(+)	18	DKBL	3754236C1
G	A3(-)	18	GY	3754236C1
H	A5BC(+)	18	YL	3754236C1
J	A5BD(-)	18	GN	3754236C1

20.65. CONNECTOR COMPOSITES *(1657), %(1657E), P. 41 | Figure 945 CONNECTOR COMPOSITES *(1657), %(1657E) | printed page 945

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M5C(+)	18	YL	1661875C1	3568570C1
B	PLUG	-	-	2025431C1	-
C	M5C(-)	18	GN	1661875C1	3568570C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/2017/2021 ISB/B6.7 DIESEL ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A@	M5C(+)	18	YL	1661875C1	3568570C1
A%	M5(+)	18	YL	1661875C1	3568570C1
B	PLUG	-	-	2025431C1	-
C@	M5C(-)	18	GN	1661875C1	3568570C1
C%	M5(-)	18	GN	1661875C1	3568570C1

Legend: @ W/F-2018-PROP-ENG ONLY ; % W/ZONAR PREWIRE ; * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE ; BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M5(+)	18	YL	1661875C1	3568570C1
B	-	-	-	-	-
C	M5(-)	18	GN	1661875C1	3568570C1

20.66. CONNECTOR COMPOSITES %(1657M), %(1658), (1660), P. 41A
Figure 946 CONNECTOR COMPOSITES %(1657M), %(1658), (1660)

20.66. CONNECTOR COMPOSITES %(1657M), %(1658), (1660), P. 41A | Figure 946 CONNECTOR COMPOSITES %(1657M), %(1658), (1660) | printed page 946

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A&	A5BA(+)	18	YL	1661875C1	3568570C1
A*	A5AG(+)	18	YL	1661875C1	3568570C1
A#	A5AG(+)	18	YL	1661875C1	3568570C1
B	-	-	-	-	-
C&	A5BB(-)	18	GN	1661875C1	3568570C1
C*	A5AH(-)	18	GN	1661875C1	3568570C1
C#	A5AG(-)	18	GN	1661875C1	3568570C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * W/F-2017-ISB-ENG ; # W/F-2018-PROP/GAS-ENG ; & W/F-2017-ISB-ENG & F-2021-B6.7-DIESEL ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M5F(+)	18	YL	3683464C1	3535424C1
B	M5F(-)	18	GN	3683464C1	3535424C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A3C(+)	18	DKBL	1661208C1
B	A3AA(+)	18	DKBL	1661208C1
C	A3BA(+)	18	DKBL	1661208C1

Legend: D-E - - - ; F-G - - -

20.67. CONNECTOR COMPOSITES %(1700), P. 41B | Figure 947 CONNECTOR COMPOSITES %(1700) | printed page 947

CIRCUIT	GA	COLOR	TERMINAL
A64	12	YL	3574287C1
A52A	14	YL	3574288C1
A52B	14	YL	3574288C1
A53B	16	YL	3574288C1
A53A	14	YL	3574288C1
A125C	14	YL	3574288C1
A53F	16	YL	3574288C1
A53B	14	YL	3574288C1
A125D	14	YL	3574288C1
A56A	14	OR	3574288C1
A56A	14	OR	3574288C1
A57A	14	OR	3574288C1
A58A	14	BN	3574288C1
A44M	16	GY	3574288C1
A44N	18	GY	3574289C1
A94BJ	10	GY	3574287C1
A94A	12	GY	3574287C1
A94A	16	GY	3574288C1
A152T	12	DKBL	3574287C1
A94BP	12	GY	3574287C1
A94BP	16	GY	3574288C1
A90	12	GY	3574287C1
A90	10	GY	3574287C1
A152U	12	YL	3574287C1
A90	10	GY	3574287C1
A94L	12	GY	3574287C1
A94L	10	GY	3574287C1
A94L	10	GY	3574287C1
A94AA	18	DKBL	2003343C1
A94AA	16	DKBL	3574285C1
A41	18	TN	2003343C1
A85A	16	GY	3574285C1
A125B	16	GY	3574285C1
A85	16	GY	3574285C1
A171-G	16	WH	3574285C1
A94AB	18	YL	2003343C1
A94AB	16	YL	3574285C1
A5AC	18	YL	2003343C1
A59J	18	GY	2003343C1
A5BC	18	LTGN	2003343C1
A59K	18	GY	2003343C1
A70LC	16	OR	3574285C1
A59L	18	GY	2003343C1
A59M	18	GY	2003343C1
A47A	18	GY	2003343C1
A39B	16	GY	3574285C1
A39F	14	BK	3574285C1
A39C	14	BK	3574285C1
A87A	18	GY	2003343C1
A10LC	18	WH	3574289C1
A87-G	18	GY	2003343C1
A39D	14	BK	3574285C1
A90H	18	GY	2003343C1
A94C(+)	16	YL	3574285C1
A94D	14	BK	3574285C1
CONTINUED		ON	SHEET_41C
BE,CE BUS	MODELS,		
NO.		SHEET	

CIRCUIT	GA	COLOR	TERMINAL
A5U(+)	18	YL	2003343C1
A5S(+)	18	YL	2003343C1
A5N(+)	18	YL	2003343C1
A5E(+)	18	YL	2003343C1
A5AG(+)	18	YL	2003343C1
A5U(-)	18	GN	2003343C1
A5S(-)	18	GN	2003343C1
A5N(-)	18	GN	2003343C1
A5E(-)	18	GN	2003343C1
A5AG(-)	18	GN	2003343C1
A110AD	18	GY	2003343C1
A59R	18	GY	2003343C1
A94U	16	VT	3574285C1
A94N(+)	16	GY	3574285C1
A59S	18	GY	2003343C1
A94V	16	LTGN	3574285C1
A94N(-)	16	OR	3574285C1
A90E	18	GY	2003343C1
A94BJ	18	GY	2003343C1
A94BA	18	GY	2003343C1
A90E	18	GY	2003343C1
A94W	16	LTBL	3574285C1
A94M(+)	16	DKBL	3574285C1
A59T	18	GY	2003343C1
A94R	16	BK	3574285C1
A94M(-)	16	YL	3574285C1
A59U	18	GY	2003343C1
A94S	16	RD	3574285C1
A13E	18	PK	2003343C1
A13F	18	PK	2003343C1
A59V	18	GY	2003343C1
A94T	16	BN	3574285C1
A67-G	18	WH	2003343C1
A67-GA	18	WH	2003343C1
A94B(+)	16	GY	3574285C1
A3C(+)	18	DKBL	2003343C1
A3(+)	18	DKBL	2003343C1
A94U	14	VT	3574285C1
A94B(-)	16	OR	3574285C1
A3C(-)	18	GY	2003343C1
A3(-)	18	GY	2003343C1
A94V	14	LTGN	3574285C1
A90B	18	GY	2003343C1
A94C(-)	16	DKBL	3574285C1
A94W	14	LTBL	3574285C1
A90B-G	18	WH	2003343C1
A67-G	18	WH	2003343C1
A67-GA	18	WH	2003343C1
A94R	14	BK	3574285C1
A9A	18	GY	2003343C1
A13E	18	PK	2003343C1
A13F	18	PK	2003343C1
A9A	18	GY	2003343C1
A94S	14	RD	3574285C1
AZ74B	16	LTGN	3574285C1
A74B	16	LTGN	3574285C1
CONTINUED		ON	
BE,CE BUS NO.	MODELS,		SHEET

20.69. CONNECTOR COMPOSITES %(1700), P. 41D | Figure 949 CONNECTOR COMPOSITES %(1700) | printed page 949

CIRCUIT	GA	COLOR	TERMINAL
A74D	16	LTGN	3574285C1
A75C	18	LTGN	2003343C1
A75C	18	LTGN	2003343C1
A94T	14	BN	3574285C1
A94D	16	BK	3574285C1
A94B(+)	16	GY	3574285C1
A59W	18	GY	2003343C1
A94E	16	RD	3574285C1
A94B(-)	16	OR	3574285C1
A59X	18	GY	2003343C1
A94F	16	BN	3574285C1
A94C(+)	16	YL	3574285C1
A59Y	18	GY	2003343C1
A94H	16	VT	3574285C1
A94C(-)	16	DKBL	3574285C1
A59Z	18	GY	2003343C1
A94K	16	LTGN	3574285C1
A5T(+)	18	YL	2003343C1
A59AA	18	GY	2003343C1
A94L	16	LTBL	3574285C1
A5T(-)	18	GN	2003343C1
A75	10	LTGN	3574287C1
A75	10	LTGN	3574287C1
A75	10	RD	3574287C1
A74D	14	LTGN	3574288C1
A74	10	LTGN	3574287C1
A74H	10	LTGN	3574287C1
A74L	18	LTGN	2003343C1
A74	18	LTGN	2003343C1
A74P	18	LTGN	2003343C1
A74C	16	LTGN	3574285C1
A74A	16	LTGN	3574285C1
A74C	16	LTGN	3574285C1
A94E	14	RD	3574285C1
A9A	18	GY	2003343C1
A171L	18	TN	2003343C1
A40	18	GY	2003343C1
A94F	14	BN	3574285C1
A5T(+)	18	YL	2003343C1
A6H	18	GY	2003343C1
A94H	14	VT	3574285C1
A5T(-)	18	GN	2003343C1
A94K	14	LTGN	3574285C1
A44AA	18	GY	2003343C1
A94L	14	LTBL	3574285C1
A36	18	TN	2003343C1
A171M	18	TN	2003343C1
A152D	18	RD	2003343C1
A152P	18	RD	2003343C1
A59N	18	GY	2003343C1
A152A	18	YL	2003343C1
A152C	18	BK	2003343C1
A152R	18	BK	2003343C1
A59P	18	GY	2003343C1
A152C	18	BK	2003343C1
A152A	18	YL	2003343C1
CONTINUED		ON	SHEET_41E
BE,CE BUS	MODELS,		
NO.			SHEET

20.70. CONNECTOR COMPOSITES %(1700), P. 41E
Figure 950 CONNECTOR COMPOSITES %(1700)

20.70. CONNECTOR COMPOSITES %(1700), P. 41E | Figure 950 CONNECTOR COMPOSITES %(1700) | printed page 950

CIRCUIT	GA	COLOR	TERMINAL
A5A(+)	18	YL	2003343C1
A152B	18	GN	2003343C1
A90F	18	GY	2003343C1
A5A(-)	18	GN	2003343C1
A119A	18	GY	2003343C1
A119H	18	GY	2003343C1
A119AA	18	GY	2003343C1
A152P	18	RD	3574289C1
A152R	18	BK	3574289C1
A119	16	GY	3574288C1
A119C	16	GY	3574288C1
A5A(+)	18	YL	3574289C1
A36CB	10	TN	3574287C1
A5A(-)	18	GN	3574289C1
A36D	14	TN	3574288C1
A94N(-)	16	OR	3574288C1
A37E	14	TN	3574288C1
A94M(-)	16	YL	3574288C1
A37F	14	TN	3574288C1
A94N(+)	16	GY	3574288C1
A37A	12	TN	3574287C1
A94M(+)	16	DK BL	3574288C1
A37H	14	TN	3574288C1
A152E	18	DK BL	3574289C1
A37J	14	TN	3574288C1
A152F	18	YL	3574289C1
A37K	14	TN	3574288C1
A14LC	18	RD	3574289C1
A37B	14	TN	3574288C1
A13LC	18	PK	3574289C1
A37C	18	TN	3574289C1

20.71. CONNECTOR COMPOSITES ##(1700), P. 42 | Figure 951 CONNECTOR COMPOSITES ##(1700) | printed page 951

CAV	CIRCUIT	GA	COLOR	TERMINAL
20%*	A5BC	18	LTGN	2003343C1
20%&	A59K	18	GY	2003343C1
21%!	A70LC	16	OR	3574285C1
21%&	A59L	18	GY	2003343C1
22%&	A59M	18	GY	2003343C1
22#@	A47A	18	GY	2003343C1
23	A39B	16	GY	3574285C1
24	A39F	14	BK	3574285C1
25	A87A	18	GY	2003343C1
26%*	A10LC	18	WH	3574289C1
27	A87-G	18	GY	2003343C1
28	A39DE	14	BK	3574285C1
29&%	A90H	18	GY	2003343C1
29%	A94D	14	BK	3574285C1
29#	A94C(+)	16	YL	3574285C1
30!%	A5U(+)	18	YL	2003343C1
30!^	A5S(+)	18	YL	2003343C1
30@	A5NE(+)	18	YL	2003343C1
31!%	A5U(-)	18	GN	2003343C1
31!^	A5S(-)	18	GN	2003343C1
31@	A5NE(-)	18	GN	2003343C1
32	A110AD	18	GY	2003343C1
33%	A94N(+)	16	GY	3574285C1
33#	A94U	16	VT	3574285C1
34%	A94N(-)	16	OR	3574285C1
34#	A94V	16	LTGN	3574285C1
35&%	A90E	18	GY	2003343C1
35*@	A94BJ	18	GY	2003343C1
35&&	A94BA	18	GY	2003343C1
35!	A90E	18	GY	2003343C1
35%	A94M(+)	16	DKBL	3574285C1
35#	A94W	16	LTBL	3574285C1

Legend: * W/POST TRIP INSPECTION ; & N/POST TRIP INSPECTION ; % W/BENDIX ABS-8 W/ABS W/PROPANE/GASOLINE ENG ; # W/BENDIX ABS-8 W/ABS W/DIESEL ENG ; @ W/500K ISB DATALINK ; ! W/HYD BRAKES W/MANUAL PARK BRAKE ; !! W/BUS SCAN/CHILD CHECKMATE ; !@ W/COWL MOUNTED DIRECTIONAL LIGHTS ; !# N/COWL MOUNTED DIRECTIONAL LIGHTS

Table: CONNECTOR 3595623C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A64	12	YL	3574287C1
2	A52A	14	YL	3574288C1
3	A52B	14	YL	3574288C1
4*	A53B	16	YL	3574288C1
4&	A53A	14	YL	3574288C1
4!!	A125C	14	YL	3574288C1
5*	A53F	16	YL	3574288C1
5&	A53B	14	YL	3574288C1
5!!	A125D	14	YL	3574288C1
6!@	A56A	14	OR	3574288C1
6!#	A56AA	14	OR	3574288C1
7!@	A57A	14	OR	3574288C1
7!#	A57AA	14	OR	3574288C1
8!@	A58A	14	OR	3574288C1
8**	A58A	14	BN	3574288C1
9	A44M	16	GY	3574288C1
10	A44N	18	GY	3574289C1
11*%	A94BJ	10	GY	3574287C1
11*#	A152T	12	DKBL	3574287C1
11*@	A94A	12	GY	3574287C1
11&&	A94A	16	GY	3574288C1
12*#	A152U	12	YL	3574287C1
12&%	A90	12	GY	3574287C1
12!	A90	10	GY	3574287C1
13&%	A94L	12	GY	3574287C1
13!	A94L	10	GY	3574287C1
14	A94AA	18	DKBL	2003343C1
15	A41	18	TN	2003343C1
16*	A85A	16	GY	3574285C1
16!!	A125B	16	GY	3574285C1
16&	A85	16	GY	3574285C1
17	-	-	-	-
18	A94AB	18	YL	2003343C1
19%*	A5AC	18	YL	2003343C1
19%&	A59J	18	GY	2003343C1

20.72. CONNECTOR COMPOSITES ##(1700), P. 43 | Figure 952 CONNECTOR COMPOSITES ##(1700) | printed page 952

Table: CONNECTOR BODY COMPOSITE

CAV	CIRCUIT	GA	COLOR	TERMINAL
48#	A94H	16	VT	3574285C1
49!*	A5T(-)	18	GN	2003343C1
49#	A94K	16	LTGN	3574285C1
50!*	A5T(+)	18	YL	2003343C1
50#	A94L	16	LTBL	3574285C1
51^!	A75	12	LTGN	3574287C1
51%%	A75	12	RD	3574287C1
51^*	A74D	14	LTGN	3574288C1
51^%	A74	12	LTGN	3574287C1
51^#	A74H	12	LTGN	3574287C1
52^!	A74L	18	LTGN	2003343C1
52%^	A74	18	LTGN	2003343C1
52%%	A74P	18	LTGN	2003343C1
52^*	A74C	16	LTGN	3574285C1
52^%	A74A	16	LTGN	3574285C1
52%	A94E	14	RD	3574285C1
53^	A171L	18	TN	2003343C1
53^&	A9AAP	18	GY	2003343C1
54&#	A40	18	GY	2003343C1
54%	A94F	14	BN	3574285C1
55*^	A5T(+)	18	YL	2003343C1
55&#	A6H	18	GY	2003343C1
55%	A94H	14	VT	3574285C1
56*^	A5T(-)	18	GN	2003343C1
56%	A94K	14	LTGN	3574285C1
57&%	A44AA	18	GY	2003343C1
57%	A94L	14	LTBL	3574285C1
58^	A171M	18	TN	2003343C1
58^&	A36	18	TN	2003343C1
59&^	A152D	18	RD	2003343C1
59&!	A152PA	18	RD	2003343C1

Legend: ^ W/BASE HARNESS W/GEN 5, PROPANE ; % W/BENDIX ABS-8 W/ABS W/PROPANE/GASOLINE ENG ; # W/BENDIX ABS-8 W/ABS W/DIESEL ENG ; @ W/500K ISB DATALINK ; !& W/BENDIX ABS-8 W/WINGMAN W/PROPANE/GASOLINE ENG ; !* W/BENDIX ABS-8 W/FUSION W/PROPANE/GASOLINE ENG ; *& W/BENDIX ABS-8 W/WINGMAN W/DIESEL ENG ; *^ W/BENDIX ABS-8 W/FUSION W/DIESEL ENG ; &^ W/BENDIX ABS-8 W/ESP W/DIESEL ENG

Table: CONNECTOR 3595623C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
36%	A94M(-)	16	YL	3574285C1
36#	A94R	16	BK	3574285C1
37!&	A13E	18	PK	2003343C1
37!*	A13FV	18	PK	2003343C1
37#	A94S	16	RD	3574285C1
38!&	A67-G	18	WH	2003343C1
38!*	A67-GA	18	WH	2003343C1
38#	A94T	16	BN	3574285C1
39@	A3(+)	18	DKBL	2003343C1
39%	A94U	14	VT	3574285C1
39#	A94B(+)	16	GY	3574285C1
40@	A3(-)	18	GY	2003343C1
40%	A94V	14	LTGN	3574285C1
40#	A94B(-)	16	OR	3574285C1
41&%	A90B	18	GY	2003343C1
41%	A94W	14	LTBL	3574285C1
41#	A94C(-)	16	DKBL	3574285C1
42&%	A90B-G	18	WH	2003343C1
42*&	A67-G	18	WH	2003343C1
42*^	A67-GA	18	WH	2003343C1
42%	A94R	16	BK	3574285C1
43&#	A9AA	18	GY	2003343C1
43*&	A13E	18	PK	2003343C1
43*^	A13F	18	PK	2003343C1
43%	A94S	16	RD	3574285C1
44^*	A74B	16	LTGN	3574285C1
44^#	A74D	16	LTGN	3574285C1
44^!	A75C	18	LTGN	2003343C1
44%	A94T	14	BN	3574285C1
45%	A94B(+)	16	GY	3574285C1
45#	A94D	16	BK	3574285C1
46%	A94B(-)	16	OR	3574285C1
46#	A94E	16	RD	3574285C1
47%	A94C(+)	16	YL	3574285C1
47#	A94F	16	BN	3574285C1
48%	A94C(-)	16	DKBL	3574285C1

20.73. CONNECTOR COMPOSITES !!(1700), P. 44 | Figure 953 CONNECTOR COMPOSITES !!(1700) | printed page 953

CAV	CIRCUIT	GA	COLOR	TERMINAL
60&^	A152A	18	YL	2003343C1
60*#	A152C	18	BK	2003343C1
60&!	A152RA	18	BK	2003343C1
61&^	A152C	18	BK	2003343C1
61*#	A152A	18	YL	2003343C1
61&!	A5AA(+)	18	YL	2003343C1
62&^	A152B	18	GN	2003343C1
62&%	A90F	18	GY	2003343C1
62&!	A5AA(-)	18	GN	2003343C1
63	A119AP	18	GY	2003343C1
64^^	A152PA	18	RD	3574289C1
65^^	A152RA	18	BK	3574289C1
66*	A119	16	GY	3574288C1
66%	A119B	16	GY	3574288C1
67^^	A5AAZ(+)	18	YL	3574289C1
67^	A36CB	10	TN	3574287C1
68^^	A5AAZ(-)	18	GN	3574289C1
68^	A36D	14	TN	3574288C1
69^	A37E	14	TN	3574288C1
69#	A94N(-)	16	OR	3574288C1
70^	A37F	14	TN	3574288C1
70#	A94M(-)	16	YL	3574288C1
71^	A37A	12	TN	3574287C1
71#	A94N(+)	16	GY	3574288C1
72^	A37H	14	TN	3574288C1
72#	A94M(+)	16	DKBL	3574288C1
73&^	A152E	18	DKBL	3574289C1
73^	A37J	14	TN	3574288C1
74&^	A152F	18	YL	3574289C1
74^	A37K	14	TN	3574288C1
75%*	A14LC	18	RD	3574289C1
75^	A37B	14	TN	3574288C1
76%*	A13LC	18	PK	3574289C1
76##	A37C	18	TN	3574289C1

20.74. CONNECTOR COMPOSITES @(1700), P. 45 | Figure 954 CONNECTOR COMPOSITES @(1700) | printed page 954

Table: CONNECTOR

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M64	14	YL	3549416C1
2	M52A	12	YL	3549415C1
3	M52B	12	YL	3549415C1
4	M53A	12	YL	3549415C1
5	M53B	12	YL	3549415C1
6	M56A	14	OR	3549416C1
7	M57A	14	OR	3549416C1
8	M58AA	14	BN	3549416C1
9	M44M	18	GY	3574277C1
10	M44N	18	GY	3574277C1
11*	M94BJ	10	GY	3549415C1
11#	M94BP	12	GY	3549415C1
12**	M90	12	GY	3549415C1
12##	M90A	10	GY	3549415C1
13**	M94L	12	GY	3549415C1
13##	M94L	10	GY	3549415C1
14	M152A	16	GY	3549417C1
15	M41	18	TN	3549418C1
16	M85A	16	GY	3549417C1
17	PLUG	-	-	3598922C1
18	M152B	16	GY	3549417C1
19%	M59J	18	GY	3549418C1
19%%	M5LSA	18	YL	3549418C1
20%	M59K	18	GY	3549418C1
20%%	M5LSB	18	LTGN	3549418C1
21%	M59L	18	GY	3549418C1
21%%	M70LS	18	OR	3549418C1
22%	M59M	18	GY	3549418C1
22%%	M47LS	18	OR	3549418C1
23	M39D	14	BK	3549417C1
24	M39C	14	BK	3549417C1
25	M87A	18	GY	3549418C1
26	M10LS	18	WH	3574277C1
27	M87-G	18	GY	3549418C1
28	M39B	14	BK	3549417C1
29**	M90H	18	GY	3549418C1
29&	M94C	16	GY	3549417C1
30&&	M5E(+)	18	YL	3549418C1

Legend: CHK DATE ; MJV0488 13SEP21 ADDED NOTES FOR FUSE B 96183U ; BLOCK.

Table: 3595622C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
30&%	M5A(+)	18	YL	3549418C1
31&&	M5E(-)	18	GN	3549418C1
31&%	M5A(-)	18	GN	3549418C1
32	M110AD	18	GY	3549418C1
33	M94BE	16	GY	3549417C1
34	M94BF	16	GY	3549417C1
35**	M90E	18	GY	3549418C1
35&	M94BH	16	GY	3549417C1
35##	M90C	18	PK	3549418C1
35#	M94BJ	18	GY	3549418C1
36	M94BJ	16	GY	3549417C1
37	M94BK	16	GY	3549417C1
38	M94BL	16	GY	3549417C1
39**	M3C+	18	DKBL	3549418C1

20.75. CONNECTOR COMPOSITES @(1700), P. 46 | Figure 955 CONNECTOR COMPOSITES @(1700) | printed page 955

Table: CONNECTOR

CAV	CIRCUIT	GA	COLOR	TERMINAL
39&	M94A	16	GY	3549417C1
40**	M3C-	18	GY	3549418C1
40&	M94B	16	GY	3549417C1
41**	M90B	18	GY	3549418C1
41&	M94D	16	GY	3549417C1
42**	M90B-G	18	WH	3549418C1
42!!	M67-GA	18	WH	3549418C1
42%	M67-GA	20	WH	3549418C1
43!	M9H	18	GY	3549418C1
43!!	M13AA	18	PK	3549418C1
43%	M13AA	20	PK	3549418C1
44^	M75C	16	DKBL	3549417C1
44^^	M75C	16	LTGN	3549417C1
45	M94E	16	GY	3549417C1
46	M94F	16	GY	3549417C1
47	M94H	16	GY	3549417C1
48	M94J	16	GY	3549417C1
49	M94K	16	GY	3549417C1
50	M94L	16	GY	3549417C1
51	M75	10	LTGN	3549415C1
52	M75A	18	LTGN	3549418C1
53	M9D	18	GY	3549418C1
54	M40	18	GY	3549418C1
55!#	M6H	16	GY	3549417C1
55!*	M5UE(+)	18	YL	3549418C1
55%	M5D(+)	18	YL	3549418C1
56#	M94BCS	18	GY	3549418C1
56!*	M5UE(-)	18	GN	3549418C1
56%	M5D(-)	18	GN	3549418C1
57	M44A	18	GY	3549418C1
58	M36	18	TN	3549418C1
59	M152C	18	RD	3549418C1
60	M152(+)	18	YL	3549418C1
61	M152D	18	BK	3549418C1
62**	M90F	18	GY	3549418C1
62!%	M152(-)	18	GN	3549418C1
63	M89A	16	VT	3549417C1
64	M152EB	18	RD	3574277C1
65	M152FB	18	BK	3574277C1

Table: 3595622C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
66	M89	16	VT	3549416C1
67	M152B+	18	YL	3574277C1
68	M152B-	18	GN	3574277C1
69	M94BB	16	GY	3549416C1
70	M94BD	16	GY	3549416C1
71	M94BA	16	GY	3549416C1
72	M94BC	16	GY	3549416C1
73	M152G	16	GY	3549416C1
74	M152H	16	GY	3549416C1
75	M14LS	18	RD	3574277C1
76	M13LS	18	PK	3574277C1

Legend: # W/AIR BRAKE W/ABS6 N/GEN 4 BODY CONTROLLER ; ** W/HYD BRAKES N/GEN 4 BODY CONTROLLER ; & W/AIR BRAKE EC 80 ; !! W/BENDIX AIR EC 80 W/BENDIX WINGMAN ; ! W/AIR SOURCE W/HYD BRAKE ; ^ W/RSM FUEL TANK W/ESPAR COOLANT HTR AFT RA ; ^^ W/RSM FUEL TANK W/COOLANT HTR MOUNTED FORWARD ; !% W/AIR BRAKE EC 80 W/STABILITY CONTROL ; !# W/AIR SOURCE W/HYD BRAKE 2010 V8

20.76. CONNECTOR COMPOSITES @(1700), P. 47
Figure 956 CONNECTOR COMPOSITES @(1700)

20.76. CONNECTOR COMPOSITES @(1700), P. 47 | Figure 956 CONNECTOR COMPOSITES @(1700) | printed page 956

Table: CONNECTOR
CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M64	14	YL	3549416C1
2	M52A	12	YL	3549415C1
3	M52B	12	YL	3549415C1
4	M53A	12	YL	3549415C1
5	M53B	12	YL	3549415C1
6	M56A	14	OR	3549416C1
7	M57A	14	OR	3549416C1
8	M58AA	14	BN	3549416C1
9	M44M	18	GY	3574277C1
10	M44N	18	GY	3574277C1
11#	M152G	16	GY	3549416C1
11^^	M94BP	12	GY	3549415C1
12#	M152H	16	GY	3549416C1
12%%	M90A	10	GY	3549415C1
12##	M90A	10	GY	3549415C1
13%%	M94L	10	GY	3549415C1
13##	M94L	10	GY	3549415C1
14	M152A	16	GY	3549417C1
15	M41	18	TN	3549418C1
16%#	M85A	16	GY	3549417C1
16#*	M85A	16	GY	3549417C1
17	M171-G	16	WH	3549417C1
18	M152B	16	GY	3549417C1
19	M59J	18	GY	3549418C1
20	M59K	18	GY	3549418C1
21	M59L	18	GY	3549418C1
22	M59M	18	GY	3549418C1
23!	M39B	14	BK	3549417C1
23!!!	M39B	14	BK	3549417C1
24	M39C	14	BK	3549417C1
25	M87A	18	GY	3549418C1
26	-	-	-	-
27	M87-G	18	GY	3549418C1
28&&	M39D	14	BK	3549417C1
28&#	M39D	14	BK	3549417C1
29	M94E	14	GY	3549417C1
30^^	M5E(+)	18	YL	3549418C1

Legend: CHK DATE ; MJV0488 13SEP21 ADDED CIRC M171-G, B 96183U ; M13AB & M67-GB.

Table: 3595622C1
CAV	CIRCUIT	GA	COLOR	TERMINAL
30!!	M5(+)	18	YL	3549418C1
30^	M5A(+)	18	YL	3549418C1
31^^	M5E(-)	18	GN	3549418C1
31!!	M5(-)	18	GN	3549418C1
31^	M5A(-)	18	GN	3549418C1
32	M110AD	18	GY	3549418C1
33	M94LA	16	GY	3549417C1
34	M94LB	16	GY	3549417C1
35*	M94RA	16	GY	3549417C1
35%%	M90C	18	PK	3549418C1
35^^	M94BJ	18	GY	3549418C1
36	M94RB	16	GY	3549417C1
37	M13AA	18	PK	3549418C1
37+	M13AB	20	PK	3549418C1
38	M67-GA	18	WH	3549418C1
38+	M67-GB	20	WH	3549418C1
39*	M94BA	14	GY	3549417C1
39^^	M3CA	18	GY	3549418C1
40*	M94BB	14	GY	3549417C1
40^^	M3CB	18	GY	3549418C1
41	M94BC	14	GY	3549417C1

Legend: %# N/HORN RT RAIL ; #* W/HORN RT RAIL ; ## W/HYD BRAKES WABCO MK25 ; %% W/HYD BRAKES WABCO MK25 W/STABILITY CONTROL ; * W/BENDIX EC-80 AIR ABS ; # W/BENDIX EC-80 AIR ABS W/STABILITY CONTROL ; ! W/HALDEX DRAIN VALVE W/AIR DRYER ; !!!W/HALDEX DRAIN VALVE N/AIR DRYER W/04VCY ; && W/BENDIX DV-2 DRAIN VALVE W/AIR DRYER

20.77. CONNECTOR COMPOSITES @(1700), P. 48 | Figure 957 CONNECTOR COMPOSITES @(1700) | printed page 957

CAV	CIRCUIT	GA	COLOR	TERMINAL
42	M94BD	14	GY	3549417C1
43*	M94BE	14	GY	3549417C1
43**	M9H	18	GY	3549418C1
44	M94BF	14	GY	3549417C1
45	M94A	16	GY	3549417C1
46	M94B	16	GY	3549417C1
47	M94C	16	GY	3549417C1
48	M94D	16	GY	3549417C1
49!!	M5UE(+)	18	YL	3549418C1
49!	M5D(+)	18	YL	3549418C1
50!!	M5UE(-)	18	GN	3549418C1
50!	M5D(-)	18	GN	3549418C1
51	-	-	-	-
52	M94F	14	GY	3549417C1
53	M148L	18	TN	3549418C1
54*	M94H	14	GY	3549417C1
54**	M40	18	GY	3549418C1
55*	M94J	14	GY	3549417C1
55**	M6H	16	GY	3549417C1
56	M94K	14	GY	3549417C1
57	M94L	14	GY	3549417C1
58	M148M	18	TN	3549418C1
59%%	M152EB	18	RD	3549418C1
59#	M152C	18	RD	3549418C1
60%%	M152FB	18	BK	3549418C1
60#	M152D	18	BK	3549418C1
61%%	M152B+	18	YL	3549418C1
61#	M152(+)	18	YL	3549418C1
62%%	M152B-	18	GN	3549418C1
62#	M152(-)	18	GN	3549418C1
63	M119A	16	VT	3549417C1
64	-	-	-	-
65	-	-	-	-
66	M119	16	VT	3549416C1
67&	M148CB	10	RD	3549415C1
67%	M36C	10	RD	3549415C1
68&	M148D	14	TN	3549416C1
68%	M36D	14	TN	3549416C1
69&	M148E	14	TN	3549416C1
69%	M37E	14	TN	3549416C1
70&	M148F	14	TN	3549416C1
71	M148A	12	TN	3549415C1
72&	M148H	12	TN	3549415C1
72%	M37H	12	TN	3549415C1
73&	M148J	12	TN	3549415C1
73%	M37J	12	TN	3549415C1
74&	M148K	12	TN	3549415C1
74%	M37K	12	TN	3549415C1
75&	M148B	14	TN	3549416C1
76%	M37C	12	TN	3549415C1

20.78. CONNECTOR COMPOSITES ##(1701), P. 49 | Figure 958 CONNECTOR COMPOSITES ##(1701) | printed page 958

CAV	CIRCUIT	GA	COLOR	TERMINAL
23&*	A26	18	TN	2003343C1
23&^	A26	18	TN	2003343C1
23&%	A26-G	18	WH	2003343C1
24%	A5N2B(+)	18	YL	2003343C1
25&#	A97RB	18	TN	2003343C1
25&@	A97RB	18	TN	2003343C1
26*	A92#141	18	GY	3574289C1
26&	A92#141	18	GY	3574289C1
27	A44AB	16	VT	3574285C1
28	A39E	14	BK	3574285C1
29*%	A90H	18	GY	2003343C1
29#	A90H	16	GY	3574285C1
30	-	-	-	-
31#*	A134	18	WH	2003343C1
32	A26	18	RD	2003343C1
33@!	A13BF	18	PK	2003343C1
33@#	A13BF	18	PK	2003343C1
33&	A13FD	18	PK	2003343C1
34^	A37E	14	TN	3574285C1
35	-	-	-	-
36^	A36D	14	TN	3574285C1
37%	A5N2B(-)	18	GN	2003343C1
38#&	A47	18	GY	2003343C1
39	-	-	-	-

Legend: W/BASE HARNESS W/GEN 5 W/DIESEL ENG ; W/BASE HARNESS W/GEN 5 W/PROPANE/GASOLINE ENG ; W/BASE HARNESS W/GEN 5 W/PROPANE ENG ; W/N2 COMMUNICATIONS MODULE W/CUMMINS CONNECTIVITY ; W/BENDIX AIR ABS-6 ; W/AIR BRAKES ABS-6 W/PARK BRAKE BUZZER ; W/AMMETER - 150 AMP W/DIESEL ENG ; W/AMMETER - 300 AMP W/DIESEL ENG ; W/CROSSING GATE W/300 AMP AMMETER

CAV	CIRCUIT	GA	COLOR	TERMINAL
1&	A17BZ	12	RD	3574287C1
2-10	-	-	-	-
11*&	A94A	12	GY	3574287C1
11!	A94A	16	GY	3574288C1
12*%	A90	12	GY	3574287C1
12#	A90	10	GY	3574287C1
13*%	A94L	12	GY	3574287C1
13#	A94L	10	GY	3574287C1
14^	A37K	14	TN	3574285C1
15^	A37J	14	TN	3574285C1
16^	A37H	14	TN	3574285C1
17^	A37F	14	TN	3574285C1
18	-	-	-	-
19*	A17B	16	PK	3574285C1
20^*	A26B	18	TN	2003343C1
20^%	A26B	18	TN	2003343C1
21	A97UA	18	VT	2003343C1
22#*	A#165	18	TN	2003343C1
22^!	A#165	18	TN	2003343C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
67#	A90C	18	GY	3574289C1
68#	A90F	18	GY	3574289C1
69%	A37C	18	TN	3574289C1
70-71	-	-	-	-
72	A5BJ(+)	18	YL	3574289C1
73	A5BJ(-)	18	GN	3574289C1
74^	A37B	14	TN	3574288C1
75^	A37A	12	TN	3574287C1
76^	A36CB	10	TN	3574287C1

Table: CONNECTOR 3595625C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
40	-	-	-	-
41*%	A90B	18	GY	2003343C1
41#	A90B	16	GY	3574285C1
42	-	-	-	-
43#*	A#163	18	YL	2003343C1
43^!	A#163	18	YL	2003343C1
44	A26A	18	TN	2003343C1
45	A5R(+)	18	YL	2003343C1
46	A5R(-)	18	GN	2003343C1
47	A97R	18	VT	2003343C1
48	A97C	18	VT	2003343C1
49	A99A	18	VT	2003343C1
50#&	A48	18	GY	2003343C1
51	-	-	-	-
52@@	A44C-G	18	WH	2003343C1
52@%	A44C	18	GY	2003343C1
53	-	-	-	-
54	A59	16	GY	3574285C1
55	A101	18	TN	2003343C1
56**	A103	18	TN	2003343C1
57*%	A90C	18	GY	2003343C1
57#	A9HT	16	GY	3574285C1
58^!	A#142	16	TN	3574285C1
59	A97WC	18	VT	2003343C1
60	A92NV	18	TN	2003343C1
61	A77G	18	LTGN	2003343C1
61&	A77F	14	LTGN	3574285C1
62	A99D	18	VT	2003343C1
63	A99F	18	VT	2003343C1
64	A47A	18	GY	3574289C1
64&	A77C	18	GY	3574289C1
65	-	-	-	-
66#	A90P	18	GY	3574289C1

20.80. CONNECTOR COMPOSITES @(1701), P. 51
Figure 960 CONNECTOR COMPOSITES @(1701)

20.80. CONNECTOR COMPOSITES @(1701), P. 51 | Figure 960 CONNECTOR COMPOSITES @(1701) | printed page 960

CAV	CIRCUIT	GA	COLOR	TERMINAL
24-25	-	-	-	-
26**	K17B	18	GY	3574277C1
26%#	K92#141	18	GY	3574277C1
27	K44	18	GY	3549418C1
28	K39D	14	GY	3549417C1
29#	K90H	18	GY	3549418C1
29%	K90H	16	GY	3549417C1
30	PLUG	-	-	3598921C1
31!!	K92A142	18	WH	3549418C1
31%#	K92A134	18	YL	3549418C1
32&*	K26E	18	TN	3549418C1
32	K26P	18	TN	3549418C1
33	K13F	18	PK	3549418C1
34	K92(+)	18	YL	3549418C1
35	K92(-)	18	GN	3549418C1
36-40	PLUG	-	-	3598921C1
41#	K90B	18	GY	3549418C1
41%	K90B	16	GY	3549417C1
42	PLUG	-	-	3598921C1
43	K92#163	18	YL	3549418C1
44&*	K26D	18	TN	3549418C1
44	K26N	18	TN	3549418C1
45!*	K5B(+)	18	YL	3549418C1
45*!	K5G(+)	18	YL	3549418C1
46!*	K5B(-)	18	GN	3549418C1
46*!	K5G(-)	18	GN	3549418C1
47	K97R	20	VT	3549418C1
48	K97C	20	VT	3549418C1
49	K99A	20	VT	3549418C1
50-51	PLUG	-	-	3598921C1
52	K44C	18	GY	3549418C1
53-54	PLUG	-	-	3598921C1
55%#	K92B101	18	LTBL	3549418C1
55#%	K122H	18	TN	3549418C1
56%#	K92B103	18	YL	3549418C1
56#%	K122F	18	TN	3549418C1
56	K92#103	18	YL	3549418C1
57#	K90C	18	GY	3549418C1
57%	K90E	16	GY	3549417C1
58!!	K92B142	18	WH	3549418C1
58%#	K92B134	18	YL	3549418C1
59	K97WC	20	VT	3549418C1
60	PLUG	-	-	3598921C1
61	K77A	16	LTGN	3549417C1
62	K99D	20	VT	3549418C1
63	K99F	20	VT	3549418C1
64	K47A	18	GY	3574277C1
65	PLUG	-	-	3598921C1
66	K90P	14	GY	3549416C1
67	K90C	18	GY	3574277C1
68	K90G	16	GY	3549416C1
69-71	PLUG	-	-	3598921C1
72	K5A(+)	20	YL	3574277C1
73	K5A(-)	20	GN	3574277C1
74-76	PLUG	-	-	3598921C1

Table: CONNECTOR 3595624C1
CAV	CIRCUIT	GA	COLOR	TERMINAL
1-4	PLUG	-	-	3598921C1
5	K122G	18	TN	3574277C1
6	K92K	18	TN	3574277C1
7	K13	18	GY	3574277C1
8-10	PLUG	-	-	3598921C1
11	K94B	10	GY	3549415C1
12#	K90	10	GY	3549415C1
12%	K90A	10	GY	3549415C1
13	K94L	12	GY	3549415C1
14-15	PLUG	-	-	3598921C1
16	K92E	18	TN	3549418C1
17-18	PLUG	-	-	3598921C1
19&	K17B	16	PK	3549417C1
19**	K17BA	16	PK	3549417C1
20##	K26C	18	TN	3549418C1
20	K26	18	TN	3549418C1
21&&	K97UA	18	VT	3549418C1
21%%	K97UA	14	VT	3549417C1
22#%	K92D	18	TN	3549418C1
22%#	K71#165	18	TN	3549418C1
23	K26	18	TN	3549418C1

Legend: # W/HYD BRAKES COMMON ; % W/HYDROMAX HYD BRAKES ; & W/BCM 4TH GEN ALLISON ; ** W/BCM 4TH GEN EATON ; ## W/300 AMP AMMETER WIRING ; && W/ELECTRIC CLUTCH FAN, W/BCM 4TH GEN ; %% W/VISCOUS FAN, HORTON FAN ; #% W/TRANSMISSION EATON EPS ; %# W/AUTOMATIC ALLISON W/BCM 4TH GEN

20.81. CONNECTOR COMPOSITES *(1701), P. 52 | Figure 961 CONNECTOR COMPOSITES *(1701) | printed page 961

CAV	CIRCUIT	GA	COLOR	TERMINAL
21	K17UA	18	PK	3549418C1
22	K71#165	18	TN	3549418C1
23	K26-G	18	WH	3549418C1
24	PLUG	-	-	3598922C1
25	K97RB	18	VT	3549418C1
26	K92#141	18	GY	3574277C1
27	K44	18	GY	3549418C1
28	K39D	14	GY	3549417C1
29	K90H	16	GY	3549417C1
30	PLUG	-	-	3598922C1
31	K92A142	18	WH	3549418C1
32	K26N	18	TN	3549418C1
33	K13F	18	PK	3549418C1
34	K36E	14	TN	3549417C1
35	PLUG	-	-	3598922C1
36	K36D	14	TN	3549417C1
37-40	PLUG	-	-	3598922C1
41	K90B	16	GY	3549417C1
42	PLUG	-	-	3598922C1
43	K92#163	18	YL	3549418C1
44	K26P	18	TN	3549418C1
45	K5A(+)	18	YL	3549418C1
46	K5A(-)	18	GN	3549418C1
47	K97R	18	VT	3549418C1
48	K97C	18	VT	3549418C1
49	K99A	18	VT	3549418C1
50-51	PLUG	-	-	3598922C1
52	K44C	18	GY	3549418C1
53-54	PLUG	-	-	3598922C1
55	K92#101	18	LTBL	3549418C1
56	K92#103	18	YL	3549418C1
57	K90E	16	GY	3549417C1
58	K92B142	18	WH	3549418C1
59	K97WC	18	VT	3549418C1
60	PLUG	-	-	3598922C1
61	K77G	18	LTGN	3549418C1
62	K99D	18	VT	3549418C1
63	K99F	18	VT	3549418C1
64	K77GB	18	LTGN	3574277C1
65	PLUG	-	-	3598922C1
66	K90P	14	GY	3549416C1
67	K90C	18	GY	3574277C1
68	K90G	16	GY	3549416C1
69-71	PLUG	-	-	3598922C1
72	K5C(+)	20	YL	3574277C1
73	K5C(-)	20	GN	3574277C1
74	K37CS	14	TN	3549416C1
75	K37DS	12	TN	3549415C1
76	K37ET	10	RD	3549415C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K17B	12	PK	3549415C1
2-10	PLUG	-	-	3598922C1
11	K94B	10	GY	3549415C1
12	K90A	10	GY	3549415C1
13	K94L	12	GY	3549415C1
14	K37K	14	TN	3549417C1
15	K37J	14	TN	3549417C1
16	K37H	14	TN	3549417C1
17	K37F	14	TN	3549417C1
18	PLUG	-	-	3598922C1
19	PLUG	-	-	3598922C1
20	K26	18	TN	3549418C1

20.82. CONNECTOR COMPOSITES #(1701), P. 53
Figure 962 CONNECTOR COMPOSITES #(1701)

20.82. CONNECTOR COMPOSITES #(1701), P. 53 | Figure 962 CONNECTOR COMPOSITES #(1701) | printed page 962

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K17B	12	PK	3549415C1
2-10	PLUG	-	-	3598921C1
11	K94B	10	GY	3549415C1
12	K90A	10	GY	3549415C1
13	K94L	12	GY	3549415C1
14	K37K	14	TN	3549417C1
15	K37J	14	TN	3549417C1
16	K37H	14	TN	3549417C1
17-19	PLUG	-	-	3598921C1
20	K26	18	TN	3549418C1
21	K17UA	18	PK	3549418C1
22	K71#165	18	TN	3549418C1
23	K26-G	18	WH	3549418C1
24-25	PLUG	-	-	3598921C1
26	K92#141	18	GY	3574277C1
27	K44	18	GY	3549418C1
28	K39D	14	GY	3549417C1
29	K90H	16	GY	3549417C1
30	PLUG	-	-	3598921C1
31	K92A142	18	WH	3549418C1
32	K26N	18	TN	3549418C1
33	K13F	18	PK	3549418C1
34	K36E	14	TN	3549417C1
35	PLUG	-	-	3598921C1
36	K36D	14	TN	3549417C1
37-40	PLUG	-	-	3598921C1
41	K90B	16	GY	3549417C1
42	PLUG	-	-	3598921C1
43	K92#163	18	YL	3549418C1
44	K26P	18	TN	3549418C1
45	K5A(+)	18	YL	3549418C1
46	K5A(-)	18	GN	3549418C1
47	K97R	18	VT	3549418C1
48	K97C	18	VT	3549418C1
49	K99A	18	VT	3549418C1
50-51	PLUG	-	-	3598921C1
52	K44C	18	GY	3549418C1
53-54	PLUG	-	-	3598921C1
55	K92#101	18	LTBL	3549418C1
56	K92#103	18	YL	3549418C1
57	K90E	16	GY	3549417C1
58	K92B142	18	WH	3549418C1
59	K97WC	18	VT	3549418C1
60	PLUG	-	-	3598921C1
61	K77G	18	LTGN	3549418C1
62	K99D	18	VT	3549418C1
63	K99F	18	VT	3549418C1
64	K77GB	18	LTGN	3574277C1
65	PLUG	-	-	3598921C1
66	K90P	14	GY	3549416C1
67	K90C	18	GY	3574277C1
68	K90G	16	GY	3549416C1
69	K37DS	12	TN	3549415C1
70-71	PLUG	-	-	3598921C1
72	K5C(+)	20	YL	3574277C1
73	K5C(-)	20	GN	3574277C1
74-75	PLUG	-	-	3598921C1
76	K37ET	10	RD	3549415C1

Legend: CIRCUIT DIAGRAM, BE,CE BUS MODELS ; NO. DATE ; 24FEB20 AE08090671 053

20.83. CONNECTOR COMPOSITES @@(1701), P. 54 | Figure 963 CONNECTOR COMPOSITES @@(1701) | printed page 963

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	A14MA	14	RD	3574288C1
3	A14MH	14	RD	3574288C1
4	A14MI	12	WH	3574287C1
5	A92G	18	GY	3574289C1
6	A92K	18	GY	3574289C1
7	A92	18	GY	3574289C1
8	A40A1	18	GY	3574289C1
9	A40B1	18	GY	3574289C1
10	A40C1	18	GY	3574289C1
11*	A94A	12	GY	3574287C1
11#	A94A	16	GY	3574288C1
12!	A90	12	GY	3574287C1
12&	A90	10	GY	3574287C1
13!	A94L	12	GY	3574287C1
13&	A94L	10	GY	3574287C1
14	A92MB	16	TN	3574285C1
15	A92MC	16	TN	3574285C1
16	A92E	18	GY	2003343C1
17	A92NP	18	TN	2003343C1
18	-	-	-	-
19	A17B	16	PK	3574285C1
20	A26B	18	TN	2003343C1
21	A97UA	18	VT	2003343C1
22	A#165	18	TN	2003343C1
22	A92D	18	GY	2003343C1
23	A26	18	TN	2003343C1
24	A92MF	16	TN	3574285C1
25	A92MG	16	TN	3574285C1
26	A92#141	18	GY	3574289C1
27	A44	16	VT	3574285C1
28	A39E	14	BK	3574285C1
29!	A90H	18	GY	2003343C1
29&	A90H	16	GY	3574285C1
30	A92NU	18	TN	2003343C1
31	A134	18	WH	2003343C1
32	A26	18	RD	2003343C1
33	A13BF	18	PK	2003343C1
34%	A92(+)	18	YL	2003343C1
34@	A92NF	18	TN	2003343C1
35%	A92(-)	18	GN	2003343C1
35@	A92NH	18	TN	2003343C1
36+	A3AA(+)	18	DKBL	2003343C1
36++	A3A(+)	18	DKBL	2003343C1
37+	A3AA(-)	18	GY	2003343C1
37++	A3A(-)	18	GY	2003343C1
38	A47	18	GY	2003343C1
39	A103	16	LTGN	3574285C1
40	A92NT	18	TN	2003343C1
41!	A90B	18	GY	2003343C1
41&	A90B	16	GY	3574285C1
42	A92NG	18	TN	2003343C1
43^	A#163	18	YL	2003343C1
43@	A#163	18	PK	2003343C1
44	A26A	18	TN	2003343C1
45^^	A5R(+)	18	YL	2003343C1

Legend: CHART CONTINUED ON SHEET_54A ; CIRCUIT DIAGRAM, BE,CE BUS MODELS ; NO. DATE ; 24FEB20 AE08090671 054

20.84. CONNECTOR COMPOSITES @@(1701), P. 54A
Figure 964 CONNECTOR COMPOSITES @@(1701)

20.84. CONNECTOR COMPOSITES @@(1701), P. 54A | Figure 964 CONNECTOR COMPOSITES @@(1701) | printed page 964

CAV	CIRCUIT	GA	COLOR	TERMINAL
45^	A5A(+)	18	YL	2003343C1
46^^	A5R(-)	18	GN	2003343C1
46^	A5A(-)	18	GN	2003343C1
47	A97R	18	VT	2003343C1
48	A97C	18	VT	2003343C1
49	A99A	18	VT	2003343C1
50	A48	18	GY	2003343C1
51	A59A1	18	GY	3574289C1
52**	A44C-G	18	WH	2003343C1
52!!	A44C	18	GY	2003343C1
53	A59B1	18	GY	2003343C1
54	-	-	-	-
55	A101	18	TN	2003343C1
56##	A103	18	TN	2003343C1
56%%	A122F	18	TN	2003343C1
57!	A90C	18	GY	2003343C1
57&	A9H	16	GY	3574285C1
58	A#142	16	TN	3574285C1
59	A97WC	18	PL	2003343C1
60	A92NV	18	TN	2003343C1
61	-	-	-	-
62	A99D	18	VT	2003343C1
63	A99F	18	PL	2003343C1
64	A47A	18	GY	3574289C1
65	A59C1	18	GY	3574289C1
66	A90P	18	GY	3574289C1
67	A90C	18	GY	3574289C1
68	A90F	18	GY	3574289C1
69-71	-	-	-	-
72	A5B(+)	18	YL	3574289C1
73	A5B(-)	18	GN	3574289C1
74	A92P	18	GY	3574289C1
75	A92M	18	GY	3574289C1
76	A92B	18	GY	3574289C1

20.85. CONNECTOR COMPOSITES @@(1701), P. 54B
Figure 965 CONNECTOR COMPOSITES @@(1701)

20.85. CONNECTOR COMPOSITES @@(1701), P. 54B | Figure 965 CONNECTOR COMPOSITES @@(1701) | printed page 965

CAV	CIRCUIT	GA	COLOR	TERMINAL
23	A26-G	18	WH	2003343C1
24	-	-	-	-
25	A97RB	18	TN	2003343C1
26	A92#141	18	GY	3574289C1
27	A44	18	GY	2003343C1
28	A39E	14	BK	3574285C1
29	A90H	16	GY	3574285C1
30-31	-	-	-	-
32	A26N	18	TN	2003343C1
33	A13F	18	PK	2003343C1
34	A37E	14	TN	3574285C1
36	A36D	14	TN	3574285C1
37-40	-	-	-	-
41	A90B	16	GY	3574285C1
42	-	-	-	-
43	A92#163	18	YL	2003343C1
44	A26P	18	TN	2003343C1
45	A5R(+)	18	YL	2003343C1
45	A5A(+)	18	YL	2003343C1
46	A5R(-)	18	GN	2003343C1
46	A5A(-)	18	GN	2003343C1
47	A97R	18	VT	2003343C1
48	A97C	18	VT	2003343C1
49	A99A	18	VT	2003343C1
50-51	-	-	-	-
52%	A44C-G	18	WH	2003343C1
52%%	A44C	18	GY	2003343C1
53-54	-	-	-	-
55	A101	18	TN	2003343C1
56**	A103	18	TN	2003343C1
56##	A103	18	TN	2003343C1
57	A9H	16	GY	3574285C1
58	A92#142	16	TN	3574285C1
59	A97WC	18	PL	2003343C1
60	-	-	-	-
61^^	A77G	18	LTGN	2003343C1
61!	A77F	14	LTGN	3574285C1
62	A99D	18	VT	2003343C1
63	A99F	18	PL	2003343C1
64	A77C	18	GY	3574289C1
65	-	-	-	-
66	A90P	18	GY	3574289C1
67	A90C	18	GY	3574289C1
68	A90F	18	GY	3574289C1
69	A37C	18	TN	3574289C1
70-71	-	-	-	-
72	A5A(+)	18	YL	3574289C1
73	A5A(-)	18	GN	3574289C1
74	A37B	14	TN	3574288C1
75	A37A	12	TN	3574287C1
76	A36CB	10	TN	3574287C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A17B	12	RD	3574287C1
2-10	-	-	-	-
11*	A94BP	12	GY	3574287C1
11#	A94BP	16	GY	3574288C1
11	A94A	12	GY	3574287C1
12	A90	10	GY	3574287C1
13	A94L	10	GY	3574287C1
14	A37K	14	TN	3574285C1
15	A37J	14	TN	3574285C1
16	A37H	14	TN	3574285C1
17	A37F	14	TN	3574285C1
18	-	-	-	-
19	A17B	16	PK	3574285C1
20!	A26	16	GY	3574285C1
20^	A26	18	TN	2003343C1
21	A97UA	18	VT	2003343C1
22	A71#165	18	TN	2003343C1

Legend: @@ N/0508108 - NOT MTA FUSE BLOCK ; * W/BENDIX AIR ABS-8 ; # W/PARKING BRAKE ALRAM ; ! W/300 AMP AMMETER N/CROSSING GATE ; ^ W/300 AMP AMMETER W/CROSSING GATE ; + W/500K DATA LINK BASIC W/ZONAR ; & W/DATA LINK BASIC W/LCT ; % W/IGNITION PARK BRAKE ; %% W/CE BUS WHEEL CHAIR LIFT

20.86. CONNECTOR COMPOSITES *@(1702), P. 55 | Figure 966 CONNECTOR COMPOSITES *@(1702) | printed page 966

CAV	CIRCUIT	GA	COLOR	TERMINAL
11	A89LB	14	OR	3549416C1
12	A89JJ	14	OR	3549416C1
13	A89RB	14	OR	3549416C1
14*	A122A	18	GY	3549418C1
14&	A122A	16	GY	3549417C1
15*	A122B	18	GY	3549418C1
15&	A122B-G	16	WH	3549417C1
16^	A74P	18	LTGN	3549418C1
16%	A74H	18	LTGN	3549418C1
16#	A74A	16	LTGN	3549417C1
17@	A74P	16	RD	3549417C1
17^	A74H	18	LTGN	3549418C1
17%	A74L	16	LTGN	3549417C1
18!	A5T(+)	18	YL	3549418C1
18!!	A5T(-)	18	GN	3549418C1
19!	A5T(-)	18	GN	3549418C1
19!!	A5T(+)	18	YL	3549418C1
20##	A133A	18	LTGN	3549418C1
20@@	A133A	16	LTGN	3549417C1
20%%	A120JA	16	LTGN	3549417C1
21*^	A120FB	18	LTGN	3549418C1
21&^	A120FF	18	LTGN	3549418C1
21&#	A120FT	18	LTGN	3549418C1
22	A120H	18	LTGN	3549418C1
23	A44D	18	GY	3549418C1
24	A44F	18	GY	3549418C1
25	A86A	18	LTGN	3549418C1
26	A86B	16	LTGN	3549416C1
27	A86R(-)	18	LTGN	3549418C1
28	A86R(+)	18	LTGN	3549418C1
29	A86L(-)	18	LTGN	3549418C1
30	A86L(+)	18	LTGN	3549418C1
31^^	A74B	16	RD	3549417C1
31&&	A74	16	LTGN	3549417C1
32	A74C	18	LTGN	3549418C1
33	A74D	18	LTGN	3549418C1
34	A120AV	16	LTGN	3549417C1
35	A86C	18	LTGN	3549418C1
36	A86D	18	LTGN	3549418C1
37**	A122H	18	GY	3549418C1
37*&	A122J	18	GY	3549418C1
38*%	A14LA	18	RD	3549418C1
38*#	A88BAT	18	LTGN	3549418C1
39*%	A13LA	18	PK	3549418C1
39*#	A88IGN	18	LTGN	3549418C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A9D	16	GY	3549416C1
2	A76AA	14	LTGN	3549416C1
3	A76AB	14	LTGN	3549416C1
4	A132	14	GY	3549416C1
5	A132A	14	GY	3549416C1
6	A58B	14	BN	3549416C1
7	A89RF	14	OR	3549416C1
8	A89ZZ	14	OR	3549416C1
9	A89SS	14	OR	3549416C1
10	A89LF	14	OR	3549416C1

20.87. CONNECTOR COMPOSITES @@(1702), P. 56 | Figure 967 CONNECTOR COMPOSITES @@(1702) | printed page 967

CAV	CIRCUIT	GA	COLOR	TERMINAL
40!!	A152X	18	GY	3549418C1
40*@	A82A	18	GY	3549418C1
41!!	A152W	18	GY	3549418C1
41*@	A82B	18	GY	3549418C1
42	A89HH	18	VT	3549418C1
43	A67A	18	GY	3549418C1
44*!	A44	16	GY	3549417C1
44^*	A44	18	GY	3549418C1
45^*	A14PK	18	RD	3549418C1
45^%	A100A	18	GY	3549418C1
46	A100B	18	GY	3549418C1
47	A77R	18	LTGN	3549418C1
48	A77AA	18	LTGN	3549418C1
49	A41A	16	TN	3549417C1
50	A117A	18	GY	3549418C1
51	-	-	-	-
52	A117B	18	GY	3549418C1
53	A62AN	18	DKBL	3549418C1
54^&	A120EE	16	LTGN	3549417C1
54^#	A120EE	18	LTGN	3549418C1
55^!	A120AP	16	LTGN	3549417C1
55&*	A120AP	18	LTGN	3549418C1
56	A119AS	18	GY	3549418C1
57	A89H	18	OR	3549418C1
58	A89DD	18	OR	3549418C1
59&^	A123F	18	GY	3549418C1
59&%	A123J	18	GY	3549418C1
60	A89KK	18	OR	3549418C1
61	A120FG	18	LTGN	3549418C1
62	A13AB	18	PK	3549418C1
63	-	-	-	-
64	A56C	14	YL	3549416C1
65	A57C	14	LTGN	3549416C1
66	A76AF	14	LTGN	3549416C1
67	A76AH	14	LTGN	3549416C1
68	A76AD	14	LTGN	3549416C1
69	A76AE	14	LTGN	3549416C1
70	A10LA	18	WH	3574277C1
71*%	A10LS	18	WH	3574277C1
71&#	A12AY	18	GY	3574277C1
72	A89YY	14	OR	3549416C1
73	A120C	16	LTGN	3549416C1
74	A120D	16	LTGN	3549416C1
75	A133	16	LTGN	3549416C1
76	A117E	18	GY	3574277C1

20.88. CONNECTOR COMPOSITES @@(1702), P. 56A
Figure 968 CONNECTOR COMPOSITES @@(1702)

20.88. CONNECTOR COMPOSITES @@(1702), P. 56A | Figure 968 CONNECTOR COMPOSITES @@(1702) | printed page 968

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A9D	16	GY	3549416C1
2	A76AA	14	LTGN	3549416C1
3	A76AB	14	LTGN	3549416C1
4	A132	14	GY	3549416C1
5	A132A	14	GY	3549416C1
6	A58B	14	BN	3549416C1
7	A89RF	14	OR	3549416C1
8	A89ZZ	14	OR	3549416C1
9	A89SS	14	OR	3549416C1
10	A89LF	14	OR	3549416C1
11	A89LB	14	OR	3549416C1
12	A89JJ	14	OR	3549416C1
13	A89RB	14	OR	3549416C1
14*	A122A	18	GY	3549418C1
14+	A122A	16	GY	3549417C1
15*	A122B	18	GY	3549418C1
15+	A122B-G	16	WH	3549417C1
16#	A74P	18	LTGN	3549418C1
16@	A74H	18	LTGN	3549418C1
16!	A74A	16	LTGN	3549417C1
17&	A74P	16	RD	3549417C1
17#	A74H	18	LTGN	3549418C1
17@	A74L	18	LTGN	3549418C1
17%	A74L	16	LTGN	3549417C1
18	A5T(+)	18	YL	3549418C1
19	A5T(-)	18	GN	3549418C1
20*%	A133A	18	LTGN	3549418C1
20*&	A133A	16	LTGN	3549417C1
20*#	A120JA	16	LTGN	3549417C1
21	A120F	18	LTGN	3549418C1
22	A120H	18	LTGN	3549418C1
23	A44D	18	GY	3549418C1
24	A44F	18	GY	3549418C1
25	A86A	18	LTGN	3549418C1
26	A86B	16	LTGN	3549416C1
27**	A86R(-)	18	LTGN	3549418C1
27*!	A86RR-	18	LTGN	3549418C1
28**	A86R(+)	18	LTGN	3549418C1
28*!	A86RR+	18	LTGN	3549418C1
29**	A86L(-)	18	LTGN	3549418C1
29*!	A86LR-	18	LTGN	3549418C1
30**	A86L(+)	18	LTGN	3549418C1
30*!	A86LR+	18	LTGN	3549418C1
31*!	A86LF+	18	LTGN	3549418C1
31&&	A74B	16	RD	3549417C1
31&%	A74	16	LTGN	3549417C1
32*!	A86LF-	18	LTGN	3549418C1
32&&	A74C	18	LTGN	3549418C1
33*!	A86RF+	18	LTGN	3549418C1
33&&	A74D	18	LTGN	3549418C1
34*!	A86RF-	18	LTGN	3549418C1
34&^	A120AV	16	LTGN	3549417C1
35	A86C	18	LTGN	3549418C1
36	A86D	18	LTGN	3549418C1
37	A122AR	18	GY	3549418C1
38&+	A144A	18	GY	3549418C1

Legend: CHART CONTINUE ON SHEET_56B ; CIRCUIT DIAGRAM, BE,CE BUS MODELS, ; NO. DATE ; 22JUL21 AE08090671 56A

20.89. CONNECTOR COMPOSITES @@(1702), P. 56B | Figure 969 CONNECTOR COMPOSITES @@(1702) | printed page 969

CAV	CIRCUIT	GA	COLOR	TERMINAL
39#^	A13LA	18	PK	3549418C1
39&!	A88IGN	18	LTGN	3549418C1
40!!	A152X	18	GY	3549418C1
40!#	A82A	18	GY	3549418C1
41!!	A152W	18	GY	3549418C1
41!#	A82B	18	GY	3549418C1
42	A89HH	18	PL	3549418C1
43!@	A84A	16	LTGN	3549417C1
43!+	A67A	18	GY	3549418C1
44!%	A137A	18	LTBL	3549418C1
44%%	A44	16	GY	3549417C1
45	A100A	18	GY	3549418C1
46	A100B	18	GY	3549418C1
47	A77R	18	LTGN	3549418C1
48	A77AA	18	LTGN	3549418C1
49	A41A	16	TN	3549417C1
50	A117A	18	GY	3549418C1
51	A82V	16	GY	3549416C1
52	A117B	18	GY	3549418C1
53	A62A	18	DKBL	3549418C1
54%^	A120EE	16	LTGN	3549417C1
54%+	A120EE	18	LTGN	3549418C1
55%&	A120AP	16	LTGN	3549417C1
55%#	A120AP	18	LTGN	3549418C1
56%@	A119L	18	GY	3549418C1
56%!	A119A	18	GY	3549418C1
57	A89H	18	OR	3549418C1
58	A89DD	18	OR	3549418C1
59##	FA123F	18	GY	3549418C1
59#!	FB123J	18	GY	3549418C1
60	A89KK	18	OR	3549418C1
61	A120F	18	LTGN	3549418C1
62	A13AB	18	PK	3549418C1
63	-	-	-	-
64	A56C	14	YL	3549416C1
65	A57C	14	LTGN	3549416C1
66	A76AF	14	LTGN	3549416C1
67	A76AH	14	LTGN	3549416C1
68	A76AD	14	LTGN	3549416C1
69	A76AE	14	LTGN	3549416C1
70#^	A10LA	18	WH	3574277C1
70	A137A	18	LTBL	3574277C1
71#^	A10LS	18	WH	3574277C1
71#*	A12A	18	GY	3574277C1
72	A89YY	14	OR	3549416C1
73	A120C	16	LTGN	3549416C1
74	A120D	16	LTGN	3549416C1
75	A133	16	LTGN	3549416C1
76	A117E	18	GY	3574277C1

20.90. CONNECTOR COMPOSITES @@(1702), P. 56C
Figure 970 CONNECTOR COMPOSITES @@(1702)

20.90. CONNECTOR COMPOSITES @@(1702), P. 56C | Figure 970 CONNECTOR COMPOSITES @@(1702) | printed page 970

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A9D	16	GY	3549416C1
2	A76AA	14	LTGN	3549416C1
3	A76AB	14	LTGN	3549416C1
4	A132	14	GY	3549416C1
5	AL132A	14	GY	3549416C1
6	A58B	14	BN	3549416C1
7	A89RF	14	OR	3549416C1
8	A89ZZ	14	OR	3549416C1
9	A89SS	14	OR	3549416C1
10	A89LF	14	OR	3549416C1
11	A89LB	14	OR	3549416C1
12	A89JJ	14	OR	3549416C1
13	AJ89RB	14	OR	3549416C1
14*	A122A	18	GY	3549418C1
14+	A122A	16	GY	3549417C1
15*	A122B	18	GY	3549418C1
15+	A122B-G	16	WH	3549417C1
16-17	-	-	-	-
18	A5T(+)	18	YL	3549418C1
19	A5T(-)	18	GN	3549418C1
20#	A133A	18	LTGN	3549418C1
20@	A133A	16	LTGN	3549417C1
20!	A120AJ	16	LTGN	3549417C1
21	A120F	18	LTGN	3549418C1
22	A120H	18	LTGN	3549418C1
23	A44D	18	GY	3549418C1
24	A44F	18	GY	3549418C1
25	A86A	18	LTGN	3549418C1
26	A86B	16	LTGN	3549416C1
27	A86R(-)	18	LTGN	3549418C1
28	A86R(+)	18	LTGN	3549418C1
29	A86L(-)	18	LTGN	3549418C1
30	A86L(+)	18	LTGN	3549418C1
31-33	-	-	-	-
34	A120AV	16	LTGN	3549417C1
35	A86C	18	LTGN	3549418C1
36	A86D	18	LTGN	3549418C1
37%	A122H	18	GY	3549418C1
37^	A122J	18	GY	3549418C1
38	A88BAT	18	LTGN	3549418C1
39	A88IGN	18	LTGN	3549418C1
40	A152X	18	GY	3549418C1
41	A152W	18	GY	3549418C1
42	A89HH	18	PL	3549418C1
43	A67A	18	GY	3549418C1
44	A44	18	GY	3549418C1
45+	A14PK	18	RD	3549418C1
45**	A100A	18	GY	3549418C1
46	A100B	18	GY	3549418C1
47	A177R	18	LTGN	3549418C1
48	A77AA	18	LTGN	3549418C1
49	-	-	-	-
50	A117A	18	GY	3549418C1
51	-	-	-	-
52	A117B	18	GY	3549418C1
53	A62A	18	DKBL	3549418C1

Legend: CHART CONTINUED ON SHEET_56D ; CIRCUIT DIAGRAM, BE,CE BUS MODELS, ; DATE ; 22JUL21 AE08090671 56C

20.91. CONNECTOR COMPOSITES @@(1702), P. 56D
Figure 971 CONNECTOR COMPOSITES @@(1702)

20.91. CONNECTOR COMPOSITES @@(1702), P. 56D | Figure 971 CONNECTOR COMPOSITES @@(1702) | printed page 971

CAV	CIRCUIT	GA	COLOR	TERMINAL
54*&	A120EE	16	LTGN	3549417C1
54*^	A120EE	18	LTGN	3549418C1
55*%	A120AP	16	LTGN	3549417C1
55*#	A120AP	18	LTGN	3549418C1
56	A119A	18	GY	3549418C1
57	A89H	18	OR	3549418C1
58	AL89DD	18	OR	3549418C1
59*!	A123F	18	GY	3549418C1
59!!	A123J	18	GY	3549418C1
60	A89KK	18	OR	3549418C1
61	A120F	18	LTGN	3549418C1
62	A13AB	18	PK	3549418C1
63	A44A	18	GY	3549418C1
64	A56C	14	YL	3549416C1
65	A57C	14	LTGN	3549416C1
66	A76AF	14	LTGN	3549416C1
67	A76AH	14	LTGN	3549416C1
68	A76AD	14	LTGN	3549416C1
69	A76AE	14	LTGN	3549416C1
70	A137A	18	LTBL	3574277C1
71	A12A	18	GY	3574277C1
72	A89YY	14	OR	3549416C1
73	A120C	16	LTGN	3549416C1
74	A120D	16	LTGN	3549416C1
75	A133	16	LTGN	3549416C1
76	A117E	16	GY	3549416C1

20.92. CONNECTOR COMPOSITES %%(1702), P. 57 | Figure 972 CONNECTOR COMPOSITES %%(1702) | printed page 972

Table: BODY COMPOSITE - MATING VIEW SHOWN

CAV	CIRCUIT	GA	COLOR	TERMINAL
16**	B74E	16	LT GN	3574285C1
16^	B74H	16	LTGN	3574285C1
16%	B74B	18	LTGN	2003343C1
16#	B74D	16	LTGN	3574285C1
16@	B74J	16	LTGN	3574285C1
16!	B74P	16	LTGN	3574285C1
16!!	B74S	16	LTGN	3574285C1
17^	B74L	16	LTGN	3574285C1
17%	B74D	18	LTGN	2003343C1
17#	B74C	16	LTGN	3574285C1
17!@	B74P	16	RD	3574285C1
18	B5B(+)	18	YL	2003343C1
19	B5B(-)	18	GN	2003343C1
20!#	B133A	18	LTGN	2003343C1
20%@	B120J	18	LTGN	2003343C1
20%!	B133L	18	LTGN	2003343C1
20##	B12C	16	LTGN	3574285C1
20#*	B14AF	16	RD	3574285C1
21	B120N	18	LTGN	2003343C1
22#^	B120W	18	LTGN	2003343C1
22#%	B120R	18	LTGN	2003343C1
23	B44C	18	GY	2003343C1
24	B44A	18	GY	2003343C1
25	B86J	16	LTGN	3574285C1
26	B86H	16	LTGN	3574288C1
27!^	B86W	16	LTGN	3574285C1
27@%	B86F	16	LTGN	3574285C1
28!^	B86V	16	LTGN	3574285C1
28@%	B86E	16	LTGN	3574285C1
29!^	B86S	16	LTGN	3574285C1
29@%	B86D	16	LTGN	3574285C1
30!^	B86T	16	LTGN	3574285C1
30@%	B86C	16	LTGN	3574285C1
31!*	B74B	16	LTGN	3574285C1
31&&	B74L	16	LTGN	3574285C1
32	B74C	18	LTGN	2003343C1
33	B74D	18	LTGN	2003343C1
34	B120AV	16	LTGN	3574285C1
35	B86B	16	LTGN	3574285C1
36	B86A	16	LTGN	3574285C1
37	B122J	18	GY	2003343C1
38^^	B144C	18	GY	2003343C1
38^*	B88BAT	18	LTGN	2003343C1
38^&	B14LS	18	RD	2003343C1
39^^	B144D	18	GY	2003343C1
39^*	B88IGN	18	LTGN	2003343C1
39^&	B13LS	18	PK	2003343C1
40	B152	18	GY	2003343C1
41	B152A	18	GY	2003343C1
42	B119B	18	GY	2003343C1
43	B67	18	GY	2003343C1
44	B101	18	TN	2003343C1
45#&	B100A	18	GY	2003343C1
45&*	B14F	18	RD	2003343C1
46	B100B	18	GY	2003343C1
47	B77C	18	LTGN	2003343C1
48	B77B	18	LTGN	2003343C1
49	B41L	18	TN	2003343C1
50	B12C	18	LTBL	2003343C1

Legend: CIRCUIT DIAGRAM, BE,CE BUS MODELS ; NO. DATE ; 24FEB20 AE08090671 057

Table: CONNECTOR 3595623C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B9L	16	GY	3574288C1
2	B76D	14	LTGN	3574288C1
3	B76C	14	LTGN	3574288C1
4	B132C	12	GY	3574287C1
5	B132B	12	GY	3574287C1
6	B58E	16	BN	3574288C1
7*	B89E	16	OR	3574288C1
7&	B89RF	14	OR	3574288C1
8	B89A	16	OR	3574288C1
9	B89D	16	OR	3574288C1
10*	B89G	16	OR	3574288C1
10&	B89LF	14	OR	3574288C1
11*	B89H	16	OR	3574288C1
11&	B89LB	14	OR	3574288C1
12*	B89B	16	OR	3574288C1
13*	B89F	16	OR	3574288C1
13&	B89RB	14	OR	3574288C1
14	B122A	18	GY	2003343C1
15	B122	18	GY	2003343C1

Legend: * W/PWL W/LT MONITOR W/+9 ; & W/PWL RED & BLUE ; ^ W/BOOSTER PUMP W/ESPAR HTR W/TIMER ; % W/WEBASTO FUEL FIRED HEATER W/TIMER ; # W/BOOS PUMP W/ CLNT HTR WIRED SEP W/ TIMER ; @ W/BOOS PUMP W/ FR MTD HTR W/ SMART TIMER ; ! W/ESPAR HTR W/TIMER PREWIRE ABOVE DRVR ; !! W/BSTR PUMP W/ FR HTR W/ TIMER IN ELEC PNL ; !@ W/FR HTR CTL BY TIMER BOOS PUMP BY SW

20.93. CONNECTOR COMPOSITES %%(1702), P. 58 | Figure 973 CONNECTOR COMPOSITES %%(1702) | printed page 973

CAV	CIRCUIT	GA	COLOR	TERMINAL
51	-	-	-	-
52	B117	18	GY	2003343C1
53	B62AM	18	DKBL	2003343C1
54!%	B120S	18	LTGN	2003343C1
54!&	B120AK	16	LTGN	3574285C1
54#@	B120K	18	LTGN	2003343C1
54#^	B120AM	18	LTGN	2003343C1
54@@	B120KB	18	LTGN	2003343C1
54@#	B120K	16	LTGN	3574285C1
55!&	B120AJ	16	LTGN	3574285C1
55^@	B120L	18	LTGN	2003343C1
55#^	B120AP	18	LTGN	2003343C1
56	B119M	18	GY	2003343C1
57	B123H	18	LTGN	2003343C1
58%&	B123E	18	LTGN	2003343C1
58%^	B123P	18	LTGN	2003343C1
59%#	B120F	18	LTGN	2003343C1
59&^	B120B	18	LTGN	2003343C1
59&%	B123RW	18	GY	2003343C1
60&#	B123A	18	GY	2003343C1
60&@	B123A	18	LTGN	2003343C1
60&!	B123A	18	OR	2003343C1
60@^	B123S	18	LTGN	2003343C1
60@&	B123W	18	GY	2003343C1
60@*	B123S	18	GY	2003343C1
60@!	B9X	18	GY	2003343C1
61	B120E	18	LTGN	2003343C1
62	B13A	16	PK	3574285C1
63	B44	18	GY	2003343C1
64^!	B56	16	OR	3574288C1
64%*	B56	16	YL	3574288C1
65^!	B57	16	OR	3574288C1
65%*	B57	16	LTGN	3574288C1
66	B76DLO	16	LTGN	3574288C1
67	B76DHI	14	LTGN	3574288C1
68#!	B76CLO	16	LTGN	3574288C1
68^#	B76DLO	16	LTGN	3574288C1
69#!	B76CHI	14	LTGN	3574288C1
69^#	B76DHI	14	LTGN	3574288C1
70	B137C	18	LT BL	3574289C1
70	B97AB	18	PL	3574289C1
70	B10LA	18	WH	3574289C1
71^&	B10LB	18	WH	3574289C1
71^%	B12SA	18	LTBL	3574289C1
71	B97AB-G	18	PL	3574289C1
72	B89C	16	OR	3574288C1
73	B12C	18	LTGN	3574289C1
74	B120K	18	LTGN	3574289C1
75	B133A	16	LTGN	3574288C1
76	B117	18	GY	3574289C1

20.94. CONNECTOR COMPOSITES @@(1702), P. 58A | Figure 974 CONNECTOR COMPOSITES @@(1702) | printed page 974

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A9L	16	GY	3574288C1
2	A76D	14	LTGN	3574288C1
3	A76C	14	LTGN	3574288C1
4	A132CV	12	GY	3574287C1
5	A132BN	12	GY	3574287C1
6	A58E	16	BN	3574288C1
7!	A89EB	16	OR	3574288C1
7@	A89E	16	OR	3574288C1
7#	A89RF	14	OR	3574288C1
8	A89AU	16	OR	3574288C1
9	A89DD	16	OR	3574288C1
10!	A89G	16	OR	3574288C1
10#	A89LF	14	OR	3574288C1
11!	A89HT	16	OR	3574288C1
11@	A89H	16	OR	3574288C1
11#	A89LB	14	OR	3574288C1
12	A89BA	16	OR	3574288C1
13!	A89FB	16	OR	3574288C1
13@	A89F	16	OR	3574288C1
13#	A89RB	14	OR	3574288C1
14%	A122AH	18	GY	2003343C1
15%	A122X	18	GY	2003343C1
16*	A74H	16	LTGN	3574285C1
16**	A74B	18	LTGN	2003343C1
16*+	A74D	16	LTGN	3574285C1
16*&	A74J	16	LTGN	3574285C1
16*^	A74P	16	LTGN	3574285C1
16*%	A74S	16	LTGN	3574285C1
17*	A74L	16	LTGN	3574285C1
17**	A74D	18	LTGN	2003343C1
17*+	A74C	16	LTGN	3574285C1
17++	A74P	16	RD	3574285C1
18	A5B(+)	18	YL	2003343C1
19	A5B(-)	18	GN	2003343C1
20*#	A133A	18	LTGN	2003343C1
20*@	A120J	18	LTGN	2003343C1
20*!	A133L	18	LTGN	2003343C1
20##	A12CF	16	LTGN	3574285C1
20#!	A12CX	16	LTGN	3574285C1
20#@	VF14AFH	16	RD	3574285C1
21	A120NH	18	LTGN	2003343C1
22#%	A120W	18	LTGN	2003343C1
22#^	A120R	18	LTGN	2003343C1
23	A44C	18	GY	2003343C1
24	A44A	18	GY	2003343C1
25	A86J	16	LTGN	3574285C1
26	A86H	16	LTGN	3574288C1
27#&	A86W	16	LTGN	3574285C1
27#*	A86F	16	LTGN	3574285C1
28#&	A86V	16	LTGN	3574285C1
28#*	A86E	16	LTGN	3574285C1
29#&	A86S	16	LTGN	3574285C1
29#*	A86D	16	LTGN	3574285C1
30#&	A86T	16	LTGN	3574285C1
30#*	A86C	16	LTGN	3574285C1
31%%	A74B	16	LTGN	3574285C1

Legend: CHART CONTINUED ON SHEET_58B ; CIRCUIT DIAGRAM, BE,CE BUS MODELS, ; DATE ; 23JUL21 AE08090671 58A

20.95. CONNECTOR COMPOSITES @@(1702), P. 58B
Figure 975 CONNECTOR COMPOSITES @@(1702)

20.95. CONNECTOR COMPOSITES @@(1702), P. 58B | Figure 975 CONNECTOR COMPOSITES @@(1702) | printed page 975

CAV	CIRCUIT	GA	COLOR	TERMINAL
43	A67	18	GY	2003343C1
44	A101	18	TN	2003343C1
45^^	A100A	18	GY	2003343C1
45^+	A14F	18	RD	2003343C1
46	A100B	18	GY	2003343C1
47	A77C	18	LTGN	2003343C1
48	A77B	18	LTGN	2003343C1
49	A41L	18	TN	2003343C1
50	A12C	18	LTBL	2003343C1
51	-	-	-	-
52	A117SD	18	GY	2003343C1
53	A62AM	18	DKBL	2003343C1
54&!	A120S	18	LTGN	2003343C1
54^#	A120AK	16	LTGN	3574285C1
54^@	A120K	18	LTGN	2003343C1
54#%	A120AM	18	LTGN	2003343C1
54&+	A120KB	18	LTGN	2003343C1
54&*	A120K	16	LTGN	3574285C1
55^#	A120AJ	16	LTGN	3574285C1
55&*	A120L	18	LTGN	2003343C1
55^!	A120AP	18	LTGN	2003343C1
56	A119M	18	GY	2003343C1
57	A123H	18	LTGN	2003343C1
58&#	A123EL	18	LTGN	2003343C1
58&@	A123P	18	LTGN	2003343C1
59&^	A120F	18	LTGN	2003343C1
59++	A120B	18	LTGN	2003343C1
59+*	A123RW	18	GY	2003343C1
60	A123A	18	GY	2003343C1
60	A123A	18	LTGN	2003343C1
60	A123A	18	OR	2003343C1
60	A123S	18	LTGN	2003343C1
60	A123W	18	GY	2003343C1
60	A123S	18	GY	2003343C1
60	A9X	18	GY	2003343C1
61	A120E	18	LTGN	2003343C1
62	A13AB	16	PK	3574285C1
63?*	A44V	18	GY	2003343C1
64?^	A56	16	OR	3574288C1
64?%	A56	16	YL	3574288C1
65?^	A57	16	OR	3574288C1
65?%	A57	16	LTGN	3574288C1
66?!	A76DLO	16	LTGN	3574288C1
66!?	A76DLO-B	16	LTGN	3574288C1
67?!	A76DHI	14	LTGN	3574288C1
67!?	A76DHI-B	14	LTGN	3574288C1
68%?	A76CLO	16	LTGN	3574288C1
68^?	A76DLO-A	16	LTGN	3574288C1
69%?	A76CHI	14	LTGN	3574288C1
69^?	A76DHI-A	14	LTGN	3574288C1
70	A10LA	18	WH	3574289C1
71%@	A10LB	18	WH	3574289C1
71?+	A12SA	18	LTBL	3574289C1
72	A89CA	16	OR	3574288C1
73	A12CP	18	LTGN	3574289C1
74	A120K	18	LTGN	3574289C1
75	A133A	16	LTGN	3574288C1
76	A117	18	GY	3574289C1

Legend: CIRCUIT DIAGRAM, BE,CE BUS MODELS, ; DATE ; 23JUL21 AE08090671 58B

CAV	CIRCUIT	GA	COLOR	TERMINAL
31%+	A74L	16	LTGN	3574285C1
32%%	A74C	18	LTGN	2003343C1
33	A74D	18	LTGN	2003343C1
34#@	A120AV	16	LTGN	3574285C1
34%@	A11A	18	WH	2003343C1
35	A86B	16	LTGN	3574285C1
36	A86A	16	LTGN	3574285C1
37	A122JA	18	GY	2003343C1
38%^	A144C	18	GY	2003343C1
38%#	A88BAT	18	LTGN	2003343C1
38%@	A14LS	18	RD	2003343C1
39%^	A144D	18	GY	2003343C1
39%#	A88IGN	18	LTGN	2003343C1
39%@	A13LS	18	PK	2003343C1
40	A152	18	GY	2003343C1
41	A152A	18	GY	2003343C1
42	A119B	18	GY	2003343C1

Legend: DATE ; INITIAL PRODUCTION A 96183U

20.96. CONNECTOR COMPOSITES @@(1703), P. 58C
Figure 976 CONNECTOR COMPOSITES @@(1703)

20.96. CONNECTOR COMPOSITES @@(1703), P. 58C | Figure 976 CONNECTOR COMPOSITES @@(1703) | printed page 976

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1*	B70	18	RD	3544884C1
A1&	B70	16	RD	3544884C1
A2	B12Y	16	LTBL	3544884C1
A3%	B71D	16	LTBL	3544884C1
A3^	B71B	16	LTBL	3544884C1
A3#	B71A	16	LTBL	3544884C1
A4@	B120D	18	LTGN	3544884C1
A4!	B120H	18	LTGN	3544884C1
A4+	B120M	18	LTGN	3544884C1
A4?	B120C	18	LTGN	3544884C1
A4**	B9D	18	GY	3544884C1
A5	B119N	18	GY	3544884C1
A6	-	-	-	-
A7	B122K	18	GY	3544876C1
A8	B44A	18	GY	3544876C1
A9	B44B	18	GY	3544876C1
A10*+	B125B	18	GY	3544884C1
A11*&	B71D	16	LTBL	3544884C1
A11*^	B71A	16	LTBL	3544884C1
A11*%	B71B	16	LTBL	3544884C1
A12*#	B122R	18	GY	3544884C1
A13*@	B145H	16	LTGN	3544884C1
A13*!	B5A(+)	18	YL	3544884C1
A13!!	B5A(+)	18	YL	3544884C1
A14*@	B145-G	16	WH	3544884C1
A14*!	B5A(-)	18	GN	3544884C1
A14!!	B5A(-)	18	GN	3544884C1
A15!@	B53D	16	YL	3544884C1
A15!#	B53A	16	YL	3544884C1
A15!%	B53AC	16	YL	3544884C1
A15!^	B53C	16	YL	3544884C1
B1!@	B53E	16	YL	3544884C1
B1!#	B53B	16	YL	3544884C1
B1!%	B53AD	16	YL	3544884C1
B2!&	B133J	18	LTGN	3544884C1
B2!*	B133N	18	LTGN	3544884C1
B3	B133K	18	LTGN	3544884C1
B3	B133M	18	LTGN	3544884C1
B4!+	B60BE	18	OR	3544884C1
B4!?	B60A	18	OR	3544884C1
B5	B128A	16	LTBL	3544884C1
B6	B128R	16	LTBL	3544884C1
B7!@	B85D	14	GY	3544877C1
B7?+	B125A	16	GY	3544876C1
B7?*	B85	16	GY	3544876C1
B7!#	B85B	16	GY	3544876C1
B7!%	B85AA	14	GY	3544877C1
B7!^	B85S	14	GY	3544877C1
B8!@	B85E	14	GY	3544877C1
B8?+	B125B	16	GY	3544876C1
B8?*	B85A	16	GY	3544876C1
B8!#	B85C	16	GY	3544876C1
B8!%	B85AB	14	GY	3544877C1
B8!^	B85T	14	GY	3544877C1
B9!@	B53G	14	YL	3544877C1
B9!#	B53C	16	YL	3544876C1

Legend: CHART CONTINUED ON SHEET_58D ; CIRCUIT DIAGRAM, BE,CE BUS MODELS, ; NO. DATE ; 26JUL21 AE08090671 58C

20.97. CONNECTOR COMPOSITES @@(1703), P. 58D
Figure 977 CONNECTOR COMPOSITES %%(1702)

20.97. CONNECTOR COMPOSITES @@(1703), P. 58D | Figure 977 CONNECTOR COMPOSITES %%(1702) | printed page 977

CAV	CIRCUIT	GA	COLOR	TERMINAL
B9!%	B53AA	14	YL	3544877C1
B9!^	B53D	14	YL	3544877C1
B10!@	B53H	16	YL	3544884C1
B10!#	B53F	16	YL	3544884C1
B10!%	B53AB	16	YL	3544884C1
B11?&	B66	16	YL	3544884C1
B11	B60BF	18	OR	3544884C1
B12	B5(+)	18	YL	3544884C1
B13	B5(-)	18	GN	3544884C1
B14?^	B171-G	16	WH	3544884C1
B14?%	B74E	18	LTGN	3544884C1
B14?#	B74M	16	LTGN	3544884C1
B15?@	B74D	16	LTGN	3544884C1
B15?!	B74P	16	LTGN	3544884C1
B15&&	B74F	16	LTGN	3544884C1
B15?%	B74C	18	LTGN	3544884C1
B15&^	B74L	16	LTGN	3544884C1
B15&%	B74L	18	LTGN	3544884C1
B15&#	B75C	18	LTGN	3544884C1
B15&!	B74D	18	LTGN	3544884C1

20.98. CONNECTOR COMPOSITES ##(1703), P. 59 | Figure 978 CONNECTOR COMPOSITES ##(1703) | printed page 978

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1*	A70LA	16	OR	3544886C1
A1&	A70BC	16	OR	3544886C1
A2^	A12AA	16	LTBL	3544886C1
A2%	A12A	16	LTBL	3544886C1
A3#	A71H	16	LTBL	3544886C1
A3@	A71H	16	OR	3544886C1
A4!	A120SK	16	LTGN	3544886C1
A4!!	A120E	16	LTGN	3544886C1
A5	A119F	18	GY	3544886C1
A6	A44C-G	18	WH	3544886C1
A7	A89CE	18	VT	3544880C1
A8**	A92EE	18	GY	3544880C1
A8!&	KD92E	18	TN	3544880C1
A8@@	A92E	18	GY	3544880C1
A9!*	A92F	18	TN	3544880C1
A9@@	A122A	18	GY	3544880C1
A9**	A122AB	18	GY	3544880C1
A10	A125K	18	GY	3544886C1
A11#	A71D	16	LTBL	3544886C1
A11*%	A71D	18	LTBL	3544886C1
A12	A44C	18	GY	3544886C1
A13	A5P(+)	18	YL	3544886C1
A14	A5P(-)	18	GN	3544886C1
A15	A53A	16	YL	3544886C1
B1	A53B	16	YL	3544886C1
B2	A133C	18	LTGN	3544886C1
B3	A133B	18	LTGN	3544886C1
B4@@	A60A	18	OR	3544886C1
B4@@	A57A	18	OR	3544886C1
B4&&	A57AS	18	OR	3544886C1
B5	A89ZX	18	OR	3544886C1
B6	A89RK	18	OR	3544886C1
B7^&	A85	16	GY	3544880C1
B7^!	A125A	16	GY	3544880C1
B8^&	A85A	16	GY	3544880C1
B8^!	A125B	16	GY	3544880C1
B9	A53C	14	YL	3544881C1
B10	A53F	16	YL	3544886C1

Legend: W/DIESEL B11@@ A56A 18 OR 3544886C1 ; B11&& A56AZ 18 OR 3544886C1 ; B12 A5NE(+) 18 YL 3544886C1 ; B12@@ A5N(+) 18 YL 3544886C1 ; B13 A5NE(-) 18 GN 3544886C1 ; B13@@ A5N(-) 18 GN 3544886C1 ; ENG B14&! A171JPS 18 GY 3544886C1 ; ENG B14^^ A74A 16 LTGN 3544886C1 ; B14@@ A171-G 16 WH 3544886C1

20.99. CONNECTOR COMPOSITES ##(1703), P. 60 | Figure 979 CONNECTOR COMPOSITES ##(1703) | printed page 979

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	B70	16	RD	3768611C1
A2	B12Y	16	LTBL	3768611C1
A3	B71AH	16	LTBL	3768611C1
A4%	B120D	18	LTGN	3768611C1
A4#	B120H	18	LTGN	3768611C1
A4@	B120M	18	LTGN	3768611C1
A4!	B120CG	18	LTGN	3768611C1
A4!!	B9D	18	GY	3768611C1
A5	B119N	18	GY	3768611C1
A6	-	-	-	-
A7	B122K	18	GY	3768608C1
A8	B44A	18	GY	3768608C1
A9	B44B	18	GY	3768608C1
A10^	B125BD	18	GY	3768611C1
A10*	B125B	18	GY	3768611C1
A11**	B71D	16	LTBL	3768611C1
A11*&	B71A	16	LTBL	3768611C1
A11*^	B71B	16	LTBL	3768611C1
A12	B122R	18	GY	3768611C1
A13	B5A(+)	18	YL	3768611C1
A14	B5A(-)	18	GN	3768611C1
A15*!	B53D	16	YL	3768611C1
A15&*	B53A	16	YL	3768611C1
A15&&	B53AC	16	YL	3768611C1
A15&^	B53C	16	YL	3768611C1
B1*!	B53E	16	YL	3768611C1
B1&*	B53B	16	YL	3768611C1
B1&&	B53AD	16	YL	3768611C1
B2&!	B133J	18	LTGN	3768611C1
B2%%	B133N	18	LTGN	3768611C1
B3&!	B133K	18	LTGN	3768611C1
B3%%	B133M	18	LTGN	3768611C1
B4%*	B60BE	18	OR	3768611C1
B4%#	B60AA	18	OR	3768611C1
B5	B128A	16	LTBL	3768611C1
B6	B128R	16	LTBL	3768611C1
B7^^	B125A	16	GY	3768608C1
B7^*	B85	16	GY	3768608C1
B7*!	B85D	14	GY	3768609C1
B7&*	B85B	16	GY	3768608C1
B7&&	B85AA	14	GY	3768609C1

20.100. CONNECTOR COMPOSITES **(1703), P. 61 | Figure 980 CONNECTOR COMPOSITES **(1703) | printed page 980

CAV	CIRCUIT	GA	COLOR	TERMINAL
B7&^	B85S	14	GY	3768609C1
B7*!	B125AK	16	GY	3768608C1
B8^^	B125B	16	GY	3768608C1
B8^*	B85A	16	GY	3768608C1
B8*!	B85E	14	GY	3768609C1
B8*!	B125BB	16	GY	3768608C1
B8&*	B85C	16	GY	3768608C1
B8&&	B85AB	14	GY	3768609C1
B8&^	B85T	14	GY	3768609C1
B9*!	B53G	14	YL	3768609C1
B9&*	B53C	16	YL	3768608C1
B9&&	B53AA	14	YL	3768609C1
B9&^	B53D	14	YL	3768609C1
B10*!	B53H	16	YL	3768611C1
B10&*	B53F	16	YL	3768611C1
B10&&	B53AB	16	YL	3768611C1
B11^&	B66	16	YL	3768611C1
B11%*	B60BF	18	OR	3768611C1
B12	B5(+)	18	YL	3768611C1
B13	B5(-)	18	GN	3768611C1
B14^!	B74N	16	LTGN	3768611C1
B14##	B74E	18	LTGN	3768611C1
B14#!	B74M	16	LTGN	3768611C1
B15#@	B74D	16	LTGN	3768611C1
B15^!	B74P	16	LTGN	3768611C1
B15##	B74C	18	LTGN	3768611C1
B15#&	B74L	16	LTGN	3768611C1
B15#*	B74L	18	LTGN	3768611C1
B15*	B75CS	18	LTGN	3768611C1
B15&	B74D	18	LTGN	3768611C1
B15#@	B74DA	16	LTGN	3768611C1

20.101. CONNECTOR COMPOSITES %(1703A), P. 61A
Figure 981 CONNECTOR COMPOSITES %(1703A)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.101. CONNECTOR COMPOSITES %(1703A), P. 61A / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, PART AE08090671 NO. RELEASE NO. 96183U 09SEP21 / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / ELEC PANEL/PLATFORM %(1703A) (LOCATED AT ELECTRICAL PANEL HARNESS) / CONNECTOR 3550638C1 / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / C D E / CAVITY CIRCUIT GA COLOR TERMINAL A B152A 18 GY 3544880C1 B B152F 18 GY 3544880C1 C B152L 18 GY 3544880C1 D B152G 18 GY 3544880C1 E B67-G 18 WH 3544880C1 / Figure 981 / CONNECTOR COMPOSITES %(1703A)

CIRCUIT	GA	COLOR	TERMINAL
B152A	18	GY	3544880C1
B152F	18	GY	3544880C1
B152L	18	GY	3544880C1
B152G	18	GY	3544880C1
B67-G	18	WH	3544880C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

20.102. CONNECTOR COMPOSITES %(1703C), P. 62 | Figure 982 CONNECTOR COMPOSITES %(1703C) | printed page 982

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1-A5	-	-	-	-
A6	A44E	18	GY	3768611C1
A7-A11	-	-	-	-
A12	A44E	18	GY	3768611C1
A13	A5AK(+)	18	YL	3768611C1
A14	A5AK(-)	18	LTGN	3768611C1
A15	A53D	16	GY	3768611C1
B1	A53D	16	GY	3768611C1
B2-B6	-	-	-	-
B7*	A85BR	16	GY	3768608C1
B7&	A125E	16	GY	3768608C1
B8*	A85BR	16	GY	3768608C1
B8&	A125E	16	GY	3768608C1
B9*	A53E	16	GY	3768608C1
B10	A53E	16	GY	3768611C1
B11	-	-	-	-
B12	A5AK(+)	18	YL	3768611C1
B13	A5AK(-)	18	LTGN	3768611C1
B14	A171PS	18	GY	3768611C1
B15	A171PS	18	GY	3768611C1

20.103. CONNECTOR COMPOSITES %(1703C), P. 63 | Figure 983 CONNECTOR COMPOSITES %(1703C) | printed page 983

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1-A5	-	-	-	-
A6%	A44E	18	GY	3544884C1
A7-A11	-	-	-	-
A12%	A44E	18	GY	3544884C1
A13%	A5AK(+)	18	YL	3544884C1
A14%	A5AK(-)	18	LTGN	3544884C1
A15%	A53D	16	GY	3544884C1
B1%	A53D	16	GY	3544884C1
B2-B6	-	-	-	-
B7*	A85B	16	GY	3544876C1
B7&	A125E	16	GY	3544876C1
B7#	A85B	16	GY	3544876C1
B7@	A85B	16	GY	3544876C1
B8*	A85B	16	GY	3544876C1
B8&	A125E	16	GY	3544876C1
B8#	A85B	16	GY	3544876C1
B8@	A85B	16	GY	3544876C1
B9%	A53E	16	GY	3544876C1
B10%	A53E	16	GY	3544884C1
B11	-	-	-	-
B12%	A5AK(+)	18	YL	3544884C1
B13%	A5AK(-)	18	LTGN	3544884C1
B14!	A171PS	18	GY	3544884C1
B15!	A171PS	18	GY	3544884C1

20.104. INTENTIONALLY LEFT BLANK, P. 64
Figure 984 Intentionally Left Blank

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.104. INTENTIONALLY LEFT BLANK, P. 64 / INTENTIONALLY LEFT BLANK / CHAPTER 20 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090671 NO. 95504E 24FEB20 / 360012 20OCT20 INITIAL PRODUCTION RELEASE. / INTENTIONALLY LEFT BLANK / Figure 984 / Intentionally Left Blank

20.105. CONNECTOR COMPOSITES *(1804), P. 65
Figure 985 CONNECTOR COMPOSITES *(1804)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.105. CONNECTOR COMPOSITES *(1804), P. 65 / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090671 NO. RELEASE NO. 95504E 24FEB20 / MJV0488 13SEP21 ADDED CIRC A97WC IN CAV E. / ACCELERATOR PEDAL *(1804) (LOCATED AT ACCELERATOR PEDAL) / CONNECTOR 1673744C1 / F E D C B A / Figure 985 / CONNECTOR COMPOSITES *(1804)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A99A	18	VT	2036586C1
B	A97R	18	VT	2036586C1
C	A97C	18	VT	2036586C1
D	A99D	18	VT	2036586C1
E#	A97WC	18	VT	2036586C1
E%	A97WC	18	PL	2036586C1
F	A99F	18	PL	2036586C1

20.106. INTENTIONALLY LEFT BLANK, P. 66
Figure 986 Intentionally Left Blank

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.106. INTENTIONALLY LEFT BLANK, P. 66 / INTENTIONALLY LEFT BLANK / CHAPTER 20 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090671 NO. 95504E 24FEB20 / 360012 20OCT20 INITIAL PRODUCTION RELEASE. / INTENTIONALLY LEFT BLANK / Figure 986 / Intentionally Left Blank

20.107. CONNECTOR COMPOSITES %(1809), %(1810), P. 67 | Figure 987 CONNECTOR COMPOSITES %(1809), %(1810) | printed page 987

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A9HA	18	GY	1661261C1
B	A89C	18	GY	1661261C1
C	-	-	-	-
D	A85B	18	GY	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	A56	18	OR	3571717C1
1&	A56	20	OR	3539213C1
2*	A57	18	OR	3571717C1
2&	A57	20	OR	3539213C1
3	A52C	20	YL	3539213C1
4	A102	20	YL	3539213C1
5	A82U	20	GY	3539213C1
6	A87-GA	18	WH	3571717C1
7	A9S	18	GY	3571717C1
8	A82S	20	GY	3539213C1
9-10	-	-	-	-
11	A82T	20	GY	3539213C1
12	A87-GC	18	GY	3571717C1

Legend: % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG ; AND W/F-2018-PROPANE/GASOLINE-ENG ; * W/REMOTE HAZARD SWITCH ; & N/REMOTE HAZARD SWITCH

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	A56AC	18	OR	3571717C1
1#	A56	20	OR	3539213C1
2*	A57	18	OR	3571717C1
2#	A57	20	OR	3539213C1
3	A52C	20	YL	3539213C1
4	A102	20	YL	3539213C1
5	A82U	20	GY	3539213C1
6	A87-GA	18	WH	3571717C1
7	A9S	18	GY	3571717C1
8	A82S	20	GY	3539213C1
9-10	-	-	-	-
11	A82T	20	GY	3539213C1
12	A87-GC	18	GY	3571717C1

Legend: % W/0508108 - MTA FUSE BLOCK ; * W/REMOTE HAZARD SWITCH ; # W/N/REMOTE HAZARD SWITCH

20.108. CONNECTOR COMPOSITES %(1811), %(1811A), %(1811B), P. 68
Figure 988 CONNECTOR COMPOSITES %(1811), %(1811A), %(1811B)

20.108. CONNECTOR COMPOSITES %(1811), %(1811A), %(1811B), P. 68 | Figure 988 CONNECTOR COMPOSITES %(1811), %(1811A), %(1811B) | printed page 988

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A40	18	GY	4147514C1
2	A9VC	18	GY	4147514C1
3	A6HB	18	GY	4147514C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1!	A40	18	GY	4147514C1
1#	A40	18	GY	4181248C1
2!	A9VC	18	GY	4147514C1
2#	A9VC	18	GY	4181248C1
3!	A6HB	18	GY	4147514C1
3#	A6HB	18	GY	4181248C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; ! W/F-2017/2021-ISB/B6.7-DIESEL ENG

CIRCUIT	GA	COLOR	TERMINAL
A40	18	GY	4147514C1
A9VC	18	GY	4147514C1
A6HB	18	GY	4147514C1

20.109. CONNECTOR COMPOSITES %(1812), %(1812A), %(1812A), P. 69 | Figure 989 CONNECTOR COMPOSITES %(1812), %(1812A), %(1812A) | printed page 989

CIRCUIT	GA	COLOR	TERMINAL
A40A	18	GY	4147514C1
A40A	18	GY	4181248C1
A9VE	18	GY	4147514C1
A9VE	18	GY	4181248C1
A6HA	18	GY	4147514C1
A6HA	18	GY	4181248C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; ! W/F-2017/2021-ISB/B6.7-DIESEL ENG

CIRCUIT	GA	COLOR	TERMINAL
A40A	18	GY	4147514C1
A40A	18	GY	4181248C1
A9VE	18	GY	4147514C1
A9VE	18	GY	4181248C1
A6HA	18	GY	4147514C1
A6HA	18	GY	4181248C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; ! W/F-2017/2021-ISB/B6.7-DIESEL ENG

CIRCUIT	GA	COLOR	TERMINAL
A40A	18	GY	4147514C1
A9VE	18	GY	4147514C1
A6HA	18	GY	4147514C1

Figure 990 CONNECTOR COMPOSITES %(1813), *(1814)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.110. CONNECTOR COMPOSITES %(1813), *(1814), P. 70 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090671 NO. RELEASE NO. 95504E 24FEB20 / CHAPTER 20 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / CONNECTOR 1661777C1 BODY LOCK 1661873C1 / AIR PARK BRAKE SWITCH %(1813) (LOCATED NEAR PARK BRAKE VALVE) / D A B C / BRAKE SWITCH *(1814) (LOCATED NEAR BRAKE PEDAL) / CONNECTOR 4184066C1 / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / B A / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A-B PLUG - - 2025431C1 - C A44CC 18 GY 3594831C1 3568570C1 D A9K 18 GY 3594831C1 3568570C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A A70F 18 RD 3766445C1 3554318C1 B A9VF 18 GY 3766445C1 3554318C1 / Figure 990 / CONNECTOR COMPOSITES %(1813), *(1814)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	A70F	18	RD	3766445C1	3554318C1
B	A9VF	18	GY	3766445C1	3554318C1

20.111. CONNECTOR COMPOSITES %(1823), %(1823A), P. 71
Figure 991 CONNECTOR COMPOSITES %(1823), %(1823A)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.111. CONNECTOR COMPOSITES %(1823), %(1823A), P. 71 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090671 NO. RELEASE NO. 95504E 24FEB20 / CHAPTER 20 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED R/D 1823 AND 1823A. / STOP LIGHT #1 CONNECTOR %(1823) (LOCATED IN PLATFORM HARNESS) / CONNECTOR 1661777C1 BODY LOCK 1661873C1 / D B A C / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK * W/BENDIX AIR ABS-6 & ABS-8 # W/BENDIX ABS-8 W/ESP/WINGMAN/FUSION / STOP LIGHT #1 CONNECTOR %(1823A) (LOCATED IN PLATFORM HARNESS) / CONNECTOR 1661777C1 BODY LOCK 1661873C1 / D B A C / % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG / CAVITY CIRCUIT GA COLOR TERMINAL SLEEVE/SLV A - - - 2025431C1 - B - - - 2025431C1 - C A70CA 18 OR 3594831C1 3568570C1 D A9VG 18 GY 3594831C1 1661872C1 / Figure 991 / CONNECTOR COMPOSITES %(1823), %(1823A)

CIRCUIT	GA	COLOR	TERMINAL
-	-	-	2025431C1
-	-	-	2025431C1
A70CA	18	OR	3594831C1
A9VG	18	GY	3594831C1

20.112. CONNECTOR COMPOSITES %(1824), %(1824A), P. 72
Figure 992 CONNECTOR COMPOSITES %(1824), %(1824A)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.112. CONNECTOR COMPOSITES %(1824), %(1824A), P. 72 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090671 NO. RELEASE NO. 95504E 24FEB20 / CHAPTER 20 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED R/D 1824A, REMOVED R/D 1823. / STOP LIGHT #2 CONNECTOR %(1824A) (LOCATED IN PLATFORM HARNESS) / CONNECTOR 1661777C1 BODY LOCK 1661873C1 / STOP LIGHT #2 CONNECTOR %(1824) (LOCATED IN PLATFORM HARNESS) / CONNECTOR 1661777C1 BODY LOCK 1661873C1 / D B A C / D B A C / % N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK * W/BENDIX AIR ABS-6 & ABS-8 # W/BENDIX ABS-8 W/ESP/WINGMAN/FUSION / CAVITY CIRCUIT GA COLOR TERMINAL SLEEVE/SLV A - - - 2025431C1 - B - - - 2025431C1 - C A70CB 18 OR 3594831C1 3568570C1 D A9VH 18 GY 3594831C1 1661872C1 / Figure 992 / CONNECTOR COMPOSITES %(1824), %(1824A)

CIRCUIT	GA	COLOR	TERMINAL
-	-	-	2025431C1
-	-	-	2025431C1
A70CB	18	OR	3594831C1
A9VH	18	GY	3594831C1

20.113. CONNECTOR COMPOSITES %(1826), %(1827), %(1828), P. 73 | Figure 993 CONNECTOR COMPOSITES %(1826), %(1827), %(1828) | printed page 993

CIRCUIT	GA	COLOR	TERMINAL
A44K-G1	14	WH	3548972C1
A40A1	18	GY	3548971C1
A40B1	18	GY	3548971C1
A40C1	18	GY	3548971C1
-	-	-	-
-	-	-	-
A59A1	18	GY	3548971C1
-	-	-	-
A59B1	18	GY	3548971C1
-	-	-	-
A59C1	18	GY	3548971C1
A5CA(-)	18	GN	3548971C1
-	-	-	-
A5CC(+)	18	YL	3548971C1
-	-	-	-
A44KA	14	PK	3548972C1
A44KB1	14	RD	3548972C1

CIRCUIT	GA	COLOR	TERMINAL
A44K-GA	14	WH	3548972C1
-	-	-	-
-	-	-	-
A5BL(-)	18	GN	3548971C1
-	-	-	-
A5BH(+)	18	YL	3548971C1
-	-	-	-
-	-	-	-
-	-	-	-
-	-	-	-
A44KC	14	RD	3548972C1

Legend: N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A92AB	18	TN	1661208C1
B	A92	18	TN	1661208C1

20.114. CONNECTOR COMPOSITES %(1829), %(1830), %(1832), P. 74
Figure 994 CONNECTOR COMPOSITES %(1829), %(1830), %(1832)

20.114. CONNECTOR COMPOSITES %(1829), %(1830), %(1832), P. 74 | Figure 994 CONNECTOR COMPOSITES %(1829), %(1830), %(1832) | printed page 994

CIRCUIT	GA	COLOR	TERMINAL
-	-	-	-
A44KB2	14	RD	INCLUDED
A44K-G2	14	WH	INCLUDED
A5BZ(+)	18	YL	INCLUDED
A5BW(-)	18	GN	INCLUDED

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	A62H	18	DKBL	0587578C1	1652325C1
B	A62-GE	18	WH	0587578C1	1652325C1
C*	A122AC	18	GY	0587578C1	3517771C1
C	A92E	18	TN	0587578C1	3517771C1
C#	A122A	18	GY	0587578C1	3517771C1
D	AR92F	18	TN	0587578C1	1652325C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; # N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG ; * W/0508108 - MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	A9HA	20	TN	3608497C1
3*	A89C	20	VT	3608497C1
3#	A89C	20	PL	3608497C1
4	A11-GE	20	WH	3608497C1
5-7	-	-	-	-
8	A62K	20	DKBL	3608497C1
9	A85B	20	GY	3608497C1
10	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; # N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG ; * W/0508108 - MTA FUSE BLOCK

20.115. CONNECTOR COMPOSITES !(1850), %(1908), %(1913), P. 75
Figure 995 CONNECTOR COMPOSITES !(1850), %(1908), %(1913)

20.115. CONNECTOR COMPOSITES !(1850), %(1908), %(1913), P. 75 | Figure 995 CONNECTOR COMPOSITES !(1850), %(1908), %(1913) | printed page 995

CAV	CIRCUIT	GA	COLOR	TERMINAL
1-2	-	-	-	-
3!	A62C	18	DKBL	3517243C1
4	-	-	-	-
5!	A#169A	18	GY	3517243C1
6-7	-	-	-	-
8!	A5K(+)	18	YL	3517243C1
8#	A5AH(+)	18	YL	3517243C1
8#	A5MN(+)	18	YL	3517243C1
9-10	-	-	-	-
11!	A134	18	WH	3517243C1
12!	A#163A	18	YL	3517243C1
13!	A#170A	18	PK	3517243C1
14	-	-	-	-
15#	A5AH(-)	18	GN	3517243C1
15#	A5MM(-)	18	GN	3517243C1
15!	A5K(-)	18	GN	3517243C1
16	-	-	-	-

Legend: # N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG ; ! W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; W/F-2017/2021-ISB/B6.7-DIESEL ENG

CIRCUIT	GA	COLOR	TERMINAL
A84A	16	LT GN	0188396R1
A84-G	16	WH	0188396R1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A132	14	GY	1661539C1
2	A132A	14	GY	1661539C1
3	-	-	-	-
4	A132A-G	14	WH	1661539C1

Figure 996 CONNECTOR COMPOSITES %(1935F), %(1935M)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.116. CONNECTOR COMPOSITES %(1935F), %(1935M), P. 76 / CHAPTER 20 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090671 NO. RELEASE NO. 95504E 24FEB20 / MJV0488 13SEP21 ADDED NOTES FOR FUSE B BLOCK. / J1939 RESISTOR 250K BODY %(1935F) (LOCATED IN INSTRUMENT PANEL) / CONNECTOR 1667741C1 BODY LOCK 1667771C1 / C B A / CONNECTOR 1667741C1 BODY LOCK 1667771C1 / C B A / J1939 RESISTOR 250K BODY %(1935M) (LOCATED IN INSTRUMENT PANEL) / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A A5C(+) 18 YL 1661875C1 3568570C1 B PLUG - - 2025431C1 - C A5C(-) 18 GN 1661875C1 3568570C1 / Figure 996 / CONNECTOR COMPOSITES %(1935F), %(1935M)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A#	A5A(+)	18	YL	1661875C1	3568570C1
A*	A5AT(+)	18	YL	1661875C1	3568570C1
B	PLUG	-	-	2025431C1	-
C#	A5A(-)	18	GN	1661875C1	3568570C1
C*	A5AT(-)	18	GN	1661875C1	3568570C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; * W/0508108 - MTA FUSE BLOCK ; # N/0508108 - NOT MTA FUSE BLOCK ; W/F-2017-ISB-ENG & W/F-2018-PROPANE ; /GASOLINE-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	A5C(+)	18	YL	1661875C1	3568570C1
B	PLUG	-	-	2025431C1	-
C	A5C(-)	18	GN	1661875C1	3568570C1

20.117. CONNECTOR COMPOSITES %(1939), %(1939D), %(1979B2), %(2016), P. 76A
Figure 997 CONNECTOR COMPOSITES %(1939), %(1939D), %(1979B2), %(2016)

20.117. CONNECTOR COMPOSITES %(1939), %(1939D), %(1979B2), %(2016), P. 76A | Figure 997 CONNECTOR COMPOSITES %(1939), %(1939D), %(1979B2), %(2016) | printed page 997

CIRCUIT	GA	COLOR	TERMINAL
A5N2C(+)	20	YL	3535302C1
A5N2C(-)	20	GN	3535302C1

Legend: % W/0508108 - MTA FUSE BLOCK

CIRCUIT	GA	COLOR	TERMINAL
C5D(+)	20	YL	4083870C1
C5D(-)	20	GN	4083870C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CIRCUIT	GA	COLOR	TERMINAL
-	-	-	-
C5B(-)	22	GN	4242907C1
C5E(-)	22	GN	4242907C1
-	-	-	-
C152	0.5	PK	4242907C1
C5B(+)	22	YL	4242907C1
C5E(+)	22	YL	4242907C1
C11COG	0.5	WH	4242907C1

Legend: % N/0508108 - NOT MTA FUSE BLOCK

CIRCUIT	GA	COLOR	TERMINAL
A17	16	PK	1661709C1
A17CA	18	LT GN	1661709C1
A17CC	18	WH	1659673C1
-	-	-	-
A17CB	18	BK	1659673C1
A17CA	18	LT GN	1659673C1

20.118. CONNECTOR COMPOSITES @(2502), P. 77
Figure 998 CONNECTOR COMPOSITES @(2502)

20.118. CONNECTOR COMPOSITES @(2502), P. 77 | Figure 998 CONNECTOR COMPOSITES @(2502) | printed page 998

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	PLUG	-	-	3573076C1
2	R47LS	18	GY	3613771C1
3	R14LS	18	RD	3613771C1
4	R5LSA	18	YL	3613771C1
5	R10LS	18	WH	3613771C1
6	R61SA	18	GY	3613771C1
7-8	PLUG	-	-	3573076C1
9	R70LS	18	OR	3613771C1
10	R13LS	18	PK	3613771C1
11	R5LSB	18	LTGN	3613771C1
12	R61SB	18	GY	3613771C1
13	R61SC	18	GY	3613771C1
14	PLUG	-	-	3573076C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	PLUG	-	-	3573076C1
2	M47LS	18	OR	3618272C1
3	M14LS	18	RD	3618272C1
4	M5LSA	18	YL	3618272C1
5	M10LS	18	WH	3618272C1
6	M61LSA	18	GY	3618272C1
7-8	PLUG	-	-	3573076C1
9	M70LS	18	OR	3618272C1
10	M13LS	18	PK	3618272C1
11	M5LSB	18	LTGN	3618272C1
12	M61LSB	18	GY	3618272C1
13	M61LSC	18	GY	3618272C1
14	PLUG	-	-	3573076C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

20.119. CONNECTOR COMPOSITES @(2503), @(2505), P. 78
Figure 999 CONNECTOR COMPOSITES @(2503), @(2505)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 20.119. CONNECTOR COMPOSITES @(2503), @(2505), P. 78 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090671 NO. RELEASE NO. 95504E 24FEB20 / CHAPTER 20 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / LIQUID SPRING FUSE HOLDER @(2503) (LOCATED NEAR TO FULL POWER CONN) / LIQUID SPRING POWER @(2505) (LOCATED IN FORWARD CHASSIS HARNESS NEAR TO REAR CONNECTOR) / LIQUID SPRING POWER @(2505) (LOCATED NEAR TO LIQUID SPRING REAR CHASSIS CONN) / CONNECTOR 3537133C1 / CONNECTOR 3515523C1 / CONNECTOR 3700151C1 / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A M14BA 8 RD 3525614C1 3515525C1 B M14BB 8 RD 3525614C1 3515525C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A M14BB 8 RD 3700154C1 3537135C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A R14B 8 RD 3700153C1 3537135C1 / Figure 999 / CONNECTOR COMPOSITES @(2503), @(2505)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M14BA	8	RD	3525614C1	3515525C1
B	M14BB	8	RD	3525614C1	3515525C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M14BB	8	RD	3700154C1	3537135C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R14B	8	RD	3700153C1	3537135C1

CONNECTOR COMPOSITE (2512-8903) (CHAPTER 21)
Figure 1000 CONNECTOR COMPOSITES *(2512), *(2513), @(2513), @(2514)

CONNECTOR COMPOSITE (2512-8903) (CHAPTER 21) | Figure 1000 CONNECTOR COMPOSITES *(2512), *(2513), @(2513), @(2514) | printed page 1000

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	A14LB	18	RD	1661875C1	3568570C1
B	A13LB	18	PK	1661875C1	3568570C1
C	A10LB	18	WH	1661875C1	3568570C1
D	A5AB	18	YL	1661875C1	3568570C1
E	A5BB	18	LTGN	1661875C1	3568570C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	A180-G	18	WH	3686943C1
2*	A5N(-)	18	GN	3686943C1
3^	A5N2A(-)	18	GN	3686943C1
4	PLUG	-	-	3833742C1
5*	A14BA	18	RD	3686943C1
6*	A5N(+)	18	YL	3686943C1
7^	A5N2A(+)	18	YL	3686943C1
8	PLUG	-	-	3833742C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; ^ W/0508108 - MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R10GB	18	WH	1661875C1	3568570C1
B	R61LI	18	GY	1661875C1	3568570C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; W/F-2017/2021-ISB/B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R10GA	18	WH	1661875C1	3568570C1
B	R61RI	18	TN	1661875C1	3568570C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; W/F-2017/2021-ISB/B6.7-ENG

21.2. CONNECTOR COMPOSITES @(2515), @(2516), @(2517), P. 2 | Figure 1001 CONNECTOR COMPOSITES @(2515), @(2516), @(2517) | printed page 1001

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R10GE	18	WH	1661875C1	3568570C1
B	R61D	18	LTGN	1661875C1	3568570C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	R13LS	18	PK	1651943C1
A2	PLUG	-	-	1687788C1
A3	R14LS	18	RD	1651943C1
B1	R5LSB	18	LTGN	1651943C1
B2	PLUG	-	-	1687788C1
B3	R61HLA	18	LTBL	1651943C1
C1	R5LSA	18	YL	1651943C1
C2	PLUG	-	-	1687788C1
C3	R61HRA	18	LTBL	1651943C1
D1-D2	PLUG	-	-	1687788C1
D3	R61HA	18	GY	1651943C1
E1-E3	PLUG	-	-	1687788C1
F1	PLUG	-	-	1687788C1
F2	R61HRB	18	YL	1651943C1
F3	R61HLB	18	TN	1651943C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	R61DA	18	GY	1651943C1
A2	R61SB	18	GY	1651943C1
A3	R70LS	18	OR	1651943C1
B1	PLUG	-	-	1687788C1
B2	R61SC	18	GY	1651943C1
B3	R10PS	18	GY	1651943C1
C1	PLUG	-	-	1687788C1
C2	R47LS	18	GY	1651943C1
C3	PLUG	-	-	1687788C1
D1	R61D	18	LTGN	1651943C1
D2	R61SA	18	GY	1651943C1
D3	R14BAA	16	RD	1651943C1
E1	R10LSB	18	WH	1651943C1
E2	R14BAB	16	RD	1651943C1
E3	R14BAC	16	RD	1651943C1
F1	R14BBA	16	RD	1651943C1
F2	R14LSD	16	RD	1651943C1
F3	R14BBB	16	RD	1651943C1
G1	R14LSE	16	RD	1651943C1
G2	R14LSF	16	RD	1651943C1
G3	R61LI	18	GY	1651943C1
H1	R14LSG	16	RD	1651943C1
H2	R14LSH	16	RD	1651943C1
H3	R61LR	18	BN	1651943C1
J1	PLUG	-	-	1687788C1
J2	R61RI	18	TN	1651943C1
J3	R61RR	18	LTGN	1651943C1
K1-K3	PLUG	-	-	1687788C1

Legend: DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 26FEB20 AE08090672 002

21.3. CONNECTOR COMPOSITES @(2521), @(2522), @(2523), @(2524), P. 3 | Figure 1002 CONNECTOR COMPOSITES @(2521), @(2522), @(2523), @(2524) | printed page 1002

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	R61HLC	18	GY	3522190C1	3522193C1
2	R61HLA	18	LTBL	3522190C1	3522193C1
3	R61HLB	18	TN	3522190C1	3522193C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	R61HLC	18	GY	3522190C1	3522193C1
2	R61HLA	18	LTBL	3522190C1	3522193C1
3	R61HLB	18	TN	3522190C1	3522193C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R61LR	18	BN	1661875C1	3568570C1
B	R10GD	18	WH	1661875C1	3568570C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; W/F-2017/2021-ISB/B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R61RR	18	LTGN	1661875C1	3568570C1
B	R10GC	18	WH	1661875C1	3568570C1

21.4. CONNECTOR COMPOSITES @(2526), @(2535), @(2536), @@(3201), P. 4 | Figure 1003 CONNECTOR COMPOSITES @(2526), @(2535), @(2536), @@(3201) | printed page 1003

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A5AA	18	YL	3614754C1
2	A5BA	18	LTGN	3614754C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M61LSC	18	GY	3522190C1	3522193C1
2	M61LSA	18	GY	3522190C1	3522193C1
3	M61LSB	18	GY	3522190C1	3522193C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R61DA	18	GY	1661875C1	3568570C1
B	R10LSA	18	WH	1661875C1	3568570C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	A9W	18	GY	1661224C1
1#	A9WA	18	GY	3541250C1
1#	A9W	18	GY	3541250C1
2	A120SK	18	LTGN	1661224C1
3	-	-	-	-
4#	A9WA	18	GY	1661224C1
4&	A123H	18	GY	1661224C1
5^	A123A	18	GY	1661224C1
5%	A123B	18	GY	1661224C1
6	-	-	-	-
7	A120-GM	18	WH	1661224C1
8@	A62LB	18	DKBL	3541250C1
8@	A62M	18	DKBL	3541250C1
9@	A62LB	18	DKBL	3541250C1
9@	A62N	18	DKBL	3541250C1
10	A62N	18	DKBL	1661224C1

21.5. CONNECTOR COMPOSITES %(3201), P. 4A | Figure 1004 CONNECTOR COMPOSITES %(3201) | printed page 1004

CAV	CIRCUIT	GA	COLOR	TERMINAL
1#	A9W	18	GY	3541250C1
1!	A9W	18	GY	1661224C1
1#	A9WA	18	GY	3541250C1
2	A120SK	18	LTGN	1661224C1
3	-	-	-	-
4#	A9WA	18	GY	1661224C1
4&	A123H	18	GY	1661224C1
5*	A123A	18	GY	1661224C1
5?	A123B	18	GY	1661224C1
6	-	-	-	-
7	A120-GM	18	WH	1661224C1
8^	A62L	18	DKBL	3541250C1
8^	A62M	18	DKBL	3541250C1
9^	A62L	18	DKBL	3541250C1
9^	A62N	18	DKBL	3541250C1
10	A62N	18	DKBL	1661224C1

Legend: % N/0508108 - NOT MTA FUSE BLOCK ; # W/W/3-POSITION DOOR SW ; ! W/SINGLE ROTARY DOOR SW ; ^ W/ROTARY DOOR SW ; & W/MASTER FLASHER SW NON SEQ 3POSITION ROTARY ; * W/NON-SEQ 3-POSITION ROTARY DOOR SW ; ? W/SEQ 3-POSITION ROTARY DOOR SW

21.6. CONNECTOR COMPOSITES @(3202A), @(3202B), @(3203), P. 5 | Figure 1005 CONNECTOR COMPOSITES @(3202A), @(3202B), @(3203) | printed page 1005

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A120C	16	LTGN	0239805R1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A120D	16	LTGN	0239805R1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1^	A120F	18	LTGN	1661224C1
1!	A120FA	18	LTGN	1661224C1
2	A9Z	18	GY	1661224C1
3	A120E	16	LTGN	1661226C1
4-6	-	-	-	-
7	A62-GN	18	WH	1661224C1
8	A62N	18	DKBL	1661224C1
9-10	-	-	-	-

21.7. CONNECTOR COMPOSITES *(4003), %(4006), *(4006), P. 6 | Figure 1006 CONNECTOR COMPOSITES *(4003), %(4006), *(4006) | printed page 1006

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K17UG	12	PK	6113343C1	6113346C1
2	K17UE	14	PK	6113342C1	6113345C1
3	PLUG	-	-	6113348C1	-
4	K17B	12	PK	6113343C1	6113346C1
5	K17UF	18	PK	4161136C1	6113345C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K17UG	12	PK	6113343C1	6113346C1
2	K17UE	14	PK	6113342C1	6113345C1
3	PLUG	-	-	6113348C1	-
4	K17B	12	PK	6113343C1	6113346C1
5	K17UF	18	PK	4161136C1	6113345C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	K14C	12	RD	1661708C1
A#	K94L	12	GY	1661708C1
B*	K94L	12	GY	1661708C1
B#	K90BB	12	GY	1661708C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; * W/HYD BRAKES ; # W/HYDROMAX HYD BRAKES

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K97PA	12	RD	1661708C1
B	K97PAB	12	VT	1661708C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

21.8. CONNECTOR COMPOSITES *(4007), P. 7 | Figure 1007 CONNECTOR COMPOSITES *(4007) | printed page 1007

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K97PC	10	RD	3752553C1	6113347C1
2	K97KD	18	RD	4161136C1	6113345C1
3	PLUG	-	-	6113348C1	-
4	K97PE	10	RD	3752553C1	6113347C1
5	K97KE	18	VT	4161136C1	4154668C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K14FHB	10	RD	3752553C1	6113347C1
2	K13FB	18	PK	4161136C1	6113345C1
3	PLUG	-	-	6113348C1	-
4	K14FHC	10	RD	3752553C1	6113347C1
5	K97-GFA	18	WH	4161136C1	4154668C1

Figure 1008 CONNECTOR COMPOSITES %(4011)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.9. CONNECTOR COMPOSITES %(4011), P. 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090672 NO. RELEASE NO. 95504E 26FEB20 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 REMOVED R/D 4009. ADDED NOTES FOR FUSE BLOCK. / PRESSURE LINE HEATER RELAY %(4011) (LOCATED AT ENGINE COMPARTMENT) / CONNECTOR 4153703C1 BODY LOCK 4154206C1 / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / Figure 1008 / CONNECTOR COMPOSITES %(4011)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K14KA	18	RD	4161136C1	4154668C1
2	K14HB	18	RD	4161136C1	4154668C1
3	PLUG	-	-	6113348C1	-
4	K95PA	18	TN	4161136C1	4154668C1
5	K95VC	18	TN	4161136C1	4154668C1

21.10. CONNECTOR COMPOSITES *(4011), %(4012), P. 9 | Figure 1009 CONNECTOR COMPOSITES *(4011), %(4012) | printed page 1009

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K37DS	12	TN	6113343C1	6113346C1
2	K37DC	18	TN	4161136C1	6113345C1
3	PLUG	-	-	6113348C1	-
4	K37D	14	RD	6113342C1	4154670C1
5	K10D-G	18	WH	4161136C1	6113345C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; W/F-2018-GASOLINE-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K37DS	12	TN	6113343C1	6113346C1
2	K37DC	18	TN	4161136C1	6113345C1
3	PLUG	-	-	6113348C1	-
4	K37D	14	RD	6113342C1	4154670C1
5	K10D-G	18	WH	4161136C1	6113345C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; W/F-2018-PROPANE-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K14KB	18	RD	4161136C1	4154668C1
2	K14HC	18	RD	4161136C1	4154668C1
3	PLUG	-	-	6113348C1	-
4	K95SA	18	TN	4161136C1	4154668C1
5	K95VB	18	TN	4161136C1	4154668C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ;
W/F-2017-ISB-ENG,F-2021-B6.7-ENG

21.11. CONNECTOR COMPOSITES %(4013), %(4014), *(4015), P. 10 | Figure 1010 CONNECTOR COMPOSITES %(4013), %(4014), *(4015) | printed page 1010

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K14KC	18	RD	4161136C1	4154668C1
2	K14HD	18	RD	4161136C1	4154668C1
3	PLUG	-	-	6113348C1	-
4	K95RA	18	TN	4161136C1	4154668C1
5	K95VA	20	TN	4161136C1	4154668C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K14P	14	RD	6113342C1	4154670C1
2	K97UD	18	RD	4161136C1	4154668C1
3	PLUG	-	-	6113348C1	-
4	K95XH	14	RD	6113342C1	4154670C1
5	K23-G1	20	TN	4161136C1	4154668C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K39A	14	GY	6113342C1	4154670C1
2	K13F	18	PK	4161136C1	6113345C1
3	PLUG	-	-	6113348C1	-
4	K39D	14	GY	6113342C1	4154670C1
5	K10-GAB	14	WH	6113342C1	4154670C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; W/F-2018-GASOLINE-ENG

21.12. CONNECTOR COMPOSITES *(4015), *(4016), P. 11 | Figure 1011 CONNECTOR COMPOSITES *(4015), *(4016) | printed page 1011

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K39A	14	GY	6113342C1	4154670C1
2	K13F	18	PK	4161136C1	6113345C1
3	PLUG	-	-	6113348C1	-
4	K39D	14	GY	6113342C1	4154670C1
5	K10-GAB	14	WH	6113342C1	4154670C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; W/F-2018-PROPANE-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K39A	14	GY	6113342C1	4154670C1
2	K13FC	18	PK	4161136C1	6113345C1
3	PLUG	-	-	6113348C1	-
4	K39D	14	GY	6113342C1	4154670C1
5	K10-GAB	18	WH	4161136C1	4154668C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K37CS	14	TN	6113342C1	4154670C1
2	K37CC	18	TN	4161136C1	6113345C1
3	PLUG	-	-	6113348C1	-
4	K37C	14	RD	6113342C1	4154670C1
5	K10C-G	18	WH	4161136C1	6113345C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; W/F-2018-PROPANE-ENG

21.13. CONNECTOR COMPOSITES *(4017), *(4018), *(4019), P. 12 | Figure 1012 CONNECTOR COMPOSITES *(4017), *(4018), *(4019) | printed page 1012

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K97PB	12	RD	1661708C1
B	K97PBB	12	VT	1661708C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K14B	14	RD	1661707C1
B	K39A	14	GY	1661707C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K77B	14	RD	6113342C1	6113345C1
2	K77D	18	RD	4161136C1	6113345C1
3	PLUG	-	-	6113348C1	-
4	K77E	16	LTGN	6113342C1	6113345C1
5	K77F	18	LTGN	4161136C1	4154668C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K77BB	14	RD	6113342C1	6113345C1
2	K77DB	18	RD	4161136C1	6113345C1
3	PLUG	-	-	6113348C1	-
4	K77EB	16	LTGN	6113342C1	6113345C1
5	K77FB	18	LTGN	4161136C1	4154668C1

Figure 1013 CONNECTOR COMPOSITES *(4034), *(4036), *(4037)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.14. CONNECTOR COMPOSITES *(4034), *(4036), *(4037), P. 13 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090672 NO. RELEASE NO. 95504E 04MAR20 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / LOW HYD FLUID LEVEL *(4034) (LOCATED OUTSIDE CENTER TOP DASH PANEL) / 2 1 / CONNECTOR 3554317C1 / 1 2 3 / HYD BRAKE SWITCH *(4036) (LOCATED INSIDE ENGINE COMPARTMENT) / CONNECTOR 3522187C1 / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / HYDROMAX BRAKE PRESSURE *(4037) (LOCATED INSIDE ENGINE COMPARTMENT) / CONNECTOR 3854645C91 / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 K90B 18 GY 3522190C1 3522193C1 2 K90C 18 GY 3522190C1 3522193C1 3 PLUG - - 3522197C1 - / CAV CIRCUIT GA COLOR TERMINAL 1 K90H 16 GY 3572625C1 2 K90X 14 GY 3711481C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 K90-G 18 GY 3554322C1 3554318C1 2 K90H 18 GY 3554322C1 3554318C1 / Figure 1013 / CONNECTOR COMPOSITES *(4034), *(4036), *(4037)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K90-G	18	GY	3554322C1	3554318C1
2	K90H	18	GY	3554322C1	3554318C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K90B	18	GY	3522190C1	3522193C1
2	K90C	18	GY	3522190C1	3522193C1
3	PLUG	-	-	3522197C1	-

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K90H	16	GY	3572625C1
2	K90X	14	GY	3711481C1

21.15. CONNECTOR COMPOSITES *(4037), *(4038), #(4039), P. 14
Figure 1014 CONNECTOR COMPOSITES *(4037), *(4038), #(4039)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.15. CONNECTOR COMPOSITES *(4037), *(4038), #(4039), P. 14 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090672 NO. RELEASE NO. 95504E 04MAR20 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED R/D 4039 AND NOTES FOR FUSE BLOCK. / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2018-PROPANE-ENG,W/F-2018-GASOLINE-ENG / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / CONNECTOR 3854645C91 / HYDROMAX BRAKE PRESSURE *(4037) (LOCATED INSIDE ENGINE COMPARTMENT) / B A / HYDROMAX FLOW SWITCH *(4038) (LOCATED IN ENGINE COMPARTMENT) / CONNECTOR 2036584C1 / B A / HYDROMAX FLOW SWITCH *(4038) (LOCATED INSIDE ENGINE COMPARTMENT) / CONNECTOR 2036584C1 / HYDROMAX DIFF PRESSURE #(4039) (LOCATED IN POWETRAIN HARNESS) / CONNECTOR 3518873C91 / # W/COMMON FOR W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / A B / CAV CIRCUIT GA COLOR TERMINAL 1 K90H 16 GY 3572625C1 2 K90X 14 GY 3711481C1 / CAV CIRCUIT GA COLOR TERMINAL A K90CC 16 GY 2036586C1 B K90-GA 16 WH 2036586C1 / CAV CIRCUIT GA COLOR TERMINAL A [K90CB] 16 - V-TERM B [K90D] 16 - V-TERM / Figure 1014 / CONNECTOR COMPOSITES *(4037), *(4038), #(4039)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K90H	16	GY	3572625C1
2	K90X	14	GY	3711481C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K90CC	16	GY	2036586C1
B	K90-GA	16	WH	2036586C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K90CC	16	GY	2036586C1
B	K90-GA	16	WH	2036586C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	[K90CB]	16	-	V-TERM
B	[K90D]	16	-	V-TERM

21.16. CONNECTOR COMPOSITES *(4040), &(4041), *(4041), P. 15 | Figure 1015 CONNECTOR COMPOSITES *(4040), &(4041), *(4041) | printed page 1015

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K90E	16	GY	2036586C1
B	K90B	16	GY	2036586C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG,

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K90E	16	GY	2036586C1
B	K90B	16	GY	2036586C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2018-PROP-ENG,

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A@	K14D	10	RD	3515522C1	3515525C1
A@	K14W	10	RD	3515522C1	3515525C1
A@	K90AA	10	GY	3515522C1	3515525C1
A*	K90AA	10	GY	3515522C1	3541256C1
A!	K90AA	10	GY	3515522C1	3515525C1
A@	K14X	10	RD	3515522C1	3515525C1
A!	K14X	10	RD	3515522C1	3515525C1
B@	K90	10	GY	3515522C1	3515525C1
B@	K94B	10	GY	3515522C1	3541256C1
B@	K90A	10	GY	3515522C1	3515525C1
B!	K90A	10	GY	3515522C1	3515525C1
B@	K94B	10	GY	3515522C1	3515525C1
B!	K94B	10	GY	3515522C1	3515525C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK ; @ W/2017/2021 ISB/B6.7 DIESEL ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M14H	8	RD	3525614C1	3515525C1
B	M14M	8	RD	3525614C1	3515525C1

Figure 1016 CONNECTOR COMPOSITES !(4041), @(4041), *(4041A)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.17. CONNECTOR COMPOSITES !(4041), @(4041), *(4041A), P. 16 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090672 NO. RELEASE NO. 95504E 04MAR20 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / HYDRULIC BRAKE FUSE HOLDER !(4041) (LOCATED INSIDE ENGINE COMPARTMENT) / CONNECTOR 3525613C1 / HYDRAULIC BRAKE FUSE HOLDER @(4041) (LOCATED IN ENGINE COMPARTMENT) / CONNECTOR 3515523C1 / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / REDUNDANT PWR FUSE HOLDER *(4041A) (LOCATED IN ENGINE COMPARTMENT) / CONNECTOR 3515523C1 / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG, F-2021-B6.7-ENG / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A M14HA 8 RD 3525614C1 3515525C1 B M14M 8 RD 3525614C1 3515525C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A M14H 10 RD 3515522C1 3515525C1 B M90A 12 GY 3614762C1 3541256C1 / Figure 1016 / CONNECTOR COMPOSITES !(4041), @(4041), *(4041A)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M14H	10	RD	3515522C1	3515525C1
B	M90A	12	GY	3614762C1	3541256C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M14HA	8	RD	3525614C1	3515525C1
B	M14M	8	RD	3525614C1	3515525C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG, ; F-2021-B6.7-ENG

Figure 1017 CONNECTOR COMPOSITES *(4043)

21.18. CONNECTOR COMPOSITES *(4043), P. 17 | Figure 1017 CONNECTOR COMPOSITES *(4043) | printed page 1017

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K14	10	GY	1661708C1
2	K90R	16	GY	1661707C1
3	-	-	-	-
4	K90DA	10	GY	1661708C1
5	K90G	16	GY	1661707C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K14	10	GY	1661708C1
2	K90R	16	GY	1661707C1
3	-	-	-	-
4	K90DA	10	GY	1661708C1
5	K90G	16	GY	1661707C1
Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2018-PROP-ENG,

21.19. CONNECTOR COMPOSITES *(4045), &(4046), P. 18
Figure 1018 CONNECTOR COMPOSITES *(4045), &(4046)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.19. CONNECTOR COMPOSITES *(4045), &(4046), P. 18 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090672 NO. RELEASE NO. 95504E 04MAR20 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2018-PROP-ENG, W/F-2018-GAS-ENG / CONNECTOR 1667639C1 / HYDROMAX MOTOR SENSE FUSE *(4045) (LOCATED INSIDE ENGINE COMPARTMENT) / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG, F-2021-B6.7-ENG / FUEL SYSTEMS FUSE *(4045) (LOCATED INSIDE ENGINE COMPARTMENT) / CONNECTOR 1667639C1 / CAV CIRCUIT GA COLOR TERMINAL A K90P 14 GY 1661707C1 B K90Y 14 GY 1661707C1 / CAV CIRCUIT GA COLOR TERMINAL A K37A 12 RD 1661708C1 B K37B 12 RD 1661708C1 / Figure 1018 / CONNECTOR COMPOSITES *(4045), &(4046)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K90P	14	GY	1661707C1
B	K90Y	14	GY	1661707C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K37A	12	RD	1661708C1
B	K37B	12	RD	1661708C1

Legend: FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; - NOT FUSE BLOCK W/F-2018-PROP-ENG,

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
GND	A82-GA	16	WH	3586990C1	3586991C1
HI	A82K	16	GY	3586990C1	3586991C1
LO	A82N	16	GY	3586990C1	3586991C1
PF	A82DA	16	GY	3586990C1	3586991C1

Legend: OPEN PLUG - - 3586993C1 - ; PR A82H 16 GY 3586990C1 3586991C1 ; & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK

Figure 1019 CONNECTOR COMPOSITES *(4046), &(4049)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.20. CONNECTOR COMPOSITES *(4046), &(4049), P. 19 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090672 NO. RELEASE NO. 95504E 04MAR20 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2018-PROP-ENG, W/F-2018-GAS-ENG / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG, F-2021-B6.7-ENG CONNECTOR 1667639C1 / HYDROMAX BRAKE PRESSURE 5 AMP FUSE *(4046) (LOCATED IN ENGINE COMPARTMENT) / HYDROMAX BRAKE PRESSURE 5 AMP FUSE *(4046) (LOCATED IN ENGINE COMPARTMENT) / CONNECTOR 1667639C1 / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK CONNECTOR 2206588C1 / 1 2 / CAV CIRCUIT GA COLOR TERMINAL A K90W 14 GY 1661707C1 B K90X 14 GY 1661707C1 / CAV CIRCUIT GA COLOR TERMINAL A K90W 14 GY 1661707C1 B K90X 14 GY 1661707C1 / Figure 1019 / CONNECTOR COMPOSITES *(4046), &(4049)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K90W	14	GY	1661707C1
B	K90X	14	GY	1661707C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG,

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K90W	14	GY	1661707C1
B	K90X	14	GY	1661707C1

Table: PANEL)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	A57E	16	OR	3522190C1	3522194C1
2	A57E-G	16	WH	3522190C1	3522194C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK

Figure 1020 CONNECTOR COMPOSITES &(4049A), &(4050), &(4050A)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.21. CONNECTOR COMPOSITES &(4049A), &(4050), &(4050A), P. 20 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090672 NO. RELEASE NO. 95504E 04MAR20 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / RH COWL MTD MARKER/DIRECT LIGHT &(4049A) (LOCATED ON FRONT TOP RIGHT PANEL) / 1 2 3 / CONNECTOR 3522187C1 / LH COWL MTD DIRECTIONAL LIGHT &(4050) (LOCATED ON FRONT TOP RIGHT PANEL) / 1 2 / CONNECTOR 2206588C1 / LH COWL MTD MARKER/DIRECT LIGHT &(4050A) (LOCATED ON FRONT TOP LEFT PANEL) / 1 2 3 / CONNECTOR 3522187C1 / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 A57E 16 OR 3522190C1 3522194C1 2 A58D 16 BN 3522190C1 3522194C1 3 A57-GA 16 WH 3522190C1 3522194C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 A56E 16 OR 3522190C1 3522194C1 2 A56E-G 16 WH 3522190C1 3522194C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 A56E 16 OR 3522190C1 3522194C1 2 A58E 16 BN 3522190C1 3522194C1 3 A56-GA 16 WH 3522190C1 3522194C1 / Figure 1020 / CONNECTOR COMPOSITES &(4049A), &(4050), &(4050A)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	A57E	16	OR	3522190C1	3522194C1
2	A58D	16	BN	3522190C1	3522194C1
3	A57-GA	16	WH	3522190C1	3522194C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	A56E	16	OR	3522190C1	3522194C1
2	A56E-G	16	WH	3522190C1	3522194C1

Legend: W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	A56E	16	OR	3522190C1	3522194C1
2	A58E	16	BN	3522190C1	3522194C1
3	A56-GA	16	WH	3522190C1	3522194C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK

21.22. CONNECTOR COMPOSITES !(4052), *(4087), &(4101), P. 21 | Figure 1021 CONNECTOR COMPOSITES !(4052), *(4087), &(4101) | printed page 1021

CAV	CIRCUIT	GA	COLOR	TERMINAL
A!	A103	16	LTGN	0239806R1

Legend: ! N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1-5	PLUG	-	-	3527276C1
6	K26	18	TN	3518963C1
7	K5C(+)	18	YL	3727971C1
8	K5C(-)	18	GN	3727971C1
9	PLUG	-	-	3527276C1
10	K26B	16	TN	3518963C1
11	K26A	16	TN	3518963C1
12	K26-G	18	WH	3518963C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K95XB	14	TN	6113342C1	6113345C1
2	K95XC	18	TN	4161136C1	4154668C1
3	PLUG	-	-	6113348C1	-
4*	K95XG	14	TN	6113342C1	6113345C1
4#	K95XG	14	PK	6113342C1	6113345C1
5	K95TB	18	GY	4161136C1	4154668C1

Legend: * W/AFT WIRING (MA05500) ; # W/AFT WIRING (PB10500,PC10500) ; & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG,

21.23. CONNECTOR COMPOSITES *(4101), *(4103), &(4103), P. 22 | Figure 1022 CONNECTOR COMPOSITES *(4101), *(4103), &(4103) | printed page 1022

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K17SC	12	RD	6113343C1	6113346C1
2	K17SE	18	RD	4161136C1	6113345C1
3	PLUG	-	-	6113348C1	-
4	K17SB	12	RD	6113343C1	6113346C1
5	K10-GB	18	WH	4161136C1	6113345C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K37ES	12	RD	6113343C1	6113346C1
2	K37EC	18	TN	4161136C1	6113345C1
3	PLUG	-	-	6113348C1	-
4	K37E	14	RD	6113342C1	4154670C1
5	K10E-G	18	WH	4161136C1	6113345C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K14EA	12	RD	6113343C1	6113346C1
2	K95-GK	18	WH	4161136C1	6113345C1
2	K95AA	18	WH	4161136C1	6113345C1
3	PLUG	-	-	6113348C1	-
4	K14P	12	RD	6113343C1	6113346C1
5	K95E	18	TN	4161136C1	4154668C1

21.24. CONNECTOR COMPOSITES *(4104), &(4104), *(4106), P. 23
Figure 1023 CONNECTOR COMPOSITES *(4104), &(4104), *(4106)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.24. CONNECTOR COMPOSITES *(4104), &(4104), *(4106), P. 23 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090672 NO. 95504E 05MAR20 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / KEY POWER *(4104) (LOCATED AT CAB DASH PANEL) / KEY POWER &(4104) (LOCATED AT CAB DASH PANEL) / CONNECTOR 1667639C1 / FUEL HEATER FUSE *(4106) (LOCATED OUTSIDE CENTER TOP DASH PANEL) / CONNECTOR 3525613C1 / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG, F-2021-B6.7-ENG / CAV CIRCUIT GA COLOR TERMINAL A* K97UB 14 VT 1661707C1 A# K97UA 14 VT 1661707C1 B K97UC 14 VT 1661707C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A K14A 10 RD 3515522C1 3515525C1 B K14FHB 10 RD 3515522C1 3541256C1 / Figure 1023 / CONNECTOR COMPOSITES *(4104), &(4104), *(4106)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K17UB	14	PK	1661707C1
B	K17UC	14	PK	1661707C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2018-PROP-ENG,

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	K97UB	14	VT	1661707C1
A#	K97UA	14	VT	1661707C1
B	K97UC	14	VT	1661707C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK /F-2017-ISB-ENG, ; * W/ELECTRIC CLUTCH FAN ; # W/4 VISCOUS FAN, HORTON FAN

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K14A	10	RD	3515522C1	3515525C1
B	K14FHB	10	RD	3515522C1	3541256C1

21.25. CONNECTOR COMPOSITES &(4106), *(4107), P. 24
Figure 1024 CONNECTOR COMPOSITES &(4106), *(4107),

21.25. CONNECTOR COMPOSITES &(4106), *(4107), P. 24 | Figure 1024 CONNECTOR COMPOSITES &(4106), *(4107), | printed page 1024

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A*	K17SA	12	RD	3614762C1	3541256C1
A#	K14B	12	RD	3614762C1	3541256C1
B*	K17SB	12	RD	3614762C1	3541256C1
B#	K39A	14	GY	3614762C1	3541256C1

Legend: * N/ENHANCED VCM FUNCTIONS ; # W/ENHANCED VCM FUNCTIONS ; & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2018-PROP-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K14B	14	RD	3614762C1	3541256C1
B	K39A	14	GY	3614762C1	3541256C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A&	K14B	14	RD	1661707C1
A#	K77C	14	RD	1661707C1
B#	K77A	14	GY	1661707C1
B&	K39A	14	GY	1661707C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK N/ENHANCED VCM FUNCTIONS

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K14M	14	RD	1661707C1
B	K95XA	14	TN	1661707C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

Figure 1025 CONNECTOR COMPOSITES *(4108), *(4109)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.26. CONNECTOR COMPOSITES *(4108), *(4109), P. 25 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090672 NO. 95504E 05MAR20 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2018-PROP-ENG, W/F-2018-GAS-ENG / CONNECTOR 1667639C1 / ECM FUSE *(4108) (LOCATED INSIDE ENGINE COMPARTMENT) / CONNECTOR 1667639C1 / INJ 1 FUSE *(4109) (LOCATED INSIDE ENGINE COMPARTMENT) / SCR SUPPLY MODULE HTR FUSE *(4108) (LOCATED OUTSIDE CENTER TOP DASH PANEL) / CONNECTOR 1667639C1 / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG, F-2021-B6.7-ENG / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2018-PROP-ENG, W/F-2018-GAS-ENG / CAV CIRCUIT GA COLOR TERMINAL A K14E 12 RD 1661708C1 B K14EA 12 RD 1661708C1 / CAV CIRCUIT GA COLOR TERMINAL A K97KA 12 RD 1661708C1 B K97KB 12 RD 1661708C1 / CAV CIRCUIT GA COLOR TERMINAL A K97JA 12 RD 1661708C1 B K97JAB 12 VT 1661708C1 / Figure 1025 / CONNECTOR COMPOSITES *(4108), *(4109)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K14E	12	RD	1661708C1
B	K14EA	12	RD	1661708C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K97KA	12	RD	1661708C1
B	K97KB	12	RD	1661708C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K97JA	12	RD	1661708C1
B	K97JAB	12	VT	1661708C1

Figure 1026 CONNECTOR COMPOSITES *(4109), *(4110), *(4111), *(4111M)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.27. CONNECTOR COMPOSITES *(4109), *(4110), *(4111), *(4111M), P. 26 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090672 NO. 95504E 05MAR20 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2018-PROP-ENG, W/F-2018-GAS-ENG CONNECTOR 1667639C1 / IGN FAN FUSE *(4111) (LOCATED OUTSIDE CENTER TOP DASH PANEL) / CONNECTOR 1667639C1 / INJ 2 FUSE *(4110) (LOCATED INSIDE ENGINE COMPARTMENT) CAV CIRCUIT GA COLOR TERMINAL A K97JB 12 RD 1661708C1 B K97JBB 12 VT 1661708C1 / A B / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG, F-2021-B6.7-ENG / CAV CIRCUIT GA COLOR TERMINAL A K14N 14 RD 1661707C1 B K14P 14 RD 1661707C1 / Figure 1026 / CONNECTOR COMPOSITES *(4109), *(4110), *(4111), *(4111M)

Table: PANEL)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K14H	14	RD	1661707C1
B	K14HA	12	RD	1661708C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG,

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K97JB	12	RD	1661708C1
B	K97JBB	12	VT	1661708C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2018-PROP-ENG,

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K14N	14	RD	1661707C1
B	K14P	14	RD	1661707C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG,

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K23	20	TN	1661875C1	3568570C1
B	K23-G	20	WH	1661875C1	3568570C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG,

21.28. CONNECTOR COMPOSITES *(4112), *(4113), *(4114), *(4115), P. 27 | Figure 1027 CONNECTOR COMPOSITES *(4112), *(4113), *(4114), *(4115) | printed page 1027

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K94L	12	GY	1661708C1
B	K90BB	12	GY	1661708C1

Legend: FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; - NOT FUSE BLOCK W/F-2018-PROP-ENG,

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K14P	14	RD	1661707C1
B	K92B	14	TN	1661707C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG,

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K90P	14	GY	1661707C1
B	K90Y	14	GY	1661707C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2018-PROP-ENG,

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K77C	14	RD	1661707C1
B	K77A	14	RD	1661707C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2018-GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K95XC	14	RD	1661707C1
B	K23B	14	RD	1661707C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG,

21.29. CONNECTOR COMPOSITES *(4116), #(4117), @(4301), P. 28 | Figure 1028 CONNECTOR COMPOSITES *(4116), #(4117), @(4301) | printed page 1028

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K23B	14	RD	6113342C1	4154670C1
2	K23A	20	TN	4161136C1	4154668C1
3	K23	18	TN	4161136C1	6113345C1
4	PLUG	-	-	6113348C1	-
5	K97-G	20	WH	4161136C1	4154668C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG,

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	K17RD2	14	RD	6113342C1	6113345C1
2	K17RA	18	RD	4161136C1	6113345C1
3	K17RC	14	RD	6113342C1	6113345C1
4	PLUG	-	-	6113348C1	-
5	K97RB	18	VT	4161136C1	4154668C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K77CB	14	RD	1661707C1
B	K77AB	14	GY	1661707C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M89	16	VT	0587575C1	1652325C1
B	M89-G	16	WH	0587575C1	1652325C1
C	M89A	16	VT	0587575C1	1652325C1
D	PLUG	-	-	0587579C1	-

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG,

21.30. CONNECTOR COMPOSITES #(4200), #(4201), #(4202), P. 28A | Figure 1029 CONNECTOR COMPOSITES #(4200), #(4201), #(4202) | printed page 1029

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A77Y	14	LT GN	2018946C1
2	A77-GA	18	WH	1659673C1
3	-	-	-	-
4	A77U	14	LT GN	1661709C1
5	A77T	18	LT GN	1659673C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A77Z	14	LT GN	1661709C1
2	A77-GA	18	WH	1661709C1
2	A77-GB	18	WH	1661709C1
3	-	-	-	-
4	A77V	14	LT GN	1661709C1
5	A77S	18	LT GN	1659673C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A77Y	14	LT GN	2206596C1
2	A77U	14	LT GN	2206596C1

21.31. CONNECTOR COMPOSITES #(4203), #(4208), P. 28B
Figure 1030 CONNECTOR COMPOSITES #(4203), #(4208)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.31. CONNECTOR COMPOSITES #(4203), #(4208), P. 28B / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, PART AE08090672 NO. RELEASE NO. 96183U 06AUG21 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / # W/F-2017-ISB-ENG N/MTA FUSE BLOCK / CONNECTOR 2206600C1 BODY LOCK 2206601C1 "BUS BODY A/C COMPRESSOR TRANS AIR OUTPUTS" #(4208) (LOCATED IN PLATFORM HARNESS) 9 1 / 16 8 CONNECTOR 0593385C1 BODY LOCK 0593387C1 / # W/F-2018-PROPANE/GASOLINE-ENG N/0508108 - NOT FUSE BLOCK / # W/0508108 - WITH MTA FUSE BLOCK / "BODY BUILDER # 2 A/C COMPRESSOR CLUTCH" #(4203) (LOCATED IN PLATFORM HARNESS) / "BUS BODY A/C COMPRESSOR TRANS AIR OUTPUTS" #(4208) (LOCATED IN PLATFORM HARNESS) 9 1 / 16 8 CONNECTOR 0593385C1 BODY LOCK 0593387C1 / CAV CIRCUIT GA COLOR TERMINAL SLEEVE/SLV 1 A77Z 14 LT GN 2206596C1 2206612C1 2 A77V 14 LT GN 2206596C1 2206612C1 / CAV CIRCUIT GA COLOR TERMINAL 1 A77E 14 LT GN 3618273C1 2 A77F 14 LT GN 3618273C1 / CAV CIRCUIT GA COLOR TERMINAL 1 A77E 14 LT GN 3618273C1 2 A77F 14 LT GN 3618273C1 / Figure 1030 / CONNECTOR COMPOSITES #(4203), #(4208)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A77Z	14	LT GN	2206596C1
2	A77V	14	LT GN	2206596C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A77E	14	LT GN	3618273C1
2	A77F	14	LT GN	3618273C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A77E	14	LT GN	3618273C1
2	A77F	14	LT GN	3618273C1

21.32. CONNECTOR COMPOSITES #(4301E), P. 29
Figure 1031 CONNECTOR COMPOSITES #(4301E)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.32. CONNECTOR COMPOSITES #(4301E), P. 29 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090672 NO. 95504E 05MAR20 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED R/D 4301E. / # W/F-2018-PROPANE/GASOLINE-ENG W/COMMON FOR W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK." / CONNECTOR 0587572C91 / EV CROSSING GATE #(4301E) (LOCATED IN FORWARD CHASSIS HARNESS) / D C B A / CAV CIRCUIT GA COLOR TERMINAL SLEEVE/SLV A M119 16 VT 0587575C1 1652325C1 B M89-G 16 WH 0587575C1 1652325C1 C M119A 16 VT 0587575C1 1652325C1 / Figure 1031 / CONNECTOR COMPOSITES #(4301E)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	M119	16	VT	0587575C1
B	M89-G	16	WH	0587575C1
C	M119A	16	VT	0587575C1

21.33. CONNECTOR COMPOSITES *(4301), %(4302), *(4302A), #(4302E), P. 30 | Figure 1032 CONNECTOR COMPOSITES *(4301), %(4302), *(4302A), #(4302E) | printed page 1032

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M119	16	VT	0587575C1	1652325C1
B	M89-G	16	WH	0587575C1	1652325C1
C	M119A	16	VT	0587575C1	1652325C1
D	PLUG	-	-	0587579C1	-

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A*	M64A	14	YL	0587577C1	0589391C1
A#	M64A	14	YL	0587577C1	1652325C1
B*	M64A-G	14	WH	0587577C1	0589391C1
B#	M64A-G	14	WH	0587577C1	1652325C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M64A	14	YL	4080386C1	4080000C1
2	M64A-G	14	WH	4080386C1	4080000C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M64A	14	YL	0587577C1	1652325C1
B	M64A-G	14	WH	0587577C1	1652325C1

21.34. CONNECTOR COMPOSITES %(4303), @(4303A), #(4303E), *(4500), P. 31 | Figure 1033 CONNECTOR COMPOSITES %(4303), @(4303A), #(4303E), *(4500) | printed page 1033

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A*	M64B	14	YL	0587577C1	0589391C1
A#	M64B	14	YL	0587577C1	1652325C1
B*	M64B-G	14	WH	0587577C1	0589391C1
B#	M64B-G	14	WH	0587577C1	1652325C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M64B	14	YL	4080386C1	4080000C1
2	M64B-G	14	WH	4080386C1	4080000C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M64B	14	YL	0587577C1	1652325C1
B	M64B-G	14	WH	0587577C1	1652325C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M87-G	18	GY	3561584C1	3536867C1
2	M87A	18	GY	3561584C1	3536867C1

21.35. CONNECTOR COMPOSITES *(4500), #(4500E), #(4501), *(4905), P. 32 | Figure 1034 CONNECTOR COMPOSITES *(4500), #(4500E), #(4501), *(4905) | printed page 1034

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A58D	14	BN	1661539C1
2	A88-G	18	WH	1661539C1
3	A88BAT	18	LTGN	1661539C1
4	A88IGN	18	LTGN	1661539C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1S	A58D	18	BN	1661539C1
2S	A88-G	18	WH	1661539C1
3S	A88BAT	18	LTGN	1661539C1
4S	A88IGN	18	LTGN	1661539C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M87-G	18	GY	3536865C1
2	M87A	18	GY	3536865C1

Legend: # W/F-2018-PROPANE/GASOLINE-ENG ; W/COMMON FOR W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT ; FUSE BLOCK.

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A82-GW	16	WH	0556897C1
A	A82-GV	16	WH	0556897C1

Legend: # W/F-2017-ISB-ENG N/MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K44	18	GY	587576C1	1652325C1
B	K44C	18	GY	587576C1	1652325C1

21.36. CONNECTOR COMPOSITES #(4502), #(4503), #(4504), #(4600), P. 32A | Figure 1035 CONNECTOR COMPOSITES #(4502), #(4503), #(4504), #(4600) | printed page 1035

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A82W	16	GY	0239805R1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A82-GV	16	WH	0239805R1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A82W	16	GY	0556897C1
A	A82V	16	GY	0556897C1

Legend: # W/F-2017-ISB-ENG N/MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A58C	14	BN	3566715C1
B	A58	14	BN	3566715C1
C	A58B	14	BN	3566715C1
D	A58A	14	BN	3566715C1
E	A58E	16	BN	1661209C1
F	A58D	16	BN	1661209C1
G	A58D	18	BN	1661208C1

Legend: # W/COMMON FOR W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK.

21.37. CONNECTOR COMPOSITES *(4905), @(4906), @(4907), P. 33 | Figure 1036 CONNECTOR COMPOSITES *(4905), @(4906), @(4907) | printed page 1036

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K44	18	GY	587576C1	1652325C1
B	K44C	18	GY	587576C1	1652325C1

Legend: FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; - NOT MTA FUSE BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M94BP	14	GY	2034787C1
2	M94BH	14	GY	2034787C1
3	PLUG	-	-	0453133C1
4	M3C+	18	DKBL	1680205C1
5	PLUG	-	-	0453133C1
6	M5(-)	18	GN	1680205C1
7	M5(+)	18	YL	1680205C1
8	PLUG	-	-	0453133C1
9	M3C-	18	GY	1680205C1
10	PLUG	-	-	0453133C1
11	M94-GB	14	GY	2034787C1
12	M94-GW	14	GY	2034787C1

Legend: W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	PLUG	-	-	-
2	M94BC	14	BN	2034787C1
3	M94BD	14	VT	2034787C1
4	M94BF	14	LTBL	2034787C1
5	[MKRF]	18	BK	1680205C1
6	[MNRF]	18	BN	1680205C1
7	[MNLF]	18	BN	1680205C1
8	[MKLF]	18	BK	1680205C1
9	M94BE	14	LTGN	2034787C1
10	M94BA	14	BK	2034787C1
11	M94BB	14	RD	2034787C1
12	PLUG	-	-	0453133C1

21.38. CONNECTOR COMPOSITES @(4908), #(4909), #(4910), @(4911), @(4912), P. 34 | Figure 1037 CONNECTOR COMPOSITES @(4908), #(4909), #(4910), @(4911), @(4912) | printed page 1037

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[RBKLR]	18	BK	1680205C1
2	[RBNLR]	18	BN	1680205C1
3	[RBKRR]	18	BK	1680205C1
4	[RBNRR]	18	BN	1680205C1
5-6	-	-	-	-
7	R94R	14	VT	2034787C1
8	R94S	14	LTGN	2034787C1
9	R94T	14	LTBL	2034787C1
10	R94M	14	BK	2034787C1
11	R94N	14	RD	2034787C1
12	R94P	14	BN	2034787C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[MBKLF]	18	BK	ASSY
2	[MBNLF]	18	BN	ASSY

Legend: # W/F-2017-ISB-ENG, F-2021-B6.7-ENG W/COMMON ; FOR W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[MBKRF]	18	BK	ASSY
2	[MBNRF]	18	BN	ASSY

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M94BA	14	BK	3679224C1	3601687C1
2	M94BB	14	RD	3679224C1	3601687C1
3	M94BC	14	BN	3679224C1	3601687C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M94BD	14	VT	3679224C1	3601687C1
2	M94BE	14	LTGN	3679224C1	3601687C1
3	M94BF	14	LTBL	3679224C1	3601687C1

21.39. CONNECTOR COMPOSITES #(4913), #(4914), P. 34A
Figure 1038 CONNECTOR COMPOSITES #(4913), #(4914)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.39. CONNECTOR COMPOSITES #(4913), #(4914), P. 34A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, PART AE08090672 NO. RELEASE NO. 96183U 08AUG21 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / "WABCO AIR ABS L REAR WHEEL SPEED SENSOR" #(4913) (LOCATED IN REAR CHASSIS HARNESS) 1 / 2 CONNECTOR WHEELSPD1 / # W/F-2017-ISB-ENG, F-2021-B6.7-ENG W/COMMON FOR W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / "WABCO AIR ABS R REAR WHEEL SPEED SENSOR" #(4914) (LOCATED IN REAR CHASSIS HARNESS) 1 / 2 CONNECTOR WHEELSPD1 / # W/F-2017-ISB-ENG, F-2021-B6.7-ENG W/COMMON FOR W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL 1 [RBKLR] 18 BK ASSY 2 [RBNLR] 18 BN ASSY / CAV CIRCUIT GA COLOR TERMINAL 1 [RBKRR] 18 BK ASSY 2 [RBNRR] 18 BN ASSY / Figure 1038 / CONNECTOR COMPOSITES #(4913), #(4914)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[RBKLR]	18	BK	ASSY
2	[RBNLR]	18	BN	ASSY

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[RBKRR]	18	BK	ASSY
2	[RBNRR]	18	BN	ASSY

21.40. CONNECTOR COMPOSITES @(4915), @(4916), @(4917F), P. 35
Figure 1039 CONNECTOR COMPOSITES @(4915), @(4916), @(4917F)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.40. CONNECTOR COMPOSITES @(4915), @(4916), @(4917F), P. 35 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090672 NO. RELEASE NO. 95504E 05MAR20 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / WABO AIR ABS LEFT REAR MODULATOR @(4915) (LOCATED NEAR RIGHT FRONT AXLE) / CONNECTOR 3919376C1 / WABO AIR ABS RIGHT REAR MODULATOR @(4916) (LOCATED NEAR RIGHT FRONT AXLE) / CONNECTOR 3919376C1 / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / WABCO AIR ABS INTERCONNECT @(4917F) (LOCATED AT FRONT CHASSIS) 2 / 1 CONNECTOR 6105357C1 / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 R94R 14 VT 3679224C1 3601687C1 2 R94S 14 LTGN 3679224C1 3601687C1 3 R94T 14 LTBL 3679224C1 3601687C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 R94M 14 BK 3679224C1 3601687C1 2 R94N 14 RD 3679224C1 3601687C1 3 R94P 14 BN 3679224C1 3601687C1 / CAV CIRCUIT GA COLOR TERMINAL 1 M94B 12 GY 3612308C1 2 PLUG - - 3573076C1 / Figure 1039 / CONNECTOR COMPOSITES @(4915), @(4916), @(4917F)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	R94M	14	BK	3679224C1	3601687C1
2	R94N	14	RD	3679224C1	3601687C1
3	R94P	14	BN	3679224C1	3601687C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	R94R	14	VT	3679224C1	3601687C1
2	R94S	14	LTGN	3679224C1	3601687C1
3	R94T	14	LTBL	3679224C1	3601687C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M94B	12	GY	3612308C1
2	PLUG	-	-	3573076C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

21.41. CONNECTOR COMPOSITES *(4917M), *(6021), P. 36 | Figure 1040 CONNECTOR COMPOSITES *(4917M), *(6021) | printed page 1040

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K94B	10	GY	3612307C1
2	PLUG	-	-	3573076C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A1	K97WC	18	VT	3535303C1	3535424C1
A2	K99F	18	VT	3535303C1	3535424C1
A3	K99D	18	VT	3535303C1	3535424C1
A4	K97-G	12	WH	3535931C1	3548945C1
A5	K97PBC	14	VT	3535931C1	3535937C1
A6	K37DC	18	TN	3535303C1	3535424C1
A7	K37EC	18	TN	3535303C1	3535424C1
A8	PLUG	-	-	3535425C1	-
B1-B2	PLUG	-	-	3535425C1	-
B3	K97R	18	VT	3535303C1	3535424C1
B4	K99A	18	VT	3535303C1	3535424C1
B5	K97C	18	VT	3535303C1	3535424C1
B6	K97PAC	14	VT	3535931C1	3535937C1
B7	PLUG	-	-	3535425C1	-
B8	K97JAC	16	VT	3535303C1	3535424C1
B9	K97KC	18	RD	3535303C1	3535424C1
B10	PLUG	-	-	3535425C1	-
B11	K77G	18	LTGN	3535303C1	3535424C1
B12	PLUG	-	-	3535425C1	-
C1-C2	PLUG	-	-	3535425C1	-
C3	K97KE	18	VT	3535303C1	3535424C1
C4-C5	PLUG	-	-	3535425C1	-
C6	K17UG	12	PK	3535931C1	3548945C1
C7	PLUG	-	-	3535425C1	-
C8	K17UF	18	PK	3535303C1	3535424C1
C9	K97JBC	16	VT	3535303C1	3535424C1
C10	PLUG	-	-	3535425C1	-
C11	K5B(+)	18	YL	3535303C1	3535424C1
C12	K5B(-)	18	GN	3535303C1	3535424C1
D1	K17RD	16	RD	3535303C1	3535424C1
D2-D5	PLUG	-	-	3535425C1	-
D6	K37CC	18	TN	3535303C1	3535424C1
D7	PLUG	-	-	3535425C1	-
D8	K77F	18	LTGN	3535303C1	3535424C1

Legend: W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

21.42. CONNECTOR COMPOSITES **(6021), P. 37 | Figure 1041 CONNECTOR COMPOSITES **(6021) | printed page 1041

Table: BODY LOCK 3743662C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K97FAA	16	VT	3743666C1
2	PLUG	-	-	3744547C1
3	K95V	18	TN	3743666C1
4	PLUG	-	-	3744547C1
5	K97UE	18	VT	3743666C1
6	K95J	20	TN	3743668C1
7	PLUG	-	-	3744547C1
8	K99DA	20	VT	3743668C1
9	K97C	20	VT	3743668C1
10	K99A	20	VT	3743668C1
11-12	PLUG	-	-	3744547C1
13	K97WI	20	VT	3743668C1
14-15	PLUG	-	-	3744547C1
16	K95H	20	TN	3743668C1
17-21	PLUG	-	-	3744547C1
22	K5C(+)	20	YL	3743668C1
23-24	PLUG	-	-	3744547C1
25	K97FAB	16	VT	3743666C1
26	K97FAC	16	VT	3743666C1
27	K97FBA	16	VT	3743666C1
28	K97FBB	16	VT	3743666C1
29-31	PLUG	-	-	3744547C1
32	K9AA	20	GY	3743668C1
33	K97R	20	VT	3743668C1
34	PLUG	-	-	3744547C1
35	K97LCS	20	VT	3743668C1
36-37	PLUG	-	-	3744547C1
38	K95PB	20	TN	3743668C1
39	K95RB	20	TN	3743668C1
40	K95SB	20	TN	3743668C1
41	K95D	20	TN	3743668C1
42	K95C	20	TN	3743668C1
43	K77B	20	LTGN	3743668C1
44-45	PLUG	-	-	3744547C1
46	K5C(-)	20	GN	3743668C1
47-48	PLUG	-	-	3744547C1
49	K97-GVC	16	WH	3743666C1
50	K97-GVB	16	WH	3743666C1
51	K97-GVA	16	WH	3743666C1
52	K97-GWB	16	WH	3743666C1
53	K95B	20	TN	3743668C1

21.43. CONNECTOR COMPOSITES *(6021), &(6022), P. 38 | Figure 1042 CONNECTOR COMPOSITES *(6021), &(6022) | printed page 1042

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A1	K97WC	18	VT	3535303C1	3535424C1
A2	K99F	18	VT	3535303C1	3535424C1
A3	K99D	18	VT	3535303C1	3535424C1
A4	K97-G	12	WH	3535931C1	3548945C1
A5	K97PBC	14	VT	3535931C1	3535937C1
A6	PLUG	-	-	3535425C1	-
A7	K37EC	18	TN	3535303C1	3535424C1
A8	PLUG	-	-	3535425C1	-
B1-B2	PLUG	-	-	3535425C1	-
B3	K97R	18	VT	3535303C1	3535424C1
B4	K99A	18	VT	3535303C1	3535424C1
B5	K97C	18	VT	3535303C1	3535424C1
B6	K97PAC	14	VT	3535931C1	3535937C1
B7	PLUG	-	-	3535425C1	-
B8	K97JAC	16	VT	3535303C1	3535424C1
B9	K97KC	18	RD	3535303C1	3535424C1
B10	K10D-G	18	WH	3535303C1	3535424C1
B11	KD77G	18	LTGN	3535303C1	3535424C1
C1-C2	PLUG	-	-	3535425C1	-
C3	K97KE	18	VT	3535303C1	3535424C1
C4-C5	PLUG	-	-	3535425C1	-
C6	K17UG	12	PK	3535931C1	3548945C1
C7	PLUG	-	-	3535425C1	-
C8	K17UF	18	PK	3535303C1	3535424C1
C9	K97JBC	16	VT	3535303C1	3535424C1
C10	PLUG	-	-	3535425C1	-
C11	K5B(+)	18	YL	3535303C1	3535424C1
C12	K5B(-)	18	GN	3535303C1	3535424C1
D1	K17RD	16	PK	3535303C1	3535424C1
D2-D7	PLUG	-	-	3535425C1	-
D8	K77F	18	LTGN	3535303C1	3535424C1

Legend: FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K95MC	20	TN	3573077C1
2	K5H(+)	18	YL	3573077C1
3	K5N2(+)	18	YL	3573077C1
4	PLUG	-	-	3573076C1
5	K95TB	18	GY	3573077C1
6	K95XF	18	PK	3573077C1
7	PLUG	-	-	3573076C1
8	K14Y	18	TN	3573077C1
9	K5A(-)	18	GN	3573077C1
10	K5N2(-)	18	GN	3573077C1
11-12	PLUG	-	-	3573076C1
13	K95-GHA	18	WH	3573077C1
14	PLUG	-	-	3573076C1

Legend: W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; - NOT MTA FUSE BLOCK

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.44. CONNECTOR COMPOSITES *(6022), %(6023), P. 39 / Figure 1083 / CONNECTOR COMPOSITES *(6022), %(6023)

21.44. CONNECTOR COMPOSITES *(6022), %(6023), P. 39
Figure 1083 CONNECTOR COMPOSITES *(6022), %(6023)

21.45. CONNECTOR COMPOSITES *(6200), *(6200A), *(6201), P. 40 | Figure 1044 CONNECTOR COMPOSITES *(6200), *(6200A), *(6201) | printed page 1044

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K77A-G	16	WH	2033819C1	1652325C1
B	K77A	16	LTGN	2033819C1	1652325C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K77H-G	16	WH	3618273C1
2	K77E	16	LTGN	3618273C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K77H-G	16	WH	3618273C1
2	K77E	16	LTGN	3618273C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K77GB	18	LTGN	3613771C1
2	K77E	16	LTGN	3613770C1
3	K77EB	16	LTGN	3613770C1
4	K77FB	18	LTGN	3613771C1
5	K77HC-G	16	WH	3613770C1
6	K77HB-G	16	WH	3613770C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A77AC	18	LTGN	879630R1
B	A77AB	18	LTGN	879630R1
C	A77AA	18	LTGN	879630R1

21.46. CONNECTOR COMPOSITES %(6201), *(6201), *(6202), P. 41 | Figure 1045 CONNECTOR COMPOSITES %(6201), *(6201), *(6202) | printed page 1045

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K77B	20	LTGN	587578C1	3517771C1
B	K97-GSP	18	WH	587578C1	3517771C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	A77AC	18	LTGN	0333732C1
A%	A77AC	18	LTGN	879630R1
B#	A77AB	18	LTGN	0333732C1
B%	A77AB	18	LTGN	879630R1
C#	A77AA	18	LTGN	0333732C1
C%	A77AA	18	LTGN	879630R1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K77A-G	16	WH	3613770C1
2#	K77A	16	LTGN	3613770C1
2%	K77B	16	LTGN	3613770C1

21.47. CONNECTOR COMPOSITES *(6334), *(6335), P. 42 | Figure 1046 CONNECTOR COMPOSITES *(6334), *(6335) | printed page 1046

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K26	18	TN	1661875C1	1661872C1
B!	K26N	18	TN	1661875C1	1661872C1
B&	PX26N	18	TN	1661875C1	1661872C1
C!	K26P	18	TN	1661875C1	1661872C1
C&	PX26P	18	TN	1661875C1	1661872C1
D	K26-G	18	WH	1661875C1	1661872C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K26C	18	TN	1667742C1	1661872C1
B	K26D	18	TN	1667742C1	1661872C1
C	K26E	18	TN	1667742C1	1661872C1
D	K26-G	18	WH	1667742C1	1661872C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K26	18	TN	1661875C1	1661872C1
B	K26P	18	TN	1661875C1	1661872C1
C	K26N	18	TN	1661875C1	1661872C1
D	K26-G	18	WH	1661875C1	1661872C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K26	18	TN	1661875C1	1661872C1
B	K26N	18	TN	1661875C1	1661872C1
C	K26P	18	TN	1661875C1	1661872C1
D	K26-G	18	WH	1661875C1	1661872C1

21.48. CONNECTOR COMPOSITES %(6365), %(6365A), *(6365B), P. 43 | Figure 1047 CONNECTOR COMPOSITES %(6365), %(6365A), *(6365B) | printed page 1047

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K95B	20	TN	3573077C1
2	K95A	20	TN	3573077C1
3	K95D	20	TN	3573077C1
4	K95C	20	TN	3573077C1
5	K6A	18	GY	3573077C1
6	PLUG	-	-	3573076C1
7	K9A	20	GY	3573077C1
8	K95H	20	TN	3573077C1
9	K5H(+)	18	YL	3573077C1
10	K5H(-)	18	GN	3573077C1
11	K95-GJ	14	WH	3989901C1
12	K95XD	14	TN	3989901C1
13-14	PLUG	-	-	3573076C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	95B	18	TN	3626441C1
2	95A	18	TN	3626441C1
3	95D	18	TN	3626441C1
4	95C	18	TN	3626441C1
5	6A	18	TN	3626441C1
6	PLUG	-	-	3573076C1
7	9A	18	TN	3626441C1
8	95H	18	TN	3626441C1
9	5A(+)	18	YL	3626441C1
10	5A(-)	18	GN	3626441C1
11	95-GJ	14	WH	3627568C1
12	95XD	14	PK	3627568C1
13-14	PLUG	-	-	3573076C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K95B	20	TN	3573077C1
2	K95A	20	TN	3573077C1
3	K95D	20	TN	3573077C1
4	K95C	20	TN	3573077C1
5	K6A	18	GY	3573077C1
6	PLUG	-	-	3573076C1
7	K9A	20	TN	3573077C1
8	K95H	20	TN	3573077C1
9	K5H(+)	18	YL	3573077C1
10	K5H(-)	18	GN	3573077C1
11	K95-GJ	14	WH	3989901C1
12	K95XD	14	PK	3989901C1
13	K5K(+)	18	YL	3573077C1
14	K5K(-)	18	GN	3573077C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 05MAR20 AE08090672 043

21.49. CONNECTOR COMPOSITES *(6366), %(6366A), P. 43A
Figure 1048 CONNECTOR COMPOSITES *(6366), %(6366A)

21.49. CONNECTOR COMPOSITES *(6366), %(6366A), P. 43A | Figure 1048 CONNECTOR COMPOSITES *(6366), %(6366A) | printed page 1048

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K95FA	20	TN	3573077C1
1	K95-GK	14	WH	3989901C1
2	K95J	20	TN	3573077C1
3	K95MC	20	TN	3573077C1
4	K14XA	14	GY	3989901C1
5	K95N	20	TN	3573077C1
6	K95M	20	TN	3573077C1
6	K97-GRS	20	WH	3573077C1
7	K95R	18	TN	3573077C1
8	K95P	18	TN	3573077C1
9	K95S	18	TN	3573077C1
10	K95-GH1	18	WH	3573077C1
11	K95-GH2	18	TN	3573077C1
12	K95XE	14	TN	3989901C1
13-14	PLUG	-	-	3573076C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CIRCUIT	GA	COLOR	TERMINAL
95FA	18	TN	3626441C1
95J	18	TN	3626441C1
95MC	18	TN	3626441C1
14X	16	TN	3627568C1
95N	18	TN	3626441C1
95M	18	TN	3626441C1
95R	16	TN	3627568C1
95P	16	TN	3627568C1
95S	16	TN	3627568C1
95GH1	16	TN	3627568C1
95GH2	18	WH	3626441C1
95XA	18	PK	3626441C1
PLUG	-	-	3573076C1

21.50. CONNECTOR COMPOSITES %(6369), %(6370), %(6372), P. 43B | Figure 1049 CONNECTOR COMPOSITES %(6369), %(6370), %(6372) | printed page 1049

CIRCUIT	GA	COLOR	TERMINAL
5HD(-)	18	GN	1680205C1
5HD(+)	18	YL	1680205C1
95GH2	18	WH	1680205C1
95XA	18	PK	1680205C1

Legend: W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CIRCUIT	GA	COLOR	TERMINAL
95B	18	TN	3573077C1
95A	18	TN	3573077C1
95D	18	TN	3573077C1
95C	18	TN	3573077C1
6A	18	TN	3573077C1
PLUG	-	-	3573076C1
9A	18	TN	3573077C1
95H	18	TN	3573077C1
5A(+)	18	YL	3573077C1
5A(-)	18	GN	3573077C1
95-GJ	14	WH	3989901C1
95XD	14	PK	3989901C1
5HE(+)	18	YL	3573077C1
5HE(-)	18	GN	3573077C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CIRCUIT	GA	COLOR	TERMINAL
95P	16	TN	1680205C1
95ZC	16	TN	1680205C1

21.51. CONNECTOR COMPOSITES %(6373), %(6374), %(6375), P. 43C
Figure 1050 CONNECTOR COMPOSITES %(6373), %(6374), %(6375)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.51. CONNECTOR COMPOSITES %(6373), %(6374), %(6375), P. 43C / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, PART AE08090672 NO. RELEASE NO. 96183U 27JUL21 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / SUCTION HEATER LINE %(6373) (LOCATED INLINE SCR HARNESS) / CONNECTOR 3854645C91 / BACKFLOW HEATER LINE %(6374) (LOCATED INLINE SCR HARNESS) / CONNECTOR 3854665C91 / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / COOLANT VALVE SOLENOID CONN %(6375) (LOCATED INLINE SCR HARNESS) / CONNECTOR 3714731C1 / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / CAVITY CIRCUIT GA COLOR TERMINAL 1 95S 16 TN 1680205C1 2 95ZD 16 TN 1680205C1 / CAVITY CIRCUIT GA COLOR TERMINAL 1 95R 16 TN 1680205C1 2 95ZE 16 TN 1680205C1 / CAVITY CIRCUIT GA COLOR TERMINAL SLEEVE/SLV 1 95N 18 TN 3601686C1 3733609C1 2 PLUG - - 3532129C1 - 3 PLUG - - 3532129C1 - 4 95M 18 TN 3601686C1 3733609C1 / Figure 1050 / CONNECTOR COMPOSITES %(6373), %(6374), %(6375)

CIRCUIT	GA	COLOR	TERMINAL
95S	16	TN	1680205C1
95ZD	16	TN	1680205C1

CIRCUIT	GA	COLOR	TERMINAL
95R	16	TN	1680205C1
95ZE	16	TN	1680205C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CIRCUIT	GA	COLOR	TERMINAL
95N	18	TN	3601686C1
PLUG	-	-	3532129C1
PLUG	-	-	3532129C1
95M	18	TN	3601686C1

21.52. CONNECTOR COMPOSITES *(6401), *(6406M), *(6704M), P. 44 | Figure 1051 CONNECTOR COMPOSITES *(6401), *(6406M), *(6704M) | printed page 1051

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K97LCL	18	VT	3554322C1	3554318C1
B	K97-GSC	18	WH	3554322C1	3554318C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K23	18	TN	3613771C1
2	K23-G2	18	WH	3613771C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K26-G	18	WH	2033819C1	1652325C1
B	K97-GFA	18	WH	2033819C1	3517771C1
C	K10-GB	16	WH	2033819C1	1652325C1
D	K90-G	18	GY	2033819C1	3517771C1
E	K77A-G	16	WH	2033819C1	1652325C1
F	K23-G	18	WH	2033819C1	1652325C1

21.53. CONNECTOR COMPOSITES &(6706M), *(6709), *(6710), P. 45 | Figure 1052 CONNECTOR COMPOSITES &(6706M), *(6709), *(6710) | printed page 1052

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K95-GA	20	TN	2033819C1	3517771C1
A	K97-GRS	20	WH	2033819C1	3517771C1
B	K95AA	18	WH	2033819C1	1652325C1
B	K95M	20	TN	2033819C1	3517771C1
C	K97-GGR	18	WH	2033819C1	3517771C1
D	K23-G	20	WH	2033819C1	3517771C1
E	K97-G	20	WH	2033819C1	3517771C1
F	PLUG	-	-	0587579C1	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K11C	10	WH	3753255C1
2	K14FHC	10	RD	3753255C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K97WIF	18	VT	3572625C1
2	K97-GSW	18	WH	3572625C1

21.54. CONNECTOR COMPOSITES *(6715), *(6715A), P. 46
Figure 1053 CONNECTOR COMPOSITES *(6715), *(6715A)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.54. CONNECTOR COMPOSITES *(6715), *(6715A), P. 46 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090672 NO. RELEASE NO. 95504E 05MAR20 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / AIR COMPRESSOR PRESSURE *(6715) (LOCATED AT ENGINE COMPARTMENT AIR COMPRESSOR) / AMBIENT AIR TEMP *(6715) (LOCATED IN ENGINE COMPARTMENT) / CONNECTOR 3522068C1 BODY LOCK 1661874C1 / A B / CONNECTOR 4196881C1 / AIR COMPRESSOR PRESSURE *(6715A) (LOCATED NEAR CAB DASH PANEL FORWARD) / CONNECTOR 4196881C1 / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG, F-2018-PROP/GAS-ENG / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / 3 2 1 / 3 2 1 / CAV CIRCUIT GA COLOR TERMINAL SLEEVE/SLV 1 M40 18 GY 1651943C1 4147517C1 2 M9H 18 GY 1651943C1 4147517C1 3 M6H 16 GY 1651943C1 4147517C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A K97AB 20 VT 1661875C1 3568570C1 B K97-GSA 20 VT 1661875C1 1661872C1 / CAV CIRCUIT GA COLOR TERMINAL SLEEVE/SLV 1 M40 18 GY 4147514C1 4147517C1 2 M9H 18 GY 4147514C1 4147517C1 3 M6H 16 GY 4147514C1 4147517C1 / Figure 1053 / CONNECTOR COMPOSITES *(6715), *(6715A)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K97AB	20	VT	1661875C1	3568570C1
B	K97-GSA	20	VT	1661875C1	1661872C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M40	18	GY	1651943C1
2	M9H	18	GY	1651943C1
3	M6H	16	GY	1651943C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M40	18	GY	4147514C1
2	M9H	18	GY	4147514C1
3	M6H	16	GY	4147514C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

21.55. CONNECTOR COMPOSITES **(6740), @(6740), P. 47
Figure 1054 CONNECTOR COMPOSITES **(6740), @(6740)

21.55. CONNECTOR COMPOSITES **(6740), @(6740), P. 47 | Figure 1054 CONNECTOR COMPOSITES **(6740), @(6740) | printed page 1054

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M11-GA	12	WH	2033816C1	0589390C1
B	M89-G	16	WH	2033819C1	1652325C1
C	M44-GB	18	WH	2033819C1	1652325C1
D*	M75-GC	10	WH	1687847C1	0589390C1
D#	M75-GA	10	WH	1687847C1	0589390C1
D%	M75-G	10	WH	1687847C1	0589390C1
E	M39C-G	14	WH	2033816C1	0589391C1
F&	M39B-G	14	WH	2033816C1	0589391C1
F##	M39D-G	14	WH	2033816C1	0589391C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 ; - MTA FUSE BLOCK AND N/0508108 - NOT MTA ; W/F-2017-ISB-ENG,F-2021-B6.7-ENG ; * W/RSM FUEL TANK W/ESPAR CLNT HTR ; # W/RSM FUEL TANK W/CLNT HTR MTD FWD ; % W/RSM FUEL TANK W/CLNT HEATER ; & W/DRAIN VALVE ; ## W/HALDEX AUTO DRAIN VALVE

Table: BODY LOCK 3551897C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M11-GA	10	WH	1687847C1	0589390C1
B	M89-G	16	WH	2033819C1	1652325C1
C*	M148-GB	10	WH	1687847C1	0589390C1
C#	M37-G	10	WH	1687847C1	0589390C1
D	M64-G	14	WH	2033816C1	0589391C1
E	M39C-G	14	WH	2033816C1	0589391C1
F&	M39D-G	14	WH	2033816C1	0589391C1
F%	M39B-G	14	WH	2033816C1	0589391C1

Legend: ** W/COMMON FOR VEHICLE W/0508108 ; - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK ; W/F-2018-PROP/GAS-ENG ; * W/PROPANE FUEL TANK,BTR ; # W/GAS FUEL TANK,BTR ; & W/BENDIX DV-2 DRAIN VALVE W/AIR DRYER ; % W/HALDEX DRAIN VALVE N/AIR DRYER

21.56. INTENTIONALLY LEFT BLANK, P. 48
Figure 1055 Intentionally Left Blank

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.56. INTENTIONALLY LEFT BLANK, P. 48 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090672 NO. 95504E 05MAR20 / INTENTIONALLY LEFT BLANK / CHAPTER 21 / MJV0488 13SEP21 REMOVED GEOMETRY. / INTENTIONALLY LEFT BLANK / Figure 1055 / Intentionally Left Blank

21.57. CONNECTOR COMPOSITES @(7150), P. 49 | Figure 1056 CONNECTOR COMPOSITES @(7150) | printed page 1056

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K92#101	18	LTBL	3686945C1
2	-	-	-	-
3	K92#103	18	YL	3686945C1
4-5	-	-	-	-
6	K5#106	18	YL	3686945C1
7-8	-	-	-	-
9	K92#109	18	GY	3686945C1
10	K92#110	18	PK	3686945C1
11	K92#111	18	OR	3686945C1
12	K92#112	18	PK	3686945C1
13	-	-	-	-
14	K92#114	18	GY	3686945C1
15	-	-	-	-
16	K92#116	18	LTBL	3686945C1
17	K92#117	18	LTBL	3686945C1

21.58. CONNECTOR COMPOSITES @(7150), P. 50
Figure 1057 CONNECTOR COMPOSITES @(7150)

21.58. CONNECTOR COMPOSITES @(7150), P. 50 | Figure 1057 CONNECTOR COMPOSITES @(7150) | printed page 1057

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K92#101	18	LTBL	3686945C1
2	-	-	-	-
3	K92#103	18	YL	3686945C1
4-5	-	-	-	-
6	K5#106	18	YL	3686945C1
7	-	-	-	-
8	K5#108	18	GN	3686945C1
9	K92#109	18	GY	3686945C1
10	K92#110	18	PK	3686945C1
11	K92#111	18	OR	3686945C1
12-13	-	-	-	-
14	K92#114	18	GY	3686945C1
15-16	-	-	-	-
17	K92#117	18	LTBL	3686945C1

21.59. CONNECTOR COMPOSITES @(7150), P. 51 | Figure 1058 CONNECTOR COMPOSITES @(7150) | printed page 1058

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K92#101	18	LTBL	3686945C1
2	-	-	-	-
3	K92#103	18	YL	3686945C1
4-5	-	-	-	-
6	K5#106	18	YL	3686945C1
7-8	-	-	-	-
9	K92#109	18	GY	3686945C1
10	K92#110	18	PK	3686945C1
11	K92#111	18	OR	3686945C1
12-13	-	-	-	-
14	K92#114	18	GY	3686945C1
15-16	-	-	-	-
17	K92#117	18	LTBL	3686945C1

21.60. CONNECTOR COMPOSITES @(7205M), @(7206F), *(7250M), P. 52 | Figure 1059 CONNECTOR COMPOSITES @(7205M), @(7206F), *(7250M) | printed page 1059

Table: CONNECTOR BODY COMPOSITE MATING VIEW

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K92C103	18	YL	1661875C1	3568570C1
B	K92#113	18	WH	1661875C1	3568570C1
C	K92#104	18	YL	1661875C1	3568570C1
D	K92#129	18	LTGN	1661875C1	3568570C1
E	K92#122	18	YL	1661875C1	3568570C1
F	K92#105	18	OR	1661875C1	3568570C1
G	K92#164	18	LTBL	1661875C1	3568570C1
H	K92#102	18	YL	1661875C1	3568570C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K92C101	18	LTBL	1667742C1	3568570C1
B	K92#117	18	LTBL	1667742C1	3568570C1
C	K92D103	18	YL	1667742C1	3568570C1
D	K92#143	18	LTBL	1667742C1	3568570C1
E	K92#142	18	WH	1667742C1	3568570C1
F	K92#145	18	OR	1667742C1	3568570C1
G	K92#130	18	WH	1667742C1	3568570C1
H	K92#123	18	LTGN	1667742C1	3568570C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K92#111	18	OR	3686945C1
2	K92#155	18	WH	3686945C1
3	K92#177	18	LTGN	3686945C1
4	K92#136	18	OR	3686945C1
5	K92#152	18	LTGN	3686945C1
6	K92#171	18	YL	3686945C1
7	-	-	-	-
8	K92#174	18	LTBL	3686945C1
9	K92#133	18	YL	3686945C1
10	K92#151	18	WH	3686945C1
11	K92#131	18	YL	3686945C1
12	K92#137	18	WH	3686945C1
13	K92#180	18	OR	3686945C1
14	K92#120	18	LTBL	3686945C1
15	K92#116	18	LTBL	3686945C1
16	K92#112	18	PK	3686945C1
17	K92#118	18	BK	3686945C1
18	K31#154	18	TN	3686945C1
19	K92#158	18	LTGN	3686945C1
20	K92#176	18	YL	3686945C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

21.61. CONNECTOR COMPOSITES *(7350), P. 53
Figure 1060 CONNECTOR COMPOSITES *(7350)

21.61. CONNECTOR COMPOSITES *(7350), P. 53 | Figure 1060 CONNECTOR COMPOSITES *(7350) | printed page 1060

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K92#152	18	LTGN	3686945C1
2	K92#133	18	YL	3686945C1
3	K92#151	18	WH	3686945C1
4	K92#117	18	LTBL	3686945C1
5	-	-	-	-
6	K92#157	18	WH	3686945C1
7	K92#179	18	PK	3686945C1
8	K31#154	18	TN	3686945C1
9	K92#158	18	LTGN	3686945C1
10	K92#178	18	WH	3686945C1
11	K92#177	18	LTGN	3686945C1
12	K92#137	18	WH	3686945C1
13	K92#131	18	YL	3686945C1
14	K92#111	18	OR	3686945C1
15	K92#155	18	WH	3686945C1
16	K92#171	18	YL	3686945C1
17	K92#136	18	OR	3686945C1
18	K92#138	18	OR	3686945C1
19	K92#174	18	LTBL	3686945C1
20	K92#114	18	GY	3686945C1
21	K92#153	18	YL	3686945C1
22	K92#173	18	LTBL	3686945C1
23	K92#134	18	WH	3686945C1
24	K92#176	18	YL	3686945C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K92#152	18	LTGN	3686945C1
2	K92#133	18	YL	3686945C1
3	K92#151	18	WH	3686945C1
4	K92#117	18	LTBL	3686945C1
5	-	-	-	-
6	K92#157	18	WH	3686945C1
7	K92#179	18	PK	3686945C1
8	K31#154	18	TN	3686945C1
9	K92#158	18	LTGN	3686945C1
10	K92#178	18	WH	3686945C1
11	K92#177	18	LTGN	3686945C1
12	K92#137	18	WH	3686945C1
13	K92#131	18	YL	3686945C1
14	K92#111	18	OR	3686945C1
15	K92#155	18	WH	3686945C1
16	K92#171	18	YL	3686945C1
17	K92#136	18	OR	3686945C1
18	K92#138	18	OR	3686945C1
19	K92#174	18	LTBL	3686945C1
20	K92#114	18	GY	3686945C1
21	K92#153	18	YL	3686945C1
22	K92#173	18	LTBL	3686945C1
23	K92#134	18	WH	3686945C1
24	K92#176	18	YL	3686945C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-GAS-ENG ; REV REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 05MAR20 AE08090672 053

21.62. CONNECTOR COMPOSITES *(7350), *(7600M), P. 54
Figure 1061 CONNECTOR COMPOSITES *(7350), *(7600M)

21.62. CONNECTOR COMPOSITES *(7350), *(7600M), P. 54 | Figure 1061 CONNECTOR COMPOSITES *(7350), *(7600M) | printed page 1061

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K92#152	18	LTGN	3686945C1
2	K92#133	18	YL	3686945C1
3	K92#151	18	WH	3686945C1
4	K92#117	18	LTBL	3686945C1
5	-	-	-	-
6	K92#157	18	WH	3686945C1
7	K92#179	18	PK	3686945C1
8	K31#154	18	TN	3686945C1
9	K92#158	18	LTGN	3686945C1
10	K92#178	18	WH	3686945C1
11	K92#177	18	LTGN	3686945C1
12	K92#137	18	WH	3686945C1
13	K92#131	18	YL	3686945C1
14	K92#111	18	OR	3686945C1
15	K92#155	18	WH	3686945C1
16	K92#171	18	YL	3686945C1
17	K92#136	18	OR	3686945C1
18	K92#138	18	OR	3686945C1
19	K92#174	18	LTBL	3686945C1
20	K92#114	18	GY	3686945C1
21	K92#153	18	YL	3686945C1
22	K92#173	18	LTBL	3686945C1
23	K92#134	18	WH	3686945C1
24	K92#176	18	YL	3686945C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K47#160	18	YL	3554322C1	3554318C1
B	K47#140	18	LTGN	3554322C1	3554318C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K47#160	18	YL	3554322C1	3554318C1
B	K47#140	18	LTGN	3554322C1	3554318C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

21.63. CONNECTOR COMPOSITES #(7601M), *(7603M), *(7603MB), *(7604M), P. 55
Figure 1062 CONNECTOR COMPOSITES #(7601M), *(7603M), *(7603MB), *(7604M)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.63. CONNECTOR COMPOSITES #(7601M), *(7603M), *(7603MB), *(7604M), P. 55 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090672 NO. RELEASE NO. 95504E 05MAR20 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / LCT OUTPUT SPEED SENSOR *(7604M) (LOCATED AT ENGINE COMPARTMENT TRANSMISSION) / B A / CONNECTOR 3610533C1 BODY LOCK 3610532C1 / WT MD ENGINE SPEED SENSOR *(7603M) (LOCATED AT ENGINE COMPARTMENT TRANSMISSION) B A / CONNECTOR 3610533C1 BODY LOCK 3610532C1 / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / B A / ENGINE INPUT SPEED SENSOR *(7603MB) (LOCATED INSIDE ENGINE COMPARTMENT NEAR TO PASS-THRU CONNECTOR) / CONNECTOR 3610533C1 BODY LOCK 3610532C1 / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / CONNECTOR 3868823C1 BODY LOCK 3610532C1 / LCT OUTPUT SPEED SENSOR 6TH GEN #(7601M) (LOCATED IN ENGINE HARNESS) B A / # F-2017-ISB-ENG,F-2021-B6.7-ENG W/COMMON FOR W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A K48#159 18 TN 3554322C1 3554318C1 B K48#139 18 OR 3554322C1 3554318C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A K48#159 18 TN 3554322C1 3554318C1 B K48#139 18 OR 3554322C1 3554318C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A K48#159 18 TN 3554322C1 3554318C1 B K48#139 18 OR 3554322C1 3554318C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A K47#160 18 YL 3554322C1 3554318C1 B K47#140 18 LTGN 3554322C1 3554318C1 / Figure 1062 / CONNECTOR COMPOSITES #(7601M), *(7603M), *(7603MB), *(7604M)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K47#160	18	YL	3554322C1	3554318C1
B	K47#140	18	LTGN	3554322C1	3554318C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K48#159	18	TN	3554322C1	3554318C1
B	K48#139	18	OR	3554322C1	3554318C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K48#159	18	TN	3554322C1	3554318C1
B	K48#139	18	OR	3554322C1	3554318C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K48#159	18	TN	3554322C1	3554318C1
B	K48#139	18	OR	3554322C1	3554318C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

21.64. CONNECTOR COMPOSITES *(7604M), *(7605M), #(7606M), *(7607M), P. 56
Figure 1063 CONNECTOR COMPOSITES *(7604M), *(7605M), #(7606M), *(7607M)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.64. CONNECTOR COMPOSITES *(7604M), *(7605M), #(7606M), *(7607M), P. 56 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090672 NO. RELEASE NO. 95504E 05MAR20 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / LCT TURBINE SPEED SENSOR *(7607M) (LOCATED AT ENGINE COMPARTMENT TRANSMISSION) / CONNECTOR 3610533C1 BODY LOCK 3610532C1 / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2018-PROP-ENG,W/F-2018-GAS-ENG / LCT ENGINE SPEED SENSOR *(7604M) (LOCATED AT ENGINE COMPARTMENT TRANSMISSION) B A / CONNECTOR 3610533C1 BODY LOCK 3610532C1 / B A / WT MD OUTPUT SPEED SENSOR *(7605M) (LOCATED AT ENGINE COMPARTMENT TRANSMISSION / CONNECTOR 3610533C1 BODY LOCK 3610532C1 / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / WT MD OUTPUT SPEED SENSOR 6TH GEN #(7606M) (LOCATED IN ENGINE HARNESS) / CONNECTOR 3868823C1 BODY LOCK 3610532C1 / # F-2017-ISB-ENG,F-2021-B6.7-ENG W/COMMON FOR W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / B A / B A / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A K47#160 18 YL 3554322C1 3554318C1 B K47#140 18 LTGN 3554322C1 3554318C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A K48#159 18 TN 3554322C1 3554318C1 B K48#139 18 OR 3554322C1 3554318C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A K92#180 18 OR 3554322C1 3554318C1 B K92#120 18 LTBL 3554322C1 3554318C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A K47#160 18 YL 3554322C1 3554318C1 B K47#140 18 LTGN 3554322C1 3554318C1 / Figure 1063 / CONNECTOR COMPOSITES *(7604M), *(7605M), #(7606M), *(7607M)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K48#159	18	TN	3554322C1	3554318C1
B	K48#139	18	OR	3554322C1	3554318C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K47#160	18	YL	3554322C1	3554318C1
B	K47#140	18	LTGN	3554322C1	3554318C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K47#160	18	YL	3554322C1	3554318C1
B	K47#140	18	LTGN	3554322C1	3554318C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K92#180	18	OR	3554322C1	3554318C1
B	K92#120	18	LTBL	3554322C1	3554318C1

Figure 1064 CONNECTOR COMPOSITES *(7607M), *(7801M)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.65. CONNECTOR COMPOSITES *(7607M), *(7801M), P. 57 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090672 NO. RELEASE NO. 95504E 05MAR20 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2018-PROP-ENG,W/F-2018-GAS-ENG / B A / LCT TURBINE SPEED SENSOR *(7607M) (LOCATED AT ENGINE COMPARTMENT TRANSMISSION) / CONNECTOR 3610533C1 BODY LOCK 3610532C1 / J1939 TERM RESISTOR *(7801M) (LOCATED AT ENGINE COMPARTMENT TRANSMISSION) / CONNECTOR 3683465C1 BODY LOCK 3683466C1 / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2018-PROP-ENG,W/F-2018-GAS-ENG / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A K92#180 18 OR 3554322C1 3554318C1 B K92#120 18 LTBL 3554322C1 3554318C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A K5C(+) 20 YL 4083870C1 3535423C1 B K5C(-) 20 GN 4083870C1 3535423C1 / Figure 1064 / CONNECTOR COMPOSITES *(7607M), *(7801M)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K92#180	18	OR	3554322C1	3554318C1
B	K92#120	18	LTBL	3554322C1	3554318C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP-ENG,W/F-2018-GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K5C(+)	20	YL	4083870C1	3535423C1
B	K5C(-)	20	GN	4083870C1	3535423C1

21.66. CONNECTOR COMPOSITES @(7801M), @(7803), P. 58
Figure 1065 CONNECTOR COMPOSITES @(7801M), @(7803)

21.66. CONNECTOR COMPOSITES @(7801M), @(7803), P. 58 | Figure 1065 CONNECTOR COMPOSITES @(7801M), @(7803) | printed page 1065

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M5A(+)	18	YL	1661875C1	3568570C1
B	PLUG	-	-	2025431C1	-
C	M5A(-)	18	GN	1661875C1	3568570C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG, ; F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A*	K5J(+)	18	YL	3683464C1	3535424C1
A#	K5F(+)	20	YL	4083870C1	3535423C1
B*	K5J(-)	18	GN	3683464C1	3535424C1
B#	K5F(-)	20	GN	4083870C1	3535423C1

Legend: * W/500K ALLISON N/PAM 250K ; # W/500K EATON EPS N/PAM 250K ; @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A*	K5(+)	18	YL	3683464C1	3535424C1
B*	K5(-)	18	GN	3683464C1	3535424C1

21.67. CONNECTOR COMPOSITES *(7803), *(7808), *(7809), P. 59 | Figure 1066 CONNECTOR COMPOSITES *(7803), *(7808), *(7809) | printed page 1066

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K5E(+)	18	YL	3683464C1	3535424C1
B	K5E(-)	18	GN	3683464C1	3535424C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP-ENG,W/F-2018-GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A5D(-)	18	GN	3517243C1
2	A5D(+)	18	YL	3517243C1
3-4	PLUG	-	-	3518314C1
5	A92NE	18	DKBL	3517243C1
6	A92NF	18	TN	3517243C1
7	A92NG	18	TN	3517243C1
8	A92NH	18	TN	3517243C1
9-13	PLUG	-	-	3518314C1
14	A92NP	18	TN	3517243C1
15-16	PLUG	-	-	3518314C1
17	A#163A	18	PK	3517243C1
18	A92NT	18	TN	3517243C1
19	A92NU	18	TN	3517243C1
20	A92NV	18	TN	3517243C1
21-24	PLUG	-	-	3518314C1

Legend: * N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	A14MA	14	RD	3535486C1	1652325C1
B	A92MB	16	TN	2039343C1	1652325C1
C	A92MC	16	TN	2039343C1	1652325C1
D	A14MD-G	14	WH	3535486C1	0589391C1
E	A14ME-G	14	WH	3535486C1	0589391C1
F	A92MF	16	TN	2039343C1	1652325C1
G	A92MG	16	TN	2039343C1	1652325C1
H	A14MH	14	RD	3535486C1	1652325C1

Legend: * N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG

THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CIRCUIT DIAGRAM, PART NO. / INTENTIONALLY LEFT BLANK / CHAPTER 21 / INTENTIONALLY LEFT BLANK / Intentionally Left Blank / 21.68. INTENTIONALLY LEFT BLANK, P. 59A

THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / RELEASE NO. / PART NO. / INTENTIONALLY LEFT BLANK / CHAPTER 21 / INTENTIONALLY LEFT BLANK / Intentionally Left Blank / 21.69. INTENTIONALLY LEFT BLANK, P. 59B

21.70. CONNECTOR COMPOSITES (7850), (7852), (7875), P. 59C
Figure 1109 CONNECTOR COMPOSITES (7850), (7852), (7875)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.70. CONNECTOR COMPOSITES (7850), (7852), (7875), P. 59C / Figure 1109 / CONNECTOR COMPOSITES (7850), (7852), (7875)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.71. CONNECTOR COMPOSITES (7876), P. 59D / Figure 1110 / CONNECTOR COMPOSITES (7876)

21.71. CONNECTOR COMPOSITES (7876), P. 59D

Figure 1110 CONNECTOR COMPOSITES (7876)

21.68. CONNECTOR COMPOSITES *(7905A), *(8003A), P. 60
Figure 1067 CONNECTOR COMPOSITES *(7905A), *(8003A)

21.68. CONNECTOR COMPOSITES *(7905A), *(8003A), P. 60 | Figure 1067 CONNECTOR COMPOSITES *(7905A), *(8003A) | printed page 1067

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1-A3	PLUG	-	-	3554386C1
B1-B2	PLUG	-	-	3554386C1
B3	A62C	18	DKBL	3565443C1
C1	A92M	18	GY	3565443C1
C2-C3	PLUG	-	-	3554386C1
D1-D3	PLUG	-	-	3554386C1
E1-E3	PLUG	-	-	3554386C1
F1	A92(+)	18	YL	3565443C1
F2	A92(-)	18	GN	3565443C1
F3	PLUG	-	-	3554386C1
G1-G3	PLUG	-	-	3554386C1
H1	PLUG	-	-	3554386C1
H2	A92K	18	GY	3565443C1
H3	PLUG	-	-	3554386C1
J1-J2	PLUG	-	-	3554386C1
J3	A92P	18	GY	3565443C1
K1-K3	PLUG	-	-	3554386C1

Legend: * N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M11-GB	12	WH	2039313C1	0589390C1
B	M58AA	14	BN	3535486C1	0589391C1
C	M57A	14	OR	3535486C1	0589391C1
D	M56A	14	OR	3535486C1	0589391C1
E	M53B	12	YL	2039313C1	0589390C1
F	M52B	12	YL	2039313C1	0589390C1
G	M11-GC	12	WH	2039313C1	0589390C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

21.69. CONNECTOR COMPOSITES @(8003E), *(8004A), @(8004E), P. 61 | Figure 1068 CONNECTOR COMPOSITES @(8003E), *(8004A), @(8004E) | printed page 1068

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M11-GB	12	WH	2039313C1	0589390C1
B	M58AA	14	BN	3535486C1	0589391C1
C	M57A	14	OR	3535486C1	0589391C1
D	M56A	14	OR	3535486C1	0589391C1
E	M53B	12	YL	2039313C1	0589390C1
F	M52B	12	YL	2039313C1	0589390C1
G	M11-GC	12	WH	2039313C1	0589390C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK W/F-2018-PROPANE/

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M53A	12	YL	2033816C1	0589390C1
B	M52A	12	YL	2033816C1	0589390C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M53A	12	YL	2033816C1	0589390C1
B	M52A	12	YL	2033816C1	0589390C1

21.70. CONNECTOR COMPOSITES @(8310), @(8310A), @(8310E), P. 62
Figure 1069 CONNECTOR COMPOSITES @(8310), @(8310A), @(8310E)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 21.70. CONNECTOR COMPOSITES @(8310), @(8310A), @(8310E), P. 62 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090672 NO. RELEASE NO. 95504E 06MAR20 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED R/D 8310E & FUSE DETAILS. / A B / CONNECTOR 1661778C1 BODY LOCK 1661874C1 / HORN @(8310) (LOCATED AT ENGINE COMPARTMENT NEAR BUMPER) / HORN @(8310A) (LOCATED AT ENGINE COMPARTMENT NEAR BUMPER) / A B / CONNECTOR 1661778C1 BODY LOCK 1661874C1 / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK * W/F-2017-ISB-ENG,F-2021-B6.7-ENG % W/F-2018-PROPANE/GASOLINE-ENG / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG, F-2021-B6.7-ENG,F-2018-PROP/GAS-ENG / HORN @(8310E) (LOCATED AT ENGINE COMPARTMENT NEAR BUMPER) / CONNECTOR 1661778C1 BODY LOCK 1661874C1 / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2018-PROPANE/ GASOLINE-ENG / A B / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A@ M85A 16 GY 1661875C1 1661872C1 B* M85-GA 16 WH 1661875C1 1661872C1 B% M85-GA 16 GY 1661875C1 1661872C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A M85A 16 GY 1661875C1 1661872C1 B M85-GA 16 WH 1661875C1 1661872C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A M85A 16 GY 1661875C1 1661872C1 B M85-GA 16 GY 1661875C1 1661872C1 / Figure 1069 / CONNECTOR COMPOSITES @(8310), @(8310A), @(8310E)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M85A	16	GY	1661875C1	1661872C1
B	M85-GA	16	WH	1661875C1	1661872C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG, ; F-2021-B6.7-ENG,F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A@	M85A	16	GY	1661875C1	1661872C1
B*	M85-GA	16	WH	1661875C1	1661872C1
B%	M85-GA	16	GY	1661875C1	1661872C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * W/F-2017-ISB-ENG,F-2021-B6.7-ENG ; % W/F-2018-PROPANE/GASOLINE-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M85A	16	GY	1661875C1	1661872C1
B	M85-GA	16	GY	1661875C1	1661872C1

21.71. CONNECTOR COMPOSITES @(8331), #(8585), #(8585A), @(8601), P. 63 | Figure 1070 CONNECTOR COMPOSITES @(8331), #(8585), #(8585A), @(8601) | printed page 1070

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	A74B	16	RD	3545087C1
1#	A74	16	LTGN	3545087C1
1%	A74P	16	RD	3545087C1
2*	A74-GA	16	WH	3545087C1
2%	A74-G	16	WH	3545087C1
3#	A74A	16	LTGN	3545087C1
3*	A74C	18	LTGN	3902785C1
3%	A74C	16	LTGN	3545087C1
4*	A74D	18	LTGN	3902785C1
4#	A74B	16	LTGN	3545087C1
4%	A74D	16	LTGN	3545087C1

Legend: * W/BOOSTER PUMP ; # N/BOOSTER PUMP ; % W/FRONT HTR CONTROL BY TIMER BOOSTER PUMP BY SW ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[M137P]	24	RD	ASSY
2	[M137G]	24	BK	ASSY
3	[M137A]	24	BL	ASSY
4	[M137V]	24	WH	ASSY

Legend: # W/COMMON FOR W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK.

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[M137P]	24	RD	ASSY
2	[M137G]	24	BK	ASSY
3	[M137A]	24	BL	ASSY
4	[M137V]	24	WH	ASSY

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A@	M41	18	TN	1661875C1	1661872C1
B*	M110AD	18	GY	1661875C1	1661872C1
B#	M110AD	18	GY	1661875C1	3568570C1

21.72. CONNECTOR COMPOSITES @(8903), #(8904), P. 64 | Figure 1071 CONNECTOR COMPOSITES @(8903), #(8904) | printed page 1071

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M5B(+)	18	YL	4062164C1	4062195C1
2	M5UE(+)	18	YL	4062164C1	4062195C1
3-4	PLUG	-	-	3987171C1	-
5	M67-GA	18	WH	4062164C1	4062195C1
6	M5B(-)	18	GN	4062164C1	4062195C1
7	M5UE(-)	18	GN	4062164C1	4062195C1
8	M13AA	18	PK	4062164C1	4062195C1
9-10	PLUG	-	-	3987171C1	-

Legend: % W/FRONT HTR CONTROL BY TIMER BOOSTER PUMP BY SW ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

CIRCUIT	GA	COLOR	TERMINAL
M13AA	20	PK	3702881C1
M13AB	20	PK	3702881C1
PLUG	-	-	3600328C1
M5E(-)	20	GN	3702881C1
M5E(-)	20	GN	3702881C1
PLUG	-	-	3600328C1
M5E(+)	20	YL	3702881C1
M5E(+)	20	YL	3702881C1
M67-GA	20	WH	3702881C1
M67-GB	20	WH	3702881C1

Legend: # W/COMMON FOR W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK.

Figure 1072 CONNECTOR COMPOSITES *(9001), @(9003), *(9004), *(9004A)

CONNECTOR COMPOSITE (9001-9996) (CHAPTER 22) | Figure 1072 CONNECTOR COMPOSITES *(9001), @(9003), *(9004), *(9004A) | printed page 1072

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M75B	18	LTGN	3509874C1	3509903C1
2	M75-GB	18	WH	3509874C1	3509903C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R75A	14	YL	2033816C1	0589391C1
B	R75C	14	DKBL	2033816C1	0589391C1
C	R75	10	RD	1687847C1	0589390C1
D*	R75-GA	10	WH	1687847C1	0589390C1
D#	R75-GD	10	WH	1687847C1	0589390C1
E	R75B	14	LTGN	2033816C1	0589391C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	R75BB	18	BK	3509874C1	3509903C1
2	R75-GE	18	WH	3509874C1	3509903C1

22.2. CONNECTOR COMPOSITES *(9005), *(9006), P. 2 | Figure 1073 CONNECTOR COMPOSITES *(9005), *(9006) | printed page 1073

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R75-GA	10	WH	1687848C1	0589390C1
B	R75B	14	LTGN	2033912C1	0589391C1
C	R75	10	RD	1687848C1	0589390C1
D	R75A	14	YL	2033912C1	0589391C1
E	R75C	14	DKBL	2033912C1	0589391C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M75-GA	10	WH	1687847C1	0589390C1
B	M75B	18	LTGN	2033819C1	1652325C1
C	M75	10	LTGN	1687847C1	0589390C1
D	M75A	18	LTGN	2033819C1	1652325C1
E	M75C	16	DKBL	2033819C1	1652325C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M75-GD	10	WH	3512334C1	0589390C1
B	M75B	18	LTGN	2039343C1	1652325C1
C	M75	10	LTGN	3512334C1	0589390C1
D	M75A	18	LTGN	2039343C1	1652325C1
E	M75B	18	LTGN	2039343C1	1652325C1
F	M75-GE	18	WH	2039343C1	1652325C1
G	M75C	16	DKBL	2039343C1	1652325C1

22.3. CONNECTOR COMPOSITES *(9006), *(9007), *(9007A), P. 3 | Figure 1074 CONNECTOR COMPOSITES *(9006), *(9007), *(9007A) | printed page 1074

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R75-GD	10	WH	1687848C1	0589390C1
B	R75B	14	LTGN	2033912C1	0589391C1
C	R75	10	RD	1687848C1	0589390C1
D	R75A	14	YL	2033912C1	0589391C1
E	R75BB	18	BK	2033911C1	1652325C1
F	R75-GE	18	WH	2033911C1	1652325C1
G	R75C	14	DKBL	2033912C1	0589391C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R75A	14	YL	2033816C1	0589391C1
B	R75C	14	DKBL	2033816C1	0589391C1
C	R75	10	RD	1687847C1	0589390C1
D	R75-GD	10	WH	1687847C1	0589390C1
E	R75B	14	LTGN	2033816C1	0589391C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R75A	14	YL	2033816C1	0589391C1
B	R75C	14	DKBL	2033816C1	0589391C1
C	R75	10	RD	1687847C1	0589390C1
D	R75-GD	10	WH	1687847C1	0589390C1
E	R75B	14	LTGN	2033816C1	0589391C1

22.4. CONNECTOR COMPOSITES *(9008), *(9009), *(9100), P. 4 | Figure 1075 CONNECTOR COMPOSITES *(9008), *(9009), *(9100) | printed page 1075

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	R75BB	18	BK	3509874C1	3509903C1
2	R75-GE	18	WH	3509874C1	3509903C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M75A	18	LTGN	2033819C1	1652325C1
B	M75C	16	LTGN	2033819C1	1652325C1
C	M75	10	LTGN	1687847C1	0589390C1
D	M75-G	10	WH	1687847C1	0589390C1
E	M75B	18	LTGN	2033819C1	1652325C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M36	18	TN	2033819C1	3517771C1
B	M9D	18	GY	2033819C1	3517771C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R36	18	BK	2033911C1	1652325C1
B	R9D	18	WH	2033911C1	1652325C1

22.5. CONNECTOR COMPOSITES @(9100), P. 5 | Figure 1076 CONNECTOR COMPOSITES @(9100) | printed page 1076

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	M148C	10	RD	3612308C1
1#	M36CB	10	RD	3612308C1
2	M148A	12	TN	3612308C1
3	M148B	14	TN	3618273C1
4*	M148D	14	TN	3618273C1
4#	M36D	14	TN	3618273C1
5*	M148E	14	TN	3618273C1
5#	M37E	14	TN	3618273C1
6	M148F	14	TN	3618273C1
7	M148-G	10	WH	3612308C1
8	M37GB	10	WH	3612308C1
9*	M148H	12	TN	3612308C1
9#	M37H	12	TN	3612308C1
10*	M148J	12	TN	3612308C1
10#	M37J	12	TN	3612308C1
11*	M148K	12	TN	3612308C1
11#	M37K	12	TN	3612308C1
12	M148L	18	TN	3618272C1
13	M148M	18	TN	3618272C1
14	M37CA	12	TN	3612308C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT FUSE BLOCK ; * W/PROPANE FUEL TANK,BTR ; # W/GAS FUEL TANK,BTR

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	R148C	10	TN	3612307C1
1#	R36C	10	TN	3612307C1
2	R148A	12	TN	3612307C1
3	R148B	14	TN	3613770C1
4*	R148D	14	TN	3613770C1
4#	R36D	14	TN	3613770C1
5*	R148E	14	TN	3613770C1
5#	R37E	14	TN	3613770C1
6	R148F	14	TN	3613770C1
7	R148-G	10	TN	3612307C1
8	R37GE	10	GY	3612307C1
9	R148H	12	TN	3612307C1
9	R37H	16	TN	3613770C1
10*	R148J	12	TN	3612307C1
10#	R37J	16	TN	3613770C1
11*	R148K	12	TN	3612307C1
11#	R37K	16	TN	3613770C1
12	R148L	18	TN	3613771C1
13	R148M	18	TN	3613771C1
14*	R37CA	12	TN	0557375C1
14#	R37CA	12	TN	3612307C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT FUSE BLOCK ; * W/PROPANE FUEL TANK ; # W/GAS FUEL TANK

Figure 1077 CONNECTOR COMPOSITES *(9100A), *(9100B), *(9101)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 22.6. CONNECTOR COMPOSITES *(9100A), *(9100B), *(9101), P. 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090673 NO. RELEASE NO. 95504E 02MAR20 / CHAPTER 22 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / FUEL GAUGE LEVEL SENSOR *(9101) (LOCATED ON FUEL TANK) / CONNECTOR 1671611C1 BODY LOCK 1671608C1 / CONNECTOR 1661778C1 BODY LOCK 1661874C1 / A B / AF FUEL SENDER *(9101) (LOCATED NEAR FUEL TANK) / A B / CONNECTOR 1661778C1 BODY LOCK 1661874C1 / FUEL CONNECTION FUEL CONNECTION ABS (40GAL) ABS (65GAL) *(9100A) *(9100B) (LOCATED NEAR FUEL TANK) / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A R36 18 BK 2033911C1 1652325C1 B R9D 18 WH 2033911C1 1652325C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A RC36 18 BK 1661875C1 1661872C1 B RG9D 18 WH 1661875C1 1661872C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A M36 18 TN 1661875C1 3568570C1 B M9D 18 GY 1661875C1 3568570C1 / Figure 1077 / CONNECTOR COMPOSITES *(9100A), *(9100B), *(9101)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R36	18	BK	2033911C1	1652325C1
B	R9D	18	WH	2033911C1	1652325C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	RC36	18	BK	1661875C1	1661872C1
B	RG9D	18	WH	1661875C1	1661872C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M36	18	TN	1661875C1	3568570C1
B	M9D	18	GY	1661875C1	3568570C1

22.7. CONNECTOR COMPOSITES *(9101), *(9101A), *(9101B), #(9101E), P. 7 | Figure 1078 CONNECTOR COMPOSITES *(9101), *(9101A), *(9101B), #(9101E) | printed page 1078

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	R148CB	10	TN	3612307C1
2	R148A	12	TN	3612307C1
3	R148B	14	TN	3613770C1
4	R148D	14	TN	3613770C1
5	R148E	14	TN	3613770C1
6	R148F	14	TN	3613770C1
7	R148-GB	10	TN	3612307C1
8	PLUG	-	-	3573076C1
9	R148H	12	TN	3612307C1
10	R148J	12	TN	3612307C1
11	R148K	12	TN	3612307C1
12	R148L	18	TN	3613771C1
13	R148M	18	TN	3613771C1
14	PLUG	-	-	3573076C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R36	18	BK	1661875C1	1661872C1
B	R9D	18	WH	1661875C1	1661872C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R36	18	BK	1661875C1	1661872C1
B	R9D	18	WH	1661875C1	3568570C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M36	18	TN	1661875C1	3568570C1
B	M9D	18	GY	1661875C1	3568570C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	R36	16	BK	1661875C1
B	RY9	16	WH	1661875C1

22.8. CONNECTOR COMPOSITES *(9120), *(9123), *(9125), *(9126), P. 8 | Figure 1079 CONNECTOR COMPOSITES *(9120), *(9123), *(9125), *(9126) | printed page 1079

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	R37K	16	TN	3535303C1	3535424C1
2	R37J	16	TN	3535303C1	3535424C1
3	R37H	16	TN	3535303C1	3535424C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R37GGB	10	GY	3535300C1	3535429C1
B	R37E	14	TN	3534163C1	3535428C1
C	R36D	14	TN	3534163C1	3535428C1
D	R36CB	10	TN	3535300C1	3535429C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R37C	18	TN	1661875C1	1661872C1
B	R37GB	16	GY	1661875C1	1661872C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R37G	10	GY	1687847C1	0589390C1
B	R37GG	10	GY	1687847C1	0589390C1
C	R37GC	10	GY	1687847C1	0589390C1
D	PLUG	-		0587579C1	-
E	PLUG	-		0587579C1	-
F	PLUG	-		0587579C1	-

22.9. CONNECTOR COMPOSITES *(9127), @(9257), *(9257), #(9257E), @(9260), P. 9 | Figure 1080 CONNECTOR COMPOSITES *(9127), @(9257), *(9257), #(9257E), @(9260) | printed page 1080

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R37C	18	TN	1661875C1	1661872C1
B	R37GB	16	GY	1661875C1	1661872C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M39C	14	BK	2033816C1	0589391C1
B	M39C-G	14	WH	2033816C1	0589391C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M39C	14	BK	2033816C1	0589391C1
B	M39C-G	14	WH	2033816C1	0589391C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	R36	16	BK	1661875C1
B	RY9	16	WH	1661875C1

Legend: # W/COMMON FOR W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	PLUG	-	-	1675451C1	-
B#	K92A109	10	WH	2025425C1	1667735C1
B*	K10-GC	16	WH	1667736C1	1664232C1
C*	K95-GG	12	WH	2025424C1	1671603C1
C#	K95-GG	10	WH	2025425C1	1667735C1

22.10. CONNECTOR COMPOSITES *(9260), *(9261), P. 10 | Figure 1081 CONNECTOR COMPOSITES *(9260), *(9261) | printed page 1081

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A#	K77H-G	16	WH	1667736C1	1664232C1
A%	K77HA-G	10	WH	2025425C1	1667735C1
B	K92A109	10	WH	2025425C1	1667735C1
C	K97-G	12	WH	2025424C1	1671603C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A#	K77H-G	16	WH	1667736C1	1664232C1
A%	K77HA-G	10	WH	2025425C1	1667735C1
B	K92A109	10	WH	2025425C1	1667735C1
C	K97-G	12	WH	2025424C1	1671603C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	PLUG	-	-	1675451C1	-
B	K92A110	10	RD	1667737C1	1667735C1
C	K97	10	RD	1667737C1	1667735C1

22.11. CONNECTOR COMPOSITES *(9261), @(9261), @(9262), P. 11
Figure 1082 CONNECTOR COMPOSITES *(9261), @(9261), @(9262)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 22.11. CONNECTOR COMPOSITES *(9261), @(9261), @(9262), P. 11 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090673 NO. RELEASE NO. 95504E 03MAR20 / CHAPTER 22 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / ARENS SHIFTER POSITIVE @(9262) (LOCATED AT STARTER MOTOR ENGINE COMPARTMENT) / CONNECTOR 1667733C1 BODY LOCK 1667734C1 / BATT POSTIVE CLEAN POWER *(9261) (LOCATED AT BATTERY CABLES) / CONNECTOR 1664531C1 BODY LOCK 1675053C1 / BATT ECM POSITIVE CONN @(9261) (LOCATED AT BATTERY CABLES) / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2018-PROP-ENG / C B A / C B A / CONNECTOR 1667733C1 BODY LOCK 1667734C1 / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A K26B 16 TN 2033819C1 1652325C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A K14E 12 RD 1667737C1 1671603C1 B K92A110 10 RD 1667737C1 1667735C1 C K97 10 VT 1667737C1 1667735C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A PLUG - - 1675451C1 - B K92A110 10 RD 1667737C1 1667735C1 C K97 10 RD 1667737C1 1667735C1 / Figure 1082 / CONNECTOR COMPOSITES *(9261), @(9261), @(9262)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	PLUG	-	-	1675451C1	-
B	K92A110	10	RD	1667737C1	1667735C1
C	K97	10	RD	1667737C1	1667735C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K14E	12	RD	1667737C1	1671603C1
B	K92A110	10	RD	1667737C1	1667735C1
C	K97	10	VT	1667737C1	1667735C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K26B	16	TN	2033819C1	1652325C1

22.12. CONNECTOR COMPOSITES *(9266), *(9267), *(9267A), P. 12 | Figure 1083 CONNECTOR COMPOSITES *(9266), *(9267), *(9267A) | printed page 1083

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A95C	18	PK	1661224C1
2	A95A	18	GY	1661224C1
3	A11-GL	18	WH	3541250C1
3	A11-GEW	18	WH	3541250C1
4-8	-	-	-	-
9	A11-GEW	18	WH	1661224C1
10	A95B	18	GY	1661224C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A9K	18	GY	1661261C1
B	A44CC	18	GY	1661261C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A44CC	18	GY	3686943C1
2	A9K	18	GY	3686943C1
3	A59A	18	GY	3686943C1
4	A90-G	18	WH	3686943C1
5-6	PLUG	-	-	3833742C1

22.13. CONNECTOR COMPOSITES @(9501), #(9501E), @(9502), P. 13 | Figure 1084 CONNECTOR COMPOSITES @(9501), #(9501E), @(9502) | printed page 1084

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	R94DA	16	GY	1680205C1
1#	R94A	16	GY	1680205C1
2	R94DB	16	GY	1680205C1
2	R94B	16	GY	1680205C1

Legend: # W/BENDIX AIR ABS W/EC-80 ; * W/BENDIX AIR ABS ; @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	R94LR+	16	GY	1680205C1
1#	R94DL+	16	GY	1680205C1
2*	R94LR-	16	OR	1680205C1
2#	R94DL-	16	OR	1680205C1

Legend: * W/BENDIX AIR BRAKE ; # BENDIX AIR BRAKE W/ABS-6 ; @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	R94A	16	GY	1680205C1
2	R94B	16	GY	1680205C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	R94A	16	GY	1680205C1
2	R94B	16	GY	1680205C1

22.14. CONNECTOR COMPOSITES @(9503), #(9503E), @(9504), @(9506), P. 14
Figure 1085 CONNECTOR COMPOSITES @(9503), #(9503E), @(9504), @(9506)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 22.14. CONNECTOR COMPOSITES @(9503), #(9503E), @(9504), @(9506), P. 14 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090672 NO. RELEASE NO. 95504E 04MAR20 / CHAPTER 21 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED R/D 4039 AND NOTES FOR FUSE BLOCK. / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2018-PROPANE-ENG,W/F-2018-GASOLINE-ENG / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / CONNECTOR 3854645C91 / HYDROMAX BRAKE PRESSURE *(4037) (LOCATED INSIDE ENGINE COMPARTMENT) / B A / HYDROMAX FLOW SWITCH *(4038) (LOCATED IN ENGINE COMPARTMENT) / CONNECTOR 2036584C1 / B A / HYDROMAX FLOW SWITCH *(4038) (LOCATED INSIDE ENGINE COMPARTMENT) / CONNECTOR 2036584C1 / HYDROMAX DIFF PRESSURE #(4039) (LOCATED IN POWETRAIN HARNESS) / CONNECTOR 3518873C91 / # W/COMMON FOR W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK. / A B / CAV CIRCUIT GA COLOR TERMINAL 1 K90H 16 GY 3572625C1 2 K90X 14 GY 3711481C1 / CAV CIRCUIT GA COLOR TERMINAL A K90CC 16 GY 2036586C1 B K90-GA 16 WH 2036586C1 / CAV CIRCUIT GA COLOR TERMINAL A [K90CB] 16 - V-TERM B [K90D] 16 - V-TERM / Figure 1085 / CONNECTOR COMPOSITES @(9503), #(9503E), @(9504), @(9506)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K90H	16	GY	3572625C1
2	K90X	14	GY	3711481C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K90CC	16	GY	2036586C1
B	K90-GA	16	WH	2036586C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	K90CC	16	GY	2036586C1
B	K90-GA	16	WH	2036586C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	[K90CB]	16	-	V-TERM
B	[K90D]	16	-	V-TERM

22.15. CONNECTOR COMPOSITES @(9507), #(9507E), *(9508), @(9508), P. 15 | Figure 1086 CONNECTOR COMPOSITES @(9507), #(9507E), *(9508), @(9508) | printed page 1086

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M94R+	16	DKBL	1680205C1
2	M94R-	16	YL	1680205C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M94RA	16	GY	1680205C1
2#	M94RB	16	GY	1680205C1
2*	M94RB	16	YL	1680205C1

Legend: # W/BENDIX AIR ABS W/ATC ; * W/BENDIX AIR ABS ; @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M94RA	16	GY	3572625C1
2	M94RB	16	GY	3572625C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M94LA	16	GY	1680205C1
2	M94LB	16	GY	1680205C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M94L+	16	GY	1680205C1
2	M94L-	16	GY	1680205C1

22.16. CONNECTOR COMPOSITES *(9509), @(9510), @(9511), P. 16 | Figure 1087 CONNECTOR COMPOSITES *(9509), @(9510), @(9511) | printed page 1087

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M94BA	16	GY	1680205C1
2	M94BB	16	GY	1680205C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M90AA-G	12	WH	3573654C1	3573655C1
2	M90A	12	GY	3573654C1	3615148C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M90C	18	GY	3573652C1	3573653C1
2	PLUG	-	-	3577748C1	-
3	M90F	18	GY	3573652C1	3573653C1
4	M44B	18	GY	3573652C1	3573653C1
5	M44C	18	GY	3573652C1	3573653C1
6	M90B-G	18	WH	3573652C1	3573653C1
7	M44D	18	GY	3573652C1	3573653C1
8	PLUG	-	-	3577748C1	-
9	M90H	18	GY	3573652C1	3573653C1
10	M90B	18	GY	3573652C1	3573653C1
11	M44A	18	GY	3573652C1	3573653C1
12-13	PLUG	-	-	3577748C1	-
14	M5(+)	18	YL	3573652C1	3573653C1
15	M5(-)	18	GN	3573652C1	3573653C1
16	M90	12	GY	3573654C1	3615148C1
17	M94L	12	GY	3573654C1	3573655C1
18	M90-GA	12	WH	3573654C1	3573655C1
19	M94-GB	12	WH	3573654C1	3573655C1
20-21	PLUG	-	-	3577748C1	-
22	M94RR+	18	DKBL	3573652C1	3573653C1
23	M94LR-	18	OR	3573652C1	3573653C1
24	[M94L-]	18	BN	3573652C1	3573653C1
25	[M94R-]	18	BN	3573652C1	3573653C1
26	M3C-	18	GY	3573652C1	3573653C1
27	M94RR-	18	YL	3573652C1	3573653C1
28	M94LR+	18	GY	3573652C1	3573653C1
29	[M94L+]	18	BK	3573652C1	3573653C1
30	[M94R+]	18	BK	3573652C1	3573653C1
31	M3C+	18	DKBL	3573652C1	3573653C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

22.17. CONNECTOR COMPOSITES @(9511E), *(9511E), P. 17 | Figure 1088 CONNECTOR COMPOSITES @(9511E), *(9511E) | printed page 1088

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M90A	10	GY	3592378C1	3592377C1
2-7	-	-	-	-	-
8	M90C	18	PK	3590850C1	-
9-11	-	-	-	-	-
12	M5(+)	20	YL	3590850C1	-
13	M5(-)	20	GN	3590850C1	-
14-17	-	-	-	-	-
18	M152(+)	18	YL	3590850C1	-
19	M152(-)	18	GN	3590850C1	-
20-21	-	-	-	-	-
22	M152E	18	RD	3590850C1	-
23-28	-	-	-	-	-
29	M152F	18	BK	3590850C1	-
30-31	-	-	-	-	-
32	M94L	10	GY	3592378C1	3592377C1
33	[M94R-]	18	BN	3590850C1	-
34	[M94R+]	18	BK	3590850C1	-
35	-	-	-	-	-
36	M94LR+	18	TN	3590850C1	-
37	M94LR-	18	TN	3590850C1	-
38-41	-	-	-	-	-
42	M94RR-	18	TN	3590850C1	-
43	M94RR+	18	TN	3590850C1	-
44	-	-	-	-	-
45	[M94L+]	18	BK	3590850C1	-
46	[M94L-]	18	BN	3590850C1	-
47	M90-G	10	WH	3592378C1	3592377C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M90A	10	GY	3592378C1	3592377C1
2-7	-	-	-	-	-
8	M90C	18	PK	3590850C1	-
9-11	-	-	-	-	-
12	M5(+)	18	YL	3590850C1	-
13	M5(-)	18	GN	3590850C1	-
14-17	-	-	-	-	-
18	M152(+)	18	YL	3590850C1	-
19	M152(-)	18	GN	3590850C1	-
20-21	-	-	-	-	-
22	M152E	18	RD	3590850C1	-
23-28	-	-	-	-	-
29	M152F	18	BK	3590850C1	-
30-31	-	-	-	-	-
32	M94L	10	GY	3592378C1	3592377C1
33	[M94R-]	18	BN	3590850C1	-
34	[M94R+]	18	BK	3590850C1	-
35	-	-	-	-	-
36	M94LR+	18	TN	3590850C1	-
37	M94LR-	18	TN	3590850C1	-
38-41	-	-	-	-	-
42	M94RR-	18	TN	3590850C1	-
43	M94RR+	18	TN	3590850C1	-
44	-	-	-	-	-
45	[M94L+]	18	BK	3590850C1	-
46	[M94L-]	18	BN	3590850C1	-
47	M90-G	10	WH	3592378C1	3592377C1

22.18. CONNECTOR COMPOSITES *(9511K), P. 18
Figure 1089 CONNECTOR COMPOSITES *(9511K)

22.18. CONNECTOR COMPOSITES *(9511K), P. 18 | Figure 1089 CONNECTOR COMPOSITES *(9511K) | printed page 1089

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M90A	10	GY	3592378C1	3592377C1
2-7	-	-	-	-	-
8	M90C	18	PK	3590850C1	-
9-11	-	-	-	-	-
12	M5(+)	18	YL	3590850C1	-
13	M5(-)	18	GN	3590850C1	-
14-31	-	-	-	-	-
32	M94L	10	GY	3592378C1	3592377C1
33	[M94S-]	18	BN	3590850C1	-
34	[M94S+]	18	BK	3590850C1	-
35	-	-	-	-	-
36	M94+	18	TN	3590850C1	-
37	M94-	18	TN	3590850C1	-
38-41	-	-	-	-	-
42	M94R-	18	TN	3590850C1	-
43	M94R+	18	TN	3590850C1	-
44	-	-	-	-	-
45	[M94L+]	18	BK	3590850C1	-
46	[M94L-]	18	BN	3590850C1	-
47	M90-G	10	WH	3592378C1	3592377C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M90A	10	GY	3592378C1	3592377C1
2-7	-	-	-	-	-
8	M90C	18	PK	3590850C1	-
9-11	-	-	-	-	-
12	M5(+)	20	YL	3590850C1	-
13	M5(-)	20	GN	3590850C1	-
14-31	-	-	-	-	-
32	M94L	10	GY	3592378C1	3592377C1
33	[M94R-]	18	BN	3590850C1	-
34	[M94R+]	18	BK	3590850C1	-
35	-	-	-	-	-
36	M94LR+	18	TN	3590850C1	-
37	M94LR-	18	TN	3590850C1	-
38-41	-	-	-	-	-
42	M94RR-	18	TN	3590850C1	-
43	M94RR+	18	TN	3590850C1	-
44	-	-	-	-	-
45	[M94L+]	18	BK	3590850C1	-
46	[M94L-]	18	BN	3590850C1	-
47	M90-G	10	WH	3592378C1	3592377C1

22.19. CONNECTOR COMPOSITES @(9512), *(9513), @(9513), P. 19 | Figure 1090 CONNECTOR COMPOSITES @(9512), *(9513), @(9513) | printed page 1090

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	R94S	16	LTGN	3554090C1
A2-A3	-	-	-	-
B1	R94T	16	LTBL	3554090C1
B2-B3	-	-	-	-
C1	R94R	16	VT	3554090C1
C2-C3	-	-	-	-
D1	R94M	16	BK	3554090C1
D2	R94A	16	DKBL	3554090C1
D3	R94B	16	YL	3554090C1
E1	R94P	16	BN	3554090C1
E2	R94RR-	16	DKBL	3554090C1
E3	R94RR+	16	YL	3554090C1
F1	R94N	16	RD	3554090C1
F2	R94LR-	16	OR	3554090C1
F3	R94LR+	16	GY	3554090C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M94BC	16	GY	1680205C1
2	M94BD	16	GY	1680205C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M152G	16	GY	3679224C1	3601687C1
2	M152H	16	GY	3679224C1	3601687C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M152G	16	GY	3679224C1	3601687C1
2	M152H	16	GY	3679224C1	3601687C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

22.20. CONNECTOR COMPOSITES #(9513A), #(9513E), #(9513EA), P. 19A | Figure 1091 CONNECTOR COMPOSITES #(9513A), #(9513E), #(9513EA) | printed page 1091

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M152G	16	GY	3679224C1
2	M152H	16	GY	3679224C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M94A	16	GY	3559035C1
2	M94B	16	GY	3559035C1
3	M94C	16	GY	3559035C1
4	M94D	16	GY	3559035C1
5	M94E	14	GY	3559035C1
6	M94F	14	GY	3559035C1
7	M94H	14	GY	3559035C1
8	M94J	14	GY	3559035C1
9	M94K	14	GY	3559035C1
10	M94L	14	GY	3559035C1
11	M152A	16	GY	3559035C1
12	M152B	16	GY	3559035C1
13	M9	18	GY	3509874C1
14	M36	18	TN	3509874C1
15	M39C	14	BK	3559035C1
16	M39C-G	14	WH	3559035C1
17	M86CA	18	LT GN	3509874C1
18	M86DA	18	LT GN	3509874C1
19	M71A	16	LT BL	3559035C1
20	M71B	16	WH	3559035C1

Legend: # W/COMMON FOR W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M86CA	18	LT GN	3618272C1
2	M86DA	18	LT GN	3618272C1
3	M71A	16	LT BL	3618273C1
4	M71B	16	WH	3618273C1

Legend: # W/COMMON FOR W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK

22.21. CONNECTOR COMPOSITES #(9513FE), P. 19B
Figure 1092 CONNECTOR COMPOSITES #(9513FE)

22.21. CONNECTOR COMPOSITES #(9513FE), P. 19B | Figure 1092 CONNECTOR COMPOSITES #(9513FE) | printed page 1092

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	R94A	16	GY	3559037C1
2	R94B	16	GY	3559037C1
3	R94C	16	GY	3559037C1
4	R94D	16	GY	3559037C1
5	R94E	12	GY	3559037C1
6	R94F	12	GY	3559037C1
7	R94H	12	GY	3559037C1
8	R94J	12	GY	3559037C1
9	R94K	12	GY	3559037C1
10	R94L	12	GY	3559037C1
11	R152A	16	GY	3559037C1
12	R152B	16	GY	3559037C1
13	R9	16	WH	3559037C1
14	R36	16	BK	3559037C1
15	R39C	14	BK	3559037C1
16	R39C-G	14	WH	3559037C1
17	R86CA	18	LT GN	3559036C1
18	R86DA	18	LT GN	3559036C1
19	R71A	16	LT BL	3559037C1
20	R71B	16	WH	3559037C1

Legend: # W/COMMON FOR W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK

22.22. CONNECTOR COMPOSITES *(9513F), @(9513F), P. 20 | Figure 1093 CONNECTOR COMPOSITES *(9513F), @(9513F) | printed page 1093

CAV	CIRCUIT	GA	COLOR	TERMINAL
1&	M94+	18	TN	3613771C1
1#	M94LR+	18	TN	3613771C1
2&	M94-	18	TN	3613771C1
2#	M94LR-	18	TN	3613771C1
3&	M94R-	18	TN	3613771C1
3#	M94RR-	18	TN	3613771C1
4&	M94R+	18	TN	3613771C1
4#	M94RR+	18	TN	3613771C1

Legend: & W/HYDRAULIC BRAKES WABCO MK25 W/BENDIX AIR CPRSR ; # W/HYDRAULIC BRAKES WABCO MK25 W/STABILITY CONTROL ; * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	R94A	16	GY	3618273C1
2	R94B	16	GY	3618273C1
3	R94C	16	GY	3618273C1
4	R94D	16	GY	3618273C1
5	R94E	12	GY	3612308C1
6	R94F	12	GY	3612308C1
7	R94H	12	GY	3612308C1
8	R94J	12	GY	3612308C1
9	R94K	12	GY	3612308C1
10	R94L	12	GY	3612308C1
11	R152A	16	GY	3618273C1
12	R152B	16	GY	3618273C1
13-14	PLUG	-	-	3573076C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	R94A	16	GY	3618273C1
2*	R94B	16	GY	3618273C1
2#	[RBKLR]	18	BK	3618272C1
3*	R94C	16	GY	3618273C1
3#	[RBNLR]	18	BN	3618272C1
4*	R94D	16	GY	3618273C1
4#	[RBNRR]	18	BN	3618272C1
5*	R94E	16	GY	3618273C1
5#	[RBKRR]	18	BK	3618272C1
6*	R94F	16	GY	3618273C1
6%	R44C	18	RD	3618272C1
7	R44N	18	GY	3618272C1
7*	R94H	16	GY	3618273C1
7%	R44D	18	BN	3618272C1
8	R94J	16	GY	3618273C1
9*	R94K	16	GY	3618273C1
9%	R94-GE	18	GN	3618272C1
10	R44-GB	18	WH	3618272C1
10*	R94L	16	GY	3618273C1
10%	R90D-G	18	BN	3618272C1
11&	R44M	18	GY	3618272C1
11*	R152A	16	GY	3618273C1
11%	R90D	18	YL	3618272C1
12	R152B	16	GY	3618273C1
13	R9D	18	WH	3618272C1
14	R36	18	BK	3618272C1

Legend: REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 03MAR20 AE08090673 020

22.23. CONNECTOR COMPOSITES *(9513M), @(9513M), P. 21 | Figure 1094 CONNECTOR COMPOSITES *(9513M), @(9513M) | printed page 1094

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M94A	16	GY	3613770C1
2	M94B	16	GY	3613770C1
3	M94C	16	GY	3613770C1
4	M94D	16	GY	3613770C1
5	M94E	14	GY	3613770C1
6	M94F	14	GY	3613770C1
7	M94H	14	GY	3613770C1
8	M94J	14	GY	3613770C1
9	M94K	14	GY	3613770C1
10	M94L	14	GY	3613770C1
11	M152A	16	GY	3613770C1
12	M152B	16	GY	3613770C1
13	M171-G	16	WH	3989901C1
14	PLUG	-	-	3573076C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[R94L+]	18	BK	3618272C1
2	[R94L-]	18	BN	3618272C1
3	[R94R-]	18	BN	3618272C1
4	[R94R+]	18	BK	3618272C1

22.24. CONNECTOR COMPOSITES @(9513M), @(9514), *(9514), P. 22 | Figure 1095 CONNECTOR COMPOSITES @(9513M), @(9514), *(9514) | printed page 1095

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M94A	16	GY	3613770C1
2*	M94LR+	18	TN	3613771C1
2#	M94LR+	18	GY	3613771C1
2%	M94B	16	GY	3613770C1
3*	M94LR-	18	TN	3613771C1
3#	M94LR-	18	OR	3613771C1
3%	M94C	16	GY	3613770C1
4*	M94RR-	18	TN	3613771C1
4#	M94RR-	18	YL	3613771C1
4%	M94D	16	GY	3613770C1
5*	M94RR+	18	TN	3613771C1
5#	M94RR+	18	DKBL	3613771C1
5%	M94E	16	GY	3613770C1
6#	M44C	18	GY	3613771C1
6%	M94F	16	GY	3613770C1
7&	M44N	18	GY	3613771C1
7#	M44D	18	GY	3613771C1
7%	M94H	16	GY	3613770C1
8	M94J	16	GY	3613770C1
9#	M94-GE	16	WH	3613770C1
9%	M94K	16	GY	3613770C1
10&	M44-GB	18	WH	3613771C1
10#	M90D-G	16	WH	3613770C1
10%	M94L	16	GY	3613770C1
11#	M90D	16	GY	3613770C1
11&	M44M	18	GY	3613771C1
11%%	M152A	16	GY	3613770C1
12	M152B	16	GY	3613770C1
13	M9D	18	GY	3613771C1
14	M36	18	TN	3613771C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M152C	18	RD	3601686C1	3733609C1
2	M152D	18	BK	3601686C1	3733609C1
3	M152(+)	18	YL	3601686C1	3733609C1
4	M152(-)	18	GN	3601686C1	3733609C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M152C	18	RD	3601686C1	3733609C1
2	M152D	18	BK	3601686C1	3733609C1
3	M152(+)	18	YL	3601686C1	3733609C1
4	M152(-)	18	GN	3601686C1	3733609C1

Figure 1096 CONNECTOR COMPOSITES #(9514A), #(9516)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 22.25. CONNECTOR COMPOSITES #(9514A), #(9516), P. 22A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, RELEASE NO. PART AE08090673 NO. 96183U 05AUG21 / CHAPTER 22 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / HYD BRAKE R FRONT WHEEL SPEED SENSOR #(9516) (LOCATED IN FORWARD CHASSIS HARNESS) 1 / 2 CONNECTOR 3710118C1 / EV BENDIX YAW RATE SENSOR #(9514A) (LOCATED IN FORWARD CHASSIS HARNESS) / CONNECTOR 3601685C1 / # W/COMMON FOR W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2018-PROPANE/GASOLINE-ENG / # W/COMMON FOR W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/F-2017-ISB-ENG, F-2021-B6.7-ENG / 1 3 / 4 2 / CAV CIRCUIT GA COLOR TERMINAL 1 [M94R+] 18 BK ASSY 2 [M94R-] 18 BN ASSY / Figure 1096 / CONNECTOR COMPOSITES #(9514A), #(9516)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M152C	18	RD	3601686C1
2	M152D	18	BK	3601686C1
3	M152(+)	18	YL	3601686C1
4	M152(-)	18	GN	3601686C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[M94R+]	18	BK	ASSY
2	[M94R-]	18	BN	ASSY

22.26. CONNECTOR COMPOSITES @(9515), *(9515), *(9516F), *(9516M), P. 23
Figure 1097 CONNECTOR COMPOSITES @(9515), *(9515), *(9516F), *(9516M)

22.26. CONNECTOR COMPOSITES @(9515), *(9515), *(9516F), *(9516M), P. 23 | Figure 1097 CONNECTOR COMPOSITES @(9515), *(9515), *(9516F), *(9516M) | printed page 1097

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M152EA	18	RD	3601686C1	3733609C1
2	M152FA	18	BK	3601686C1	3733609C1
3	M152A+	18	YL	3601686C1	3733609C1
4	M152A-	18	GN	3601686C1	3733609C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	M152EA	18	RD	3601686C1	3733609C1
2	M152FA	18	BK	3601686C1	3733609C1
3	M152A+	18	YL	3601686C1	3733609C1
4	M152A-	18	GN	3601686C1	3733609C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R44M	18	GY	1667742C1	1661872C1
B	R44-GB	18	WH	1667742C1	1661872C1
C	R44N	18	GY	1667742C1	1661872C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M44M	18	GY	1661875C1	1661872C1
B	M44-GB	18	WH	1661875C1	1661872C1
C	M44N	18	GY	1661875C1	1661872C1

22.27. CONNECTOR COMPOSITES #(9516A), #(9517), *(9517A), #(9517A), P. 23A | Figure 1098 CONNECTOR COMPOSITES #(9516A), #(9517), *(9517A), #(9517A) | printed page 1098

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[M94R+]	18	BK	ASSY
2	[M94R-]	18	BN	ASSY

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[M94R+]	18	BK	ASSY
1	[M94S+]	18	BK	ASSY
2	[M94R-]	18	BN	ASSY
2	[M94S-]	18	BN	ASSY

CAV	CIRCUIT	GA	COLOR	TERMINAL
1!	[M94L+]	18	BK	ASSY
2!	[M94L-]	18	BN	ASSY

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[M94L+]	18	BK	ASSY
2	[M94L-]	18	BN	ASSY

22.28. CONNECTOR COMPOSITES *(9518), @(9518), #(9518E), @(9519), P. 24 | Figure 1099 CONNECTOR COMPOSITES *(9518), @(9518), #(9518E), @(9519) | printed page 1099

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	R94M	16	GY	2033819C1
A&	R94E	12	GY	2033816C1
B#	R94N	16	GY	2033819C1
B&	R94F	12	GY	2033816C1
C#	R94P	16	GY	2033819C1
C&	R94H	12	GY	2033816C1

Legend: # BENDIX AIR W/ATC ; & BENDIX EC-80 AIR ABS W/ATC-ESP ; * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R94M	16	BK	2033819C1	1652325C1
B	R94N	16	RD	2033819C1	1652325C1
C	R94P	16	BN	2033819C1	1652325C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R94E	12	GY	2033816C1	0589391C1
B	R94F	12	GY	2033816C1	0589391C1
C	R94H	12	GY	2033816C1	0589391C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R94R	16	VT	2033819C1	1652325C1
B	R94S	16	LTGN	2033819C1	1652325C1
C	R94T	16	LTBL	2033819C1	1652325C1

22.29. CONNECTOR COMPOSITES *(9519), #(9519E), P. 24A
Figure 1100 CONNECTOR COMPOSITES *(9519), #(9519E)

22.29. CONNECTOR COMPOSITES *(9519), #(9519E), P. 24A | Figure 1100 CONNECTOR COMPOSITES *(9519), #(9519E) | printed page 1100

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	R94R	16	GY	2033819C1
A&	R94J	12	GY	2033816C1
B#	R94S	16	GY	2033819C1
B&	R94K	12	GY	2033816C1
C#	R94T	16	GY	2033819C1
C&	R94L	12	GY	2033816C1

Legend: # BENDIX AIR W/ATC ; & BENDIX EC-80 AIR ABS W/ATC-ESP ; * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	R94J	12	GY	2033816C1
B	R94K	12	GY	2033816C1
C	R94L	12	GY	2033816C1

22.30. CONNECTOR COMPOSITES *(9520), @(9520), *(9520), #(9520E), *(9521), P. 25 | Figure 1101 CONNECTOR COMPOSITES *(9520), @(9520), *(9520), #(9520E), *(9521) | printed page 1101

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R94E	16	GY	2033819C1	1652325C1
B	R94F	16	GY	2033819C1	1652325C1
C	R94H	16	GY	2033819C1	1652325C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M94BA	16	BK	2033819C1	1652325C1
B	M94BB	16	RD	2033819C1	1652325C1
C	M94BC	16	BN	2033819C1	1652325C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A#	M94BA	14	GY	2033816C1	0589391C1
A&	M94BA	16	GY	2033819C1	1652325C1
B#	M94BB	14	GY	2033816C1	0589391C1
B&	M94BB	16	GY	2033819C1	1652325C1
C#	M94BC	14	GY	2033816C1	0589391C1
C&	M94BC	16	GY	2033819C1	1652325C1

Legend: # W/BENDIX EC-80 AIR ABS W/ATC ; & W/BENDIX AIR BRAKES ; * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M94BA	14	GY	2033816C1	0589391C1
B	M94BB	14	GY	2033816C1	0589391C1
C	M94BC	14	GY	2033816C1	0589391C1

Legend: # W/F-2018-PROPANE/GASOLINE-ENG ; W/COMMON FOR W/0508108 - MTA FUSE BLOCK ; 1686834C1 AND N/0508108 - NOT FUSE BLOCK.

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A#	M94BD	14	GY	2033816C1	0589391C1
A&	M94BD	16	GY	2033819C1	1652325C1
B#	M94BE	14	GY	2033816C1	0589391C1
B&	M94BE	16	GY	2033819C1	1652325C1
C#	M94BF	14	GY	2033816C1	0589391C1
C&	M94BF	16	GY	2033819C1	1652325C1

Legend: # W/BENDIX EC-80 AIR ABS W/ATC ; & W/BENDIX AIR BRAKES ; * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG ; REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 03MAR20 AE08090673 025

22.31. CONNECTOR COMPOSITES @(9521), #(9521E), @(9522), *(9522), P. 26 | Figure 1102 CONNECTOR COMPOSITES @(9521), #(9521E), @(9522), *(9522) | printed page 1102

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R94J	16	GY	2033819C1	1652325C1
B	R94K	16	GY	2033819C1	1652325C1
C	R94L	16	GY	2033819C1	1652325C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M94BD	16	VT	2033819C1	1652325C1
B	M94BE	16	LTGN	2033819C1	1652325C1
C	M94BF	16	LTBL	2033819C1	1652325C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M94BD	14	GY	2033816C1	0589391C1
B	M94BE	14	GY	2033816C1	0589391C1
C	M94BF	14	GY	2033816C1	0589391C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M94BE	16	GY	2033819C1	1652325C1
B	M94BF	16	GY	2033819C1	1652325C1
C	M94BH	16	GY	2033819C1	1652325C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1&	R94A	16	GY	3518961C1
1#	R152A	16	GY	3518961C1
2&	R94B	16	GY	3518961C1
2#	R152B	16	GY	3518961C1

Legend: & W/BENDIX AIR W/ATC ; # W/BENDIX EC-80 AIR ABS W/ATC-ESP ; * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG ; DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 03MAR20 AE08090673 026

22.32. CONNECTOR COMPOSITES @(9522), #(9522E), @(9523), *(9526), P. 27
Figure 1103 CONNECTOR COMPOSITES @(9522), #(9522E), @(9523), *(9526)

22.32. CONNECTOR COMPOSITES @(9522), #(9522E), @(9523), *(9526), P. 27 | Figure 1103 CONNECTOR COMPOSITES @(9522), #(9522E), @(9523), *(9526) | printed page 1103

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	R94A	16	DKBL	3518961C1
2	R94B	16	YL	3518961C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	R152A	16	GY	3518961C1
2	R152B	16	GY	3518961C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	R152A	16	GY	3518961C1
2	R152B	16	GY	3518961C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M94BJ	16	GY	2033819C1	1652325C1
B	M94BK	16	GY	2033819C1	1652325C1
C	M94BL	16	GY	2033819C1	1652325C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M39D	14	BK	2033816C1	0589391C1
B	M39D-G	14	WH	2033816C1	0589391C1

22.33. CONNECTOR COMPOSITES @(9526), (9526A), *(9526), (9526A), #(9526E),
Figure 1104 CONNECTOR COMPOSITES @(9526), (9526A), *(9526), (9526A), #(9526E), *(9527),

22.33. CONNECTOR COMPOSITES @(9526), (9526A), *(9526), (9526A), #(9526E), | Figure 1104 CONNECTOR COMPOSITES @(9526), (9526A), *(9526), (9526A), #(9526E), *(9527), | printed page 1104

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M39B	14	BK	2033816C1	0589391C1
B	M39B-G	14	WH	2033816C1	0589391C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M39D	14	BK	2033816C1	0589391C1
B	M39D-G	14	WH	2033816C1	0589391C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	M39D	14	BK	2033816C1
B	M39D-G	14	WH	2033816C1

Legend: # W/F-2018-PROPANE/GASOLINE-ENG ; W/COMMON FOR W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK.

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M39B	14	BK	0587575C1	0589391C1
B	M39B-G	14	WH	0587575C1	0589391C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M39D	14	BK	0587575C1	0589391C1
B	M39D-G	14	WH	0587575C1	0589391C1

22.34. CONNECTOR COMPOSITES *(9527A), @(9530F), *(9535), @(9536), P. 29
Figure 1105 CONNECTOR COMPOSITES *(9527A), @(9530F), *(9535), @(9536)

22.34. CONNECTOR COMPOSITES *(9527A), @(9530F), *(9535), @(9536), P. 29 | Figure 1105 CONNECTOR COMPOSITES *(9527A), @(9530F), *(9535), @(9536) | printed page 1105

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M39B	14	BK	0587575C1	0589391C1
B	M39B-G	14	WH	0587575C1	0589391C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M5E(+)	18	YL	3686943C1
2	PLUG	-	-	3833742C1
3	M5E(-)	18	GN	3686943C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R59Y	16	BK	1661875C1	1661872C1
B	R59Z	16	BN	1661875C1	1661872C1
C	R59AA	16	RD	1661875C1	1661872C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R59V	16	LTBL	1661875C1	1661872C1
B	R59W	16	LTGN	1661875C1	1661872C1
C	R59X	16	VT	1661875C1	1661872C1

22.35. CONNECTOR COMPOSITES @(9537), @(9538), *(9538), P. 30 | Figure 1106 CONNECTOR COMPOSITES @(9537), @(9538), *(9538) | printed page 1106

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	R59V	16	LTBL	1680206C1
2	R59W	16	LTGN	1680206C1
3	R59X	16	VT	1680206C1
4	R59Y	16	BK	1680206C1
5	R59Z	16	BN	1680206C1
6	R59AA	16	RD	1680206C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M3C-	18	GY	1680205C1
2	M5(-)	18	GN	1680205C1
3	M94L+	16	GY	1680205C1
4	M94R+	16	DKBL	1680205C1
5	M3C+	18	DKBL	1680205C1
6	M5(+)	18	YL	1680205C1
7	M94L-	16	GY	1680205C1
8	M94R-	16	YL	1680205C1
9	M94BJ	18	GY	1680205C1
10-11	PLUG	-	-	0453133C1
12	M94BCS	18	GY	1680205C1
13	PLUG	-	-	0453133C1
14	M94BP	12	GY	3557534C1
15	M94-G	12	WH	3557534C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M3CB	18	GY	1680205C1
2	M5(-)	18	GN	1680205C1
3	M94LA	16	GY	1680205C1
4	M94RA	16	GY	1680205C1
5	M3CA	18	GY	1680205C1
6	M5(+)	18	YL	1680205C1
7	M94LB	16	GY	1680205C1
8	M94RB	16	YL	1680205C1
9	M94BJ	18	GY	1680205C1
10-13	PLUG	-	-	0453133C1
14	M94BP	12	GY	3557534C1
15	M94-G	12	WH	3557534C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG

22.36. CONNECTOR COMPOSITES @(9539), *(9539), @(9540), P. 31 | Figure 1107 CONNECTOR COMPOSITES @(9539), *(9539), @(9540) | printed page 1107

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	R94DL+	16	GY	1680205C1
2	R94DL-	16	OR	1680205C1
3	R94DR+	16	YL	1680205C1
4	R94DR-	16	DKBL	1680205C1
5-6	PLUG	-	-	0453133C1
7	R94BC	16	BN	1680205C1
8	R94BA	16	BK	1680205C1
9	R94BF	16	LTBL	1680205C1
10	R94BD	16	VT	1680205C1
11	R94P	16	BN	1680205C1
12	R94M	16	BK	1680205C1
13	R94BB	16	RD	1680205C1
14	R94BE	16	LTGN	1680205C1
15	R94N	16	RD	1680205C1
16	R94S	16	LTGN	1680205C1
17	R94T	16	LTBL	1680205C1
18	R94R	16	VT	1680205C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

Table: FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	R94DA	16	GY	1680205C1
2	R94DB	16	GY	1680205C1
3	R94DC	16	GY	1680205C1
4	R94DD	16	GY	1680205C1
5-6	PLUG	-	-	0453133C1
7	R94BC	16	GY	1680205C1
8	R94BA	16	GY	1680205C1
9	R94BF	16	GY	1680205C1
10	R94BD	16	GY	1680205C1
11	R94P	16	GY	1680205C1
12	R94M	16	GY	1680205C1
13	R94BB	16	GY	1680205C1
14	R94BE	16	GY	1680205C1
15	R94N	16	GY	1680205C1
16	R94S	16	GY	1680205C1
17	R94T	16	GY	1680205C1
18	R94R	16	GY	1680205C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1-6	PLUG	-	-	0453133C1
7	R94A	16	DKBL	1680205C1
8-12	PLUG	-	-	0453133C1
13	R94B	16	YL	1680205C1
14-18	PLUG	-	-	0453133C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

22.37. CONNECTOR COMPOSITES *(9540), *(9541F), @(9541F), P. 32 | Figure 1108 CONNECTOR COMPOSITES *(9540), *(9541F), @(9541F) | printed page 1108

CAV	CIRCUIT	GA	COLOR	TERMINAL
1-6	PLUG	-	-	0453133C1
7	R94A	16	GY	1680205C1
8-12	PLUG	-	-	0453133C1
13	R94B	16	GY	1680205C1
14-18	PLUG	-	-	0453133C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R94BA	16	GY	1667742C1	1661872C1
B	R94BB	16	GY	1667742C1	1661872C1
C	R94BC	16	GY	1667742C1	1661872C1
D	R94BD	16	GY	1667742C1	1661872C1
E	R94BE	16	GY	1667742C1	1661872C1
F	R94BF	16	GY	1667742C1	1661872C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R94BA	16	BK	1667742C1	1661872C1
B	R94BB	16	RD	1667742C1	1661872C1
C	R94BC	16	BN	1667742C1	1661872C1
D	R94BD	16	VT	1667742C1	1661872C1
E	R94BE	16	LTGN	1667742C1	1661872C1
F	R94BF	16	LTBL	1667742C1	1661872C1

22.38. CONNECTOR COMPOSITES @(9541M), *(9541M), @(9543), P. 33 | Figure 1109 CONNECTOR COMPOSITES @(9541M), *(9541M), @(9543) | printed page 1109

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M94BA	16	BK	1661875C1	1661872C1
B	M94BB	16	RD	1661875C1	1661872C1
C	M94BC	16	BN	1661875C1	1661872C1
D	M94BD	16	VT	1661875C1	1661872C1
E	M94BE	16	LTGN	1661875C1	1661872C1
F	M94BF	16	LTBL	1661875C1	1661872C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M94BA	16	GY	1661875C1	1661872C1
B	M94BB	16	GY	1661875C1	1661872C1
C	M94BC	16	GY	1661875C1	1661872C1
D	M94BD	16	GY	1661875C1	1661872C1
E	M94BE	16	GY	1661875C1	1661872C1
F	M94BF	16	GY	1661875C1	1661872C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-PROP/GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	A94-GA	12	WH	3597157C1
1*	A94-GC	12	WH	3597157C1
1*	A94-G	12	WH	3597157C1
2	-	-	-	-
3	A94Y	18	GY	3598072C1
4	A94AB	18	YL	3598072C1
5	A94AA	18	DKBL	3598072C1
6	-	-	-	-
7	A5F(-)	18	GN	3598072C1
8	A5F(+)	18	YL	3598072C1
9	-	-	-	-
10	A94C(+)	16	YL	3598073C1
11	A94C(-)	16	DKBL	3598073C1
12-15	-	-	-	-
16	A94A	12	GY	3597157C1
17-18	-	-	-	-

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK ; * W/BENDIX ABS-8

22.39. CONNECTOR COMPOSITES %(9544), %(9545), #(9545E), P. 34 | Figure 1110 CONNECTOR COMPOSITES %(9544), %(9545), #(9545E) | printed page 1110

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	A94W	14	LTBL	3598073C1
1#	A94W	16	LTBL	3598073C1
2*	A94U	14	VT	3598073C1
2*	A94U	16	VT	3598073C1
3*	A94V	14	LTGN	3598073C1
3#	A94V	16	LTGN	3598073C1
4*	A94T	14	BN	3598073C1
4#	A94T	16	BN	3598073C1
5	A94N(+)	16	GY	3598073C1
6	A94S	16	RD	3598073C1
7	A94R	16	BK	3598073C1
8	A94N(-)	16	OR	3598073C1
9*	A94K	14	LTGN	3598073C1
9#	A94K	16	LTGN	3598073C1
10*	A94L	14	LTBL	3598073C1
10#	A94L	16	LTBL	3598073C1
11	A94M(+)	16	DKBL	3598073C1
12*	A94E	14	RD	3598073C1
12#	A94E	16	RD	3598073C1
13*	A94H	14	VT	3598073C1
13#	A94H	16	VT	3598073C1
14	A94M(-)	16	YL	3598073C1
15	A94B(+)	16	GY	3598073C1
16*	A94F	14	BN	3598073C1
16#	A94F	16	BN	3598073C1
17*	A94D	14	BK	3598073C1
17#	A94D	16	BK	3598073C1
18	A94B(-)	16	OR	3598073C1

Legend: # W/2017/2021 ISB/B6.7 DIESEL ENG ; % W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1-2	-	-	-	-
3#	A152F	18	YL	3598072C1
3*	A152F	16	YL	3598073C1
4	-	-	-	-
5#	A152E	18	DKBL	3598072C1
5*	A152E	16	DKBL	3598073C1
6-15	-	-	-	-

Legend: * W/F-2018-PROP/GAS-ENG ; # W/2017/2021 ISB/B6.7 DIESEL ENG ; % W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK

CIRCUIT	GA	COLOR	TERMINAL
R71AA	16	LT BL	2206584C1
R71BA	16	WH	2206584C1

22.40. CONNECTOR COMPOSITES @(9546), @(9547), P. 35 | Figure 1111 CONNECTOR COMPOSITES @(9546), @(9547) | printed page 1111

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A9L	18	GY	3598072C1
2	A40B	18	GY	3598072C1
3	-	-	-	-
4	A6C	18	GY	3598072C1
5	A40C	18	GY	3598072C1
6	-	-	-	-
7	A152J	18	GN	3598072C1
8	A152H	18	YL	3598072C1
9	-	-	-	-
10	A152K	18	BK	3598072C1
11	A152L	18	RD	3598072C1
12	-	-	-	-

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A152P	18	BK	3601801C1
2	A152R	18	RD	3601801C1
3	A152M	18	YL	3601801C1
4	A152N	18	GN	3601801C1
5-7	-	-	-	-

22.41. INTENTIONALLY LEFT BLANK, P. 36
Figure 1112 CONNECTOR COMPOSITES Intentionally Left Blank

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 22.41. INTENTIONALLY LEFT BLANK, P. 36 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090673 NO. 95504E 04MAR20 / INTENTIONALLY LEFT BLANK / CHAPTER 22 / 360012 20OCT20 INITIAL PRODUCTION RELEASE. / INTENTIONALLY LEFT BLANK / Figure 1112 / CONNECTOR COMPOSITES Intentionally Left Blank

22.42. CONNECTOR COMPOSITES %(9547A), %(9548), %(9549), P. 37 | Figure 1113 CONNECTOR COMPOSITES %(9547A), %(9548), %(9549) | printed page 1113

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	A5A(-)	20	GY	3602660C1
1*	A5AY(-)	20	GY	3602660C1
1@	A5A(-)	18	GN	3702881C1
2*	A152J	20	GY	3602660C1
2@	A152J	18	GY	3702881C1
3*	A152J	20	GY	3602660C1
3@	A152J	18	GY	3702881C1
4*	A5AY(+)	20	GY	3602660C1
4*	A5A(+)	20	GY	3602660C1
4@	A5A(+)	18	YL	3702881C1
5*	A152P	20	GY	3602660C1
5@	A152P	18	RD	3702881C1
6*	A152R	20	GY	3602660C1
6@	A152R	18	BK	3702881C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; * W/0508108 - MTA FUSE BLOCK ; @ N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1-3	-	-	-	-
4	A152S	18	RD	3673333C1
4	A152V	18	GY	3673333C1
5	A152-G	18	WH	3673333C1
5	A152-GA	18	WH	3673333C1
6	A5L(-)	18	GN	3673333C1
7	A5L(+)	18	YL	3673333C1
8	-	-	-	-

CIRCUIT	GA	COLOR	TERMINAL
A40B	18	GY	4147514C1
A40B	18	GY	4181248C1
A9E	18	GY	4147514C1
A9E	18	GY	4181248C1
A6A	18	GY	4147514C1
A6A	18	GY	4181248C1

22.43. CONNECTOR COMPOSITES %(9550), %(9551), (9552), P. 38 | Figure 1114 CONNECTOR COMPOSITES %(9550), %(9551), (9552) | printed page 1114

CIRCUIT	GA	COLOR	TERMINAL
A40C	18	GY	4147514C1
A40C	18	GY	4181248C1
A9F	18	GY	4147514C1
A9F	18	GY	4181248C1
A6B	18	GY	4147514C1
A6B	18	GY	4181248C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A%	A101A	16	TN	1661215C1
A*	A99J	16	TN	1661215C1
B%	A101B	16	TN	1661215C1
B*	A99L	16	TN	1661215C1

CIRCUIT	GA	COLOR	TERMINAL
A40C	18	GY	4147514C1
A40C	18	GY	4181248C1
A9F	18	GY	4147514C1
A9F	18	GY	4181248C1
A6B	18	GY	4147514C1
A6B	18	GY	4181248C1

22.44. CONNECTOR COMPOSITES %(9555), #(9555E), %(9556), *(9736), P. 39 | Figure 1115 CONNECTOR COMPOSITES %(9555), #(9555E), %(9556), *(9736) | printed page 1115

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A122A	16	GY	1661261C1
B	A122B-G	16	WH	1661261C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	R86CA	18	LT GN	3522190C1
2	R86DA	18	LT GN	3522190C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M59H-G	14	WH	2033816C1	0589391C1
B	M59J	18	GY	2033819C1	3517771C1
C	M59K	18	GY	2033819C1	3517771C1
D	M59L	18	GY	2033819C1	3517771C1
E	M59M	18	GY	2033819C1	3517771C1

22.45. CONNECTOR COMPOSITES @(9736), #(9736A), *(9737), P. 40
Figure 1116 CONNECTOR COMPOSITES @(9736), #(9736A), *(9737)

22.45. CONNECTOR COMPOSITES @(9736), #(9736A), *(9737), P. 40 | Figure 1116 CONNECTOR COMPOSITES @(9736), #(9736A), *(9737) | printed page 1116

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M59H-G	14	WH	2033816C1	0589391C1
B	M59J	18	GY	2033819C1	1652325C1
C	M59K	18	GY	2033819C1	1652325C1
D	M59L	18	GY	2033819C1	1652325C1
E	M59M	18	GY	2033819C1	1652325C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M59H-G	14	WH	2033816C1	0589391C1
B	M59J	18	GY	2033819C1	3517771C1
C	M59K	18	GY	2033819C1	3517771C1
D	M59L	18	GY	2033819C1	3517771C1
E	M59M	18	GY	2033819C1	3517771C1

Legend: # W/COMMON FOR W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M11-GD	12	WH	1673747C1	0589390C1

22.46. CONNECTOR COMPOSITES @(9737), #(9737E), @(9777), @(9777M), *(9777M), P. 41 | Figure 1117 CONNECTOR COMPOSITES @(9737), #(9737E), @(9777), @(9777M), *(9777M) | printed page 1117

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M11-GD	12	WH	1673747C1	0589390C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M11-GD	12	WH	1673747C1	0589390C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R90D	18	YL	1661875C1	1661872C1
B	R94-GE	18	GN	1661875C1	1661872C1
C	R44D	18	BN	1661875C1	1661872C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R44M	18	GY	1661875C1	1661872C1
B	R44-GB	18	WH	1661875C1	1661872C1
C	R44N	18	GY	1661875C1	1661872C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R44M	18	GY	1661875C1	1661872C1
B	R44-GB	18	WH	1661875C1	1661872C1
C	R44N	18	GY	1661875C1	1661872C1

22.47. CONNECTOR COMPOSITES @(9778), *(9785F), P. 42
Figure 1118 CONNECTOR COMPOSITES @(9778), *(9785F)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 22.47. CONNECTOR COMPOSITES @(9778), *(9785F), P. 42 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090673 NO. RELEASE NO. 95504E 04MAR20 / CHAPTER 22 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / HYD BRAKE POWER *(9785F) (LOCATED INSIDE ENGINE COMPARTMENT NEAR TO PASS-THRU CONNECTOR) / HYD BRAKE POWER *(9785F) (LOCATED INSIDE ENGINE COMPARTMENT NEARTO PASS-THRU CONNECTOR) / SAHR CUT OFF SOLENOID @(9778) (LOCATED INSIDE LEFT FRAME RAIL AT HCU) / CONNECTOR 3522068C1 BODY LOCK 1661874C1 / CONNECTOR 3537133C1 / HYD BRAKE POWER *(9785F) (LOCATED INSIDE ENGINE COMPARTMENT NEAR TO PASS-THRU CONNECTOR) / CONNECTOR 3537133C1 / CONNECTOR 3537133C1 / A B / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2018-GAS-ENG / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2018-PROP-ENG / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A R44C 18 RD 1661875C1 1661872C1 B R90D-G 18 BN 1661875C1 1661872C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A K90S 8 GY 3700153C1 3537135C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A K90S 8 GY 3700153C1 3537135C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A K90S 8 GY 3700153C1 3537135C1 / Figure 1118 / CONNECTOR COMPOSITES @(9778), *(9785F)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	R44C	18	RD	1661875C1	1661872C1
B	R90D-G	18	BN	1661875C1	1661872C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K90S	8	GY	3700153C1	3537135C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2018-GAS-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K90S	8	GY	3700153C1	3537135C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	K90S	8	GY	3700153C1	3537135C1

22.48. CONNECTOR COMPOSITES @(9785M), *(9785M), #(9808E), *(9995), P. 43
Figure 1119 CONNECTOR COMPOSITES @(9785M), *(9785M), #(9808E), *(9995)

22.48. CONNECTOR COMPOSITES @(9785M), *(9785M), #(9808E), *(9995), P. 43 | Figure 1119 CONNECTOR COMPOSITES @(9785M), *(9785M), #(9808E), *(9995) | printed page 1119

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M14M	8	RD	3700154C1	3537135C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	M14M	8	RD	3700154C1	3537135C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	M94LA	16	GY	1680205C1
2	M94LB	16	GY	1680205C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A62A	14	DKBL	3566715C1
B	A74A	18	DKBL	1661208C1
C	-	-	-	-
D	A62L	18	DKBL	1661208C1
E	-	-	-	-
F	-	-	-	-
G	-	-	-	-
H	-	-	-	-
J	-	-	-	-
K	-	-	-	-

22.49. CONNECTOR COMPOSITES *(9996), P. 44
Figure 1120 CONNECTOR COMPOSITES *(9996)

22.49. CONNECTOR COMPOSITES *(9996), P. 44 | Figure 1120 CONNECTOR COMPOSITES *(9996) | printed page 1120

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A74A	18	DKBL	3548971C1
2	A74P	18	LTGN	3548971C1
3	-	-	-	-
4	A74-GA	18	WH	3548971C1
5-7	-	-	-	-
8	A75C	18	LTGN	3548971C1
9	-	-	-	-
10	A74B	18	LTGN	3548971C1
11	A74H	18	LTGN	3548971C1
12	A74-GB	18	WH	3548971C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK

22.50. CONNECTOR COMPOSITES *(9996), *(9997), *(9998), P. 45 | Figure 1121 CONNECTOR COMPOSITES *(9996), *(9997), *(9998) | printed page 1121

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A74A	18	DKBL	3548971C1
2	A74P	18	LTGN	3548971C1
3	-	-	-	-
4	A74-GA	18	WH	3548971C1
5-7	-	-	-	-
8	A75C	18	LTGN	3548971C1
9	-	-	-	-
10	A74B	18	LTGN	3548971C1
11	A74H	18	LTGN	3548971C1
12	A74-GB	18	WH	3548971C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A74A	18	DKBL	3548971C1
2	A74P	18	LTGN	3548971C1
3	-	-	-	-
4	A74B	18	LTGN	3548971C1
8	A74L	18	LTGN	3548971C1
10	A74D	18	LTGN	3548971C1
11	A74H	18	LTGN	3548971C1
12	A74C	18	LTGN	3548971C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A79P	16	PK	2025418C1
2	A79L	16	GY	2025418C1
3	A9B	16	GY	2018946C1
4	-	-	-	-
5	A44BB	16	GY	2018946C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK W/F-2017-ISB-ENG,F-2021-B6.7-ENG

22.51. CONNECTOR COMPOSITES *(9998), *(9999), P. 46 | Figure 1122 CONNECTOR COMPOSITES *(9998), *(9999) | printed page 1122

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A79P	16	PK	2025418C1
2	A79L	16	GY	2025418C1
3	A9B	16	GY	2018946C1
4	-	-	-	-
5	A44BB	16	GY	2018946C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A79B	16	RD	2025418C1
2	A79J	16	GY	2025418C1
3	A79E	16	GY	2018946C1
4	A79F	16	GY	2025418C1
5	-	-	-	-

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	A79B	16	RD	2025418C1
2	A79J	16	GY	2025418C1
3	A79E	16	GY	2018946C1
4	A79F	16	GY	2025418C1
5	-	-	-	-

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT ; MTA FUSE BLOCK W/F-2018-PROP/GAS-ENG

22.52. CONNECTOR COMPOSITES %(1027), &(1028), P. 47 | Figure 1123 CONNECTOR COMPOSITES %(1027), &(1028) | printed page 1123

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A5B(-)	18	GN	3534164C1
B	A5H(-)	18	GN	3534164C1
C	A5P(-)	18	LTGN	3534164C1
D	A5P(-)	18	LTGN	3534164C1
E	-	-	-	-
F	A5T(-)	20	LTGN	3535484C1
G	A5T(+)	20	YL	3535484C1
H	-	-	-	-
J	A5P(+)	18	YL	3534164C1
K	A5P(+)	18	YL	3534164C1
L	A5H(+)	18	YL	3534164C1
M	A5B(+)	18	YL	3534164C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A5L3(-)	18	GN	3534164C1
B	A5A(-)	18	GN	3534164C1
C	A5R(-)	18	LTGN	3534164C1
D	A5R(-)	18	LTGN	3534164C1
E	A5BF(-)	18	GN	3534164C1
F#	A5U(-)	18	GN	3534164C1
F%	A5V(-)	18	GN	3534164C1
F*	A5E(-)	18	GN	3534164C1
G#	A5U(+)	18	YL	3534164C1
G*	A5E(+)	19	YL	3534164C1
G%	A5V(+)	18	YL	3534164C1
H	A5BF(+)	18	YL	3534164C1
J	A5R(+)	18	YL	3534164C1
K	A5R(+)	18	YL	3534164C1
L	A5A(+)	18	YL	3534164C1
M	A5L3(+)	18	YL	3534164C1

Legend: * W/DATA RECORDER WIRING ; % W/ROLLTEK SEAT WIRING ; & W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK

22.53. CONNECTOR COMPOSITES &(1027), &(1028), P. 48 | Figure 1124 CONNECTOR COMPOSITES &(1027), &(1028) | printed page 1124

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A5B(-)	18	GN	3534164C1
B	A5H(-)	18	GN	3534164C1
C	A5P(-)	18	LTGN	3534164C1
D	A5P(-)	18	LTGN	3534164C1
E	-	-	-	-
F	A5T(-)	20	LTGN	3535484C1
G	A5T(+)	20	YL	3535484C1
H	-	-	-	-
J	A5P(+)	18	YL	3534164C1
K	A5P(+)	18	YL	3534164C1
L	A5H(+)	18	YL	3534164C1
M	A5B(+)	18	YL	3534164C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A5L3(-)	18	GN	3534164C1
B	A5A(-)	18	GN	3534164C1
C	A5R(-)	18	LTGN	3534164C1
D	A5R(-)	18	LTGN	3534164C1
E	A5BF(-)	18	GN	3534164C1
F#	A5U(-)	18	GN	3534164C1
F%	A5V(-)	18	GN	3534164C1
F*	A5E(-)	18	GN	3534164C1
G#	A5U(+)	18	YL	3534164C1
G*	A5E(+)	19	YL	3534164C1
G%	A5V(+)	18	YL	3534164C1
H	A5BF(+)	18	YL	3534164C1
J	A5R(+)	18	YL	3534164C1
K	A5R(+)	18	YL	3534164C1
L	A5A(+)	18	YL	3534164C1
M	A5L3(+)	18	YL	3534164C1

Legend: * W/DATA RECORDER WIRING ; % W/ROLLTEK SEAT WIRING ; & W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK

22.54. CONNECTOR COMPOSITES %(1027), &(1028), P. 49 | Figure 1125 CONNECTOR COMPOSITES %(1027), &(1028) | printed page 1125

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A5B(-)	18	GN	3534164C1
B	A5H(-)	18	GN	3534164C1
C	A5P(-)	18	LTGN	3534164C1
D	A5P(-)	18	LTGN	3534164C1
E	-	-	-	-
F	A5T(-)	20	LTGN	3535484C1
G	A5T(+)	20	YL	3535484C1
H	-	-	-	-
J	A5P(+)	18	YL	3534164C1
K	A5P(+)	18	YL	3534164C1
L	A5H(+)	18	YL	3534164C1
M	A5B(+)	18	YL	3534164C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A5L3(-)	18	GN	3534164C1
B	A5A(-)	18	GN	3534164C1
C	A5R(-)	18	LTGN	3534164C1
D	A5R(-)	18	LTGN	3534164C1
E	A5BF(-)	18	GN	3534164C1
F#	A5U(-)	18	GN	3534164C1
F%	A5V(-)	18	GN	3534164C1
F*	A5E(-)	18	GN	3534164C1
G#	A5U(+)	18	YL	3534164C1
G*	A5E(+)	19	YL	3534164C1
G%	A5V(+)	18	YL	3534164C1
H	A5BF(+)	18	YL	3534164C1
J	A5R(+)	18	YL	3534164C1
K	A5R(+)	18	YL	3534164C1
L	A5A(+)	18	YL	3534164C1
M	A5L3(+)	18	YL	3534164C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK ; * W/DATA RECORDER WIRING ; % W/ROLLTEK SEAT WIRING

22.55. CONNECTOR COMPOSITES %(1027), &(1028), P. 50 | Figure 1126 CONNECTOR COMPOSITES %(1027), &(1028) | printed page 1126

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A5B(-)	18	GN	3534164C1
B	A5H(-)	18	GN	3534164C1
C	A5P(-)	18	LTGN	3534164C1
D	A5P(-)	18	LTGN	3534164C1
E	-	-	-	-
F	A5T(-)	20	LTGN	3535484C1
G	A5T(+)	20	YL	3535484C1
H	-	-	-	-
J	A5P(+)	18	YL	3534164C1
K	A5P(+)	18	YL	3534164C1
L	A5H(+)	18	YL	3534164C1
M	A5B(+)	18	YL	3534164C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A5L3(-)	18	GN	3534164C1
B	A5A(-)	18	GN	3534164C1
C	A5R(-)	18	LTGN	3534164C1
D	A5R(-)	18	LTGN	3534164C1
E	A5BF(-)	18	GN	3534164C1
F#	A5U(-)	18	GN	3534164C1
F%	A5V(-)	18	GN	3534164C1
F*	A5E(-)	18	GN	3534164C1
G#	A5U(+)	18	YL	3534164C1
G*	A5E(+)	19	YL	3534164C1
G%	A5V(+)	18	YL	3534164C1
H	A5BF(+)	18	YL	3534164C1
J	A5R(+)	18	YL	3534164C1
K	A5R(+)	18	YL	3534164C1
L	A5A(+)	18	YL	3534164C1
M	A5L3(+)	18	YL	3534164C1

Legend: * W/DATA RECORDER WIRING ; % W/ROLLTEK SEAT WIRING ; & W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK

CONNECTOR COMPOSITE (10000-10300) (CHAPTER 23) | Figure 1127 CONNECTOR COMPOSITES @@(10000) | printed page 1127

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	C58A	18	BN	3544886C1
A2	C58	18	BN	3544886C1
A3	C11-G	12	WH	3544881C1
A4	C11-GA	12	WH	3544881C1
A5	C76A	18	LTGN	3544880C1
A5^^	C76A	14	LTGN	3544881C1
A6	C76-GA	18	WH	3544880C1
A6%#	C76-G	18	WH	3544880C1
A6^^	C76-GA	14	WH	3544881C1
A7#	C120	16	LTGN	3544886C1
A7@	C120A	18	LTGN	3544886C1
A8#	C120A	16	LTGN	3544886C1
A8@	C120	18	LTGN	3544886C1
B1#	C120-G	16	WH	3544886C1
B1@	C120-GA	18	WH	3544886C1
B2@	C120-GA	16	WH	3544886C1
B2!	C120B	18	LTGN	3544886C1
B3	C81A	18	LTGN	3544886C1
B4	C81B	18	LTGN	3544886C1
B5	C78R	18	LTGN	3544886C1
B5&&	C78	18	LTGN	3544886C1
B6**	C133D	16	LTGN	3544886C1
B6*	C133	16	LTGN	3544886C1
B6	C125AA	18	GY	3544886C1
B7	C89LA	16	OR	3544886C1
B8	C89LR	16	OR	3544886C1
B9	C89RR	16	OR	3544886C1
B9%	C89RA	16	OR	3544886C1
B10%	C89RA	16	OR	3544886C1
B10	C89RR	16	OR	3544886C1
B11	C128	16	LTBL	3544886C1
B12	C89A-M	16	OR	3544886C1
C1	C89B-M	16	OR	3544886C1
C2	C89C-M	16	OR	3544886C1
C3	C89D-M	16	OR	3544886C1
C4	C76B	18	LTGN	3544886C1
C4^^	C76B	16	LTGN	3544886C1
C5^	C76D	16	LTGN	3544886C1
C5	C76D	18	LTGN	3544886C1
C6	C137	16	LTBL	3544886C1
C7	C120C	18	LTGN	3544886C1
C8	C86A	16	LTGN	3544886C1
C9	C86	16	LTGN	3544886C1
C10	C134A	16	OR	3544886C1
C11	C122A	16	DKBL	3544886C1
C11##	C122	16	DKBL	3544886C1
C11%%	C122	16	GY	3544886C1
C12	C125	16	GY	3544886C1
D1	C124	16	LTGN	3544886C1
D2	C133	16	LTGN	3544886C1
D3	C76C	18	LTGN	3544880C1
D3^	C76C	14	LTGN	3544881C1
D4	C76-GC	18	WH	3544880C1
D4^	C76-GC	14	WH	3544881C1
D5	C139B	14	YL	3544881C1
D5*#	C139B	16	YL	3544880C1
D6	C120C	18	LTGN	3544880C1
D7	C63	18	DKBL	3544886C1
D7##	C122-G	16	WH	3544886C1
D7%%	C125AC	18	GY	3544886C1
D8	C125AB	18	GY	3544886C1

23.2. CONNECTOR COMPOSITES @@(10000), P. 2 | Figure 1128 CONNECTOR COMPOSITES @@(10000) | printed page 1128

Connector 10000: WAY DETRIMENTAL TO THE INTEREST OF ELEC PANEL/FRONT CAP BULKHEAD CONNECTION) B C

CAV	CIRCUIT	GA	COLOR	TERMINAL
B1&	B120-GC	18	WH	3544884C1
B1#	B120-GU	16	WH	3544884C1
B1#	B120-GT	16	WH	3544884C1
B2#	B120U	18	LTGN	3544884C1
B2#	B120N	18	LTGN	3544884C1
B2#	B120-GU	16	WH	3544884C1
B2#	B120R	18	LTGN	3544884C1
B2??	B120NJ	18	LTGN	3544884C1
B3	B133J	18	LTGN	3544884C1
B4	B133K	18	LTGN	3544884C1
B5	B78D	18	LTGN	3544884C1
B6	B133H	18	LTGN	3544884C1
B7**	B89A	16	OR	3544884C1
B7##	B89LA	16	OR	3544884C1
B7&&	B89LFA	16	OR	3544884C1
B8**	B89B	16	OR	3544884C1
B8##	B89LR	16	OR	3544884C1
B8&&	B89LFR	16	OR	3544884C1
B9**	B89C	16	OR	3544884C1
B9##	B89RR	16	OR	3544884C1
B9&&	B89RFR	16	OR	3544884C1
B9??	B89CD	16	OR	3544884C1
B9??	B89CE	16	OR	3544884C1
B9??	B89CB	16	OR	3544884C1
B10**	B89D	16	OR	3544884C1
B10##	B89RA	16	OR	3544884C1
B10&&	B89RFA	16	OR	3544884C1
B11	B128	16	LTBL	3544884C1
B11??	B128K	16	LTBL	3544884C1
B12	B89RA-M	16	OR	3544884C1
C1	B89RR-M	16	OR	3544884C1
C2	B89LR-M	16	OR	3544884C1
C3	B89LA-M	16	OR	3544884C1
C4*#	B76ELO	16	LTGN	3544884C1
C4*#	B76CLO	16	LTGN	3544884C1
C4*#	B76DLO	16	LTGN	3544884C1
C4??	B76DLO-B	16	LTGN	3544884C1
C5	B76DLO	16	LTGN	3544884C1
C6	B137	16	LTBL	3544884C1
C7	B120	18	LTGN	3544884C1
C8	B86L	16	LTGN	3544884C1
C9	B86K	16	LTGN	3544884C1
C10*%	B134F	16	OR	3544884C1
C10*%	B134B	16	OR	3544884C1
C11	B122Z	16	GY	3544884C1
C12	B120BJ	18	LTGN	3544884C1
C12*&	B117C	18	GY	3544884C1
C12!!	B125C	18	GY	3544884C1
C12!*	B120B	18	LTGN	3544884C1
C12!&	B125CMD	18	GY	3544884C1
D1	-	-	-	-
D2	B133P	18	LTGN	3544884C1
D3	B76DHI	14	LTGN	3544877C1
D4	B76-GD	14	WH	3544877C1
D5	B139B	16	YL	3544876C1
D6#	B120W	18	LTGN	3544876C1
D6#	B120-GV	16	WH	3544876C1
D7	B122AA	16	WH	3544884C1
D8	B137A	16	LTBL	3544884C1

Connector 10000: WAY DETRIMENTAL TO THE INTEREST OF ELEC PANEL/FRONT CAP BULKHEAD CONNECTION) B C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	B58J	16	BN	3544884C1
A2	B58C	18	BN	3544884C1
A3	B11-GE	12	WH	3544877C1
A4	B11-GF	12	WH	3544877C1
A5*	B76EHI	14	LTGN	3544877C1
A5*	B76CHI	14	LTGN	3544877C1
A5?	B76DHI	14	LTGN	3544877C1
A5??	B76DHI-B	14	LTGN	3544877C1
A6*	B76-GE	14	WH	3544877C1
A6*	B76-GC	14	WH	3544877C1
A6*	B76-GA	14	WH	3544877C1
A7#	B120-GT	16	WH	3544884C1
A7#	B120T	16	LTGN	3544884C1
A7&	B120T	18	LTGN	3544884C1
A7??	B120TB	18	LTGN	3544884C1
A8??	B120TC	18	LTGN	3544884C1
A8&	B120U	18	LTGN	3544884C1
A8#	B120T	18	LTGN	3544884C1
A8#	B120U	16	LTGN	3544884C1

Legend: A9_A12 - - -

Connector 10001: FRONT CAP/ELEC PNL BULKHED JUNCTION) C B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	C78LA	18	LTGN	3544886C1
A2	C78LB	18	LTGN	3544886C1
A3	C78LC	18	LTGN	3544880C1
A4	C78LD	18	LTGN	3544880C1
A5	C78LE	18	LTGN	3544880C1
A6	C78LF	18	LTGN	3544880C1
A7	C152	18	GY	3544886C1
A7@	C152	O.5	PK	3544885C1
A8	C152M	18	GY	3544886C1
A8@	C152H	18	GY	3544886C1
A9-A12	-	-	-	-
B1	C78RA	18	LTGN	3544886C1
B10	C86LF-	16	LTGN	3544886C1
B11	C86RF+	16	LTGN	3544886C1
B12	C86RF-	16	LTGN	3544886C1
B2	C78RB	18	LTGN	3544886C1
B3	C78RC	18	LTGN	3544886C1
B4	C78RD	18	LTGN	3544886C1
B5	C78RE	18	LTGN	3544886C1
B6	C78RF	18	LTGN	3544886C1
B7#	C125AA	18	BK	3544886C1
B7*	C67-G	20	WH	3544885C1
B7@	C152K	18	GY	3544886C1
B8#	C125AB	18	LTGN	3544886C1
B8*	C67	20	GY	3544885C1
B8@	C152E	18	GY	3544886C1
B9#	C125AC	18	RD	3544886C1
B9%	C86LF+	16	LTGN	3544886C1
B9*	C152-GB	18	WH	3544886C1
C1	C68	16	BN	3544886C1
C10	C70R-M	16	RD	3544886C1
C11	C56L-M	18	YL	3544886C1
C12	C71R-M	18	LTBL	3544886C1
C2	C71	18	LTBL	3544886C1
C3	C57	18	YL	3544886C1
C4	C56	18	YL	3544886C1
C5	C70	16	RD	3544886C1
C6	C70L-M	16	RD	3544886C1
C7	C128-G	16	WH	3544886C1
C7&	C57R-M	18	LTGN	3544886C1
C8	C71L-M	18	LTBL	3544886C1
C9	C68L-M	16	BN	3544886C1
D1	C68R-M	16	BN	3544886C1
D2	C5(+)	20	YL	3544885C1
D3	C5(-)	20	GN	3544879C1
D4	C5C(+)	20	YL	3544879C1
D5	C5C(-)	20	GN	3544879C1
D6	C5H(+)	20	YL	3544879C1
D7	C5H(-)	20	GN	3544885C1
D8@	C152D	18	GY	3544886C1

23.4. CONNECTOR COMPOSITES @(10001), P. 4 | Figure 1130 CONNECTOR COMPOSITES @(10001) | printed page 1130

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	B78LA	20	LTGN	3544883C1
A2	B78LB	20	LTGN	3544883C1
A3	B78LC	20	LTGN	3544875C1
A4	B78LD	20	LTGN	3544875C1
A5	B78LE	18	LTGN	3544876C1
A6	B78LF	20	LTGN	3544875C1
A7	B152	18	GY	3544884C1
A8	B152A	18	GY	3544884C1
B1	B78RA	20	LTGN	3544883C1
B2	B78RB	20	LTGN	3544883C1
B3	B78RC	20	LTGN	3544883C1
B4	B78RD	20	LTGN	3544883C1
B5	B78RE	20	LTGN	3544883C1
B6	B78RF	20	LTGN	3544883C1
B7*	B67-G	18	WH	3544884C1
B7#	B125AA	18	BK	3544884C1
B7&	B125MA	18	GY	3544884C1
B7?	B152L	18	GY	3544884C1
B7^	B97AB	18	PL	3544884C1
B8*	B67	18	GY	3544884C1
B8#	B125AB	18	LTGN	3544884C1
B8&	B125MB	18	GY	3544884C1
B8?	B152G	18	GY	3544884C1
B8^	B97AB-G	18	PL	3544884C1
B9%	B86P	16	LTGN	3544884C1
B9*	B152-G	18	WH	3544884C1
B9#	B125AC	18	RD	3544884C1
B9&	B125MC	18	GY	3544884C1

Legend: W/9 ; W/9 B11% B86Y 16 LTGN 3544884C1 ; B11** B86X 16 LTGN 3544884C1 ; B12** B86X 16 LTGN 3544884C1 ; B12% B86Y 16 LTGN 3544884C1 ; C1 B68A 16 BN 3544884C1 ; C2## B71D 16 LTBL 3544884C1 ; C2## B71E 16 LTBL 3544884C1 ; C3 B57B 16 LTGN 3544884C1

23.5. CONNECTOR COMPOSITES %(10003), %(10004), @(10009), P. 5 | Figure 1131 CONNECTOR COMPOSITES %(10003), %(10004), @(10009) | printed page 1131

Connector 10003: D E

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C78K	18	LTGN	1661261C1
B	C78J	18	LTGN	1661261C1
C	C78H	18	LTGN	1661261C1
D	C78F	18	LTGN	1661261C1
E	C78E	18	LTGN	1661261C1
F	C78D	18	LTGN	1661261C1
G	C78B	18	LTGN	1661261C1
H	C78-G	18	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10004: REAR END LIGHTS

CAV	CIRCUIT	GA	COLOR	TERMINAL
1-2	-	-	-	-
3	C68	16	BN	1661539C1
4	C71	18	LTBL	1661539C1
5	C57	18	LTGN	1661539C1
6	C56	18	YL	1661539C1
7	C70	16	RD	1661539C1
8	C70L-M	16	RD	1661539C1
9	C57R-M	18	LTGN	1661539C1
10	C71L-M	18	LTBL	1661539C1
11	C68L-M	16	BN	1661539C1
12	C70R-M	16	RD	1661539C1
13	C56L-M	18	YL	1661539C1
14	C71R-M	18	LTBL	1661539C1
15	C68R-M	16	BN	1661539C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10009: GROUND CIRCUITS K

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C11-GA	12	WH	3566715C1
B	-	-	-	-
B	C11COG	0.5	WH	1661208C1
C	C137-G	16	WH	1661209C1
D#	C11-GB	16	WH	1661209C1
D%	C133-G	16	WH	1661209C1
D*	C133-GB	16	WH	1661209C1
E	-	-	-	-
F	C120-GC	18	WH	1661208C1
G	-	-	-	-
H	C63-G	18	WH	1661208C1
J	C89-G	16	WH	1661209C1

Legend: * W/START INTERLOCK-ENTER DOOR-GND ; # W/INTERLOCK,STARTER W/MICRO LIMIT SW,W/VANDAL LOCK ; % W/LOCKING COMPARTMENT-GND ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

23.6. CONNECTOR COMPOSITES !(10010), %(10011), ^(12012), P. 6 | Figure 1132 CONNECTOR COMPOSITES !(10010), %(10011), ^(10012) | printed page 1132

Connector 10010: BULKHEAD JUNCTION) K

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C11-GA	12	WH	3566715C1
B	C125-G	16	WH	1661209C1
C	C128-G	16	WH	1661209C1
D	C89-G	16	WH	1661209C1
E*	C78-GR	18	WH	1661208C1
E#	C78-G	18	WH	1661208C1
F^	C122G	16	WH	1661209C1
F@	C122-G	16	WH	1661209C1
G%	C139-GB	14	WH	3566715C1
G&	C139-GB	16	WH	1661209C1
H	C58-GH	18	WH	1661208C1
J	C58-GJ	18	WH	1661208C1
K	C134-G	16	WH	1661209C1

Legend: * W/HEATED MIRRORS,RIGHT ONLY OVERHEAD ; # W/HEATED MIRRORS LEFT & RIGHT OVERHEAD ; % W/LIGHT,RIGHT SIDE PEDESTRIAN ; & W/LIGHT,LED RIGHT SIDE PEDESTRIAN ; ^ W/3" IND LIFT DOOR, ; @ W/2" IND LIFT DOOR ; ! W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND N/0508108 - ; NOT MTA FUSE BLOCK

Connector 10011: FAR LEFT DEFOG FAN BULKHEAD-LEFT) B A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	C76E	18	LTGN	1661261C1
A#	C76A	18	LTGN	1661261C1
B*	C76F	18	LTGN	1661261C1
B#	C76B	18	LTGN	1661261C1
C*	C76-GE	18	WH	1661261C1
C#	C76-GA	18	WH	1661261C1

Legend: * W/DEFOG FAN,FAR L & CTR BLOWER & FAR R ; # W/L DEFOG FAN-L SW ; % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND N/0508108 - ; NOT MTA FUSE BLOCK

Connector 10012: LEFT CENTER DEFOG FAN -CENTER) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A%	C76H	18	LTGN	1661261C1
A*	C76E	18	LTGN	1661261C1
A@	C76A	18	LTGN	1661261C1
A#	C76C	18	LTGN	1661261C1
B%	C76J	18	LTGN	1661261C1
B*	C76F	18	LTGN	1661261C1
B@	C76B	18	LTGN	1661261C1
B#	C76D	18	LTGN	1661261C1
C%	C76-GH	18	WH	1661261C1
C*	C76-GE	18	WH	1661261C1
C@	C76-GA	18	WH	1661261C1
C#	C76-GC	18	WH	1661261C1

Legend: @ W/CTR L DEFOG FAN - L SW ; # W/CTR L DEFOG FAN - R SW ; % W/FAR L & CTR L DEFOG FANS - L SW ; * W/CTR L & CTR/FAR R DEFOG FANS - R SW ; ^ W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND N/0508108 - ; NOT MTA FUSE BLOCK

23.7. CONNECTOR COMPOSITES &(10013), &(10014), &(10014A), P. 7 | Figure 1133 CONNECTOR COMPOSITES &(10013), &(10014), &(10014A) | printed page 1133

Connector 10013: CENTER RIGHT DEFOG FAN -CENTER) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A%	C76E	18	LTGN	1661261C1
A*	C76H	18	LTGN	1661261C1
A@	C76C	18	LTGN	1661261C1
A#	C76A	18	LTGN	1661261C1
B%	C76F	18	LTGN	1661261C1
B*	C76J	18	LTGN	1661261C1
B@	C76D	18	LTGN	1661261C1
B#	C76B	18	LTGN	1661261C1
C%	C76-GE	18	WH	1661261C1
C*	C76-GH	18	LTGN	1661261C1
C@	C76-GC	18	WH	1661261C1
C#	C76-GA	18	WH	1661261C1

Legend: @ W/CTR R DEFOG FAN - R SW ; # W/CTR R DEFOG FAN -L SW ; % W/CTR R & FAR R DEFOG FANS - R SW ; * W/CTR L & CTR R DEFOG FANS - R SW ; & W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND N/0508108 - ; NOT MTA FUSE BLOCK

Connector 10014: FAR RIGHT DEFOG FAN A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	C76H	18	LTGN	1661261C1
A%	C76C	18	LTGN	1661261C1
B*	C76J	18	LTGN	1661261C1
B%	C76D	18	LTGN	1661261C1
C*	C76-GH	18	WH	1661261C1
C%	C76-GC	18	WH	1661261C1

Legend: % W/FAR R DEFOG FAN - R SW ; * W/FAR/CTR L/R & FAR R DEFOG FANS - R SW ; & W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND N/0508108 - ; NOT MTA FUSE BLOCK

Connector 10014A: FAR RIGHT DEFOG FAN - AE B A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C76C	18	LTGN	1661261C1
B	C76D	18	LTGN	1661261C1
C	C76-GC	18	WH	1661261C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND N/0508108 - ; NOT MTA FUSE BLOCK

23.8. CONNECTOR COMPOSITES %(10015), %(10016), %(10017), %(10018), P. 8 | Figure 1134 CONNECTOR COMPOSITES %(10015), %(10016), %(10017), %(10018) | printed page 1134

Connector 10015: CENTER BLOWER BULKHEAD-RIGHT)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	C76A	14	LTGN	1661539C1
1#	C76C	14	LTGN	1661539C1
2*	C76B	16	LTGN	1661539C1
2#	C76D	16	LTGN	1661539C1
3*	C76-GA	14	WH	1661539C1
3#	C76-GC	14	WH	1661539C1

Legend: * W/DEFOG FAN,CENTER BLOWER,N/DRIVER DEFOG FAN ; # W/DEFOG FAN,CENTER BLOWER,W/DRIVER DEFOG FAN ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10016: CORNER MARKER LT BULKHEAD-LEFT) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C58E	18	BN	1661261C1
B	C58-GE	18	WH	1661261C1

Connector 10017: 2ND CORNER MARKER LIGHT BULKHEAD LEFT) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C58H	18	BN	1661261C1
B	C58-GH	18	WH	1661261C1

Connector 10018: CORNER MARKER LIGHT BULKHEAD-RIGHT)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C58F	18	BN	1661261C1
B	C58-GF	18	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

23.9. CONNECTOR COMPOSITES %(10019), %(10020), %(10021), %(10022), %(10023), P. 9 | Figure 1135 CONNECTOR COMPOSITES %(10019), %(10020), %(10021), %(10022), %(10023) | printed page 1135

Connector 10019: BULKHEAD-RIGHT) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C58J	18	BN	1661261C1
B	C58-GJ	18	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10020: CLUSTER LIGHTS BULKHEAD-CENTER) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C58B	18	BN	1661261C1
B	C58-GB	18	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10021: BODY LOCK 1661263C1 CLUSTER LIGHTS BULKHEAD-CENTER)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C58C	18	BN	1661261C1
B	C58-GC	18	WH	1661261C1

Connector 10022: CLUSTER LIGHTS BULKHEAD-CENTER)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C58D	18	BN	1661261C1
B	C58-GD	18	WH	1661261C1

Connector 10023: HEATED MIRROR BULKHEADT-LEFT)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C78L	18	LTGN	1661261C1
B	C78-GL	18	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

23.10. CONNECTOR COMPOSITES %(10024), %(10025A), %(10025B), %(10025C), P. 10 | Figure 1136 CONNECTOR COMPOSITES %(10024), %(10025A), %(10025B), %(10025C) | printed page 1136

Connector 10024: A B BULKHEAD - RIGHT) CAV A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C78R	18	LTGN	1661261C1
B	C78-GR	18	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10025A: LIGHT MONITOR CONNECTOR A 4 1 1 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C89RR-M	16	OR	1661539C1
2	C89RA	16	OR	1661539C1
3	C89RA-M	16	OR	1661539C1
4	C89RR	16	OR	1661539C1
5	C89A-M	16	OR	1661539C1
6	C89B-M	16	OR	1661539C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10025B: LIGHT MONITOR CONNECTOR B CAV 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C89LR-M	16	OR	1661538C1
2	C89LA	16	OR	1661538C1
3	C89LA-M	16	OR	1661538C1
4	C89LR	16	OR	1661538C1
5	C89D-M	16	OR	1661538C1
6	C89C-M	16	OR	1661538C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10025C: LIGHT MONITOR CONNECTOR C 1 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C70	16	RD	1661539C1
2	C70R-M	16	RD	1661539C1
3	C57R-M	18	LTGN	1661539C1
4	C57	18	YL	1661539C1
5		-	-	-
6	C71	18	LTBL	1661539C1
7	C68R-M	16	BN	1661539C1
8	C71R-M	18	LTBL	1661539C1
9	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

23.11. CONNECTOR COMPOSITES &(10025D), &(10026A), &(10026B), &(10026C), P. 11 | Figure 1137 CONNECTOR COMPOSITES &(10025D), &(10026A), &(10026B), &(10026C) | printed page 1137

Connector 10025D: LIGHT MONITOR CONNECTOR D 4 5 6

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C70L-M	16	RD	1661538C1
2	C56	18	YL	1661538C1
3	C56L-M	18	YL	1661538C1
4	C128	16	LTBL	1661538C1
5	C71L-M	18	LTBL	1661538C1
6	C128-G	16	WH	1661538C1
7	C68	16	BN	1661538C1
8	C68L-M	16	BN	1661538C1
9	-	-	-	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10026A: LIGHT MONITOR CONNECTOR A 4 1 CAV 1 2

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C89RR-M	16	OR	1661539C1
2	C89RA	16	OR	1661539C1
3	C89RA-M	16	OR	1661539C1
4	C89RR	16	OR	1661539C1
5	C89A-M	16	OR	1661539C1
6	C89B-M	16	OR	1661539C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10026B: LIGHT MONITOR CONNECTOR B CAV 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C89LR-M	16	OR	1661538C1
2	C89LA	16	OR	1661538C1
3	C89LA-M	16	OR	1661538C1
4	C89LR	16	OR	1661538C1
5	C89D-M	16	OR	1661538C1
6	C89C-M	16	OR	1661538C1

Connector 10026C: LIGHT MONITOR CONNECTOR C 1 2 3 3 4 5

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C70	16	RD	1661539C1
2	C70R-M	16	RD	1661539C1
3	C57R-M	18	LTGN	1661539C1
4	C57	18	LTGN	1661539C1
5	-	-	-	-
6	C71	18	LTBL	1661539C1
7	C68R-M	16	BN	1661539C1
8	C71R-M	18	LTBL	1661539C1
9	-	-	-	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

23.12. CONNECTOR COMPOSITES %(10026D), %(10027), %10028, 10028A, P. 12 | Figure 1138 CONNECTOR COMPOSITES %(10026D), %(10027), %10028, 10028A | printed page 1138

Connector 10026D: 1 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C70L-M	16	RD	1661538C1
2	C56	18	YL	1661538C1
3	C56L-M	18	YL	1661538C1
4	C128	16	LTBL	1661538C1
5	C71L-M	18	LTBL	1661538C1
6	C128-G	16	WH	1661538C1
7	C68	16	BN	1661538C1
8	C68L-M	16	BN	1661538C1
9	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10027: PA HORN A B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C86	16	LTGN	1661261C1
B	C86A	16	LTGN	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10027: PA HORN A B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	C89LRA	16	OR	1661539C1
1&	C89LR-M	16	OR	1661539C1
1#	C89LR	16	OR	1661539C1
2	C89-GA	16	WH	1661539C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; * W/LT MONITOR W/ADDL WARN LT ; & W/CE/BE WARNING LTS-W/LT MONITOR ; # W/WARNING LIGHT N/LT MONITOR

Figure 1139 CONNECTOR COMPOSITES %10029, 10029A, %10030, 10030A

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 23.13. CONNECTOR COMPOSITES %10029, 10029A, %10030, 10030A, P. 13 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090674 NO. 95504E 02MAR20 / CHAPTER 23 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / AMBER WARNING LIGHT %(10030/10030A) (LOCATED AT FRONT BULKHEAD-RIGHT) / CONNECTOR 1669029C1 / CONNECTOR 1669029C1 / AMBER WARNING LIGHT %(10029/10029A) (LOCATED AT FRONT BULKHEAD-LEFT) / 1 1 2 2 / 1 2 / CAV CIRCUIT GA COLOR TERMINAL 1* C89LAA 16 OR 1661539C1 1& C89LA-M 16 OR 1661539C1 1# C89LA 16 OR 1661539C1 2 C89-GB 16 WH 1661539C1 / Figure 1139 / CONNECTOR COMPOSITES %10029, 10029A, %10030, 10030A

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	C89LAA	16	OR	1661539C1
1&	C89LA-M	16	OR	1661539C1
1#	C89LA	16	OR	1661539C1
2	C89-GB	16	WH	1661539C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	C89RAA	16	OR	1661539C1
1&	C89RA-M	16	OR	1661539C1
1#	C89RA	16	OR	1661539C1
2	C89-GC	16	WH	1661539C1

Legend: * W/LT MONITOR W/ADDL WARN LT ; & W/CE/BE WARNING LTS-W/LT MONITOR ; # W/WARNING LIGHT N/LT MONITOR ; % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Figure 1140 CONNECTOR COMPOSITES %10031, 10031A, %10032A, %10032B, %10033A

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 23.14. CONNECTOR COMPOSITES %10031, 10031A, %10032A, %10032B, %10033A, P. 14 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090674 NO. 95504E 02MAR20 / CHAPTER 23 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / LIFT INDICATOR LIGHT %(10032A) (LOCATED AT FRONT BULKHEAD-CENTER) / CONNECTOR 1669029C1 / CONNECTOR 2206658C1 / AMBER WARNING LIGHT %(10032B) (LOCATED AT FRONT BULKHEAD-CENTER) / RED WARNING LIGHT %(10031/10031A) (LOCATED AT FRONT BULKHEAD-RIGHT) / 1 2 / CONNECTOR 2206658C1 / CONNECTOR 2206658C1 / LIFT INDICATOR LIGHT %(10033A) (LOCATED AT FRONT BULKHEAD-CENTER) / CAV CIRCUIT GA COLOR TERMINAL A C122A 16 DKBL 0239805R1 % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A C122G 16 WH 0239805R1 / CAV CIRCUIT GA COLOR TERMINAL A C122 16 DKBL 0239805R1 / Figure 1140 / CONNECTOR COMPOSITES %10031, 10031A, %10032A, %10032B, %10033A

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	C89RRA	16	OR	1661539C1
1&	C89RR-M	16	OR	1661539C1
1	C89RR	16	OR	1661539C1
2	C89-GD	16	WH	1661539C1
2&	C89-GB	16	WH	1661539C1

Legend: * W/LT MONITOR W/ADDL WARN LT ; & W/CE/BE WARNING LTS-W/LT MONITOR ; % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10032A: LIFT INDICATOR LIGHT BULKHEAD-CENTER)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C122A	16	DKBL	0239805R1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10032B: AMBER WARNING LIGHT BULKHEAD-CENTER)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C122	16	DKBL	0239805R1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10033A: LIFT INDICATOR LIGHT BULKHEAD-CENTER)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C122G	16	WH	0239805R1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

23.15. CONNECTOR COMPOSITES %10034, %10035, %10036, %10037, %10038,
Figure 1141 CONNECTOR COMPOSITES %10034, %10035, %10036, %10037, %10038, %10039

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 23.15. CONNECTOR COMPOSITES %10034, %10035, %10036, %10037, %10038, %10039, P. 15 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090674 NO. 95504E 02MAR20 / CHAPTER 23 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED R/D 10037. / CAMERA %(10035) (LOCATED AT FRONT BULKHEAD-CENTER) / DESTINATION SIGN %(10036) (LOCATED AT FRONT BULKHEAD-CENTER) A B CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 2206658C1 / SAFETY COMPT %(10038) (LOCATED AT FRONT BULKHEAD-CENTER) / CAMERA %(10034) (LOCATED AT FRONT BULKHEAD-CENTER) / A CONNECTOR 2206658C1 / CONNECTOR 2206658C1 / SAFETY COMPT %(10039) (LOCATED AT FRONT BULKHEAD-CENTER) / CONNECTOR 2206658C1 / CAV CIRCUIT GA COLOR TERMINAL A C137 16 LTBL 0239805R1 % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / LED ILLUM DSTN SIGN %(10037) (LOCATED AT FRONT BULKHEAD-CENTER) B A CONNECTOR 2206658C1 BODY LOCK 1661264C1 / CAV CIRCUIT GA COLOR TERMINAL A C137-G 16 WH 0239805R1 / CAV CIRCUIT GA COLOR TERMINAL A C134A 16 OR 1661261C1 B C134-G 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A C133-GA 16 WH 0239805R1 / CAV CIRCUIT GA COLOR TERMINAL A C133A 16 LTGN 0239805R1 / CAV CIRCUIT GA COLOR TERMINAL A C134A 16 OR 1661262C1 B C134-G 16 WH 1661262C1 / Figure 1141 / CONNECTOR COMPOSITES %10034, %10035, %10036, %10037, %10038, %10039

Connector 10034: BULKHEAD-CENTER) A CAV A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C137	16	LTBL	0239805R1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10035: CAMERA BULKHEAD-CENTER) CAV A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C137-G	16	WH	0239805R1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10036: CONNECTOR 2206658C1 DESTINATION SIGN BULKHEAD-CENTER) A B CAV A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C134A	16	OR	1661261C1
B	C134-G	16	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10037: LED ILLUM DSTN SIGN BULKHEAD-CENTER) B CAV A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C134A	16	OR	1661262C1
B	C134-G	16	WH	1661262C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10038: SAFETY COMPT BULKHEAD-CENTER) A % N/0508108

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C133A	16	LTGN	0239805R1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10039: SAFETY COMPT BULKHEAD-CENTER) A % A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C133-GA	16	WH	0239805R1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Figure 1142 CONNECTOR COMPOSITES %10041, %10042, %10043, %10046, %10046A

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 23.16. CONNECTOR COMPOSITES %10041, %10042, %10043, %10046, %10046A, P. 16 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090674 NO. 95504E 02MAR20 / CHAPTER 23 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTES FOR FUSE B BLOCK. / (NC) STARTER INTERLOCK %(10042) (LOCATED AT FRONT BULKHEAD-RIGHT) / STARTER INTERLOCK %(10043) (LOCATED AT FRONT BULKHEAD-RIGHT) / CONNECTOR 1669029C1 / PEDESTRIAN LIGHT %(10046) (LOCATED AT FRONT BULKHEAD-RIGHT) / ALT ENT DR DUMP VALVE %(10041) (LOCATED AT FRONT BULKHEAD-RIGHT) / CONNECTOR 1669029C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / LED PED LIGHT %(10046A) (LOCATED AT FRONT BULKHEAD-RIGHT) / CONNECTOR 2206658C1 / 1 2 / CONNECTOR 2206658C1 / 1 2 / A B / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A C133-GB 16 WH 0239805R1 % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A C133 16 LTGN 0239805R1 / CAV CIRCUIT GA COLOR TERMINAL A C139B 16 YL 1661261C1 B C139-GB 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL 1 C139B 14 YL 1661539C1 2 C139-GB 14 WH 1661539C1 / Figure 1142 / CONNECTOR COMPOSITES %10041, %10042, %10043, %10046, %10046A

Connector 10041: BULKHEAD-RIGHT)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C120C	18	LTGN	1661539C1
2	C120-GC	18	WH	1661539C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10042: CONNECTOR 1669029C1 (NC) STARTER INTERLOCK BULKHEAD-RIGHT) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C133	16	LTGN	0239805R1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10043: CONNECTOR 2206658C1 STARTER INTERLOCK BULKHEAD-RIGHT)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C133-GB	16	WH	0239805R1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10046: CONNECTOR 2206658C1 PEDESTRIAN LIGHT BULKHEAD-RIGHT)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C139B	14	YL	1661539C1
2	C139-GB	14	WH	1661539C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10046A: CONNECTOR 1669029C1 LED PED LIGHT BULKHEAD-RIGHT) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C139B	16	YL	1661261C1
B	C139-GB	16	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

23.17. CONNECTOR COMPOSITES %10047, %10048, %10049, %10050, P. 17 | Figure 1143 CONNECTOR COMPOSITES %10047, %10048, %10049, %10050 | printed page 1143

Connector 10047: BULKHEAD-RIGHT) CAV

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C120	16	LTGN	1661539C1
2	C120A	16	LTGN	1661539C1
3	C120-G	16	WH	1661539C1
4	C120-GA	16	WH	1661539C1
5-6	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10048: MOTORIZED MIRROR BULKHEAD-RIGHT) C& D* D&

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	C78K	18	LTGN	1661262C1
A&	C78RA	18	LTGN	1661262C1
B*	C78J	18	LTGN	1661262C1
B&	C78RB	18	LTGN	1661262C1
C*	C78H	18	LTGN	1661262C1
C&	C78RC	18	LTGN	1661262C1
D*	C78F	18	LTGN	1661262C1
D&	C78RD	18	LTGN	1661262C1
E*	C78E	18	LTGN	1661262C1
E&	C78RE	18	LTGN	1661262C1
F*	C78D	18	LTGN	1661262C1
F&	C78RF	18	LTGN	1661262C1
G#	C78B	18	LTGN	1661262C1
G*	C78	18	LTGN	1661262C1
H*	C78-G	18	WH	1661262C1
H#	C78-GB	18	WH	1661262C1

Legend: * W/RIGHT MOTORIZED MIRROR HEAT ; # W/LEFT AND RIGHT MOTORIZED MIRROR HEAT ; & W/RIGHT MOTORIZED MIRROR-CE/BE ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10049: SAFETY COMPLEMENT BULKHEAD-CENTER) CAV

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C133B	16	LTGN	0239805R1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10050: SAFETY COMPARTMENT BULKHEAD-CENTER) CAV A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C133-GC	16	WH	0239805R1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

23.18. CONNECTOR COMPOSITES %10051, %10052, %10057A, %10059, P. 18 | Figure 1144 CONNECTOR COMPOSITES %10051, %10052, %10057A, %10059 | printed page 1144

Connector 10051: SAFETY COMPARTMENT LATCH AND BUZZER BULKHEAD-CENTER) B CAV A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C133	16	LTGN	1661262C1
B	C133C	16	LTGN	1661262C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10052: AIR DOOR OPEN SOLENOID BULKHEAD-RIGHT) CAV A

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	C120A	18	LTGN	1661875C1	1661872C1
B	C120-GC	18	WH	1661875C1	1661872C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10057A: CHILD CHECK MOTION SENSOR 2* 2# 3*

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	C125AA	18	BK	4117333C1
1#	C125AA	18	GY	4117333C1
2*	C125AD	18	BK	4117333C1
2#	C125AD	18	GY	4117333C1
3*	C125AB	18	LTGN	4117333C1
3#	C125AB	18	GY	4117333C1
4*	C125AE	18	BK	4117333C1
4#	C125AE	18	GY	4117333C1

Legend: * W/THEFTMATE W/DOOR SWITCH ; # W/THEFTMATE N/SNOOZE ; % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10059: VANDAL LOCK BULKHEAD-RIGHT) CAV 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C81A	18	LTGN	1661538C1
2	C81B	18	LTGN	1661538C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

23.19. CONNECTOR COMPOSITES %10060, %10061, %10070, %10072, P. 19 | Figure 1145 CONNECTOR COMPOSITES %10060, %10061, %10070, %10072 | printed page 1145

Connector 10060: BULKHEAD-RIGHT)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C120B	18	LTGN	1661539C1
2	C120C	18	LTGN	1661539C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10061: CONNECTOR 1669029C1 AIR DOOR CLOSE SOLENOID BULKHEAD-RIGHT)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	C120	18	LTGN	1661875C1	1661872C1
B	C120-GB	18	WH	1661875C1	1661872C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10070: BODY LOCK 1661874C1 L MOTORIZED MIRROR BULKHEAD-LEFT)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C78LA	18	LTGN	1661262C1
B	C78LB	18	LTGN	1661262C1
C	C78LC	18	LTGN	1661262C1
D	C78LD	18	LTGN	1661262C1
E	C78LE	18	LTGN	1661262C1
F	C78LF	18	LTGN	1661262C1
G	C78A	18	LTGN	1661262C1
H	C78-GA	18	WH	1661262C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10072: DRIVERS DOME LIGHT BULKHEAD-CENTER) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C63	18	DKBL	1661261C1
B	C63-G	18	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

23.20. CONNECTOR COMPOSITES %10075, %10076, %10077, %10078, P. 20 | Figure 1146 CONNECTOR COMPOSITES %10075, %10076, %10077, %10078 | printed page 1146

Connector 10075: BULKHEAD JUNCTION) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C89LAB	18	OR	1661261C1
B	C89-GA	18	WH	1661261C1
C	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10076: LEFT RED WARN LT BULKHEAD JUNCTION)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C89LRB	18	OR	1661261C1
B	C89-GB	18	WH	1661261C1
C	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10077: RIGHT AMBER WARN LT BULKHEAD JUNCTION) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C89RAB	18	OR	1661261C1
B	C89-GC	18	WH	1661261C1
C	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10078: RIGHT RED WARN LT BULKHEAD JUNCTION) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C89RRB	18	OR	1661261C1
B	C89-GD	18	WH	1661261C1
C	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Figure 1147 CONNECTOR COMPOSITES %10083, %10084, %10085, %10086

Components: VANDAL LOCK SW (10086)

Connector 10083: SDP MODULE

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C152L	20	GY	3535805C1
2	C152F	20	GY	3535805C1
3-4	-	-	-	-
5	C5A(+)	20	YL	3535805C1
6	C5A(-)	20	GN	3535805C1
7	C67-G	20	WH	3535805C1
8	C67	20	GY	3535805C1
9	C152C	20	GY	3535805C1
10	C152D	20	GY	3535805C1
11	C152E	20	GY	3535805C1
12	C5D(+)	20	YL	3535805C1
13	C5D(-)	20	GN	3535805C1
14-15	-	-	-	-
16	C152-GA	20	WH	3535805C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10084: FUSION CAMERA 9 8

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C152A	20	GY	6127313C1
2	-	-	-	-
3	C5B(-)	20	GN	6127313C1
4	C5B(+)	20	YL	6127313C1
5	-	-	-	-
6	C5E(-)	20	GN	6127313C1
7	C5E(+)	20	YL	6127313C1
8	C152-G	20	WH	6127313C1
9	C152B	20	GY	6127313C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10085: DEFOG FAN UNDER DRVR OVHD COMPT BULKHEAD-LEFT) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C76A	18	LTGN	1661261C1
B	C76B	18	LTGN	1661261C1
C	C76-G	18	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10086: STARTER INTERLOCK VANDAL LOCK SW B A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C11-GB	16	WH	1661262C1
B	C133	16	LTGN	1661262C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

23.22. CONNECTOR COMPOSITES %10101, %10102, %10103, P. 22 | Figure 1148 CONNECTOR COMPOSITES %10101, %10102, %10103 | printed page 1148

Connector 10101: LEFT DIRECTIONAL LIGHT LEFT OF VECHILE)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	D56-M	16	YL	3522190C1	3522194C1
2	D56-G	16	WH	3522190C1	3522194C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10101: WEBASTO HTR ELECTRICAL PANEL)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B74B	18	LTGN	1661539C1
1*	B74B	16	RD	1661539C1
1*	B74B	16	LTGN	1661539C1
2	B74C	18	LTGN	1661539C1
3	B74D	18	LTGN	1661539C1
4	-	-	-	-
5*	B74A	12	LTGN	2030386C1
5*	B74A	12	RD	2030386C1
6*	B74A-G	12	WH	2030386C1
6*	B74A-GA	12	WH	2030386C1

Legend: * W/WEBASTO FUEL FIRED HEATER W/SMART TIMER ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10102: LEFT STOP/TAIL LIGHT 1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	D68L-G	16	WH	3522190C1	3522194C1
2	D68L-M	16	BN	3522190C1	3522194C1
3	D70L-M	16	RD	3522190C1	3522194C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10103: LEFT BACKUP LIGHT 1 CAV 1 2

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	D71L-M	16	LTBL	3522190C1	3522194C1
2	D71L-G	16	WH	3522190C1	3522194C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

23.23. CONNECTOR COMPOSITES %10104, %10105, %10105A, %10106, 10106A, P. 23 | Figure 1149 CONNECTOR COMPOSITES %10104, %10105, %10105A, %10106, 10106A | printed page 1149

Connector 10104: LEFT STOP/TAIL LICENCE LIGHT LEFT OF VEHICLE) 1 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	D68-GA	16	WH	3522190C1	3522194C1
2	D68A	16	BN	3522190C1	3522194C1
3	D70A	16	RD	3522190C1	3522194C1

Connector 10105: CONNECTOR 3522187C1 LEFT LICENCE LIGHT LEFT OF VEHICLE)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	D68B	16	BN	3522190C1	3522194C1
2	D68-GB	16	WH	3522190C1	3522194C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10105A: ADDITIONAL LEFT STOP/TAIL LIGHT REAR EMERGENCY DOOR)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	D68-GA	16	WH	3522190C1	3522194C1
2	D68C	16	BN	3522190C1	3522194C1
3	D70C	16	RD	3522190C1	3522194C1

Connector 10105A: ADDITIONAL LEFT STOP/TAIL LIGHT REAR EMERGENCY DOOR)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	D133C	16	LTGN	0239805R1
A#	D133B	16	LTGN	0239805R1

Legend: * W/REAR AND SED/LIFT DOOR VANDAL LOCK ; # W/REAR DOOR VANDAL LOCK ; % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

23.24. CONNECTOR COMPOSITES %10108, %10109, 10109A, %10112, %10113, | Figure 1150 CONNECTOR COMPOSITES %10108, %10109, 10109A, %10112, %10113, %10114 | printed page 1150

Connector 10108: A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	D58K	16	BN	1661261C1
B	D58-GK	16	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10108: A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	D127A	18	OR	1661262C1
B	D127-G	16	WH	1661262C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10112: WARNING LIGHT RED 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	D89LR-M	16	OR	1661539C1
2	D89LR-G	16	WH	1661539C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10113: CONNECTOR 1669029C1 WARNING LIGHT AMBER 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	D89LA-M	16	OR	1661539C1
2	D89LA-G	16	WH	1661539C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10114: CONNECTOR 1669029C1 LH REAR CLUSTER LIGHT BUS REAR PANEL) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	D58C	16	BN	1661261C1
B	D58-GC	16	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Figure 1151 CONNECTOR COMPOSITES %10115, %10116, 10117, %10118

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 23.25. CONNECTOR COMPOSITES %10115, %10116, 10117, %10118, P. 25 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090674 95504E 02MAR20 / CHAPTER 23 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / RH REAR CLUSTER LIGHT %(10116) (LOCATED AT RIGHT SIDE BUS REAR PANEL) / WARNING LIGHT RH RED %(10117) (LOCATED AT RIGHT SIDE BUS REAR PANEL) / A B CONNECTOR 1661259C1 BODY LOCK 1661263C1 / WARNING LIGHT RH AMBER %(10118) (LOCATED AT REAR TOP RIGHT SIDE) / CENTER REAR CLUSTER LIGHT %(10115) (LOCATED AT BUS REAR PANEL CENTER) / CONNECTOR 1669029C1 / 1 2 / A B CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1669029C1 / 1 2 / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A D58D 16 BN 1661261C1 B D58-GD 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A D58E 16 BN 1661261C1 B D58-GE 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL 1 D89RA-M 16 OR 1661539C1 2 D89RA-G 16 WH 1661539C1 / Figure 1151 / CONNECTOR COMPOSITES %10115, %10116, 10117, %10118

Connector 10115: A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	D58D	16	BN	1661261C1
B	D58-GD	16	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10116: BODY LOCK 1661263C1 RH REAR CLUSTER LIGHT BUS REAR PANEL) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	D58E	16	BN	1661261C1
B	D58-GE	16	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10117: WARNING LIGHT RH RED BUS REAR PANEL)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	D89RR-M	16	OR	1661539C1
2	D89RR-G	16	WH	1661539C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10118: WARNING LIGHT RH AMBER TOP RIGHT SIDE)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	D89RA-M	16	OR	1661539C1
2	D89RA-G	16	WH	1661539C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

23.26. CONNECTOR COMPOSITES %10119, %10122, P. 26
Figure 1152 CONNECTOR COMPOSITES %10119, %10122

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 23.26. CONNECTOR COMPOSITES %10119, %10122, P. 26 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART NO. RELEASE NO. AE08090674 95504E 02MAR20 / CHAPTER 23 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / RIGHT BACKUP LIGHT %(10122) (LOCATED AT REAR RIGHT SIDE) / A B CONNECTOR 1661259C1 BODY LOCK 1661263C1 / RH CORNER MARKER LIGHT %(10119) (LOCATED AT REAR TOP RIGHT SIDE) / CONNECTOR 2206588C1 / 1 2 / Figure 1152 / CONNECTOR COMPOSITES %10119, %10122

Connector 10119: A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	D58H	16	BN	1661261C1
B	D58-GH	16	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10122: BODY LOCK 1661263C1 RIGHT BACKUP LIGHT

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	D71R-M	16	LTBL	3522190C1	3522194C1
2	D71R-G	16	WH	3522190C1	3522194C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

23.27. CONNECTOR COMPOSITES %10123, %10124, %10125, %10126, P. 27 | Figure 1153 CONNECTOR COMPOSITES %10123, %10124, %10125, %10126 | printed page 1153

Connector 10123: RIGHT STOP/TAIL LIGHT 1 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	D68R-G	16	WH	3522190C1	3522194C1
2	D68R-M	16	BN	3522190C1	3522194C1
3	D70R-M	16	RD	3522190C1	3522194C1

Connector 10124: RIGHT DIRECTIONAL LIGHT 1 CAV 1 2

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	D57-M	16	LTGN	3522190C1	3522194C1
2	D57-G	16	WH	3522190C1	3522194C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10125: RIGHT STOP/TAIL LICENSE LIGHT 1 2* 2# 3

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	D68-GC	16	WH	3522190C1	3522194C1
2*	D68C	16	BN	3522190C1	3522194C1
2#	D68B	16	BN	3522190C1	3522194C1
3	D70B	16	RD	3522190C1	3522194C1

Legend: * W/LEFT LICENSE PLATE LIGHT ; # W/ADDITIONAL STOP/TAIL LIGHT ; % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10126: LOWER RIGHT BACKUP LIGHT 1 2

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	D68D	16	BN	3522190C1	3522194C1
2	D68-GD	16	WH	3522190C1	3522194C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

23.28. CONNECTOR COMPOSITES %10126A, %10128, %10142, %10142A, P. 28 | Figure 1154 CONNECTOR COMPOSITES %10126A, %10128, %10142, %10142A | printed page 1154

Connector 10126A: ADDITIONAL RIGHT STOP/TAIL LIGHT OF REAR EMERGENCY DOOR)

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	D68-GB	16	WH	3522190C1	3522194C1
2	D68D	16	BN	3522190C1	3522194C1
3	D70D	16	RD	3522190C1	3522194C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10128: DRIVERS ALERT SIGN C D E F D E

CAV	CIRCUIT	GA	COLOR	TERMINAL
A&	D71A	16	LTBL	1661261C1
A^	D71	16	LTBL	1661261C1
B	D57B	16	LTGN	1661261C1
C	D56	16	YL	1661261C1
D	D89RA	16	OR	1661261C1
E	D89LA	16	OR	1661261C1
F	D11-GF	16	WH	1661261C1
G#	D89RR	16	OR	1661261C1
G*	D89RRB	16	OR	1661261C1
H#	D89LR	16	OR	1661261C1
H*	D89LRB	16	OR	1661261C1

Legend: * W/PUPIL WARNING LTS W/LTS ABOVE BPR & DRIVER ALERT SIGN ; # W/PUPIL WARNING LTS W/DRIVER ALERT SIGN ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK ; ^ W/BACK UP LT W/DRIVER ALERT SIGN ; & W/ADDITIONAL BACK UP LT W/DRIVER ALERT SIGN

Connector 10142: & EMERGENCY EXIT LIGHT A B * A# B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	D58N	16	BN	1661261C1
A#	D12D	18	LTBL	1661261C1
B	D58-GN	16	WH	1661261C1

Legend: * W/CLEARANCE/ID LTS & ACT EMERGENCY EXIT LT ; # W/IGN CIRC W/EMERGENCY EXIT LT ; % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10142A: EMERGENCY EXIT LIGHT A B % B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	D143	16	DKBL	1661261C1
B	D143-G	16	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

23.29. CONNECTOR COMPOSITES %10143, #10144, %10156, %10157, %10160, P. 29 | Figure 1155 CONNECTOR COMPOSITES %10143, #10144, %10156, %10157, %10160 | printed page 1155

Connector 10143: A B % B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	D134A	16	OR	1661261C1
B	D134-G	16	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10144: CONNECTOR 1661259C1 BODY LOCK 1661263C1 LED ILLUM DSTN SIGN B A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	D134A	16	OR	1661262C1
B	D134-G	16	WH	1661262C1

Legend: # W/COMMON FOR W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT FUSE BLOCK.

Connector 10156: CONNECTOR 1661260C1 BODY LOCK 1661264C1 RH DUAL CORNER MARKER LT A B % B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	D58M	16	BN	1661261C1
B	D58-GM	16	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10157: CONNECTOR 1661259C1 BODY LOCK 1661263C1 LH DUAL CORNER MARKER LIGHT A B % B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	D58L	16	BN	1661261C1
B	D58-GL	16	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10160: CONNECTOR 1661259C1 BODY LOCK 1661263C1 LH REAR CAP GROUND SPLICE K A B C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	D11-GA	10	WH	1661211C1
B	D11-GD	16	WH	1661209C1
C	D58-G	16	WH	1661209C1
D	D58-GA	16	WH	1661209C1
E	D127-G	16	WH	1661209C1
F	D89-G	16	WH	1661209C1
G	D89-GC	16	WH	1661209C1
H	D11-GG	16	WH	1661209C1
J#	D68-GE	16	WH	1661209C1
J&	D68-G	16	WH	1661209C1
J*	D68-GB	16	WH	1661209C1
K	D125-G	16	WH	1661209C1

Legend: # W/LEFT AND RIGHT LICENSE PLATE LIGHT ; * W/LEFT LICENSE PLATE LIGHT ; & W/ADDITIONAL STOP/TAIL LIGHT ; % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

23.30. CONNECTOR COMPOSITES %10161, %10172, %10173, %10174, P. 30 | Figure 1156 CONNECTOR COMPOSITES %10161, %10172, %10173, %10174 | printed page 1156

Connector 10161: K CAV A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	D11-GB	10	WH	1661211C1
B	D11-GE	16	WH	1661209C1
C	D11-GF	16	WH	1661209C1
D	D71-G	16	WH	1661209C1
E	D134-G	16	WH	1661209C1
F#	D143-G	16	WH	1661209C1
F*	D58-GN	16	WH	1661209C1
G	D58-GL	16	WH	1661209C1
H	D58-GL	16	BN	1661209C1
J	BV71-G	16	WH	1661209C1
K	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK ; * W/EMERGENCY EXIT LIGHT ; # W/CEILING-MOUNTED EMERGENCY EXIT LIGHT

Connector 10172: BODY LOCK 2007316C1 LOWER LEFT WARNING LIGHT CAV REAR EMERGENCY DOOR) 1# 2

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1*	D89RRA	16	OR	3522190C1	3522194C1
1#	D89RR	16	OR	3522190C1	3522194C1
2	D89-GA	16	WH	3522190C1	3522194C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; * W/PUPIL WARNING LTS W/LTS ABOVE BPR & ; DRIVER ALERT SIGN ; # W/PUPIL WARNING LTS W/LTS ABOVE BPR

Connector 10173: LOWER RIGHT WARNING LIGHT REAR EMERGENCY DOOR) 1* 1# 2

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1*	D89LRA	16	OR	3522190C1	3522194C1
1#	D89LR	16	OR	3522190C1	3522194C1
2	D89-GB	16	WH	3522190C1	3522194C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; * W/PUPIL WARNING LTS W/LTS ABOVE BPR & ; DRIVER ALERT SIGN ; # W/PUPIL WARNING LTS W/LTS ABOVE BPR

Connector 10174: CONNECTOR 2206588C1 LOWER LEFT BACKUP LIGHT REAR EMERGENCY DOOR) 1* D71A 1# D71L-M 2 D71L-G

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1*	D71A	16	LTBL	3522190C1	3522194C1
1#	D71L-M	16	LTBL	3522190C1	3522194C1
2	D71L-G	16	WH	3522190C1	3522194C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; * W/PUPIL WARNING LTS W/LTS ABOVE BPR & ; DRIVER ALERT SIGN ; # W/PUPIL WARNING LTS W/LTS ABOVE BPR

23.31. CONNECTOR COMPOSITES @10175, @10177, @10183, @10200, P. 31 | Figure 1157 CONNECTOR COMPOSITES @10175, @10177, @10183, @10200 | printed page 1157

Connector 10175: LOWER RIGHT BACKUP LIGHT REAR EMERGENCY DOOR) 1! 1# 1*

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1!	D71C	16	LTBL	3522190C1	3522194C1
1#	D71R-M	16	LTBL	3522190C1	3522194C1
1*	D71B	16	LTBL	3522190C1	3522194C1
2	D71R-G	16	WH	3522190C1	3522194C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * W/BACKUP LT STD & MOUNTED LOW & OUTBOARD ; # W/BACKUP LT LOW & OUTBOARD W/DRIVER ALERT SIGN ; ! W/ADDITIONAL BACK UP LT W/DRIVER ALERT SIGN

Connector 10177: CONNECTOR 2206588C1 ! REAR DOOR SWITCH BOX 2 3*

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	D117	18	GY	1661539C1
3*	D130B	18	GY	1661539C1
3#	D130C	18	GY	1661539C1
4	D11-GG	16	WH	1661539C1
5	-	-	-	-
6	D12B	18	LTBL	1661539C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * W/R SIDE EMERGENCY DOOR AND REAR EMERGENCY EXIT DOOR ; # W/REAR EMERGENCY EXIT DOOR

Connector 10183: * W/R SIDE CONNECTOR 2206662C1 # W/REAR RIGHT REAR MARKER LIGHT A B B* B#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	D58R	16	BN	1661261C1
B*	D58-GL	16	WH	1661261C1
B#	D58-GL	16	BN	1661261C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * W/CL/ID LT & CEILING REE LT & REAR MARKER LT ; # W/CL/ID,REAR MARKER, & FL LT

Connector 10200: DOOR CONTROL 7 8 4 1 1# 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B9D	18	GY	1661224C1
1#	B9A	18	GY	1661224C1
2	B120H	18	LTGN	1661224C1
3	-	-	-	-
4&	B123T	18	GY	1661224C1
4#	B9A	18	GY	3541250C1
4#	B9C	18	GY	3541250C1
5	B120F	18	LTGN	1661224C1
6	-	-	-	-
7	KA62-GAP	18	WH	1661224C1
8%	KA62ACB	18	DKBL	3541250C1
8%	KA62ADA	18	DKBL	3541250C1
9%	KA62ADA	18	DKBL	3541250C1
9%	B62AE	18	DKBL	3541250C1
10	B62AE	18	DKBL	1661224C1

Legend: W/0508108 - MTA FUSE BLOCK ; W/ROTARY DOOR W/3POSITION & NON-SEQ & MASTER SW ; W/ROTARY DOOR N/3POSITION & NON-SEQ FLASHER & MASTER SW ; W/L MASTER FLASHER W/3POSITION ROTARY DOOR W/NON-SEQ ; W/ROTARY DOOR CONTROL COMMON

23.32. CONNECTOR COMPOSITES %10200, %10201, P. 31A | Figure 1158 CONNECTOR COMPOSITES %10200, %10201 | printed page 1158

Connector 10200: CAV DOOR CONTROL 1! 7 8 2# 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1!	B9D	18	GY	1661224C1
1#	B9A	18	GY	1661224C1
2#	B120H	18	LT GN	1661224C1
3	-	-	-	-
4*	B123T	18	GY	1661224C1
4#	B9A	18	GY	3541250C1
4#	B9C	18	GY	3541250C1
5#	B120F	18	LT GN	1661224C1
6	-	-	-	-
7#	B62-GAC	18	WH	1661224C1
8#	B62AC	18	DK BL	3541250C1
8#	B62AD	18	DK BL	3541250C1
9#	B62AD	18	DK BL	3541250C1
9#	B62AE	18	DK BL	3541250C1
10#	B62AE	18	DK BL	1661224C1

Legend: % N/0508108 - NOT MTA FUSE BLOCK ; ! W/L 3 POSN RTRY DOOR CONT W/NON SEQUENTIAL ; & MSTR SW ; # W/LEFT PNL MT DOOR CONT 2 & 3 POSN ROTARY ; * W/L MT MSTR SW W/NON SEQUENTIAL 3POSN RTRY

Connector 10201: * DOME LIGHT POWER G A* A& A^

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	B63AS	12	DKBL	3566715C1
A&	B63AZ	12	DKBL	3566715C1
A^	B63AH	12	DKBL	3566715C1
B	B63BB	16	DKBL	1661209C1
C	B63CA	16	DKBL	1661209C1
D	B63AK	18	DKBL	1661208C1
E#	B63WD	18	DKBL	1661208C1
E?	BG63WV	16	DKBL	1661209C1
F	B63AAA	14	DKBL	3566715C1
G@	B63AAB	16	DKBL	1661209C1
G!	B63ACA	18	DKBL	1661208C1
G**	B63AE	18	DKBL	1661208C1
G!!	B63M	16	DKBL	1661209C1

Legend: % W/0508108 - MTA FUSE BLOCK ; * W/DOME LT FEED BATTERY W/RHEO ; & W/DOME LT FEED IGNITION ; ^ W/DOME LT FEED BATTERY ; # W/DOME LT W/REAR ROW & W/ REE & N/RHEO ; ? W/REAR ROW SW CONN AND SUPPLY ; @ W/DOME LT ACTVTD BY LIFT DOOR ; ! W/ACTIVITY DOME LT ; ** W/GUARD DOME LT

23.33. CONNECTOR COMPOSITES @10201, @@10202, P. 32 | Figure 1159 CONNECTOR COMPOSITES @10201, @@10202 | printed page 1159

Connector 10201: G C D

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B63A	12	DKBL	3566715C1
B	B63B	16	DKBL	1661209C1
C	B63C	16	DKBL	1661209C1
D	B63AK	18	DKBL	1661208C1
E*	B63W	18	DKBL	1661208C1
E#	B63W	16	DKBL	1661209C1
F	B63AA	14	DKBL	3566715C1
G&	B63AA	16	DKBL	1661209C1
G%	B63AC	18	DKBL	1661208C1
G!	B63AE	18	DKBL	1661208C1
G^	B63M	16	DKBL	1661209C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * W/DOME LT W/REAR ROW W/EMERGENCY EXIT W/2 MIN ; # W/REAR ROW SW CONN AND SUPPLY ; & W/DOME LT ACTIVATED BY LIFT DOOR ; % W/ACTIVITY DOME LT W/9 ; ! W/GUARD DOME LT W/9 ; ^ W/DOME LT ACTIVATED BY ENTRANCE DOOR W/REAR ROW DOME

Connector 10202: DOME LIGHT OUTPUT A ML CAV K&& K!^

CAV	CIRCUIT	GA	COLOR	TERMINAL
K&&	B63S	16	DKBL	3534165C1
K!^	B63D	14	DKBL	3534165C1
K^^	B63T	16	DKBL	3534165C1
K!^	B63S	16	LTBL	3534165C1
K!!	B63C	14	DKBL	3534165C1
K!!	B63C	16	DKBL	3534165C1
K**	B63R	14	DKBL	3534165C1
K*&	B63D	14	DKBL	3534165C1
L*	B63E	16	DKBL	3534165C1
L#	B63RD	12	DKBL	3546091C1
L%	B63RK	12	DKBL	3546091C1
M	B63R	16	DKBL	3534165C1

Connector 10202: DOME LIGHT OUTPUT A ML CAV K&& K!^
Table: BODY LOCK 3700749C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B63F	16	DKBL	3534164C1
B*	B63D	16	DKBL	3534165C1
B#	B63RC	12	DKBL	3546091C1
B%	B63RJ	12	DKBL	3546091C1
B&	B63A	14	DKBL	3534165C1
C**	B63T	16	LTBL	3534165C1
C&&	B63T	16	DKBL	3534165C1
C%%	B63B	16	DKBL	3534165C1
C!^	B63E	14	DKBL	3534165C1
C^^	B63S	16	DKBL	3534164C1
C^	B63T	12	DKBL	3546091C1
C!!	B63D	14	DKBL	3534165C1
C!!	B63D	16	DKBL	3534165C1
D	-	-	-	-
E	B131A	16	DKBL	3534165C1
F##	B63AP	16	DKBL	3534165C1
F#	B63E	16	DKBL	3534165C1
G#	B63E	16	DKBL	3534165C1
G##	B63AN	16	DKBL	3534165C1
J	-	-	-	-

Legend: CHK DATE ; SEE CH 01_AE08090652 B 96183U ; _027 FOR CHANGE DETAILS.

23.34. CONNECTOR COMPOSITES %10202, P. 32A | Figure 1160 CONNECTOR COMPOSITES %10202 | printed page 1160

Connector 10202: DOME LIGHT OUTPUT

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	B63FB	16	DKBL	3534164C1
A?	B63FC	16	DKBL	3534164C1
B**	B63DW	16	DKBL	3534164C1
B*&	B63RC	12	DKBL	3546091C1
B*^	B63RJ	12	DKBL	3546091C1
B*%	B63AT	14	DKBL	3534165C1
B*#	B63D	16	DKBL	3534164C1
C*!	B63T	16	DKBL	3534164C1
C^	B63T	16	LTBL	3534164C1
C^^	B63B	16	DKBL	3534164C1
C^*	B63EC	14	DKBL	3534165C1
C^&	B63S	16	DKBL	3534164C1
C^#	B63T	12	DKBL	3546091C1
C^!	B63DT	14	DKBL	3534165C1
C#	B63TA	16	DKBL	3534164C1
C##	B63DP	16	DKBL	3534164C1
C#*	B63EA	14	DKBL	3534165C1
D	-	-	-	-
E	B131A	16	DKBL	3534164C1
F#&	B63AP	16	DKBL	3534164C1
F#^	B63E	16	DKBL	3534164C1
G#^	B63E	16	DKBL	3534164C1
G#&	B63AN	16	DKBL	3534164C1
J#%	B63BD	14	DKBL	3534165C1
J#^	B63B	14	DKBL	3534165C1
K*!	B63S	16	DKBL	3534164C1
K^*	B63DH	14	DKBL	3534165C1
K^&	B63T	16	DKBL	3534164C1
K!	B63S	16	LTBL	3534164C1
K^!	B63C	14	DKBL	3534165C1
K##	B63C	16	DKBL	3534164C1
K#*	B63DR	14	DKBL	3534165C1
L!!	B63E	16	DKBL	3534164C1
L*&	B63RD	12	DKBL	3546091C1
L*^	B63RK	12	DKBL	3546091C1
M	B63R	16	DKBL	3534164C1

23.35. CONNECTOR COMPOSITES @10203, @10203A, @10204, P. 33 | Figure 1161 CONNECTOR COMPOSITES @10203, @10203A, @10204 | printed page 1161

Connector 10203: 7 8 4 1 3# 4

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B120AC	18	LTGN	1661224C1
2	B120AA	18	LTGN	1661224C1
3*	B120AE	18	LTGN	3541250C1
3#	B131D	18	DKBL	3541250C1
4	-	-	-	-
5	B9K	18	GY	1661224C1
6%	B89L	18	OR	1661224C1
6^	B89LE	18	OR	1661224C1
7	B62-GBL	18	WH	1661224C1
8	B62BL	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * W/AED AIR N/+9 ; # W/AED AIR W/+9 ; % N/0508108 - NOT MTA FUSE BLOCK ; ^ W/0508108 - MTA FUSE BLOCK

Connector 10203A: # W/AED CONNECTOR 3530563C1 % N/0508108 ^ W/0508108 LEFT AED ELECTRIC 7 8 4 1 2 3 4

Table: - MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B120AA	18	LTGN	1661224C1
3	B120AE	18	LTGN	1661224C1
4	-	-	-	-
5	B123B	18	OR	1661224C1
6	B89L	18	OR	1661224C1
7	B62-GBL	18	WH	1661224C1
8	B62BL	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10204: N/0508108 CONNECTOR 3530563C1 EMER EXIT BUZZER SPLICE K J B& B#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B11-GAM	18	WH	1661208C1
B*	B117JZ	16	LTGN	1661209C1
B&	B63-GA	14	WH	3566715C1
B#	B117F	18	GY	1661208C1
C	B117E	18	GY	1661208C1
D	B129	18	GY	1661208C1
E	B126	18	GY	1661208C1
F##	B117D	18	GY	1661208C1
F**	B117A	18	GY	1661208C1
F%	B63C	18	DKBL	1661209C1
F!	B117DF	16	GY	1661209C1
F%	B117D	16	GY	1661209C1
G@	B130	18	GY	1661208C1
G!	B117DG	16	GY	1661209C1
G%	B117D	16	GY	1661209C1
G@	B125PB	18	GY	1661208C1
H*%	B125F	18	GY	1661208C1
H%%	B125C	18	GY	1661208C1
J%	B117	18	GY	1661208C1
J!	B117SD	18	GY	1661208C1
K	B131-GS	16	WH	1661209C1

Legend: *% W/CHILD CHECK-MATE ARMED BY PWL W/9 ; W/25A ; ! W/0508108 - MTA FUSE BLOCK ; ACTIVATED DOME W/9 @ W/COMMON FOR VEHICLE W/0508108 - MTA ; MIN W/REAR ROW FUSE BLOCK AND N/0508108 - NOT MTA ; BUZZER W/+9 FUSE BLOCK ; REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE

23.36. CONNECTOR COMPOSITES %10205, %10207, %10211, %10212, %10219, P. 34 | Figure 1162 CONNECTOR COMPOSITES %10205, %10207, %10211, %10212, %10219 | printed page 1162

Connector 10205: A CONTROL PANEL) A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B139C	16	YL	1661261C1
B	B139-GA	16	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10207: BLOCK CONNECTOR 1661259C1 BODY LOCK 1661263C1 DRIVERS DOME LT A B A% A# B*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	B63AB	16	DKBL	1661261C1
A%	B63AG	16	DKBL	1661261C1
A#	B3ABA	16	DKBL	1661261C1
B*	B63-GAB	16	WH	1661261C1
B#	B63-GAB	16	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; * N/0508108 - NOT MTA FUSE BLOCK ; # W/0508108 - MTA FUSE BLOCK

Connector 10211: * # BUS SCAN MODULE ELECTRICAL PANEL) 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B125-GA	18	WH	1661539C1
2	B125	18	GY	1661539C1
3	B125E	18	GY	1661539C1
4	B125A	18	GY	1661539C1
5	B125K	18	GY	1661539C1
6	-	-	-	-
7	B125C	18	GY	1661539C1
8	B125F	16	GY	1661539C1
9	-	-	-	-

Connector 10212: CHECK MATE MODULE 4 5* 5#

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B125D	18	GY	3761061C1
2	B125-G	18	WH	3761061C1
3	B125	18	GY	3761061C1
4	B125C	18	GY	3761061C1
5*	B70C	18	RD	3761061C1
5#	B119	18	GY	3761061C1
5&	B119Y	18	GY	3761061C1
6	B125E	18	GY	3761061C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; * W/STOP/TAIL/TURN LT W/CHK W/CHILD CHK MATE ; # N/0508108 - NOT MTA FUSE BLOCK ; & W/0508108 - MTA FUSE BLOCK

Connector 10219: # & STOP ARM SOLENOID 1 CAV 1 2

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B119H	18	GY	1661539C1
2	B119-GB	18	WH	1661539C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

23.37. CONNECTOR COMPOSITES %10219A, %10219B, %10221, %10224, P. 35 | Figure 1163 CONNECTOR COMPOSITES %10219A, %10219B, %10221, %10224 | printed page 1163

Connector 10219A: CROSSING GATE CAV CIRCUIT

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B119N	18	GY	1661539C1
2	B119-GN	18	WH	1661539C1

Connector 10219B: % W/COMMON CONNECTOR 1669029C1 AND CROSSING GATE CAV CIRCUIT 1 B119C

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B119C	16	GY	1661539C1
2	B119-GN	16	WH	1661539C1

Connector 10221: AND CONNECTOR 1669029C1 STOP ARM 3 1 2 PANEL HARNESS) 2# 2! 3%

CAV	CIRCUIT	GA	COLOR	TERMINAL
1%	B119E	18	GY	1661261C1
2#	B89AA	18	OR	1661261C1
2!	B89AAC	18	OR	1661261C1
3%	B89BB	18	OR	1661261C1
4%	B119F	18	GY	1661261C1
5!	B119-GHC	18	WH	1661261C1
5	-	-	-	-
6%	B119-GC	18	WH	1661261C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; # N/0508108 - NOT MTA FUSE BLOCK ; ! W/0508108 - MTA FUSE BLOCK

Connector 10224: ! TEMP SENSOR CONTROL PANEL) CAV CIRCUIT A B41E B B41F

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	B41E	18	TN	0587578C1	1652325C1
B	B41F	18	TN	0587578C1	1652325C1

23.38. CONNECTOR COMPOSITES %10226, %10227, %10228, %10229, P. 36 | Figure 1164 CONNECTOR COMPOSITES %10226, %10227, %10228, %10229 | printed page 1164

Connector 10226: 7 8 CAV 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B76A	16	LTGN	1661226C1
3	B76ALO	16	LTGN	1661226C1
4-5	-	-	-	-
6	B76AHI	16	LTGN	1661226C1
7	B62-GY	18	WH	1661224C1
8	B62Y	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10227: % CONNECTOR 3530563C1 AND REAR POWER VENT 7 8 4 1 1 2

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B76B	16	LTGN	1661226C1
3	B76BLO	16	LTGN	1661226C1
4-5	-	-	-	-
6	B76BHI	16	LTGN	1661226C1
7	B62-GZ	18	WH	1661224C1
8	B62Z	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10228: AND CONNECTOR 3530563C1 BOTTOM STEP HEAT 7 8 4 1 1 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B132B	18	GY	1661224C1
3	B132C	18	GY	1661224C1
4-6	-	-	-	-
7	B62-GH	18	WH	1661224C1
8	B62H	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10229: AND CONNECTOR 3530563C1 DRIVERS HEATER CAV 7 8 2 3* 3!

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B75	12	LTGN	1661227C1
3*	B75A	12	LTGN	1661227C1
3!	B75ABA	16	LTGN	1661227C1
3#	B75AB	16	LTGN	556897C1
4-5	-	-	-	-
6	B75B	12	LTGN	1661227C1
7	B62-GA	18	WH	1661224C1
8	B62A	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * W/BOOSTER PUMP N/ACTIVATED BY DRVR HTR SW ; # N/0508108 - NOT MTA FUSE BLOCK ; ! W/0508108 - MTA FUSE BLOCK ; REV REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 03MAR20 AE08090674 036

23.39. CONNECTOR COMPOSITES @10230, %10230, P. 37 | Figure 1165 CONNECTOR COMPOSITES @10230, %10230 | printed page 1165

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B63F	16	DKBL	1661226C1
2	B63B	16	DKBL	1661226C1
3*	B63RE	12	DKBL	1661227C1
3#	B63RN	14	DKBL	1661227C1
3&	B63D	16	DKBL	1661226C1
3%	B63P	14	DKBL	1661226C1
3%%	B63D	16	LTBL	1661226C1
3!	B63	14	DKBL	1661226C1
3^	B63AN	16	DKBL	1661226C1
3**	B63C	16	DKBL	1661226C1
3##	B63D	12	DKBL	1661227C1
4	-	-	-	-
5#	B63RC	12	DKBL	1661227C1
5^	B63AM	16	DKBL	1661226C1
6#	B63RJ	12	DKBL	1661227C1
6^	B63AP	16	DKBL	1661226C1
7#	B62-GU	18	WH	3541250C1
7#	B62-GV	18	WH	3541250C1
7*	B62-GU	18	WH	1661224C1
8#	B62U	18	DKBL	3541250C1
8#	B62V	18	DKBL	3541250C1
8*	B62U	18	DKBL	1661224C1
9-10	-	-	-	-

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B63FG	16	DKBL	1661226C1
2	B63BB	16	DKBL	1661226C1
3	B63RE	12	DKBL	1661227C1
3#	B63RN	14	DKBL	1661226C1
3!!	B63DW	16	DKBL	1661226C1
3%%	B63A	14	DKBL	1661226C1
3^^	B63DA	14	DKBL	1661226C1
3&&	B63DV	16	DKBL	1661226C1
3**	B63	14	DKBL	1661226C1
3?	B3AN	16	DKBL	1661226C1
3??	B63CR	16	DKBL	1661226C1
3+	B63DY	14	DKBL	1661226C1
4	-	-	-	-
5#	B63RC	12	DKBL	1661227C1
5##	B63AM	16	DKBL	1661226C1
6#	B63RJ	12	DKBL	1661227C1
6?	B63AP	16	DKBL	1661226C1
7!	B62-GU	18	WH	3541250C1
7!	B62-GV	18	WH	3541250C1
7^	B62-GU	18	WH	1661224C1
8!	B62U	18	DKBL	3541250C1
8!	B62V	18	DKBL	3541250C1
8^	B62U	18	DKBL	1661224C1
9	-	-	-	-
10	-	-	-	-

23.40. CONNECTOR COMPOSITES %10231, %10233, P. 37A | Figure 1166 CONNECTOR COMPOSITES %10231, %10233 | printed page 1166

Connector 10231: 7 8 1 2

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B63C	16	DKBL	1661226C1
3*	B63RM	12	DKBL	1661227C1
3#	B63E	16	DKBL	1661226C1
4	-	-	-	-
5	B63RD	12	DKBL	1661227C1
6	B63RK	12	DKBL	1661227C1
7	B62-GV	18	WH	1661224C1
8	B62V	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: * W/DOME LT SPLIT SW W/RHEO W/ +9 FRONT WDO ; # W/DOME LT SPLIT SW N/RHEO W/ +9 FRONT WDO ; % N/0508108 - NOT MTA FUSE BLOCK

Connector 10231: % DOME LIGHT 7 8 2 3* 3#

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B63CA	16	DKBL	1661226C1
3*	B63RM	14	DKBL	1661226C1
3#	B63E	16	DKBL	1661226C1
4	-	-	-	-
5	B63RD	12	DKBL	1661227C1
6	B63RK	12	DKBL	1661227C1
7	B62-GV	18	WH	1661224C1
8	B62V	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: % W/0508108 - MTA FUSE BLOCK ; * W/DOME LT SPLIT SW W/RHEO ; # W/DOME LT SPLIT SW N/RHEO

Connector 10233: CONNECTOR 3530563C1 # REAR ROW DOME LIGHT 7 8 4 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2*	B63WD	18	DKBL	1661224C1
2&	B63WV	16	DKBL	1661226C1
3!	B63REA	16	DKBL	1661226C1
3^	B63X	18	DKBL	1661224C1
3%	B63X	18	DKBL	3541250C1
3%	B63Z	18	DKBL	3541250C1
3?	B63RR	14	DKBL	1661226C1
3??	B63RR	16	DKBL	1661226C1
3!!	B63D	16	DKBL	1661226C1
3#	B63WE	16	DKBL	1661226C1
3##	B63WA	16	DKBL	1661226C1
3^^	B63Z	16	DKBL	1661226C1
4-6	-	-	-	-
7	B62-GAH	18	WH	1661224C1
8	B62AH	18	DKBL	1661224C1
9-10	-	-	-	-

23.41. CONNECTOR COMPOSITES %10232, @10233, P. 38 | Figure 1167 CONNECTOR COMPOSITES %10232, @10233 | printed page 1167

Connector 10232: 7 8 1 2# 2!

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2#	B63AC	18	DKBL	1661224C1
2!	B63ACA	18	DKBL	1661224C1
3	B63AD	18	DKBL	1661224C1
4-6	-	-	-	-
7	B62-GAK	18	WH	1661224C1
8	B62AK	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; # N/0508108 - NOT MTA FUSE BLOCK ; ! W/0508108 - MTA FUSE BLOCK

Connector 10233: REAR ROW DOME LIGHT 7 8 3% 3&

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2*	B63W	18	DKBL	1661224C1
2#	B63W	16	DKBL	1661226C1
3%	B63RE	16	DKBL	1661226C1
3&	B63D	16	DKBL	1661226C1
3**	B63X	18	DKBL	1661224C1
3##	B63X	18	DKBL	3541250C1
3##	B63Z	18	DKBL	3541250C1
3&&	B63RR	14	DKBL	1661226C1
3*#	B63RR	16	DKBL	1661226C1
3#*	B63X	16	DKBL	0239805R1
3#*	B63WA	16	DKBL	0239805R1
3*&	B63Z	16	DKBL	0239805R1
4-6	-	-	-	-
7	B62-GAH	18	WH	1661224C1
8	B62AH	18	DKBL	1661224C1
9-10	-	-	-	-

23.42. CONNECTOR COMPOSITES %10234, %10235, @10236, P. 39 | Figure 1168 CONNECTOR COMPOSITES %10234, %10235, @10236 | printed page 1168

Connector 10234: 7 8 2! 3!

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2&	B63AA	14	DKBL	1661226C1
2!	B63AAA	14	DKBL	1661226C1
3!	B63ABA	16	DKBL	1661226C1
3!	B63ABB	14	DKBL	1661226C1
3*	B63AB	16	DKBL	1661226C1
3#	B63AB	14	DKBL	1661226C1
4-6	-	-	-	-
7	B62-GAJ	18	WH	1661224C1
8	B62AJ	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * W/RED DRIVERS DOME W/ DRIVERS DOME LT ; # W/DRIVERS DOME LT ACTIVATED BY STEP LIGHT ; & N/0508108 - NOT MTA FUSE BLOCK ; ! W/0508108 - MTA FUSE BLOCK

Connector 10235: & ! GUARD DOME LIGHT 7 8 4 1 CAV 1 2

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B63AE	18	DKBL	1661224C1
3	B63AF	18	DKBL	1661224C1
4-6	-	-	-	-
7	B62-GAL	18	WH	1661224C1
8	B62AL	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10236: MASTER FLASHER 7 8 4 1 3 5

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B123F	18	LTGN	1661224C1
3	-	-	-	-
5	B9H	18	GY	1661224C1
6*	B123B	18	OR	3541250C1
6#	B123A	18	GY	3541250C1
6#	B123T	18	GY	3541250C1
6%	B123A	18	LTGN	3541250C1
6%	B123B	18	LTGN	3541250C1
6&	B123A	18	LTGN	1661224C1
6!	B123A	18	OR	3541250C1
6^	B123B	18	GY	1661224C1
6^^	B123B	18	LTGN	1661224C1
5-6	-	-	-	-
7	B62-GAC	18	WH	1661224C1
8	B62AC	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * W/L MOUNTED MASTER SW W/L AED ; # W/L MOUNTED MASTER SW W/NON SEQUENTIAL3POSITION ROTARY ; % W/PWL ACTIVATED BY LIFT DOOR OPEN & MASTER SW ; & W/L MOUNTED MASTER SW N/FLASHER CANCEL ; ! W/L MOUNTED MASTER SW W/L AED ; ^ W/L MOUNTED MASTERSW W/MOMENTRARY FLR CANCEL ; ^^ W/L MOUNTED MASTER SW W/SINGLE CYCLE CANCEL

23.43. CONNECTOR COMPOSITES %10236A, %10237, %10238, P. 40 | Figure 1169 CONNECTOR COMPOSITES %10236A, %10237, %10238 | printed page 1169

Connector 10236A: 7 8 4 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B123-GK	18	WH	1661224C1
3	B123M	18	GY	1661224C1
4	-	-	-	-
5	B123-GL	18	WH	1661224C1
6	-	-	-	-
7	B62-GAG	18	WH	1661224C1
8	B62-AG	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10237: FLASHER START 7 8 1! 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1&	B123E	18	LTGN	1661224C1
1!	B123EL	18	LTGN	1661224C1
2	B9E	18	GY	1661224C1
3	B123H	18	LTGN	1661224C1
4-6	-	-	-	-
7&	B62-GAC	18	WH	1661224C1
7!	B62-GAV	18	WH	1661224C1
8&	B62AC	18	DKBL	1661224C1
8!	B62ACA	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK ; & N/0508108 - NOT MTA FUSE BLOCK ; ! W/0508108 - MTA FUSE BLOCK

Connector 10238: ! FLASHER OVERRIDE 7 8 4 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B123J	18	LTGN	1661224C1
3-4	-	-	-	-
5	B9J	18	LTGN	1661224C1
6&	B123E	18	GY	1661224C1
6!	B123EM	18	GY	1661224C1
7	B62-GAR	18	WH	1661224C1
8	B62AR	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK ; & N/0508108 - NOT MTA FUSE BLOCK ; ! W/0508108 - MTA FUSE BLOCK

23.44. CONNECTOR COMPOSITES %10239, %10241, %10242, P. 41 | Figure 1170 CONNECTOR COMPOSITES %10239, %10241, %10242 | printed page 1170

Table: INC.

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2*	B9H	18	GY	1661224C1
2&	B123B	18	GY	1661224C1
2!	B9HJ	18	GY	1661224C1
2#	B123-GL	18	WH	1661224C1
3#	B123N	18	GY	1661224C1
3&	B123A	18	LTGN	1661224C1
3&	B123M	18	LTGN	1661224C1
4	-	-	-	-
5	B123F	18	GY	1661224C1
6	-	-	-	-
7*	B62-GAC	18	WH	1661224C1
7*	B62-GAD	18	WH	1661224C1
7%	B62-GBG	18	WH	1661224C1
7*	B62-GAC	16	LTGN	1661226C1
7!	B62-GAT	18	WH	1661224C1
7!	B62-GDA	18	WH	1661224C1
7!	B62-GAU	16	LTGN	1661226C1
8*	B62AC	18	DKBL	1661224C1
8*	B62AD	18	DKBL	1661224C1
8!	B62ACC	18	DKBL	1661224C1
8!	B62ADB	18	DKBL	1661224C1
8%	B62-BG	18	DKBL	1661224C1
8%	B62AC	16	LTGN	1661226C1
9-10	-	-	-	-

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2*	B119L	18	GY	1661224C1
2!	B119LT	18	GY	1661224C1
3	B119M	18	GY	1661224C1
4-6	-	-	-	-
7	B62-GE	18	WH	1661224C1
8	B62E	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 ; - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * N/0508108 - NOT MTA FUSE BLOCK ; ! W/0508108 - MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B119-GG	18	WH	1661224C1
3	B119-GH	18	WH	1661224C1
4-5	-	-	-	-
6	B119-GJ	18	WH	1661224C1
7	B62-GD	18	WH	1661224C1
8	B62D	18	DKBL	1661224C1
9-10	-	-	-	-

23.45. CONNECTOR COMPOSITES @10243A, @10243B, @10244A, P. 42 | Figure 1171 CONNECTOR COMPOSITES @10243A, @10243B, @10244A | printed page 1171

Connector 10243A: CAV 1 2 LEFT FRONT HEATER 7 8 4 1 5 2 3& B75K 3# B75AC

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B75AL	12	LTGN	1661227C1
3*	B75K	12	LTGN	1661227C1
3!	B75ACA	14	LTGN	1661227C1
3&	B75K	14	LTGN	1661226C1
3#	B75AC	14	LTGN	1661227C1
3%	B75AD	14	LTGN	1661227C1
4%	-	-	-	-
5#	B75L	12	LTGN	1661227C1
5!	B75LA	12	LTGN	1661227C1
6*	B75C	14	LTGN	1661226C1
6!	B75ABB	14	LTGN	1661227C1
6%	B75AA	14	LTGN	1661227C1
6#	B75AB	14	LTGN	1661227C1
7	B62-GK	18	WH	1661224C1
8	B62K	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * W/84.5KBTU DUAL SW ACTIVATES BOOSTER PUMP ; % W/84.5KBTU SINGLE SW ; # N/0508108 - NOT MTA FUSE BLOCK ; ! W/0508108 - MTA FUSE BLOCK

Connector 10243B: # N/0508108 ! W/0508108 LEFT FRONT HEATER 2 CAV 5 7 2 8 4 1 2# B75L 2! B75LA

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2#	B75L	12	LTGN	1661227C1
2!	B75LA	12	LTGN	1661227C1
3	B75M	14	LTGN	1661226C1
4-5	-	-	-	-
6	B75N	14	LTGN	1661226C1
7	B62-GL	18	WH	1661224C1
8	B62L	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; # N/0508108 - NOT MTA FUSE BLOCK ; ! W/0508108 - MTA FUSE BLOCK

Connector 10244A: # N/0508108 ! W/0508108 LEFT REAR HEATER CAV 5 7 2 8 4 1 2 3* 3#

Table: W/0508108 - MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B75P	12	LTGN	1661227C1
3*	B75D	12	LTGN	1661227C1
3#	B75D	14	LTGN	1661226C1
3%	B75BC	14	LTGN	1661227C1
3%	B75BD	14	LTGN	1661227C1
4%	-	-	-	-
5	B75F	12	LTGN	1661227C1
6#	B75E	14	LTGN	1661226C1
6%	B75BA	14	LTGN	1661227C1
6%	B75BB	14	LTGN	1661227C1
7	B62-GM	18	WH	1661224C1
8	B62M	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * W/84.5KBTU DUAL SW ACTIVATES BOOSTER PUMP ; # W/84.5KBTU DUAL SW ; % W/84.5KBTU SINGLE SW ; REV REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 03MAR20 AE08090674 042

23.46. CONNECTOR COMPOSITES @10244B, @10245A, @10245B, P. 43 | Figure 1172 CONNECTOR COMPOSITES @10244B, @10245A, @10245B | printed page 1172

Connector 10244B: LEFT REAR HEATER 2 5 7 2 8 4 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B75F	12	LTGN	1661227C1
3	B75H	14	LTGN	1661226C1
4-5	-	-	-	-
6	B75J	14	LTGN	1661226C1
7	B62-GN	18	WH	1661224C1
8	B62N	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10245A: @ CONNECTOR 3530563C1 RIGHT FRONT HEATER 7 8 2 3* 3#

Table: N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B75R	12	LTGN	1661227C1
3*	B75S	12	LTGN	1661227C1
3#	B75S	14	LTGN	1661226C1
3%	B75CC	14	LTGN	1661227C1
3%	B75CD	14	LTGN	1661227C1
4	-	-	-	-
5	B75U	12	LTGN	1661227C1
6&	B75T	14	LTGN	1661226C1
6%	B75CA	14	LTGN	1661227C1
6%	B75CB	14	LTGN	1661227C1
7	B62-GP	18	WH	1661224C1
8	B62P	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * W/84.5KBTU DUAL SW BOOSTER PUMP ; # W/50KBTU SINGLE SW ; % W/84.5KBTU SINGLE SW ; & W/50KBTU/84.5KBTU SINGLE SW BOOSTER PUMP

Connector 10245B: & RIGHT FRONT HEATER 2 5 7 2 8 4 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B75U	12	LTGN	1661227C1
3	B75V	14	LTGN	1661226C1
4-5	-	-	-	-
6	B75W	14	LTGN	1661226C1
7	B62-GR	18	WH	1661224C1
8	B62R	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

23.47. CONNECTOR COMPOSITES &10246A, &10246B, *10247, P. 44 | Figure 1173 CONNECTOR COMPOSITES &10246A, &10246B, *10247 | printed page 1173

Connector 10246A: 7 8 4 1 2% 2@ 3%

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2%	B75X	12	LTGN	1661227C1
2@	B75AM	12	LTGN	1661227C1
3%	B75Y	12	LTGN	1661227C1
3*	B75Y	14	LTGN	1661226C1
3@	B75DC	14	LTGN	1661227C1
3@	B75DD	14	LT GN	1661227C1
4	-	-	-	-
5!	B75AAC	12	LTGN	1661227C1
5^	B75AA	12	LTGN	1661227C1
6*	B75Z	14	LTGN	1661226C1
6#	B75Z	12	LTGN	1661227C1
6@	B75DA	14	LTGN	1661227C1
6@	B75DB	14	LTGN	1661227C1
7	B62-GS	18	WH	1661224C1
8	B62S	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: - @ W/84.5KBTU SINGLE SWITCH ; % W/BOOSTER PUMP ; BLOCK * W/STANDARD ; # W/WALL MOUNTED

Connector 10246B: ^ N/0508108 - NOT MTA FUSE BLOCK * ! W/0508108 - MTA FUSE BLOCK # RIGHT REAR HEA 7 8 4 1 2* 2! 2#

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2*	B75AA	12	LTGN	1661227C1
2!	B75AAC	12	LTGN	1661227C1
2#	B75AJ	12	LTGN	1661227C1
3*	B75AB	14	LTGN	1661226C1
3#	B75AB	12	LTGN	1661227C1
4-5	-	-	-	-
6*	B75AC	14	LTGN	1661226C1
6#	B75AC	12	LTGN	1661227C1
7	B62-GT	18	WH	1661224C1
8	B62T	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: * W/84.5KBTU DUAL SWITCH ; # W/WALL MOUNT 75KBTU/80KBTU ; ! W/0508108 - MTA FUSE BLOCK

Connector 10247: LF AUX HEATER FG C** C!

CAV	CIRCUIT	GA	COLOR	TERMINAL
A%	B75C	14	LTGN	3544877C1
A@	B75AA	14	LTGN	3544877C1
B	-	-	-	-
C**	B75N	14	LTGN	3544877C1
C!	B75ABB	14	LTGN	3544877C1
C@	B75AB	14	LTGN	3544877C1
D#	B75L	12	LTGN	3544877C1
D!	B75LB	12	LTGN	3544877C1
D!	B75ACA	14	LTGN	3544877C1
D&	B75K	14	LTGN	3544877C1
D@	B75AC	14	LTGN	3544877C1
E	B75-GB	12	WH	3544877C1
F#	B75M	14	LTGN	3544877C1
F@	B75AD	14	LTGN	3544877C1

23.48. CONNECTOR COMPOSITES &10248, &10249, &10250, P. 45 | Figure 1174 CONNECTOR COMPOSITES &10248, &10249, &10250 | printed page 1174

Connector 10248: A@ B C**

CAV	CIRCUIT	GA	COLOR	TERMINAL
A**	B75E	14	LTGN	3544877C1
A@	B75BA	14	LTGN	3544877C1
B	-	-	-	-
C**	B75J	14	LTGN	3544877C1
C@	B75BB	14	LTGN	3544877C1
D*	B75D	14	LTGN	3544877C1
D#	B75L	12	LTGN	3544877C1
D@	B75BC	14	LTGN	3544877C1
D!	B75LC	12	LTGN	3544877C1
E^	B75-GA	12	WH	3544877C1
E!	B75-GAA	12	WH	3544877C1
F%	B75H	14	LTGN	3544877C1
F@	B75BD	14	LTGN	3544877C1

Connector 10249: ^ N/0508108 - NOT MTA FUSE BLOCK RF AUX HEATER A@@ A@ C#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A@@	B75T	14	LTGN	3544877C1
A@	B75CA	14	LTGN	3544877C1
C#	B75W	14	LTGN	3544877C1
C@	B75CB	14	LTGN	3544877C1
D%	B75L	12	LTGN	3544877C1
D*	B75S	14	LTGN	3544877C1
D@	B75CC	14	LTGN	3544877C1
D!	B75LD	12	LTGN	3544877C1

Legend: W/0508108- E B75-GC 12 WH 3544877C1 ; - F# B75V 14 LTGN 3544877C1 ; F@ B75CD 14 LTGN 3544877C1

Connector 10250: RR AUX HEATER B* C* C%

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	B75Z	14	LTGN	3544877C1
A%	B75Z	12	LTGN	3544877C1
A@	B75DA	14	LTGN	3544877C1
B*	B75-GA	12	WH	3544877C1
C*	B75AC	14	LTGN	3544877C1
C%	B75AC	12	LTGN	3544877C1
C@	B75DB	14	LTGN	3544877C1
D#	B75Y	14	LTGN	3544877C1
D%%	B75L	12	LTGN	3544877C1
D@	B75DC	14	LTGN	3544877C1
E	B75-GD	12	WH	3544877C1

Legend: W/0508108- F* B75AB 14 LTGN 3544877C1 ; F% B75AB 12 LTGN 3544877C1 ; F@ B75DD 14 LTGN 3544877C1

23.49. CONNECTOR COMPOSITES &10253, &10254, ?10255, P. 46 | Figure 1175 CONNECTOR COMPOSITES &10253, &10254, ?10255 | printed page 1175

Connector 10253: ANY WAY DETRIMENTAL TO THE INTEREST OF INC. CONVECTION HEATER 7 8 4 1 2^ 2! 3^

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B74BA	18	LTGN	1661224C1
2^	B74A	18	LTGN	1661224C1
2!	B74AA	18	LTGN	1661224C1
3^	B74B	18	LTGN	1661224C1
4-6	-	-	-	-
7	B62-GBJ	18	WH	1661224C1
8	B62BJ	18	DKBL	1661224C1
7-10	-	-	-	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; ! W/0508108 - MTA FUSE BLOCK ; ^ N/0508108 - NOT MTA FUSE BLOCK

Connector 10254: ^ N/0508108 CONNECTOR 3530563C1 CONVECTION HEATER CAV 1 1! B74BA 2! B74-GD 2^ B74-G

CAV	CIRCUIT	GA	COLOR	TERMINAL
1^	B74B	18	LTGN	1661538C1
1!	B74BA	18	LTGN	1661538C1
2!	B74-GD	18	WH	1661538C1
2^	B74-G	18	WH	1661538C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; ! W/0508108 - MTA FUSE BLOCK ; ^ N/0508108 - NOT MTA FUSE BLOCK

Connector 10254: ^ N/0508108 CONNECTOR 3530563C1 CONVECTION HEATER CAV 1 1! B74BA 2! B74-GD 2^ B74-G

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B74	12	LTGN	1661227C1
1#	B74C	12	LTGN	1661227C1
1&	B74G	12	LTGN	1661227C1
1%	B74C	16	LTGN	239805R1
1^	B74CA	16	LTGN	1661226C1
2?	B74A	12	LTGN	1661227C1
2^	B74AB	12	LTGN	1661227C1
3%	B74C	16	LTGN	1661227C1
3%%	B74B	12	LTGN	1661227C1
3!	B74D	14	LTGN	1661227C1
3&&	B74F	14	LTGN	1661227C1
3*	B74	12	LTGN	1661228C1
3*	B74H	14	LTGN	1661228C1
3#	B74C	12	LTGN	1661228C1
3#	B74D	14	LTGN	1661228C1
3**	B74D	16	LTGN	1661227C1
3&	B74G	12	LTGN	1661228C1
3??	B74D	12	LTGN	1661227C1
3??	B74D	12	LTGN	1661228C1
3?	B74H	12	LTGN	1661228C1
4-5	-	-	-	-
6%	B74D	16	LTGN	1661226C1
6!	B74E	16	LTGN	1661226C1
6*	B74F	14	LTGN	1661226C1
6#	B74E	14	LTGN	1661226C1
7%	B62-GC	18	WH	1661224C1
7&	B62-GA	18	WH	1661224C1
7^	B62-GAM	18	WH	1661224C1
8^	B62AA	18	DKBL	1661224C1
8%	B62C	18	DKBL	1661224C1
8&	B62A	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 03MAR20 AE08090674 046

23.50. CONNECTOR COMPOSITES #10255A, P. 46A
Figure 1176 CONNECTOR COMPOSITES #10255A

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 23.50. CONNECTOR COMPOSITES #10255A, P. 46A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090674 NO. 96183U 01SEP21 / CHAPTER 23 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / CONNECTOR 3530563C1 / BOOSTER PUMP #(10255A) (LOCATED ON DRIVER CONTROL PANEL) 7 8 4 1 5 2 / 6 9 / 3 10 / # W/0508108 - MTA FUSE BLOCK / Figure 1176 / CONNECTOR COMPOSITES #10255A

Connector 10255A: BOOSTER PUMP 7 8 1 2

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B9JA	18	GY	1661224C1
3	B9HA	18	GY	1661224C1
4-6	-	-	-	-
7	B62GC	18	WH	1661224C1
8	B62CA	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: # W/0508108 - MTA FUSE BLOCK

23.51. CONNECTOR COMPOSITES &10256, &10256B, &10257, &10258, P. 47 | Figure 1177 &10256, &10256B, &10257, &10258 | printed page 1177

Connector 10256: 7 8 4 1 2^ 2!

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2^	B60	18	OR	1661224C1
2!	B60C	18	OR	1661224C1
3^	B60A	18	OR	1661224C1
3!	B60AA	18	OR	1661224C1
4-6	-	-	-	-
7	B62-GBK	18	WH	1661224C1
8	B62BK	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; ! W/0508108 - MTA FUSE BLOCK ; ^ N/0508108 - NOT MTA FUSE BLOCK

Connector 10256B: AND ! CONNECTOR 3530563C1 ^ HAZARD LT 7 8 4 1 CAV 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B60BH	18	OR	1661224C1
3-4	-	-	-	-
5	B60BA	18	OR	1661224C1
6	B60BD	18	OR	1661224C1
7	B62-GBK	18	WH	1661224C1
8	B62BK	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10257: & CONNECTOR 3530563C1 AND MASTER DISCONNECT 1 7 8 2 3* 3#

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B12MD	18	LTBL	1661224C1
3*	B12N	18	LTBL	3541250C1
3#	B12S	18	LTBL	3541250C1
4-6	-	-	-	-
7	B62-GAW	18	WH	1661224C1
8	B62AW	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * W/MASTER DISCONNECT SW W/NOISE SUPPRESSION ; # W/MASTER DISCONNECT SW N/NOISE SUPPRESSION

Connector 10258: CONNECTOR 3530563C1 CAV STEPWELL HEATER FAN 1 7 8 4 1 2! 3^ 3!

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2^	B132A	12	GY	1661227C1
2!	B132AX	12	GY	1661227C1
3^	B132B	12	GY	1661227C1
3!	B132BN	12	GY	1661227C1
4-5	-	-	-	-
6^	B132C	12	GY	1661227C1
6!	B132CV	12	GY	1661227C1
7	B62-GJ	18	WH	1661224C1
8	B62J	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; ! W/0508108 - MTA FUSE BLOCK ; ^ N/0508108 - NOT MTA FUSE BLOCK ; REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 03MAR20 AE08090674 047

23.52. CONNECTOR COMPOSITES &10259, @10264, &10267A, P. 48 | Figure 1178 CONNECTOR COMPOSITES &10259, @10264, &10267A | printed page 1178

Connector 10264: NOISE SUPPRESSION 7 8 1# 1! 2

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B118R	16	LTBL	1661226C1
1#	B118L	18	LTBL	1661224C1
1!	B118L	18	LTBL	1661226C1
2	B12S	18	LTBL	1661224C1
3-6	-	-	-	-
7#	B62-GBF	18	WH	1661224C1
7&	B62-G	18	WH	1661224C1
7^	B62-GG	18	WH	1661224C1
7^	B62-G	18	WH	1661224C1
8	B62BF	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; ! W/IGNITION MASTER DISC W/NOISE SUPPRESSION ; & 1 ABATEMENT ADAPTER ; ^ W/NOISE SUPPRESSION W/LOW VOLTAGE MODULE ; * W/NOISE SUPPRESSION W/AC NOISE ABATEMENT ; # W/NOISE SUPPRESSION SW OUTPUTS ; & W/NOISE SUPPRESSION W/LOW VOLTAGE DISCONNECT

Connector 10267A: # W/NOISE & W/NOISE DESTINATION SIGN CAV 7 8 4 1 2 3 4

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B134	16	OR	1661226C1
3	B134F	16	OR	1661226C1
4	-	-	-	-
5	B134A	16	OR	1661226C1
6	B134R	16	OR	1661226C1
7	B62-GAE	18	WH	1661224C1
8*	B62AE	18	DKBL	1661224C1
8#	B62AEW	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * N/0508108 - NOT MTA FUSE BLOCK ; # W/0508108 - MTA FUSE BLOCK

23.53. CONNECTOR COMPOSITES &10267B, &10268, P. 49 | Figure 1179 CONNECTOR COMPOSITES &10267B, &10268 | printed page 1179

Connector 10267B: DESTINATION SIGN 2 7 8 4 1 CAV 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B134A	16	OR	1661226C1
3	B134R	16	OR	1661226C1
4-6	-	-	-	-
7	B62-GAF	18	WH	1661224C1
8	B62AF	18	DKBL	1661224C1
9-10	-	-	-	-

Connector 10268: LUGGAGE BOX LT 7 8 CAV

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B135A	16	OR	1661226C1
3	B135	16	OR	1661226C1
4-6	-	-	-	-
7	B62-GX	18	WH	1661224C1
8	B62X	18	DKBL	1661224C1
9-10	-	-	-	-

23.54. CONNECTOR COMPOSITES &10270, &10281, &10282, P. 50 | Figure 1180 CONNECTOR COMPOSITES &10270, &10281, &10282 | printed page 1180

Connector 10270: STROBE LIGHT 7 8 4 1 3^ 3#

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2#	B127A	16	OR	1661226C1
2!	B127A	16	OR	1661227C1
2!	B127C	16	OR	1661227C1
3^	B127D	16	OR	1661226C1
3#	B127B	16	OR	1661226C1
3!	B127B	16	OR	1661227C1
3!	B127D	16	OR	1661227C1
4	-	-	-	-
5	B127	16	BK	1661226C1
6*	B127F	16	OR	1661226C1
6^	B127B	16	OR	1661226C1
7#	B62-GW	18	WH	1661224C1
8#	B62W	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; # W/STROBE LT ACTIVATED W/SW ; ! W/STROBE LT ACTVTD W/SW OR PWL ; ^ W/STROBE LT ACTVTD W/MOM SW ; * W/ STROBE LT INDICATOR

Connector 10281: LIFT 7 8 4 1 5 6 7*

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B62BN	18	DKBL	1661224C1
3-4	-	-	-	-
5	B122T	18	GY	1661224C1
6	B122U	18	WH	1661224C1
7*	B62-GAD	18	WH	1661224C1
7^	B62-GD	18	WH	1661224C1
7^	B62-GDB	18	WH	1661224C1
7^	B62-GDC	18	WH	1661224C1
8	B62AD	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * N/0508108 - NOT MTA FUSE BLOCK ; ^ W/0508108 - MTA FUSE BLOCK

Connector 10282: ^ W/0508108 PEDESTRIAN LIGHTS 87 30^ 30^ 30*

CAV	CIRCUIT	GA	COLOR	TERMINAL
30^	B139C	16	YL	0556897C1
30^	B139B	16	YL	0556897C1
30*	B139B	16	YL	0239805R1
85^	B139-G	16	WH	0556897C1
85*	B139-G	16	WH	0239805R1
85^	B139-GA	16	WH	0556897C1
86^	B139	16	YL	0239805R1
87	-	-	-	-

Legend: 87a* B120AL 16 LTGN 0239805R1 ; 87a# B119T 16 GY 0239805R1 ; & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; ^ DUAL PEDESTRIAN LIGHTS W/ TIMER ; # W/PEDESTRIAN LT W/TIMER W/STOP ARM ; * W/PEDESTRIAN LT W/TIMER N/STOP ARM ; REV REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS

23.55. CONNECTOR COMPOSITES &10283, &10284, &10285, &10286, P. 51 | Figure 1181 CONNECTOR COMPOSITES &10283, &10284, &10285, &10286 | printed page 1181

Connector 10283: 7 8 4 1 1 2

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B67-G	18	WH	1661224C1
3	B67-GA	18	WH	1661224C1
4-6	-	-	-	-
7	B62-GBR	18	WH	1661224C1
8	B62BR	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10284: CAV DRIVERS FAN 1^ 1* 2&

CAV	CIRCUIT	GA	COLOR	TERMINAL
1&	B76FHI	14	LTGN	1661538C1
1^	B76DHI-A	14	LTGN	1661538C1
1*	B76DHI	14	LTGN	1661538C1
2&	B76FLO	16	LTGN	1661538C1
2^	B76DLO-A	16	LTGN	1661538C1
2*	B76DLO	16	LTGN	1661538C1
3&	B76-GF	14	WH	1661538C1
3&	B76D-G	14	WH	1661538C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * N/0508108 - NOT MTA FUSE BLOCK ; ^ W/0508108 - MTA FUSE BLOCK

Connector 10285: * CONNECTOR 2206665C1 ^ AIR HORN A A# A% B#

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A#	B100B	18	GY	1661875C1	1661872C1
A%	B100A	18	GY	1661875C1	1661872C1
B#	B100-G	18	WH	1661875C1	1661872C1
B%	B100-GA	16	WH	1661875C1	1661872C1

Legend: # W/AIR HORN ACTIVATED BY PANEL SW & FOOT SW ; % W/AIR HORN ACTIVATED BY PULL CHAIN ; & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10286: & BODY LOCK 1661874C1 AND AIR HORN 7 8 4 1 1 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B100A	18	GY	1661224C1
3	B100B	18	GY	1661224C1
4-6	-	-	-	-
7	B62-GB	18	WH	1661224C1
8	B62B	18	DKBL	1661224C1
9-10	-	-	-	-

23.56. CONNECTOR COMPOSITES &10293, &10295, &10299, &10300, P. 52 | Figure 1182 CONNECTOR COMPOSITES &10293, &10295, &10299, &10300 | printed page 1182

Connector 10293: HEATED MIRROR 7 8 4 1 2^ 3*

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2*	B78A	18	LTGN	1661224C1
2^	B78AR	18	LTGN	1661224C1
3*	B78B	18	LTGN	1661224C1
3^	B78BA	18	LTGN	1661224C1
4-6	-	-	-	-
7	B62-GAS	18	WH	1661224C1
8*	B62AS	18	DKBL	1661224C1
8^	B62ASA	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * N/0508108 - NOT MTA FUSE BLOCK ; ^ W/0508108 - MTA FUSE BLOCK

Connector 10295: ^ W/0508108 HEATED MIRROR TIMER 1 1 2 3&

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B78E	18	LTGN	1661538C1
2	B78-GE	18	WH	1661538C1
3&	B78E	18	LTGN	1661536C1
3*	B78D	18	LTGN	1661536C1
3^	B78DK	18	LTGN	1661536C1
4	B78AD	18	LTGN	1661538C1

Connector 10299: CONNECTOR 2206666C1 DRIVERS ALARM A B A# A^ A^

CAV	CIRCUIT	GA	COLOR	TERMINAL
A&	B12W	18	LTBL	1661261C1
A#	B14W	18	RD	1661261C1
A^	B14WA	18	RD	1661261C1
A^	B14WB	18	RD	1661261C1
B&	B11-GAL	18	WH	1661261C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; # N/0508108 - NOT MTA FUSE BLOCK ; ^ W/0508108 - MTA FUSE BLOCK

Connector 10300: # N/0508108 ^ W/0508108 STROBE LIGHT LATCH 87 30* B127C 30* B127D 85 B127-G

CAV	CIRCUIT	GA	COLOR	TERMINAL
30*	B127C	16	OR	0556897C1
30*	B127D	16	OR	0556897C1
85	B127-G	16	WH	0239805R1
86	B127A	16	BK	0239805R1
87	-	-	-	-

Legend: 87a B127B 16 OR 0239805R1 ; & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * MUTUALLY EXCLUSIVE

CONNECTOR COMPOSITE (10301-10440) (CHAPTER 24) | Figure 1183 CONNECTOR COMPOSITES @@10301 | printed page 1183

Connector 10301:

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B14L	12	BK	3768157C1
2@	B14LH	12	BK	3768157C1
3-4	-	-	-	-
5	B122E	16	GY	3768013C1
6#	B133A	18	LTGN	3768012C1
6!	B120J	18	LTGN	3768012C1
6!!	B120J	16	LTGN	3768013C1
7	B71H	18	LTBL	3768012C1
8!%	B14SE	16	RD	3768013C1
8!^	B137	16	LTBL	3768013C1
9	B14CD	12	BK	3768018C1
10	-	-	-	-
11**	B14D	12	BK	3768018C1
11*&	B118D	12	BK	3768018C1
12	-	-	-	-
13	B135A	16	OR	3768013C1
14	B86B	16	LTGN	3768013C1
15*!	B75R	12	LTGN	3768014C1
15&&	B75AM	12	LTGN	3768014C1
16	B76A	16	LTGN	3768013C1
17	-	-	-	-
18	B13D	12	BK	3768157C1
19-20	-	-	-	-
21	B13A	18	PK	3768012C1
21	B125H	18	GY	3768012C1
21^%	B125HA	18	GY	3768012C1
22^^	B120AD	18	LTGN	3768012C1
22^*	B120AL	16	LTGN	3768013C1
22^*	B120ALD	16	LTGN	3768013C1
22^&	B77A	18	LTGN	3768012C1
22^%	B13A	18	PK	3768012C1
22^#	B13AA	18	PK	3768012C1
22^!	B13	18	PK	3768012C1
23%	B120NH	18	LTGN	3768012C1
23&	B120NJ	18	LTGN	3768012C1
24	B13LS	18	PK	3768012C1
25-27	-	-	-	-
28**	B14FB	12	BK	3768014C1
28*&	B118F	12	BK	3768014C1
29-31	-	-	-	-
32	B76D	14	LTGN	3768014C1
33**	B14EA	12	BK	3768018C1
33*&	B118E	14	BK	3768018C1
34	-	-	-	-
35**	B14Z	12	BK	3768018C1
35*&	B118H	12	BK	3768018C1
36	-	-	-	-
37?	B75AM	12	LTGN	3768014C1
37&^	B75X	12	LTGN	3768014C1
37&&	B75AJ	12	LTGN	3768014C1
38	B76B	16	LTGN	3768013C1
39	B75P	12	LTGN	3768014C1
39	B75R	12	LTGN	3768014C1
40	B86A	16	LTGN	3768013C1

24.2. CONNECTOR COMPOSITES @@10301, P. 1A | Figure 1184 CONNECTOR COMPOSITES @@10301 | printed page 1184

Connector 10301: FUSE BLOCK LOCATION CAVITY FUSE DESCRIPTION
Table: (LOCATED AT FLASHER PLATE)

LOCATION	FUSE DESCRIPTION
F1 A1, B1	DRIVERS HEATER
F2 E1, F1	STEPWELL FLOOR HEATER
F3 G1, H1	CONVECTION HEATER
F3 G1, H1	LEFT FRONT PASSENGER HEATER
F4 A2, B2	DEFOG FAN RIGHT SWITCH
F4 A2, B2	DEFOG FAN (X2) RIGHT SWITCH
F4 A2, B2	CENTER BLOWER RIGHT SWITCH
F5 E2, F2	LEFT REAR PASSENGER HEATER
F6 G2, H2	RADIO POWER
F7 A3, B3	RIGHT REAR WALL HEATER SWITCH 1
F7 A3, B3	RIGHT FRONT PASSENGER HEATER
F8 E3, F3	FRONT POWER VENT
F9 G3, H3	AIR CONDITIONING
F10 A4, B4	RIGHT REAR WALL HEATER SWITCH 2
F10 A4, B4	RIGHT REAR HEATER
F11 E4, F4	REAR POWER VENT
F12 G4, H4	DEFOG FAN LEFT SWITCH
F12 G4, H4	DEFOG FAN (X2) LEFT SWITCH
F12 G4, H4	CENTER BLOWER LEFT SWITCH

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A1*	(B14W)	-	-	3515516C1
A1#	(B118A)	-	-	3515516C1
A2*	B14F	12	BK	3573311C1
A2#	B118F	12	BK	3573311C1
A3*	B14D	12	BK	3536301C1
A3#	B118D	12	BK	3536301C1
A4*	B14E	12	BK	3536301C1
A4#	B118E	14	BK	3536301C1
B1	B75	12	LTGN	3573311C1
B2	B76D	14	LTGN	3573312C1
B3%	B75R	12	LTGN	3573311C1
B3&	B75AM	12	LTGN	3573311C1
B4@	B75X	12	LTGN	3573311C1
B4&	B75AJ	12	LTGN	3573311C1
B4##	B75AM	12	LTGN	3573311C1
C1*	(B14W)	-	-	3515516C1
C1#	(B118A)	-	-	3515516C1
C2	-	-	-	-
C3*	(B14D)	-	-	3536301C1
C3#	(B118D)	-	-	3536301C1
C4*	(B14E)	-	-	3536301C1
C4#	(B118E)	-	-	3536301C1
D1-D4	-	-	-	-
E1*	B14W	10	BK	3515516C1
E1#	B118A	10	BK	3515516C1
E2*	B14Z	12	BK	3536299C1
E2#	B118H	12	BK	3536299C1
E3*	(B14D)	-	-	3536301C1
E3#	(B118D)	-	-	3536301C1
E4*	(B14E)	-	-	3536301C1
E4#	(B118E)	-	-	3536301C1
F1	B132A	12	GY	3573311C1

Legend: CHK DATE ; MJV0488 13SEP21 INITIAL PRODUCTION A 96183U ; RELEASE.

Connector 10301: FUSE BLOCK LOCATION CAVITY FUSE DESCRIPTION
Table: CENTER BLOWER LEFT SWITCH

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
F2	B75P	12	LTGN	3573311C1
F2#!	B75R	12	LTGN	3573311C1
F3	B76A	16	LTGN	3573312C1
F4	B76B	16	LTGN	3573312C1
G1*	B14Y	14	BK	3573312C1
G1#	B118B	14	BK	3573312C1
G2*	(B14Z)	-	-	3536299C1
G2#	(B118H)	-	-	3536299C1
G3*	B14C	14	BK	3536299C1
G3#	B118C	12	BK	3536299C1
G4*	B14CJ	14	BK	3573312C1
G4#	B118J	12	BK	3573311C1
H1**	B75AL	12	LTGN	3573311C1
H1*#	B74A	18	LTGN	3515517C1
H1#*	B75R	12	LTGN	3516158C1
H2	B86A	16	LTGN	3573312C1
H3	B77A	18	LTGN	3515517C1
H4	B76C	14	LTGN	3573312C1
J1-J2	-	-	-	-
J3*	(B14C)	-	-	3536299C1
J3#	B14CJ	14	BK	3536299C1
J3*	(B118C)			3536299C1
J3#	B118J	12	BK	3536299C1
J4	-	-	-	-

Legend: * POWER CABLE N/MASTER DISC & N/NOISE SUPPRESSION ; # W/NOISE SUPPRESSION CIRCUIT ; % W/R FRONT PASSENGER HTR SINGLE SW ; & W/R REAR WALL MOUNTED HTR ; @ W/R REAR PASSENGER HTR SINGLE SW ; ** W/L FRONT PASSENGER HTR SINGLE SW ; *# W/CONVECTION HTR ; ## R REAR 84.5K BTU SINGLE SW ; #! LT MID, R MID, R REAR HTR

24.3. CONNECTOR COMPOSITES @@10302, P. 2 | Figure 1185 CONNECTOR COMPOSITES @@10302 | printed page 1185

Connector 10302: FUSE BLOCK - B9

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B14N	12	BK	3768157C1
3-4	-	-	-	-
5*	B14AB	18	RD	3768012C1
5&	B14	18	RD	3768012C1
5^	B125H	16	GY	3768013C1
5%	B125E	18	GY	3768012C1
5#	B14CMA	18	RD	3768013C1
5#	B14CMB	18	RD	3768013C1
5!!	B14CMA	18	RD	3768012C1
5#!	B14VA	18	RD	3768012C1
5#%	B14KL	18	RD	3768012C1
6*	B14BC	14	RD	3768014C1
6!%	B14XC	14	RD	3768014C1
6&	B85X	14	GY	3768014C1
6!&	B85X	14	RD	3768014C1
6#	B125F	18	GY	3768012C1
6^	B125A	18	GY	3768012C1
6%	B53	16	GY	3768013C1
7*^	B144B	18	GY	3768013C1
7*%	B14UB	14	RD	3768014C1
7*^	B144	18	GY	3768013C1
8	B14LS	18	RD	3768012C1
9	-	-	-	-
10	B12H	12	BK	3768156C1
11	-	-	-	-
12	B14HH	16	BK	3768017C1
13&#	B12A	18	LTBL	3768012C1
13^^	B12W	18	LTBL	3768013C1
13^^	B12C	18	LTBL	3768013C1
14	B58J	16	BN	3768013C1
15*	B12AC	18	LTBL	3768012C1
15#	B125C	18	GY	3768012C1
15!%	B12AP	18	LTBL	3768012C1
15^	B125	18	GY	3768012C1
15!&	B12	18	LTBL	3768012C1
15&	B12AJ	18	LTBL	3768012C1
15#!	B12AK	18	LTBL	3768012C1
16!!	B125K	16	GY	3768013C1
16#	B125J	16	GY	3768013C1
17	-	-	-	-
18	B12HK	12	BK	3768018C1

Legend: & LIFT 19%! B14WW 12 BK 3768018C1 ; 19#* B118A 12 BK 3768018C1 ; 20 - - - ; 21%% B12RC 14 LTGN 3768014C1 ; 21*% B12UA 14 LTBL 3768014C1

24.4. CONNECTOR COMPOSITES @@10302, P. 3 | Figure 1186 CONNECTOR COMPOSITES @@10302 | printed page 1186

Connector 10302: FUSE BLOCK - B9

CAV	CIRCUIT	GA	COLOR	TERMINAL
22##	B139	16	YL	3768013C1
22#!	B128J	16	LTBL	3768013C1
23	B75	12	LTGN	3768014C1
24	B132AX	12	GY	3768014C1
25	-	-	-	-
26	B12K	12	BK	3768156C1
27-28	-	-	-	-
29	B78A	18	LTGN	3768012C1
30**	B128	16	LTBL	3768013C1
30?	B128K	16	LTBL	3768013C1
31	B131A	16	DKBL	3768013C1
32	-	-	-	-
33	B12KL	12	BK	3768014C1
34	-	-	-	-
35	-	-	-	-
35??	B14HG	14	BK	3768156C1
35+	B14HE	14	BK	3768156C1
35?+	B14HY	14	BK	3768156C1
36	-	-	-	-
37	B63AS	16	DKBL	3768013C1
38*!	B63AAH	12	DKBL	3768014C1
38&&	B63AH	12	DKBL	3768014C1
38!	B63BK	16	DKBL	3768013C1
39&^	B63M	16	DKBL	3768013C1
39&	B14H	14	RD	3768014C1
39!	B63L	16	DKBL	3768013C1
39^*	B63AW	16	DKBL	3768013C1
39%	B85	16	GY	3768013C1
39*	B14CA	14	RD	3768014C1
39&	B14HZ	14	RD	3768014C1
39?&	B14MA	16	RD	3768013C1
40^#	B60BH	18	OR	3768012C1
40^!	B60C	18	OR	3768012C1

24.5. CONNECTOR COMPOSITES @@10302, P. 3A | Figure 1187 CONNECTOR COMPOSITES @@(10302) | printed page 1187

Connector 10302: FLASHER PLATE) 1 4 2 3 A1# B12B A2# B12BJ A2* B14RJ

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
C3#	B12DJ	14	BK	3536299C1
C3#	(B14T)	-	-	3536299C1
C3*	B14TJ	14	BK	3536299C1
C4	-	-	-	-
D1-D4	-	-	-	-
E1*	B14P	12	BK	3536299C1
E1#	B12A	12	BK	3536299C1
E2*	B14S	12	BK	3536299C1
E2#	B12C	12	BK	3536299C1
E3*	B14U	12	BK	3536299C1
E3#	B12E	12	BK	3536299C1
E4*	B14V	10	BK	3536298C1
E4#	B12F	10	BK	3536298C1
F1	B74A	12	LTGN	3573311C1
F2	B63A	12	DKBL	3573311C1
F3*	B137A	16	LTBL	3573312C1
F3#	B146A	12	GY	3573311C1
F4*#	B105	16	WH	3573312C1
F4*%	B105	16	LTGN	3573312C1
G1#	(B12A)	-	-	3536299C1
G1*	(B14P)	-	-	3536299C1
G2#	(B12C)	-	-	3536299C1
G2*	(B14S)	-	-	3536299C1
G3#	(B12E)	-	-	3536299C1
G3*	(B14U)	-	-	3536299C1
G4#	(B12F)	-	-	3536298C1
G4*	(B14V)	-	-	3536298C1
G4#	B12FJ	10	BK	3536298C1
G4*	B14VJ	10	BK	3536298C1
H1*&	B86U	14	LTGN	3573312C1
H1*@	B12RA	14	LTGN	3573312C1
H1!	B12RD	14	LT BL	3573312C1
H2#*	B137B	14	LTBL	3573312C1
H2*@	B86U	14	LTGN	3573312C1
H2##	B137A	16	LTBL	3573312C1
H2#%	B137	16	LTBL	3573312C1
H2#&	B13K	18	PK	3534164C1
H2*	B13	18	PK	3534164C1
H2!	B12RC	14	LT BL	3573312C1
H3#@	B134	16	OR	3573312C1
H3%*	B134	16	RD	3573312C1
H4%#	B105A	16	LTGN	3573312C1
H4%%	B105	16	LTGN	3573312C1
H4%&	B12RB	14	LTGN	3573312C1
H4%@	B125A	18	GY	3573312C1
H4%@	B125T	18	GY	3573312C1
H4?	B13K	18	PK	3534164C1
H4!	B12RB	14	LTBL	3573312C1
J1-J4	-	-	-	-

Connector 10302: FLASHER PLATE) 1 4 2 3 A1# B12B A2# B12BJ A2* B14RJ

Table: FUSE BLOCK #10302

LOCATION	FUSE DESCRIPTION	RATING
F13	STEP WARMER	25A
F14	BOOSTER PUMP/DEFOG FAN DRIVERS BLOWER	15A/20A
F15	TWO-WAY RADIO TERMINAL STRIP	20A
F16	AIR HORN	3A
F17	DOME LIGHTS (STANDARD)	15A
F18	DDR/DVR SYSTEM	7.5A/3A
F18	CAMERA SYSTEM	7.5A
F18	VIDEO SYSTEM TERMINAL STRIP	20A
F19	HEATED MIRRORS	15A
F20	CAMERA SYSTEM	5A
F21	DESTINATION SIGN	10A
F22	TRACTION CHAINS	7.5A
F22	TRACTION SANDERS	15A
F23	AIR SEAT	15A
F24	HEATED SEAT/CHILD SAFETY ALARM	7.5A

Legend: * W/POWER CABLE N/MASTER DISC & N/NOISE SUPPRESSION H4%# B105A 16 LTGN 3573312C1 ; # W/POWER CABLE W/MASTER DISC & W/NOISE SUPPRESSION H4%% B105 16 LTGN 3573312C1 ; % W/DOOR CONTROL ELEC ; & W/HEATED MIRROR W/TIMER ; ** W/TRACTION CHAINS ; *# W/AIR SEAT ; *% W/HEATED SELF CONTAINED AIR SEAT ; *& W/2 WAY RADIO POWER STRIP ; *@ W/2 WAY RADIO & ACCESSORY FEED

24.6. CONNECTOR COMPOSITES @@10303, P. 4 | Figure 1188 CONNECTOR COMPOSITES @@10303 | printed page 1188

Connector 10303: FUSE BLOCK - B6

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B14KK	12	BK	3768157C1
2?	B63T	16	DKBL	3768155C1
3	-	-	-	-
4	B10LA	18	WH	3768012C1
5	B84	16	LTGN	3768013C1
6*	B74A	12	LTGN	3768014C1
6&	B74A	12	RD	3768014C1
6^	B74B	16	RD	3768013C1
6%	B74B	14	LTGN	3768014C1
6#	B74C	16	LTGN	3768013C1
6!	B74	16	LTGN	3768013C1
6!!	B74	14	LTGN	3768014C1
6!#	B74P	16	RD	3768013C1
7	B58	16	BN	3768013C1
8	B10LB	18	WH	3768012C1
9	-	-	-	-
10	B14MM	12	BK	3768157C1
11	-	-	-	-
12*&	B14Y	14	BK	3768014C1
12*^	B118B	14	BK	3768014C1
13#&	B14UA	14	RD	3768014C1
13^	B74	12	RD	3768014C1
13*!	B14AH	16	RD	3768013C1
13&&	B14RH	16	RD	3768013C1

24.7. CONNECTOR COMPOSITES @10303, P. 5 | Figure 1189 CONNECTOR COMPOSITES @10303 | printed page 1189

Connector 10303: FUSE BLOCK - B6

CAV	CIRCUIT	GA	COLOR	TERMINAL
14&*	B119G	16	GY	3768013C1
14&^	B89Z	14	OR	3768014C1
15&%	B71CY	16	LTBL	3768013C1
15&#	B131A	16	DKBL	3768013C1
16&!	B75AL	12	LTGN	3768014C1
16^^	B74AA	18	LTGN	3768012C1
16?	B75R	12	LTGN	3768014C1
17^*	B12B	18	LTBL	3768012C1
17^&	B125C	18	GY	3768013C1
17^&	B130A	18	GY	3768013C1
18^#	B120WZ	18	LTGN	3768012C1
18^!	B120WA	18	LTGN	3768012C1
19	B12NH	12	BK	3768018C1
20	-	-	-	-
21^*	B12W	18	LTBL	3768013C1
21^&	B130	18	GY	3768012C1
21^*	B12C	18	LTBL	3768013C1
22%!	B123N	18	LTGN	3768012C1
22##	B120WAN	18	LTGN	3768012C1
23#*	B12RD	14	LTGN	3768014C1
23#&	B12UB	14	LTBL	3768014C1
24	B63AX	16	DKBL	3768013C1
25	-	-	-	-
26	B14XX	12	BK	3768157C1
27-28	-	-	-	-

24.8. CONNECTOR COMPOSITES @10303, P. 6 | Figure 1190 CONNECTOR COMPOSITES @10303 | printed page 1190

Connector 10303: FUSE BLOCK - B6

CAV	CIRCUIT	GA	COLOR	TERMINAL
29#%	B14CA	14	RD	3768014C1
29@	B14DM	14	RD	3768014C1
29^&	B63EE	14	RD	3768014C1
29@!	B14	14	RD	3768014C1
29@#	B121	18	YL	3768012C1
29@%	B125M	16	GY	3768013C1
29@^	B63N	16	DKBL	3768013C1
30@&	B136	16	YL	3768013C1
30@*	B121	18	YL	3768012C1
31*@	B14WA	18	RD	3768013C1
31&@	B121	18	YL	3768012C1
31*@	B14J	18	RD	3768013C1
31*@	B14WB	18	RD	3768013C1
32%@	B133L	18	LTGN	3768012C1
32!%	B131AH	16	DKBL	3768014C1
32!%	B131B	16	DKBL	3768014C1
32!%	B131AT	16	DKBL	3768014C1
33	B117J	18	LTGN	3768012C1
34	-	-	-	-
35!^	B14VV	12	BK	3768157C1
35*^	B12F	12	BK	3768157C1
36	-	-	-	-
37	B117M	18	GY	3768012C1
38	B63AM	16	DKBL	3768013C1
39!*	B105A	16	LTGN	3768013C1
39**	B105	16	LTGN	3768013C1
39#*	B12RB	14	LTGN	3768014C1
39%^	B125AN	18	GY	3768013C1
39%^	B125TD	18	GY	3768013C1
40#!	B105	16	WH	3768013C1
40!*	B105	16	LTGN	3768013C1

24.9. CONNECTOR COMPOSITES @@10303, P. 6A | Figure 1191 CONNECTOR COMPOSITES @@10303 | printed page 1191

Connector 10303: A A2 A3 A4

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	(B14H)	-	-	3536304C1
A2	(B14K)	-	-	3536303C1
A3	(B14L)	-	-	3536304C1
A4	(B14LJ)	-	-	3536304C1
B1*	B63A	12	DKBL	3573311C1
B1#	B63AH	12	DKBL	3573311C1
B1%	B63B	16	DKBL	3573312C1
B1#	B63AA	16	DKBL	3573312C1
B2&	B84	16	LTGN	3573312C1
B2%	B84	16	LTGN	3573312C1
B3&	B122E	16	GY	3573312C1
B3%	B44	18	GY	3573312C1
B4@	B135A	16	OR	3573312C1
B4^	B14UB	14	RD	3573312C1
C1	(B14H)	-	-	3536304C1
C2	(B14K)	-	-	3536303C1
C3	(B14L)	-	-	3536304C1
C4	(B14LJ)	-	-	3536304C1
D1-D4	-	-	-	-
E1	B14H	14	BK	3536304C1
E2	B14K	10	BK	3536303C1
E3	B14L	12	BK	3536304C1
E4	(B14LJ)	-	-	3536304C1
F1&	B63M	16	DKBL	3573312C1
F1*	B14H	14	RD	3573312C1
F1%	B63L	16	DKBL	3573311C1
F1%	B63M	16	DKBL	3573311C1
F1**	B63A	16	DKBL	3573312C1
F1*#	B85	16	GY	3573312C1
F1*%	B125J	16	GY	3573312C1
F1^^	B125J	16	GY	3573311C1
F1^%	B14M	16	RD	3573312C1
F1^^	B125L	16	GY	3573311C1
F1^#	B14CA	14	RD	3573312C1
F2*&	B74A	12	LTGN	3573311C1
F2*&	B74A	12	RD	3573311C1
F2#*	B74B	16	RD	3573312C1
F2##	B74B	14	LTGN	3573312C1
F2#%	B74C	16	LTGN	3573312C1
F2#&	B74	14	LTGN	3573312C1
F2#	B74P	16	RD	3573312C1
F2*%	B74	16	LTGN	3573312C1
F3&	B133A	18	LTGN	3515517C1
F3*	B120J	18	LTGN	3515517C1
F3%	B120J	16	LTGN	3573312C1
F3%	B120J	16	LTGN	3536295C1
F3**	B12C	16	LTGN	3536295C1
F3*#	B120J	16	LTGN	3573311C1
F3*%	B12C	16	LTGN	3573311C1
F3&*	B14AF	16	RD	3573311C1
F4	B86B	16	LTGN	3573312C1
G1	(B14H)	-	-	3536304C1
G2	(B14K)	-	-	3536303C1
G3&#	(B14L)	-	-	3536304C1
G3&#	B14LJ	12	BK	3536304C1
G4	B14LJ	12	BK	3536304C1
H1&%	B60BH	18	OR	3515517C1
H1&&	B60	18	OR	3515517C1
H2	B58	16	BN	3573312C1
H3	B71H	18	LTBL	3515517C1
H4?	B137	16	LTBL	3573312C1
H4^&	B14SE	16	RD	3573312C1
J1-J4	-	-	-	-

Legend: CIRCUIT DIAGRAM, BE,CE BUS MODELS, ; NO. DATE ; 08AUG21 AE08090675 06A

Connector 10303: A A2 A3 A4

Table: FUSE BLOCK #10303

LOCATION	FUSE DESCRIPTION	RATING
F25	DOME LIGHTS (HOT)	15A
F26	DOME LIGHT OPTIONS	15A
F26	PTI- CHECKMATE	5A
F26	PTI- THEFTMATE	15A
F26	PTI- CRS	15A
F27	HAZARD LIGHTS	3A
F28	DC OUTLET	15A
F29	FUEL FIRED HEATER TIMER	
F30	CLEARANCE LIGHTS	10A
F31	LIFT INTERLOCK	15A
F32	MANUAL DOOR VANDAL LOCK	7.5A
F32	AIR DOOR VANDAL LOCK	10A
F32	ELECTRIC ENTRANCE DOOR	15A
F33	REVERSE MOTION SENSOR	5A
F34	LUGGAGE BOX LIGHTS	7.5A
F35	RADIO MEMORY	5A
F36	DDR SYSTEM	5A

Legend: * W/DOME LT BATTERY FEED ; # DOME LT IGNITION FEED W/RHEO ; % DOME LT ACTIVATED W/EMERGENCY EXIT, TIMER & SW ; & DOME LT TIMER N/REAR ROW DOME ; ** DOME LT RR ROW ON SEP SW & W/REE DOOR ; *# W/CHILD MONITOR COMMON ; *% W/THEFT MATE PREWIRE ; *& W/WEBASTO FUEL FIRED HTR W/TIMER ; #* W/COOLANT HTR W/TIMER & LOW VOLTAGE DISC

24.10. CONNECTOR COMPOSITES @10304, P. 7 | Figure 1192 CONNECTOR COMPOSITES @10304 | printed page 1192

Connector 10304: FUSE BLOCK - B3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B63UB	18	DKBL	3768012C1
1&	B60BF	18	OR	3768012C1
1#	B63UD	18	DKBL	3768012C1
2^	B14ACK	12	BK	3768157C1
2*!	B118FK	12	BK	3768014C1
3	B125C	18	GY	3768012C1
4!	B125RA	18	GY	3768012C1
4!!	B131AA	18	DKBL	3768012C1
5&	B60BC	18	OR	3768012C1
5*	B63UA	18	DKBL	3768012C1
5#	B63UB	18	DKBL	3768012C1
6	B12RB	14	LTGN	3768014C1
7!&	B125B	18	GY	3768013C1
7!&	B125D	18	GY	3768013C1
7##	B125BD	18	GY	3768013C1
8!!	B131AD	16	DKBL	3768013C1
8!	B125R	18	GY	3768012C1
9	B12L	14	BK	3768018C1
10	-	-	-	-
11*#	B14P	12	BK	3768018C1
11*!	B12AM	12	BK	3768018C1
12	-	-	-	-
13&*	B127A	16	OR	3768013C1
13&^	B127	16	BK	3768014C1
13&^	B127A	16	BK	3768014C1
13&#	B127B	16	OR	3768013C1
14	B12AU	18	LTBL	3768012C1
15	B74A	12	LTGN	3768014C1
15#!	B74AB	12	LTGN	3768014C1
16^&	B86U	14	LTGN	3768014C1
16^*	B12RA	14	LTGN	3768014C1
17*#	B14S	12	BK	3768018C1
17*!	B12CL	12	BK	3768018C1
18-19	-	-	-	-
20*#	B14U	12	BK	3768018C1
20*!	B12E	12	BK	3768018C1

24.11. CONNECTOR COMPOSITES @10304, P. 8 | Figure 1193 CONNECTOR COMPOSITES @10304 | printed page 1193

Connector 10304: FUSE BLOCK - B3

CAV	CIRCUIT	GA	COLOR	TERMINAL
21	B63AZ	12	DKBL	3768014C1
22%*	B137B	14	LTBL	3768014C1
22%#	B86U	14	LTGN	3768014C1
22%!	B137A	16	LTBL	3768013C1
22##	B137	16	LTBL	3768013C1
22#%	B13K	18	PK	3768012C1
22#^	B13X	18	PK	3768012C1
23	-	-	-	-
23	B117CD	18	GY	3768012C1
24#*	B134	16	OR	3768013C1
24#!	B134	16	RD	3768013C1
25	B60BE	18	OR	3768012C1
26**	B63G	16	WH	3768013C1
26*&	B63-GM	18	WH	3768012C1
26*^	B63-G	18	WH	3768012C1
26*%	B117S	18	GY	3768012C1
27	-	-	-	-
28^	B14CV	14	BK	3768018C1
28*!	B118C	12	BK	3768018C1
29	B60BB	18	OR	3768012C1
30!#	B117D	18	GY	3768012C1
30*^	B63ED	16	GY	3768013C1
30*%	B117A	18	GY	3768012C1
31	B77A	18	LTGN	3768012C1
32	B76C	14	LTGN	3768014C1
33*#	B14T	14	BK	3768018C1
33*!	B12D	14	BK	3768018C1
34	-	-	-	-
35*#	B14R	14	BK	3768014C1
35*!	B12BT	14	BK	3768014C1
36	B117K	18	LTGN	3768012C1
37%%	B78AR	18	LTGN	3768012C1
37%^	B78DK	18	LTGN	3768012C1
38%&	B138A	16	GY	3768013C1
39#	B132A	12	GY	3768014C1
40	B133E	18	LTGN	3768012C1

24.12. CONNECTOR COMPOSITES @@10304, P. 8A | Figure 1194 CONNECTOR COMPOSITES @@10304 | printed page 1194

Connector 10304: WAY DETRIMENTAL TO THE INTEREST OF FUSE BLOCK 1 4 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
B1*	B14UA	14	RD	3573312C1
B1&	B14	16	RD	3573312C1
B1^^	B14AH	16	RD	3573312C1
B1#	B74	12	RD	3573311C1
B2&	B125D	16	GY	3573311C1
B2&	B14	18	RD	3534164C1
B2&	B125H	16	GY	3573311C1
B2**	B125D	18	GY	3573312C1
B2*#	B125H	16	GY	3573312C1
B2*&	B125E	18	GY	3573312C1
B2*#	B14CMA	18	RD	3534164C1
B2%%	B14CMA	18	RD	3573312C1
B2%%	B14CMB	18	RD	3573312C1
B2^	B14AA	18	RD	3573312C1
B2^	B14AB	18	RD	3573312C1
B3*%	B133U	18	LTGN	3573312C1
B3*%	B17C	18	LTGN	3573312C1
B3*%	B17C	18	LTGN	3534164C1
B3^%	B17C	18	PK	3573312C1
B4^!	B13SE	16	PK	3573312C1
B4^	B13AA	18	PK	3534164C1
B4	-	-	-	-
C1	(B14M)	-	-	3536303C1
C2	(B14N)	-	-	3536304C1
C3	(B13D)	-	-	3536304C1
C4	(B13DJ)	-	-	3536304C1
D1	-	-	-	-
D2	B14LS	18	RD	3534164C1
D3	B13LS	18	PK	3534164C1
D4	-	-	-	-
E1	B14M	10	BK	3536303C1
E2	B14N	12	BK	3536304C1
E3	B13D	12	BK	3536304C1
E4	(B13DJ)	-	-	3536304C1
F1*	B119	16	GY	3573312C1
F1#*	B89	14	OR	3573312C1
F2##	B85X	14	GY	3516158C1
F2**	B14X	14	RD	3516158C1
F2*#	B125A	18	GY	3515517C1
F2#%	B53	16	GY	3573312C1
F2*#	B125F	18	GY	3515517C1
F2#%	B85X	14	RD	3516158C1
F2^	B14BA	14	RD	3516158C1
F3#&	B120AA	18	LTGN	3573312C1
F3##	B13	18	PK	3534164C1
F3#%	B120AB	18	LTGN	3573312C1
F3#&	B120AB	16	LTGN	3573312C1
F3#	B77A	18	LTGN	3534164C1
F3#	B13A	18	PK	3534164C1
F4	B119L	18	GY	3515517C1

Connector 10304: WAY DETRIMENTAL TO THE INTEREST OF FUSE BLOCK 1 4 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	(B14M)	-	-	3536303C1
A2	(B14N)	-	-	3536304C1
A3	(B13D)	-	-	3536304C1
A4	(B13DJ)	-	-	3536304C1

Legend: @@ N/0508108 - NOT MTA FUSE BLOCK ; * W/BATTERY & ACCESSORY FEED ; # W/COOLANT HTR W/TIMER ; & LOW VOLTAGE DISC ; % W/SEON PREWIRE ; & W/BUS SCAN PTI ; ** W/CHILD MONITOR ; *# W/THEFT MATE PREWIRE ; *% W/OVERHEAD LOCKING COMPARTMENT

24.13. CONNECTOR COMPOSITES @@10304, P. 8B | Figure 1195 CONNECTOR COMPOSITES @@10304 | printed page 1195

Connector 10304: CHART CONTINUED FROM SHEET 08A FUSE BLOCK 1 4 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
G1	(B14M)	-	-	3536303C1
G2	(B14N)	-	-	3536304C1
G3	(B13D)	-	-	3536304C1
G3	B13DJ	12	BK	3536304C1
G4	B13DJ	12	BK	3536304C1
H1	B71C	16	LTBL	3573312C1
H1??	B131A	16	DKBL	3573312C1
H2%#	B144B	18	GY	3573312C1
H2*	B14UB	14	RD	3573312C1
H2%#	B144	18	GY	3573312C1
H2?	B14UA	14	RD	3573312C1
H3	B120N	18	LTGN	3515517C1
H4%&	B13A	18	PK	3515517C1
H4*#	B125H	18	GY	3515517C1
H4?*	B125H	18	PK	3534164C1
J1-J4	-	-	-	-

Connector 10304: CHART CONTINUED FROM SHEET 08A FUSE BLOCK 1 4 2 3

Table: FUSE BLOCK # 10304

LOCATION	FUSE DESCRIPTION	RATING
F37	SPARE TIRE WINCH	25A
F37	DVR SYSTEM	5A
F38	STOP-ARM / CROSSING GATE	7.5A
F39	PUPIL WARNING LIGHTS RED & BLUE	15A
F39	B/U LIGHTS - ACTIVATED BY REAR	
F39		15A
F39	EMERGENCY EXIT	
F39	PTI - CRS	10A
F40	PTI - CHECKMATE	3A
F40	PTI - THEFTMATE	5A
F41	PTI - CHECKMATE - DEACTIVATE	3A
F41	PTI - CRS - HEADLIGHTS	15A
F41	PTI - THEFTMATE	10A
F43	STARTER INTERLOCK	3A
F44	ALTERNATE ENTRANCE DOOR ELECTRIC	7.5A
F44	AIR CONDITIONING NOISE SUPPRESSION	5A
F44	PTI - CHECKMATE	3A
F44	ALTERNATE ENTRANCE DOOR AIR OPERATED	3A
F45	ENTRANCE DOOR	7.5A
F46	FUEL FIRED HEATER TIMER	3A
F47	STOP-ARM / CROSSING GATE CANCEL	3A
F48	DOME LIGHT TIMER RELAY	5A
F48	PTI - THEFTMATE	3A
F98	LIQUID SPRING SUSPENSION	5A
F99	LIQUID SPRING SUSPENSION	5A

24.14. CONNECTOR COMPOSITES @10305, P. 9
Figure 1196 CONNECTOR COMPOSITES @10305

24.14. CONNECTOR COMPOSITES @10305, P. 9 | Figure 1196 CONNECTOR COMPOSITES @10305 | printed page 1196

Connector 10305: FUSE BLOCK - B1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B133R	18	LTGN	3768013C1
1*	B133P	18	LTGN	3768013C1
1!!	B133P	18	LTGN	3768012C1
2	B117H	18	LTGN	3768012C1
3^^	B13SE	16	PK	3768013C1
3!	B74N	16	LTGN	3768013C1
4	B119LT	18	GY	3768012C1
5^	B133U	18	LTGN	3768013C1
5^	B17C	18	LTGN	3768013C1
5**	B17C	18	LTGN	3768012C1
6	B125E	18	GY	3768012C1
7	B140	18	TN	3768012C1
8	B41B	18	TN	3768012C1
9	B143	18	DKBL	3768012C1
10	B100A	18	GY	3768012C1
11	B13E	12	BK	3768018C1
12	-	-	-	-
13	B13DC	12	BK	3768156C1
14-17	-	-	-	-
18	B12MG	14	BK	3768156C1
19	B12HM	16	BK	3768013C1
20%	B14RR	16	BK	3768013C1
20#	B12BB	16	BK	3768013C1
R1-30	B132A	12	GY	4185895C1
R1-85	B132-GC	18	WH	4200453C1
R1-86	B132C	18	GY	4200453C1
R1-87	B132	12	GY	4185895C1

24.15. CONNECTOR COMPOSITES @10305, P. 9A
Figure 1197 CONNECTOR COMPOSITES @10305

24.15. CONNECTOR COMPOSITES @10305, P. 9A | Figure 1197 CONNECTOR COMPOSITES @10305 | printed page 1197

Connector 10305: FUSE BLOCK A A1 A2

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	(B12H)			3536303C1
A2	(B12HJ)			3536303C1
A3	B60BE	18	OR	3534164C1
A4	(B12KJ)			3536303C1
B1*	B12A	18	LTBL	3534164C1
B1#	B12W	18	LTBL	3573312C1
B1#	B12C	18	LTBL	3573312C1
B2%	B12RC	14	LTGN	3516158C1
B2&	B12RC	14	LTGN	3573312C1
B2?	B12UA	14	LTBL	3573312C1
B3	B60BB	18	OR	3534164C1
B4	B131A	16	DKBL	3573312C1
C1	(B12H)			3536303C1
C2	(B12HJ)			3536303C1
C3	(B12K)			3515516C1
C4	(B12KJ)			3536303C1
D1-D4	-	-	-	-
E1	B12H	10	BK	3536303C1
E2	(B12HJ)			3536303C1
E3	B12K	10	BK	3515516C1
E4	(B12KJ)			3536303C1
F1	B58J	16	BN	3573312C1
F2*#	B139	16	YL	3573312C1
F2*%	B128	16	LTBL	3573312C1
F3	B78A	18	LTGN	3515517C1
F4*	B63A	16	DKBL	3573312C1
G1	(B12H)			3536303C1
G1	B12HJ	10	BK	3536303C1
G2	B12HJ	10	BK	3536303C1
G3	(B12K)			3515516C1
G3	B12KJ	10	BK	3515516C1
G4	B12KJ	10	BK	3536303C1
H1	B143	18	DKBL	3515517C1
H2#*	B125	18	GY	3515517C1
H2*&	B12	18	LTBL	3515517C1
H2**	B12A	18	LTBL	3515517C1
H2##	B125	18	GY	3534164C1
H2#%	B125C	18	GY	3515517C1
H2^	B12AA	18	LTBL	3536295C1
H2^	B12AB	18	LTBL	3536295C1
H2??	B125C	18	GY	3534164C1
H2^^	B12	18	LTBL	3534164C1
H3	B128	16	LTBL	3573312C1
H4	B41B	18	TN	3515517C1
J1-J4	-	-	-	-

Connector 10305: FUSE BLOCK A A1 A2

Table: FUSE BLOCK #10305

LOCATION	FUSE DESCRIPTION	RATING
F49	EMERGENCY EXIT ALARMS	7.5A
F50	FRONT CLUSTER LIGHTS	0.5A
F51	EMERGENCY EXIT LIGHTS	3A
F52	TRACTION SANDERS	3A
F53	PEDESTRIAN LIGHTS	20A
F54	PTI - CHECK MATE	3A
F54	PTI - THEFTMATE	3A
F54	PTI - CRS	5A
F55	CONVECTION HEATERS	5A
D55	AUX HAZARD (ALSO D70)	
F56	MOTORIZED MIRRORS	10A
F57	LIGHT MONITOR	7.5A
F57	INDICATOR LIGHT MONITOR	3A
F58	STEP LIGHT	7.5A
F59	HEATED WIPER BLADES	7.5A
F59	DOME LIGHT OPTIONS	5A
F60	ENGINE COMPARTMENT TEMP SENSOR	3A
? W/BATTERY	& ACCESSORY FEED	
^ W/CHECKMATE	CONNECTORS	
^^ W/POST	TRIP W/SNOOZE & LIFT WARNING	
?? W/THEFTMATE	W/ EMERGENCY EXIT ACTIVATED	

Legend: * W/DRIVERS ALARM - PIEZO, ACCESSORY FEED N/+9 ; # W/DRIVERS ALARM - ACCESSORY FEED W/BATTERY ; FEED BUZZER ; % W/ACCESSORY POWER STRIP ; & W/2 WAY RADIO & ACCESSORY FEED ; ** W/TRACTION SANDERS ; *# W/PEDESTRIAN LIGHT - TIMER ; *% PWL W/DUAL MONITOR N/+9 ; *& W/HEATED WIPER BLBES

24.16. CONNECTOR COMPOSITES @@10306, P. 9B
Figure 1198 CONNECTOR COMPOSITES @@10306

24.16. CONNECTOR COMPOSITES @@10306, P. 9B | Figure 1198 CONNECTOR COMPOSITES @@10306 | printed page 1198

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	B12B	18	LTBL	3515517C1
A1&&	B125C	18	GY	3536295C1
A1&&	B130A	18	GY	3536295C1
A2*	B120W	18	LTGN	3515517C1
A2#	B120WA	18	LTGN	3515517C1
A3	B117J	18	LTGN	3515517C1
A4%	B63UB	18	DKBL	3534164C1
A4&	B60BF	18	OR	3534164C1
B1@	B12W	18	LTBL	3573312C1
B1**	B12C	18	LTBL	3573312C1
B1&&	B130	18	GY	3534164C1
B2*#	B123N	18	LTGN	3515517C1
B2*%	B120WA	18	LTGN	3515517C1
B3	B117M	18	GY	3515517C1
B4&	B60BC	18	OR	3534164C1
B4%	B63UA	18	DKBL	3534164C1
C1	B10LA	18	WH	3534164C1
C2-C4	-	-	-	-
D1	B10LB	18	WH	3534164C1
D2-D4	-	-	-	-
E1	B12L	14	BK	3536304C1
E2	B12M	14	BK	3536299C1
E3	(B12MJ)			3536299C1
E4	B13E	12	BK	3536299C1
F1*&	B127A	16	OR	3573312C1
F1*@	B127	16	BK	3573311C1
F1*@	B127A	16	BK	3573311C1
F1#*	B127B	16	OR	3573312C1
F2	B125E	18	GY	3534164C1
F3##	B12RD	14	LTGN	3573312C1
F3#%	B12UB	14	LBL	3573312C1
F4#&	B133R	18	LTGN	3573312C1
F4#@	B84	16	LTGN	3573312C1
F4#&	B133P	18	LTGN	3573312C1
F4%*	B133P	18	LTGN	3534164C1
G1	(B12L)			3536299C1
G2	(B12M)			3536299C1
G2	B12MJ	14	BK	3536299C1
G3	B12MJ	14	BK	3536299C1
G4	(B13E)			3536299C1
H1	B12A	18	LTBL	3515517C1
H2	B140	18	TN	3515517C1
H3	B63A	16	DKBL	3573312C1
H4	B117H	18	LTGN	3515517C1
J1-J4	-	-	-	-

Connector 10306: FUSE BLOCK 1 4 2 3 TERMINAL 3515517C1
Table: FUSE BLOCK #10306
LOCATION	FUSE DESCRIPTION	RATING
D61	SEE CIRCUIT DIAGRAM	
F62	STROBE LIGHT	7.5A
F63	DOME LIGHT TIMER RELAY	5A
D64	SEE CIRCUIT DIAGRAM	
F65	PTI - LEAVE NO STUDENT BEHIND	3A
F66	BATTERY ISOLATOR	3A
D67	REAR DOOR OPTIONS	
F68	SEE CIRCUIT DIAGRAM -	
F69	SEE CIRCUIT DIAGRAM -	
D70	AUX HAZARD (ALSO D55)	
F71	LOCKING COMPARTMENT	3A
F71	DC POWER SOURCE	15A
F72	BUZZER ISOLATION RELAY	3A
F105	LIQUID SPRING SUSPENSION	5A

Legend: * W/ELEC/AIR DOOR W/SINGLE CYCLE FLASHER CANCEL ; # W/AIR DOOR OPEN W/RRX CANCEL ; % W/DOME LT RELAY EE OR ENTER DOOR TRIGGER ; & W/L PANEL MOUNTED HAZARD SW ; @ W/DRIVERS ALARM - MECHANICAL, ACCESSORY FEED N/+9 ; ** DRIVERS ALARM - MECHANICAL, ACCESSORY FEED W/+9 ; *# W/SINGLE CYCLE FLASHER CANCEL ; *% W/RRX CANCEL ; *& W/STROBE LT SW ACTIVATED N/SCR

24.17. CONNECTOR COMPOSITES @@10307, P. 9C | Figure 1199 CONNECTOR COMPOSITES @@10307 | printed page 1199

Connector 10307: 1 4 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1@#	B125C	18	GY	3515517C1
A1?	B117BA	18	GY	3515517C1
A2#&	B125RA	18	GY	3534164C1
A2?	B131AA	18	DKBL	3534164C1
A2^	B63F	18	DKBL	3534164C1
A3*	B63G	16	WH	3515517C1
A3#	B63-GM	18	WH	3515517C1
A3%	B63-G	18	WH	3515517C1
A3&	B117	18	GY	3534164C1
A3^	B63B	18	DKBL	3515517C1
A4	B117K	18	LTGN	3515517C1
B1@	B125B	18	GY	3573312C1
B1@	B125D	18	GY	3573312C1
B1?	B117B	18	GY	3573312C1
B1?	B117C	18	GY	3573312C1
B2#&	B125R	18	GY	3534164C1
B2?	B131AB	18	DKBL	3534164C1
B2^	B63H	18	DKBL	3534164C1
B3#	B117D	18	GY	3515517C1
B3%	B63E	16	GY	3515517C1
B3&	B117A	18	GY	3534164C1
B3^	B63C	16	DKBL	3515517C1
B4	B133E	18	LTGN	3515517C1
C1	B119-G	16	WH	3573312C1
C2	B119L	16	GY	3573312C1
C3-C4	-	-	-	-
D1	B119C	16	GY	3573312C1
D2	B119S	16	GY	3573312C1
D3-D4	-	-	-	-
E1**	B14AA	10	BK	3536298C1
E1*#	B118K	10	BK	3536298C1
E2*%	(B12FJ)			3536298C1
E2*&	(B14VJ)			3536298C1
E3	B14X	10	BK	3536298C1
E4	(B14XJ)			3536298C1
F1-F2	-	-	-	-
F3*@	B14CA	14	RD	3573312C1
F3#*	B14DM	14	RD	3573312C1
F3##	B121	18	YL	3515517C1
F3#%	B125M	16	GY	3573312C1
F3!	B14	14	RD	3573312C1
F3^	B63D	16	DKBL	3573312C1

Legend: @# W/PTID ; ? W/CHECKMATE CONNECTORS ; ! W/DOME LT SINGLE SW N/RHEO ; @@ N/0508108 - NOT MTA FUSE BLOCK

24.18. CONNECTOR COMPOSITES @@10307, P. 9D | Figure 1200 CONNECTOR COMPOSITES @@10307 | printed page 1200

Connector 10307: CHART CONTINUED FROM SHEET 09C FUSE BLOCK 1 4 2 3
Table: BODY LOCK 2 3599541C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
F3#&	B63N	16	DKBL	3573312C1
F3#@	B63E	14	RD	3573312C1
F4&@	B14W	18	RD	3573312C1
F4&@	B14J	18	RD	3573312C1
F4&&	B121	18	YL	3534164C1
G1**	(B14AA)	-	-	3536298C1
G1*#	(B118K)	-	-	3536298C1
G2*%	B12FJ	10	BK	3536298C1
G2*&	B14VJ	10	BK	3536298C1
G3**	(B14X)	-	-	3536298C1
G3*#	B14XJ	10	BK	3536298C1
G4	B14XJ	10	BK	3536298C1
H1	B12RB	14	LTGN	3573312C1
H2	B63AM	16	DKBL	3573312C1
H3	B136	16	YL	3573312C1
H3%%	B121	18	YL	3534164C1
H4#	B133L	18	LTGN	3515517C1
H4%	B131A	16	DKBL	3536295C1
H4&	B131B	16	DKBL	3536295C1
J1-J4	-	-	-	-

24.19. CONNECTOR COMPOSITES %%10308, P. 10
Figure 1201 CONNECTOR COMPOSITES %%10308

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.19. CONNECTOR COMPOSITES %%10308, P. 10 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090675 NO. 95504E 31MAY20 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 SEE CH 01_AE08090652 _028 FOR DETAILS. / FUSE BLOCK - B11 %%(10308) (LOCATED IN ELECTRICAL PANEL HARNESS) / CONNECTOR 3768010C1 RELAY LOCK 3768011C1 RETAINER 4149060C1 / CHART CONTINUED ON / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / Figure 1201 / CONNECTOR COMPOSITES %%10308

Connector 10308: FUSE BLOCK - B11

CAV	CIRCUIT	GA	COLOR	TERMINAL
R1-30	B58	16	BN	3768007C1
R1-85	B58-GF	18	WH	3768003C1
R1-86	B58F	18	BN	3768003C1
R1-87	B58A	16	BN	3768007C1

Legend: R2-30% B71F 16 LTBL 3768007C1 ; R2-30& B71S 16 OR 3768007C1 ; R2-30^ B71B 16 LTBL 3768007C1 ; R2-30! B127B 16 OR 3768007C1 ; R2-30# B71E 16 LTBL 3768007C1 ; R2-85! B127J 16 OR 3768004C1 ; R2-85% B117BB 18 LTBL 3768003C1 ; R2-86! B127-G 16 WH 3768004C1 ; R2-86% B71DH 16 LTBL 3768004C1

Figure 1202 CONNECTOR COMPOSITES %%10308

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.20. CONNECTOR COMPOSITES %%10308, P. 11 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090675 NO. 95504E 31MAY20 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 SEE CH 01_AE08090652 _028 FOR DETAILS. / FUSE BLOCK - B11 %%(10308) (LOCATED IN ELECTRICAL PANEL HARNESS) / CONNECTOR 3768010C1 RELAY LOCK 3768011C1 RETAINER 4149060C1 / CHART CONTINUED FROM / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / Figure 1202 / CONNECTOR COMPOSITES %%10308

Connector 10308: FUSE BLOCK - B11

CAV	CIRCUIT	GA	COLOR	TERMINAL
R3-86	B123CK	18	LTGN	3768003C1
R3-87	B123E	18	LTGN	3768007C1

Legend: R4-30* B77C 18 LTGN 3768007C1 ; R4-30^! B131 16 DKBL 3768007C1 ; R4-85* B77-G 18 WH 3768003C1 ; R4-85^! B131-GS 16 WH 3768004C1 ; R4-86^! B131B 16 DKBL 3768004C1 ; R4-86* B77B 18 LTGN 3768003C1 ; R4-87* B77D 18 LTGN 3768007C1 ; R4-87^! B131AT 16 DKBL 3768007C1 ; R4-87# B131AH 16 DKBL 3768007C1

24.21. CONNECTOR COMPOSITES @@10308, P. 11A | Figure 1203 CONNECTOR COMPOSITES @@10308 | printed page 1203

Connector 10308: DETRIMENTAL TO THE INTEREST OF CONNECTOR RELAY BLOCK A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	B58-GF	18	WH	3515517C1
A2	B58	16	BN	3573312C1
A3*	B77-G	18	WH	3515517C1
A3#	B131-GS	16	WH	3515517C1
A4*	B77C	18	LTGN	3515517C1
A4#	B131	16	DKBL	3515517C1
B1	B58A	16	BN	3573312C1
B2	B58F	18	BN	3515517C1
B3*	B77D	18	LTGN	3515517C1
B3#	B131A	16	DKBL	3515517C1
B4#	B131B	16	DKBL	3515517C1
B4*	B77B	18	LTGN	3515517C1
C1%	B127D	16	OR	3573311C1
C1&	B117B	18	LTBL	3534164C1
C1%	B127F	16	OR	3573311C1
C2*	B71F	16	LTBL	3573312C1
C2**	B127B	16	OR	3573312C1
C2*#	B71E	16	LTBL	3573312C1
C2#%	B71L	16	OR	3573311C1
C2##	B71R	16	OR	3573311C1
C2	B71B	16	LT BL	3573312C1
C3*	B146-G	18	WH	3515517C1
C3#	B137-GA	16	WH	3515517C1
C3#*	B137-GA	18	WH	3515517C1
C4	B146A	12	GY	3573311C1
C4	B137C	16	LTBL	3573312C1
D1%	B127E	16	OR	3573312C1
D1*%	B71A	16	LTBL	3573312C1
D1*&	B71D	16	LTBL	3573312C1
D1*&	B71D	16	LTBL	3573311C1
D1#%	B71DA	16	LTBL	3573311C1
D1*#	B71B	16	LTBL	3573311C1
D1*	B71C	16	OR	3573311C1
D2	-	-	-	-
D3	B146B	12	GY	3573311C1

Legend: CHK DATE ; MJV0488 13SEP21 INITIAL PRODUCTION A 96183U ; RELEASE.

Connector 10308: DETRIMENTAL TO THE INTEREST OF CONNECTOR RELAY BLOCK A

RELAY	LOCATION	DESCRIPTION
	A1,A2,B1,B2	CLEARANCE LIGHT RELAY
	A3,A4,B3,B4	A / C RELAY
C1,C2,D1,D2,E1,E2		B / U LIGHT RELAY
C1,C2,D1,D2,E1,E2	C3,C4,D3,D4	AIR COMPRESSOR RELAY
C1,C2,D1,D2,E1,E2	E1,F1,G1,G2	PUPIL WARNING LIGHT RELAY
C1,C2,D1,D2,E1,E2	E3,F3,E4,F4	CHILD SAFETY ALARM RELAY
C1,C2,D1,D2,E1,E2	J1,J2,H1,H2	PARK BRAKE RELAY
C1,C2,D1,D2,E1,E2	G3,G4,H3,H4	CHILD SAFETY ALARM RELAY

24.22. CONNECTOR COMPOSITES @@10308, P. 11B | Figure 1204 CONNECTOR COMPOSITES @@10308 | printed page 1204

Connector 10308: FROM SHEET 11A CAV RELAY BLOCK A D4## B71C D4#* B71D

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
D3	B137D	16	LTBL	3573312C1
D4**	B12	18	LTBL	3515517C1
D4##	B71C	18	LTBL	3515517C1
D4#*	B71D	16	LTBL	3515517C1
E1	B127F	16	OR	3573312C1
E1	B71B	16	LTBL	3573312C1
E2**	B127-G	16	WH	3573312C1
E2##	B71B	16	LTBL	3573311C1
E2#*	B71C	16	LTBL	3573311C1
E3?	B125-GU	18	WH	3573312C1
E3?	B125-GV	18	WH	3573312C1
E3^*	B125PB	18	GY	3534164C1
E4?	B125-GV	18	WH	3515517C1
E4^%	B125PA	18	GY	3534164C1
F1	B123D	18	LTGN	3515517C1
F2#*	B9F	18	LTGN	3515517C1
F2##	B123B	18	LTGN	3515517C1
F3?	B125S	18	GY	3515517C1
F3^%	B125-GB	18	GY	3534164C1
F3^*	B125PA	18	GY	3515517C1
F4?	B120C	18	LTGN	3515517C1
F4^*	B14CMB	18	RD	3515517C1
F4^%	B14CMB	18	RD	3534164C1
G1	B123E	18	LTGN	3515517C1
G2	B123C	18	LTGN	3515517C1
G3**	B125V	18	GY	3515517C1
G3*&	B120B	16	LTBL	3515517C1
G3^	B117E	16	GY	3515517C1
G3^&	B171-G	16	WH	3515517C1
G4?	B9P	18	GY	3515517C1
G4#	B9B	18	GY	3515517C1
G4^&	B171-GA	16	WH	3515517C1
G4^	B117A	18	GY	3515517C1
H1#%	B44-G	18	WH	3536295C1
H1#%	B44-GA	18	WH	3536295C1
H2	B44-GA	18	WH	3515517C1
H3?	B89N	18	OR	3515517C1
H3#	B9C	18	GY	3515517C1
H3^!	B171-GB	16	WH	3515517C1
H3^^	B171-GB	16	WH	3536295C1
H3^^	B171-GD	18	WH	3536295C1
H3^	B117B	18	GY	3515517C1
H4	B125T	18	GY	3534164C1
J1	B44A	18	GY	3515517C1
J2	B44	18	GY	3515517C1
J3	-	-	-	-
J3^	B11GF	16	WH	3573312C1
J4	B123-GC	18	WH	3534164C1
J4^!	B17D	18	PK	3534164C1
J4^^	B171	18	GY	3573312C1
J4^^	B17D	18	PK	3573312C1
J4^	B14AE	18	RD	3573312C1
J4^	B14AF	18	RD	3573312C1

Connector 10308: FROM SHEET 11A CAV RELAY BLOCK A D4## B71C D4#* B71D

RELAY	LOCATION	DESCRIPTION
	A1,A2,B1,B2	CLEARANCE LIGHT RELAY
	A3,A4,B3,B4	A / C RELAY
C1,C2,D1,D2,E1,E2		B / U LIGHT RELAY
C1,C2,D1,D2,E1,E2	C3,C4,D3,D4	AIR COMPRESSOR RELAY
C1,C2,D1,D2,E1,E2	E1,F1,G1,G2	PUPIL WARNING LIGHT RELAY
C1,C2,D1,D2,E1,E2	E3,F3,E4,F4	CHILD SAFETY ALARM RELAY
C1,C2,D1,D2,E1,E2	J1,J2,H1,H2	PARK BRAKE RELAY
C1,C2,D1,D2,E1,E2	G3,G4,H3,H4	CHILD SAFETY ALARM RELAY

Legend: @@ N/0508108 - MTA FUSE BLOCK ; * W/AIR CONDITIONING ; # W/SED LANDING LIGHT ; % W/STROBE LT SW OR SARM ACTIVATED ; & W/BACK UP LT ACTIVATED BY REDR COMMON ; ** W/STROBE LT SW OR SARM ACTIVATED N/+9 FR WDO ; *# W/BACK UP LT ACTIVATED BY REDR W/MONITOR ; *% W/REE ACTIVATED BACK UP LT SIGNAL ; *& W/REE ACTIVATED BACK UP LT SIGNAL W/DRIVER ALERT H3^^ B171-GB 16 WH 3536295C1

Figure 1205 CONNECTOR COMPOSITES @@10309

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.23. CONNECTOR COMPOSITES @@10309, P. 12 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090675 NO. RELEASE NO. 95504E 03MAR20 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 SEE CH 01_AE08090652 _028 FOR DETAILS. / FUSE BLOCK - B8 @@(10309) (LOCATED IN ELECTRICAL PANEL HARNESS) / CONNECTOR 3768010C1 RELAY LOCK 3768011C1 RETAINER 4149060C1 / CHART CONTINUED ON / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / Figure 1205 / CONNECTOR COMPOSITES @@10309

24.24. CONNECTOR COMPOSITES @@10309, P. 13
Figure 1206 CONNECTOR COMPOSITES @@10309

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.24. CONNECTOR COMPOSITES @@10309, P. 13 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090675 NO. RELEASE NO. 95504E 31MAY20 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 SEE CH 01_AE08090652 _028 FOR DETAILS. / FUSE BLOCK - B8 @@(10309) (LOCATED IN ELECTRICAL PANEL HARNESS) / CONNECTOR 3768010C1 RELAY LOCK 3768011C1 RETAINER 4149060C1 / CHART CONTINUED FROM / 86 87a 85 / 86 87a 85 / 86 87a 85 / 87a 86 85 / 86 87a 85 / 86 87a 85 / Figure 1206 / CONNECTOR COMPOSITES @@10309

24.25. CONNECTOR COMPOSITES @@10309, P. 14
Figure 1207 CONNECTOR COMPOSITES @@10309

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.25. CONNECTOR COMPOSITES @@10309, P. 14 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090675 NO. RELEASE NO. 95504E 31MAY20 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 SEE CH 01_AE08090652 _028 FOR DETAILS. / CHART CONTINUED FROM / FUSE BLOCK - B8 @@(10309) (LOCATED IN ELECTRICAL PANEL HARNESS) / CONNECTOR 3768010C1 RELAY LOCK 3768011C1 RETAINER 4149060C1 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / Figure 1207 / CONNECTOR COMPOSITES @@10309

24.26. CONNECTOR COMPOSITES @@10309, P. 14A | Figure 1208 CONNECTOR COMPOSITES @@10309 | printed page 1208

Connector 10309: FLASHER PLATE) A B3*% B3*# B3*&

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1*	B120-GL	18	WH	3573312C1
A1#	B120-GL	18	WH	3515517C1
A1#	B120-GS	18	WH	3573312C1
A1%	B120AJ	16	LTGN	3573312C1
A1&	B120AP	18	LTGN	3534164C1
A1??	B120-GK	18	WH	3573312C1
A2*	B9C	18	GY	3515517C1
A2#	B120U	18	LTGN	3515517C1
A2%	B120U	16	LTGN	3573312C1
A2&	B120U	18	LTGN	3534164C1
A3@	B125E	18	GY	3515517C1
A3**	B125K	18	GY	3515517C1
A3&	B85A-G	18	WH	3515517C1
A3*#	B85-GH	18	WH	3515517C1
A3@	B85FU	18	GY	3515517C1
A3*#	B125FB	18	GY	3534164C1
A3?#	B125E	18	GY	3534164C1
A3?	B53BC	18	GY	3515517C1
A4*%	B125D	18	GY	3515517C1
A4*#	B85T	14	GY	3516158C1
A4*%	B85A	16	GY	3573312C1
A4#%	B85E	14	GY	3516158C1
A4##	B85C	16	GY	3573312C1
A4*&	B125B	16	GY	3515517C1
A4?	B85AB	14	GY	3516158C1
B1	B120-GU	16	WH	3573312C1

Legend: * W/DOOR CONTROL MANUAL ; # W/DOOR CONTROL AIR OR ELEC ; % W/DOOR CONTROL ELEC (LOW DRIVER) ; & W/DOOR CONTROL AIR (LOW DRIVER) ; @ W/LEAVE NO STUDENT BEHIND W/BATTERY FEED ; ** W/BUS SCAN PTI ; *# W/CHILD MONITOR COMMON ; *% W/BUS SCAN & CHILD CHECK MATE PTI ; *& W/THEFT MATE PREWIRE

24.27. CONNECTOR COMPOSITES @@10309, P. 14B | Figure 1209 CONNECTOR COMPOSITES @@10309 | printed page 1209

Connector 10309: FROM SHEET 14A 2 1 RELAY BLOCK FLASHER PLATE)

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
D1%	B120AK	16	LTGN	3573311C1
D1&	B120AM	18	LTGN	3536295C1
D2#	B120T	18	LTGN	3515517C1
D2%	B120T	16	LTGN	3573312C1
D2&	B120T	18	LTGN	3534164C1
D3#%	B53B-G	18	WH	3534164C1
D3*#	B125FA	18	GY	3573312C1
D3*#	B125FB	18	GY	3573312C1
D3?	B53-GHA	18	WH	3534164C1
D3@	B85CK	18	GY	3534164C1
D3?+	B125P	18	GY	3573312C1
D3?+	B125PA	18	GY	3573312C1
D3?*	B53BB	18	GY	3573312C1
D3?*	B53BC	18	GY	3573312C1
D4??	B53E	16	YL	3573312C1
D4*#	B53B	16	YL	3573312C1
D4?&	B63T	16	LTBL	3573312C1
D4?*	B53AD	16	YL	3573312C1
E1	B120-GT	16	WH	3573312C1
E2	-	-	-	-
E3&*	B53D	16	YL	3573312C1
E3*#	B53A	16	YL	3573312C1
E3%*	B53C	16	YL	3573312C1
E3?*	B53AC	16	YL	3573312C1
E3?&	B63D	16	LTBL	3573312C1
E4	-	-	-	-
F1%	B120X	16	LTGN	3573311C1
F1*	B120V	16	LTGN	3515517C1
F1&	B120N	18	LTGN	3573312C1
F1&	B120P	18	LTGN	3573312C1
F1##	B120X	18	LTGN	3573312C1
F1&*	B120X	18	LTGN	3536295C1
F1#*	B120V	16	LTGN	3573312C1
F1%	B120Y	16	LTGN	3573311C1
F1##	B120W	18	LTGN	3573312C1
F1%*	B120W	18	LTGN	3536295C1
F2%	B120Y	16	LTGN	3573311C1
F2%	B120Z	16	LTGN	3573311C1
F2&*	B120S	18	LTGN	3515517C1
F2%%	B120S	18	LTGN	3573312C1
F2%#	B120WA	18	LTGN	3573312C1
F2%#	B120S	18	LTGN	3536295C1
F2%%	B1A	16	LTGN	3536295C1
F2%&	B120KC	18	LTGN	3534164C1
F2&*	B120P	18	LTGN	3534164C1

24.28. CONNECTOR COMPOSITES @@10309, P. 14C
Figure 1210 CONNECTOR COMPOSITES @@10309

24.28. CONNECTOR COMPOSITES @@10309, P. 14C | Figure 1210 CONNECTOR COMPOSITES @@10309 | printed page 1210

Connector 10309: 1 2 RELAY BLOCK FLASHER PLATE) F3*# F3@ F3&

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
F2%	B120JC	16	LTGN	3573311C1
F2%	B120S	16	LTGN	3573311C1
F2?^	B120S	18	LTGN	3534164C1
F3*#	B14C	14	RD	3573312C1
F3@	B53	16	GY	3573311C1
F3&	B14HL	14	RD	3573312C1
F3%*	B53J	16	YL	3573311C1
F3%	B53A	14	RD	3573312C1
F3?*	B14BA	14	RD	3573311C1
F3?+	B125M	16	GY	3573312C1
F3?*	B14BB	16	RD	3573311C1
F4*	B125HLA	18	GY	3534164C1
F4#%	B125EA	18	GY	3573312C1
F4#&	B125EB	18	GY	3573312C1
F4&#	B53G	18	RD	3534164C1
F4?+	B125L	16	GY	3573311C1
F4?+	B125M	16	GY	3573311C1
F4?*	B14AD	18	RD	3573312C1
F4?*	B14AC	18	RD	3573312C1
G1*	B120-GK	18	WH	3573312C1
G1*	B120-GL	18	WH	3573312C1
G1%	B120P	16	LTGN	3573312C1
G1&	B120AN	18	LTGN	3534164C1
G1?*	B117BA	18	GY	3534164C1
G2	B131A	16	DKBL	3573312C1
G3&#	B63-GAB	16	WH	3573311C1
G3&#	B63-GAC	14	WH	3573311C1
G3*#	B53C-G	18	WH	3534164C1
G3*#	B53-GHB	18	WH	3534164C1
G3%&	B125F	18	GY	3573312C1
G3%#	B125FA	18	GY	3573312C1
G3*#	B85ER	18	GY	3534164C1
G3?+	B125N	18	GY	3573312C1
G3?+	B125P	18	GY	3573312C1
G3?*	B53BA	18	GY	3573312C1
G3?*	B53BB	18	GY	3573312C1
G4&#	B63AG	16	DKBL	3515517C1
G4%&	B53H	16	YL	3515517C1
G4*#	B53F	16	YL	3573312C1
G4%&	B53F	16	YL	3515517C1
G4?%	B63RW	16	DKBL	3515517C1
G4?*	B53AB	16	YL	3515517C1
H1	B131B	16	DKBL	3573312C1
H2%&	B120KD	18	LTGN	3534164C1
H2&*	B120S	16	LTGN	3573311C1
H2*	B120K	18	LTGN	3573312C1
H2&	B120L	18	LTGN	3573312C1

24.29. CONNECTOR COMPOSITES @@10309, P. 14D
Figure 1211 CONNECTOR COMPOSITES @@10309

24.29. CONNECTOR COMPOSITES @@10309, P. 14D | Figure 1211 CONNECTOR COMPOSITES @@10309 | printed page 1211

Connector 10309: RELAY BLOCK 2 1 3 4

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
H2***	B120M	18	LTGN	3573312C1
H2***	B120W	18	LTGN	3573312C1
H2%	B120Z	16	LTGN	3573312C1
H2&*	B120S	18	LTGN	3573312C1
H2&&	B120K	16	LTGN	3573311C1
H2?	B12AB	18	LTBL	3534164C1
H3&#	B63AB	14	DKBL	3516158C1
H3###	B53G	14	YL	3516158C1
H3*#	B53C	16	YL	3573312C1
H3%%%	B53D	14	YL	3516158C1
H3??	B63X	16	DKBL	3515517C1
H3?	B53AA	14	YL	3516158C1
H4	-	-	-	-
J1	-	-	-	-
J2	-	-	-	-
J3###	B14FX	14	RD	3516158C1
J3&#	B63AK	18	DKBL	3515517C1
J3*#	B53J	16	YL	3573312C1
J3%%%	B14HR	14	RD	3516158C1
J3&&&	B53B	14	RD	3516158C1
J3?	B14BB	16	RD	3515517C1
J3??	B125K	16	GY	3515517C1
J4###	B125HRA	18	GY	3515517C1
J4&#	B63AJ	18	DKBL	3515517C1
J4*#	B125EB	18	GY	3534164C1
J4&&&	B53H	18	RD	3515517C1
J4??	B125J	16	GY	3536295C1
J4??	B125K	16	GY	3536295C1
J4?	B14AB	18	RD	3536295C1
J4?	B14AC	18	RD	3536295C1

24.30. CONNECTOR COMPOSITES @10310, P. 15
Figure 1212 CONNECTOR COMPOSITES @10310

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.30. CONNECTOR COMPOSITES @10310, P. 15 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090675 NO. RELEASE NO. 95504E 31MAY20 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 SEE CH 01_AE08090652 _028 FOR DETAILS. / FUSE BLOCK - B5 @(10310) (LOCATED IN ELECTRICAL PANEL HARNESS) / CONNECTOR 3768010C1 RELAY LOCK 3768011C1 RETAINER 4149060C1 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 87a 85 86 / 86 87a 85 / Figure 1212 / CONNECTOR COMPOSITES @10310

24.31. CONNECTOR COMPOSITES @@10310, P. 15A | Figure 1213 CONNECTOR COMPOSITES @@10310 | printed page 1213

Connector 10310: RELAY BLOCK 4 3 2 1

CIRCUIT	GA	COLOR	TERMINAL
B89GG	16	WH	3515517C1
B119B	18	GY	3515517C1
B119A	16	GY	3573312C1
B89HH	14	OR	3573312C1
B119C	18	GY	3573312C1
B117K	18	LTGN	3515517C1
B117-GL	18	WH	3515517C1
B119D	16	GY	3573312C1
B89RR	16	OR	3573312C1
B119C	18	GY	3515517C1
B89LRR	18	OR	3515517C1
B117L	18	GY	3515517C1
B117H	18	LTGN	3515517C1
B125PA	18	GY	3573312C1
B139-G	16	WH	3515517C1
B12-G	18	WH	3534164C1
B125P	18	GY	3573312C1
B139A	16	YL	3515517C1
B63T	16	LTBL	3573312C1
B12AB	18	LTBL	3534164C1
B171-GC	18	WH	3515517C1
B133D	18	LTGN	3515517C1
B133T	18	LTGN	3515517C1
B17	18	LTGN	3515517C1
B63D	16	DKBL	3573312C1
B139B	16	YL	3573312C1
B12AA	18	LTBL	3534164C1
B119T	16	GY	3573312C1
B120AL	16	LTGN	3573312C1
B12	18	LTBL	3573312C1
B12AA	18	LTBL	3573312C1
B17B	18	LTGN	3534164C1
B41-GC	18	WH	3515517C1
B89G	16	WH	3515517C1
B125M	16	GY	3515517C1
B120AC	16	LTGN	3515517C1
B125M	16	GY	3536295C1
B41H	18	TN	3515517C1
B131C	18	DKBL	3515517C1
B89H	14	OR	3516158C1
B125L	16	GY	3536295C1
B17C	18	PK	3515517C1
B17C	18	PK	3515517C1
B17C	18	LTGN	3515517C1
B17C	18	LTGN	3515517C1
B41D	18	TN	3573312C1
B41J	18	TN	3573312C1
B131D	18	DKBL	3534164C1
B89RA-M	16	OR	3573312C1
B41C	18	TN	3573312C1

24.32. CONNECTOR COMPOSITES @@10310, P. 15B | Figure 1214 CONNECTOR COMPOSITES @@10310 | printed page 1214

Connector 10310: CHART CONTINUED FROM SHEET 15A RELAY BLOCK 4 3 2 1

CIRCUIT	GA	COLOR	TERMINAL
B41J	18	TN	3573312C1
B131D	18	DKBL	3534164C1
B89RA-M	16	OR	3573312C1
B41C	18	TN	3573312C1
B41J	18	TN	3573312C1
B89RM	18	OR	3534164C1
B120-GG	18	WH	3534164C1
B120-GD	18	WH	3573312C1
B120-GA	18	WH	3515517C1
B134-G	16	WH	3515517C1
B134-G	16	WH	3515517C1
B120A	16	LTBL	3536295C1
B120B	16	LTBL	3536295C1
B120-GE	18	WH	3573312C1
B120AB	16	LTGN	3573312C1
B134	16	RD	3573312C1
B134	16	RD	3515517C1
B123C	18	LTGN	3515517C1
B123T	18	GY	3515517C1
B120-GG	18	WH	3536295C1
B133B	18	LTGN	3515517C1
B12Z	16	LTBL	3573312C1
B122C	18	GY	3534164C1
B120-GF	18	WH	3536295C1
B123P	18	LTGN	3515517C1
B120-GE	18	WH	3573312C1
B120-GF	18	WH	3573312C1
B133T	18	LTGN	3515517C1
B122T	18	GY	3534164C1
B123A	18	LTGN	3515517C1
B120AV	16	LTGN	3573312C1
B120AH	16	LTGN	3573312C1
B120B	18	LTGN	3515517C1
B134F	16	OR	3573311C1
B134R	16	OR	3573311C1
B134B	16	OR	3515517C1
B123RW	18	GY	3515517C1
B134B	16	OR	3573312C1
B134A	16	OR	3573312C1
B123C	18	LTGN	3536295C1
B133D	18	LTGN	3534164C1
B120JC	16	LTGN	3573312C1
B122TB	18	GY	3534164C1
B120-GH	16	WH	3515517C1
B123S	18	LTGN	3536295C1
B123S	18	LTGN	3515517C1
B122-GC	18	WH	3573312C1
B122-GB	18	WH	3573312C1
B120AF	16	LTGN	3573312C1
B120AE	18	LTGN	3536295C1

24.33. CONNECTOR COMPOSITES @@10310, P. 15C | Figure 1215 CONNECTOR COMPOSITES @@10310 | printed page 1215

Connector 10310: CHART CONTINUED FROM SHEET 15B RELAY BLOCK 4 3 2 1

CIRCUIT	GA	COLOR	TERMINAL
B133C	18	LTGN	3515517C1
B120-GJ	16	LTGN	3573312C1
B120AC	16	LTGN	3536295C1
B120AD	18	LTGN	3536295C1
B133U	18	LTGN	3515517C1
B123R	18	LTGN	3515517C1
B9T-G	16	GY	3573312C1

Connector 10310: CHART CONTINUED FROM SHEET 15B RELAY BLOCK 4 3 2 1

RELAY	LOCATION	DESCRIPTION
A1,A2,B1,B2		STOP ARM RELAY
C1,C2,D1,D2		PED LT RELAY
E1,E2,F1,F2		TEMP SENSOR RELAY
G1,G2,H1,H2,J1,J2		AED RELAY
A3,A4,B3,B4		BUZZER RELAY
C3,C4,D3,D4,E3,E4	STARTER	INTERLOCK RELAY
G3,G4,H3,H4,J3,J4	AED	VANDAL LOCK RELAY

Figure 1216 CONNECTOR COMPOSITES @@10311

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.34. CONNECTOR COMPOSITES @@10311, P. 16 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090675 NO. RELEASE NO. 95504E 31MAY20 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 SEE CH 01_AE08090652 _028 FOR DETAILS. / FUSE BLOCK - B2 @@(10311) (LOCATED IN ELECTRICAL PANEL HARNESS) / CONNECTOR 3768010C1 RELAY LOCK 3768011C1 RETAINER 4149060C1 / CHART CONTINUED ON / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / Figure 1216 / CONNECTOR COMPOSITES @@10311

Figure 1217 CONNECTOR COMPOSITES @@10311

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.35. CONNECTOR COMPOSITES @@10311, P. 17 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090675 NO. RELEASE NO. 95504E 31MAY20 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / SEE CH 01_AE08090652 _028 FOR DETAILS. / FUSE BLOCK - B2 @@(10311) (LOCATED IN ELECTRICAL PANEL HARNESS) / CONNECTOR 3768010C1 RELAY LOCK 3768011C1 RETAINER 4149060C1 / CHART CONTINUED ON / CHART CONTINUED ON / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / Figure 1217 / CONNECTOR COMPOSITES @@10311

Figure 1218 CONNECTOR COMPOSITES @@10311

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.36. CONNECTOR COMPOSITES @@10311, P. 18 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090675 NO. RELEASE NO. 95504E 31MAY20 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / SEE CH 01_AE08090652 _028 FOR DETAILS. / FUSE BLOCK - B2 @@(10311) (LOCATED IN ELECTRICAL PANEL HARNESS) / CONNECTOR 3768010C1 RELAY LOCK 3768011C1 RETAINER 4149060C1 / CHART CONTINUED ON / CHART CONTINUED FROM / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / Figure 1218 / CONNECTOR COMPOSITES @@10311

Figure 1219 CONNECTOR COMPOSITES @@10311

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.37. CONNECTOR COMPOSITES @@10311, P. 19 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090675 NO. RELEASE NO. 95504E 03MAR20 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / SEE CH 01_AE08090652 _028 FOR DETAILS. / FUSE BLOCK - B2 @@(10311) (LOCATED IN ELECTRICAL PANEL HARNESS) / CONNECTOR 3768010C1 RELAY LOCK 3768011C1 RETAINER 4149060C1 / CHART CONTINUED ON / CHART CONTINUED FROM / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / Figure 1219 / CONNECTOR COMPOSITES @@10311

Figure 1220 CONNECTOR COMPOSITES @@10311

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.38. CONNECTOR COMPOSITES @@10311, P. 20 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090675 NO. RELEASE NO. 95504E 03MAR20 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / SEE CH 01_AE08090652 _028 FOR DETAILS. / FUSE BLOCK - B2 @@(10311) (LOCATED IN ELECTRICAL PANEL HARNESS) / CHART CONTINUED FROM / CONNECTOR 3768010C1 RELAY LOCK 3768011C1 RETAINER 4149060C1 / 86 87a 85 / 87a 85 86 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / Figure 1220 / CONNECTOR COMPOSITES @@10311

24.39. CONNECTOR COMPOSITES @@@10311, P. 20A
Figure 1221 CONNECTOR COMPOSITES @@@10311

24.39. CONNECTOR COMPOSITES @@@10311, P. 20A | Figure 1221 CONNECTOR COMPOSITES @@@10311 | printed page 1221

Connector 10311: CAVITY A1? RELAY BLOCK 1 A1#@ A A2*^ A2#? A2?&

CIRCUIT	GA	COLOR	TERMINAL
B63A	18	DKBL	3573312C1
B117DA	16	DKBL	3573311C1
(B14M)	-	-	3534164C1
(B63N)	-	-	3536302C1
(B63M)	-	-	3536302C1
B63C	16	DKBL	3573312C1
B63-GF	16	WH	3573312C1
B63A	16	DKBL	3573311C1
(B63NA)	-	-	3536299C1
B63AB	18	DKBL	3534164C1
B63MJ	18	DKBL	3534164C1
B63MJ	18	DKBL	3536302C1
B63B	16	DKBL	3573311C1
B63NA	16	DKBL	3536299C1
B63E	16	DKBL	3536302C1
B63T	12	DKBL	3573311C1
B74-G	18	WH	3573312C1
B74F	18	LTGN	3573312C1
B74-G	18	WH	3534164C1
B74-GT	16	WH	3573312C1
B74-GB	18	WH	3573312C1
B74F	18	LTGN	3573312C1
B74-GC	18	WH	3534164C1
B74-GC	16	WH	3573312C1
B74-G	16	WH	3573311C1
B74-GA	16	WH	3573311C1
B74-G	18	WH	3573312C1
B74-GF	18	WH	3573312C1
B74-GC	16	WH	3573312C1
B74M	12	LTGN	3573311C1
B74H	12	LTGN	3573311C1
B74S	12	LTGN	3573311C1
B74M	12	LTGN	3573311C1
B74H	12	LTGN	3573311C1
B74M	12	LTGN	3573311C1
B74N	12	LTGN	3573311C1
B74M	16	LTGN	3573312C1
B74K	12	LTGN	3573311C1
B63UA	18	DKBL	3573312C1
B63Z	18	DKBL	3515517C1
B63U	18	DKBL	3573312C1
B63UA	18	DKBL	3573312C1
B63B	16	DKBL	3573312C1
B63D	16	WH	3573312C1
B63C	16	DKBL	3573312C1
B125P	18	GY	3534164C1
B11GC	16	WH	3573311C1
B63K	18	DKBL	3534164C1
B63D	12	DKBL	3573311C1
B63U	18	DKBL	3573312C1
B63U	18	DKBL	3515517C1
B11GB	16	WH	3573311C1
B63MJ	18	DKBL	3515517C1
B63V	18	DKBL	3515517C1
B63MJ	18	DKBL	3515517C1
B120KA	18	LTGN	3515517C1
B63C	16	DKBL	3515517C1
CHART CONTINUED			ON SHEET
BE,CE BUS NO.	MODELS,		SHEET

CIRCUIT	GA	COLOR	TERMINAL
B63-GM	18	WH	3534164C1
B63-GM	18	WH	3515517C1
B63-G	16	WH	3515517C1
B63-GE	14	WH	3516158C1
B63-G	18	WH	3515517C1
B11GA	16	WH	3573311C1
B11GB	16	WH	3573311C1
B63B	18	DKBL	3573312C1
B117D	16	GY	3573311C1
B11-GJ	16	WH	3515517C1
B125L	18	GY	3534164C1

24.40. CONNECTOR COMPOSITES @@@10311, P. 20B
Figure 1222 CONNECTOR COMPOSITES @@@10311

24.40. CONNECTOR COMPOSITES @@@10311, P. 20B | Figure 1222 CONNECTOR COMPOSITES @@@10311 | printed page 1222

Connector 10311: FROM SHEET 20A CAVITY B3%@ RELAY BLOCK 1 B3** A B3^* B3*@ B3*#

CIRCUIT	GA	COLOR	TERMINAL
B74D	12	LTGN	3573311C1
B74D	12	LTGN	3573311C1
B74F	12	LTGN	3573311C1
B74H	12	LTGN	3573311C1
B74D	12	LTGN	3573311C1
B74D	16	LTGN	3573312C1
B74H	12	LTGN	3573311C1
B63B	18	DKBL	3534164C1
B125P	18	GY	3573312C1
B125P	18	GY	3573312C1
B11-G	18	WH	3573312C1
B11-GA	18	WH	3573312C1
(B11-G)	-	-	3536302C1
(B11-G)	-	-	3536302C1
B11-GJ	16	WH	3536302C1
B11-G	18	WH	3536300C1
B11-G	16	WH	3536300C1
B63B	18	DKBL	3534164C1
B63J	16	DKBL	3573312C1
B125LA	18	GY	3573312C1
B125LA	18	GY	3573312C1
B125-GK	18	WH	3573312C1
B125-GL	18	WH	3573312C1
B63GA	18	WH	3536300C1
B11-G	18	WH	3573312C1
B11-GA	18	WH	3573312C1
B63MA	16	DKBL	3573311C1
B63MB	16	DKBL	3573311C1
B125DMA	18	GY	3534164C1
B63A	16	DKBL	3573312C1
B125N	18	GY	3573312C1
B125N	18	GY	3573312C1
B63-G	16	WH	3573312C1
B125L	18	GY	3573312C1
B125L	18	GY	3573312C1
B14G	14	RD	3573312C1
B125L	16	GY	3573311C1
B63N	16	DKBL	3536300C1
B63N	16	DKBL	3536302C1
B63M	16	DKBL	3536302C1
B63M	16	DKBL	3536300C1
B63A	16	DKBL	3573312C1
B14G	14	RD	3573312C1
(B125N)	-	-	3536299C1
(B63NA)	-	-	3536299C1
(B63E)	-	-	3536302C1
B63M	16	DKBL	3573311C1
B14DMC	14	RD	3573312C1
B63J	14	RD	3573312C1
B125K	16	GY	3573311C1
B125L	16	GY	3573311C1
B125K	16	GY	3573311C1
B63WB	16	DKBL	3573312C1
B63R	14	DKBL	3573312C1
B125N	16	GY	3536299C1
B63NB	16	DKBL	3536299C1
B63N	16	DKBL	3573311C1
CHART CONTINUED			ON SHEET
BE,CE BUS NO.	MODELS,		SHEET

Table: ACTIVATED DOME W/REAR ROW

CIRCUIT	GA	COLOR	TERMINAL
B63B	16	DKBL	3515517C1
B63N	16	DKBL	3573311C1
B63NA	16	DKBL	3573311C1
B131AB	18	DKBL	3536295C1
B131AC	16	DKBL	3536295C1
B63D	16	DKBL	3573311C1
B63E	16	DKBL	3573311C1
B74D	12	LTGN	3573311C1
		REV	REFERENCE
		A	96183U

24.41. CONNECTOR COMPOSITES @@@10311, P. 20C
Figure 1223 CONNECTOR COMPOSITES @@@10311

24.41. CONNECTOR COMPOSITES @@@10311, P. 20C | Figure 1223 CONNECTOR COMPOSITES @@@10311 | printed page 1223

Connector 10311: FROM SHEET 20B CAVITY C3*@ RELAY BLOCK 1 C3*# A C3^ C3%@ C3**

CIRCUIT	GA	COLOR	TERMINAL
B74	14	LTGN	3573311C1
B74B	16	RD	3573311C1
B74B	14	LTGN	3573311C1
B74K	16	LTGN	3573311C1
B74C	16	LTGN	3573311C1
B74K	16	LTGN	3573311C1
B74C	16	LTGN	3573311C1
B74K	16	LTGN	3573311C1
B74K	16	RD	3573311C1
B74C	16	LTGN	3573311C1
B74T	16	LTGN	3573312C1
B74H	16	LTGN	3573311C1
B74M	18	LTGN	3534164C1
B74H	16	LTGN	3573311C1
B74J	16	LTGN	3573311C1
B74E	16	LTGN	3573311C1
B74F	16	LTGN	3573311C1
B74J	16	LTGN	3573311C1
B74D	16	LTGN	3573312C1
B74J	16	LTGN	3573312C1
B74H	18	LTGN	3573312C1
B74J	18	LTGN	3573312C1
B74D	16	LTGN	3573312C1
B63WA	16	DKBL	3573312C1
B63P	14	DKBL	3573312C1
B63WA	16	DKBL	3573311C1
B117DA	16	DKBL	3573312C1
B63D	14	DKBL	3573312C1
B63S	16	DKBL	3573312C1
B63S	16	DKBL	3573312C1
B63B	16	DKBL	3573312C1
B63D	14	DKBL	3573312C1
B63S	16	DKBL	3573312C1
B63S	16	LTBL	3573312C1
B63S	16	DKBL	3573312C1
B63WB	16	DKBL	3573311C1
B63C	14	DKBL	3573312C1
B63C	16	DKBL	3573312C1
B14DA	18	RD	3534164C1
B125J	16	GY	3573311C1
B125K	16	GY	3573311C1
B125J	16	GY	3573311C1
B125K	16	GY	3573311C1
B120A	18	LTGN	3573312C1
B63C	16	DKBL	3573312C1
B63U	18	DKBL	3573312C1
B14DA	18	RD	3534164C1
B125M	16	GY	3573311C1
B125N	16	GY	3573311C1
B120A	18	LTGN	3573312C1
B14DMA	18	RD	3534164C1
B63F	14	RD	3573312C1
B63U	18	DKBL	3515517C1
B63U	18	DKBL	3573312C1
B63V	18	DKBL	3573312C1
B63U	18	DKBL	3573312C1
B63P	18	DKBL	3573312C1
CHART CONTINUED			ON SHEET
BE,CE BUS NO.	MODELS,		SHEET

CIRCUIT	GA	COLOR	TERMINAL
B63MB	16	DKBL	3573311C1
B63MC	16	DKBL	3573311C1
B74B	14	LTGN	3573311C1
B74B	14	LTGN	3573311C1
B74R	12	LTGN	3573311C1
B74B	14	LTGN	3573311C1
B74	12	RD	3573311C1
B74B	14	LTGN	3573311C1

24.42. CONNECTOR COMPOSITES @@@10311, P. 20D
Figure 1224 CONNECTOR COMPOSITES @@@10311

24.42. CONNECTOR COMPOSITES @@@10311, P. 20D | Figure 1224 CONNECTOR COMPOSITES @@@10311 | printed page 1224

Connector 10311: FROM SHEET 20C CAVITY D3^ RELAY BLOCK 1 D3** A D3*@ D3*# D3#

CIRCUIT	GA	COLOR	TERMINAL
B74F	18	LTGN	3515517C1
B74F	18	LTGN	3515517C1
B74-GC	16	WH	3516158C1
B74-GA	16	WH	3515517C1
B74-GF	18	WH	3515517C1
B74-GC	16	WH	3516158C1
B9S	18	GY	3534164C1
B74P	16	LTGN	3573312C1
B74P	16	LTGN	3573312C1
B74J	16	LTGN	3573312C1
B74P	16	LTGN	3573312C1
B74P	16	LTGN	3573312C1
B74J	16	LTGN	3573312C1
B63C	18	DKBL	3534164C1
B14M	16	RD	3573312C1
(B11-G)	-	-	3536302C1
(B11-G)	-	-	3536302C1
(B11-G)	-	-	3536300C1
(B11-G)	-	-	3536300C1
B63C	18	DKBL	3534164C1
B117	18	GY	3573312C1
(B63GA)	-	-	3536300C1
B63Z	16	DKBL	3573312C1
B125DMB	18	GY	3534164C1
B63B	16	DKBL	3573312C1
B125P	18	GY	3534164C1
B63N	16	DKBL	3573312C1
B125LA	18	GY	3534164C1
B125LA	18	GY	3573312C1
B125-GK	18	WH	3534164C1
B11-GA	18	WH	3534164C1
B14E	14	RD	3573312C1
B63U	18	DKBL	3573312C1
(B63N)	-	-	3536300C1
(B63N)	-	-	3536302C1
(B63M)	-	-	3536302C1
(B63M)	-	-	3536300C1
B14E	14	RD	3573312C1
B63M	16	DKBL	3573311C1
B63N	16	DKBL	3573311C1
(B125N)	-	-	3536299C1
B63NB	16	DKBL	3573312C1
(B63E)	-	-	3536302C1
B63N	16	DKBL	3573312C1
B14DMB	14	RD	3573312C1
B63G	14	RD	3573312C1
B63T	16	LTBL	3573312C1
B63P	18	DKBL	3573312C1
B125NB	16	GY	3536299C1
B74E	16	LTGN	3573312C1
B74E	16	LTGN	3573312C1
B74F	14	LTGN	3573312C1
B74E	14	LTGN	3573312C1
B74E	14	LTGN	3573312C1
B74F	14	LTGN	3573312C1
B9T	18	GY	3534164C1
B63M	16	DKBL	3573311C1
CHART CONTINUED			ON SHEET
BE,CE BUS NO.	MODELS,		SHEET

Table: PREWIRE

CIRCUIT	GA	COLOR	TERMINAL
B63P	18	DKBL	3573312C1
B63U	18	DKBL	3573312C1
B125P	18	GY	3573312C1
B125PA	18	GY	3573312C1
B63K	18	DKBL	3536300C1
B63U	18	DKBL	3573312C1
B63RW	16	DKBL	3573312C1
B74-GB	14	WH	3516158C1
B11-GA	18	WH	3515517C1
B74-GB	14	WH	3516158C1
CHANGE		REV	REFERENCE
		A	96183U

24.43. CONNECTOR COMPOSITES @@@10311, P. 20E | Figure 1225 CONNECTOR COMPOSITES @@@10311 | printed page 1225

Connector 10311: FROM SHEET 20D CAVITY 1 F1@ RELAY BLOCK F1* F2## F2## F2#&

CIRCUIT	GA	COLOR	TERMINAL
B63D	14	DKBL	3573312C1
B63D	16	DKBL	3573312C1
B14FA	18	RD	3534164C1
B125L	16	GY	3573311C1
B125M	16	GY	3573311C1
B63P	16	DKBL	3573312C1
B63U	18	DKBL	3573312C1
B63P	16	DKBL	3573312C1
B63U	18	DKBL	3573312C1
B63U	18	DKBL	3515517C1
B63P	18	DKBL	3515517C1
B63P	18	DKBL	3515517C1
B14FA	18	RD	3534164C1
B125NB	16	GY	3573312C1
B125PA	18	GY	3573312C1
B125R	18	GY	3573312C1
B63H	18	DKBL	3536300C1
(B63K)	-	-	3536300C1
B63U	18	DKBL	3534164C1
B63MC	16	DKBL	3573312C1
B14DMD	18	RD	3534164C1
B63H	14	RD	3573312C1
B63T	16	DKBL	3573312C1
B74K	16	LTGN	3573311C1
B74K	16	LTGN	3573311C1
B74L	16	LTGN	3573311C1
B74C	16	LTGN	3573311C1
B74K	16	LTGN	3573311C1
B74K	16	RD	3573311C1
B74C	16	LTGN	3573311C1
B74L	16	LTGN	3573311C1
B74K	16	LTGN	3573311C1
B74L	16	LTGN	3573311C1
B74L	16	RD	3573311C1
B74M	16	LTGN	3573311C1
B74J	16	LTGN	3573312C1
B74J	16	LTGN	3573312C1
B74D	16	LTGN	3573311C1
B74J	16	LTGN	3573311C1
B120A	18	LTGN	3534164C1
B74J	18	LTGN	3534164C1
B74D	16	LTGN	3573311C1
B74E	16	LTGN	3573311C1
B74M	16	LTGN	3573311C1
B74E	16	LTGN	3573311C1
B63D	12	DKBL	3573311C1
B11-G	16	WH	3536302C1
B11-G	16	WH	3536302C1
B63-G	14	WH	3573312C1
B63H	16	WH	3573311C1
B122DA	18	GY	3534164C1
B63J	16	DKBL	3573311C1
B63AA	18	DKBL	3573312C1
B63AB	18	DKBL	3573312C1
B122DD	18	GY	3534164C1
B12B	16	LTBL	3573312C1
B63A	14	DKBL	3573312C1
CHART CONTINUED			ON SHEET
BE,CE BUS	MODELS,		
NO.			SHEET

CIRCUIT	GA	COLOR	TERMINAL
B63E	14	DKBL	3573312C1
B125M	16	GY	3573312C1
B11-GA	18	WH	3534164C1
B63T	16	DKBL	3573312C1
B63T	16	DKBL	3573312C1
B63T	16	DKBL	3573312C1
B63E	14	DKBL	3573312C1
B63T	16	DKBL	3573312C1
B63T	16	DKBL	3573312C1
B63MA	16	DKBL	3573311C1
CHANGE		REV	REFERENCE
		A	96183U

24.44. CONNECTOR COMPOSITES @@@10311, P. 20F
Figure 1226 CONNECTOR COMPOSITES @@@10311

Connector 10311: FROM SHEET 20E CAVITY G2?* RELAY BLOCK G2%* 1 A G3%! G3#^ G4@+

CIRCUIT	GA	COLOR	TERMINAL
B63AB	16	DKBL	3573312C1
B63RW	16	DKBL	3573312C1
B63RW	16	DKBL	3573312C1
B123K	18	GY	3515517C1
B123-GL	18	WH	3515517C1
B123B	18	LTGN	3515517C1
B9T	18	GY	3515517C1
B9S	18	GY	3515517C1
B9C	18	GY	3515517C1
B122DC	18	GY	3515517C1
(B14M)	-	-	3536302C1
B12A	18	LTBL	3515517C1
B63E	16	DKBL	3536295C1
B63F	16	DKBL	3536295C1
B63	14	DKBL	3516158C1
B63RR	14	DKBL	3516158C1
B63RR	16	DKBL	3515517C1
B14DB	18	RD	3534164C1
B63P	18	DKBL	3534164C1
B63AA	16	DKBL	3573311C1
B63AB	16	DKBL	3573311C1
B123A	18	LTGN	3515517C1
B123T	18	GY	3536295C1
B123W	18	GY	3536295C1
B123S	18	GY	3515517C1
B9X	18	GY	3515517C1
B14	14	RD	3573311C1
B14A	18	RD	3573311C1
B63K	16	DKBL	3573312C1
B13A	18	PK	3515517C1
B14A	18	RD	3515517C1
B63K	16	DKBL	3536295C1
B63L	16	DKBL	3536295C1
B123K	18	LTGN	3515517C1
B123L	18	LTGN	3536295C1
B123R	18	LTGN	3536295C1
B13H	18	PK	3515517C1

RELAY	LOCATION	DESCRIPTION
A1,A2,B1,B2	REAR	ROW DOME LT RELAY
C1,C2,D1,D2		REAR DOME LT RELAY
E1,E2,F1,F2		FRONT DOME LT RELAY
G1,G2,H1,H2,J1,J2		2 MIN TIMER RELAY
A3,A4,B3,B4,C3,C4		BOOSTER PUMP RELAY
D3,D4,E3,E4,F3,F4		BOOSTER PUMP RELAY
G3,G4,H3,H4,J3,J4	FLASHER	SYSTEM RELAY
G3,G4,H3,H4,J3,J4	CHANGE	REV REFERENCE DRAWN
INITIAL	PRODUCTION	A 96183U
INITIAL		RELEASE NO.

24.45. CONNECTOR COMPOSITES @@10312, P. 21
Figure 1227 CONNECTOR COMPOSITES @@10312

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.45. CONNECTOR COMPOSITES @@10312, P. 21 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090675 NO. RELEASE NO. 95504E 04MAR20 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / SEE CH 01_AE08090652 _028 FOR DETAILS. / FUSE BLOCK - B4 @@(10312) (LOCATED IN ELECTRICAL PANEL HARNESS) / CHART CONTINUED ON / CONNECTOR 3768010C1 RELAY LOCK 3768011C1 RETAINER 4149060C1 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / Figure 1227 / CONNECTOR COMPOSITES @@10312

Figure 1228 CONNECTOR COMPOSITES @@10312

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.46. CONNECTOR COMPOSITES @@10312, P. 22 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090675 NO. 95504E 04MAR20 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / SEE CH 01_AE08090652 _028 FOR DETAILS. / FUSE BLOCK - B4 @@(10312) (LOCATED IN ELECTRICAL PANEL HARNESS) / CHART CONTINUED FROM / CONNECTOR 3768010C1 RELAY LOCK 3768011C1 RETAINER 4149060C1 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / Figure 1228 / CONNECTOR COMPOSITES @@10312

24.47. CONNECTOR COMPOSITES @@10312, P. 22A | Figure 1229 CONNECTOR COMPOSITES @@10312 | printed page 1229

Connector 10312: RELAY BLOCK 4 3 2 1

CIRCUIT	GA	COLOR	TERMINAL
B122D	18	WH	3515517C1
B122F	16	GY	3573312C1
B122H	18	GY	3573312C1
B122F	16	GY	3573312C1
B122J	18	GY	3515517C1
B44C	18	GY	3515517C1
B122H	18	GY	3515517C1
B122V	16	GY	3573311C1
B122V	16	GY	3573311C1
B122V	16	GY	3573311C1
B122N	16	GY	3573311C1
B122N	16	BN	3573312C1
B122N	16	BN	3573312C1
B122N	16	GY	3573311C1
B122N	16	GY	3573311C1
B122E	16	GY	3573311C1
B122F	16	GY	3573311C1
B122E	16	GY	3573311C1
B122F	16	GY	3573311C1
B122L	18	GY	3573312C1
B122M	18	GY	3573312C1
B122M	18	GY	3515517C1
B122L	18	GY	3573312C1
B122M	18	GY	3573312C1
B122M	18	GY	3534164C1
B13	18	PK	3534164C1
B122-G	18	WH	3534164C1
B13A	18	PK	3515517C1
B13A	18	PK	3534164C1
B123-GK	18	WH	3515517C1
B123L	18	GY	3515517C1
B123K	18	LTGN	3536295C1
B123M	18	LTGN	3536295C1
B123F	18	GY	3515517C1
B122-G	18	WH	3534164C1
B122-G	18	WH	3573312C1
B13A	18	PK	3573312C1
B44C	18	GY	3573312C1
B44B	18	GY	3573312C1
B44C	18	GY	3515517C1
B123-GL	18	WH	3515517C1
B123R	18	GY	3534164C1
B120WA	18	LTGN	3534164C1
B122L	18	GY	3515517C1
B122L	18	GY	3534164C1
-	-	-	-
B123P	18	LTGN	3515517C1
B123N	18	LTGN	3515517C1
-	-	-	-
B13	18	PK	3573312C1
B13A	18	PK	3573312C1
B13	18	PK	3534164C1
B130	18	GY	3515517C1
B130	18	GY	3515517C1
B130	18	GY	3515517C1
B118-GA	14	WH	3516158C1
B130A	18	GY	3515517C1
CONTINUED		ON	SHEET
BE,CE BUS	MODELS,		
NO.			SHEET

24.48. CONNECTOR COMPOSITES @@10312, P. 22B
Figure 1230 CONNECTOR COMPOSITES @@10312

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.48. CONNECTOR COMPOSITES @@10312, P. 22B / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, RELEASE NO. PART AE08090675 NO. 96183U 29JUL21 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / RELAY BLOCK @@(10312) (LOCATED AT FLASHER PLATE) / CONNECTOR 3534572C1 BODY LOCK 3536085C1 BODY LOCK 3599541C1 / 1 A / CHART CONTINUED FROM / Figure 1230 / CONNECTOR COMPOSITES @@10312

RELAY	LOCATION	DESCRIPTION
A1,A2,B1,B2		LIFT LT RELAY
C1,C2,D1,D2,E1,E2		FLASHER SYSTEM RELAY
F1,F2,G1,G2.H1,H2,	J1,J2	STEP WARMER RELAY
A3,A4,B3,B4		LIFT INTERLOCK RELAY
C3,C4,D3,D4,E3,E4		LIFT INTERLOCK RELAY
F3,F4,G3,G4,H3,H4,J3,J4		STEP WARMER RELAY

24.49. CONNECTOR COMPOSITES @@10313, P. 23
Figure 1231 CONNECTOR COMPOSITES @@10313

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.49. CONNECTOR COMPOSITES @@10313, P. 23 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090675 NO. 95504E 04MAR20 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / SEE CH 01_AE08090652 _028 FOR DETAILS. / FUSE BLOCK - B1 @@(10313) (LOCATED IN ELECTRICAL PANEL HARNESS) / CHART CONTINUED ON / 86 87a 85 / 86 87a 85 / 87a 85 86 / 86 87a 85 / 86 87a 85 / 86 87a 85 / Figure 1231 / CONNECTOR COMPOSITES @@10313

Connector 10313: FUSE BLOCK - B1

CAV	CIRCUIT	GA	COLOR	TERMINAL
R1-30	B119L	16	GY	3768007C1
R1-85	B119-G	16	WH	3768004C1
R1-86	B119S	16	GY	3768004C1
R1-87	B119C	16	GY	3768007C1
R2-30	B17	18	LTGN	3768007C1

Legend: R2-85* B133D 18 LTGN 3768003C1 ; R2-85& B133T 18 LTGN 3768003C1 ; R2-86& B17C 18 LTGN 3768003C1 ; R2-86* B17C 18 LTGN 3768003C1 ; R2-87A B17B 18 LTGN 3768003C1 ; R3-30^ B12BJ 16 LTBL 3768007C1 ; R3-30% B122DD 18 GY 3768007C1 ; R3-30# B63AT 14 DKBL 3768008C1 ; R3-30! B63AB 16 DKBL 3768007C1

Figure 1232 CONNECTOR COMPOSITES @@10313

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.50. CONNECTOR COMPOSITES @@10313, P. 24 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090675 NO. 95504E 04MAR20 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / SEE CH 01_AE08090652 _028 FOR DETAILS. / CHART CONTINUED FROM / FUSE BLOCK - B1 @@(10313) (LOCATED IN ELECTRICAL PANEL HARNESS) / CONNECTOR 3768010C1 RELAY LOCK3768011C1 RETAINER 4149060C1 / 86 87a 85 / 86 87a 85 / 87a 86 85 / 86 87a 85 / 86 87a 85 / 86 87a 85 / Figure 1232 / CONNECTOR COMPOSITES @@10313

24.51. CONNECTOR COMPOSITES @10314, P. 24A
Figure 1233 CONNECTOR COMPOSITES @10314

24.51. CONNECTOR COMPOSITES @10314, P. 24A | Figure 1233 CONNECTOR COMPOSITES @10314 | printed page 1233

Connector 10314: NS1

CIRCUIT	GA	COLOR	TERMINAL
B14NS1	8	BK	2230259C1
B11-GAD	18	WH	3535326C1
B11-GAE	18	WH	3535326C1
B118L	18	LTBL	3535326C1
B12S	18	LTBL	3535326C1
B118LA	18	LTBL	3535326C1
B118M	18	LTBL	3535326C1
B12T	18	LTBL	3535326C1
B118A	10	BK	2230259C1
B118B	14	BK	2230259C1

24.52. CONNECTOR COMPOSITES @10315, P. 25
Figure 1234 CONNECTOR COMPOSITES @10315

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.52. CONNECTOR COMPOSITES @10315, P. 25 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090675 NO. 95504E 04MAR20 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED FUSE DETAILS & REMOVED R/D 10314. / * W/NOISE SUPPRESSION W/LOW VOLTAGE MODULE # W/SW MASTER DISC N/NOISE SUPPRESSION SW @ W/0508108 - MTA FUSE BLOCK / FUSE BLOCK - B7 @(10315) (LOCATED IN PLATFORM HARNESS) / CONNECTOR 4100070C1 BODY LOCK 4100116C1 / FUSE BLOCK - B4 @(10316) (LOCATED IN PLATFORM HARNESS) / CONNECTOR 4100070C1 BODY LOCK 4100116C1 / Figure 1234 / CONNECTOR COMPOSITES @10315

Connector 10315: FUSE BLOCK - B7 R1-85% R1-85! R1-86*

CAV	CIRCUIT	GA	COLOR	TERMINAL
R1-30	B14NS3	8	BK	4100163C1

Legend: R1-85% B11-GAF 18 WH 3768007C1 ; R1-85! B11-GADG 18 WH 3768007C1 ; R1-86* B118N 18 LTBL 3768007C1 ; R1-86# B12U 18 LTBL 3768007C1 ; R1-87% B118DE 12 BK 4185895C1 ; R1-87! B118AR 12 BK 4185895C1 ; R2-30 B14NS4 8 BK 4100163C1 ; R2-85 B11-GAG 16 WH 3768007C1 ; R2-85! B11-GADJ 16 WH 3768007C1

Connector 10316: FUSE BLOCK - B4 CAV R1-30

CAV	CIRCUIT	GA	COLOR	TERMINAL
R1-30	B14MD1	8	BK	4100163C1
R1-85	B11-GADA	16	WH	3768007C1

Legend: R1-86* B12T 16 LTBL 3768007C1 ; R1-86# B12M 16 LTBL 3768007C1 ; R1-87 B12ABG 12 BK 4185895C1 ; R2-30 B14MD2 8 BK 4100163C1 ; R2-85 B11-GAB 18 WH 3768007C1 ; R2-86 B12P 18 LTBL 3768007C1 ; R2-87 B12CD 12 BK 4185895C1

24.53. CONNECTOR COMPOSITES @10316, @10317, P. 26 | Figure 1235 CONNECTOR COMPOSITES @10316, @10317 | printed page 1235

Connector 10316: NS3 87

CAV	CIRCUIT	GA	COLOR	TERMINAL
30	B14NS3	8	BK	2230259C1
85	B11-GAF	18	WH	3535326C1
85	B11-GAG	16	WH	3535326C1
86%	B118N	18	LTBL	3535326C1
86#	B12U	18	LTBL	3535326C1
86%	B118P	16	BK	3535326C1
86#	B12V	16	LTBL	3535326C1
87*	B118D	12	BK	2230299C1
87*	B118E	14	BK	2230299C1

Legend: @ N/0508108 - NOT MTA FUSE BLOCK ; * W/NOISE SUPPRESSION CIRCUITS ; % W/NOISE SUPPRESSION IGN ACTIVATED ; # W/MASTER DISCONNECT SW N/NOISE SUPPRESSION

Connector 10317: CONNECTOR 3534579C1 BODY LOCK 2230260C1 FUSE BLOCK - B7

CAV	CIRCUIT	GA	COLOR	TERMINAL
R1-30	B14MD3	8	BK	4100163C1
R1-85	B11-GAC	16	WH	3768007C1
R1-86	B12R	16	LTBL	3768007C1
R1-87	B12EF	10	BK	4185895C1
R2-30	B14IGN	8	BK	4100163C1
R2-85	B11-GAR	16	WH	3768007C1
R2-86	B13AB	16	PK	3768007C1
R2-87	B13DE	12	BK	4185895C1

Connector 10317: BODY LOCK 4100116C1 NS4 87

CAV	CIRCUIT	GA	COLOR	TERMINAL
30	B14NS4	8	BK	2230259C1
85	B11-GAG	16	WH	3535326C1
86#	B118P	16	BK	3535326C1
86%	B12V	16	LTBL	3535326C1
87*	B118F	12	BK	2230259C1
87*	B118K	10	BK	2230259C1

24.54. CONNECTOR COMPOSITES @10318, @10319, P. 27 | Figure 1236 CONNECTOR COMPOSITES @10318, @10319 | printed page 1236

Connector 10318:

CAV	CIRCUIT	GA	COLOR	TERMINAL
R1-30	B14AC1	8	BK	4100163C1
R1-85	B11-GAJ	18	WH	3768007C1
R1-86	B13BC	16	PK	3768007C1
R1-87	B12HL	10	BK	4185895C1
R2-30	B14AC2	8	BK	4100163C1
R2-85	B11-GAK	16	WH	3768007C1
R2-86	B13C	16	PK	3768007C1
R2-87	B12KM	10	BK	4185895C1

Connector 10318: MD1 87

CAV	CIRCUIT	GA	COLOR	TERMINAL
30	B14MD1	8	BK	2230259C1
85*	B11-GAA	18	WH	3535326C1
85*	B11-GAB	18	WH	3535326C1
86%	B12N	18	LTBL	3535326C1
86%	B12P	18	LTBL	3535326C1
87*	B12A	12	BK	2230299C1
87*	B12B	14	BK	2230299C1

Connector 10319: BODY LOCK 2230260C1 MD2 87

CAV	CIRCUIT	GA	COLOR	TERMINAL
30*	B14MD2	8	BK	2230259C1
85*	B11-GAB	18	WH	3535326C1
85*	B11-GAC	16	WH	3535326C1
86%	B12P	18	LT BL	3535326C1
86%	B12R	16	LT BL	3535326C1
87*	B12C	12	BK	2230299C1
87*	B12D	14	BK	2230299C1

Legend: @ N/0508108 - NOT MTA FUSE BLOCK ; * W/POWER CABLE W/MASTER DISC & ; W/NOISE SUPPRESSION ; % W/MASTER DISCONNECT IGN ACTIVATED

24.55. CONNECTOR COMPOSITES @10320, @10321, @10322, P. 27A
Figure 1237 CONNECTOR COMPOSITES @10320, @10321, @10322

24.55. CONNECTOR COMPOSITES @10320, @10321, @10322, P. 27A | Figure 1237 CONNECTOR COMPOSITES @10320, @10321, @10322 | printed page 1237

Connector 10320:

CAV	GAUGE	COLOR	TERMINAL
30 B14MD3	8	BK	2230259C1
85 B11-GAC	16	WH	3535326C1
86 B12R	16	LTBL	3535326C1
87* B12E	12	BK	2230259C1
87* B12F	10	BK	2230259C1

Connector 10321: IGN1 87

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
30	B14IGN	8	BK	2230259C1
85*	B11-GAH	18	WH	3535326C1
85*	B11-GAJ	18	WH	3535326C1
86*	B13A	16	PK	3535326C1
87*	B13D	12	BK	2230259C1
87*	B13E	12	BK	2230259C1

Connector 10322: ACC1 87

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
30	B14AC1	8	BK	2230259C1
85*	B11-GAJ	18	WH	3535326C1
85*	B11-GAK	16	WH	3535326C1
86*	B13B	18	PK	3535326C1
86*	B13C	16	PK	3535326C1
87*	B12H	10	BK	2230259C1
87*	B12L	14	BK	2230259C1

Legend: * W/COMMON EFFECTS ; # N/0508108 - NOT MTA FUSE BLOCK

24.56. CONNECTOR COMPOSITES @10323, @10324, @10325, P. 27B
Figure 1238 CONNECTOR COMPOSITES @10323, @10324, @10325

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.56. CONNECTOR COMPOSITES @10323, @10324, @10325, P. 27B / CHAPTER 24 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, PART AE08090675 NO. RELEASE NO. 96183U 09AUG21 / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / CONNECTOR 2206658C1 / ACC2 #(10323) (LOCATED AT FLASHER PLATE) / CONNECTOR 3534579C1 BODY LOCK 2230260C1 / BUS SCAN PILOT LT (+) #(10324) (LOCATED NEAR DRIVER CONTROL PANEL) / BUS SCAN PILOT LT (-) #(10325) (LOCATED NEAR DRIVER CONTROL PANEL) / CONNECTOR 2206658C1 / * W/COMMON EFFECTS # N/0508108 - NOT MTA FUSE BLOCK / # N/0508108 - NOT MTA FUSE BLOCK / # N/0508108 - NOT MTA FUSE BLOCK / CAV CIRCUIT GAUGE COLOR TERMINAL A B125F 16 GY 0239805R1 / CAV CIRCUIT GAUGE COLOR TERMINAL 30 B14AC2 8 BK 2230259C1 85 B11-GAK 16 WH 3535326C1 86 B13C 16 PK 3535326C1 87* B12K 10 BK 2230259C1 87* B12M 14 BK 2230259C1 / CAV CIRCUIT GAUGE COLOR TERMINAL A B125-GB 16 WH 0239805R1 / Figure 1238 / CONNECTOR COMPOSITES @10323, @10324, @10325

Connector 10323: 87

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
30	B14AC2	8	BK	2230259C1
85	B11-GAK	16	WH	3535326C1
86	B13C	16	PK	3535326C1
87*	B12K	10	BK	2230259C1
87*	B12M	14	BK	2230259C1

Legend: * W/COMMON EFFECTS ; # N/0508108 - NOT MTA FUSE BLOCK

Connector 10324: BUS SCAN PILOT LT (+) CONTROL PANEL)

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	B125F	16	GY	0239805R1

Connector 10325: BUS SCAN PILOT LT (-) CONTROL PANEL)

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	B125-GB	16	WH	0239805R1

24.57. CONNECTOR COMPOSITES @10327, @10328, %10329, P. 28 | Figure 1239 CONNECTOR COMPOSITES @10327, @10328, %10329 | printed page 1239

Connector 10327: SW ILLUM A ML C KJ D B C D

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B62AY	18	DKBL	3534164C1
B	B62A	18	DKBL	3534164C1
C	B62B	18	DKBL	3534164C1
D	B62H	18	DKBL	3534164C1
E!	B62ADB	18	DKBL	3534164C1
E#	B62D	18	DKBL	3534164C1
F	B62E	18	DKBL	3534164C1
G	B62-GE	18	WH	3534164C1
H!	B62-GDA	18	WH	3534164C1
H#	B62-GD	18	WH	3534164C1
J	B62-GH	18	WH	3534164C1
K	B62-GB	18	WH	3534164C1
L	B62-GA	18	WH	3534164C1
M	B62-GAY	18	WH	3534164C1

Connector 10328: SW ILLUM A ML

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B62AZ	18	DKBL	3534164C1
B	B62J	18	DKBL	3534164C1
C	B62U	18	DKBL	3534164C1
D	B62BP	18	DKBL	3534164C1
E	B62X	18	DKBL	3534164C1
F	-	-	-	-
G	-	-	-	-
H	B62-GX	18	WH	3534164C1
J	B62-GBP	18	WH	3534164C1
K	B62-GU	18	WH	3534164C1
L	B62-GJ	18	WH	3534164C1
M	B62-GAZ	18	WH	3534164C1

Legend: FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10329: BODY LOCK 3700749C1 @ AND SW ILLUM PANEL) A ML

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B62BA	18	DKBL	3534164C1
B	B62Y	18	DKBL	3534164C1
C	B62Z	18	DKBL	3534164C1
D@	B62AB	18	DKBL	3534164C1
D%%	B62AC	18	DKBL	3534164C1
D!	B62-BG	18	DKBL	3534164C1
D*	B62AC	16	LTGN	3534165C1
D#	B62ACC	18	DKBL	3534164C1
E#	B62ACB	18	DKBL	3534164C1
E!!	B62AC	18	DKBL	3534164C1
F	B62AD	18	DKBL	3534164C1
G#	B62-GD	18	WH	3534164C1
G#	B62-GDB	18	WH	3534164C1
G#	B62-GDC	18	WH	3534164C1
G!!	B62-GAD	18	WH	3534164C1
H!!	B62-GAC	18	WH	3534164C1
H#	B62-GAP	18	WH	3534164C1
K!!	B62-GAA	18	DKBL	3534164C1
J	B62-GAB	18	WH	3534164C1
K%	B62-GZ	18	WH	3534164C1
L	B62-GY	18	WH	3534164C1
M	B62-GBA	18	WH	3534164C1

24.58. CONNECTOR COMPOSITES @10330, @10331, P. 29 | Figure 1240 CONNECTOR COMPOSITES @10330, @10331 | printed page 1240

Connector 10330: SW ILLUM A ML

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B62BB	18	DKBL	3534164C1
B^	B62AJ	18	DKBL	3534164C1
B!	B62AG	18	DKBL	3534164C1
C^	B62AS	18	DKBL	3534164C1
C!	B62ASA	18	DKBL	3534164C1
D	B62AT	18	DKBL	3534164C1
E	B62AW	18	DKBL	3534164C1
F*	B62AC	18	DKBL	3534164C1
F^	B62AD	18	DKBL	3534164C1
F#	B62AR	18	DKBL	3534164C1
F&	B62-AG	18	DKBL	3534164C1
G*	B62-GAC	18	WH	3534164C1
G^	B62-GAD	18	WH	3534164C1
G#	B62-GAR	18	WH	3534164C1
G&	B62-GAG	18	WH	3534164C1
H	B62-GAW	18	WH	3534164C1
J^	B62-GAC	18	WH	3534164C1
J!	B62-GAT	18	WH	3534164C1
J!	B62-GAU	16	LTGN	3534164C1
J&	B62-GBG	18	WH	3534164C1
J^	B62-GAC	16	LTGN	3534165C1
K	B62-GAS	18	WH	3534164C1
L	B62-GAJ	18	WH	3534164C1
M	B62-GBB	18	WH	3534164C1

Connector 10331: SW ILLUM A ML

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B62BC	18	DKBL	3534164C1
B	B62C	18	DKBL	3534164C1
B!	B62AA	18	DKBL	3534164C1
B^	B62A	18	DKBL	3534164C1
C	-	-	-	-
D	B62T	18	DKBL	3534164C1
E	B62K	18	DKBL	3534164C1
F	B62L	18	DKBL	3534164C1
G	B62-GL	18	WH	3534164C1
H	B62-GK	18	WH	3534164C1
J	B62-GT	18	WH	3534164C1
K!	KX125-GH	18	WH	3534164C1
L	B62-GC	18	WH	3534164C1
L!	B62-GAM	18	WH	3534164C1
L^	B62-GA	18	WH	3534164C1
M	B62-GBC	18	WH	3534164C1

24.59. CONNECTOR COMPOSITES %10332, %10333, @10334, P. 30 | Figure 1241 CONNECTOR COMPOSITES %10332, %10333, @10334 | printed page 1241

Connector 10332: A ML C* B62N C# B62BJ D^ B62P

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B62BD	18	DKBL	3534164C1
B	B62M	18	DKBL	3534164C1
C*	B62N	18	DKBL	3534164C1
C#	B62BJ	18	DKBL	3534164C1
D^	B62P	18	DKBL	3534164C1
D!	B62P	18	DKBL	3534164C1
E	B62R	18	DKBL	3534164C1
F	B62S	18	DKBL	3534164C1
G	B62-GS	18	WH	3534164C1
H	B62-GR	18	WH	3534164C1
J^	B62-GP	18	WH	3534164C1
J!	B62-GP	18	WH	3534164C1
K*	B62-GN	18	WH	3534164C1
K#	B62-GBJ	18	WH	3534164C1
L	B62-GM	18	WH	3534164C1
M	B62-GBD	18	WH	3534164C1

Connector 10333: M B62-GBD CAV CIRCUIT SW ILLUM B A ML B B62W 18 C^ B62AE 18 C! B62AEW 18

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B62BE	18	DKBL	3534164C1
B	B62W	18	DKBL	3534164C1
C^	B62AE	18	DKBL	3534164C1
C!	B62AEW	18	DKBL	3534164C1
D	B62AF	18	DKBL	3534164C1
E	B62AH	18	DKBL	3534164C1
F*	B62AK	18	DKBL	3534164C1
F#	B62AL	18	DKBL	3534164C1
G*	B62-GAK	18	WH	3534164C1
G#	B62-GAL	18	WH	3534164C1
H	B62-GAH	18	WH	3534164C1
J	B62-GAF	18	WH	3534164C1
K	B62-GAE	18	WH	3534164C1
L	B62-GW	18	WH	3534164C1
M	B62-GBE	18	WH	3534164C1

Connector 10334: M B62-GBE GROUND SPLICE J K A B11-GA B* B11GD B# B127-GA

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B11-GA	12	WH	3566715C1
B*	B11GD	16	WH	1661209C1
B#	B127-GA	16	WH	1661209C1
C&	B119-GB	18	WH	1661208C1
C%	B89GA	16	WH	1661209C1
C!	B119-GC	18	WH	1661208C1
D	B119-GE	16	WH	1661209C1
E*&	B119-GN	16	WH	1661209C1
E&&	B119-GN	18	WH	1661208C1
F!!	B63-GAB	16	WH	1661209C1
F**	B63-GAC	14	WH	3566715C1
G	B78-GE	18	WH	1661208C1
H##	B63-GA	16	WH	1661209C1
H%%	B136-GA	16	WH	1661209C1
J	B128-G	16	WH	1661209C1
K*&	B137-GC	16	WH	1661209C1
K^	B119-GG	18	WH	1661208C1
K*&	-	-	-	-

24.60. CONNECTOR COMPOSITES @10335A, P. 31 | Figure 1242 CONNECTOR COMPOSITES @10335A | printed page 1242

Connector 10335A: K

CAV	CIRCUIT	GA	COLOR	TERMINAL
A^	B11-GB	16	WH	1661209C1
A!	B11-GBY	16	WH	1661209C1
B@	B58-GF	18	WH	1661208C1
C@	B77-G	18	WH	1661208C1
D*	B74-G	18	WH	1661208C1
D&	B74-G	16	WH	1661209C1
D^	B74-GB	14	WH	3566715C1
D%	B74-GB	18	WH	1661208C1
D#	B74-GT	16	WH	1661209C1
D!	B74E	18	LTGN	1661208C1
D!	B74-GE	18	WH	1661208C1
D^	B74F	18	WH	1661208C1
E	B132-GC	18	WH	1661208C1
F**	B63-GB	16	WH	1661209C1
F!	B11-G	16	WH	1661209C1
F!	B11-GN	18	WH	1661208C1
F^	B11-GA	16	WH	1661209C1
F!	B11-GB	16	WH	1661209C1
F!	B11-GB	18	WH	1661208C1
F!	B11-GD	16	WH	1661209C1
F@	B63-G	16	WH	1661209C1
F!!	B11-G	18	WH	1661208C1
G^	B122	18	GY	1661208C1
G!	B122X	18	GY	1661208C1
H@	B122-GB	18	WH	1661208C1
J@	B122-G	18	WH	1661208C1
K@	B122-GA	18	WH	1661208C1
K^	B122-GC	18	WH	1661208C1

24.61. CONNECTOR COMPOSITES @10335B, P. 31A
Figure 1243 CONNECTOR COMPOSITES @10335B

24.61. CONNECTOR COMPOSITES @10335B, P. 31A | Figure 1243 CONNECTOR COMPOSITES @10335B | printed page 1243

Connector 10335B: K

CAV	CIRCUIT	GA	COLOR	TERMINAL
A@	B11-GK	16	WH	1661209C1
B@	B120-GK	18	WH	1661208C1
C^	B117-GL	18	WH	1661208C1
C!	B122-GB	18	WH	1661208C1
D*	B120-G	18	WH	1661208C1
D&	B11-G	18	WH	1661208C1
D!!	B11-GS	18	WH	1661208C1
D^^	B146-G	18	WH	1661208C1
E@	B11-GAA	18	WH	1661208C1
F^^	B11-GAD	18	WH	1661208C1
F^%	B11-GADC	18	WH	1661208C1
F^#	B11-GADB	18	WH	1661208C1
G^^	B11-GAH	18	WH	1661208C1
G^*	B11-GAZ	18	WH	1661208C1
H@	B41-GC	18	WH	1661208C1
J#	B125-G	18	WH	1661208C1
J%%	B125-GL	18	WH	1661208C1
J^^	B125-G	16	WH	1661209C1
J^^	B63GA	18	WH	1661208C1
K&	B125A	18	GY	1661208C1
K?	MJ125B	18	GY	1661208C1

24.62. CONNECTOR COMPOSITES ?*10336, ?*10337, %10339, P. 32 | Figure 1244 CONNECTOR COMPOSITES ?*10336, ?*10337, %10339 | printed page 1244

CAV	CIRCUIT	GA	COLOR	TERMINAL
A?	B11-GC	10	WH	1661211C1
A??	B11-GCX	10	WH	1661211C1
B*?	B105-G	16	WH	1661209C1
C*	B125-GA	16	WH	1661209C1
C#	B125-GA	10	WH	1661211C1
C^	B125-GA	14	WH	3566715C1
C%	B125-GD	18	WH	1661208C1
C!	B11GA	16	WH	1661209C1
D	B133-GR	18	WH	1661208C1
E	B44-G	18	WH	1661208C1
F	B119-G	16	WH	1661209C1
G	B139-G	16	WH	1661209C1
H	B125-GS	18	WH	1661208C1
J**	B120-GD	18	WH	1661208C1
J##	B134-G	16	WH	1661209C1
K%%	B123-GK	18	WH	1661208C1
K&&	B125U-G	18	WH	1661208C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A?	B11-GD	12	WH	3566715C1
A??	B11-GDM	12	WH	3566715C1
B*	B100-G	18	WH	1661208C1
B#	B100-G	16	GY	1661209C1
C?*	B144-G	18	WH	1661208C1
C?	B171-GA	16	WH	1661209C1
D?*	B41-GK	18	WH	1661208C1
E?*	B120-GC	18	WH	1661208C1
F?*	B62-G	18	WH	1661208C1
G?*	B86-G	16	WH	1661209C1
H?*	B62-GAN	18	WH	1661208C1
J?*	B78-G	18	WH	1661208C1
K?*	B127-G	16	WH	1661209C1

Legend: * W/AIR HORN ACTVTD BY FOOT SW ; # W/AIR HORN ACTVTD BY PULL CHAIN ; ? N/0508108 - NOT MTA FUSE BLOCK ; ?? W/0508108 - MTA FUSE BLOCK ; ?* W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10339: CA 2018 CHECKMATE 1 3 2 4 5 6

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B14A	18	RD	3761061C1
2*	B125-GM	18	WH	3761061C1
2#	B125-G	18	WH	3761061C1
3	B13	18	PK	3761061C1
4	B125	18	GY	3761061C1
5	B60	18	OR	3761061C1
6*	B125HH	18	GY	3761061C1
6#	B85	18	GY	3761061C1

Legend: DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 04MAR20 AE08090675 032

24.63. CONNECTOR COMPOSITES %10341, %10334, @10344, P. 33 | Figure 1245 CONNECTOR COMPOSITES %10341, %10334, @10344 | printed page 1245

Connector 10341: 1 2

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	B136A	16	YL	3522190C1	3522194C1
2	B136-GA	16	WH	3522190C1	3522194C1

Connector 10334: CONNECTOR 2206588C1 GROUND SPLICE 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B11-GAP	12	WH	3566715C1
B!	B11GD	16	WH	1661209C1
B@	B127-GA	16	WH	1661209C1
C#	B119-GB	18	WH	1661208C1
C%	B89GA	16	WH	1661209C1
C^	B119-GC	18	WH	1661208C1
D	B119-GE	16	WH	1661209C1
E&	B119-GN	18	WH	1661208C1
E*	B119-GN	16	WH	1661209C1
F?	B63-GAB	16	WH	1661209C1
F??	B63-GAC	14	WH	3566715C1
G	B78-GE	18	WH	1661208C1
H!!	B63-GAA	16	WH	1661209C1
H^^	B136-GA	16	WH	1661209C1
J	B128-G	16	WH	1661209C1

Connector 10344: ^^ W/ELECTRICAL COMPARTMENT LT PEDESTRIAN LIGHT 7 8

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B139	16	YL	1661226C1
3	B139A	16	YL	1661226C1
4-6	-	-	-	-
7	B62-GBM	18	WH	1661224C1
8	B62BM	18	DKBL	1661224C1
9-10	-	-	-	-

24.64. CONNECTOR COMPOSITES %10350A, P. 33A
Figure 1246 CONNECTOR COMPOSITES %10350A

24.64. CONNECTOR COMPOSITES %10350A, P. 33A | Figure 1246 CONNECTOR COMPOSITES %10350A | printed page 1246

Connector 10350A: K

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B9M	16	GY	1661209C1
B	B77D	18	LTGN	1661208C1
C	B9B	18	GY	1661208C1
D*	B9A	18	GY	1661208C1
D#	B9D	18	GY	1661208C1
D&	B9C	18	GY	1661208C1
E	B60BA	18	OR	1661208C1
F**	B9K	18	GY	1661208C1
F^	B9H	18	GY	1661208C1
F!	NB9HJ	18	GY	1661208C1
G	B9E	18	GY	1661208C1
H	B9F	18	LTGN	1661208C1
J	B9J	18	LTGN	1661208C1
K%%	B9H	18	GY	1661208C1
K*#	B123A	18	LTGN	1661208C1
K%*	B9S	18	GY	1661208C1
K#*	B123B	18	GY	1661208C1

Legend: W/L PANEL MOUNTED DOOR CONTROL 3 POSITION TOGGLE ; W/L 3 POSITION ROTARY DOOR CONTROL W/NON SEQUENTIAL ; W/DOOR CONTROL MANUAL ; W/L AED AIR W/DUMP VALVE W/9 ; W/MASTER SW N/FLASHER CANCEL ; W/NO L MASTER SW ; W/OMIT MASTER FLASHER W/MOMENTARY CANCEL ; W/MASTER,RRX,AMB CANCEL W/2 POSITION TOGGLE ; W/0508108 - MTA FUSE BLOCK

24.65. CONNECTOR COMPOSITES %10350B, %10353, %10354, P. 34 | Figure 1247 CONNECTOR COMPOSITES %10350B, %10353, %10354 | printed page 1247

Connector 10350B: ZVR SPLICE K

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B9N	16	GY	1661209C1
B	B9P	18	GY	1661208C1
C	B152-G	18	WH	1661208C1
D	B67-GA	18	WH	1661208C1
E	B9A	18	GY	1661208C1
F	B9B	18	GY	1661208C1
G	-	-	-	-
H	-	-	-	-
J	-	-	-	-
K	-	-	-	-

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10353: BODY LOCK 2007316C1 UPPER FLAT MIRROR

CAV	CIRCUIT	GA	COLOR	TERMINAL
1%	B78LA	20	LTGN	3535805C1
1^	B78V	20	LTGN	3535805C1
2%	B78RA	20	LTGN	3535805C1
3%	B78LD	20	LTGN	3535805C1
3^	B78X	20	LTGN	3535805C1
4%	B78RD	20	LTGN	3535805C1
5%	B62AU	20	DKBL	3535805C1
6%	B78B	20	LTGN	3535805C1
7%	B78N	20	LTGN	3535805C1
8%	B78-GC	20	WH	3535805C1
	- NOT MTA		FUSE	BLOCK

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10354: LOWER CONVEX MIRROR

CAV	CIRCUIT	GA	COLOR	TERMINAL
1%	B78LC	20	LTGN	3535805C1
1^	KT78Z	20	LTGN	3535805C1
2%	B78RC	20	LTGN	3535805C1
3%	B78LF	20	LTGN	3535805C1
3^	KT78AB	20	LTGN	3535805C1
4%	B78RF	20	LTGN	3535805C1
5%	B62AV	20	DKBL	3535805C1
6%	B78C	20	LTGN	3535805C1
7%	B78S	20	LTGN	3535805C1
8%	B78-GD	20	WH	3535805C1
	- NOT MTA		FUSE	BLOCK

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

24.66. CONNECTOR COMPOSITES @10355, %10356, %10357, %10357A, P. 35
Figure 1248 CONNECTOR COMPOSITES @10355, %10356, %10357, %10357A

24.66. CONNECTOR COMPOSITES @10355, %10356, %10357, %10357A, P. 35 | Figure 1248 CONNECTOR COMPOSITES @10355, %10356, %10357, %10357A | printed page 1248

Connector 10355: PEDESTRIAN LIGHT PANEL PLATFORM) A H

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B78V	20	LTGN	3534481C1
B	B78T	18	LTGN	1661262C1
C	B78Z	20	LTGN	3534481C1
D	B78X	20	LTGN	3534481C1
E	B78P	18	LTGN	1661262C1
F	B78AB	20	LTGN	3534481C1
G	-	-	-	-
H	B78-GA	18	WH	1661262C1

Legend: @ N/0508108 - NOT MTA FUSE BLOCK

Connector 10356: HEATED MIRROR SPLICE G

CAV	CIRCUIT	GA	COLOR	TERMINAL
A^	B78B	18	LTGN	1661208C1
A!	B78BA	18	LTGN	1661208C1
B	-	-	-	-
C%	B78D	18	LTGN	1661208C1
D%	B78J	18	LTGN	1661208C1
E%	B78AD	18	LTGN	1661208C1

Legend: F-G - - - ; ! W/0508108 - MTA FUSE BLOCK ; ^ N/0508108 - NOT MTA FUSE BLOCK ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10357: CONNECTOR 2006789C1 BODY LOCK 2006792C1 DOOR SIGNAL A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B1A	16	LTGN	0239805R1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10357A: CONNECTOR 2206658C1 DOOR SIGNAL TALK BUS A !

CAV	CIRCUIT	GA	COLOR	TERMINAL
A!	B120C	16	LTGN	0239806R1
A^	B120C	18	LTGN	2206655C1

Legend: ! W/0508108 - MTA FUSE BLOCK ; ^ N/0508108 - NOT MTA FUSE BLOCK ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

24.67. CONNECTOR COMPOSITES %10358, %10358A, @10358B, %10359, P. 36 | Figure 1249 CONNECTOR COMPOSITES %10358, %10358A, @10358B, %10359 | printed page 1249

Connector 10358: A CAV A B

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	B105	16	LTGN	0587577C1	1652325C1
B	B105-G	16	WH	0587577C1	1652325C1
C	B105A	16	LTGN	0587577C1	1652325C1

Connector 10358A: CONNECTOR 0587569C91 STOP ARM EXTEND G F E B C D

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B119P	16	GY	1661209C1
B	B119F	18	GY	1661208C1
C	B119H	18	GY	1661208C1
D	B119J	16	GY	1661209C1
E	B119L	16	GY	1661209C1
F	B127E	16	OR	1661209C1
G	B119T	16	GY	1661209C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10358B: A CONNECTOR 2006789C1 BLOCK BODY LOCK 2006792C1 STOP ARM EXTEND G F E B@ B! B!!

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B119R	16	GY	1661209C1
B@	B119V	18	GY	1661208C1
B!	B119HJ	18	GY	1661208C1
B!!	B119W	18	GY	1661208C1
B^	B119AA	18	GY	1661208C1
B#	B119	18	GY	1661208C1
B%	B119	18	GY	1661208C1
C@	B119	18	GY	1661208C1
C	B119Y	18	GY	1661208C1

Legend: D-G - - - ; N/0508108 - NOT MTA FUSE BLOCK ; POWER N/0508108 - NOT MTA FUSE BLOCK ; 9 W/0508108 - MTA FUSE BLOCK ; W/ADDL PWR W/0508108 - MTA FUSE BLOCK ; W/0508108 - MTA FUSE BLOCK ; WARNING LT ; - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10359: @ W/COMMON FOR VEHICLE W/0508108 - MTA STOP ARM POWER G

CAV	CIRCUIT	GA	COLOR	TERMINAL
A%	B119	16	GY	1661209C1
B%	B119E	18	GY	1661208C1
C%	B119A	16	GY	1661209C1
D%	B119K	16	GY	1661209C1

Legend: E-G - - - ; ! W/0508108 - MTA FUSE BLOCK ; ^ N/0508108 - NOT MTA FUSE BLOCK ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

24.68. CONNECTOR COMPOSITES @10360A, @10360A, @10360B, P. 37 | Figure 1250 CONNECTOR COMPOSITES @10360A, @10360A, @10360B | printed page 1250

Connector 10360A: TEMP SENSOR BUZZER)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	B128LA	16	OR	3534164C1
A#	B89LFA	16	OR	3534164C1
B%	DV89FA	16	OR	3534164C1
B&	LR119SY	18	GY	3534164C1
C	PM89LD	16	OR	3534164C1
D*	B128RA	16	OR	3534164C1
D#	B89RFA	16	OR	3534164C1
E	-	-	-	-
F	PM89JA	16	OR	3534164C1
G	B89K	16	OR	3534164C1
H	B89AA	16	OR	3534164C1
J	B89RRA	16	OR	3534164C1
K	B89M	16	OR	3534164C1
L	B89AD	16	OR	3534164C1
M	B89LRA	16	OR	3534164C1

Legend: * W/LT MON MODULE W/IND,COMMON ; # W/PWL-AMBER INPUTS ; % W/STROBE LT ACTIVATED W/SW OR PWL W/9 ; & W/CHILD SAFETY ALARM W/SPEAKER ; @ W/0508108 - MTA FUSE BLOCK

Connector 10360A: AMBER PWL SPL TEMP SENSOR BUZZER) A M

Table: W/0508108 - MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	B128LA	16	OR	3534164C1
A#	B89LFA	16	OR	3534164C1
B%	DV89FA	16	OR	3534164C1
B&	LR119SY	18	GY	3534164C1
C	PM89LD	16	OR	3534164C1
D*	B128RA	16	OR	3534164C1
D#	B89RFA	16	OR	3534164C1
E	-	-	-	-
F	PM89JA	16	OR	3534164C1
G	B89K	16	OR	3534164C1
H	B89AA	16	OR	3534164C1
J	B89RRA	16	OR	3534164C1
K	B89M	16	OR	3534164C1
L	B89AD	16	OR	3534164C1
M	B89LRA	16	OR	3534164C1

Legend: @ N/0508108 - NOT MTA FUSE BLOCK ; * W/LIGHT MON MODULE W/IND, COMMON ; # W/PWL - AMBER INPUTS ; % W/STROBE LT SW ACT W/SCR ; ! W/CHILD SAFETY ALARM

Connector 10360B: ! W/CHILD RED PWL SPLICE K G H A& B C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	B84-G	16	WH	1661209C1
A&	B84-GA	16	WH	1661209C1
B	-	-	-	-
C	B84-GB	16	WH	1661209C1
D^	B76-GC	14	WH	3566715C1
D#	B76-GA	14	WH	3566715C1
E	B76-GD	14	WH	3566715C1
F	-	-	-	-
G	B76D-G	14	WH	3566715C1

Legend: H-J - - - ; K B76-G 10 WH 1661211C1 ; * W/1 DC POWER SOURCE LOCATED IN DASH ; & W/2 DC POWER SOURCE LOCATED IN DASH AND OVERHEAD ; ^ W/DEFOG FAN FAR L OR CTR L ; # W/DEFOG FAN CTR L OR L & BHD ; @ W/0508108 - MTA FUSE BLOCK ; REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS

24.69. CONNECTOR COMPOSITES %10360R, P. 37 | Figure 1251 CONNECTOR COMPOSITES %10360R | printed page 1251

Connector 10360R: TEMP SENSOR BUZZER)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	B128LR	16	OR	3534164C1
A#	B89LFR	16	OR	3534164C1
B	B89EA	16	OR	3534164C1
C	B89S	16	OR	3534164C1
D*	B128RR	16	OR	3534164C1
D#	B89RFR	16	OR	3534164C1
E	-	-	-	-
F	B89N	16	OR	3534164C1
G	B89R	16	OR	3534164C1
H	B89AB	16	OR	3534164C1
J	B89RRR	16	OR	3534164C1
K	B89U	16	OR	3534164C1
L	B89AC	16	OR	3534164C1
M	B89LRR	16	OR	3534164C1

Legend: * W/PUPIL WARNING LT W/SW PANEL INDICATOR MONITOR W/9 ; # W/PUPIL WARNING LT N/LT MONITOR W/+9 ; % W/0508108 - MTA FUSE BLOCK

Connector 10360R: RED PWL SPL TEMP SENSOR BUZZER)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	B128LR	16	OR	3534165C1
A#	B89LFR	16	OR	3534165C1
B	B89E	16	OR	3534165C1
C	B89S	16	OR	3534165C1
D*	B128RR	16	OR	3534165C1
D#	B89RFR	16	OR	3534165C1
E	-	-	-	-
F	B89N	16	OR	3534165C1
G	B89R	16	OR	3534165C1
H	B89AB	16	OR	3534165C1
J	B89RRR	16	OR	3534165C1
K	B89U	16	OR	3534165C1
L	B89AC	16	OR	3534165C1
M	B89LRR	16	OR	3534165C1

Legend: % N/0508108 - NOT MTA FUSE BLOCK ; * W/LT MON MODULE W/IND, COMMON ; # W/PWL - RED INPUTS

24.70. CONNECTOR COMPOSITES %10361, %10363, %10364, P. 38 | Figure 1252 CONNECTOR COMPOSITES %10361, %10363, %10364 | printed page 1252

Connector 10361: G

CAV	CIRCUIT	GA	COLOR	TERMINAL
A%	B74T	16	LTGN	1661209C1
B%	B75AD	16	LTGN	1661209C1
B!	B75ADA	16	LTGN	1661209C1
C%	B75AR	16	LTGN	1661209C1
D%	B75AP	16	LTGN	1661209C1
E%	B75AN	16	LTGN	1661209C1
F%	B75AH	16	LTGN	1661209C1
G	-	-	-	-

Connector 10363: CONNECTOR 2006789C1 BODY LOCK 2006792C1 DRIVER HEATER DIODE PACK 2 1 2 1 1 2

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B75ABA	16	LTGN	1680205C1
2	B75ADA	16	LTGN	1680205C1

Connector 10363: CONNCTOR 3866308C1 BODY LOCK 1684263C1 DRIVER HEATER DIODE PACK 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B75AB	16	LTGN	1661538C1
2	B75AD	16	LTGN	1661538C1

Legend: % N/0508108 - NOT MTA FUSE BLOCK

Connector 10364: CONNCTOR 1669030C1 ACC SPLICE RLY COILS G

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	B12X	18	LTBL	1661208C1
A#	B12W	18	LTBL	1661208C1
B^	B12C	18	LTGN	1661208C1
B!	B12CP	18	LTGN	1661208C1
C	B123F	18	LTGN	1661208C1
D	B123J	18	LTGN	1661208C1
E	B132B	18	GY	1661208C1
F	B62BN	18	DKBL	1661208C1
F^	B12	18	LTBL	1661208C1
G**	B120A	18	LTGN	1661208C1
G##	B120A	16	LTBL	1661209C1

Legend: * W/EMERGENCY EXIT ACCESSORY FEED N/+9 W/PIEZO ALARM ; # W/EMERGENCY EXIT BATTERY FEED W/+9 W/PIEZO ALARM ; ** W/L PANEL MOUNTED DOOR CONTROL 3 POSITION TOGGLE ; ## W/3 POSITION TOGGLE & W/ AMBER CANCEL ; ! W/0508108 - MTA FUSE BLOCK ; ^ N/0508108 - NOT MTA FUSE BLOCK ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

24.71. CONNECTOR COMPOSITES &10365, &&10366, &10367, P. 39 | Figure 1253 CONNECTOR COMPOSITES &10365, &&10366, &10367 | printed page 1253

Connector 10365: 7 8 4 1 CAV 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B120E	18	LTGN	1661224C1
2	B9B	18	GY	1661224C1
3	B120D	18	LTGN	1661224C1
4-6	-	-	-	-
7	B62-GAB	18	WH	1661224C1
8	B62AB	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK

Connector 10366: PRIMARY SW ILLUM CAV A ML A# B62AP B B62AX C B62BF

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	B62AM	18	DKBL	3534164C1
A#	B62AP	18	DKBL	3534164C1
B	B62AX	18	DKBL	3534164C1
C	B62BF	18	DKBL	3534164C1
D	B74K	18	DKBL	3534164C1
E	B62BK	18	DKBL	3534164C1
F	B62AC	18	DKBL	3534164C1
G	B62-GAC	18	WH	3534164C1
H	B62-GBK	18	WH	3534164C1
J	-	-	-	-
K%	B62-GBF	18	WH	3534164C1
K&	B62-G	18	WH	3534164C1
L	B62-GAX	18	WH	3534164C1
M	B62-G	18	WH	3534164C1

Legend: && N/0508108 - NOT MTA FUSE BLOCK ; * W/BODY SW PANEL ILLUMINATION ; # W/BODY SW PANEL ILLUMINATION WITH RHEOSTAT ; % W/NOISE SUPRSN SW OUTPUTS ; & W/NOISE SUPPRESSION W/LOW VOLTAGE DISCONNECT

Connector 10367: & W/NOISE DRIVERS HEATER D CAV

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B75B	12	LTGN	1661227C1
B	-	-	-	-
C	B75A	12	LTGN	1661227C1
D	B75-G	12	WH	1661227C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK

24.72. CONNECTOR COMPOSITES !10366, P. 39
Figure 1254 CONNECTOR COMPOSITES !10366

24.72. CONNECTOR COMPOSITES !10366, P. 39 | Figure 1254 CONNECTOR COMPOSITES !10366 | printed page 1254

Connector 10366: PRIMARY SW ILLUM A ML

CIRCUIT	GA	COLOR	TERMINAL
B62AM	18	DKBL	3534164C1
B62AP	18	DKBL	3534164C1
B62AX	18	DKBL	3534164C1
B62BF	18	DKBL	3534164C1
-	-	-	-
B62BK	18	DKBL	3534164C1
B62ACA	18	DKBL	3534164C1
B62-GAV	18	WH	3534164C1
B62-GBK	18	WH	3534164C1
-	-	-	-
B62-GBF	18	WH	3534164C1
B62-GG	18	WH	3534164C1
B62-GAX	18	WH	3534164C1
B62-G	18	WH	3534164C1

Legend: ! W/0508108 - MTA FUSE BLOCK ; * W/BODY SW PANEL ILLUMINATION ; # W/BODY SW PANEL ILLUMINATION WITH RHEOSTAT ; % W/NOISE SUPRSN SW OUTPUTS ; & W/NOISE SUPPRESSION W/LOW VOLTAGE DISCONNECT"

24.73. CONNECTOR COMPOSITES &10368, **10369, **10370, P. 40 | Figure 1255 CONNECTOR COMPOSITES &10368, **10369, **10370 | printed page 1255

Connector 10368: A CAV

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	B105-G	16	WH	0587577C1	1652325C1
B	B105	16	LTGN	0587577C1	1652325C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK

Connector 10369: ACC SPLICE RLY COILS G B C D*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B12Y	16	LTBL	1661209C1
B	B13	18	PK	1661208C1
C	B13B	18	PK	1661208C1
D*	B12N	18	LTBL	1661208C1
D#	B12MD	18	LTBL	1661208C1
E&	B118L	18	LTBL	1661208C1
E%	B12S	18	LTBL	1661208C1
F	B74L	18	PK	1661208C1
G%%	B123L	18	LTGN	1661208C1
G&&	B13H	18	PK	1661208C1
G##	B12Z	16	LTBL	1661209C1

Legend: ** N/0508108 - NOT MTA FUSE BLOCK ; * W/MASTER DISCONNECT IGN ACT ; # W/MASTER DISCONNECT SW COMMON ; & W/NOISE SUPRSN IGN ACT ; % W/NOISE SUPRSN N/MASTER DISCONNECT ; %% W/LEFT MT MSTR SW W/FLR CANCEL VIRGINIA ; && W/MSTR,RRX,AMB CNCL W/3 POSN TOGGLE ; ## W/ELECTRIC DOOR WITH KEY OFF SW

Connector 10370: LIFT SPLICE A ML B C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B44	18	GY	3534164C1
B	B44A	18	GY	3534164C1
C	B122S	16	BN	3534164C1
D	B122Z	16	GY	3534164C1
E	B123C	18	LTGN	3534164C1
F	B122C	18	GY	3534164C1
G	B122P	18	GY	3534164C1
H	B122A	18	GY	3534164C1
J	B63-G	16	WH	3534164C1
K	B122T	18	GY	3534164C1
L*	B122DA	18	GY	3534164C1
L#	B122AA	16	WH	3534164C1
L%	B122A	18	GY	3534164C1
M	B123D	18	LTGN	3534164C1

Legend: ** N/0508108 - NOT MTA FUSE BLOCK ; * W/CCM/TM W/SNOOZE W/LIFT ; # W/LIFT INDICATOR 3 IN BULKHEAD LT ; % W/CHECKMATE W/SNOOZE,+9,EMER ACT & LIFT

24.74. CONNECTOR COMPOSITES !10369, !10370, P. 40A
Figure 1256 CONNECTOR COMPOSITES !10369, !10370

24.74. CONNECTOR COMPOSITES !10369, !10370, P. 40A | Figure 1256 CONNECTOR COMPOSITES !10369, !10370 | printed page 1256

Connector 10369: ACC SPLICE RLY COILS

CIRCUIT	GA	COLOR	TERMINAL
B12Y	16	LTBL	1661209C1
B13Y	18	PK	1661208C1
B13P	18	PK	1661208C1
B13Z	18	PK	1661208C1
B13BZ	18	PK	1661208C1
B12N	18	LTBL	1661208C1
B12MD	18	LTBL	1661208C1
B118L	18	LTBL	1661208C1
B12S	18	LTBL	1661208C1
-	-	-	-
B123L	18	LTGN	1661208C1
B13H	18	PK	1661208C1
B12Z	16	LTBL	1661209C1

Connector 10370: LIFT SPLICE

CIRCUIT	GA	COLOR	TERMINAL
B44	18	GY	3534164C1
B44A	18	GY	3534164C1
B122S	16	BN	3534164C1
BS122Z	16	GY	3534164C1
B123CK	18	LTGN	3534164C1
B122C	18	GY	3534164C1
B122P	18	GY	3534164C1
B122AB	18	GY	3534164C1
B63-GC	16	WH	3534164C1
B122T	18	GY	3534164C1
B122AA	16	WH	3534164C1
B122A	18	GY	3534164C1
B122DA	18	GY	3534164C1
B123D	18	LTGN	3534164C1

Legend: ! W/0508108 - MTA FUSE BLOCK ; !! W/LIFT DOOR INDICATOR INDICATOR 3 IN ; BULKHEAD LT ; && W/CHILD MONITOR SYSTEMS ; ** W/POWER DISTRIBUTION DISC W/NOISE

24.75. CONNECTOR COMPOSITES &10371, &10372, &10375, &10375A, P. 41 | Figure 1257 CONNECTOR COMPOSITES &10371, &10372, &10375, &10375A | printed page 1257

Connector 10371: FLASHING LIFT INDICATOR IN ELECTRICAL PANEL) CAV 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B122V	16	GY	2018946C1
2	B122B	18	GY	1659673C1
3	-	-	-	-
4	B122A	18	GY	1659673C1
5*	B122B	18	GY	2018946C1
5*	B122-GB	18	WH	2018946C1

Connector 10372: ELECTRONIC PANEL DIMMER IN ELECTRICAL PANEL) A C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B62AN	18	DKBL	1661208C1
B	B62-GAN	18	WH	1661208C1
C	B62AP	18	DKBL	1661208C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK

Connector 10375: CONNECTOR 1661198C1 DC POWER SOURCE IN ELECTRICAL PANEL) CAV 1* 1#

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B84A	16	LTGN	1661538C1
1#	B84	16	LTGN	1661538C1
2#	B84-G	16	WH	1661538C1
2*	B84-GA	16	WH	1661538C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK ; # W/1 DC PWR SOURCE LOCATED IN DASH ; * W/2 DC PWR SOURCE LOCATED IN DASH AND OVHD

Connector 10375A: * W/2 DC CONNECTOR 1669030C1 DC POWER IN ELECTRICAL PANEL)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B84B	16	LTGN	0188396R1
B	B84-GB	16	WH	0188396R1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK

24.76. CONNECTOR COMPOSITES !10371, P. 41A
Figure 1258 CONNECTOR COMPOSITES !10371

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.76. CONNECTOR COMPOSITES !10371, P. 41A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, RELEASE NO. PART AE08090675 NO. 96183U 21JUL21 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / FLASHING LIFT INDICATOR !(10371) (LOCATED NEAR FUSE BLOCK IN ELECTRICAL PANEL) / !! W/LIFT INTERLOCK AND LIGHTS ! W/0508108 - MTA FUSE BLOCK" / CONNECTOR 0593385C1 BODY LOCK 0593387C1 / Figure 1258 / CONNECTOR COMPOSITES !10371

Connector 10371: FLASHING LIFT INDICATOR IN ELECTRICAL PANEL)

CIRCUIT	GA	COLOR	TERMINAL
B122V	16	GY	1661226C1
B122B	18	GY	1661224C1
-	-	-	-
B122AH	18	GY	1661224C1
B122B	18	GY	3541250C1
B122-GB	18	WH	3541250C1

24.77. CONNECTOR COMPOSITES &10375B, &10376, &10377, &10380, P. 42 | Figure 1259 CONNECTOR COMPOSITES &10375B, &10376, &10377, &10380 | printed page 1259

Connector 10375B: DC POWER OUTLET IN SW PNL IN ELECTRICAL PANEL)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B84	16	LTGN	1661538C1
2	B84-G	16	WH	1661538C1

Connector 10376: CONNECTOR 1669030C1 RHEOSTAT DIMMER 7 8 4 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B63RH	12	DKBL	1661227C1
2	B63AL	12	DKBL	1661227C1
3	B63RF	12	DKBL	1661227C1
4-6	-	-	-	-
7	B62-GBP	18	WH	1661224C1
8	B62BP	18	DKBL	1661224C1
9-10	-	-	-	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT FUSE BLOCK

Connector 10377: CONNECTOR 3530563C1 RHEOSTAT DIODE 1 4

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	PLUG	-	-	0453133C1
2	B63RM	14	DKBL	2034787C1
3	B63RN	14	DKBL	2034787C1
4	B63RE	14	DKBL	2034787C1

Connector 10380: BODY LOCK 3545579C1 CL LT OPTIONS G

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B58D	16	BN	1661209C1
B	B131A	16	DKBL	1661209C1
C	B58J	16	BN	1661209C1
D	B143	18	DKBL	1661208C1
E	B121	18	YL	1661208C1
F	B62AN	18	DKBL	1661208C1
G*	B131C	18	DKBL	1661208C1
G#	B134B	16	OR	1661209C1
G%	B134A	16	OR	1661209C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT FUSE BLOCK ; * W/LEFT AED ELECTRIC W/MSTR SW W/9 ; % W/SIGN,FR ONLY,CL LT ACTVTD,COML BUS ; # W/SIGN,FR & REAR,ACTVTD BY CL LIGHTS ; DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 04MAR20 AE08090675 042

24.78. CONNECTOR COMPOSITES !10377, P. 42A
Figure 1260 CONNECTOR COMPOSITES !10377

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.78. CONNECTOR COMPOSITES !10377, P. 42A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, RELEASE NO. PART AE08090675 NO. 96183U 21JUL21 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / RHEOSTAT DIODE !(10377) (LOCATED IN ELECTRICAL PANEL) / ! N/0508108 - NOT MTA FUSE BLOCK / CONNECTOR 2206665C1 / 1 2 3 / CAV CIRCUIT GA COLOR TERMINAL 1 B63RM 12 DKBL 2030385C1 2 B63RE 12 DKBL 2030385C1 3 B63RN 12 DKBL 2030385C1 / Figure 1260 / CONNECTOR COMPOSITES !10377

Connector 10377: RHEOSTAT DIODE

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B63RM	12	DKBL	2030385C1
2	B63RE	12	DKBL	2030385C1
3	B63RN	12	DKBL	2030385C1

24.79. CONNECTOR COMPOSITES &10381, &10382, &10383, P. 43 | Figure 1261 CONNECTOR COMPOSITES &10381, &10382, &10383 | printed page 1261

Connector 10381: G

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B68D	16	BN	1661209C1
B	B66	16	YL	1661209C1

Legend: C-G - - -

Connector 10382: CONNECTOR 2006789C1 N/0508108 BODY LOCK 2006792C1 STARTER INTERLOCK G AT DRIVERS B-PILLAR)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B133F	18	LTGN	1661208C1
B	B133E	18	LTGN	1661208C1
C	B133D	18	LTGN	1661208C1
D	B133H	18	LTGN	1661208C1
E	B133A	16	LTGN	1661209C1

Legend: F-G - - -

Connector 10383: FIRE SUPPRESSION SYSTEM CAV 1 2

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B144A	18	GY	1661539C1
2	B144-GA	18	WH	1661539C1
3	B144-GG	18	WH	1661539C1

24.80. CONNECTOR COMPOSITES !10382, P. 43A
Figure 1262 CONNECTOR COMPOSITES !10382

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.80. CONNECTOR COMPOSITES !10382, P. 43A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, RELEASE NO. PART AE08090675 NO. 96183U 21JUL21 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / STARTER INTERLOCK !(10382) (LOCATED UNDER LIGHT BAR AT DRIVERS B-PILLAR) / ! N/0508108 - NOT MTA FUSE BLOCK * W/DEFOG AND BLOWER FANS # W/DEFOG AND BLOWER FANS" / CONNECTOR 2006789C1 BODY LOCK 2006792C1 / G F E D C B / Figure 1262 / CONNECTOR COMPOSITES !10382

Connector 10382: STARTER INTERLOCK AT DRIVERS B-PILLAR) B C*

CIRCUIT	GA	COLOR	TERMINAL
B133F	18	LTGN	1661208C1
B133E	18	LTGN	1661208C1
B171-GC	18	WH	1661208C1
B133D	18	LTGN	1661208C1
B133H	18	LTGN	1661208C1
B133A	16	LTGN	1661209C1
-	-	-	-
B171-GB	16	WH	1661209C1

24.81. CONNECTOR COMPOSITES &10384, &10385, &10386, P. 44 | Figure 1263 CONNECTOR COMPOSITES &10384, &10385, &10386 | printed page 1263

Connector 10384: 1 CAV 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B144E	18	GY	1661538C1
2	B144B	18	GY	1661538C1
3	B144F	18	GY	1661538C1

Connector 10385: CONNECTOR 2206665C1 FIRE SUPPRESSION SYSTEM 1 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B144C	18	GY	1661538C1
2	-	-	-	-
3	B144D	18	GY	1661538C1
4	B144E	18	GY	1661538C1
5	B144-GF	18	WH	1661538C1
6	B144F	18	GY	1661538C1

Connector 10386: N/0508108 - CONNECTOR 2206667C1 REAR DOOR SPLICE G F A B C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B117F	18	GY	1661208C1
B	B117B	18	LTBL	1661208C1
C	B117M	18	GY	1661208C1
D*	B117D	18	GY	1661208C1
D#	B63E	16	GY	1661209C1

Legend: E-G - - - ; * W/DOME LTS ACTVTD BY REDR ; # W/DOME LT W/REAR ROW & W/REE & N/RHEO ; & N/0508108 - NOT MTA FUSE BLOCK

Connector 10386: CONNECTOR 2006789C1 BODY LOCK 2006792C1 REAR DOOR SPLICE G CAV A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B117F	18	GY	1661208C1
B	B117BB	18	LTBL	1661208C1
C	B117M	18	GY	1661208C1
D*	B117D	18	GY	1661208C1
D#	B63ED	16	GY	1661209C1

Legend: E-G - - - ; & W/0508108 - MTA FUSE BLOCK ; * W/DOME LTS ACTVTD BY REDR ; # W/DOME LT W/REAR ROW & W/REE & N/RHEO

24.82. CONNECTOR COMPOSITES &&10389, &&10389, P. 45 | Figure 1264 CONNECTOR COMPOSITES &&10389, &&10389 | printed page 1264

Connector 10387: 1A 1B

CAV	CIRCUIT	GA	COLOR	TERMINAL
1A	B62AA	18	DK BL	1661224C1
1B	B62-GAA	18	DK BL	1661224C1
2A	-	-	-	-
2B	-	-	-	-

Connector 10389: DOOR OPTION G C D E*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B131B	16	DKBL	1661209C1
B	B131C	16	DKBL	1661209C1
C	-	-	-	-
D	B120AL	16	LTGN	1661209C1
E*	B120A	18	LTGN	1661208C1
E#	B63UB	18	DKBL	1661208C1
E%	B125RA	18	GY	1661208C1
E&	B131AA	18	DKBL	1661208C1
E%%	B63F	18	DKBL	1661208C1
E!!	B120A	18	LTGN	1661208C1
F	B63AJ	18	DKBL	1661208C1
G	B119S	16	GY	1661209C1

Legend: && N/0508108 - NOT MTA FUSE BLOCK ; * W/DOME LTS ACTVTD BY ENTR DOOR ; # W/EMER EXIT & ENTR DOOR ACTVTD DOME LT ; % W/CHILD MONITOR W/ENTR ACTVTD DOME W/9 ; & W/CCM ENTR DOOR AND EMER EXIT ACTVD ; %% W/DOME LIGHT WITH ENTER EXIT ACTIVE DOME LIGHT ; !! W/DOME LIGHT WITH ENTER OR WITH REAR DOME

Connector 10389: %% BODY LOCK 2006792C1 !! DOOR OPTION G

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B131BC	16	DKBL	1661209C1
B	B131CV	16	DKBL	1661209C1
C	-	-	-	-
D	B120AL	16	LTGN	1661209C1
E*	B120AS	18	LTGN	1661208C1
E#	B63UB	18	DKBL	1661208C1
E%	B125RA	18	GY	1661208C1
E&	B131AA	18	DKBL	1661208C1
E!!	B120AW	18	LTGN	1661208C1
E%%	B63UD	18	DKBL	1661208C1
F	B63AJ	18	DKBL	1661208C1
G	B119S	16	GY	1661209C1

Legend: && N/0508108 - NOT MTA FUSE BLOCK ; * W/DOME LTS ACTVTD BY ENTR DOOR ; # W/EMER EXIT & ENTR DOOR ACTVTD DOME LT ; % W/CHILD MONITOR W/ENTR ACTVTD DOME W/9 ; & W/CCM ENTR DOOR AND EMER EXIT ACTVD ; %% W/EXIT/ENTR DOOR ACTIVATED DOME W/REAR ; !! W/ENTR DOOR WITH REAR ROW DOME

24.83. CONNECTOR COMPOSITES %10389, &10390, &10391, &%10397, P. 46 | Figure 1265 CONNECTOR COMPOSITES %10389, &10390, &10391, &%10397 | printed page 1265

Connector 10389: IN ANY WAY DETRIMENTAL TO THE INTEREST OF INC. DOOR OPTIONS G A* B# B*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	B131BC	16	DKBL	1661209C1
A*	B131B	16	DKBL	1661209C1
B#	B131CV	16	DKBL	1661209C1
B*	B131C	16	DKBL	1661209C1
C	-	-	-	-
D%	B120AL	16	LTA	1661209C1
E#	B120AS	18	LTA	1661208C1
E%	B63UB	18	DKBL	1661208C1
E%	B125RA	18	GY	1661208C1
E#	B63UD	18	DKBL	1661208C1
E%	B131AA	18	DKBL	1661208C1
E#	B120AW	18	LTA	1661208C1
E%	B120A	18	LTA	1661208C1
E*	B63F	18	DKBL	1661208C1
F%	B63AJ	18	DKBL	1661208C1
G%	B119S	16	GY	1661209C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; # W/0508108 - MTA FUSE BLOCK ; * N/0508108 - NOT MTA FUSE BLOCK

Connector 10390: * N/0508108 ENGINE COMPARTMENT CAV TEMP SENSOR BUZZER 1-3 3 1 5

Table: N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1-3	-	-	-	-
4	B41-GK	18	WH	1659673C1
5	B41K	18	TN	1659673C1

Connector 10391: CONNECTOR 0593385C1 BODY LOCK 0593387C1 AIR SEAT A CAV

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	B105-G	16	WH	0587577C1	1652325C1
B	B105	16	WH	0587577C1	1652325C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK

Connector 10397: CONNECTOR 0587567C91 DOME LT TIMER 87 85* 85#

CAV	CIRCUIT	GA	COLOR	TERMINAL
30*	B63P	16	DKBL	0239805R1
30#	B63C	16	DKBL	0239805R1
85*	B11-GA	16	WH	0556897C1
85#	B63-GA	16	WH	0239805R1
85%	B11-G	16	WH	0556897C1
86%	B63M	16	DKBL	0556897C1
86%	B63N	16	DKBL	0556897C1
86#	B63B	16	DKBL	0239805R1
87	-	-	-	-

Legend: 87a* B12B 16 LTBL 0239805R1 ; 87a# B63A 16 DKBL 0239805R1 ; &% N/0508108 - NOT MTA FUSE BLOCK ; * W/DOME LTS ACTVTD BY ENTR DOOR ; # W/EMER EXIT & ENTR DOOR ACTVTD DOME LT ; % W/CHILD MONITOR W/ENTR ACTVTD DOME W/9 ; & W/CCM ENTR DOOR AND EMER EXIT ACTVD ; REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS

24.84. CONNECTOR COMPOSITES !10390, !10397, P. 46A
Figure 1266 CONNECTOR COMPOSITES !10390, !10397

24.84. CONNECTOR COMPOSITES !10390, !10397, P. 46A | Figure 1266 CONNECTOR COMPOSITES !10390, !10397 | printed page 1266

Connector 10390: ENGINE COMPARTMENT TEMP SENSOR BUZZER 2 3 4

CIRCUIT	GA	COLOR	TERMINAL
-	-	-	-
-	-	-	-
-	-	-	-
BY41K	18	TN	1661224C1
BY41-GK	18	WH	1661224C1

Connector 10397: DOME LT TIMER 87 30* 30# 85*

CIRCUIT	GA	COLOR	TERMINAL
B63P	16	DKBL	239805R1
B63C	16	DKBL	239805R1
B11-GA	16	WH	556897C1
B63-GA	16	WH	239805R1
B11-G	16	WH	556897C1
B63M	16	DKBL	556897C1
B63N	16	DKBL	556897C1
B63BK	16	DKBL	239805R1
B12BJ	16	LTBL	239805R1
B63AS	16	DKBL	239805R1

Legend: ! W/0508108 - MTA FUSE BLOCK ; * W/DOME LTS ACTVTD BY ENTR DOOR ; # W/EMER EXIT & ENTR DOOR ACTVTD DOME LT ; % W/CHILD MONITOR W/ENTR ACTVTD DOME W/9 ; & W/CCM ENTR DOOR AND EMER EXIT ACTVD

24.85. CONNECTOR COMPOSITES &10398, &10399, !10399, P. 47 | Figure 1267 CONNECTOR COMPOSITES &10398, &10399, !10399 | printed page 1267

Connector 10398: OVERHEAD LOCKING COMPT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B133R	18	LTGN	1661261C1
B	B133-GR	18	WH	1661261C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK

Connector 10399: SW ILLUM A ML B C D

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B62BH	18	DKBL	3534164C1
B	-	-	-	-
C	B62BL	18	DKBL	3534164C1
D	B62AS	18	DKBL	3534164C1
E	B62BR	18	DKBL	3534164C1
F*	B62	18	DKBL	3534164C1
F#	B62A	18	DKBL	3534164C1
G*	B62-GGA	18	WH	3534164C1
G#	B62-GF	18	WH	3534164C1
H	B62-GBR	18	WH	3534164C1
J	B62-GA	18	WH	3534164C1
K	B62-GBL	18	WH	3534164C1
L	-	-	-	-
M	B62-GBH	18	WH	3534164C1

Legend: & W/0508108 - MTA FUSE BLOCK ; * W/MSTR,RRX,AMB CNCL W/2 POSN TOGGLE ; # W/3 POSN TOGGLE & W/AMBER CANCEL

Connector 10399: SW ILLUM

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B62BH	18	DKBL	3534164C1
B	B62BM	18	DKBL	3534164C1
C	B62BL	18	DKBL	3534164C1
D	B62A	18	DKBL	3534164C1
E	B62BR	18	DKBL	3534164C1
F#	B62	18	DKBL	3534164C1
F%	B62A	18	DKBL	3534164C1
G#	B62-G	18	WH	3534164C1
G%	B62-GA	18	WH	3534164C1
H	B62-GBR	18	WH	3534164C1
J	B62-GA	18	WH	3534164C1
K	B62-GBL	18	WH	3534164C1
L	B62-GBM	18	WH	3534164C1
M	B62-GBH	18	WH	3534164C1

Legend: ! N/0508108 - NOT MTA FUSE BLOCK ; # W/AMBER CANCEL W/2 POS OR SW ; % W/3 POSN & W/AMBER CANCEL

24.86. CONNECTOR COMPOSITES %10400, P. 48
Figure 1268 CONNECTOR COMPOSITES %10400

24.86. CONNECTOR COMPOSITES %10400, P. 48 | Figure 1268 CONNECTOR COMPOSITES %10400 | printed page 1268

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1*	E124	16	LTGN	3544886C1
A2*	E68	16	BN	3544886C1
A3*	E11-G	10	WH	3544882C1
A4*	E70	14	RD	3544881C1
A5*	E70L-M	14	RD	3544881C1
A6*	E70R-M	14	RD	3544881C1
A7*	E68L-M	16	BN	3544886C1
A8*	E68R-M	16	BN	3544886C1
B1*	E56-M	16	YL	3544886C1
B2*	E57	16	LTGN	3544886C1
B3*	E57-M	16	LTGN	3544886C1
B4*	E71	16	LTBL	3544886C1
B5*	E71L-M	16	LTBL	3544886C1
B6*	E71R-M	16	LTBL	3544886C1
B7^	E121	16	YL	3544886C1
B8^	E121A	18	YL	3544886C1
B9^	E41	18	TN	3544886C1
B10^	E41A	18	TN	3544886C1
B11^	E140	18	TN	3544886C1
B11#	E143	16	DKBL	3544886C1
B12*	E89LA-M	16	OR	3544886C1
C1*	E89LR-M	16	OR	3544886C1
C2*	E89RA-M	16	OR	3544886C1
C3*	E89RR-M	16	OR	3544886C1
C4*	E56	16	YL	3544886C1
C4*	E56A	16	YL	3544886C1
C5*	E58B	16	BN	3544886C1
C5*	E58A	16	BN	3544886C1
C6*	E126A	18	GY	3544886C1
C7*	E89RR	16	OR	3544886C1
C8!	E12C	18	LTBL	3544886C1
C8#	E12C	18	BK	3544886C1
C8!	E12B	18	LTBL	3544886C1
C8#	E12B	18	BK	3544886C1
C9*	E130C	18	GY	3544886C1
C9*	E130B	18	GY	3544886C1
C10*	E143V	18	DKBL	3544886C1
C11*	E133A	18	LTGN	3544886C1
C12*	E129A	18	GY	3544886C1
D1*	E127A	18	OR	3544886C1
D1*	E127B	18	OR	3544886C1
D2*	E89LA	16	OR	3544886C1
D3*	E11-GA	10	WH	3544882C1
D4^	E74	12	LTGN	3544881C1
D5^	E74-G	12	WH	3544881C1
D6&	E131	16	DKBL	3544880C1
D6^	E141	16	LTGN	3544880C1
D7*	E89LR	16	OR	3544886C1
D8*	E89RA	16	OR	3544886C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; ! W/5 TO 8, 10 TO 12 LH WDO ; * W/5 TO 8, 10 TO 13 LH WDO ; ^ W/ 12 TO 13 LH WDO ; # W/13 LH WDO ; & W/11 TO 13 LH WDO ; DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS

24.87. CONNECTOR COMPOSITES @10400, P. 48A
Figure 1269 CONNECTOR COMPOSITES @10400

24.87. CONNECTOR COMPOSITES @10400, P. 48A | Figure 1269 CONNECTOR COMPOSITES @10400 | printed page 1269

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	E124	16	LTGN	3544884C1
A2	E68	16	BN	3544884C1
A3	E11-G	10	WH	3544878C1
A4	E70	14	RD	3544877C1
A5	E70L-M	14	RD	3544877C1
A6	E70R-M	14	RD	3544877C1
A7	E68L-M	16	BN	3544884C1
A8	E68R-M	16	BN	3544884C1
B1	E56-M	16	YL	3544884C1
B2	E57	16	LTGN	3544884C1
B3	E57-M	16	LTGN	3544884C1
B4	E71	16	LTBL	3544884C1
B5	E71L-M	16	LTBL	3544884C1
B6	E71R-M	16	LTBL	3544884C1
B7	-	-	-	-
B8	-	-	-	-
B9	-	-	-	-
B10	-	-	-	-
B11	-	-	-	-
B12	E89LA-M	16	OR	3544884C1
C1	E89LR-M	16	OR	3544884C1
C2	E89RA-M	16	OR	3544884C1
C3	E89RR-M	16	OR	3544884C1
C4	E56	16	YL	3544884C1
C4	E56A	16	YL	3544884C1
C5	E58B	16	BN	3544884C1
C5	E58A	16	BN	3544884C1
C6	E126A	18	GY	3544884C1
C7	E89RR	16	OR	3544884C1
C8	E12B	18	LTBL	3544884C1
C8	E12C	18	LTBL	3544884C1
C9	E130B	18	GY	3544884C1
C9	E130D	16	GY	3544884C1
C9	E130C	18	GY	3544884C1
C10	E143V	18	DKBL	3544884C1
C11	E133A	18	LTGN	3544884C1
C12	E129A	18	GY	3544884C1
D1	E127B	18	OR	3544884C1
D1	E127A	18	OR	3544884C1
D2	E89LA	16	OR	3544884C1
D3	E11-GA	10	WH	3544878C1
D4	-	-	-	-
D5	-	-	-	-
D6	E131	16	DKBL	3544876C1
D7	E89LR	16	OR	3544884C1
D8	E89RA	16	OR	3544884C1

24.88. CONNECTOR COMPOSITES !%10400A, P. 49 | Figure 1270 CONNECTOR COMPOSITES !%10400A | printed page 1270

Connector 10400A: D A B 1 C 1
Table: BODY LOCK 3553650C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	-	-	-	-
A2*	B68	16	BN	3544884C1
A3	B11-GJ	10	WH	3544878C1
A4	B70A	16	RD	3544876C1
A5#	B70L	16	RD	3544876C1
A5%	B70L-M	16	RD	3544876C1
A6#	B70R	16	RD	3544876C1
A6%	B70R-M	16	RD	3544876C1
A7*	B68L	16	BN	3544884C1
A7%	B68L-M	16	BN	3544884C1
A8*	B68R	16	BN	3544884C1
A8%	B68R-M	16	BN	3544884C1
B1@	B56L	16	YL	3544884C1
B1^	B56L	16	OR	3544884C1
B1%	B56L-M	16	YL	3544884C1
B2^	B57A	16	OR	3544884C1
B2!	B57A	16	LTGN	3544884C1
B3^	B57R	16	OR	3544884C1
B3@	B57R	16	LTGN	3544884C1
B3!	B57R-M	16	LTGN	3544884C1
B4**	B71	16	LTBL	3544884C1
B4##	B71DA	16	LTBL	3544884C1
B4%%	B71C	16	OR	3544884C1
B4!!	B71C	16	LTBL	3544884C1
B5@@	B71L	16	LTBL	3544884C1
B5&&	B71L-M	16	LTBL	3544884C1
B6@@	B71R	16	LTBL	3544884C1
B6&&	B71R-M	16	LTBL	3544884C1
B7-B11	-	-	-	-
B12^^	B89E	16	OR	3544884C1
B12*#	B89LA-M	16	OR	3544884C1
B12*%	B89LRA	16	OR	3544884C1
C1^^	B89F	16	OR	3544884C1
C1*#	B89LR-M	16	OR	3544884C1
C1*&	B89LRR	16	OR	3544884C1
C2^^	B89J	16	OR	3544884C1
C2*#	B89RA-M	16	OR	3544884C1

24.89. CONNECTOR COMPOSITES !%10400B, P. 50 | Figure 1271 CONNECTOR COMPOSITES !%10400B | printed page 1271

Connector 10400B: D A B 1 C 1
Table: BODY LOCK 3553650C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	-	-	-	-
A2	B68	16	BN	3544884C1
A3	B11-GJ	10	WH	3544878C1
A4	B70A	16	RD	3544876C1
A5*	B70L	16	RD	3544876C1
A5&	B70L-M	16	RD	3544876C1
A6*	B70R	16	RD	3544876C1
A6&	B70R-M	16	RD	3544876C1
A7%	B68L	16	BN	3544884C1
A7&	B68L-M	16	BN	3544884C1
A8%	B68R	16	BN	3544884C1
A8&	B68R-M	16	BN	3544884C1
B1^	B56L	16	OR	3544884C1
B1!	B56L	16	YL	3544884C1
B1&	B56L-M	16	YL	3544884C1
B2^	B57A	16	OR	3544884C1
B2!	B57A	16	LTGN	3544884C1
B3^	B57R	16	OR	3544884C1
B3!	B57R	16	LTGN	3544884C1
B3&	B57R-M	16	LTGN	3544884C1
B4**	B71	16	LTBL	3544884C1
B4##	B71C	16	LTBL	3544884C1
B5%%	B71L	16	LTBL	3544884C1
B5&&	B71L	16	OR	3544884C1
B5^^	B71L-M	16	LTBL	3544884C1
B6%%	B71R	16	LTBL	3544884C1
B6&&	B71R	16	OR	3544884C1
B6^^	B71R-M	16	LTBL	3544884C1
B7-B11	-	-	-	-
B12@	B89E	16	OR	3544884C1
B12@@	B89LA-M	16	OR	3544884C1
B12*#	B89LRA	16	OR	3544884C1
C1@	B89F	16	OR	3544884C1
C1@@	B89LR-M	16	OR	3544884C1
C1*%	B89LRR	16	OR	3544884C1
C2@	B89J	16	OR	3544884C1

24.90. CONNECTOR COMPOSITES !%10401, P. 51 | Figure 1272 CONNECTOR COMPOSITES !%10401 | printed page 1272

Connector 10401: /ELECTRICAL PANEL) C B B2%* B3%* B3%#
Table: STABILIZER 3612514C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1^	E63A	16	DKBL	3544886C1
A1&	E63B	16	DKBL	3544886C1
A1@	E63	16	DKBL	3544886C1
A1@	E63H	16	DKBL	3544886C1
A1%	E63C	16	DKBL	3544886C1
A1#	E63W	16	DKBL	3544886C1
A2^	E63P	16	DKBL	3544886C1
A2%	E63AT	16	LTGN	3544886C1
A2&	E63R	16	DKBL	3544886C1
A2&	E63AH	16	DKBL	3544886C1
A2**	E63AT	16	LTBL	3544886C1
A2@	E63UA	16	DKBL	3544886C1
A2@	E63AU	16	DKBL	3544886C1
A2*%	E63B	16	DKBL	3544886C1
A2*%	E63A	16	DKBL	3544886C1
A2#	E63AT	16	DKBL	3544886C1
A2*#	E63U	16	DKBL	3544886C1
A3^	E11-GB1	12	WH	3544881C1
A4^	E124	12	LTGN	3544881C1
A5^	E117	18	GY	3544880C1
A6^	E122AM	16	GY	3544880C1
A7*&	E63K	16	DKBL	3544886C1
A7#*	E63BB	18	DKBL	3544886C1
A7*@	E63AN	18	DKBL	3544886C1
A7##	E63M	18	DKBL	3544886C1
A7#	E63AN	16	DKBL	3544886C1
A7&	E63L	16	DKBL	3544886C1
A8#%	E63AS	18	DKBL	3544886C1
A8#&	E63AT	16	DKBL	3544886C1
A8#@	E63AT	18	DKBL	3544886C1
A8*%	E63BA	18	DKBL	3544886C1
B1^	E63BC	18	DKBL	3544886C1

Legend: CHK DATE ; MJV0488 13SEP21 ADDED NOTES FOR FUSE B 96183U

Figure 1273 CONNECTOR COMPOSITES !%10401

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 24.91. CONNECTOR COMPOSITES !%10401, P. 52 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090675 NO. 95504E 05MAR20 / CHAPTER 24 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / LH BODY/ELECTRICAL PANEL !%(10401) (LOCATED AT JUNCTION LEFT BODY /ELECTRICAL PANEL) / B C CONNECTOR 3612511C1 BODY LOCK 3553652C1 LEVER LOCK 3553654C1 STABILIZER 3612514C1 / 8 7 6 5 4 3 2 1 / 12 12 11 11 10 10 9 9 8 8 7 7 6 6 5 5 4 4 3 3 2 2 1 1 / 8 7 6 5 4 3 2 1 / B C / CHART CONTINUED FROM / Figure 1273 / CONNECTOR COMPOSITES !%10401

24.92. CONNECTOR COMPOSITES ??10401A, P. 53 | Figure 1274 CONNECTOR COMPOSITES ??10401A | printed page 1274

Table: BODY LOCK 3553650C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	B63FB	16	DKBL	3544884C1
A2	B63R	16	DKBL	3544884C1
A3	B11-GG	12	WH	3544877C1
A4	B63RDA	16	DKBL	3544876C1
A5	B117F	18	GY	3544876C1
A6	-	-	-	-
A7*	B63X	18	DKBL	3544884C1
A7#	B63RCA	16	DKBL	3544884C1
A7%	B63RW	16	DKBL	3544884C1
A7&	B63F	16	DKBL	3544884C1
A7^	B63WB	16	DKBL	3544884C1
A7*%	B63WF	16	DKBL	3544884C1
A8	B63AD	18	DKBL	3544884C1
B1	B63AF	18	DKBL	3544884C1
B2	B120AC	18	LTGN	3544884C1
B3	B120AE	18	LTGN	3544884C1
B4	B120AB	18	LTGN	3544884C1
B5	B120	18	LTGN	3544884C1
B6	B76ALO	16	LTGN	3544884C1
B7	B76AHI	16	LTGN	3544884C1
B8	B76BLO	16	LTGN	3544884C1
B9	B76BHI	16	LTGN	3544884C1
B10	B133M	18	LTGN	3544884C1
B11	B133N	18	LTGN	3544884C1
B12	-	-	-	-
C1	B122TA	18	GY	3544884C1
C2	B122-GA	18	WH	3544884C1
C3	B122R	18	GY	3544884C1
C4	B122P	18	GY	3544884C1
C5@	B122N	16	BN	3544884C1
C5**	B122N	16	GY	3544884C1
C6	B122S	16	BN	3544884C1
C7##	B125D	18	GY	3544884C1
C7%%	B125F	18	GY	3544884C1
C7&&	B125A	18	GY	3544884C1
C7^^	B125	18	GY	3544884C1
C7!!	B125BC	18	GY	3544884C1

Legend: CHK DATE ; MJV0488 13SEP21 ADDED NOTES FOR FUSE B 96183U

24.93. CONNECTOR COMPOSITES ??10401A, P. 53A
Figure 1275 CONNECTOR COMPOSITES ??10401A

24.93. CONNECTOR COMPOSITES ??10401A, P. 53A | Figure 1275 CONNECTOR COMPOSITES ??10401A | printed page 1275

Table: BODY LOCK 3553650C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	B63F	16	DKBL	3544884C1
A2	B63R	16	DKBL	3544884C1
A3	B11-GG	12	WH	3544877C1
A4	B63RD	16	DKBL	3544876C1
A5	B117F	18	GY	3544876C1
A6	-	-	-	-
A7*	B63X	18	DKBL	3544884C1
A7#	B63RC	16	DKBL	3544884C1
A7%	B63RW	16	DKBL	3544884C1
A7&	B63E	16	DKBL	3544884C1
A7^	B63WB	16	DKBL	3544884C1
A8	B63AD	18	DKBL	3544884C1
B1	B63AF	18	DKBL	3544884C1
B2	B120AC	18	LTGN	3544884C1
B3	B120AE	18	LTGN	3544884C1
B4	B120AB	18	LTGN	3544884C1
B5	B120	18	LTGN	3544884C1
B6	B76ALO	16	LTGN	3544884C1
B7	B76AHI	16	LTGN	3544884C1
B8	B76BLO	16	LTGN	3544884C1
B9	B76BHI	16	LTGN	3544884C1
B10	B133M	18	LTGN	3544884C1
B11	B133N	18	LTGN	3544884C1
B12	-	-	-	-
C1	B122TA	18	GY	3544884C1
C2	B122-GA	18	WH	3544884C1
C3	B122R	18	GY	3544884C1
C4	B122P	18	GY	3544884C1
C5@	B122N	16	BN	3544884C1
C5**	B122N	16	GY	3544884C1
C6	B122S	16	BN	3544884C1
C7##	B125D	18	GY	3544884C1
C7%%	B125F	18	GY	3544884C1
C7&&	B125A	18	GY	3544884C1
C7^^	B125	18	GY	3544884C1
C7!!	B125B	18	GY	3544884C1

24.94. CONNECTOR COMPOSITES ??10401B, P. 54 | Figure 1276 CONNECTOR COMPOSITES ??10401B | printed page 1276

Table: BODY LOCK 3553650C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	B63FC	16	DKBL	3544884C1
A2	B63R	16	DKBL	3544884C1
A3	B11-GG	12	WH	3544877C1
A4	B63RDB	16	DKBL	3544876C1
A5	B117F	18	GY	3544876C1
A6	-	-	-	-
A7*	B63X	18	DKBL	3544884C1
A7#	B63RCB	16	DKBL	3544884C1
A7%	B63RW	16	DKBL	3544884C1
A7&	B63WB	16	DKBL	3544884C1
A8	B63AD	18	DKBL	3544884C1
B1	B63AF	18	DKBL	3544884C1
B2^	B120AC	18	LTGN	3544884C1
B2!	B120-GJ	16	LTGN	3544884C1
B3^	B120AE	18	LTGN	3544884C1
B3!	B120-GH	16	WH	3544884C1
B4^	B120AB	18	LTGN	3544884C1
B4!	B120AF	16	LTGN	3544884C1
B5^	B120	18	LTGN	3544884C1
B5!	B120AH	16	LTGN	3544884C1
B6	B76ALO	16	LTGN	3544884C1
B7	B76AHI	16	LTGN	3544884C1
B8	B76BLO	16	LTGN	3544884C1
B9	B76BHI	16	LTGN	3544884C1
B10	B133M	18	LTGN	3544884C1
B11	B133N	18	LTGN	3544884C1
B12	-	-	-	-
C1	B122TA	18	GY	3544884C1
C2	B122-GA	18	WH	3544884C1
C3	B122R	18	GY	3544884C1
C4	B122P	18	GY	3544884C1
C5!!	B122NA	16	BN	3544884C1
C5+	B122NB	16	GY	3544884C1
C6	B122S	16	BN	3544884C1
C7@	B125D	18	GY	3544884C1
C7**	B125F	18	GY	3544884C1
C7##	B125A	18	GY	3544884C1

24.95. CONNECTOR COMPOSITES ??10401B, P. 54A
Figure 1277 CONNECTOR COMPOSITES ??10401B

24.95. CONNECTOR COMPOSITES ??10401B, P. 54A | Figure 1277 CONNECTOR COMPOSITES ??10401B | printed page 1277

Table: BODY LOCK 3553650C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	B63F	16	DKBL	3544884C1
A2	B63R	16	DKBL	3544884C1
A3	B11-GG	12	WH	3544877C1
A4	B63RD	16	DKBL	3544876C1
A5	B117F	18	GY	3544876C1
A6	-	-	-	-
A7*	B63X	18	DKBL	3544884C1
A7#	B63RC	16	DKBL	3544884C1
A7%	B63RW	16	DKBL	3544884C1
A7&	B63WB	16	DKBL	3544884C1
A8	B63AD	18	DKBL	3544884C1
B1	B63AF	18	DKBL	3544884C1
B2^	B120AC	18	LTGN	3544884C1
B2!	B120-GJ	16	LTGN	3544884C1
B3^	B120AE	18	LTGN	3544884C1
B3!	B120-GH	16	WH	3544884C1
B4^	B120AB	18	LTGN	3544884C1
B4!	B120AF	16	LTGN	3544884C1
B5^	B120	18	LTGN	3544884C1
B5!	B120AH	16	LTGN	3544884C1
B6	B76ALO	16	LTGN	3544884C1
B7	B76AHI	16	LTGN	3544884C1
B8	B76BLO	16	LTGN	3544884C1
B9	B76BHI	16	LTGN	3544884C1
B10	B133M	18	LTGN	3544884C1
B11	B133N	18	LTGN	3544884C1
B12	-	-	-	-
C1	B122TA	18	GY	3544884C1
C2	B122-GA	18	WH	3544884C1
C3	B122R	18	GY	3544884C1
C4	B122P	18	GY	3544884C1
C5!!	B122N	16	BN	3544884C1
C5+	B122N	16	GY	3544884C1
C6	B122S	16	BN	3544884C1
C7@	B125D	18	GY	3544884C1
C7**	B125F	18	GY	3544884C1
C7##	B125A	18	GY	3544884C1

24.96. CONNECTOR COMPOSITES #10402, %%10405, P. 55 | Figure 1278 CONNECTOR COMPOSITES #10402, %%10405 | printed page 1278

Connector 10402: INSTRUMENT PANEL) K CAV A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B123P	18	LTGN	1661208C1
B%	B89N	18	OR	1661208C1
B*	B89NA	18	OR	1661208C1
C	-	-	-	-
D%	B123E	18	GY	1661208C1
D*	B123EM	18	GY	1661208C1
E#	B89L	18	OR	1661208C1
E*	B89LE	18	OR	1661208C1
F#	B123E	18	LTGN	1661208C1
G	-	-	-	-
H	-	-	-	-
J	-	-	-	-
K	-	-	-	-

Legend: # W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; % N/0508108 - NOT MTA FUSE BLOCK ; * W/0508108 - MTA FUSE BLOCK

Connector 10405: INTERCONNECT LH BODY TO REAR CAP C B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	D12C	18	LTBL	3544886C1
A2*	D63U	16	DKBL	3544886C1
A2#	D63UA	16	DKBL	3544886C1
A3-A6	-	-	-	-
A7	D63M	16	DKBL	3544886C1
A8	D63AU	16	DKBL	3544886C1
B1	D63BE	18	DKBL	3544886C1
B2	D120A	18	LTGN	3544886C1
B3	D120B	18	LTGN	3544886C1
B4	D120C	18	LTGN	3544886C1
B5	D120D	18	LTGN	3544886C1
B6	D130C	18	GY	3544886C1
B7**	D133B	16	LTGN	3544886C1
B7##	D133B	18	LTGN	3544886C1
B8	D81A	18	LTGN	3544886C1
B9	D81B	18	LTGN	3544886C1
B10	D122-GA	16	WH	3544886C1
B11&	D122-GB	16	WH	3544886C1
B11%	D122-GY	16	GY	3544886C1
B12	D122-GC	16	WH	3544886C1
C1	D122A	16	GY	3544886C1
C2	D122B	16	GY	3544886C1
C3	D122C	16	GY	3544886C1
C4	D122D	16	GY	3544886C1
C5-C6	-	-	-	-
C7	D86A(-)	16	LTGN	3544886C1
C8	D86B(+)	16	LTGN	3544886C1
C9	D63AS	18	DKBL	3544886C1
C10	D125B	16	GY	3544886C1
C11-C12	-	-	-	-
D1-D2	-	-	-	-
D3	D125A	16	GY	3544880C1
D4-D8	-	-	-	-

24.97. CONNECTOR COMPOSITES ??10405, P. 56 | Figure 1279 CONNECTOR COMPOSITES ??10405 | printed page 1279

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1^	E12C	18	LTBL	3544884C1
A1#	E12C	18	BK	3544884C1
A2*#	E63U	16	DKBL	3544884C1
A2%	E63U	16	LTGN	3544884C1
A2@	E63H	16	DKBL	3544884C1
A2@	E63UB	16	DKBL	3544884C1
A2&	E63U	16	WH	3544884C1
A2**	E63B	16	DKBL	3544884C1
A2**	E63C	16	DKBL	3544884C1
A3**	E124	12	LTGN	3544877C1
A4**	E122AN	16	GY	3544876C1
A5**	E122AP	16	GY	3544876C1
A6**	E122AM	16	GY	3544876C1
A7*#	E63M	16	DKBL	3544884C1
A7*%	E63AR	16	DKBL	3544884C1
A7*@	E63BB	18	DKBL	3544884C1
A7*&	E63M	18	DKBL	3544884C1
A7#*	E63AR	18	DKBL	3544884C1
A8@	E63AW	16	DKBL	3544884C1
A8*#	E63AU	16	DKBL	3544884C1
B1*#	E63BE	18	DKBL	3544884C1
B2*#	E120A	18	LTGN	3544884C1
B3*#	E120B	18	LTGN	3544884C1
B4*#	E120C	18	LTGN	3544884C1
B5*#	E120D	18	LTGN	3544884C1
B6*#	E130C	18	GY	3544884C1
B6@	E130C	16	GY	3544884C1
B7*#	E133B	18	LTGN	3544884C1
B8*#	E81A	18	LTGN	3544884C1
B9*#	E81B	18	LTGN	3544884C1
B10*#	E122-GA	16	WH	3544884C1
B11*#	E122-GY	16	WH	3544884C1
B11*#	E122-GB	16	WH	3544884C1
B12*#	E122-GC	16	WH	3544884C1
C1*#	E122A	16	GY	3544884C1
C2*#	E122B	16	GY	3544884C1
C3*#	E122C	16	GY	3544884C1
C4*#	E122D	16	GY	3544884C1
C5**	E77A	16	LTGN	3544884C1
C6**	E77B	16	LTGN	3544884C1
C7##	E86A(-)	16	LTGN	3544884C1
C7**	E86A	16	LTGN	3544884C1
C8##	E86B(+)	16	LTGN	3544884C1
C8**	E86B	16	LTGN	3544884C1
C9#*%	E63AS	18	DKBL	3544884C1
C9#%	E63BA	18	DKBL	3544884C1
C10*#	E125B	16	GY	3544884C1
C11**	E144	16	GY	3544884C1
C12**	E144A	16	GY	3544884C1
D1**	E144B	16	GY	3544884C1
D2**	E144-G	16	WH	3544884C1
D3*#	E125A	16	GY	3544876C1
D4**	E144F	16	GY	3544876C1
D5-D6	-	-	-	-
D7**	E144D	16	GY	3544884C1
D8**	E144E	16	GY	3544884C1

Legend: DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 05MAR20 AE08090675 056

24.98. CONNECTOR COMPOSITES %10406, P. 57 | Figure 1280 CONNECTOR COMPOSITES %10406 | printed page 1280

Connector 10406: INTERCONNECT LH BODY TO REAR CAP C B A6 A7* A7#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	D124	16	LTGN	3544886C1
A2#	D68	16	BN	3544886C1
A2*	D68B	16	BN	3544886C1
A3-A4	-	-	-	-
A5	D70L-M	16	RD	3544880C1
A6	D70	14	RD	3544881C1
A7*	D68A	16	BN	3544886C1
A7#	D68L-M	16	BN	3544886C1
A8#	D68C	16	BN	3544886C1
A8*	D68R-M	16	BN	3544886C1
A8#	D68B	16	BN	3544886C1
B1-B3	-	-	-	-
B4	D56-M	16	YL	3544886C1
B5	D57	16	LTGN	3544886C1
B6	D57-M	16	LTGN	3544886C1
B7@	D71	16	LTBL	3544886C1
B7&	D71D	16	LTBL	3544886C1
B8	D71L-M	16	LTBL	3544886C1
B9	D71R-M	16	LTBL	3544886C1
B10-B12	-	-	-	-
C1-C2	-	-	-	-
C3	D89LA-M	16	OR	3544886C1
C4	D89LR-M	16	OR	3544886C1
C5	D89RA-M	16	OR	3544886C1
C6	D89RR-M	16	OR	3544886C1
C7	D56	16	YL	3544886C1
C8	D58B	16	BN	3544886C1
C9	D126B	18	GY	3544886C1
C10	D117	18	GY	3544886C1
C11	D127A	18	OR	3544886C1
C12	D89LA	16	OR	3544886C1
D1	D89LR	16	OR	3544886C1
D2	D89RA	16	OR	3544886C1
D3	D11-G	10	WH	3544882C1
D4	D134A	16	OR	3544880C1
D5	D70R-M	16	RD	3544880C1
D6	-	-	-	-
D7	D89RR	16	OR	3544886C1
D8	-	-	-	-

24.99. CONNECTOR COMPOSITES %10406, P. 58 | Figure 1281 CONNECTOR COMPOSITES %10406 | printed page 1281

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1*	E124	16	LTGN	3544884C1
A2*	E68	16	BN	3544884C1
A3#	E74	12	LTGN	3544877C1
A4#	E74-G	12	WH	3544877C1
A5*	E70L-M	14	RD	3544877C1
A6*	E70	14	RD	3544877C1
A7*	E68L-M	16	BN	3544884C1
A8*	E68R-M	16	BN	3544884C1
B1#	E63BF	18	DKBL	3544884C1
B2#	E63-GY	18	WH	3544884C1
B3	-	-	-	-
B4*	E56-M	16	YL	3544884C1
B5*	E57	16	LTGN	3544884C1
B6*	E57-M	16	LTGN	3544884C1
B7*	E71	16	LTBL	3544884C1
B8*	E71L-M	16	LTBL	3544884C1
B9*	E71R-M	16	LTBL	3544884C1
B10#	E121	16	YL	3544884C1
B11#	E121A	18	YL	3544884C1
B12#	E41	18	TN	3544884C1
C1#	E41A	18	TN	3544884C1
C2#	E140	18	TN	3544884C1
C3*	E89LA-M	16	OR	3544884C1
C4*	E89LR-M	16	OR	3544884C1
C5*	E89RA-M	16	OR	3544884C1
C6*	E89RR-M	16	OR	3544884C1
C7*	E56	16	YL	3544884C1
C8*	E58B	16	BN	3544884C1
C9*	E126B	18	GY	3544884C1
C10*	E117	18	GY	3544884C1
C11*	E127A	18	OR	3544884C1
C12*	E89LA	16	OR	3544884C1
D1*	E89LR	16	OR	3544884C1
D2*	E89RA	16	OR	3544884C1
D3*	E11-G	10	WH	3544878C1
D4*	E134A	16	OR	3544876C1
D5*	E70R-M	14	RD	3544877C1
D6#	E141	16	LTGN	3544876C1
D7*	E89RR	16	OR	3544884C1
D8*	E71A	16	DKBL	3544884C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; * W/5 TO 13 LH WDO ; # W/12 TO 13 LH WDO

24.100. CONNECTOR COMPOSITES @10410, @10411, @10411A, @10412, @10412A, P. 59 | Figure 1282 CONNECTOR COMPOSITES @10410, @10411, @10411A, @10412, @10412A | printed page 1282

Connector 10410: A B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E56C	18	YL	1661261C1
B	E56-G	18	WH	1661261C1

Legend: @ W/5 TO 13 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10411: BODY LOCK 1661263C1 SIDE SIDE DIR DIR LT LT A B A* B# B*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	E56F	18	YL	1661261C1
A*	E56G	18	YL	1661261C1
B#	E56-GC	18	WH	1661261C1
B*	E56-GD	18	WH	1661261C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; # W/5 TO 9 & 11 TO 13 LH WDO ; * W/10 LH WDO

Connector 10411A: BODY LOCK 1661263C1 # * SIDE DIR LT A B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E56F	18	YL	1661261C1
B	E56-GC	18	WH	1661261C1

Legend: @ W/13 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10412: SIDE DIRECTIONAL LIGHT FORWARD REAR WHEEL POCKET A B A^ B# B%

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	E56E	18	YL	1661261C1
A%	E56F	18	YL	1661261C1
A^	KP56L	18	YL	1661261C1
B#	E56-GB	18	WH	1661261C1
B%	E56-GC	18	WH	1661261C1
B^	KP56-GH	18	WH	1661261C1

Legend: # W/9 TO 10 & 12 TO 13 LH WDO ; % W/11 LH WDO ; ^ W/6 LH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10412A: SIDE DIRECTIONAL LIGHT FORWARD RR WHEEL POCKET FE/CE B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E56E	18	YL	1661261C1
B	E56-GB	18	WH	1661261C1

24.101. CONNECTOR COMPOSITES @10412B, @10413, @10413A, @10413B, @10414, P. 60 | Figure 1283 CONNECTOR COMPOSITES @10412B, @10413, @10413A, @10413B, @10414 | printed page 1283

Connector 10412B: A B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E56E	18	YL	1661261C1
B	E56-GB	18	WH	1661261C1

Legend: @ W/13 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10413: CAV SIDE DIRECTIONAL LIGHT A* OVER REAR WHEEL POCKET A B * W/9 TO B#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	E56H	18	YL	1661261C1
A#	E56M	18	YL	1661261C1
B*	E56-GD	18	WH	1661261C1
B#	E56-GJ	18	WH	1661261C1

Legend: * W/9 TO 13 LH WDO ; # W/6 LH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10413A: BLOCK CAV SIDE DIR LT OVER RR WHL A* A B B* B#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	E56M	18	YL	1661261C1
A#	E56H	18	YL	1661261C1
B*	E56-GJ	18	WH	1661261C1
B#	E56-GD	18	WH	1661261C1

Legend: # W/9 TO 13 LH WDO ; * W/6 LH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10413B: @ SIDE DIR LT OVER RR WHL - CE A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E56H	18	YL	1661261C1
B	E56-GD	18	WH	1661261C1

Legend: @ W/13 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10414: SIDE DIR LT AFTER REAR WHL PKT A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E56D	18	YL	1661261C1
B	E56-GA	18	WH	1661261C1

24.102. CONNECTOR COMPOSITES @10416, @10417, @10417A, @10417B, @10418, P. 61 | Figure 1284 CONNECTOR COMPOSITES @10416, @10417, @10417A, @10417B, @10418 | printed page 1284

Connector 10416: B A B C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E56J	18	YL	1661261C1
B	E58D	18	BN	1661261C1
C	E56-GE	18	WH	1661261C1

Legend: @ W/5 TO 13 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10417: SIDE MARKER LIGHT B A C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E56K	18	YL	1661261C1
B	E58E	18	BN	1661261C1
C	E56-GF	18	WH	1661261C1

Connector 10417A: BODY LOCK 1661890C1 SIDE MARKER LIGHT B A B C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E56K	18	YL	1661261C1
B	E58E	18	BN	1661261C1
C	E56-GF	18	WH	1661261C1

Legend: @ W/8,12,13 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10417B: BODY LOCK 1661890C1 SIDE MARKER LIGHT A A E56L B E58F C E56-GG

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E56L	18	YL	1661261C1
B	E58F	18	BN	1661261C1
C	E56-GG	18	WH	1661261C1

Connector 10418: INTERMEDIATE MARKER LT CAV A A# E58D B* E58-GA B# E58-GB

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	E58C	18	BN	1661261C1
A#	E58D	18	BN	1661261C1
B*	E58-GA	18	WH	1661261C1
B#	E58-GB	18	WH	1661261C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; * W/5-9 & 11-13 LH WDO ; # W/10 LH WDO

24.103. CONNECTOR COMPOSITES @10418A, ?10419, P. 62 | Figure 1285 CONNECTOR COMPOSITES @10418A, ?10419 | printed page 1285

Connector 10418A: INTERMEDIATE MARKER LT CAV A B E58-GA

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E58C	18	BN	1661261C1
B	E58-GA	18	WH	1661261C1

Connector 10418A: INTERMEDIATE MARKER LT CAV A B E58-GA

CAV	CIRCUIT	GA	COLOR	TERMINAL
A^	E11-GA	10	WH	1661211C1
B^	E56-G	18	WH	1661208C1
B^	E56-GE	18	WH	1661208C1
B#	E56-GF	18	WH	1661208C1
B&	E58-GH	18	WH	1661208C1
B%	E58-GB	18	WH	1661208C1
C@	E58-GA	18	WH	1661208C1
C**	E58-GB	18	WH	1661208C1
D*#	E56-GJ	18	WH	1661208C1
D*%	E56-GH	18	WH	1661208C1
D#*	E56-GG	18	WH	1661208C1
D#%	E56-GD	18	WH	1661208C1
D#&	E56-GC	18	WH	1661208C1
D*@	E56-GF	18	WH	1661208C1
D##	E56-GB	18	WH	1661208C1
D#*	E56-GA	18	WH	1661208C1
E#@	E126-GA	18	WH	1661208C1
E%*	E126-GA	18	WH	1661209C1
E%*	E126-GD	18	WH	1661209C1
F^	E143-GA	18	WH	1661208C1
G^	E130-GA	18	WH	1661208C1
G%%	E141-G	16	WH	1661209C1
H^	E143-GV	18	WH	1661208C1
J^	E129-GA	18	WH	1661208C1
K^	E11-GC	12	WH	3566715C1
	FOR	VEHICLE		W/0508108
	AND N/0508108		- NOT	MTA
	LH WDO			

Legend: # W/5 LH WDOSPLICE DIR/CLEAR LT ; & W/6-12 LH WDO ; % W/13 LH WDO ; @ W/6-9 AND 11-13 LH WDO ; ** W/10 LH WDO ; *# W/5-9 AND 11 LH WDO ; *% W/5-9 LH WDO ; *@ W/6-13 LH WDO ; #* W/8 LH WDO

24.104. CONNECTOR COMPOSITES ?10420, ?10421, P. 63 | Figure 1286 CONNECTOR COMPOSITES ?10420, ?10421 | printed page 1286

CAV	CIRCUIT	GA	COLOR	TERMINAL
A^	E126A	18	GY	3534164C1
B^	E126B	18	GY	3534164C1
C^	E126C	16	GY	3534165C1
C#	E126D	16	GY	3534165C1
C#	E126E	16	GY	3534165C1
C#	E126F	16	GY	3534165C1
D#	E126H	16	GY	3534165C1
D%	E126J	16	GY	3534165C1
D&	E126K	16	GY	3534165C1
D@	E126L	16	GY	3534165C1
D**	E126D	16	GY	3534165C1
E*#	E126M	16	GY	3534165C1
E*%	E126N	16	GY	3534165C1
E*&	E126P	16	GY	3534165C1
E**	E126E	16	GY	3534165C1
E*@	E126R	16	GY	3534165C1
F**	E126C	18	GY	3534164C1
F*@	E126T	16	GY	3534165C1
G^	E126-GA	18	WH	3534164C1
H^	E126-GB	16	WH	3534165C1
H#	E126-GC	16	WH	3534165C1
H#	E126-GD	16	WH	3534165C1
H#	E126-GE	16	WH	3534165C1
J#	E126-GF	16	WH	3534165C1
J%	E126-GH	16	WH	3534165C1
J&	E126-GJ	16	WH	3534165C1
J@	E126-GK	16	WH	3534165C1
J**	E126-GC	16	WH	3534165C1
K*#	E126-GL	16	WH	3534165C1
K*%	E126-GM	16	WH	3534165C1
K*&	E126-GN	16	WH	3534165C1
K**	E126-GD	16	WH	3534165C1
K*@	E126-GP	16	WH	3534165C1
L*@	E126-GR	16	WH	3534165C1
M	-	-	-	-
	LH WDO			

Legend: # W/5-11 AND 13 LH WDO ; % W/6-11 AND 13 LH WDO ; & W/7-11 AND 13 LH WDO ; @ W/8-11 AND 13 LH WDO ; ** W/12 LH WDO ; *# W/9-11 AND 13 LH WDO ; *% W/10-11 AND 13 LH WDO ; *& W/11 AND 13 LH WDO ; *@ W/13 LH WDO

Table: BODY LOCK 3700749C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A^	E56A	16	YL	3534165C1
B^	E56	16	YL	3534165C1
C^	E56C	18	YL	3534164C1
C^	E56J	18	YL	3534164C1
C#	E58H	18	BN	3534164C1
D^	E56D	18	YL	3534164C1
D%	E56M	18	YL	3534164C1
D&	E56L	18	YL	3534164C1
D^	E56K	18	YL	3534164C1
D#	E58J	18	BN	3534164C1
D@	E56A	18	YL	3534164C1
D**	E56E	18	YL	3534164C1
D*#	E56H	18	YL	3534164C1
D*%	E56F	18	YL	3534164C1
E*&	E56F	18	YL	3534164C1
E*@	E56G	18	YL	3534164C1
F%*	E58E	18	BN	3534164C1
G^	E58A	16	BN	3534165C1
H^	E58B	16	BN	3534165C1
J*&	E58C	18	BN	3534164C1
J*@	E58D	18	BN	3534164C1
K^	E58D	18	BN	3534164C1
K#&	E58H	18	BN	3534164C1
K##	E58F	18	BN	3534164C1
L#%	E58F	18	BN	3534164C1
L^	E58E	18	BN	3534164C1
L#&	E58J	18	BN	3534164C1
L##	E58H	18	BN	3534164C1
M^	E143A	18	DKBL	3534164C1
	LH WDO			

Legend: # W/7-8 LH WDO ; % W/5-9 AND 11 LH WDO ; & W/5-9 LH WDO ; @ W/8 LH WDO ; ** W/9-10 AND 12-13 LH WDO ; *# W/9-13 LH WDO ; *% W/11 LH WDO ; *& W/5-9 AND 11-13 LH WDO ; *@ W/10 LH WDO

Table: BODY LOCK 3700749C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A^	E143A	18	DKBL	3534164C1
B	E143C	18	DKBL	3534164C1
C^	E143B	18	DKBL	3534164C1
C#&	E143C	18	DKBL	3534164C1
C^	E143D	18	DKBL	3534164C1
C^	E143E	18	DKBL	3534164C1
D^	E143F	18	DKBL	3534164C1
D@	E143H	18	DKBL	3534164C1
D#	E143J	18	DKBL	3534164C1
D%	E143K	18	DKBL	3534164C1
E&	E143L	18	DKBL	3534164C1
E*	E143M	18	DKBL	3534164C1
E@@	E143N	18	DKBL	3534164C1
E##	E143P	18	DKBL	3534164C1
F&&	E143R	18	DKBL	3534164C1
G^	E143-GA	18	WH	3534164C1
H^	E143-GB	18	WH	3534164C1
H#&	E143-GC	18	WH	3534164C1
H^	E143-GD	18	WH	3534164C1
H^	E143-GE	18	WH	3534164C1
J^	E143-GF	18	WH	3534164C1
J@	E143-GH	18	WH	3534164C1
J#	E143-GJ	18	WH	3534164C1
J%	E143-GK	18	WH	3534164C1
K&	E143-GL	18	WH	3534164C1
K*	E143-GM	18	WH	3534164C1
K@@	E143-GN	18	WH	3534164C1
K##	E143-GP	18	WH	3534164C1
L*@	E143-GR	18	WH	3534164C1
TO	13 LH WDO			

Legend: @ W/6 TO 13 LH WDO ; # W/7 TO 13 LH WDO ; % W/8 TO 13 LH WDO ; & W/9 TO 13 LH WDO ; * W/10 TO 13 LH WDO ; @@ W/11 TO 13 LH WDO ; ## W/12,13 LH WDO ; && W/13 LH WDO ; #& W/5 TO 8 & 10 TO 13 LH WDO

Table: BODY LOCK 3543731C1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A^	E133A	18	LTGN	3535303C1	3535424C1
B^	E133B	18	LTGN	3535303C1	3535424C1
C^	E133C	18	LTGN	3535303C1	3535424C1
D*	E133N	18	LTGN	3535303C1	3535424C1
D#	E133P	18	LTGN	3535303C1	3535424C1
D%	E133R	18	LTGN	3535303C1	3535424C1
D&	E133T	18	LTGN	3535303C1	3535424C1
D^	E133D	18	LTGN	3535303C1	3535424C1
D^	E133E	18	LTGN	3535303C1	3535424C1
D^	E133F	18	LTGN	3535303C1	3535424C1
D^	E133H	18	LTGN	3535303C1	3535424C1
E^	E133J	18	LTGN	3535303C1	3535424C1
E**	E133K	18	LTGN	3535303C1	3535424C1
E##	E133L	18	LTGN	3535303C1	3535424C1
E@	E133M	18	LTGN	3535303C1	3535424C1
E&&	E133U	18	LTGN	3535303C1	3535424C1
F	PLUG	-	-	3535425C1	-
^	W/5 TO 13	LH	WDO		

Legend: * W/9 TO 13 LH WDO ; # W/10 TO 13 LH WDO ; % W/11 TO 13 LH WDO ; & W/12,13 LH WDO ; ** W/6 TO 13 LH WDO ; ## W/7 TO 13 LH WDO ; @ W/8 TO 13 LH WDO ; && W/13 LH WDO ; ? W/COMMON FOR VEHICLE W/0508108 - MTA

24.106. CONNECTOR COMPOSITES @10424, @10425, @10426, @10427, @10428, P. 65 | Figure 1288 CONNECTOR COMPOSITES @10424, @10425, @10426, @10427, @10428 | printed page 1288

Connector 10424: KOUT WDO SECT 1 A B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E126C	16	GY	1661261C1
B	E126-GB	16	WH	1661261C1

Legend: @ W/5 TO 13 LH WDOW/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10425: CONNECTOR 1661259C1 BODY LOCK 1661263C1 KOUT WDO SECT 2 A B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E126D	16	GY	1661261C1
B	E126-GC	16	WH	1661261C1

Legend: @ W/5 TO 13 LH WDOW/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10426: KOUT WDO SECT 3 A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E126E	16	GY	1661261C1
B	E126-GD	16	WH	1661261C1

Legend: @ W/5 TO 13 LH WDOW/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10427: KOUT WDO SECT 4 A B CAV A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E126F	16	GY	1661261C1
B	E126-GE	16	WH	1661261C1

Legend: @ W/5 TO 13 LH WDOW/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10428: KOUT WDO SECT 5 A B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E126H	16	GY	1661261C1
B	E126-GF	16	WH	1661261C1

Legend: @ W/5 TO 13 LH WDOW/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

24.107. CONNECTOR COMPOSITES @10429, @10430, @10431, @10432, @10433, P. 66
Figure 1289 CONNECTOR COMPOSITES @10429, @10430, @10431, @10432, @10433

24.107. CONNECTOR COMPOSITES @10429, @10430, @10431, @10432, @10433, P. 66 | Figure 1289 CONNECTOR COMPOSITES @10429, @10430, @10431, @10432, @10433 | printed page 1289

Connector 10429: KOUT WDO SECT 6 A B B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E126J	16	GY	1661261C1
B	E126-GH	16	WH	1661261C1

Legend: @ W/6 TO 13 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10430: BODY LOCK 1661263C1 KOUT WDO SECT 7 A B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E126K	16	GY	1661261C1
B	E126-GJ	16	WH	1661261C1

Legend: @ W/7 TO 13 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10431: KOUT WDO SECT 8 CAV A B B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E126L	16	GY	1661261C1
B	E126-GK	16	WH	1661261C1

Legend: @ W/8 TO 13 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10432: KOUT WDO SECT 9 A B CAV A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E126M	16	GY	1661261C1
B	E126-GL	16	WH	1661261C1

Legend: @ W/9 TO 13 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10433: KOUT WDO SECT 10 A B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E126N	16	GY	1661261C1
B	E126-GM	16	WH	1661261C1

24.108. CONNECTOR COMPOSITES @10434, @10435, @10436, @10439, @10440, P. 67
Figure 1290 CONNECTOR COMPOSITES @10434, @10435, @10436, @10439, @10440

24.108. CONNECTOR COMPOSITES @10434, @10435, @10436, @10439, @10440, P. 67 | Figure 1290 CONNECTOR COMPOSITES @10434, @10435, @10436, @10439, @10440 | printed page 1290

Connector 10434: KOUT WDO SECT 11 A B A E126P B E126-GN

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E126P	16	GY	1661261C1
B	E126-GN	16	WH	1661261C1

Legend: @ W/11 TO 13 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10435: CONNECTOR 1661259C1 BODY LOCK 1661263C1 KOUT WDO SECT 12 A B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E126R	16	GY	1661261C1
B	E126-GP	16	WH	1661261C1

Connector 10436: KOUT WDO SECT 13 A B CAV A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E126T	16	GY	1661261C1
B	E126-GR	16	WH	1661261C1

Legend: @ W/13 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10439: EMER EXIT LT SECT 1 A B CAV A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143B	18	DKBL	1661261C1
B	E143-GB	18	WH	1661261C1

Connector 10440: EMER EXIT LT SECT 2 A B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143C	18	DKBL	1661261C1
B	E143-GC	18	WH	1661261C1

CONNECTOR COMPOSITE (10441-10740) (CHAPTER 25) | Figure 1291 CONNECTOR COMPOSITES @10441, @10442, @10443, @10444, @10445 | printed page 1291

Connector 10441: A B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143D	18	DKBL	1661261C1
B	E143-GD	18	WH	1661261C1

Legend: @ W/5 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10442: CONNECTOR 1661259C1 N/0508108 BODY LOCK 1661263C1 EMER EXIT LT SECT 4 A B A E143E B E143-GE

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143E	18	DKBL	1661261C1
B	E143-GE	18	WH	1661261C1

Legend: @ W/5 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10443: BODY LOCK 1661263C1 EMER EXIT LT SECT 5 A B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143F	18	DKBL	1661261C1
B	E143-GF	18	WH	1661261C1

Legend: @ W/5 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10444: BODY LOCK 1661263C1 EMER EXIT LT SECT 6 A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143H	18	DKBL	1661261C1
B	E143-GH	18	WH	1661261C1

Connector 10444: BODY LOCK 1661263C1 NC BUZZ DIODE CAV PANEL HARNESS) A# A* B#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A%	B12J	18	LTBL	0333736C1
A#	B12JA	18	LTBL	0333736C1
A*	B12JAB	18	LT BL	0333736C1
B#	B12JA	18	LTBL	0333732C1
B*	B12JAB	18	LT BL	0333732C1
C#	B12JB	18	LTBL	0333732C1
C*	B12JAC	18	LT BL	0333732C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; # W/0508108 - MTA FUSE BLOCK ; * N/0508108 - NOT MTA FUSE BLOCK

Connector 10445: CONNECTOR 0598839C1 # * 3 RED LIGHT SECTION 7 A B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143J	18	DKBL	1661261C1
B	E143-GJ	18	WH	1661261C1

Legend: @ W/7 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK ; REV REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 25FEB20 AE08090676 001

25.2. CONNECTOR COMPOSITES @10446, @10447, @10448, @10449, @10450,
Figure 1292 CONNECTOR COMPOSITES @10446, @10447, @10448, @10449, @10450, @10451

25.2. CONNECTOR COMPOSITES @10446, @10447, @10448, @10449, @10450, | Figure 1292 CONNECTOR COMPOSITES @10446, @10447, @10448, @10449, @10450, @10451 | printed page 1292

Connector 10446: A B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143K	18	DKBL	1661261C1
B	E143-GK	18	WH	1661261C1

Legend: @ W/8 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10447: CONNECTOR 1661259C1 BODY LOCK 1661263C1 EMER EXIT LT SECT 9 A B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143L	18	DKBL	1661261C1
B	E143-GL	18	WH	1661261C1

Legend: @ W/9 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10448: BODY LOCK 1661263C1 EMER EXIT LT SECT 10 A B A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143M	18	DKBL	1661261C1
B	E143-GM	18	WH	1661261C1

Legend: @ W/10 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10449: BODY LOCK 1661263C1 EMER EXIT LT SECT 11 A B CAV CIRCUIT A E143N B E143-GN

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143N	18	DKBL	1661261C1
B	E143-GN	18	WH	1661261C1

Legend: @ W/11 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10450: EMERGENCY EXIT LIGHT SECT 12 A B B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143P	18	DKBL	1661261C1
B	E143-GP	18	WH	1661261C1

Legend: @ W/12 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10451: BODY LOCK 1661263C1 EMERGENCY EXIT LIGHT SECT 13 B A A E143R B E143-GR

Table: 13

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143R	18	DKBL	1661261C1
B	E143-GR	18	WH	1661261C1

25.3. CONNECTOR COMPOSITES @10454A, @10454B, @10454C, @10454D,
Figure 1293 CONNECTOR COMPOSITES @10454A, @10454B, @10454C, @10454D, @10454E

25.3. CONNECTOR COMPOSITES @10454A, @10454B, @10454C, @10454D, | Figure 1293 CONNECTOR COMPOSITES @10454A, @10454B, @10454C, @10454D, @10454E | printed page 1293

Connector 10454A: B A B C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E130D	18	GY	1661261C1
B	E130-GA	18	WH	1661261C1
C	E133C	18	LTGN	1661261C1

Connector 10454B: SIDE EMERGENCY DOOR CAV B A B C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E130D	18	GY	1661261C1
B	E130-GA	18	WH	1661261C1
C	E133C	18	LTGN	1661261C1

Legend: @ W/6 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10454C: BODY LOCK 1661890C1 SIDE EMERGENCY DOOR B A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E130D	18	GY	1661261C1
B	E130-GA	18	WH	1661261C1
C	E133C	18	LTGN	1661261C1

Legend: @ W/8 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10454D: BODY LOCK 1661890C1 SIDE EMERGENCY DOOR B A CAV A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E130D	18	GY	1661261C1
B	E130-GA	18	WH	1661261C1
C	E133C	18	LTGN	1661261C1

Legend: @ W/9 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10454E: SIDE EMERGENCY DOOR B C A B C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E130D	18	GY	1661261C1
B	E130-GA	18	WH	1661261C1
C	E133C	18	LTGN	1661261C1

25.4. CONNECTOR COMPOSITES @10454F, @10454G, @10454H, @10455A,
Figure 1294 CONNECTOR COMPOSITES @10454F, @10454G, @10454H, @10455A, @10455B

25.4. CONNECTOR COMPOSITES @10454F, @10454G, @10454H, @10455A, | Figure 1294 CONNECTOR COMPOSITES @10454F, @10454G, @10454H, @10455A, @10455B | printed page 1294

Connector 10454F: B A B C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E130D	18	GY	1661261C1
B	E130-GA	18	WH	1661261C1
C	E133C	18	LTGN	1661261C1

Legend: @ W/12 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10454G: SIDE EMERGENCY DOOR CAV B A B C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E130D	18	GY	1661261C1
B	E130-GA	18	WH	1661261C1
C	E133C	18	LTGN	1661261C1

Legend: @ W/12 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10454H: BODY LOCK 1661890C1 SIDE EMERGENCY DOOR B A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E130D	18	GY	1661261C1
B	E130-GA	18	WH	1661261C1
C	E133C	18	LTGN	1661261C1

Legend: @ W/13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10455A: SIDE EMERGENCY DOOR ALARM CAV A A* B& B!

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	E12D	18	BK	1661261C1
A*	E12D	18	LTBL	1661261C1
B&	E130E	18	GY	1661261C1
B!	E130D	18	GY	1661261C1

Legend: * W/5-12 LH WDO ; # W/13 LH WDO ; & W/5-11 & 13 LH WDO ; ! W/12 LH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10455B: SIDE EMERGENCY DOOR ALARM A B A# B*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A&	E12D	18	LTBL	1661261C1
A#	E12D	18	BK	1661261C1
B*	E130E	18	GY	1661261C1

25.5. CONNECTOR COMPOSITES @10455C, @10455D, @10455E, @10455F, P. 5 | Figure 1295 CONNECTOR COMPOSITES @10455C, @10455D, @10455E, @10455F | printed page 1295

Connector 10455C: SIDE EMERGENCY DOOR ALARM CAV A A# B&

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	E12D	18	LTBL	1661261C1
A#	E12D	18	BK	1661261C1
B&	E130E	18	GY	1661261C1

Legend: * W/8-12 LH WDO ; # W/13 LH WDO ; & W/8-13 LH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10455D: SIDE EMERGENCY DOOR ALARM CAV A A# B&

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	E12D	18	LTBL	1661261C1
A#	E12D	18	BK	1661261C1
B&	E130E	18	GY	1661261C1

Legend: * W/9-12 LH WDO ; # W/13 LH WDO ; & W/9-13 LH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10455E: AND SIDE EMERGENCY DOOR ALARM A CAV A& A#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A&	E12D	18	LTBL	1661261C1
A#	E12D	18	BK	1661261C1
B*	E130E	18	GY	1661261C1

Legend: * W/12-13 LH WDO ; # W/13 LH WDO ; & W/12 LH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10455F: SIDE EMERGENCY DOOR ALARM A B A# B&

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	E12D	18	BK	1661261C1
A#	E12D	18	LTBL	1661261C1
B&	E130E	18	GY	1661261C1

Legend: * W/13 LH WDO ; # W/12 LH WDO ; & W/12 AND 13 LH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

25.6. CONNECTOR COMPOSITES @10455G, @10455H, @10456, @10456A, @10456B, P. 6 | Figure 1296 CONNECTOR COMPOSITES @10455G, @10455H, @10456, @10456A, @10456B | printed page 1296

Connector 10455G: A A# E12D B& E130E

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	E12D	18	BK	1661261C1
A#	E12D	18	LTBL	1661261C1
B&	E130E	18	GY	1661261C1

Legend: * W/13 LH WDO ; # W/12 LH WDO ; & W/12 AND 13 LH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10455H: BODY LOCK 1661263C1 AND SIDE EMERGENCY DOOR ALARM A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E12D	18	BK	1661261C1
B	E130E	18	GY	1661261C1

Legend: @ W/13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10456: SIDE EMERGENCY DOOR LIGHT A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143V	18	DKBL	1661261C1
B	E143-GV	18	WH	1661261C1

Legend: @ W/5 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10456A: SIDE EMERGENCY DOOR LIGHT A CAV A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143V	18	DKBL	1661261C1
B	E143-GV	18	WH	1661261C1

Connector 10456B: SIDE EMERGENCY DOOR LIGHT A B B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143V	18	DKBL	1661261C1
B	E143-GV	18	WH	1661261C1

Legend: @ W/7-13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

25.7. CONNECTOR COMPOSITES @10456C, @10456D, @10456E, @10456F, | Figure 1297 CONNECTOR COMPOSITES @10456C, @10456D, @10456E, @10456F, @10456G | printed page 1297

Connector 10456C: A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143V	18	DKBL	1661261C1
B	E143-GV	18	WH	1661261C1

Legend: @ W/8-13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10456D: BODY LOCK 1661263C1 SIDE EMERGENCY DOOR LIGHT A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143V	18	DKBL	1661261C1
B	E143-GV	18	WH	1661261C1

Legend: @ W/9-13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10456E: SIDE EMERGENCY DOOR LIGHT A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143V	18	DKBL	1661261C1
B	E143-GV	18	WH	1661261C1

Legend: @ W/12-13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10456F: SIDE EMERGENCY DOOR LIGHT A CAV A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143V	18	DKBL	1661261C1
B	E143-GV	18	WH	1661261C1

Legend: @ W/12-13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10456G: SIDE EMERGENCY DOOR LIGHT CAV @ W/12-13 A B B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143V	18	DKBL	1661261C1
B	E143-GV	18	WH	1661261C1

Legend: @ W/12-13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

25.8. CONNECTOR COMPOSITES @10456H, @10457, @10458, @10459, P. 8 | Figure 1298 CONNECTOR COMPOSITES @10456H, @10457, @10458, @10459 | printed page 1298

Connector 10456H: A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E143V	18	DKBL	1661261C1
B	E143-GV	18	WH	1661261C1

Legend: @ W/13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10457: BODY LOCK 1661263C1 ROOF HATCH SECT 1 5 4 6 1 E129B 2 E129-GB 3 E133D

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	E129B	18	GY	1661262C1
2	E129-GB	18	WH	1661262C1
3	E133D	18	LTGN	1661262C1
4	E76A	16	LTGN	1661262C1
5	E76B	16	LTGN	1661262C1
6	E76-GA	16	WH	1661262C1

Legend: @ W/5 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10458: ROOF HATCH SECT 2 5 4 6 1 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	E129C	18	GY	1661262C1
2	E129-GC	18	WH	1661262C1
3	E133E	18	LTGN	1661262C1
4	E76A	16	LTGN	1661262C1
5	E76B	16	LTGN	1661262C1
6	E76-GA	16	WH	1661262C1

Legend: @ W/5 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10459: ROOF HATCH SECT 3 5 4 6 2 3 4#

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	E129D	18	GY	1661262C1
2	E129-GD	18	WH	1661262C1
3	E133F	18	LTGN	1661262C1
4#	E76A	16	LTGN	1661262C1
4!	E76C	16	LTGN	1661262C1
5	E76B	16	LTGN	1661262C1
5!	E76D	16	LTGN	1661262C1
6	E76-GA	16	WH	1661262C1
6!	E76-GB	16	WH	1661262C1

Legend: ! W/12 LH WDO ; # W/5 - 11 & 13 LH WDO ; @ W/5 - 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

25.9. CONNECTOR COMPOSITES @10460, @10461, @10462, P. 9 | Figure 1299 CONNECTOR COMPOSITES @10460, @10461, @10462 | printed page 1299

Connector 10460: ROOF HATCH SECT 4 5 4 6 4 4 5

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	E129E	18	GY	1661262C1
2	E129-GE	18	WH	1661262C1
3	E133H	18	LTGN	1661262C1
4	E76A	16	LTGN	1661262C1
4	E76C	16	LTGN	1661262C1
5	E76B	16	LTGN	1661262C1
5	E76D	16	LTGN	1661262C1
6	E76-GA	16	WH	1661262C1
6	E76-GB	16	WH	1661262C1

Legend: @ W/5 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10461: ROOF HATCH SECT 5 1 E129F 2 E129-GF 3 E133J

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	E129F	18	GY	1661262C1
2	E129-GF	18	WH	1661262C1
3	E133J	18	LTGN	1661262C1
4	E76A	16	LTGN	1661262C1
4	E76C	16	LTGN	1661262C1
5	E76B	16	LTGN	1661262C1
5	E76D	16	LTGN	1661262C1
6	E76-GA	16	WH	1661262C1
6	E76-GB	16	WH	1661262C1

Legend: @ W/5 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10462: ROOF HATCH SECT 8 CAV 5 4 6 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	E129H	18	GY	1661262C1
2	E129-GH	18	WH	1661262C1
3	E133K	18	LTGN	1661262C1
4	E76A	16	LTGN	1661262C1
4	E76C	16	LTGN	1661262C1
5	E76B	16	LTGN	1661262C1
5	E76D	16	LTGN	1661262C1
6	E76-GA	16	WH	1661262C1
6	E76-GB	16	WH	1661262C1

Legend: @ W/5 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

25.10. CONNECTOR COMPOSITES @10463, @10464, @10465, P. 10 | Figure 1300 CONNECTOR COMPOSITES @10463, @10464, @10465 | printed page 1300

Connector 10463: CAV 1 2 ROOF HATCH SECT 7 3 5 4 6 4 5

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	E129J	18	GY	1661262C1
2	E129-GJ	18	WH	1661262C1
3	E133L	18	LTGN	1661262C1
4	E76A	16	LTGN	1661262C1
4	E76C	16	LTGN	1661262C1
5	E76B	16	LTGN	1661262C1
5	E76D	16	LTGN	1661262C1
6	E76-GA	16	WH	1661262C1
6	E76-GB	16	WH	1661262C1

Legend: @ W/7 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10464: ROOF HATCH SECT 8 1 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	E129K	18	GY	1661262C1
2	E129-GK	18	WH	1661262C1
3	E133M	18	LTGN	1661262C1
4	E76A	16	LTGN	1661262C1
4	E76C	16	LTGN	1661262C1
5	E76B	16	LTGN	1661262C1
5	E76D	16	LTGN	1661262C1
6	E76-GA	16	WH	1661262C1
6	E76-GB	16	WH	1661262C1

Legend: @ W/8 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10465: ROOF HATCH SECT 9 CAV 5 4 6 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	E129L	18	GY	1661262C1
2	E129-GL	18	WH	1661262C1
3	E133N	18	LTGN	1661262C1
4	E76C	16	LTGN	1661262C1
5	E76D	16	LTGN	1661262C1
6	E76-GB	16	WH	1661262C1

Legend: @ W/9 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

25.11. CONNECTOR COMPOSITES @10466, @10467, @10468, @10469, P. 11 | Figure 1301 CONNECTOR COMPOSITES @10466, @10467, @10468, @10469 | printed page 1301

Connector 10466: ROOF HATCH SECT 10 5 4 6

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	E129M	18	GY	1661262C1
2	E129-GM	18	WH	1661262C1
3	E133P	18	LTGN	1661262C1
4	E76C	16	LTGN	1661262C1
5	E76D	16	LTGN	1661262C1
6	E76-GB	16	WH	1661262C1

Legend: @ W/10 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10467: ROOF HATCH SECT 11 5 4 6

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	E129N	18	GY	1661262C1
2	E129-GN	18	WH	1661262C1
3	E133R	18	LTGN	1661262C1
4	E76C	16	LTGN	1661262C1
5	E76D	16	LTGN	1661262C1
6	E76-GB	16	WH	1661262C1

Legend: @ W/11 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10468: ROOF HATCH SECT 12 5 4 6

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	E129P	18	GY	1661262C1
2	E129-GP	18	WH	1661262C1
3	E133T	18	LTGN	1661262C1
4	E76C	16	LTGN	1661262C1
5	E76D	16	LTGN	1661262C1
6	E76-GB	16	WH	1661262C1

Legend: @ W/12 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10469: ROOF HATCH 5 4 6

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	E129R	18	GY	1661262C1
2	E129-GR	18	WH	1661262C1
3	E133U	18	LTGN	1661262C1
4	E76C	16	LTGN	1661262C1
5	E76D	16	LTGN	1661262C1
6	E76-GB	16	WH	1661262C1

Legend: @ W/13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

25.12. CONNECTOR COMPOSITES %10472, P. 12 | Figure 1302 CONNECTOR COMPOSITES %10472 | printed page 1302

Connector 10472: BODY HARNESS)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	E129A	18	GY	3534164C1
B#	E129B	18	GY	3534164C1
B#	E129C	18	GY	3534164C1
B#	E129D	18	GY	3534164C1
B#	E129E	18	GY	3534164C1
B#	E129F	18	GY	3534164C1
C*	EL129H	18	GY	3534164C1
C&	E129J	18	GY	3534164C1
C^	E129K	18	GY	3534164C1
C@	E129L	18	GY	3534164C1
C!	E129M	18	GY	3534164C1
C??	E129N	18	GY	3534164C1
D?	E129N	18	GY	3534164C1
D?	E129P	18	GY	3534164C1
D!!	E129R	18	GY	3534164C1
E	-	-	-	-
F	-	-	-	-
G#	E129-GA	18	WH	3534164C1
H#	E129-GB	18	WH	3534164C1
H#	E129-GC	18	WH	3534164C1
H#	E129-GD	18	WH	3534164C1
H#	E129-GE	18	WH	3534164C1
H#	E129-GF	18	WH	3534164C1
J*	EL129-GH	18	WH	3534164C1
J&	E129-GJ	18	WH	3534164C1
J^	E129-GK	18	WH	3534164C1
J@	E129-GL	18	WH	3534164C1
J!	E129-GM	18	WH	3534164C1
J??	E129-A	18	WH	3534164C1
K?	E129-A	18	WH	3534164C1
K?	E129-GP	18	WH	3534164C1
K!!	E129-GR	18	WH	3534164C1
L	-	-	-	-
M	-	-	-	-

25.13. CONNECTOR COMPOSITES *10473, %10474A, %10474B, %10474C, P. 13 | Figure 1303 CONNECTOR COMPOSITES *10473, %10474A, %10474B, %10474C | printed page 1303

Connector 10473: SPLICE PACK OTHER GNDS A@ B@ C@

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A@	E11-GB2	16	WH	3535303C1	3535424C1
B@	E76-GA	16	WH	3535303C1	3535424C1
C@	E76-GB	16	WH	3535303C1	3535424C1
D@	E127-GA	18	WH	3535303C1	3535424C1
D#	E127-GB	18	WH	3535303C1	3535424C1
E%	E127-GB	18	WH	3535303C1	3535424C1
E&	E127-GA	18	WH	3535303C1	3535424C1
F@	PLUG	-	-	3535425C1	-

Legend: @ W/5-13 LH WDO ; # W/5-11 & 13 LH WDO ; % W/5-11 LH WDO ; & W/12 LH WDO ; * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10474A: STROBE LIGHT A B A@ B@

CAV	CIRCUIT	GA	COLOR	TERMINAL
A@	E127B	18	OR	1661261C1
A@	E127C	18	OR	1661261C1
B@	E127-GA	18	WH	1661261C1
B#	E127-GB	18	WH	1661261C1

Legend: @ W/5-13 LH WDO ; # W/5-11 & 13 LH WDO ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10474B: STROBE LIGHT A B B@ B#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A@	E127A	18	OR	1661261C1
A@	E127C	18	OR	1661261C1
B@	E127-GA	18	WH	1661261C1
B#	E127-GB	18	WH	1661261C1

Legend: @ W/5-13 LH WDO ; # W/5-11 & 13 LH WDO ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10474C: BODY LOCK 1661263C1 STROBE LIGHT A B CAV A@ A@

CAV	CIRCUIT	GA	COLOR	TERMINAL
A@	E127A	18	OR	1661261C1
A@	E127C	18	OR	1661261C1
B@	E127-GA	18	WH	1661261C1
B#	E127-GB	18	WH	1661261C1

Legend: @ W/5-13 LH WDO ; # W/5-11 & 13 LH WDO ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

25.14. CONNECTOR COMPOSITES %10474D, %10474E, %10474F, %10474G, | Figure 1304 CONNECTOR COMPOSITES %10474D, %10474E, %10474F, %10474G, %10474H | printed page 1304

Connector 10474D: STROBE LIGHT A B B#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A@	E127A	18	OR	1661261C1
A@	E127C	18	OR	1661261C1
B@	E127-GA	18	WH	1661261C1
B#	E127-GB	18	WH	1661261C1

Legend: @ W/5-13 LH WDO ; # W/5-11 & 13 LH WDO ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10474E: STROBE LIGHT A B A@ A@ B@

CAV	CIRCUIT	GA	COLOR	TERMINAL
A@	E127A	18	OR	1661261C1
A@	E127C	18	OR	1661261C1
B@	E127-GA	18	WH	1661261C1
B#	E127-GB	18	WH	1661261C1

Legend: @ W/5-13 LH WDO ; # W/5-11 & 13 LH WDO ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10474F: STROBE LIGHT A B A* B*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	E127A	18	OR	1661261C1
A*	E127C	18	OR	1661261C1
B*	E127-GA	18	WH	1661261C1
B#	E127-GB	18	WH	1661261C1

Legend: * W/6-13 LH WDO ; # W/6-11 & 13 LH WDO ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10474G: CAV STROBE LIGHT A* A B B* B#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	E127A	18	OR	1661261C1
A*	E127C	18	OR	1661261C1
B*	E127-GA	18	WH	1661261C1
B#	E127-GB	18	WH	1661261C1

Legend: * W/7-13 LH WDO ; # W/7-11 & 13 LH WDO ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10474H: BODY LOCK 1661263C1 STROBE LIGHT A B A* B*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	E127A	18	OR	1661261C1
A*	E127C	18	OR	1661261C1
B*	E127-GA	18	WH	1661261C1
B#	E127-GB	18	WH	1661261C1

Legend: * W/8-13 LH WDO ; # W/8-11 & 13 LH WDO ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

25.15. CONNECTOR COMPOSITES %10474J, %10474K, %10474L, %10474M, P. 15 | Figure 1305 CONNECTOR COMPOSITES %10474J, %10474K, %10474L, %10474M | printed page 1305

Connector 10474J: STROBE LIGHT A B A* B* B#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	E127A	18	OR	1661261C1
A*	E127C	18	OR	1661261C1
B*	E127-GA	18	WH	1661261C1
B#	E127-GB	18	WH	1661261C1

Legend: * W/9-13 LH WDO ; # W/9-11 & 13 LH WDO ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10474K: STROBE LIGHT A B A* A* B*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	E127A	18	OR	1661261C1
A*	E127C	18	OR	1661261C1
B*	E127-GA	18	WH	1661261C1
B#	E127-GB	18	WH	1661261C1

Legend: * W/10-13 LH WDO ; # W/10-11 & 13 LH WDO ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10474L: STROBE LIGHT A B B* B#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	E127A	18	OR	1661261C1
A*	E127C	18	OR	1661261C1
B*	E127-GA	18	WH	1661261C1
B#	E127-GB	18	WH	1661261C1

Legend: * W/11-13 LH WDO ; # W/11 & 13 LH WDO ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10474M: BODY LOCK 1661263C1 STROBE LIGHT A B CAV A* A*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	E127A	18	OR	1661261C1
A*	E127C	18	OR	1661261C1
B*	E127-GA	18	WH	1661261C1
B#	E127-GB	18	WH	1661261C1

Legend: * W/12-13 LH WDO ; # W/13 LH WDO ; % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

25.16. CONNECTOR COMPOSITES @10474N, @10475, @10475A, P. 16 | Figure 1306 CONNECTOR COMPOSITES @10474N, @10475, @10475A | printed page 1306

Connector 10474N: STROBE LIGHT A B A B B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E127A	18	OR	1661261C1
A	E127C	18	OR	1661261C1
B	E127-GA	18	WH	1661261C1
B	E127-GB	18	WH	1661261C1

Legend: @ W/13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10475: REAR STOP ARM ELECTRICAL PANEL) 2# 2*

CAV	CIRCUIT	GA	COLOR	TERMINAL
1#	E119A	18	BK	1661262C1
1*	E119A	18	GY	1661262C1
2#	E119F	18	OR	1661262C1
2*	E89A	18	OR	1661262C1
3#	E119C	18	GY	1661262C1
3*	E89B	18	OR	1661262C1
4#	E119D	18	GY	1661262C1
4*	E119B	18	GY	1661262C1
5#	E119E	18	OR	1661262C1
5*	E119C	18	GY	1661262C1
6#	E119-GA	18	WH	1661262C1
6*	E119-G	18	WH	1661262C1

Legend: # W/5-11 LH WDO ; * W/12 AND 13 LH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10475A: AND REAR STOP ARM ELECTRICAL PANEL) 1* 1# 2*

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B119K	16	GY	1661261C1
1#	B119K	16	GY	1661261C1
2*	B89C	16	OR	1661261C1
2#	B89C	16	OR	1661261C1
3#	B89D	16	OR	1661261C1
3*	B89DA	16	OR	1661261C1
4*	B119J	16	GY	1661261C1
4#	B119J	16	GY	1661261C1
5#	B119-GJ	18	WH	1661261C1
6*	B119-GE	16	WH	1661261C1
6#	B119-GE	16	WH	1661261C1

25.17. CONNECTOR COMPOSITES @10475B, @10476, @10479, P. 17 | Figure 1307 CONNECTOR COMPOSITES @10475B, @10476, @10479 | printed page 1307

Connector 10475B: 1* 1# 2* REAR STOP ARM 2# ELECTRICAL PANEL) 3* 4*

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B119K	16	GY	1661261C1
1#	B119K	16	GY	1661261C1
2*	B89C	16	OR	1661261C1
2#	B89C	16	OR	1661261C1
3#	B89DB	16	OR	1661261C1
3*	B89D	16	OR	1661261C1
4*	B119J	16	GY	1661261C1
4#	B119J	16	GY	1661261C1
5#	B119-GJ	18	WH	1661261C1
6*	B119-GE	16	WH	1661261C1
6#	B119-GE	18	WH	1661261C1

Connector 10476: REAR STOP ARM ARM XMSN HARNESS) 1* 2# 2*

CAV	CIRCUIT	GA	COLOR	TERMINAL
1#	E119A	18	BK	1661262C1
1*	E119A	18	BK	1661262C1
2#	E119F	18	OR	1661262C1
2*	E89A	18	OR	1661262C1
3#	E119C	18	GY	1661262C1
3*	E89B	18	OR	1661262C1
4#	E119D	18	GY	1661262C1
4*	E119B	18	GY	1661262C1
5#	E119E	18	OR	1661262C1
5*	E119C	18	GY	1661262C1
6#	E119-GA	18	WH	1661262C1
6*	E119-G	18	WH	1661262C1

Legend: # W/5-11 LH WDO ; * W/12 AND 13 LH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10479: AND ALT ENTR DOOR CAV AFT OF "0 BOW") 1* 2* 2*

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	E120F	18	LTGN	1661539C1
1*	E120K	16	LTGN	1661539C1
2*	E120E	18	LTGN	1661539C1
2*	E120L	16	LTGN	1661539C1
3*	E120-GA	18	WH	1661539C1
3*	E120-GB	16	LTGN	1661539C1
4*	E120H	18	LTGN	1661539C1
4*	E120-GC	16	LTGN	1661539C1
5*	E81A	18	LTGN	1661539C1
6*	E81B	18	LTGN	1661539C1

Legend: * W/7-13 LH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

25.18. CONNECTOR COMPOSITES @@10482, @@10483, P. 18 | Figure 1308 CONNECTOR COMPOSITES @@10482, @@10483 | printed page 1308

Connector 10482: SPLICE PACK K

CAV	CIRCUIT	GA	COLOR	TERMINAL
A^	E11-GC	12	WH	3566715C1
B%	E63-GF	16	WH	1661209C1
B^	E63-GA	16	WH	1661209C1
B^	E63-GN	16	WH	1661209C1
C&	E63-GW	16	WH	1661209C1
C@	E63-GAE	18	WH	1661208C1
C#&	E131-G	16	WH	1661209C1
D^	E63-GAF	18	WH	1661208C1
E**	E58-GF	18	WH	1661208C1
E@	E120-GA	18	WH	1661208C1
E&&	E131-G	16	WH	1661209C1
F##	E120-GA	18	WH	1661208C1
F%%	E131-G	16	WH	1661209C1
G#@	E56-GC	18	WH	1661208C1
G**	E58-GA	18	WH	1661208C1
G*&	E56-GD	18	WH	1661208C1
H^	E56-GA	18	WH	1661208C1
H**	E58-GB	18	WH	1661208C1
H*@	E58-GJ	18	WH	1661208C1
H#*	E58-GC	18	WH	1661208C1
H#*	E56-GC	18	WH	1661208C1

Legend: J-K - - - ; ^ W/5-13 LH WDO ; # W/6 LH WDO ; % W/9 LH WDO ; & W/7-8 AND 11 LH WDO ; @ W/12 LH WDO ; ** W/5 LH WDO ; *# W/7-9, 11 AND 13 LH WDO ; *% W/5-9 AND 11-13 LH WDO

Connector 10483: DOME LIGHT STANDARD STAGGER SECTION 1 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A@	E63C	16	DKBL	1661261C1
A@	E63X	16	DKBL	1661261C1
A#	E63A	16	DKBL	1661261C1
B@	E63-GB	16	WH	1661261C1
B&	E63-GA	16	WH	1661261C1
B@	E63-GM	16	WH	1661261C1

25.19. CONNECTOR COMPOSITES @10483A, @10483B, @10484, @10484A, P. 19 | Figure 1309 CONNECTOR COMPOSITES @10483A, @10483B, @10484, @10484A | printed page 1309

Connector 10483A: DOME LT OVER EACH SEAT A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63AC	16	DKBL	1661261C1
B	E63-GAC	16	DKBL	1661261C1

Legend: @ W/9 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10483B: 12 DOME LT A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63A	16	DKBL	1661261C1
B	E63A-G	16	WH	1661261C1

Connector 10484: DOME LIGHT SECTION 3 A A# B@ B#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A@	E63Y	16	DKBL	1661261C1
A#	E63D	16	DKBL	1661261C1
A#	E63AD	16	DKBL	1661261C1
B@	E63-GP	16	WH	1661261C1
B#	E63-GD	16	WH	1661261C1
B#	E63-GAD	16	WH	1661261C1

Legend: @ W/5-13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK ; # W/6 LH WDO

Connector 10484A: DOME LT OVER EACH SEAT A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63AD	16	DKBL	1661261C1
B	E63-GAD	16	DKBL	1661261C1

Legend: @ W/9 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

25.20. CONNECTOR COMPOSITES @@10485, @@10486, P. 20 | Figure 1310 CONNECTOR COMPOSITES @@10485, @@10486 | printed page 1310

CAV	CIRCUIT	GA	COLOR	TERMINAL
A^	E63D	16	DKBL	1661261C1
A#	E63L	16	DKBL	1661261C1
A%	E63R	16	DKBL	1661261C1
A^	E63Z	16	DKBL	1661261C1
A#	E63AP	16	DKBL	1661261C1
A#	E63AF	16	DKBL	1661261C1
A&	E63H	16	DKBL	1661261C1
A@	E63F	16	DKBL	1661261C1
A@	E63T	16	DKBL	1661261C1
A@	E63AJ	16	DKBL	1661261C1
B^	E63-GC	16	WH	1661261C1
B^	E63-GR	16	WH	1661261C1
B&	E63-GH	16	WH	1661261C1

Connector 10486: DOME LIGHT SECTION 7 A A% A&

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	E63AA	16	DKBL	1661261C1
A%	E63AF	16	DKBL	1661261C1
A&	E63AX	16	DKBL	1661261C1
A@	E63AC	16	DKBL	1661261C1
B*	E63-GT	16	WH	1661261C1

25.21. CONNECTOR COMPOSITES @@10487, @10488, @10489, P. 21 | Figure 1311 CONNECTOR COMPOSITES @@10487, @10488, @10489 | printed page 1311

Connector 10487: DOME LIGHT SECTION 9 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	E63E	16	DKBL	1661261C1
A*	E63R	16	DKBL	1661261C1
A*	E63AB	16	DKBL	1661261C1
A#	E63AP	18	DKBL	1661261C1
A%	E63AH	16	DKBL	1661261C1
A&	E63AP	16	DKBL	1661261C1
A@	E63AV	16	DKBL	1661261C1
A**	E63AF	16	DKBL	1661261C1
B*	E63-GD	16	WH	1661261C1
B%	E63-GL	16	WH	1661261C1
B*	E63-GU	16	WH	1661261C1
B*#	E63-GV	16	WH	1661261C1

Legend: * W/9-13 LH WDO ; # W/9 LH WDO ; % W/9-12 LH WDO ; & W/10 LH WDO ; @ W/12 LH WDO ; ** W/13 LH WDO ; *# W/11 LH WDO ; @@ W/13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND

Connector 10488: DOME LIGHT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	E63AC	16	DKBL	1661261C1
A#	E63AP	16	DKBL	1661261C1
A#	E63AN	16	DKBL	1661261C1
A%	E63AP	18	DKBL	1661261C1
A%	E63AJ	16	DKBL	1661261C1
A&	E63AH	16	DKBL	1661261C1
B*	E63-GV	16	WH	1661261C1
B#	E63-GU	16	WH	1661261C1

Legend: * W/11-13 LH WDO ; # W/11 LH WDO ; % W/12 LH WDO ; & W/13 LH WDO ; @ W/13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10489: DOME LIGHT SECTION 13

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63F	16	DKBL	1661261C1
A	E63L	16	DKBL	1661261C1
A	E63S	16	DKBL	1661261C1
A	E63T	16	DKBL	1661261C1
A	E63AD	16	DKBL	1661261C1
A	E63AP	16	DKBL	1661261C1
A	E63AJ	16	DKBL	1661261C1
B	E63-GE	16	WH	1661261C1
B	E63-GK	16	WH	1661261C1
B	E63-GW	16	WH	1661261C1

Legend: * W/13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

25.22. CONNECTOR COMPOSITES @10491B, @10491C, @10491D, P. 22
Figure 1312 CONNECTOR COMPOSITES @10491B, @10491C, @10491D

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 25.22. CONNECTOR COMPOSITES @10491B, @10491C, @10491D, P. 22 / CHAPTER 25 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090676 NO. 95504E 27FEB20 / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / ACTIVITY LIGHT @(10491C) (LOCATED AT LEFT BODY- WINDOW SECTION 8) / ACTIVITY LIGHT @(10491D) (LEFT BODY-WINDOW SECTION 11) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661259C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / @ W/8 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / @ W/11 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / ACTIVITY DOME LIGHT @(10491B) (LOCATED AT LEFT BODY- WINDOW SECTION 12) / @ W/12 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / A B / A B / A B / CAV CIRCUIT GA COLOR TERMINAL A E63BA 18 DKBL 1661261C1 B E63-GAE 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A E63AT 18 DKBL 1661261C1 B E63-GW 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A E63AT 16 DKBL 1661261C1 B E63-GW 16 WH 1661261C1 / Figure 1312 / CONNECTOR COMPOSITES @10491B, @10491C, @10491D

Connector 10491B: ACTIVITY DOME LIGHT WINDOW SECTION 12)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63BA	18	DKBL	1661261C1
B	E63-GAE	18	WH	1661261C1

Connector 10491C: ACTIVITY LIGHT WINDOW SECTION 8)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63AT	18	DKBL	1661261C1
B	E63-GW	16	WH	1661261C1

Connector 10491D: ACTIVITY LIGHT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63AT	16	DKBL	1661261C1
B	E63-GW	16	WH	1661261C1

25.23. CONNECTOR COMPOSITES @10491E, @10492, @10500, @10506, @10506A,
Figure 1313 CONNECTOR COMPOSITES @10491E, @10492, @10500, @10506, @10506A, @10506B

25.23. CONNECTOR COMPOSITES @10491E, @10492, @10500, @10506, @10506A, | Figure 1313 CONNECTOR COMPOSITES @10491E, @10492, @10500, @10506, @10506A, @10506B | printed page 1313

Connector 10491E: @ W/7 LH WDO W/0508108 - A B B E63-GW
Table: INTEREST OF CONNECTOR BODY

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63AT	16	DKBL	1661261C1
B	E63-GW	16	WH	1661261C1

Legend: @ W/7 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10492: W/0508108 N/0508108 CONNECTOR 1661259C1 BODY LOCK 1661263C1 DOME LT GUARD CAV 1ST WINDOW SECTION) @ W/5 TO 13 A B B E63-GAF

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63BD	18	DKBL	1661261C1
B	E63-GAF	18	WH	1661261C1

Legend: @ W/5 TO 13 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10500: N/0508108 CONNECTOR 1661259C1 BODY LOCK 1661263C1 INPOWER STROBE MODULE CAV CIRC 1# B127D 16 2* B127C 16 2# B127C 16

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B127D	16	OR	3686946C1
1#	B127D	16	OR	3686946C1
2*	B127C	16	OR	3686946C1
2#	B127C	16	OR	3686946C1
3	PLUG	-	-	3833742C1
4#	B89F	16	OR	3686946C1
4*	B89FA	18	OR	3686946C1
5	PLUG	-	-	3833742C1
6*	B127-G	16	WH	3686946C1
6#	B127-G	16	WH	3686946C1
7	PLUG	-	-	3833742C1
8*	B89E	16	OR	3686946C1
8#	B89EA	16	OR	3686946C1

Connector 10506: 8# B89EA SIDE DIR LT FWD REAR WHL PKT CAV A B A# E56M B* KP56-GH B# KP56-GJ

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	E56L	18	YL	1661261C1
A#	E56M	18	YL	1661261C1
B*	KP56-GH	18	WH	1661261C1
B#	KP56-GJ	18	WH	1661261C1

Legend: * W/5,7 & 9 LH WDO ; # W/11 LH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10506A: SIDE DIRECTIONAL LIGHT FORWARD CAV REAR WHEEL POCKET A @ W/8 LH W/0508108 N/0508108 A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E56L	18	YL	1661261C1
B	E56-GH	18	WH	1661261C1

Legend: @ W/8 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10506B: BODY LOCK 1661263C1 SIDE DIRECTIONAL LIGHT FORWARD CAV REAR WHEEL POCKET A @ W/8 LH W/0508108 N/0508108 A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E56A	18	YL	1661261C1
B	E56-GA	18	WH	1661261C1

Legend: @ W/8 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Figure 1314 CONNECTOR COMPOSITES @10507, @10507A, @10508

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 25.24. CONNECTOR COMPOSITES @10507, @10507A, @10508, P. 24 / CHAPTER 25 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090676 NO. 95504E 27FEB20 / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / 12 DOME LIGHT @(10507A) (LOCATED AT LEFT BODY) / DOME LIGHT OVER EACH SEAT @(10508) (LOCATED AT LEFT BODY) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / @ W/9 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / @ W/9 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / DOME LIGHT OVER EACH SEAT @(10507) (LOCATED AT LEFT BODY) / @ W/9 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / A B / A B / A B / CAV CIRCUIT GA COLOR TERMINAL A E63J 16 DKBL 1661261C1 B E63-GH 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A E63B 16 DKBL 1661261C1 B E63B-G 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A E63U 16 DKBL 1661261C1 B E63-GJ 16 WH 1661261C1 / Figure 1314 / CONNECTOR COMPOSITES @10507, @10507A, @10508

Connector 10507: DOME LIGHT OVER EACH SEAT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63J	16	DKBL	1661261C1
B	E63-GH	16	WH	1661261C1

Connector 10507A: 12 DOME LIGHT

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63B	16	DKBL	1661261C1
B	E63B-G	16	WH	1661261C1

Connector 10508: DOME LIGHT OVER EACH SEAT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63U	16	DKBL	1661261C1
B	E63-GJ	16	WH	1661261C1

Figure 1315 CONNECTOR COMPOSITES @10508A, @10509, @10510

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 25.25. CONNECTOR COMPOSITES @10508A, @10509, @10510, P. 25 / CHAPTER 25 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090676 NO. 95504E 27FEB20 / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / DOME LIGHT OVER EACH SEAT @(10509) (LOCATED AT LEFT BODY) / DOME LIGHT OVER EACH SEAT @(10510) (LOCATED AT LEFT BODY) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661259C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / @ W/9 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / @ W/9 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / 12 DOME LIGHT @(10508A) (LOCATED AT LEFT BODY) / @ W/9 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / A B / A B / A B / CAV CIRCUIT GA COLOR TERMINAL A E63C 16 DKBL 1661261C1 B E63C-G 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A E63AL 16 DKBL 1661261C1 B E63-GS 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A E63AS 16 DKBL 1661261C1 B E63-GZ 16 WH 1661261C1 / Figure 1315 / CONNECTOR COMPOSITES @10508A, @10509, @10510

Connector 10508A: 12 DOME LIGHT

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63C	16	DKBL	1661261C1
B	E63C-G	16	WH	1661261C1

Legend: @ W/9 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10509: DOME LIGHT OVER EACH SEAT

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63AL	16	DKBL	1661261C1
B	E63-GS	16	WH	1661261C1

Legend: @ W/9 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10510: DOME LIGHT OVER EACH SEAT

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63AS	16	DKBL	1661261C1
B	E63-GZ	16	WH	1661261C1

Figure 1316 CONNECTOR COMPOSITES @10510A, @10511, @10511A

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 25.26. CONNECTOR COMPOSITES @10510A, @10511, @10511A, P. 26 / CHAPTER 25 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090676 NO. 95504E 27FEB20 / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / SIDE DIRECTIONAL LIGHT OVER REAR WHEEL POCKET CE @(10511) (LOCATED AT LEFT BODY) / SIDE DIRECTIONAL LIGHT OVER REAR WHEEL POCKET CE @(10511A) (LOCATED AT LEFT BODY) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / @ W/5,7,9 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / @ W/8 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / 12 DOME LIGHT @(10510A) (LOCATED AT LEFT BODY) / @ W/9 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / A B / A B / A B / CAV CIRCUIT GA COLOR TERMINAL A E63F 16 DKBL 1661261C1 B E63F-G 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A E56M 18 YL 1661261C1 B E56-GJ 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A E56M 18 YL 1661261C1 B E56-GJ 18 WH 1661261C1 / Figure 1316 / CONNECTOR COMPOSITES @10510A, @10511, @10511A

Connector 10510A: 12 DOME LIGHT

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63F	16	DKBL	1661261C1
B	E63F-G	16	WH	1661261C1

Connector 10511: SIDE DIRECTIONAL LIGHT OVER REAR WHEEL POCKET CE

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E56M	18	YL	1661261C1
B	E56-GJ	18	WH	1661261C1

Legend: @ W/5,7,9 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10511A: SIDE DIRECTIONAL LIGHT OVER REAR WHEEL POCKET CE

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E56M	18	YL	1661261C1
B	E56-GJ	18	WH	1661261C1

25.27. CONNECTOR COMPOSITES @10511B, @10512, @10513, P. 27 | Figure 1317 CONNECTOR COMPOSITES @10511B, @10512, @10513 | printed page 1317

Connector 10511B: SIDE DIRECTIONAL LIGHT OVER REAR WHEEL POCKET A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E56A	18	YL	1661261C1
B	E56-GA	18	WH	1661261C1

Connector 10512: SIDE MARKER LIGHT CE A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E56K	18	YL	1661261C1
B	E58E	18	BN	1661261C1
C	E56-GF	18	WH	1661261C1

Connector 10513: VFIRE SUPPRESSION JAMMER

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	E144	16	GY	1661538C1
2	E144A	16	GY	1661538C1
3	E144B	16	GY	1661538C1
4	E144D	16	GY	1661538C1
5	E144E	16	GY	1661538C1
6	E144F	16	GY	1661538C1
7	E144-G	16	WH	1661538C1
8	-	-	-	-
9	-	-	-	-

25.28. CONNECTOR COMPOSITES @10513, @10513A, @10514, P. 28 | Figure 1318 CONNECTOR COMPOSITES @10513, @10513A, @10514 | printed page 1318

Connector 10513: PTI-STOP REAR SWITCH WINDOW SECTION) C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	D125A	16	GY	1661262C1
B*	D125B	16	GY	1661262C1
B#	D125A	16	GY	1661262C1
C	D125-G	16	WH	1661262C1

Legend: *PTI STOP DEACTIVATION SW IN LT BAR ; #PTI PULSE SW IN LT BAR ; @ W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10513A: PTI-STOP REAR SWITCH WINDOW SECTION)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	-	-	-	-
B	D125A	16	GY	1661262C1
C	D125-G	16	WH	1661262C1

Connector 10514: DOME LIGHT OVER EACH SEAT /12 DOME LIGHT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63AU	16	DKBL	1661261C1
B	E63-GAA	16	WH	1661261C1

25.29. CONNECTOR COMPOSITES @10514, @10514A, @10515, P. 29 | Figure 1319 CONNECTOR COMPOSITES @10514, @10514A, @10515 | printed page 1319

Connector 10514: SPLICE REAR K/O WDO A ML

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E126D	18	GY	3534164C1
B	E126C	18	GY	3534164C1
C	E126K	16	GY	3534165C1
D	E126L	16	GY	3534165C1
E	E126M	16	GY	3534165C1
G	E126-GD	18	WH	3534164C1
H	E126-GJ	16	WH	3534165C1
J	E126-GK	16	WH	3534165C1
K	E126-GL	16	WH	3534165C1
M	E126-GR	18	WH	3534164C1

Legend: @ W/12 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10514A: DOME LIGHT OVER EACH SEAT/12 DOME LIGHT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63G	16	DKBL	1661261C1
B	E63G-G	16	WH	1661261C1

Connector 10515: DOME LIGHT OVER EACH SEAT/12 DOME LIGHT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63AM	16	DKBL	1661261C1
B	E63-GAG	16	WH	1661261C1

Legend: @ W/9 LH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

25.30. CONNECTOR COMPOSITES @10515, @10515A, @10516, P. 30 | Figure 1320 CONNECTOR COMPOSITES @10515, @10515A, @10516 | printed page 1320

Connector 10515: SPLICE FR K/O WDO

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E126E	18	GY	3534164C1
B	E126D	18	GY	3534164C1
C	E126F	16	GY	3534165C1
D	E126H	16	GY	3534165C1
E	E126J	16	GY	3534165C1
G	E126-GC	18	WH	3534164C1
H	E126-GE	16	WH	3534165C1
J	E126-GF	16	WH	3534165C1
K	E126-GH	16	WH	3534165C1
M	E126-GR	18	WH	3534164C1

Legend: W/12 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10515A: DOME LIGHT OVER EACH SEAT/12 DOME LIGHT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63E	16	DKBL	1661261C1
B	E63E-G	16	WH	1661261C1

Connector 10516: DOME LIGHT OVER EACH SEAT/12 DOME LIGHT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63V	16	DKBL	1661261C1
B	E63-GL	16	WH	1661261C1

Legend: @ W/9 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

25.31. CONNECTOR COMPOSITES @10516, @10516A, @10517, P. 31 | Figure 1321 CONNECTOR COMPOSITES @10516, @10516A, @10517 | printed page 1321

Connector 10516: SPLICE REAR K/O WDO

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E126E	18	GY	3534164C1
C	E126N	16	GY	3534165C1
D	E126P	16	GY	3534165C1
E	E126R	16	GY	3534165C1
G	E126-GC	18	WH	3534164C1
H	E126-GM	16	WH	3534165C1
J	E126-GN	16	WH	3534165C1
K	E126-GP	16	WH	3534165C1

Legend: @ W/12 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10516A: DOME LIGHT OVER EACH SEAT/12 DOME LIGHT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E63D	16	DKBL	1661261C1
B	E63D-G	16	WH	1661261C1

Connector 10517: SPLICE PACK STROBE LIGHT

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A&	E127A	18	OR	3535303C1	3535424C1
A#	E127C	18	OR	3535303C1	3535424C1
B!	E127C	18	OR	3535303C1	3535424C1
C%	E127C	18	OR	3535303C1	3535424C1
D	PLUG	-	-	3535425C1	-
E#	E127A	18	OR	3535303C1	3535424C1

Legend: & W/5 TO 6 & 8 TO 11 & 13 LH WDO ; % W/5 TO 13 LH WDO ; ! W/5 TO 9 & 11 LH WDO ; # W/7 & 12 LH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE

25.32. CONNECTOR COMPOSITES @10518, @10519, @10529, P. 32 | Figure 1322 CONNECTOR COMPOSITES @10518, @10519, @10529 | printed page 1322

Connector 10518: SIDE MARKER LIGHT

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	E58F	18	BN	1661261C1
A*	E58H	18	BN	1661261C1
B*	E58-GH	18	WH	1661261C1
B%	E58-GF	18	WH	1661261C1
B&	E58-GB	18	WH	1661261C1

Legend: * W/ 6 TO 12 LH WDO ; # W/ 5 & 13 LH WDO ; % W/5 LH WDO ; & W/13 LH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK

Connector 10519: SIDE MARKER LT AFT LR WHL PKT CAV A%

CAV	CIRCUIT	GA	COLOR	TERMINAL
A%	E58E	18	BN	1661261C1
A*	E58J	18	BN	1661261C1
A&	E58H	18	BN	1661261C1
B*	E58-GJ	18	WH	1661261C1
B%	E58-GB	18	WH	1661261C1
B&	E58-GC	18	WH	1661261C1

Legend: * W/ 6 TO 12 LH WDO ; % W/5 LH WDO ; & W/13 LH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK

Connector 10529: EMERGENCY DOOR LIGHT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A@	E143	16	DKBL	0239805R1

Legend: @ W/13 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

25.33. CONNECTOR COMPOSITES %10555G, %10555H, %10555J, %10555K, P. 32A | Figure 1323 CONNECTOR COMPOSITES %10555G, %10555H, %10555J, %10555K | printed page 1323

Connector 10555G: ANY WAY DETRIMENTAL TO THE INTEREST OF INC. TO LH BODY SIDE CAMERA

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[B137E]	20	LT BL	ASSY
2	[B137F]	20	LT BL	ASSY
3	[B137G]	20	LT BL	ASSY
4	[B137H]	20	LT BL	ASSY

Legend: % N/0508108 - NOT MTA FUSE BLOCK

Connector 10555H: CONNECTOR 4121239C91 TO DISTRIBUTOR UNIT FRONT CAMERA 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[B137E]	20	LT BL	ASSY
2	[B137F]	20	LT BL	ASSY
3	[B137G]	20	LT BL	ASSY
4	[B137H]	20	LT BL	ASSY

Connector 10555J: CONNECTOR 4121239C91 TO LH BODY SIDE CAMERA

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[B137E]	20	LT BL	ASSY
2	[B137F]	20	LT BL	ASSY
3	[B137G]	20	LT BL	ASSY
4	[B137H]	20	LT BL	ASSY

Legend: % N/0508108 - NOT MTA FUSE BLOCK

Connector 10555K: CONNECTOR 4121278C91 TO SPILTTER SIDE CAMERA

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[B137E]	20	LT BL	ASSY
2	[B137F]	20	LT BL	ASSY
3	[B137G]	20	LT BL	ASSY
4	[B137H]	20	LT BL	ASSY

Legend: % N/0508108 - NOT MTA FUSE BLOCK

25.34. CONNECTOR COMPOSITES %10556E, %10556F, P. 32B
Figure 1324 CONNECTOR COMPOSITES %10556E, %10556F

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 25.34. CONNECTOR COMPOSITES %10556E, %10556F, P. 32B / CHAPTER 25 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, RELEASE NO. PART AE08090676 NO. 96183U 11AUG21 / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / CONNECTOR 4121237C91 / TO LH BODY REAR CAMERA %(10556E) (LOCATED IN ELEC PANEL HARNESS) / % N/0508108 - NOT MTA FUSE BLOCK / TO SPILTTER REAR CAMERA %(10556F) (LOCATED IN ELEC PANEL HARNESS) / CONNECTOR 4121237C91 / % N/0508108 - NOT MTA FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL 1 [B137A] 20 LT BL ASSY 2 [B137B] 20 LT BL ASSY 3 [B137C] 20 LT BL ASSY 4 [B137D] 20 LT BL ASSY / CAV CIRCUIT GA COLOR TERMINAL 1 [B137A] 20 LT BL ASSY 2 [B137B] 20 LT BL ASSY 3 [B137C] 20 LT BL ASSY 4 [B137D] 20 LT BL ASSY / Figure 1324 / CONNECTOR COMPOSITES %10556E, %10556F

Connector 10556E: ANY WAY DETRIMENTAL TO THE INTEREST OF INC. TO LH BODY REAR CAMERA

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[B137A]	20	LT BL	ASSY
2	[B137B]	20	LT BL	ASSY
3	[B137C]	20	LT BL	ASSY
4	[B137D]	20	LT BL	ASSY

Legend: % N/0508108 - NOT MTA FUSE BLOCK

Connector 10556F: % CONNECTOR 4121237C91 TO SPILTTER REAR CAMERA 1 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[B137A]	20	LT BL	ASSY
2	[B137B]	20	LT BL	ASSY
3	[B137C]	20	LT BL	ASSY
4	[B137D]	20	LT BL	ASSY

Legend: % N/0508108 - NOT MTA FUSE BLOCK

25.35. CONNECTOR COMPOSITES %10557G, %10557H, %10557J, %10557K, P. 32C | Figure 1325 CONNECTOR COMPOSITES %10557G, %10557H, %10557J, %10557K | printed page 1325

Connector 10557G: TO PLATFORM FRONT CAMERA

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[B137J]	20	LTBL	ASSY
2	[B137K]	20	LTBL	ASSY
3	[B137L]	20	LTBL	ASSY
4	[B137M]	20	LTBL	ASSY

Legend: % N/0508108 - NOT MTA FUSE BLOCK

Connector 10557H: CONNECTOR 4121238C91 TO DISTRIBUTOR UNIT FRONT CAMERA 2 3 4

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[B137J]	20	LTBL	ASSY
2	[B137K]	20	LTBL	ASSY
3	[B137L]	20	LTBL	ASSY
4	[B137M]	20	LTBL	ASSY

Legend: % N/0508108 - NOT MTA FUSE BLOCK

Connector 10557J: CONNECTOR 4121238C91 TO SPLITTER FRONT CAMERA 1 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[B137J]	20	LTBL	ASSY
2	[B137K]	20	LTBL	ASSY
3	[B137L]	20	LTBL	ASSY
4	[B137M]	20	LTBL	ASSY

Legend: % N/0508108 - NOT MTA FUSE BLOCK

Connector 10557K: CONNECTOR 4121277C91 TO PLATFORM FRONT CAMERA

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	[B137J]	20	LTBL	ASSY
2	[B137K]	20	LTBL	ASSY
3	[B137L]	20	LTBL	ASSY
4	[B137M]	20	LTBL	ASSY

Legend: % N/0508108 - NOT MTA FUSE BLOCK

25.36. CONNECTOR COMPOSITES @@10700, P. 33 | Figure 1326 CONNECTOR COMPOSITES @@10700 | printed page 1326

Connector 10700: INTERCONNECT REAR CAP TO RH BODY

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1*	D57A	16	LTGN	3544884C1
A1#	D57	16	LTGN	3544884C1
A2	D124	16	LTGN	3544884C1
A3	D11-GF	12	WH	3544877C1
A4	D58J	16	BN	3544876C1
A5	D126B	18	GY	3544876C1
A7	D86B(+)	16	LTGN	3544884C1
A8	D86A(-)	16	LTGN	3544884C1
B1	-	-	-	-
B2	D63M	16	DKBL	3544884C1
B3	D63AU	16	DKBL	3544884C1
B4	D63BE	18	DKBL	3544884C1
B5##	D63U	16	DKBL	3544884C1
B5**	D63UB	16	DKBL	3544884C1
B6	D63AS	18	DKBL	3544884C1
B7	D120A	18	LTGN	3544884C1
B8	D120B	18	LTGN	3544884C1
B9	D120D	18	LTGN	3544884C1
B10	D120C	18	LTGN	3544884C1
B11	D81B	18	LTGN	3544884C1
B12	D81A	18	LTGN	3544884C1
C1&	D130A	18	GY	3544884C1
C1&&	D130C	18	GY	3544884C1
C2&	D12A	18	LTBL	3544884C1
C2&&	D12C	18	LTBL	3544884C1
C3@	D133D	18	LTGN	3544884C1
C3#*	D133D	16	LTGN	3544884C1
C3*#	D133B	18	LTGN	3544884C1
C4	D122-GA	16	WH	3544884C1
C5^	D122-GB	16	WH	3544884C1
C5^^	D122-GY	16	GY	3544884C1
C6	D122A	16	GY	3544884C1
C7	D122-GC	16	WH	3544884C1
C8	D122B	16	GY	3544884C1
C9	D122C	16	GY	3544884C1
C10	D122D	16	GY	3544884C1
C11-C12	-	-	-	-
D1-D8	-	-	-	-

Legend: # W/STANDARD R TURN L ; * W/R TURN L FOR W/DRIVERS ALERT SIGN ; ## W/DELUXE DOME LT ; ** N/DELUXE DOME LT ; & W/REAR EMERGENCY EXIT DOOR ; && N/REAR EMERGENCY EXIT DOOR ; #* W/VANDAL LOCK-STARTER INTERLOCK ; (REAR AND SED OR LIFT DOOR) ; *# W/VANDAL LOCK-STARTER INTERLOCK

25.37. CONNECTOR COMPOSITES @@10700, P. 34
Figure 1327 CONNECTOR COMPOSITES @@10700

25.37. CONNECTOR COMPOSITES @@10700, P. 34 | Figure 1327 CONNECTOR COMPOSITES @@10700 | printed page 1327

Connector 10700: INC. RIGHT BODY/REAR CAP C B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A8&*	F86CW	16	LTBL	3544886C1
A8%	F86B(-)	16	LTGN	3544886C1
A8*	F86A	16	LTGN	3544886C1
A8*	F86C	16	LTGN	3544886C1
A8*	F86J	16	LTGN	3544886C1
A8*	F86S	16	LTGN	3544886C1
A8*	F86AJ	16	LTGN	3544886C1
A8*	F86BK	16	LTGN	3544886C1
A8%%	F86B	16	LTGN	3544886C1
A8%%	F86BB	16	LTGN	3544886C1
A8^	F86B(-)	16	LTBL	3544886C1
B1	-	-	-	-
B2%%	F63J	16	DKBL	3544886C1
B2	F63M	16	DKBL	3544886C1
B3%	F63D	16	DKBL	3544886C1
B3	F63AU	16	DKBL	3544886C1
B4	F63BE	16	DKBL	3544886C1
B5***	F63	16	DKBL	3544886C1
B5&*	F63F	16	DKBL	3544886C1
B5	F63U	16	DKBL	3544886C1
B5%%	F63B	16	DKBL	3544886C1
B6#*	F63AS	16	DKBL	3544886C1
B6^	F63X	16	DKBL	3544886C1
B7%	F120A	18	LTGN	3544886C1
B7%%	F120H	18	LTGN	3544886C1
B8%	F120B	18	LTGN	3544886C1
B8^	F120B	18	BK	3544886C1
B8%%	F120J	18	LTGN	3544886C1
B9%%	F120E	18	LTGN	3544886C1
B9%%	F120D	18	LTGN	3544886C1
B10%%	F120F	18	LTGN	3544886C1
B10%	F120C	18	LTGN	3544886C1
B11%	F81B	18	LTGN	3544886C1
B12%	F81A	18	LTGN	3544886C1
C1	F130C	18	GY	3544886C1
C1***	F141	16	GY	3544886C1
C2#*	F12C	16	LTBL	3544886C1
C2%%	F12A	16	LTBL	3544886C1
C3	F133D	18	LTGN	3544886C1
C3%%	F133A	18	LTGN	3544886C1
C3%%	F133B	18	LTGN	3544886C1

Legend: % W/5 & 7 TO 13 RH WDO ; * W/12,13 RH WDO ; ** W/5,7,8,10,11 RH WDO ; ## W/9,13 RH WDO ; %% W/12 RH WDO ; *& W/7,8,9 RH WDO ; #* W/5 TO 11 RH WDO ; *# W/9,11 RH WDO ; %* w/7 TO 11 RH WDO

Connector 10700: INC. RIGHT BODY/REAR CAP C B
Table: LEVER LOCK 3553654C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1%	F57B	16	LTGN	3544886C1
A2	F124	16	LTGN	3544886C1
A3#*	F11-GF	12	WH	3544881C1
A3*	F11-G	12	WH	3544881C1
A4##	F58J	16	BN	3544880C1
A4**	F58BJ	16	BN	3544880C1
A4%%	F58	16	BN	3544880C1
A5%	F126B	18	GY	3544880C1
A6	-	-	-	-
A7*&	F86C(+)	16	LTBL	3544886C1
A7**	F86B(+)	16	LTGN	3544886C1
A7#*	F86B(+)	16	LTBL	3544886C1
A7*#	F86F(+)	16	LTBL	3544886C1
A7*#	F86R(+)	16	LTBL	3544886C1
A7%	F86A(+)	16	LTBL	3544886C1
A7**	F86CZ	16	LTBL	3544886C1
A7%	F86A(+)	16	LTGN	3544886C1
A7*	F86	16	LTGN	3544886C1
A7*	F86B	16	LTGN	3544886C1
A7*	F86E	16	LTGN	3544886C1
A7*	F86N	16	LTGN	3544886C1
A7*	F86AA	16	LTGN	3544886C1
A7*	F86BA	16	LTGN	3544886C1
A7%%	F86A	16	LTGN	3544886C1
A8#*	F86A(-)	16	LTGN	3544886C1
A8#*	F86A(-)	16	LTBL	3544886C1
A8%*	F86D(-)	16	LTBL	3544886C1
A8*#	F86L(-)	16	LTBL	3544886C1
A8#*	F86M(-)	16	LTBL	3544886C1

25.38. CONNECTOR COMPOSITES @10700, P. 35 | Figure 1328 CONNECTOR COMPOSITES @10700 | printed page 1328

Connector 10700: CHART CONTINUED FROM SHEET 034 RIGHT BODY/REAR CAP C B

CAV	CIRCUIT	GA	COLOR	TERMINAL
C5*	F122-GE	16	WH	3544886C1
C5*	F122-GJ	16	WH	3544886C1
C5*	F122-GM	16	WH	3544886C1
C5*	F122-GR	16	WH	3544886C1
C5%%	F122-GV	16	WH	3544886C1
C5*	F122GAD	16	WH	3544886C1
C5^	F122-GU	16	WH	3544886C1
C6	F122A	16	GY	3544886C1
C6%%	F122A	18	GY	3544886C1
C6%%	F122W	16	GY	3544886C1
C6*	F122D	16	GY	3544886C1
C6*	F122H	16	GY	3544886C1
C6*	F122L	16	GY	3544886C1
C6*	F122P	16	GY	3544886C1
C6%%	F122C	16	GY	3544886C1
C6*	F122AJ	16	GY	3544886C1
C6^	F122T	16	GY	3544886C1
C7	F122-GC	16	WH	3544886C1
C7%%	F122-GC	18	WH	3544886C1
C7%%	F122-GY	16	WH	3544886C1
C7*	F122-GF	16	WH	3544886C1
C7*	F122-GK	16	WH	3544886C1
C7*	F122-GN	16	WH	3544886C1
C7*	F122-GS	16	WH	3544886C1
C7%%	F122-GP	16	WH	3544886C1
C7*	F122GAE	16	WH	3544886C1
C7^	F122-GV	16	WH	3544886C1
C8	F122B	16	GY	3544886C1
C8%%	F122B	18	GY	3544886C1
C8%%	F122X	16	GY	3544886C1
C8*	F122E	16	GY	3544886C1
C8*	F122J	16	GY	3544886C1
C8*	F122M	16	GY	3544886C1
C8*	F122R	16	GY	3544886C1
C8%%	F122A	16	GY	3544886C1
C8*	F122AK	16	GY	3544886C1
C8^	F122B	16	WH	3544886C1
C8^	F122U	16	GY	3544886C1
C9	F122C	16	GY	3544886C1
C9*#	F122C	16	BN	3544886C1
C9%%	-			
C9%%	F122C	18	GY	3544886C1
C9%%	F122Y	16	GY	3544886C1
C9%%	F122F	16	GY	3544886C1

Legend: * W/12,13 RH WDO ; %% W/12 RH WDO ; *# W/9,11 RH WDO ; ^ W/13 RH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK

Connector 10700: CHART CONTINUED FROM SHEET 034 RIGHT BODY/REAR CAP C B

CAV	CIRCUIT	GA	COLOR	TERMINAL
C3*	F133C	18	LTGN	3544886C1
C3*	F133E	18	LTGN	3544886C1
C3*	F133F	18	LTGN	3544886C1
C3*	F133H	18	LTGN	3544886C1
C3*	F133J	18	LTGN	3544886C1
C3*	F133K	18	LTGN	3544886C1
C3*	F133T	18	LTGN	3544886C1
C3*	F133M	18	LTGN	3544886C1
C3*	F133N	18	LTGN	3544886C1
C3*	F133P	18	LTGN	3544886C1
C3*	F133R	18	LTGN	3544886C1
C3*	F133S	18	LTGN	3544886C1
C3*	F133T	18	LTGN	3544886C1
C3^	F133L	18	LTGN	3544886C1
C4	F122-GA	16	WH	3544886C1
C4%%	F122-GA	18	WH	3544886C1
C4%%	F122-GW	16	WH	3544886C1
C4*	F122-GD	16	WH	3544886C1
C4*	F122-GH	16	WH	3544886C1
C4*	F122-GL	16	WH	3544886C1
C4*	F122-GP	16	WH	3544886C1
C4*	F122-GT	16	WH	3544886C1
C4*	F122GAC	16	WH	3544886C1
C4^	F122-GA	16	GY	3544886C1
C5	F122-GB	16	WH	3544886C1
C5%%	F122-GB	18	WH	3544886C1
C5%%	F122-GX	16	WH	3544886C1

25.39. CONNECTOR COMPOSITES @10700, P. 36
Figure 1329 CONNECTOR COMPOSITES @10700

25.39. CONNECTOR COMPOSITES @10700, P. 36 | Figure 1329 CONNECTOR COMPOSITES @10700 | printed page 1329

Connector 10700: RIGHT BODY/REAR CAP C B

CAV	CIRCUIT	GA	COLOR	TERMINAL
C9%%	F122K	16	GY	3544886C1
C9%%	F122N	16	GY	3544886C1
C9%%	F122S	16	GY	3544886C1
C9%%	F122B	16	GY	3544886C1
C9*	F122AL	16	GY	3544886C1
C10	F122D	16	GY	3544886C1
C10*#	F122D	16	BK	3544886C1
C10%%	F122AC	18	GY	3544886C1
C10%%	F122AD	16	GY	3544886C1
C10%%	F122AE	16	GY	3544886C1
C10%%	F122AF	16	GY	3544886C1
C10%%	F122AH	16	GY	3544886C1
C10%%	F122AK	16	GY	3544886C1
C11	-	-	-	-
C12*	F141	16	LTGN	3544886C1
D1*	F122AM	16	GY	3544886C1
D2*	F122AN	16	GY	3544886C1
D3*	F122AP	16	GY	3544880C1
D4-D8	-	-	-	-

Legend: * W/12,13 RH WDO ; ** W/5,7,8,10,11 RH WDO ; %% W/12 RH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK

25.40. CONNECTOR COMPOSITES @10701, P. 37 | Figure 1330 CONNECTOR COMPOSITES @10701 | printed page 1330

Connector 10701: SPLICE PACK GROUND LIGHTS K B B B*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F11-GA	16	WH	1661209C1
B	F57-G	18	WH	1661208C1
B	F58-GB	18	WH	1661208C1
B*	F58-GD	18	WH	1661208C1
B#	F58-GH	18	WH	1661208C1
C%	F58-GA	18	WH	1661208C1
C	F57-GB	18	WH	1661208C1
D	F57-GC	18	WH	1661208C1
D*	F58-GE	18	WH	1661208C1
D**	F58-GJ	18	WH	1661208C1
E	F57-GF	18	WH	1661208C1
E%%	F57-GH	18	WH	1661208C1
E#*	F58-GC	18	WH	1661208C1
E*#	F57-GD	18	WH	1661208C1
E*#	F57-GE	18	WH	1661208C1
F%	F58-GC	18	WH	1661208C1
G	F58-GA	18	WH	1661208C1
H	F63-G	16	WH	1661209C1
H%*	F63-GK	16	WH	1661209C1
H%*	F63-GA	16	WH	1661209C1
H	F63-GF	16	WH	1661209C1
H**	F63-G	12	WH	3566715C1
J	F63-GA	16	WH	1661209C1
K	F120-G	18	WH	1661208C1

Legend: * W/5,13 RH WDO ; # W/6 TO 11 RH WDO ; % W/5,8 RH WDO ; ** W/6 TO 12 RH WDO ; *# W/8 TO 13 RH WDO ; #* W/6,7,9 TO 13 RH WDO ; %% W/5 TO 9,12 RH WDO ; ** W/12,13 RH WDO ; %* W/9 RH WDO

25.41. CONNECTOR COMPOSITES @10702, @10703, P. 38 | Figure 1331 CONNECTOR COMPOSITES @10702, @10703 | printed page 1331

Connector 10702: INC. SPLICE PACK GROUND LIGHTS K B C C*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F11-GB	16	WH	1661209C1
B	F126-G	18	WH	1661208C1
C	F143GAL	18	WH	1661208C1
C*	F143GAM	18	WH	1661208C1
C#	F143-GT	18	WH	1661208C1
C**	F143-GU	18	WH	1661208C1
C**	F143-GV	18	WH	1661208C1
C**	F143-GW	18	WH	1661208C1
C##	F143-GY	18	WH	1661208C1
C#*	F143-GX	18	WH	1661208C1
C*#	F143-GP	18	WH	1661208C1
C*#	F143-GR	18	WH	1661208C1
C*#	F143-GS	18	WH	1661208C1
C%%	F143-GZ	18	WH	1661208C1
C%%	F143GAA	18	WH	1661208C1
C%%	F143GAB	18	WH	1661208C1
D	F130-GA	18	WH	1661208C1
D*	F130-GB	18	WH	1661208C1
D#	F130-G	18	WH	1661208C1
D&	F130-GC	18	WH	1661208C1
D&	F130-GD	18	WH	1661208C1
D	F141-G	16	WH	1661209C1
E*#	F130-G	18	WH	1661208C1
E	F63-GX	16	WH	1661209C1
F	F143-G	18	WH	1661208C1
G#*	F141-G	16	WH	1661209C1
H*#	F12-G	18	WH	1661208C1

Legend: J-K - - - ; * W/7 TO 11,13 RH WDO ; # W/8 TO 13 RH WDO ; ** W/9 TO 13 RH WDO ; ## W/ 11,13 RH WDO ; #* W/12,13 RH WDO ; *# W/ 12 RH WDO ; %% W/13 RH WDO ; & W/9,10 RH WDO

Connector 10703: SPARE WIRE CAV A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F124	16	LTGN	0239805R1

25.42. CONNECTOR COMPOSITES @10704, P. 39 | Figure 1332 CONNECTOR COMPOSITES @10704 | printed page 1332

Connector 10704: ANY WAY DETRIMENTAL TO THE INTEREST OF INC. COMBO SPLICE CONNECTOR A ML B B* B#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F57B	16	LTGN	3534165C1
B	F57A	18	LTGN	3534164C1
B*	F57C	18	LTGN	3534164C1
B#	F57F	18	LTGN	3534164C1
B*#	F58H	18	BN	3534164C1
C	F57B	18	LTGN	3534164C1
C**	F57B	18	LTGN	3534164C1
D	F57C	18	LTGN	3534164C1
D#*	F58J	18	BN	3534164C1
E##	F57D	18	LTGN	3534164C1
E&	F57K	18	LTGN	3534164C1
F##	F57E	18	LTGN	3534164C1
F	F57H	18	LTGN	3534164C1
F&&	F57L	18	LTGN	3534164C1
F&#	F57J	18	LTGN	3534164C1
F^	F58J	18	BN	3534164C1
G&&	F58B	16	BN	3534165C1
G^^	F58BJ	16	BN	3534165C1
G&*	F58J	16	BN	3534165C1
H###	F58A	18	BN	3534164C1
H&&	F122	16	BN	3534165C1
J	F58B	18	BN	3534164C1
J***	F58H	18	BN	3534164C1
J**	F58D	18	BN	3534164C1
K&&	F58D	18	BN	3534164C1
K	F58C	18	BN	3534164C1
K***	F58J	18	BN	3534164C1
K*^	F58E	18	BN	3534164C1
L	F143	18	DKBL	3534164C1
L###	F143AL	18	DKBL	3534164C1
L	F143T	18	DKBL	3534164C1
L	F143AM	18	DKBL	3534164C1
L	F143U	18	DKBL	3534164C1
L	F143V	18	DKBL	3534164C1
L	F143W	18	DKBL	3534164C1
L*	F143X	18	DKBL	3534164C1
L&&	F143P	18	DKBL	3534164C1
L	F143Y	18	DKBL	3534164C1
L&&	F143R	18	DKBL	3534164C1
L**	F143Z	18	DKBL	3534164C1
L&&	F143S	18	DKBL	3534164C1
L**	F143AA	18	DKBL	3534164C1
L**	F143AB	18	DKBL	3534164C1
M	F58D	18	BN	3534164C1

25.43. CONNECTOR COMPOSITES @10705, #10706, @10706A, P. 40 | Figure 1333 CONNECTOR COMPOSITES @10705, #10706, @10706A | printed page 1333

Connector 10705:

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F57C	18	LTGN	1661261C1
B	F57-GC	18	WH	1661261C1

Connector 10706: SIDE DIR LT OVER REAR WHL PKT FE

CAV	CIRCUIT	GA	COLOR	TERMINAL
A%	F57K	18	LTGN	1661261C1
A@	F57D	18	LTGN	1661261C1
B%	F57-GH	18	WH	1661261C1
B@	F57-GD	18	WH	1661261C1

Legend: @ W/9,10,12,13 RH WDO ; % W/6 RH WDO ; # W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK

Connector 10706A: SIDE DIR LT OVER REAR WHL PKT-F

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F57D	18	LTGN	1661261C1
A	F57K	18	LTGN	1661261C1
B	F57-GD	18	WH	1661261C1
B	F57-GH	18	WH	1661261C1

25.44. CONNECTOR COMPOSITES @10706B, %10707, %10707A, %10707B, %10708, P. 41 | Figure 1334 CONNECTOR COMPOSITES @10706B, %10707, %10707A, %10707B, %10708 | printed page 1334

Connector 10706B: SIDE DIR LT OVER REAR WHL PKT CE A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F57D	18	LTGN	1661261C1
B	F57-GD	18	WH	1661261C1

Connector 10706B: SIDE DIR LT OVER REAR WHL PKT CE A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A@	F57E	18	LTGN	1661261C1
A!	F57J	18	LTGN	1661261C1
B@	F57-GE	18	WH	1661261C1
B!	F57-GF	18	WH	1661261C1

Connector 10708: SIDE DIR/MKR LT FWD REAR WHL PKT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A@	F57H	18	LTGN	1661261C1
A!	F57H	18	LTGN	1661261C1
B@	F58C	18	BN	1661261C1
B!	F58C	18	BN	1661261C1
C@	F58-GC	18	WH	1661261C1
C!	F58-GC	18	WH	1661261C1

Legend: @ W/5,8 TO 13 RH WDO ; ! W/6 RH WDO ; % W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCKO

25.45. CONNECTOR COMPOSITES @10708A, @10708B, %10709, !10709A, %10710,
Figure 1335 CONNECTOR COMPOSITES @10708A, @10708B, %10709, !10709A, %10710, !10710A

25.45. CONNECTOR COMPOSITES @10708A, @10708B, %10709, !10709A, %10710, | Figure 1335 CONNECTOR COMPOSITES @10708A, @10708B, %10709, !10709A, %10710, !10710A | printed page 1335

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	F57L	18	LTGN	1661261C1
A*	F57H	18	LTGN	1661261C1
B#	F58D	18	BN	1661261C1
B*	F58C	18	BN	1661261C1
C*	F58-GC	18	WH	1661261C1
C#	F58-GH	18	WH	1661261C1

Legend: * W/7,13 RH WDO ; # W/12 RH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F57B	18	LTGN	1661261C1
B	F57-GB	18	WH	1661261C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F58A	18	BN	1661261C1
B	F58-GA	18	WH	1661261C1

25.46. CONNECTOR COMPOSITES @10711, @10712, @10713, P. 43 | Figure 1336 CONNECTOR COMPOSITES @10711, @10712, @10713 | printed page 1336

Connector 10711: A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F57A	18	LTGN	1661261C1
B	F57-G	18	WH	1661261C1

Legend: @ W/5 TO 13 RH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10712: SIDE DIR/MARKER LT AFTER ENT DR B A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	AK57F	18	LTGN	1661261C1
A#	AK57C	18	LTGN	1661261C1
B*	AK58B	18	BN	1661261C1
C*	AK58-GB	18	WH	1661261C1

Legend: * W/5 TO 11 RH WDO ; # W/12,13 RH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK

Connector 10713: SPLICE CONNECTOR KOUT WDO

CAV	CIRCUIT	GA	COLOR	TERMINAL
D*#	F126H	16	GY	3534165C1
D#*	F126J	16	GY	3534165C1
D&	F126K	16	GY	3534165C1
E&&	F126L	16	GY	3534165C1
E&*	F126M	16	GY	3534165C1
E#	F126N	16	GY	3534165C1
F^	F126P	16	GY	3534165C1
G@	F126-G	18	WH	3534164C1
H@	F126-GA	16	WH	3534165C1
H@	F126-GB	16	WH	3534165C1
H@	F126-GC	16	WH	3534165C1
J@	F126-GD	16	WH	3534165C1
J@	F126-GE	16	WH	3534165C1
J%	F126-GF	16	WH	3534165C1
K*#	F126-GH	16	WH	3534165C1
K#*	F126-GJ	16	WH	3534165C1
K&	F126-GK	16	WH	3534165C1
L&&	F126-GL	16	WH	3534165C1
L&*	F126-GM	16	WH	3534165C1
L#	F126-GN	16	WH	3534165C1
M^	F126-GP	16	WH	3534165C1

Legend: # W/12,13 RH WDO ; * W/5 TO 11 RH WDO ; *# W/7 TO 13 RH WDO ; #* W/8 TO 13 RH WDO ; & W/9 TO 13 RH WDO ; && W/10 TO 13 RH WDO ; &* W/11,12,13 RH WDO ; ^ W/13 RH WDO ; % W/6 TO 13 RH WDO

Connector 10713: SPLICE CONNECTOR KOUT WDO

CAV	CIRCUIT	GA	COLOR	TERMINAL
A@	F126B	18	GY	3534164C1
B@	F126A	16	GY	3534165C1
B#	F126	16	GY	3534165C1
B*	F126B	16	GY	3534165C1
B@	F126C	16	GY	3534165C1
C@	F126D	16	GY	3534165C1
C@	F126E	16	GY	3534165C1
C%	F126F	16	GY	3534165C1

25.47. CONNECTOR COMPOSITES @@10714, P. 44 | Figure 1337 CONNECTOR COMPOSITES @@10714 | printed page 1337

Connector 10714: SPLICE CONNECTOR EMER EXIT WDO A ML

CAV	CIRCUIT	GA	COLOR	TERMINAL
H!!	F143-GC	18	WH	3534164C1
H@	F143GAN	18	WH	3534164C1
H^^	F143GAP	18	WH	3534164C1
H*&	F143GAB	18	WH	3534164C1
H++	F143GAR	18	WH	3534164C1
H*%	F143GAS	18	WH	3534164C1
H*	F143GAT	18	WH	3534164C1
J!!	F143-GD	18	WH	3534164C1
J!!	F143-GE	18	WH	3534164C1
J##	F143-GF	18	WH	3534164C1
J++	F143-GA	18	WH	3534164C1
J#	F143GAC	18	WH	3534164C1
J!	F143GAD	18	WH	3534164C1
J&	F143GAR	18	WH	3534164C1
J&	F143GAS	18	WH	3534164C1
K+	F143-GH	18	WH	3534164C1
K&&	F143-GJ	18	WH	3534164C1
K#*	F143-GK	18	WH	3534164C1
K%	F143GAE	18	WH	3534164C1
K%	F143GAF	18	WH	3534164C1
K**	F143GAH	18	WH	3534164C1
K**	F143GAJ	18	WH	3534164C1
K**	F143GAK	18	WH	3534164C1
K**	F143GAL	18	WH	3534164C1
L#	F143-GL	18	WH	3534164C1
L!	F143-GM	18	WH	3534164C1
L%	F143-GN	18	WH	3534164C1
L^	F143GAH	18	WH	3534164C1
L^	F143GAJ	18	WH	3534164C1
M^	F143GAK	18	WH	3534164C1
M**	F143-GP	18	WH	3534164C1

Connector 10714: SPLICE CONNECTOR EMER EXIT WDO A ML

CAV	CIRCUIT	GA	COLOR	TERMINAL
A!!	F143	18	DKBL	3534164C1
B!!	F143A	18	DKBL	3534164C1
B!!	F143B	18	DKBL	3534164C1
B!!	F143C	18	DKBL	3534164C1
B@	F143AN	18	DKBL	3534164C1
B^^	F143AP	18	DKBL	3534164C1
B&&	F143AB	18	DKBL	3534164C1
B++	F143AR	18	DKBL	3534164C1
B*%	F143AS	18	DKBL	3534164C1
B*	F143AT	18	DKBL	3534164C1
C!!	F143D	18	DKBL	3534164C1
C!!	F143E	18	DKBL	3534164C1
C##	F143F	18	DKBL	3534164C1
C#*	F143AC	18	DKBL	3534164C1
C!	F143AD	18	DKBL	3534164C1
C&	F143AR	18	DKBL	3534164C1
C&	F143AS	18	DKBL	3534164C1
D+	F143H	18	DKBL	3534164C1
D&&	F143J	18	DKBL	3534164C1
D#*	F143K	18	DKBL	3534164C1
D%	F143AE	18	DKBL	3534164C1
D%	F143AF	18	DKBL	3534164C1
D**	F143AH	18	DKBL	3534164C1
D**	F143AJ	18	DKBL	3534164C1
D**	F143AK	18	DKBL	3534164C1
D**	F143AL	18	DKBL	3534164C1
E#	F143L	18	DKBL	3534164C1
E!	F143M	18	DKBL	3534164C1
E%	F143N	18	DKBL	3534164C1
E^	F143AH	18	DKBL	3534164C1
E^	F143AJ	18	DKBL	3534164C1
F^	F143AK	18	DKBL	3534164C1
F**	F143P	18	DKBL	3534164C1
G!!	F143-G	18	WH	3534164C1
H!!	F143-GA	18	WH	3534164C1
H!!	F143-GB	18	WH	3534164C1

Figure 1338 CONNECTOR COMPOSITES @10715, @10716, @10717

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 25.48. CONNECTOR COMPOSITES @10715, @10716, @10717, P. 45 / CHAPTER 25 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090676 NO. RELEASE NO. 95504E 28FEB20 / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / KOUT WDO SECT 1 @(10715) (LOCATED AT RIGHT BODY) / KOUT WDO SECT 2 @(10716) (LOCATED AT RIGHT BODY) / KOUT WDO SECT 3 @(10717) (LOCATED AT RIGHT BODY) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / @ W/5 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / * W/12,13 RH WDO # W/5 TO 11 RH WDO & W/5 TO 13 RH WDO @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / @ W/5 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / A B / A B / A B / CAV CIRCUIT GA COLOR TERMINAL A F126A 16 GY 1661261C1 B F126-GA 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A* F126 16 GY 1661261C1 A# F126B 16 GY 1661261C1 B& F126-GB 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F126C 16 GY 1661261C1 B F126-GC 16 WH 1661261C1 / Figure 1338 / CONNECTOR COMPOSITES @10715, @10716, @10717

Connector 10715: KOUT WDO SECT 1 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F126A	16	GY	1661261C1
B	F126-GA	16	WH	1661261C1

Legend: @ W/5 TO 13 RH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10716: KOUT WDO SECT 2 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F126	16	GY	1661261C1
A#	F126B	16	GY	1661261C1
B&	F126-GB	16	WH	1661261C1

Legend: * W/12,13 RH WDO ; # W/5 TO 11 RH WDO ; & W/5 TO 13 RH WDO ; @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT MTA ; FUSE BLOCK

Connector 10717: KOUT WDO SECT 3 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F126C	16	GY	1661261C1
B	F126-GC	16	WH	1661261C1

Legend: @ W/5 TO 13 RH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

25.49. CONNECTOR COMPOSITES @10718, @10719, @10720, P. 46
Figure 1339 CONNECTOR COMPOSITES @10718, @10719, @10720

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 25.49. CONNECTOR COMPOSITES @10718, @10719, @10720, P. 46 / CHAPTER 25 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090676 NO. RELEASE NO. 95504E 28FEB20 / MJV0488 13SEP21 ADDED NOTES FOR FUSE B BLOCK. / KOUT WDO SECT 4 @(10718) (LOCATED AT RIGHT BODY) / KOUT WDO SECT 5 @(10719) (LOCATED AT RIGHT BODY) / KOUT WDO SECT 6 @(10720) (LOCATED AT RIGHT BODY) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / @ W/5 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / @ W/5 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / @ W/6 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / A B / A B / A B / CAV CIRCUIT GA COLOR TERMINAL A F126D 16 GY 1661261C1 B F126-GD 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F126E 16 GY 1661261C1 B F126-GE 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F126F 16 GY 1661261C1 B F126-GF 16 WH 1661261C1 / Figure 1339 / CONNECTOR COMPOSITES @10718, @10719, @10720

Connector 10718: KOUT WDO SECT 4 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F126D	16	GY	1661261C1
B	F126-GD	16	WH	1661261C1

Connector 10719: KOUT WDO SECT 5 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F126E	16	GY	1661261C1
B	F126-GE	16	WH	1661261C1

Legend: @ W/5 TO 13 RH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10720: KOUT WDO SECT 6 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F126F	16	GY	1661261C1
B	F126-GF	16	WH	1661261C1

Legend: @ W/6 TO 13 RH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

25.50. CONNECTOR COMPOSITES @10721, @10722, @10723, P. 47
Figure 1340 CONNECTOR COMPOSITES @10721, @10722, @10723

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 25.50. CONNECTOR COMPOSITES @10721, @10722, @10723, P. 47 / CHAPTER 25 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090676 NO. RELEASE NO. 95504E 28FEB20 / MJV0488 13SEP21 ADDED NOTES FOR FUSE B BLOCK. / KOUT WDO SECT 7 @(10721) (LOCATED AT RIGHT BODY) / KOUT WDO SECT 8 @(10722) (LOCATED AT RIGHT BODY) / KOUT WDO SECT 9 @(10723) (LOCATED AT RIGHT BODY) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / @ W/7 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / A B / A B / A B / @ W/8 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / @ W/9 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A F126H 16 GY 1661261C1 B F126-GH 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F126J 16 GY 1661261C1 B F126-GJ 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F126K 16 GY 1661261C1 B F126-GK 16 WH 1661261C1 / Figure 1340 / CONNECTOR COMPOSITES @10721, @10722, @10723

Connector 10721: KOUT WDO SECT 7 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F126H	16	GY	1661261C1
B	F126-GH	16	WH	1661261C1

Connector 10722: KOUT WDO SECT 8 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F126J	16	GY	1661261C1
B	F126-GJ	16	WH	1661261C1

Connector 10723: KOUT WDO SECT 9 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F126K	16	GY	1661261C1
B	F126-GK	16	WH	1661261C1

Legend: @ W/9 TO 13 RH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

25.51. CONNECTOR COMPOSITES @10724, @10725, @10726, P. 48
Figure 1341 CONNECTOR COMPOSITES @10724, @10725, @10726

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 25.51. CONNECTOR COMPOSITES @10724, @10725, @10726, P. 48 / CHAPTER 25 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090676 NO. RELEASE NO. 95504E 28FEB20 / MJV0488 13SEP21 ADDED NOTES FOR FUSE B BLOCK. / KOUT WDO SECT 10 @(10724) (LOCATED AT RIGHT BODY) / KOUT WDO SECT 11 @(10725) (LOCATED AT RIGHT BODY) / KOUT WDO SECT 12 @(10726) (LOCATED AT RIGHT BODY) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / @ W/10 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / A B / A B / A B / @ W/11 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / @ W/12 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A F126L 16 GY 1661261C1 B F126-GL 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F126M 16 GY 1661261C1 B F126-GM 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F126N 16 GY 1661261C1 B F126-GN 16 WH 1661261C1 / Figure 1341 / CONNECTOR COMPOSITES @10724, @10725, @10726

Connector 10724: KOUT WDO SECT 10 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F126L	16	GY	1661261C1
B	F126-GL	16	WH	1661261C1

Legend: @ W/10 TO 13 RH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10725: KOUT WDO SECT 11 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F126M	16	GY	1661261C1
B	F126-GM	16	WH	1661261C1

Connector 10726: KOUT WDO SECT 12 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F126N	16	GY	1661261C1
B	F126-GN	16	WH	1661261C1

Legend: @ W/12 TO 13 RH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Figure 1342 CONNECTOR COMPOSITES @10727, @10730, @10731

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 25.52. CONNECTOR COMPOSITES @10727, @10730, @10731, P. 49 / CHAPTER 25 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090676 NO. RELEASE NO. 95504E 28FEB20 / MJV0488 13SEP21 ADDED NOTES FOR FUSE B BLOCK / KOUT WDO SECT 13 @(10727) (LOCATED AT RIGHT BODY) / EMER EXIT LT @(10730) (LOCATED AT RIGHT BODY) / EMER EXIT LT @(10731) (LOCATED AT RIGHT BODY) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / @ W/13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / A B / A B / A B / @ W/5 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A F126P 16 GY 1661261C1 B F126-GP 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F143A 18 DKBL 1661261C1 B F143-GA 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F143B 18 DKBL 1661261C1 B F143-GB 18 WH 1661261C1 / Figure 1342 / CONNECTOR COMPOSITES @10727, @10730, @10731

Connector 10727: KOUT WDO SECT 13 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F126P	16	GY	1661261C1
B	F126-GP	16	WH	1661261C1

Legend: @ W/13 RH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10730: EMER EXIT LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F143A	18	DKBL	1661261C1
B	F143-GA	18	WH	1661261C1

Legend: @ W/5 TO 13 RH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Connector 10731: EMER EXIT LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F143B	18	DKBL	1661261C1
B	F143-GB	18	WH	1661261C1

Legend: @ W/5 TO 13 RH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK

Figure 1343 CONNECTOR COMPOSITES @10732, @10733, @10734

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 25.53. CONNECTOR COMPOSITES @10732, @10733, @10734, P. 50 / CHAPTER 25 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090676 NO. RELEASE NO. 95504E 28FEB20 / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / EMER EXIT LT @(10732) (LOCATED AT RIGHT BODY) / EMER EXIT LT @(10733) (LOCATED AT RIGHT BODY) / EMER EXIT LT @(10734) (LOCATED AT RIGHT BODY) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / @ W/5 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / A B / A B / A B / @ W/5 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / @ W/5 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A F143C 18 DKBL 1661261C1 B F143-GC 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F143D 18 DKBL 1661261C1 B F143-GD 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F143E 18 DKBL 1661261C1 B F143-GE 18 WH 1661261C1 / Figure 1343 / CONNECTOR COMPOSITES @10732, @10733, @10734

Connector 10732: EMER EXIT LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F143C	18	DKBL	1661261C1
B	F143-GC	18	WH	1661261C1

Legend: @ W/5 TO 13 RH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10733: EMER EXIT LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F143D	18	DKBL	1661261C1
B	F143-GD	18	WH	1661261C1

Connector 10734: EMER EXIT LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F143E	18	DKBL	1661261C1
B	F143-GE	18	WH	1661261C1

Legend: @ W/5 TO 13 RH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

25.54. CONNECTOR COMPOSITES @10735, @10736, @10737, P. 51
Figure 1344 CONNECTOR COMPOSITES @10735, @10736, @10737

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 25.54. CONNECTOR COMPOSITES @10735, @10736, @10737, P. 51 / CHAPTER 25 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090676 NO. RELEASE NO. 95504E 28FEB20 / MJV0488 13SEP21 ADDED NOTES FOR FUSE B BLOCK. / EMER EXIT LT @(10735) (LOCATED AT RIGHT BODY) / EMER EXIT LT @(10736) (LOCATED AT RIGHT BODY) / EMER EXIT LT @(10737) (LOCATED AT RIGHT BODY) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / @ W/6 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / A B / A B / A B / @ W/7 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / @ W/8 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A F143F 18 DKBL 1661261C1 B F143-GF 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F143H 18 DKBL 1661261C1 B F143-GH 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F143J 18 DKBL 1661261C1 B F143-GJ 18 WH 1661261C1 / Figure 1344 / CONNECTOR COMPOSITES @10735, @10736, @10737

Connector 10735: EMER EXIT LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F143F	18	DKBL	1661261C1
B	F143-GF	18	WH	1661261C1

Legend: @ W/6 TO 13 RH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10736: EMER EXIT LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F143H	18	DKBL	1661261C1
B	F143-GH	18	WH	1661261C1

Legend: @ W/7 TO 13 RH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10737: EMER EXIT LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F143J	18	DKBL	1661261C1
B	F143-GJ	18	WH	1661261C1

Legend: @ W/8 TO 13 RH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Figure 1345 CONNECTOR COMPOSITES @10738, @10739, @10740

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 25.55. CONNECTOR COMPOSITES @10738, @10739, @10740, P. 52 / CHAPTER 25 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090676 NO. RELEASE NO. 95504E 28FEB20 / MJV0488 13SEP21 ADDED NOTES FOR FUSE BLOCK. / EMER EXIT LT @(10738) (LOCATED AT RIGHT BODY) / EMER EXIT LT @(10739) (LOCATED AT RIGHT BODY) / EMER EXIT LT @(10740) (LOCATED AT RIGHT BODY) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / @ W/9 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / A B / A B / A B / @ W/10 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / @ W/11 TO 13 RH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A F143K 18 DKBL 1661261C1 B F143-GK 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F143L 18 DKBL 1661261C1 B F143-GL 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F143M 18 DKBL 1661261C1 B F143-GM 18 WH 1661261C1 / Figure 1345 / CONNECTOR COMPOSITES @10738, @10739, @10740

Connector 10738: EMER EXIT LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F143K	18	DKBL	1661261C1
B	F143-GK	18	WH	1661261C1

Legend: @ W/9 TO 13 RH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Connector 10739: EMER EXIT LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F143L	18	DKBL	1661261C1
B	F143-GL	18	WH	1661261C1

Connector 10740: EMER EXIT LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F143M	18	DKBL	1661261C1
B	F143-GM	18	WH	1661261C1

Legend: @ W/11 TO 13 RH WDO W/COMMON FOR VEHICLE ; W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT MTA FUSE BLOCK

Figure 1346 CONNECTOR COMPOSITES @10741, @10742, *10751, *10751A

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / CONNECTOR COMPOSITE (10741-84331) (CHAPTER 26) / 26.1. CONNECTOR COMPOSITES @10741, @10742, *10751, *10751A, P. 1 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090677 NO. RELEASE NO. 95504E 28FEB20 / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / EMER EXIT LT @(10741) (LOCATED AT RIGHT BODY) / EMER EXIT LT @(10742) (LOCATED AT RIGHT BODY) / PARK BRAKE ALARM (-) *(10751) (LOCATED INSIDE CABIN) / CONNECTOR 2206658C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/12,13 RH WDO / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/13 RH WDO / A B / A B / PARK BRAKE ALARM (+) *(10751A) (LOCATED INSIDE CABIN COMPARTMENT) / CONNECTOR 2206658C1 / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A F143N 18 DKBL 1661261C1 B F143-GN 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F143P 18 DKBL 1661261C1 B F143-GP 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A A79F 16 GY 0239805R1 / CAV CIRCUIT GA COLOR TERMINAL A A79L-G 16 WH 0239805R1 / Figure 1346 / CONNECTOR COMPOSITES @10741, @10742, *10751, *10751A

Connector 10741: EMER EXIT LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F143N	18	DKBL	1661261C1
B	F143-GN	18	WH	1661261C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/12,13 RH WDO

Connector 10742: EMER EXIT LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F143P	18	DKBL	1661261C1
B	F143-GP	18	WH	1661261C1

Legend: W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK W/13 RH WDO

Connector 10751: PARK BRAKE ALARM (-)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A79L-G	16	WH	0239805R1

Connector 10751A: PARK BRAKE ALARM (+) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A79F	16	GY	0239805R1

Figure 1347 CONNECTOR COMPOSITES @10757, &10757A, &10757B

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.2. CONNECTOR COMPOSITES @10757, &10757A, &10757B, P. 2 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090677 NO. RELEASE NO. 95504E 28FEB20 / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / DOME LT SECT 1 @(10757) (LOCATED AT RIGHT BODY) / DOME LT OVER EACH SEAT &(10757A) (LOCATED AT RIGHT BODY) A B / 12 DOME LT &(10757B) (LOCATED AT RIGHT BODY) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / A B / A B / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK & W/5-9 RH WDO * W/5-6 RH WDO % W/5-13 RH WDO / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK *W/9 RH WDO / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK * W/9 RH WDO / CAV CIRCUIT GA COLOR TERMINAL A% F63A 16 DKBL 1661261C1 A* F63U 16 DKBL 1661261C1 B& F63-GA 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A* F63AA 16 DKBL 1661261C1 B* F63-GV 16 DKBL 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A* F63A 16 DKBL 1661261C1 B* F63A-G 16 WH 1661261C1 / Figure 1347 / CONNECTOR COMPOSITES @10757, &10757A, &10757B

Connector 10757: DOME LT SECT 1 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A%	F63A	16	DKBL	1661261C1
A*	F63U	16	DKBL	1661261C1
B&	F63-GA	16	WH	1661261C1

Connector 10757A: DOME LT OVER EACH SEAT A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F63AA	16	DKBL	1661261C1
B*	F63-GV	16	DKBL	1661261C1

Connector 10757B: 12 DOME LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F63A	16	DKBL	1661261C1
B*	F63A-G	16	WH	1661261C1

26.3. CONNECTOR COMPOSITES *10758, *10758A, &10759, P. 3 | Figure 1348 CONNECTOR COMPOSITES *10758, *10758A, &10759 | printed page 1348

Connector 10758: DOME LT SECT 3 A CAV A%

CAV	CIRCUIT	GA	COLOR	TERMINAL
A%	F63B	16	DKBL	1661261C1
A%	F63U	16	DKBL	1661261C1
A#	F63AU	16	DKBL	1661261C1
B%	F63-GB	16	WH	1661261C1
B#	F63-G	16	WH	1661261C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; % W/5-13 RH WDO ; # W/5-6 RH WDO

Connector 10758A: DOME LT OVER EACH SEAT A B CAV A@

CAV	CIRCUIT	GA	COLOR	TERMINAL
A@	F63AB	16	DKBL	1661261C1
B@	F63-GW	16	DKBL	1661261C1

Connector 10759: DOME LT SECT 5 A CAV A%

CAV	CIRCUIT	GA	COLOR	TERMINAL
A%	F63C	16	DKBL	1661261C1
A*	F63M	16	DKBL	1661261C1
A#	F63AU	16	DKBL	1661261C1
B%	F63-GC	16	WH	1661261C1

26.4. CONNECTOR COMPOSITES &10760, *10760A, &10761, P. 4 | Figure 1349 CONNECTOR COMPOSITES &10760, *10760A, &10761 | printed page 1349

Connector 10760: DOME LT SECT 7 A CAV A*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F63D	16	DKBL	1661261C1
A#	F63M	16	DKBL	1661261C1
A%	F63AU	16	DKBL	1661261C1
B*	F63-GD	16	WH	1661261C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/7-13 RH WDO ; # W/7-10 RH WDO ; % W/7-11 RH WDO

Connector 10760A: 12 DOME LT A CAV A*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F63E	16	DKBL	1661261C1
B*	F63E-G	16	WH	1661261C1

Connector 10761: DOME LT SECT 9 A CAV A* A*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F63E	16	DKBL	1661261C1
A*	F63M	16	DKBL	1661261C1
A#	F63R	16	DKBL	1661261C1
B*	F63-GE	16	WH	1661261C1

26.5. CONNECTOR COMPOSITES &10761A, &10762, @10763, P. 5 | Figure 1350 CONNECTOR COMPOSITES &10761A, &10762, @10763 | printed page 1350

Connector 10761A: A CAV A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63F	16	DKBL	1661261C1
B	F63F-G	16	WH	1661261C1

Connector 10762: DOME LT SECT 11 A CAV A@ A@

CAV	CIRCUIT	GA	COLOR	TERMINAL
A@	F63F	16	DKBL	1661261C1
A@	F63M	16	DKBL	1661261C1
A@	F63N	16	DKBL	1661261C1
A*	F63J	16	DKBL	1661261C1
B@	F63-GF	16	WH	1661261C1

Connector 10763: DOME LT SECT 13 A CAV A A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63H	16	DKBL	1661261C1
A	F63M	16	DKBL	1661261C1
A	F63P	16	DKBL	1661261C1
B	F63-GH	16	WH	1661261C1

Figure 1351 CONNECTOR COMPOSITES @10765B, @10765C, @10765D

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.6. CONNECTOR COMPOSITES @10765B, @10765C, @10765D, P. 6 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090677 NO. RELEASE NO. 95504E 28FEB20 / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / ACTIVITY DOME LT @(10765B) (LOCATED AT RIGHT BODY) / ACTIVITY LT SECT 10 @(10765C) (LOCATED AT RIGHT BODY) / ACTIVITY DOME LT @(10765D) (LOCATED AT RIGHT BODY) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/10 RH WDO / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/5,9 RH WDO / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/RH BODY 13 WDO / A B / A B / A B / CAV CIRCUIT GA COLOR TERMINAL A F63X 16 DKBL 1661261C1 B F63-GX 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F63AS 16 DKBL 1661261C1 B F63-GX 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F63AS 16 DKBL 1661261C1 B F63-GX 16 WH 1661261C1 / Figure 1351 / CONNECTOR COMPOSITES @10765B, @10765C, @10765D

Connector 10765B: A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63X	16	DKBL	1661261C1
B	F63-GX	16	WH	1661261C1

Connector 10765C: ACTIVITY LT SECT 10 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63AS	16	DKBL	1661261C1
B	F63-GX	16	WH	1661261C1

Connector 10765D: ACTIVITY DOME LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63AS	16	DKBL	1661261C1
B	F63-GX	16	WH	1661261C1

26.7. CONNECTOR COMPOSITES @10767, @10768, %10769C, P. 7 | Figure 1352 CONNECTOR COMPOSITES @10767, @10768, %10769C | printed page 1352

Connector 10767: CAV ACCESSORY SPLICE A* B& B## B**

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A*	F12A	16	LTBL	3535303C1	3535424C1
A#	F12C	16	LTBL	3535303C1	3535424C1
B&	F12B	18	BK	3535303C1	3535424C1
B##	F12B	18	LTBL	3535303C1	3535424C1
B**	F12U	18	LTBL	3535303C1	3535424C
B*#	F12V	18	LTBL	3535303C1	3535424C1
B#*	F12A	18	LTBL	3535303C1	3535424C1
B&&	F12C	18	LTBL	3535303C1	3535424C1
B&*	F12W	18	LTBL	3535303C1	3535424C1
B&*	F12X	18	LTBL	3535303C1	3535424C1
B&&	F12D	18	LTBL	3535303C1	3535424C1
B^	F12E	18	LTBL	3535303C1	3535424C1
C^^	F12C	18	LTBL	3535303C1	3535424C1

Legend: D-F PLUG - - 3535425C1 - ; @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/12,13 RH WDO ; # W/5,7 TO 11 RH WDO ; & W/13 RH WDO ; ## W/9 TO 12 RH WDO ; ** W/5 TO 13 RH WDO ; *# W/7 TO 13 RH WDO

Connector 10768: GUARD DOME LT SECT 1 A CAV A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63BE	16	DKBL	1661261C1
B	F63-GA	16	WH	1661261C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK W/5 TO 13 RH WDO

Connector 10769C: AIR DOOR CYLINDER CAV 1* 2#

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	F120A	18	LTGN	1661539C1
2#	F120B	18	BK	1661539C1
2&	F120B	18	LTGN	1661539C1
3*	F120-G	18	WH	1661539C1

Legend: % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/8,9,12,13 RH WDO ; # W/13 RH WDO ; & W/8,9,12 RH WDO ; REV REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; FOR FUSE B 96183U ; RELEASE NO. DATE

26.8. CONNECTOR COMPOSITES !10769D, @10769E, &10769F, @10769G, P. 8 | Figure 1353 CONNECTOR COMPOSITES !10769D, @10769E, &10769F, @10769G | printed page 1353

Connector 10769D: INC. AIR DOOR CYLINDER 1 2&

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	F120A	18	LTGN	1661539C1
2&	F120B	18	LTGN	1661539C1
2#	F120B	18	BK	1661539C1
3	F120-G	18	WH	1661539C1

Legend: ! W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; & W/10 RH WDO ; # W/13 RH WDO

Connector 10769E: CONNECTOR CONNECTOR 2206660C1 2206660C1 AIR DOOR CYLINDER 1 2

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	F120A	18	LTGN	1661539C1
2	F120B	18	LTGN	1661539C1
3	F120-G	18	WH	1661539C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK W/10,11RH WDO

Connector 10769F: AIR DOOR CYLINDER 1@ 1P% 2@

CAV	CIRCUIT	GA	COLOR	TERMINAL
1@	F120A	18	LTGN	1661539C1
1P%	F120H	18	LTGN	1661538C1
2@	F120B	18	LTGN	1661539C1
2P%	F120J	18	LTGN	1661538C1
3@	F120-G	18	WH	1661539C1
3P%	F120-G	18	WH	1661538C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; @ W/11,13 RH WDO ; % W/12 RH WDO

Connector 10769G: CONNECTOR 2206660C1 % AIR DOOR CYLINDER CAV CIRCUIT

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	F120A	18	LTGN	1661539C1
2	F120B	18	LTGN	1661539C1
3	F120-G	18	WH	1661539C1

Figure 1354 CONNECTOR COMPOSITES @10770C, @10770D, @10770E, @10770F

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.9. CONNECTOR COMPOSITES @10770C, @10770D, @10770E, @10770F, P. 9 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090677 NO. RELEASE NO. 95504E 28FEB20 / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / VANDAL LOCK ALT ENT DOOR @(10770C) (LOCATED AT BODY) / VANDAL LOCK ALT ENT DOOR @(10770D) (LOCATED AT BODY) / VANDAL LOCK ALT ENT DOOR @(10770E) (LOCATED AT BODY) / CONNECTOR 1669029C1 / CONNECTOR 1669029C1 / CONNECTOR 1669029C1 / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/10,13 RH WDO / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/10,11 RH WDO / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/8,9,12,13 RH WDO / VANDAL LOCK ALT ENT DOOR @(10770F) (LOCATED AT BODY) / CONNECTOR 1669029C1 / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/11 TO 13 RH WDO / 1 2 / 1 2 / 1 2 / 1 2 / CAV CIRCUIT GA COLOR TERMINAL 1 F81B 18 LTGN 1661539C1 2 F81A 18 LTGN 1661539C1 / CAV CIRCUIT GA COLOR TERMINAL 1 F81B 18 LTGN 1661539C1 2 F81A 18 LTGN 1661539C1 / CAV CIRCUIT GA COLOR TERMINAL 1 F81B 18 LTGN 1661539C1 2 F81A 18 LTGN 1661539C1 / CAV CIRCUIT GA COLOR TERMINAL 1 F81B 18 LTGN 1661539C1 2 F81A 18 LTGN 1661539C1 / Figure 1354 / CONNECTOR COMPOSITES @10770C, @10770D, @10770E, @10770F

Connector 10770C:

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	F81B	18	LTGN	1661539C1
2	F81A	18	LTGN	1661539C1

Connector 10770D: VANDAL LOCK ALT ENT DOOR

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	F81B	18	LTGN	1661539C1
2	F81A	18	LTGN	1661539C1

Legend: FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; - NOT FUSE BLOCK W/10,13 RH WDO

Connector 10770E: VANDAL LOCK ALT ENT DOOR

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	F81B	18	LTGN	1661539C1
2	F81A	18	LTGN	1661539C1

Connector 10770F: VANDAL LOCK ALT ENT DOOR CAV CIRCUIT

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	F81B	18	LTGN	1661539C1
2	F81A	18	LTGN	1661539C1

Figure 1355 CONNECTOR COMPOSITES @10770G @10771A

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.10. CONNECTOR COMPOSITES @10770G @10771A, P. 10 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090677 NO. RELEASE NO. 95504E 28FEB20 / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / VANDAL LOCK ALT ENT DOOR @(10770G) (LOCATED AT RIGHT BODY) / SED SECT 1-2 @(10771A) (LOCATED AT RIGHT BODY) / CONNECTOR 1661889C1 BODY LOCK 1661890C1 / CONNECTOR 1669029C1 / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/13 RH WDO / A B C / 1 2 / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK # W/5 TO 11 & 13 RH WDO * W/12 RH WDO / CAV CIRCUIT GA COLOR TERMINAL 1 F81B 18 LTGN 1661539C1 2 F81A 18 LTGN 1661539C1 / Figure 1355 / CONNECTOR COMPOSITES @10770G @10771A

Connector 10770G: VANDAL LOCK ALT ENT DOOR CAV CIRCUIT

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	F81B	18	LTGN	1661539C1
2	F81A	18	LTGN	1661539C1

Connector 10771A: SED SECT 1-2 A* B*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	F130E	18	GY	1661261C1
A*	F130A	18	GY	1661261C1
B*	F130-G	18	WH	1661261C1
B#	F130-GA	18	WH	1661261C1
C*	F133A	18	LTGN	1661261C1
C#	F133D	18	LTGN	1661261C1

26.11. CONNECTOR COMPOSITES @10771B, @10771C, @10771D, P. 11 | Figure 1356 CONNECTOR COMPOSITES @10771B, @10771C, @10771D | printed page 1356

Connector 10771B: CAV SED SECT 2-3 A A# B* B#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F130A	18	GY	1661261C1
A#	F130J	18	GY	1661261C1
B*	F130-G	18	WH	1661261C1
B#	F130-GB	18	WH	1661261C1
C#	F133D	18	LTGN	1661261C1
C*	F133B	18	LTGN	1661261C1

Connector 10771C: SED SECT 3-4 CAV A B& C*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A&	F130A	18	GY	1661261C1
B&	F130-G	18	WH	1661261C1
C*	F133C	18	LTGN	1661261C1
C#	F133D	18	LTGN	1661261C1

Connector 10771D: SED SECT 4-5 A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F130A	18	GY	1661261C1
B	F130-G	18	WH	1661261C1
C	F133D	18	LTGN	1661261C1

26.12. CONNECTOR COMPOSITES @10771E, @10771F, @10771G, P. 12 | Figure 1357 CONNECTOR COMPOSITES @10771E, @10771F, @10771G | printed page 1357

Connector 10771E: SED SECT 5- 6 A A B C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F130A	18	GY	1661261C1
B	F130-G	18	WH	1661261C1
C	F133D	18	LTGN	1661261C1
C	F133E	18	LTGN	1661261C1

Connector 10771F: SED SECT 6-7 A A B C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F130A	18	GY	1661261C1
B	F130-G	18	WH	1661261C1
C	F133F	18	LTGN	1661261C1

Connector 10771G: SED SECT 7-8 A B# B&

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F130A	18	GY	1661261C1
B#	F130-G	18	WH	1661261C1
B&	F130-GC	18	WH	1661261C1
C&	F133D	18	LTGN	1661261C1
C#	F133H	18	LTGN	1661261C1

26.13. CONNECTOR COMPOSITES @10771H, @10771J, @10771K, P. 13 | Figure 1358 CONNECTOR COMPOSITES @10771H, @10771J, @10771K | printed page 1358

Connector 10771H: CAV SED SECT 8-9 A A# B* B#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A&	F130A	18	GY	1661261C1
A#	F130L	18	GY	1661261C1
B*	F130-G	18	WH	1661261C1
B#	F130-GC	18	WH	1661261C1
B%	F130-GD	18	WH	1661261C1
C**	F133D	18	LTGN	1661261C1
C*	F133J	18	LTGN	1661261C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/13 RH WDO ; # W/10 RH WDO ; & W/9,13 RH WDO ; ** W/9,10 RH WDO ; % W/9 RH WDO

Connector 10771J: SED SECT 9-10 CAV A A# A* B^

CAV	CIRCUIT	GA	COLOR	TERMINAL
A&	F130A	18	GY	1661261C1
A#	F130N	18	GY	1661261C1
A*	F130A	18	GY	1661261C1
B^	F130-G	18	WH	1661261C1
B#	F130-GD	18	WH	1661261C1
C#	F133D	18	LTGN	1661261C1
C&	F133D	18	LTGN	1661261C1
C*	F133J	18	LTGN	1661261C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/12 RH WDO ; # W/10 RH WDO ; & W/11 RH WDO ; ^ W/11,12 RH WDO

Connector 10771K: SED SECT 10-11 A A& F130A B& F130-G C* F133D

CAV	CIRCUIT	GA	COLOR	TERMINAL
A&	F130A	18	GY	1661261C1
B&	F130-G	18	WH	1661261C1
C*	F133D	18	LTGN	1661261C1
C#	F133K	18	LTGN	1661261C1

Figure 1359 CONNECTOR COMPOSITES %10771L, @10771M

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.14. CONNECTOR COMPOSITES %10771L, @10771M, P. 14 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090677 NO. RELEASE NO. 95504E 28FEB20 / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / %(10771L) (LOCATED AT RIGHT BODY) / SED SECT 12-13 @(10771M) (LOCATED AT RIGHT BODY) / CONNECTOR 1661889C1 BODY LOCK 1661890C1 / CONNECTOR 1661889C1 BODY LOCK 1661890C1 / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/13 RH WDO / A B C / A B C / % W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK & W/12,13 RH WDO * W12 RH WDO # W/13 RH WDO / CAV CIRCUIT GA COLOR TERMINAL A& F130A 18 GY 1661261C1 B& F130-G 18 WH 1661261C1 C* F133T 18 LTGN 1661261C1 C# F133L 18 LTGN 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F130A 18 GY 1661261C1 B F130-G 18 WH 1661261C1 C F133M 18 LTGN 1661261C1 / Figure 1359 / CONNECTOR COMPOSITES %10771L, @10771M

Connector 10771L: A A& B&

CAV	CIRCUIT	GA	COLOR	TERMINAL
A&	F130A	18	GY	1661261C1
B&	F130-G	18	WH	1661261C1
C*	F133T	18	LTGN	1661261C1
C#	F133L	18	LTGN	1661261C1

Connector 10771M: SED SECT 12-13 A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F130A	18	GY	1661261C1
B	F130-G	18	WH	1661261C1
C	F133M	18	LTGN	1661261C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK W/13 RH WDO

26.15. CONNECTOR COMPOSITES @10772A, @10772B, @10772C, P. 15 | Figure 1360 CONNECTOR COMPOSITES @10772A, @10772B, @10772C | printed page 1360

Connector 10772A: SED ALARM SECT 1-2 A A* B#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A&	F12U	18	LTBL	1661261C1
A*	F12B	18	LTBL	1661261C1
B#	F130F	18	GY	1661261C1
B*	F130B	18	GY	1661261C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; & W/5 TO 11,13 RH WDO ; * W/12 RH WDO ; # W/6 TO 11,13 RH WDO

Connector 10772B: SED ALARM SECT 2-3 A A& B&

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F12B	18	LTBL	1661261C1
A&	F12V	18	LTBL	1661261C1
B&	F130K	18	GY	1661261C1
B*	F130B	18	GY	1661261C1

Connector 10772C: SED ALARM SECT 3-4 CAV A# B&

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F12A	18	LTBL	1661261C1
A#	F12A	18	BK	1661261C1
B&	F130B	18	GY	1661261C1

26.16. CONNECTOR COMPOSITES &10772D, &10772E, &10772F, P. 16 | Figure 1361 CONNECTOR COMPOSITES &10772D, &10772E, &10772F | printed page 1361

Connector 10772D: SED ALARM SECT 4-5 A* A# B%

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F12B	18	LTBL	1661261C1
A#	F12B	18	BK	1661261C1
B%	F130B	18	GY	1661261C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/9 TO 12 RH WDO ; % W/9 TO 13 RH WDO ; # W/13 RH WDO

Connector 10772E: SED ALARM SECT 5-6 A A# B%

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F12C	18	LTBL	1661261C1
A#	F12B	18	BK	1661261C1
B%	F130B	18	GY	1661261C1

Connector 10772F: SED ALARM SECT 6-7 A A* A# B*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F12B	18	LTBL	1661261C1
A#	F12B	18	BK	1661261C1
B*	F130B	18	GY	1661261C1

26.17. CONNECTOR COMPOSITES !10772G, !10772H, !10772G, P. 17 | Figure 1362 CONNECTOR COMPOSITES !10772G, !10772H, !10772G | printed page 1362

Connector 10772G: SED ALARM A^ A*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A^	F12W	18	LTBL	1661261C1
A*	F12B	18	LTBL	1661261C1
A#	F12B	18	BK	1661261C1
B&	F130B	18	GY	1661261C1

Connector 10772H: SED ALARM A A* A#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A^	F12X	18	LTBL	1661261C1
A*	F12C	18	LTBL	1661261C1
A#	F12B	18	BK	1661261C1
B&	F130B	18	GY	1661261C1
B*	F130M	18	GY	1661261C1

Connector 10772J: SED ALARM SECT 9-10 CE CAV A A^ F12B B# F130P

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F12D	18	LTBL	1661261C1
A^	F12B	18	LTBL	1661261C1
B#	F130P	18	GY	1661261C1
B&	F130B	18	GY	1661261C1
B^	F130B	18	WH	1661261C1

Legend: ! W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; ^ W/12 RH WDO ; * W/10,11 RH WDO ; # W/10 RH WDO ; & W/11 RH WDO

26.18. CONNECTOR COMPOSITES !10772K, !10772L, !10772M, P. 18 | Figure 1363 CONNECTOR COMPOSITES !10772K, !10772L, !10772M | printed page 1363

Connector 10772K: SED ALARM SECT 10-11 CE A* A# A&

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F12E	18	LTBL	1661261C1
A#	F12B	18	LTBL	1661261C1
A&	F12B	18	BK	1661261C1
B**	F130B	18	GY	1661261C1

Legend: ! W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/11 RH WDO ; # W/12 RH WDO ; & W/13 RH WDO ; ** W/11,12,13 RH WDO

Connector 10772L: SED ALARM A A* A# B&

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F12B	18	LTBL	1661261C1
A#	F12B	18	BK	1661261C1
B&	F130B	18	GY	1661261C1

Connector 10772M: SED ALARM SECT 12-13 A CAV A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F12B	18	BK	1661261C1
B	F130B	18	GY	1661261C1

26.19. CONNECTOR COMPOSITES &10773A, &10773B, !10773C, P. 19 | Figure 1364 CONNECTOR COMPOSITES &10773A, &10773B, !10773C | printed page 1364

Connector 10773A: A A* A# A#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F143AL	18	DKBL	1661261C1
A#	F143T	18	DKBL	1661261C1
A#	F143AB	18	DKBL	1661261C1
A*	F143AN	18	DKBL	1661261C1
B*	F143GAL	18	WH	1661261C1
B#	F143-GT	18	WH	1661261C1
B#	F143GAB	18	WH	1661261C1
B*	F143GAN	18	WH	1661261C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/5-11,13 RH WDO ; # W/12 RH WDO

Connector 10773B: CAV SED LT A A# A# A*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F143AM	18	DKBL	1661261C1
A#	F143T	18	DKBL	1661261C1
A#	F143AB	18	DKBL	1661261C1
A*	F143AP	18	DKBL	1661261C1
B*	F143GAM	18	WH	1661261C1
B#	F143-GT	18	WH	1661261C1
B#	F143GAB	18	WH	1661261C1
B*	F143GAP	18	WH	1661261C1

Connector 10773C: SED LT A A* A*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F143T	18	DKBL	1661261C1
A*	F143AB	18	DKBL	1661261C1
B*	F143-GT	18	WH	1661261C1
B#	F143-GA	18	WH	1661261C1
B&	F143GAB	18	WH	1661261C1

Legend: ! W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/8 TO 13 RH WDO ; # W/9,10 RH WDO ; & W/8,11 TO 13 RH WDO

26.20. CONNECTOR COMPOSITES !10773D, &10773E, &10773F, !10773G, P. 20 | Figure 1365 CONNECTOR COMPOSITES !10773D, &10773E, &10773F, !10773G | printed page 1365

Connector 10773D: SED LT A A* A*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F143U	18	DKBL	1661261C1
A*	F143AC	18	DKBL	1661261C1
B*	F143-GU	18	WH	1661261C1
B#	F143-GA	18	WH	1661261C1
B&	F143GAC	18	WH	1661261C1

Legend: ! W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/9 TO 13 RH WDO ; # W/9 RH WDO ; & W/10 TO 13 RH WDO

Connector 10773E: SED LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F143V	18	DKBL	1661261C1
A	F143AD	18	DKBL	1661261C1
B	F143-GV	18	WH	1661261C1
B	F143GAD	18	WH	1661261C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK W/11 TO 13 RH WDO

Connector 10773F: SED LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F143W	18	DKBL	1661261C1
A	F143AE	18	DKBL	1661261C1
B	F143-GW	18	WH	1661261C1
B	F143GAE	18	WH	1661261C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK W/12 TO 13 RH WDO

Connector 10773G: SED LT CE A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F143V	18	DKBL	1661261C1
A#	F143X	18	DKBL	1661261C1
A#	F143AF	18	DKBL	1661261C1
A*	F143AR	18	DKBL	1661261C1
A&	F12C	18	LTBL	1661261C1
B*	F143-GV	18	WH	1661261C1
B#	F143-GX	18	WH	1661261C1
B#	F143GAF	18	WH	1661261C1
B*	F143GAR	18	WH	1661261C1
B&	F12-G	18	WH	1661261C1

Legend: ! W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * W/9 RH WDO ; # W/12 TO 13 RH WDO ; & W/12 RH WDO

26.21. CONNECTOR COMPOSITES !10773H, !10773J, !10773K, P. 21 | Figure 1366 CONNECTOR COMPOSITES !10773H, !10773J, !10773K | printed page 1366

Connector 10773H: CAV SED LT CE A* A A& A&

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F143V	18	DKBL	1661261C1
A#	F143W	18	DKBL	1661261C1
A&	F143Y	18	DKBL	1661261C1
A&	F143AH	18	DKBL	1661261C1
A**	F143AS	18	DKBL	1661261C1
B*	F143-GV	18	WH	1661261C1
B#	F143-GW	18	WH	1661261C1
B&	F143-GY	18	WH	1661261C1
B&	F143GAH	18	WH	1661261C1
B**	F143GAS	18	WH	1661261C1

Legend: ! W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/10 RH WDO ; # W/9 RH WDO ; & W/13 RH WDO ; **W/9,10 RH WDO

Connector 10773J: CAV SED LT CE A A# A* A**

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F143P	18	DKBL	1661261C1
A#	F143W	18	DKBL	1661261C1
A*	F143AH	18	DKBL	1661261C1
A**	F143AR	18	DKBL	1661261C1
A##	F143AT	18	DKBL	1661261C1
B*	F143-GP	18	WH	1661261C1
B#	F143-GW	18	WH	1661261C1
B*	F143GAH	18	WH	1661261C1
B**	F143GAR	18	WH	1661261C1
B##	F143GAT	18	WH	1661261C1

Legend: ! W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/12 RH WDO ; # W/10,11 RH WDO ; ** W/11 RH WDO ; ## W/10 RH WDO

Connector 10773K: SED LT CE CAV A B A# A& A^

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F143R	18	DKBL	1661261C1
A#	F143Z	18	DKBL	1661261C1
A&	F143Y	18	DKBL	1661261C1
A^	F143AJ	18	DKBL	1661261C1
A&	F143AS	18	DKBL	1661261C1
B*	F143-GR	18	WH	1661261C1
B#	F143-GZ	18	WH	1661261C1
B&	F143-GY	18	WH	1661261C1
B^	F143GAJ	18	WH	1661261C1
B&	F143GAS	18	WH	1661261C1

Legend: ! W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/12 RH WDO ; # W/13 RH WDO ; & W/11 RH WDO ; ^ W/12,13 RH WDO

26.22. CONNECTOR COMPOSITES !10773L, @10773M, P. 22 | Figure 1367 CONNECTOR COMPOSITES !10773L, @10773M | printed page 1367

Connector 10773L: SED LT A A# A* A&

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	F143AA	18	DKBL	1661261C1
A*	F143S	18	DKBL	1661261C1
A&	F143AK	18	DKBL	1661261C1
B#	F143GAA	18	WH	1661261C1
B*	F143-GS	18	WH	1661261C1
B&	F143GAK	18	WH	1661261C1

Connector 10773M: SED LT SECT 12-13 A A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F143AL	18	DKBL	1661261C1
A	F143AB	18	DKBL	1661261C1
B	F143GAL	18	WH	1661261C1
B	F143GAB	18	WH	1661261C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK W/13 RH WDO

26.23. CONNECTOR COMPOSITES !10774, !10774A, !10774B, P. 23 | Figure 1368 CONNECTOR COMPOSITES !10774, !10774A, !10774B | printed page 1368

Connector 10774: A B G H C V122A D V122-GC

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	V122-GA	18	WH	1661262C1
B*	V122-GY	16	GY	1661262C1
B#	V122-GB	18	WH	1661262C1
C	V122A	18	GY	1661262C1
D	V122-GC	18	WH	1661262C1
E	V122B	18	GY	1661262C1
F	V122C	18	GY	1661262C1
G&	V122D	18	GY	1661262C1
G^	V122T	16	LTGN	1661262C1
H	V133	16	LTGN	1661262C1

Legend: ! W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/LIFT POWER INTERLOCK W/LIFT DOOR ACTIVATED ; # W/LIFT POWER INTRLK W/DOOR LOCK ; & W/LIGHTS TOGGLE SWITCH ACTIVATED ; ^ W/LIGHTS EXTERIOR ACTIVATED BY DOORS AND CLEARANCE

Connector 10774A: CAV A* LIFT DOOR SECT 1-2 C D E F B* F122-GB B# F122-GB C* F122A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F122-GA	16	WH	1661261C1
A#	F122-GA	18	WH	1661261C1
B*	F122-GB	16	WH	1661261C1
B#	F122-GB	18	WH	1661261C1
C*	F122A	16	GY	1661261C1
C#	F122A	18	GY	1661261C1
D*	F122-GC	16	WH	1661261C1
D#	F122-GC	18	WH	1661261C1
E*	F122B	16	GY	1661261C1
E#	F122B	18	GY	1661261C1
F*	F122C	16	GY	1661261C1
F#	F122C	18	GY	1661261C1

Legend: W/0508108 G* F122D 16 GY 1661261C1 ; N/0508108 G# F122AC 18 GY 1661261C1 ; H& F133D 18 LTGN 1661261C1 ; H** F133M 18 LTGN 1661261C1

Connector 10774B: ** W/12,13 RH WDO LIFT DOOR SECT 2-3 CAV C D E F C* D# D*

CAV	CIRCUIT	GA	COLOR	TERMINAL
C#	F122W	16	GY	1661261C1
C*	F122A	16	GY	1661261C1
D#	F122-GY	16	WH	1661261C1
D*	F122-GC	16	WH	1661261C1
E*	F122B	16	GY	1661261C1
E#	F122X	16	GY	1661261C1
F*	F122C	16	GY	1661261C1
F#	F122Y	16	GY	1661261C1
G%	F122D	16	GY	1661261C1
H&	F133D	16	LTGN	1661261C1
H**	F133D	18	LTGN	1661261C1

Legend: 1661261C1 ; # W/12 RH WDO ; & W/10 RH WDO ; 1661261C1 ; % W/10-11 RH WDO ; W/0508108 - MTA FUSE BLOCK ; REV REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE

Connector 10774B: ** W/12,13 RH WDO LIFT DOOR SECT 2-3 CAV C D E F C* D# D*
Table: BODY LOCK 3515764C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	F122-GW	16	WH	1661261C1
A*	F122-GA	16	WH	1661261C1
B#	F122-GX	16	WH	1661261C1
B*	F122-GB	16	WH	1661261C1

Legend: ! W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; CHK DATE ; MJV0488 13SEP21 ADDED NOTE FOR FUSE B 96183U

26.24. CONNECTOR COMPOSITES !10774C, !10774D, !10774E, P. 24 | Figure 1369 CONNECTOR COMPOSITES !10774C, !10774D, !10774E | printed page 1369

Connector 10774C: D E

CAV	CIRCUIT	GA	COLOR	TERMINAL
A@	F122-GA	16	WH	1661261C1
B@	F122-GB	16	WH	1661261C1
C@	F122A	16	GY	1661261C1
D@	F122-GC	16	WH	1661261C1
E@	F122B	16	GY	1661261C1
F@	F122C	16	GY	1661261C1
G*	F122AC	16	GY	1661261C1
G#	F122D	16	GY	1661261C1
H&	F133D	18	LTGN	1661261C1
H**	F133M	18	LTGN	1661261C1

Legend: @ W/8 TO 13 RH WDO ; - * W/12 RH WDO ; # W/8 TO 11,13 RH WDO ; & W/8 TO 11 RH WDO ; ** W/12,13 RH WDO

Connector 10774D: E D

Table: ** W/12,13 RH WDO

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	F122-GA	16	WH	1661261C1
A*	F122-GD	16	WH	1661261C1
B#	F122-GB	16	WH	1661261C1
B*	F122-GE	16	WH	1661261C1
C#	F122A	16	GY	1661261C1
C*	F122D	16	GY	1661261C1
D#	F122-GC	16	WH	1661261C1
D*	F122-GF	16	WH	1661261C1
E#	F122B	16	GY	1661261C1
E*	F122E	16	GY	1661261C1
F&	F122C	16	GY	1661261C1
F**	F122F	16	GY	1661261C1
G**	F122AD	16	GY	1661261C1
G%	F122D	16	GY	1661261C1
H#	F133D	18	LTGN	1661261C1
H*	F133N	18	LTGN	1661261C1

Legend: W/0508108 - # W/5,9,10,11 RH WDO ; N/0508108 - * W/12,13 RH WDO ; & W/5,9 TO 11,13 RH WDO ; ** W/12 RH WDO ; % W/5,9,10,11,13 RH WDO

Connector 10774E: LIFT DOOR SECT 5-6 E D

Table: % W/5,9,10,11,13 RH WDO

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F122-GA	16	WH	1661261C1
A#	F122-GH	16	WH	1661261C1
B*	F122-GB	16	WH	1661261C1
B#	F122-GJ	16	WH	1661261C1
C*	F122A	16	GY	1661261C1
C#	F122H	16	GY	1661261C1
D*	F122-GC	16	WH	1661261C1
D#	F122-GK	16	WH	1661261C1
E*	F122B	16	GY	1661261C1
E#	F122J	16	GY	1661261C1
F%	F122C	16	BN	1661261C1
F^	F122K	16	GY	1661261C1
F&	F122C	16	GY	1661261C1
G^	F122AE	16	GY	1661261C1
G%	F122D	16	BK	1661261C1
G&	F122D	16	GY	1661261C1
G^	F122	16	BN	1661261C1
H*	F133D	18	LTGN	1661261C1
H#	F133P	18	LTGN	1661261C1

Legend: DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 28FEB20 AE08090677 024

26.25. CONNECTOR COMPOSITES !10774F, !10774G, !10774H, P. 25 | Figure 1370 CONNECTOR COMPOSITES !10774F, !10774G, !10774H | printed page 1370

Connector 10774F: C D E F

CAV	CIRCUIT	GA	COLOR	TERMINAL
C#	F122L	16	GY	1661261C1
D*	F122-GC	16	WH	1661261C1
D#	F122-GN	16	WH	1661261C1
E*	F122B	16	GY	1661261C1
E#	F122M	16	GY	1661261C1
F&	F122C	16	GY	1661261C1
F**	F122N	16	GY	1661261C1
G**	F122AF	16	GY	1661261C1
G&	F122D	16	GY	1661261C1
H*	F133D	18	LTGN	1661261C1
H#	F133R	18	LTGN	1661261C1

Legend: ! W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND N/0508108-NOT FUSE BLOCK ; * W/7 RH WDO ; # W/12,13 RH WDO ; & W/7,13 RH WDO ; ** W/12 RH WDO

Connector 10774F: C D E F
Table: BODY LOCK 3515764C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F122-GA	16	WH	1661261C1
A#	F122-GL	16	WH	1661261C1
B*	F122-GB	16	WH	1661261C1
B#	F122-GM	16	WH	1661261C1
C*	F122A	16	GY	1661261C1

Connector 10774G: ** LIFT DOOR SECT 7-8 E D C F

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F122-GA	16	WH	1661261C1
A#	F122-GP	16	WH	1661261C1
B*	F122-GB	16	WH	1661261C1
B#	F122-GR	16	WH	1661261C1
C*	F122A	16	GY	1661261C1
C#	F122P	16	GY	1661261C1
D*	F122-GC	16	WH	1661261C1
D#	F122-GS	16	WH	1661261C1
E*	F122B	16	GY	1661261C1
E#	F122R	16	GY	1661261C1
F**	F122C	16	GY	1661261C1

Legend: W/0508108 - F& F122S 16 GY 1661261C1 ; G** F122D 16 GY 1661261C1 ; G& F122AH 16 GY 1661261C1 ; H* F133D 18 LTGN 1661261C1 ; H# F133S 18 LTGN 1661261C1

Connector 10774H: LIFT DOOR SECT 8-9 E D C F

CAV	CIRCUIT	GA	COLOR	TERMINAL
D*	F122-GC	16	WH	1661261C1
D#	F122-GV	16	WH	1661261C1
E*	F122B	16	GY	1661261C1
E#	F122U	16	GY	1661261C1
F&	F122C	16	GY	1661261C1
G&	F122D	16	GY	1661261C1
H*	F133D	18	LTGN	1661261C1
H#	F133T	18	LTGN	1661261C1

Legend: ! W/COMMON FOR VEHICLE W/0508108 - ; MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK ; * W/9,10 RH WDO ; # W/13 RH WDO ; & W/9,10,13 RH WDO

Connector 10774H: LIFT DOOR SECT 8-9 E D C F
Table: BODY LOCK 3515764C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F122-GA	16	WH	1661261C1
A#	F122-GT	16	WH	1661261C1
B*	F122-GB	16	WH	1661261C1
B#	F122-GU	16	WH	1661261C1
C*	F122A	16	GY	1661261C1
C#	F122T	16	GY	1661261C1

Legend: CHK DATE ; MJV0488 13SEP21 ADDED NOTE FOR FUSE B 96183U

26.26. CONNECTOR COMPOSITES %10765E, @10774J, @10774K, @10774L, P. 26 | Figure 1371 CONNECTOR COMPOSITES %10765E, @10774J, @10774K, @10774L | printed page 1371

Connector 10765E: ACTIVITY DOME LIGHT % A B B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63AS	16	DKBL	1661261C1
B	F63-GX	16	WH	1661261C1

Connector 10774J: LIFT DOOR SECT 9-10 C D E F B C D

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F122-GA	16	WH	1661261C1
B	F122-GB	16	WH	1661261C1
C	F122A	16	GY	1661261C1
D	F122-GC	16	WH	1661261C1
E	F122B	16	GY	1661261C1
F	F122C	16	GY	1661261C1
G	F122D	16	GY	1661261C1
H	F133D	18	LTGN	1661261C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK W/10 RH WDO

Connector 10774K: LIFT DOOR SECT 10-11 E D A# B& C&

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	F122-GA	16	WH	1661261C1
A#	F122-GA	16	GY	1661261C1
B&	F122-GB	16	WH	1661261C1
C&	F122A	16	GY	1661261C1
D&	F122-GC	16	WH	1661261C1
E&	F122B	16	GY	1661261C1
F*	F122C	16	BN	1661261C1
F#	F122C	16	GY	1661261C1
G*	F122D	16	BK	1661261C1
H*	F133D	18	LTGN	1661261C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK ; * W/11 RH WDO ; # W/13 RH WDO ; & W/11,13 RH WDO

Connector 10774L: & LIFT DOOR SECT 11-12 E D B C D

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F122-GT	16	WH	1661261C1
B	F122-GV	16	WH	1661261C1
C	F122C	16	GY	1661261C1
D	F122-GP	16	WH	1661261C1
E	F122A	16	GY	1661261C1
F	F122B	16	GY	1661261C1
G	F122AK	16	GY	1661261C1
H	F133T	18	LTGN	1661261C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK W/12 RH WDO

26.27. CONNECTOR COMPOSITES @10774M, @10778C, @10778D, P. 27 | Figure 1372 CONNECTOR COMPOSITES @10774M, @10778C, @10778D | printed page 1372

Connector 10774M: LIFT DOOR SECT 10-11 D E

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F122-GT	16	WH	1661261C1
B	F122-GU	16	WH	1661261C1
C	F122T	16	GY	1661261C1
D	F122-GV	16	WH	1661261C1
E	F122U	16	GY	1661261C1
F	F122C	16	GY	1661261C1
G	F122D	16	GY	1661261C1
H	F133T	18	LTGN	1661261C1

Connector 10778C: DUMP VALVE SW ALT ENT DOOR

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	F120D	18	LTGN	1661539C1
2	F120C	18	LTGN	1661539C1

Connector 10778D: DUMP VALVE SW ALT ENT DOOR

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	F120D	18	LTGN	1661539C1
2	F120C	18	LTGN	1661539C1

26.28. CONNECTOR COMPOSITES @10778E, @10778F, *10778G, P. 28
Figure 1373 CONNECTOR COMPOSITES @10778E, @10778F, *10778G

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.28. CONNECTOR COMPOSITES @10778E, @10778F, *10778G, P. 28 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090677 NO. RELEASE NO. 95504E 28FEB20 / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / DUMP VALVE SW ALT ENT DOOR @(10778E) (LOCATED AT RIGHT BODY) / DUMP VALVE SW ALT ENT DOOR @(10778F) (LOCATED AT RIGHT BODY) / DUMP VALVE SW AED SECT 11-12 *(10778G) (LOCATED AT RIGHT BODY) / CONNECTOR 1669029C1 * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/13 RH WDO / CONNECTOR 1669029C1 / CONNECTOR 1669029C1 / * W/11,13 RH WDO # W/12 RH WDO / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/10,11 RH WDO / 1 2 / 1 2 / 1 2 / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL 1* F120D 18 LTGN 1661539C1 1# F120E 18 LTGN 1661539C1 2* F120C 18 LTGN 1661539C1 2# F120F 18 LTGN 1661539C1 / CAV CIRCUIT GA COLOR TERMINAL 1 F120D 18 LTGN 1661539C1 2 F120C 18 LTGN 1661539C1 / CAV CIRCUIT GA COLOR TERMINAL 1 F120D 18 LTGN 1661539C1 2 F120C 18 LTGN 1661539C1 / Figure 1373 / CONNECTOR COMPOSITES @10778E, @10778F, *10778G

Connector 10778E: DUMP VALVE SW ALT ENT DOOR

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	F120D	18	LTGN	1661539C1
2	F120C	18	LTGN	1661539C1

Connector 10778F: DUMP VALVE SW ALT ENT DOOR

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	F120D	18	LTGN	1661539C1
1#	F120E	18	LTGN	1661539C1
2*	F120C	18	LTGN	1661539C1
2#	F120F	18	LTGN	1661539C1

Legend: * W/11,13 RH WDO ; # W/12 RH WDO

Connector 10778G: DUMP VALVE SW AED SECT 11-12

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	F120D	18	LTGN	1661539C1
2	F120C	18	LTGN	1661539C1

Figure 1374 CONNECTOR COMPOSITES @10779, @10779A, @10779B

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.29. CONNECTOR COMPOSITES @10779, @10779A, @10779B, P. 29 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090677 NO. 95504E 28FEB20 / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / SIDE DIR LT FWD REAR WHL PKT @(10779) (LOCATED AT BODY) / SIDE DIR LT FWD REAR WHL PKT @(10779A) (LOCATED AT BODY) / SIDE DIR LT FWD REAR WHL PKT @(10779B) (LOCATED AT BODY) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/8 RH WDO / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/8 RH WDO / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/5,7,9, 11 RH WDO / A B / A B / A B / CAV CIRCUIT GA COLOR TERMINAL A F57E 18 LTGN 1661261C1 B F57-GE 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F57J 18 LTGN 1661261C1 B F57-GF 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F57J 18 LTGN 1661261C1 B F57-GF 18 WH 1661261C1 / Figure 1374 / CONNECTOR COMPOSITES @10779, @10779A, @10779B

Connector 10779: SIDE DIR LT FWD REAR WHL PKT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F57J	18	LTGN	1661261C1
B	F57-GF	18	WH	1661261C1

Connector 10779A: SIDE DIR LT FWD REAR WHL PKT

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F57E	18	LTGN	1661261C1
B	F57-GE	18	WH	1661261C1

Connector 10779B: SIDE DIR LT FWD REAR WHL PKT

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F57J	18	LTGN	1661261C1
B	F57-GF	18	WH	1661261C1

26.30. CONNECTOR COMPOSITES @@10780, @10780, P. 30 | Figure 1375 CONNECTOR COMPOSITES @@10780, @10780 | printed page 1375

Connector 10780: CAV A SPLICE BLOCK A ML B# C D

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	V122C	18	GY	3534164C1
B*	V122E	18	GY	3534164C1
B#	V122G	18	GY	3534164C1
C	V122F	18	GY	3534164C1
D	V122	18	GY	3534164C1
E%	V122L	18	GY	3534164C1
E&	V122L	16	GY	3534165C1
G	V122-GH	18	WH	3534164C1
H%	V122-GE	16	WH	3534165C1
H&	V122-GE	18	WH	3534164C1
J^	V122-GG	18	WH	3534164C1
J@	V122-GA	18	WH	3534164C1
K	V122-GF	18	WH	3534164C1
L*	V122-GL	18	WH	3534164C1
L#	V122-GM	18	WH	3534164C1
L!	V122-GM	16	GY	3534165C1
M	V122-GD	18	WH	3534164C1

Legend: @@ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK W/5,7,9 RH WDO ; * W/LIGHT INTERIOR DOME MTD IN DOOR HEADER-PE ; # W/LIGHT INTERIOR W/TWO EXTERIOR LTS ; & W/BUZZER DEACTIVATED W/DOOR OPEN NORTH CARDLINA ; ^ W/LIGHT EXTERIOR MTD BELOW LIFT DOOR IN SKIRT ; @ W/LIGHTS LIFT DOOR 3 EXTERIOR LIGHTS ; ! W/LIGHTS INTERIOR W/EXTERIOR LIGHTS

Connector 10780: SIDE DIR LT OVER REAR WHL PKT CAV @ W/COMMON B F57-GH

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F57K	18	LTGN	1661261C1
B	F57-GH	18	WH	1661261C1

26.31. CONNECTOR COMPOSITES @10781, !10781, @10781A, P. 31 | Figure 1376 CONNECTOR COMPOSITES @10781, !10781, @10781A | printed page 1376

Connector 10781: CMB LT FWD REAR WHL PKT CE A A B C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F57H	18	LTGN	1661261C1
B	F58C	18	BN	1661261C1
C	F58-GC	18	WH	1661261C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT MTA FUSE BLOCK W/9, 11 RH WDO

Connector 10781: SIDE DIRECTINOAL/MARKER LIGHT FWD REAR WHL PKT 1@ 1^ 1*

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1@	V122B	18	GY	3522190C1	3522193C1
1^	V122	18	GY	3522190C1	3522193C1
1*	V122T	16	LTGN	3522190C1	3522194C1
2@	V122B-G	18	GY	3522190C1	3522193C1
2#	V122-G	16	WH	3522190C1	3522194C1
2^	V122-GG	18	WH	3522190C1	3522193C1

Legend: ! W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; @ W/LIGHTS LIFT DOOR 3 EXTERIOR LIGHTS ; ^ W/LIGHT EXTERIOR MTD BELOW LIFT DOOR IN SKIRT ; * W/LIGHTS EXTERIOR ACTIVATED BY DOORS AND CLEARANCE ; # W/SPLICE CLEARANCE LIGHT AND LIFT DOOR ACTVD LT

Connector 10781A: SKIRT LIFT DOOR LT CAV 1 2

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	V122C	18	GY	3522190C1	3522193C1
2	V122C-G	18	GY	3522190C1	3522193C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK

26.32. CONNECTOR COMPOSITES &10784, &10785, &10786A, P. 32
Figure 1377 CONNECTOR COMPOSITES &10784, &10785, &10786A

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.32. CONNECTOR COMPOSITES &10784, &10785, &10786A, P. 32 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090677 NO. 95504E 02MAR20 / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / LIFT DR BUZZER &(10784) (LOCATED AT LIFT DOOR) A B / CEILING MTD DOME &(10785) (LOCATED AT LIFT DOOR) / INPUT FROM STD DOME LT &(10786A) (LOCATED AT LIFT DOOR) / CONNECTOR 1669030C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / A B / 1 2 / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK * W/BUZZER # W/BUZZER DEACTIVATED W/DOOR OPEN / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A* V122L 18 GY 1661261C1 B# V122-GP 16 WH 1661261C1 B* V122-GE 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A V122E 18 GY 1661261C1 B V122-GJ 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL 1 V63 18 DK BL 1661539C1 2 - - - - / Figure 1377 / CONNECTOR COMPOSITES &10784, &10785, &10786A

Connector 10784: LIFT DR BUZZER A B A* B#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	V122L	18	GY	1661261C1
B#	V122-GP	16	WH	1661261C1
B*	V122-GE	18	WH	1661261C1

Connector 10785: CEILING MTD DOME A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	V122E	18	GY	1661261C1
B	V122-GJ	18	WH	1661261C1

Connector 10786A: INPUT FROM STD DOME LT CAV

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	V63	18	DK BL	1661539C1
2	-	-	-	-

Figure 1378 CONNECTOR COMPOSITES &10786B, &10787, &10788A

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.33. CONNECTOR COMPOSITES &10786B, &10787, &10788A, P. 33 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090677 NO. 95504E 02MAR20 / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / INPUT FROM STD DOME LT &(10786B) (LOCATED AT LIFT DOOR HARNESS) / DIODE PACK &(10787) (LOCATED AT LIFT DOOR HARNESS) / LIFT DOME LT &(10788A) (LOCATED AT LIFT DOOR HARNESS) / CONNECTOR 1669029C1 BODY LOCK 1661264C1 & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / CONNECTOR 1661260C1 BODY LOCK 1661264C1 / CONNECTOR 2206665C1 / B A / 1 2 3 / 1 2 / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A V63 18 DK BL 1661262C1 B - - - - / CAV CIRCUIT GA COLOR TERMINAL 1 V122E 18 GY 1661538C1 2 V122F 18 GY 1661538C1 3 V63 18 DK BL 1661538C1 / CAV CIRCUIT GA COLOR TERMINAL 1P V122F 18 GY 1661538C1 2P V122-GL 18 WH 1661538C1 / Figure 1378 / CONNECTOR COMPOSITES &10786B, &10787, &10788A

Connector 10786B: INPUT FROM STD DOME LT B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	V63	18	DK BL	1661262C1
B	-	-	-	-

Connector 10787: DIODE PACK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	V122E	18	GY	1661538C1
2	V122F	18	GY	1661538C1
3	V63	18	DK BL	1661538C1

Connector 10788A: LIFT DOME LT

CAV	CIRCUIT	GA	COLOR	TERMINAL
1P	V122F	18	GY	1661538C1
2P	V122-GL	18	WH	1661538C1

26.34. CONNECTOR COMPOSITES &10788B, &10789, &10795, P. 34
Figure 1379 CONNECTOR COMPOSITES &10788B, &10789, &10795

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.34. CONNECTOR COMPOSITES &10788B, &10789, &10795, P. 34 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090677 NO. 95504E 02MAR20 / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / LIFT DOME LT &(10788B) (LOCATED AT LIFT DOOR) / UPPER LIFT DR LT &(10789) (LOCATED AT LIFT DOOR) / LOWER POST LIFT DR LT &(10795) (LOCATED AT LIFT DOOR) / CONNECTOR 2206588C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 2206588C1 / A B / 1 2 / 1 2 / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A V122F 18 GY 1661261C1 B V122-GL 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 V122F 18 GY 3522190C1 3522193C1 2 V122-GF 18 WH 3522190C1 3522193C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 V122K 18 GY 3522190C1 3522193C1 2 V122-GK 18 WH 3522190C1 3522193C1 / Figure 1379 / CONNECTOR COMPOSITES &10788B, &10789, &10795

Connector 10788B: INC. LIFT DOME LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	V122F	18	GY	1661261C1
B	V122-GL	18	WH	1661261C1

Connector 10789: UPPER LIFT DR LT

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	V122F	18	GY	3522190C1	3522193C1
2	V122-GF	18	WH	3522190C1	3522193C1

Connector 10795: LOWER POST LIFT DR LT

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	V122K	18	GY	3522190C1	3522193C1
2	V122-GK	18	WH	3522190C1	3522193C1

Figure 1380 CONNECTOR COMPOSITES @10796A, @10796B, @10800

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.35. CONNECTOR COMPOSITES @10796A, @10796B, @10800, P. 35 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090677 NO. RELEASE NO. 95504E 02MAR20 / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / STARTER INTERLOCK @(10796A) (LOCATED AT LIFT DOOR HARNESS) / STARTER INTERLOCK @(10796B) (LOCATED AT LIFT DOOR HARNESS) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/9 RH WDO / CONNECTOR 2206658C1 / CONNECTOR 2206658C1 / DOME LT OVER EACH SEAT (2) @(10800) (LOCATED AT RIGHT BODY) / A B / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A V133 16 LTGN 0239805R1 / CAV CIRCUIT GA COLOR TERMINAL A V133 16 LTGN 0239805R1 / CAV CIRCUIT GA COLOR TERMINAL A F63T 16 DKBL 1661261C1 B F63-GL 16 WH 1661261C1 / Figure 1380 / CONNECTOR COMPOSITES @10796A, @10796B, @10800

Connector 10796A: STARTER INTERLOCK A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	V133	16	LTGN	0239805R1

Connector 10796B: STARTER INTERLOCK A CAV

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	V133	16	LTGN	0239805R1

Connector 10800: DOME LT OVER EACH SEAT (2) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63T	16	DKBL	1661261C1
B	F63-GL	16	WH	1661261C1

26.36. CONNECTOR COMPOSITES @10800A, @10801, @10801A, P. 36
Figure 1381 CONNECTOR COMPOSITES @10800A, @10801, @10801A

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.36. CONNECTOR COMPOSITES @10800A, @10801, @10801A, P. 36 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090677 NO. RELEASE NO. 95504E 02MAR20 / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / 12 DOME LT @(10800A) (LOCATED AT RIGHT BODY) / DOME LT OVER EACH SEAT (4) @(10801) (LOCATED AT RIGHT BODY) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / 12 DOME LT @(10801A) (LOCATED AT RIGHT BODY) / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/9 RH WDO / A B / A B / A B / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/9 RH WDO / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/9 RH WDO / CAV CIRCUIT GA COLOR TERMINAL A F63B 16 DKBL 1661261C1 B F63B-G 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F63S 16 DKBL 1661261C1 B F63-GM 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F63C 16 DKBL 1661261C1 B F63C-G 16 WH 1661261C1 / Figure 1381 / CONNECTOR COMPOSITES @10800A, @10801, @10801A

Connector 10800A: 12 DOME LT A CAV

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63B	16	DKBL	1661261C1
B	F63B-G	16	WH	1661261C1

Connector 10801: DOME LT OVER EACH SEAT (4) A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63S	16	DKBL	1661261C1
B	F63-GM	16	WH	1661261C1

Connector 10801A: 12 DOME LT A CAV A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63C	16	DKBL	1661261C1
B	F63C-G	16	WH	1661261C1

Figure 1382 CONNECTOR COMPOSITES @10801C, @10801E, @10802

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.37. CONNECTOR COMPOSITES @10801C, @10801E, @10802, P. 37 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090677 NO. RELEASE NO. 95504E 02MAR20 / MJV0488 13SEP21 ADDED R/D 10801D & FUSE DETAILS. / SED LANDING LT SECT 3 & 4 @(10801C) (LOCATED AT LEFT BODY) / SED LANDING LT SECT 5 & 6 @(10801E) (LOCATED AT LEFT BODY) / DOME LT OVER EACH SEAT (6) @(10802) (LOCATED AT RIGHT BODY) A B CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/9 RH WDO / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/13 LH WDO / A B / A B / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/9 & 11-13 LH WDO / A B / SET LANDING LIGHT %(10801D) (LOCATED IN LEFT BODY HARNESS) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / % W/11 LH WDO W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT MTA FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A E131 16 DKBL 1661261C1 B E131-G 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A E131 16 DKBL 1661261C1 B E131-G 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F63W 16 DKBL 1661261C1 B F63-GP 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A E131 16 DKBL 1661261C1 B E131-G 16 WH 1661261C1 / Figure 1382 / CONNECTOR COMPOSITES @10801C, @10801E, @10802

Connector 10801C: INC. SED LANDING LT SECT 3 & 4 A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E131	16	DKBL	1661261C1
B	E131-G	16	WH	1661261C1

Connector 10801D: BODY LOCK 1661263C1 SET LANDING LIGHT A A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E131	16	DKBL	1661261C1
B	E131-G	16	WH	1661261C1

Connector 10801E: BODY LOCK 1661263C1 SED LANDING LT SECT 5 & 6 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	E131	16	DKBL	1661261C1
B	E131-G	16	WH	1661261C1

Connector 10802: DOME LT OVER EACH SEAT (6) A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63W	16	DKBL	1661261C1
B	F63-GP	16	WH	1661261C1

Figure 1383 CONNECTOR COMPOSITES @10803, @10804, @10804A

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.38. CONNECTOR COMPOSITES @10803, @10804, @10804A, P. 38 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090677 NO. RELEASE NO. 95504E 02MAR20 / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / DOME LT OVER EACH SEAT (8) @(10803) (LOCATED NEAR AIR DOOR CYLINDER) / DOME LT OVER EACH SEAT (5) @(10804) (LOCATED RIGHT SIDE ABOVE SEAT) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / 12 DOME LT @(10804A) (LOCATED RIGHT SIDE ABOVE SEAT) / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/9 RH WDO / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/9 RH WDO / A B / A B / A B / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/9 RH WDO / CAV CIRCUIT GA COLOR TERMINAL A F63Y 16 DKBL 1661261C1 B F63-GS 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F63V 16 DKBL 1661261C1 B F63-GN 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F63D 16 DKBL 1661261C1 B F63D-G 16 WH 1661261C1 / Figure 1383 / CONNECTOR COMPOSITES @10803, @10804, @10804A

Connector 10803: DOME LT OVER EACH SEAT (8) A CAV

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63Y	16	DKBL	1661261C1
B	F63-GS	16	WH	1661261C1

Connector 10804: DOME LT OVER EACH SEAT (5) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63V	16	DKBL	1661261C1
B	F63-GN	16	WH	1661261C1

Connector 10804A: 12 DOME LT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63D	16	DKBL	1661261C1
B	F63D-G	16	WH	1661261C1

Figure 1384 CONNECTOR COMPOSITES @10805, @10806, @10807A

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.39. CONNECTOR COMPOSITES @10805, @10806, @10807A, P. 39 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090677 NO. RELEASE NO. 95504E 02MAR20 / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / DOME LT OVER EACH SEAT (7) @(10805) (LOCATED RIGHT SIDE ABOVE SEAT) / DOME LT OVER EACH SEAT (9) @(10806) (LOCATED RIGHT SIDE ABOVE SEAT) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / SIDE DIR LT OVER REAR WHL PKT @(10807A) (LOCATED RIGHT SIDE ABOVE SEAT) / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/8 RH WDO / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/8 RH WDO / A B / A B / A B / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/9 RH WDO / CAV CIRCUIT GA COLOR TERMINAL A F63X 16 DKBL 1661261C1 B F63-GR 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F63Z 16 DKBL 1661261C1 B F63-GT 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F57D 18 LTGN 1661261C1 B F57-GD 18 WH 1661261C1 / Figure 1384 / CONNECTOR COMPOSITES @10805, @10806, @10807A

Connector 10805: DOME LT OVER EACH SEAT (7) A CAV

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63X	16	DKBL	1661261C1
B	F63-GR	16	WH	1661261C1

Connector 10806: DOME LT OVER EACH SEAT (9) A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63Z	16	DKBL	1661261C1
B	F63-GT	16	WH	1661261C1

Connector 10807A: SIDE DIR LT OVER REAR WHL PKT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F57D	18	LTGN	1661261C1
B	F57-GD	18	WH	1661261C1

26.40. CONNECTOR COMPOSITES @10807A, @10807B, P. 40 | Figure 1385 CONNECTOR COMPOSITES @10807A, @10807B | printed page 1385

Connector 10807A: MIRAGE LIFT DOOR 3 4

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	F122GAC	16	WH	1661539C1
2	F122GAD	16	WH	1661539C1
3	F122AJ	16	GY	1661539C1
4	F122GAE	16	WH	1661539C1
5	F122AK	16	GY	1661539C1
6	F122AL	16	GY	1661539C1
7	F122AM	16	GY	1661539C1
8	F122AN	16	GY	1661539C1
9	F122AP	16	GY	1661539C1

Connector 10807B: SIDE DIR LT OVER REAR WHL PKT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F57K	18	LTGN	1661261C1
B	F57-GH	18	WH	1661261C1

Connector 10807B: MIRAGE LIFT DOOR

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	F122GAC	16	WH	1661539C1
2	F122GAD	16	WH	1661539C1
3	F122AJ	16	GY	1661539C1
4	F122GAE	16	WH	1661539C1
5	F122AK	16	GY	1661539C1
6	F122AL	16	GY	1661539C1
7	F122AM	16	GY	1661539C1
8	F122AN	16	GY	1661539C1
9	F122AP	16	GY	1661539C1

Figure 1386 CONNECTOR COMPOSITES @10808, &10831, &10832

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.41. CONNECTOR COMPOSITES @10808, &10831, &10832, P. 41 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090677 NO. RELEASE NO. 95504E 02MAR20 / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / SIDE DIR/MKR LT FWD REAR WHL PK @(10808) (LOCATED AT RIGHT BODY) / FLOOR LIFT DOOR LT &(10831) (LOCATED AT RIGHT BODY) / CONNECTOR 2206588C1 / CONNECTOR 1661889C1 BODY LOCK 1661890C1 / CONNECTOR 2206588C1 / MID LIFT DOOR LT &(10832) (LOCATED AT RIGHT BODY) / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/8 RH WDO / A B C / 1 2 / 1 2 / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A F57H 18 LTGN 1661261C1 B F58C 18 BN 1661261C1 C F58-GC 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 V122M 18 GY 3522190C1 3522193C1 2 V122-GP 18 WH 3522190C1 3522193C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 V122H 18 GY 3522190C1 3522193C1 2 V122-GN 18 WH 3522190C1 3522193C1 / Figure 1386 / CONNECTOR COMPOSITES @10808, &10831, &10832

Connector 10808: SIDE DIR/MKR LT FWD REAR WHL PK A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F57H	18	LTGN	1661261C1
B	F58C	18	BN	1661261C1
C	F58-GC	18	WH	1661261C1

Connector 10831: FLOOR LIFT DOOR LT

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	V122M	18	GY	3522190C1	3522193C1
2	V122-GP	18	WH	3522190C1	3522193C1

Connector 10832: MID LIFT DOOR LT

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	V122H	18	GY	3522190C1	3522193C1
2	V122-GN	18	WH	3522190C1	3522193C1

26.42. CONNECTOR COMPOSITES 10833, 10833A, 10837, P. 42
Figure 1387 CONNECTOR COMPOSITES 10833, 10833A, 10837

Components: AFT ENT DR (10837); MID LIFT DOOR LT (10833); MID LIFT DOOR LT (10833A)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.42. CONNECTOR COMPOSITES 10833, 10833A, 10837, P. 42 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090677 NO. 95504E 02MAR20 / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / MID LIFT DOOR LT (10833) (LOCATED AT LIFT DOOR) / MID LIFT DOOR LT (10833A) (LOCATED AT LIFT DOOR) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 2206588C1 / CONNECTOR 2206588C1 / SIDE MARKER LIGHT AFT ENT DR (10837) (LOCATED AT RIGHT BODY) / 1 2 / 1 2 / # W/6 TO 12 RH WDO * W/5,13 RH WDO / A B / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 V122H 18 GY 3522190C1 3522193C1 2 V122-GN 18 WH 3522190C1 3522193C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 V122A 18 GY 3522190C1 3522193C1 2 V122A-G 18 GY 3522190C1 3522193C1 / CAV CIRCUIT GA COLOR TERMINAL A# F58H 18 BN 1661261C1 A* F58D 18 BN 1661261C1 B# F58-GH 18 WH 1661261C1 B* F58-GD 18 WH 1661261C1 / Figure 1387 / CONNECTOR COMPOSITES 10833, 10833A, 10837

Connector 10833: MID LIFT DOOR LT

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	V122H	18	GY	3522190C1	3522193C1
2	V122-GN	18	WH	3522190C1	3522193C1

Connector 10833A: MID LIFT DOOR LT

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	V122A	18	GY	3522190C1	3522193C1
2	V122A-G	18	GY	3522190C1	3522193C1

Connector 10837: SIDE MARKER LIGHT AFT ENT DR A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	F58H	18	BN	1661261C1
A*	F58D	18	BN	1661261C1
B#	F58-GH	18	WH	1661261C1
B*	F58-GD	18	WH	1661261C1

Legend: # W/6 TO 12 RH WDO ; * W/5,13 RH WDO

26.43. CONNECTOR COMPOSITES 108387, @10840, P. 43
Figure 1388 CONNECTOR COMPOSITES 108387, @10840

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.43. CONNECTOR COMPOSITES 108387, @10840, P. 43 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090677 NO. RELEASE NO. 95504E 02MAR20 / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / SIDE MKR LT AFTER REAR WHL PKT @(10838) (LOCATED AT RIGHT BODY) / DOME LT SECT 2 @(10840) (LOCATED AT RIGHT BODY) A B / CONNECTOR 1661260C1 BODY LOCK 1661264C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / DOME LT SECT 2 @(10840) (LOCATED AT LIFT DOOR HARNESS) B A / # W/6 TO 12 RH WDO * W/5, 13 RH WDO / @ W/10 RH WDO / A B / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/10 RH WDO / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A# F58J 18 BN 1661261C1 A* F58E 18 BN 1661261C1 B# F58-GJ 18 WH 1661261C1 B* F58-GE 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F63A 16 DKBL 1661261C1 B F63-GA 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A V57 18 LTGN 1661262C1 B V57-G 18 WH 1661262C1 / Figure 1388 / CONNECTOR COMPOSITES 108387, @10840

Connector 10838: SIDE MKR LT AFTER REAR WHL PKT A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	F58J	18	BN	1661261C1
A*	F58E	18	BN	1661261C1
B#	F58-GJ	18	WH	1661261C1
B*	F58-GE	18	WH	1661261C1

Legend: # W/6 TO 12 RH WDO ; * W/5, 13 RH WDO

Connector 10840: DOME LT SECT 2 A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63A	16	DKBL	1661261C1
B	F63-GA	16	WH	1661261C1

Legend: @ W/10 RH WDO

Connector 10840: DOME LT SECT 2 B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	V57	18	LTGN	1661262C1
B	V57-G	18	WH	1661262C1

Figure 1389 CONNECTOR COMPOSITES @10841, @10842, @10843

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.44. CONNECTOR COMPOSITES @10841, @10842, @10843, P. 44 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090677 NO. RELEASE NO. 95504E 02MAR20 / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / DOME LT SECT 4 @(10841) (LOCATED AT RIGHT BODY) / DOME LT SECT 6 @(10842) (LOCATED AT RIGHT BODY) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / A A B B CONNECTOR 1661259C1 BODY LOCK 1661263C1 @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/10 RH WDO / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / DOME LT SECT 8 @(10843) (LOCATED AT RIGHT BODY) / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/10 RH WDO / A B / B A / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK W/10 RH WDO / DIRECTIONAL PASSTHROUGH @(10841) (LOCATED AT RIGHT BODY) / CONNECTOR 1661259C1 BODY LOCK 1661263C1 / A A B B / @ W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL A V57 18 LTGN 1661261C1 B V57-G 18 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F63C 16 DKBL 1661261C1 B F63-GC 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F63D 16 DKBL 1661261C1 B F63-GD 16 WH 1661261C1 / CAV CIRCUIT GA COLOR TERMINAL A F63B 16 DKBL 1661261C1 B F63-GB 16 WH 1661261C1 / Figure 1389 / CONNECTOR COMPOSITES @10841, @10842, @10843

Connector 10841: A A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63B	16	DKBL	1661261C1
B	F63-GB	16	WH	1661261C1

Connector 10841: DIRECTIONAL PASSTHROUGH

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	V57	18	LTGN	1661261C1
B	V57-G	18	WH	1661261C1

Connector 10842: DOME LT SECT 6 A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63C	16	DKBL	1661261C1
B	F63-GC	16	WH	1661261C1

Connector 10843: N/0508108 - NOT DOME LT SECT 8 B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63D	16	DKBL	1661261C1
B	F63-GD	16	WH	1661261C1

26.45. CONNECTOR COMPOSITES @10844, &11025A, &11025B, &11025C, P. 45 | Figure 1390 CONNECTOR COMPOSITES @10844, &11025A, &11025B, &11025C | printed page 1390

Connector 10844: DOME LT SECT 10 A B B A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	F63E	16	DKBL	1661261C1
B	F63-GE	16	WH	1661261C1

Connector 11025A: LIGHT MONITOR CONNECTOR A

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C89RR-M	16	OR	1661539C1
2	C89RA	16	OR	1661539C1
3	C89RA-M	16	OR	1661539C1
4	C89RR	16	OR	1661539C1
5	C89A-M	16	OR	1661539C1
6	C89B-M	16	OR	1661539C1

Connector 11025B: N/0508108 LIGHT MONITOR CONNECTOR B

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C89LR-M	16	OR	1661538C1
2	C89LA	16	OR	1661538C1
3	C89LA-M	16	OR	1661538C1
4	C89LR	16	OR	1661538C1
5	C89D-M	16	OR	1661538C1
6	C89C-M	16	OR	1661538C1

Legend: FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; - NOT FUSE BLOCK

Connector 11025C: CONNECTOR 2206667C1 LIGHT MONITOR CONNECTOR C

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C70	16	RD	1661539C1
2	C70R-M	16	RD	1661539C1
3	C57R-M	18	LTGN	1661539C1
4	C57	18	YL	1661539C1
6	C71	18	LTBL	1661539C1
7	C68R-M	16	BN	1661539C1
8	C71R-M	18	LTBL	1661539C1
9	-	-	-	-

Legend: FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; - NOT FUSE BLOCK

26.46. CONNECTOR COMPOSITES &11025D, &11026, &11027, P. 46 | Figure 1391 CONNECTOR COMPOSITES &11025D, &11026, &11027 | printed page 1391

Connector 11025D:

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	C70L-M	16	RD	1661538C1
2	C56	18	YL	1661538C1
3	C56L-M	18	YL	1661538C1
4	C128	16	LTBL	1661538C1
5	C71L-M	18	LTBL	1661538C1
6	C128-G	16	WH	1661538C1
7	C68	16	BN	1661538C1
8	C68L-M	16	BN	1661538C1
9	-	-	-	-

Connector 11026: LIFT DOOR LIGHT N/AC A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C122	16	GY	1661261C1
B	C122-G	16	WH	1661261C1

Connector 11027: LIFT DOOR LIGHT N/AC A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	C122	16	GY	1661261C1
B	C122-G	16	WH	1661261C1

26.47. INTENTIONALLY LEFT BLANK, P. 47
Figure 1392 INTENTIONALLY LEFT BLANK

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.47. INTENTIONALLY LEFT BLANK, P. 47 / CHAPTER 26 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090677 NO. 95504E 29FEB20 / MJV0488 13SEP21 REMOVED GEOMETRY. / INTENTIONALLY LEFT BLANK / Figure 1392 / INTENTIONALLY LEFT BLANK

26.48. CONNECTOR COMPOSITES @11303, @11337, P. 48 | Figure 1393 CONNECTOR COMPOSITES @11303, @11337 | printed page 1393

Connector 11303: TWO MIN TIMER NC 87 CAV 30

CAV	CIRCUIT	GA	COLOR	TERMINAL
30	B131AC	16	DKBL	239805R1
85	B11GC	16	WH	239805R1
86	B14AG	16	RD	239805R1
87*	B117D	16	GY	556897C1
87*	B117E	16	GY	556897C1

Legend: @ N/0508108 - NOT MTA FUSE BLOCK ; * W/CCM ENTR DOOR AND EMER EXIT ACTD

Connector 11337: CA 2018 SNOOZE ON 1 4 1 2 3*

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	PLUG	-	-	0453133C1
2	B89	18	OR	1651969C1
3*	B60A	18	OR	1651969C1
3#	B60H	18	OR	1651969C1
4*	B60B	18	OR	1651969C1
4#	B60	18	OR	1651969C1

Legend: @ W/0508108 - MTA FUSE BLOCK ; * W/THEFTMATE PREWIRE W/SNOOZE ; # W/CHECKMATE W/SNOOZE PLUS 9 W/EMER ACT

Connector 11303: BODY LOCK 3545579C1 TWO MIN TIMER NC 87

CAV	CIRCUIT	GA	COLOR	TERMINAL
30	B131AC	16	DKBL	239805R1
85	B11GCC	16	WH	239805R1
86	B14AG	16	RD	239805R1
87*	B117DG	16	GY	556897C1
87*	B117EE	16	GY	556897C1

Legend: @ W/0508108 - MTA FUSE BLOCK ; * W/CCM ENTR DOOR AND EMER EXIT ACTD

Connector 11337: CONNECTOR 2206594C1 CA 2018 SNOOZE ON 1 4 A B B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B131AC	16	DKBL	0333732C1
B	B11GC	16	WH	0333732C1
B	B14AG	16	RD	0333732C1
C	B117D	16	GY	0333732C1
C	B117E	16	GY	0333732C1
D	PLUG	-	-	0453133C1

Legend: @ N/0508108 - NOT MTA FUSE BLOCK

26.49. CONNECTOR COMPOSITES @11338, &11340, &11341, P. 49 | Figure 1394 CONNECTOR COMPOSITES @11338, &11340, &11341 | printed page 1394

Connector 11338: INPOWER HAZARD ASSERT 2# 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B60A	18	OR	3686945C1
1#	B60H	18	OR	3686945C1
2*	B14XA	16	RD	3686944C1
2#	B14P	16	RD	3686944C1
2#	B14P	14	RD	3686944C1
3	PLUG	-	-	3833742C1
4%	B56C	16	YL	3686944C1
4!	B56H	16	OR	3686944C1
4&	B56H	16	YL	3686944C1
5	PLUG	-	-	3833742C1
6	B60-G	16	WH	3686944C1
7	PLUG	-	-	3833742C1
8%	B57C	16	LTGN	3686944C1
8!	B57H	16	OR	3686944C1
8&	B57H	16	LTGN	3686944C1

Legend: @ W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK ; * W/THEFTMATE PREWIRE W/SNOOZE ; # W/CHECKMATE W/SNOOZE PLUS 9 W/EMER ACT ; % W/STOP/TAIL/TURN W/CHECKMATE W/SNOOZE W/LT MNTR ; ! W/STOP/TAIL/TURN LT W/CHECKMATE W/SNOOZE W/+9 ; & W/STOP/TAIL/TURN W/VID PREWIRE W/THEFTMATE

Connector 11340: CA 2018 CHECKMATE VL

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B12AB	18	LTBL	3761061C1
1#	B12	18	LTBL	3761061C1
2*	B130MD	18	GY	3761061C1
2#	B130A	18	GY	3761061C1
3	-	-	-	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT FUSE BLOCK ; * CHECKMATE W/SNOOZE,+9,EMER ACT & LIFT ; # CHECKMATE W/SNOOZE PLUS 9 W/EMER ACT

Connector 11341: ESPAR FUEL PUMP CA 2018 CHECKMATE OR 2* 2#

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2*	B125DM	18	GY	3761061C1
2#	B63	18	DKBL	3761061C1

26.50. CONNECTOR COMPOSITES &11342, &!11500, P. 50
Figure 1395 CONNECTOR COMPOSITES &11342, &!11500

26.50. CONNECTOR COMPOSITES &11342, &!11500, P. 50 | Figure 1395 CONNECTOR COMPOSITES &11342, &!11500 | printed page 1395

Connector 11342: CA 2018 CHECKMATE GN

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B101	18	TN	3761061C1
3	-	-	-	-

Connector 11500: CONNECTOR 4086451C1 ELECTRICAL PANEL SEALED ENGINE ENGINE COMPARTMENT))

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	B131C	16	DKBL	3544884C1
A2	B131D	18	DKBL	3544884C1
A3	B138	16	GY	3544876C1
A4*	B74B	12	LTGN	3544877C1
A4#	B74S	12	LTGN	3544877C1
A4&	B74H	12	LTGN	3544877C1
A4%	B74M	12	LTGN	3544877C1
A4!	B74N	12	LTGN	3544877C1
A4^	B74M	16	LTGN	3544876C1
A4^^	B74K	12	LTGN	3544877C1
A5	-	-	-	-
A6	B146B	12	GY	3544877C1
A7-A8	-	-	-	-
B1	B121	18	YL	3544884C1
B2	B78J	18	LTGN	3544884C1
B3-B4	-	-	-	-
B5	B135	16	OR	3544884C1
B6	-	-	-	-
B7	B122M	18	GY	3544884C1
B8!!	B122U	18	WH	3544884C1
B8**	B122T	18	GY	3544884C1
B9##	B125X	18	GY	3544884C1
B9&&	B125U	18	GY	3544884C1
B10&&	B125U-G	18	WH	3544884C1
B10##	B125W	18	GY	3544884C1
B11	B86M	16	LTGN	3544884C1
B12	B86N	16	LTGN	3544884C1
C1	B144A	18	GY	3544884C1
C2	B144	18	GY	3544884C1
C3	B77A	18	LTGN	3544884C1
C4	B77B	18	LTGN	3544884C1
C5-C11	-	-	-	-
C12	B41A	18	TN	3544884C1
D1	B41	18	TN	3544884C1

Legend: W/9 ; D3 B132 12 GY 3544877C1 ; D4-D6 - - - ; D7 B71A 16 LTBL 3544884C1 ; D8%% B71H 18 LTBL 3544884C1 ; D8%& B71H 16 LTBL 3544884C1

26.51. CONNECTOR COMPOSITES &11500, @11502, P. 51 | Figure 1396 CONNECTOR COMPOSITES &11500, @11502 | printed page 1396

Connector 11500: USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF INC. SEALED ENGINE /ELECTRICAL PA C B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A1	Y131	16	DKBL	3544886C1
A2	Y131D	16	DKBL	3544886C1
A3*	Y138	12	GY	3544881C1
A3#	Y138	16	GY	3544880C1
A4	Y74	12	LTGN	3544881C1
A5	-	-	-	-
A6	Y146	12	GY	3544881C1
A7	Y62	18	DKBL	3544886C1
A8	Y12	18	LTBL	3544886C1
A9-A12	-	-	-	-
B1	Y121	16	YL	3544886C1
B2	Y78A	16	LTGN	3544886C1
B3	Y124	16	LTGN	3544886C1
B4	-	-	-	-
B5	Y135	16	OR	3544886C1
B7	Y122	16	GY	3544886C1
B8	Y122A	16	GY	3544886C1
B9	Y125W	18	GY	3544886C1
B10	Y125X	18	GY	3544886C1
B11	Y86A	16	LTGN	3544886C1
B12	Y86	16	LTGN	3544886C1
C1	Y144A	16	GY	3544886C1
C2	Y144	16	GY	3544886C1
C3%	Y77	18	LTGN	3544886C1
C3^	Y77	16	LTGN	3544886C1
C4	Y77B	18	LTGN	3544886C1
C5-C11	-	-	-	-
C12	Y41A	18	TN	3544886C1
D1	Y41	18	TN	3544886C1
D2	Y140	18	TN	3544886C1
D3	Y132	12	GY	3544881C1
D4-D6	-	-	-	-
D7	Y71	16	LTBL	3544886C1
D8	Y71H	16	LTBL	3544886C1
D9-D12	-	-	-	-

Connector 11502: BOOSTER PUMP 2010 EMISSIONS

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y74	12	LTGN	2206597C1	2206612C1
2	Y74-G	12	WH	2206597C1	2206612C1

26.52. CONNECTOR COMPOSITES &11502, &11503, P. 52 | Figure 1397 CONNECTOR COMPOSITES &11502, &11503 | printed page 1397

Connector 11502: K CAV A* A#

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	B125-GA	16	WH	1661209C1
A#	B125-G	18	WH	1661208C1
B*	B60-G	16	WH	1661209C1
B#	B125-GA	18	GY	1661208C1
C*	B125-G	18	WH	1661208C1
C#	B125-GB	18	GY	1661208C1
D	B85A-G	18	WH	1661208C1
E	B53B-G	18	WH	1661208C1
F	B53C-G	18	WH	1661208C1
G	B125-GE	18	WH	1661208C1
H	B122DC	18	GY	1661208C1
J	-	-	-	-
K	-	-	-	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/CCM/TM W/SNOOZE W/LIFT ; # W/CCM/TM W/9,W/EMER ACT DOMES

Connector 11503: * CONNECTOR 2007315C1 # BODY LOCK 2007316C1 CCM/TM POWER SPLICE BLOCK COMPARTMENT LIGHT) K A! A% B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A!	B14	18	RD	1661208C1
A%	B14VA	18	RD	1661208C1
B	B14A	18	RD	1661208C1
C	B14HA	18	RD	1661208C1
D	B14HB	18	RD	1661208C1
E!	B14X	18	RD	1661208C1
E%	B14XD	18	RD	1661208C1
F	-	-	-	-
G	B14DB	18	RD	1661208C1
H	B14F	18	RD	1661208C1
J	-	-	-	-
K	-	-	-	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; ! N/0508108 - NOT MTA FUSE BLOCK ; % W/0508108 - MTA FUSE BLOCK

Connector 11503: ENG COMPT LT SWITCH IN CAV A*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A*	Y121A	16	YL	0239805R1
A#	Y121	16	YL	0239805R1

26.53. CONNECTOR COMPOSITES &11504, &11505, P. 53 | Figure 1398 CONNECTOR COMPOSITES &11504, &11505 | printed page 1398

Connector 11504: COMPARTMENT LIGHT) G

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B130A	18	GY	1661208C1
B	B130MD	18	GY	1661208C1
C	B125C	18	GY	1661208C1
D	B122DD	18	GY	1661208C1
E	-	-	-	-
F	-	-	-	-
G	-	-	-	-

Connector 11504: ENG COMPT LT SWITCH OUT A CAV A# A*

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	Y121A	16	YL	0239805R1
A*	Y121B	16	YL	0239805R1

Connector 11505: ENG COMPT LIGHT 1 CAV 1#

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1#	Y121A	16	YL	3522190C1	3522194C1
1*	Y121B	16	YL	3522190C1	3522194C1
2	Y121-GA	16	WH	3522190C1	3522193C1

26.54. CONNECTOR COMPOSITES &11505, &11506, P. 54 | Figure 1399 CONNECTOR COMPOSITES &11505, &11506 | printed page 1399

Connector 11505: COMPARTMENT) G

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B14SE	16	RD	1661209C1
B	B88BAT	18	LTGN	1661208C1
C	-	-	-	-
D	-	-	-	-
E	-	-	-	-
F	-	-	-	-
G	-	-	-	-

Connector 11506: SPECIAL EQUIP IGN FEED G

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B13SE	16	PK	1661209C1
B	B88IGN	18	LTGN	1661208C1
C	-	-	-	-
D	-	-	-	-
E	-	-	-	-
F	-	-	-	-
G	-	-	-	-

Connector 11506: PA HORN UNDERHOOD 1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y86	16	LTGN	3522190C1	3522194C1
2	Y86A	16	LTGN	3522190C1	3522194C1

26.55. CONNECTOR COMPOSITES &11507, &11509, P. 55 | Figure 1400 CONNECTOR COMPOSITES &11507, &11509 | printed page 1400

Connector 11507: GROUND SPLICE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	Y78-GA	16	WH	3535303C1	3535424C1
B	-	-	-	-	-
C	Y11-GC	16	WH	3535303C1	3535424C1
D	Y131-GD	16	WH	3535303C1	3535424C1
E	-	-	-	-	-
F#	Y71-G	16	WH	3535303C1	3535424C1
F%	Y71B	16	WH	3535303C1	3535424C1
G	Y11-GD	16	WH	3535303C1	3535424C1
H	Y121-GA	16	WH	3535303C1	3535424C1
J	Y140-G	18	WH	3535303C1	3535424C1
K	Y138-G	16	WH	3535303C1	3535424C1
L	Y11-GE	16	WH	3535303C1	3535424C1
M	Y135-G	16	WH	3535303C1	3535424C1

Connector 11509: GROUND/PWR SPLICE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	Y131B	16	DKBL	3535303C1	3535424C1
B	Y131A	16	DKBL	3535303C1	3535424C1
C	Y131	16	DKBL	3535303C1	3535424C1
D	Y131C	16	DKBL	3535303C1	3535424C1
E	Y131-GB	16	WH	3535303C1	3535424C1
F	Y131-GA	16	WH	3535303C1	3535424C1
G	Y11-GA	16	WH	3535303C1	3535424C1
H	Y131-GC	16	WH	3535303C1	3535424C1

Legend: J-K - - - ; L Y11-GB 16 WH 3535303C1 3535424C1 ; M - - -

26.56. CONNECTOR COMPOSITES &11511, &11512, &11513, &11514, P. 56 | Figure 1401 CONNECTOR COMPOSITES &11511, &11512, &11513, &11514 | printed page 1401

Connector 11511: 1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y135	16	OR	3522190C1	3522194C1
2	Y135-G	16	WH	3522190C1	3522193C1

Connector 11512: LIFT SOLENOID

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y122	16	GY	3522190C1	3522194C1
2	Y122A	16	GY	3522190C1	3522194C1

Connector 11513: TRACTION CHAINS

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y138	16	GY	3522190C1	3522194C1
2	Y138-G	16	WH	3522190C1	3522193C1

Connector 11514: TRACTION SANDERS

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	Y138	12	GY	2033816C1	0589390C1
B	Y138-G	12	WH	2033816C1	0589390C1
C	Y12	18	LT BL	2033819C1	1652325C1
D	Y62	18	DK BL	2033819C1	1652325C1

26.57. CONNECTOR COMPOSITES &11515, &11516, &11517, &11518, P. 57 | Figure 1402 CONNECTOR COMPOSITES &11515, &11516, &11517, &11518 | printed page 1402

Connector 11515: A

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	Y71H	16	LTBL	1667742C1	1661872C1
B	Y71-G	16	WH	1667742C1	1661872C1
C	Y71	16	LTBL	1667742C1	1661872C1

Connector 11516: BACK UP ALARM

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y71	16	LTBL	3522190C1	3522194C1
2	Y71-G	16	WH	3522190C1	3522193C1

Connector 11517: AED STEP LIGHT

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y131D	16	DKBL	3522190C1	3522194C1
2	Y131-GD	16	WH	3522190C1	3522193C1

Connector 11518: AIR COMPRESSOR

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y146	12	GY	2206596C1	2206612C1
2	Y146-G	12	WH	2206596C1	2206612C1

Figure 1403 CONNECTOR COMPOSITES &11519, &11520, &11520A, &11521

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.58. CONNECTOR COMPOSITES &11519, &11520, &11520A, &11521, P. 58 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090677 NO. 95504E 02MAR20 / CHAPTER 26 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / CROSSVIEW HTD MIRROR SEALED ENG/ FR END HARNESS &(11519) (LOCATED IN SEALED ENGINE HARNESS) / 1 2 / CONNECTOR 2206588C1 / CONNECTOR 3512967C1 / TYRE WINCH &(11520) (LOCATED IN SEALED ENGINE HARNESS) / TIRE WINCH FUSE &(11520A) (LOCATED IN SEALED ENGINE HARNESS) / CONNECTOR 3525613C1 / BATTERY ISOLATOR &(11521) (LOCATED IN SEALED ENGINE HARNESS) / CONNECTOR 2206587C1 / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 Y140 18 TN 2206584C1 3522193C1 2 Y140-G 18 WH 2206584C1 3522193C1 / CAV CIRCUIT GA COLOR TERMINAL A Y115A 10 LTGN 3679001C1 B Y115-G 10 WH 3679001C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 Y78A 16 LTGN 3522190C1 3522194C1 2 Y78-GA 16 WH 3522190C1 3522193C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A Y115 10 LTGN 3515522C1 3515525C1 B Y115A 10 LTGN 3515522C1 3515525C1 / Figure 1403 / CONNECTOR COMPOSITES &11519, &11520, &11520A, &11521

Connector 11519: 1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y78A	16	LTGN	3522190C1	3522194C1
2	Y78-GA	16	WH	3522190C1	3522193C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK

Connector 11520: TYRE WINCH

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	Y115A	10	LTGN	3679001C1
B	Y115-G	10	WH	3679001C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK

Connector 11520A: TIRE WINCH FUSE

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	Y115	10	LTGN	3515522C1	3515525C1
B	Y115A	10	LTGN	3515522C1	3515525C1

Connector 11521: CONNECTOR 3525613C1 BATTERY ISOLATOR

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y140	18	TN	2206584C1	3522193C1
2	Y140-G	18	WH	2206584C1	3522193C1

26.59. CONNECTOR COMPOSITES &11522, &11523, &11524, &11526, P. 59
Figure 1404 CONNECTOR COMPOSITES &11522, &11523, &11524, &11526

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.59. CONNECTOR COMPOSITES &11522, &11523, &11524, &11526, P. 59 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090677 NO. 95504E 02MAR20 / CHAPTER 26 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / FIRE SUPPRESSION SYSTEM &(11522) (LOCATED IN SEALED ENGINE HARNESS) / 1 2 / CONNECTOR 2206588C1 / CONNECTOR 0587567C91 / ENGINE COMPARTMENT TEMP SENSOR &(11523) (LOCATED IN SEALED ENGINE HARNESS) / BOOSTER PUMP PRE 2010 EMISSIONS &(11524) (LOCATED IN SEALED ENGINE HARNESS) / CONNECTOR 2206603C1 LOCKPLATE 2206602C1 / A B / 1 2 / FWD STEP LIGHT &(11526) (LOCATED IN SEALED ENGINE HARNESS) / CONNECTOR 2206588C1 / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 Y131B 16 DKBL 3522190C1 3522193C1 2 Y131-GB 16 WH 3522190C1 3522193C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV A Y41 18 TN 0587578C1 1652325C1 B Y41A 18 TN 0587578C1 1652325C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 Y144 16 GY 3522190C1 3522194C1 2 Y144A 16 GY 3522190C1 3522194C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 Y74 12 LTGN 2206597C1 2206612C1 2 Y74-G 12 WH 2206597C1 2206612C1 / Figure 1404 / CONNECTOR COMPOSITES &11522, &11523, &11524, &11526

Connector 11522: INC. FIRE SUPPRESSION SYSTEM

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y144	16	GY	3522190C1	3522194C1
2	Y144A	16	GY	3522190C1	3522194C1

Connector 11523: ENGINE COMPARTMENT TEMP SENSOR

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
A	Y41	18	TN	0587578C1	1652325C1
B	Y41A	18	TN	0587578C1	1652325C1

Connector 11524: BOOSTER PUMP PRE 2010 EMISSIONS

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y74	12	LTGN	2206597C1	2206612C1
2	Y74-G	12	WH	2206597C1	2206612C1

Connector 11526: FWD STEP LIGHT

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y131B	16	DKBL	3522190C1	3522193C1
2	Y131-GB	16	WH	3522190C1	3522193C1

26.60. CONNECTOR COMPOSITES &11527, &11528, &11529, &11530, P. 60 | Figure 1405 CONNECTOR COMPOSITES &11527, &11528, &11529, &11530 | printed page 1405

Connector 11527: PA HORN UNDER STEPWELL 1 CAV

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y86	16	LTGN	3522190C1	3522194C1
2	Y86A	16	LTGN	3522190C1	3522194C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK

Connector 11528: BOTTOM STEP WARMER CAV

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1*	Y132A	12	GY	2206597C1	2206612C1
1#	Y132	12	GY	2206597C1	2206612C1
2*	Y132-GA	12	WH	2206597C1	2206612C1
2#	Y132-G	12	WH	2206597C1	2206612C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/BOTTOM & SECOND STEP WARMERS ; # W/BOTTOM STEP WARMER WIRES

Connector 11529: SECOND STEP WARMER CAV

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y132B	12	GY	2206597C1	2206612C1
2	Y132-GB	12	WH	2206597C1	2206612C1

Connector 11530: AFT STEP LIGHT CAV

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y131A	16	DKBL	3522190C1	3522193C1
2	Y131-GA	16	WH	3522190C1	3522193C1

Figure 1406 CONNECTOR COMPOSITES &11532A, &11533, &11534, &11535

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.61. CONNECTOR COMPOSITES &11532A, &11533, &11534, &11535, P. 61 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS RELEASE NO. PART AE08090677 NO. 95504E 02MAR20 / CHAPTER 26 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / LIFT RELAY &(11532A) (LOCATED IN SEALED ENGINE HARNESS) / 1 2 / CONNECTOR 2206588C1 / CONNECTOR 2206585C1 / A/C IGNITION SOURCE &(11533) (LOCATED IN SEALED ENGINE HARNESS) / ENG COMPT LIGHT &(11534) (LOCATED IN SEALED ENGINE HARNESS) / BOOSTER PUMP 2010 CE &(11535) (LOCATED IN SEALED ENGINE HARNESS) / 1 2 / CONNECTOR 2206588C1 / CONNECTOR 2206603C1 LOCKPLATE 2206602C1 / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 Y74 12 LTGN 2206597C1 2206612C1 2 Y74-G 12 WH 2206597C1 2206612C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 Y77 18 LTGN 2206584C1 3522193C1 / CAV CIRCUIT GA COLOR TERMINAL SEAL/SLV 1 Y121 16 YL 3522190C1 3522194C1 2 Y121A 16 YL 3522190C1 3522194C1 / Figure 1406 / CONNECTOR COMPOSITES &11532A, &11533, &11534, &11535

Connector 11532A: LIFT RELAY 1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y122	16	GY	3522190C1	3522194C1
2	Y122A	16	GY	3522190C1	3522194C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK

Connector 11533: A/C IGNITION SOURCE

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y77	18	LTGN	2206584C1	3522193C1

Connector 11534: ENG COMPT LIGHT

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y121	16	YL	3522190C1	3522194C1
2	Y121A	16	YL	3522190C1	3522194C1

Connector 11535: BOOSTER PUMP 2010 CE

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y74	12	LTGN	2206597C1	2206612C1
2	Y74-G	12	WH	2206597C1	2206612C1

26.62. CONNECTOR COMPOSITE &11536, &11537, &11538, %11539A, P. 62 | Figure 1407 CONNECTOR COMPOSITES &11536, &11537, &11538, %11539A | printed page 1407

Connector 11536: BOOSTER PUMP HIGH OUTPUT CE ENGINE HARNESS)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	PLUG	-	-	0453133C1
2	Y74-G	12	WH	3557534C1
3	Y74A	12	RD	3557534C1
4	Y74	12	LT GN	3557534C1

Connector 11537: WEDGELOCK 3557539C1 BOOSTER PUMP HIGH OUTPUT BE ENGINE HARNESS)

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	PLUG	-	-	0453133C1
2	Y74-G	12	WH	3557534C1
3	Y74A	12	RD	3557534C1
4	Y74	12	LT GN	3557534C1

Connector 11538: WEDGELOCK 3557539C1 BOOSTER PUMP HIGH OUTPUT FUSE ENGINE HARNESS)

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	Y74B	12	RD	1661708C1
B	Y74A	12	RD	1661708C1

Connector 11539A: CONNECTOR 1667639C1 REAR ILLUMINATION LIGHT 2

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	R71AB	16	LT BL	2206584C1
2	R71BB	16	WH	2206584C1

26.63. CONNECTOR COMPOSITES &11540, &11545, %11548, &11601, &11623A, P. 63 | Figure 1408 CONNECTOR COMPOSITES &11540, &11545, %11548, &11601, &11623A | printed page 1408

Connector 11540: A CAV A B

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	Y77D	18	LTGN	0333732C1
B	Y77C	18	LTGN	0333732C1
C	Y77B	18	LTGN	0333732C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK

Connector 11545: & CONNECTOR 0598839C1 CHILD SAFETY ALARM 1 CAV 1

CAV	CIRCUIT	GA	COLOR	TERMINAL	SEAL/SLV
1	Y125W	18	GY	3522190C1	3522193C1
2	Y125X	18	GY	3522190C1	3522193C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK

Connector 11548: CONNECTOR 2206588C1 4 EV BACK UP ALARM/NOISE GEN TO FWD CHASSIS ENGINE HARNESS) CAV CIRCUIT 1 Y86RR1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	Y86RR1	18	LT A	3613771C1
2	Y86RR2	18	LT A	3613771C1
3	Y71A	16	LT BL	3613770C1
4	Y71B	16	WH	3613770C1

Connector 11601: 1 CONNECTOR 3820176C1 STOP ARM WARNING LT SPLICE CONTROL PANEL) A ML B! B* C

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B89T	16	OR	3534164C1
B!	B89AA	18	OR	3534164C1
B*	B89AAC	18	OR	3534164C1
C	B89C	16	OR	3534164C1
D!	B89	18	OR	3534164C1

Legend: E-J - - - ; K B89D 16 OR 3534164C1 ; K* B89DA 16 OR 3534164C1 ; K* B89DB 16 OR 3534164C1 ; L B89BB 18 OR 3534164C1 ; M B89P 16 OR 3534164C1 ; & W/COMMON FOR VEHICLE W/0508108 - MTA ; FUSE BLOCK AND N/0508108 - NOT FUSE BLOCK ; * W/0508108 - MTA FUSE BLOCK

Connector 11623A: ! WEBASTO SMART TIMER 3 1 2 3* 3#

Table: ! N/0508108 - NOT MTA FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B74K	16	LTGN	3545087C1
1#	B74	16	LTGN	3545087C1
2	B74-G	16	WH	3545087C1
3*	B74E	16	LTGN	3545087C1
3#	B74S	16	LTGN	3545087C1
4*	B74L	18	LTGN	3902785C1
4#	B74D	18	LTGN	3902785C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT FUSE BLOCK ; * W/BOOS PUMP W/FR MTD HTR W/SMART TIMER ; # W/BSTR PUMP W/FR HTR W/TIMER IN ELEC PNL ; REV REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 02MAR20 AE08090677 063

26.64. CONNECTOR COMPOSITES *11626, !11626, &11627, &11628, %11630, P. 64 | Figure 1409 CONNECTOR COMPOSITES *11626, !11626, &11627, &11628, %11630 | printed page 1409

Connector 11626: 2 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B75AK	16	LTGN	1680205C1
2	B75AH	16	LTGN	1680205C1

Legend: * W/0508108 - MTA FUSE BLOCK

Connector 11626: CONNECTOR 3866308C1 BODY LOCK 1684263C1 RR HEATER DIODE PACK 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B75AK	16	LTGN	1661538C1
2	B75AH	16	LTGN	1661538C1

Legend: ! N/0508108 - NOT MTA FUSE BLOCK

Connector 11628: CSA SPEAKER

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B125X	18	GY	3982617C1
2	-	-	-	-
3	B125W	18	GY	3982617C1

Connector 11630: CONNECTOR 3982619C1 7 DAY TIMER WEBASTO 12 11 10

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B74K	18	DK BL	3548971C1
2	B74C	18	LT A	3548971C1
3	-	-	-	-
4	B74H	18	WH	3548971C1
5-7	-	-	-	-
8	B74D	18	LT A	3548971C1
9	-	-	-	-
10	B74L	18	PK	3548971C1
11	B74B	18	LT A	3548971C1
12	B74J	18	WH	3548971C1

Legend: % N/0508108 - NOT MTA FUSE BLOCK ; REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE ; 95504E 02MAR20 AE08090677 064

26.65. CONNECTOR COMPOSITES &11631, &11632, &11633, &11634, &11635, P. 65 | Figure 1410 CONNECTOR COMPOSITES &11631, &11632, &11633, &11634, &11635 | printed page 1410

Connector 11631: 4 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B74K	16	LTGN	1680205C1
2	B74J	16	LTGN	1680205C1
3	B74-GB	18	WH	1680205C1
4	B74E	18	RD	1680205C1

Connector 11632: CONNECTOR 3545577C1 BODY LOCK 3545579C1 WEBASTO SMART TIMER 3 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B74B	16	RD	3545087C1
2	B74-GA	16	WH	3545087C1
3	B74C	18	LTGN	3902785C1
4	B74D	18	LTGN	3902785C1

Legend: FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; - NOT FUSE BLOCK

Connector 11633: CONNECTOR 3544980C1 NOISE ABATEMENT SPLICE G

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B118R	16	LTBL	1661209C1
B	B118S	16	LTBL	1661209C1
C	B118T	16	LTBL	1661209C1
D	-	-	-	-
E	-	-	-	-
F	-	-	-	-
G	-	-	-	-

Connector 11634: NOISE ABATEMENT 1 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B118S	16	LTBL	3535326C1

Connector 11635: CONNECTOR 2206658C1 NOISE ABATEMENT 2 A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B118T	16	LTBL	3535326C1

26.66. CONNECTOR COMPOSITES *11636, *11637, *11638, &11640, &11641, P. 66 | Figure 1411 CONNECTOR COMPOSITES *11636, *11637, *11638, &11640, &11641 | printed page 1411

Connector 11636: RF HTR DIODE PACK CAV

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B75AG	16	LTGN	1680205C1
2	B75AN	16	LTGN	1680205C1

Legend: * W/0508108 - MTA FUSE BLOCK

Connector 11637: LR HTR DIODE PACK CAV 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B75AF	16	LTGN	1680205C1
2	B75AP	16	LTGN	1680205C1

Legend: * W/0508108 - MTA FUSE BLOCK

Connector 11638: LF HTR DIODE PACK CAV 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B75AE	16	LTGN	1680205C1
2	B75AR	16	LTGN	1680205C1

Connector 11640: CHILD MONITOR DOME LT OUT 2 1 1 2* 2#

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2*	B125L	18	GY	3761061C1
2#	B63AA	18	DKBL	3761061C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/CHILD MONITOR W/EMER ACTVTD DOME W/9 ; # W/CCM ENTR DOOR AND EMER EXIT ACTVD

Connector 11641: CONNECTOR 4086453C1 * # CHILD MONITOR DOOR SW INPUT 1 2 3 1# 2% 2*

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B12AA	18	LTBL	3761061C1
1#	B125	18	GY	3761061C1
2%	B120B	18	LTGN	3761061C1
2*	B117A	18	GY	3761061C1
3	-	-	-	-

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/CCM ENTR DOOR AND EMER EXIT ACTD ; # W/PTI ACTIVE INDICATOR LIGHT ; % W/CHILD MONITOR W/ EMER ACTVTD DOME W/9

26.67. CONNECTOR COMPOSITES !11636, !11637, !11638, P. 66A
Figure 1412 CONNECTOR COMPOSITES !11636, !11637, !11638

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.67. CONNECTOR COMPOSITES !11636, !11637, !11638, P. 66A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, RELEASE NO. PART AE08090677 NO. 96183U 20JUL21 / CHAPTER 26 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / RF HTR DIODE PACK !(11636) (LOCATED IN ELECTRICAL PANEL) / CONNECTOR 1669030C1 / ! N/0508108 - NOT MTA FUSE BLOCK / 1 2 / RF HTR DIODE PACK !(11637) (LOCATED IN ELECTRICAL PANEL) / ! N/0508108 - NOT MTA FUSE BLOCK / CONNECTOR 1669030C1 / 1 2 / RF HTR DIODE PACK !(11638) (LOCATED IN ELECTRICAL PANEL) / 1 2 / CONNECTOR 1669030C1 / ! N/0508108 - NOT MTA FUSE BLOCK / CAVITY CIRCUIT GA COLOR TERMINAL A B75AG 16 LT GN 1661538C1 B B75AN 16 LT GN 1661538C1 / CAVITY CIRCUIT GA COLOR TERMINAL A B75AF 16 LT GN 1661538C1 B B75AP 16 LT GN 1661538C1 / CAVITY CIRCUIT GA COLOR TERMINAL A B75AE 16 LT GN 1661538C1 B B75AR 16 LT GN 1661538C1 / Figure 1412 / CONNECTOR COMPOSITES !11636, !11637, !11638

Connector 11636: RF HTR DIODE PACK 1

CIRCUIT	GA	COLOR	TERMINAL
B75AG	16	LT GN	1661538C1
B75AN	16	LT GN	1661538C1

Legend: ! N/0508108 - NOT MTA FUSE BLOCK

Connector 11637: RF HTR DIODE PACK

CIRCUIT	GA	COLOR	TERMINAL
B75AF	16	LT GN	1661538C1
B75AP	16	LT GN	1661538C1

Legend: ! N/0508108 - NOT MTA FUSE BLOCK

Connector 11638: RF HTR DIODE PACK

CIRCUIT	GA	COLOR	TERMINAL
B75AE	16	LT GN	1661538C1
B75AR	16	LT GN	1661538C1

26.68. CONNECTOR COMPOSITES &11641A, &11642, &11642A, &11643, P. 67 | Figure 1413 CONNECTOR COMPOSITES &11641A, &11642, &11642A, &11643 | printed page 1413

Connector 11641A:
Table: BODY COMPOSITE MATING

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B125MA	18	GY	3761061C1
1#	B125AA	18	BK	3761061C1
2*	B125MB	18	GY	3761061C1
2#	B125AB	18	LTGN	3761061C1
3*	B125MC	18	GY	3761061C1
3#	B125AC	18	RD	3761061C1

Legend: * W/THEFTMATE PREWIRE W/SNOOZE ; # W/CCM/TM W/9,W/EMER ACT DOMES ; FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; - NOT FUSE BLOCK

Connector 11642: CHILD MONITOR
Table: FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B125D	18	GY	3761061C1
1#	B14AA	18	RD	3761061C1
2*	B125-GD	18	WH	3761061C1
2#	B11GE	18	WH	3761061C1
3*	B125	18	GY	3761061C1
3#	B13AA	18	PK	3761061C1
4	B125A	18	GY	3761061C1
5	B119	18	GY	3761061C1
6*	B125F	18	GY	3761061C1
6#	B53BA	18	GY	3761061C1

Legend: * W/CHILD MON COMMON ; # W/CCM ENTR DOOR AND EMER EXIT ACTVD ; FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; - NOT FUSE BLOCK

Connector 11642A: & THEFT MATE RED DOT IN ELECTRICAL PANEL))
Table: FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B14A	18	RD	3761061C1
1#	B14CMA	18	RD	3761061C1
2*	B125-G	18	WH	3761061C1
2#	B125-GA	18	GY	3761061C1
3*	B13A	18	PK	3761061C1
3#	B125H	18	GY	3761061C1
4*	B125D	18	GY	3761061C1
4#	B125B	18	GY	3761061C1
5*	B60B	18	OR	3761061C1
5#	B119	18	GY	3761061C1
6*	B125HH	18	GY	3761061C1
6#	B125E	18	GY	3761061C1

Legend: * W/CCM/TM W/SNOOZE W/LIFT ; # W/CCM/TM W/9,W/EMER ACT DOMES ; FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; - NOT FUSE BLOCK

Connector 11643: & SEON POWER 3 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B14AH	16	RD	3545087C1
2	B11-GZ	16	WH	3545087C1
3	-	-	-	-
4	B13K	18	PK	3902785C1

26.69. CONNECTOR COMPOSITES &11644, &11645, &11646, !11647, !11648, P. 68 | Figure 1414 CONNECTOR COMPOSITES &11644, &11645, &11646, !11647, !11648 | printed page 1414

Connector 11644: 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B56LA	18	OR	1661539C1
1#	B56LA	18	YL	1661539C1
2	B119V	18	GY	1661539C1
3	B70C	18	RD	1661539C1
4*	B57RA	18	OR	1661539C1
4#	B57RA	18	LTGN	1661539C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/STOP/TAIL/DIR LT W/VIDEO CCM & SNOOZE +9 ; # W/STOP/TAIL/TURN LT W/VIDEO W/THEFT

Connector 11645: CONNECTOR 2206661C1 RED DRIVERS OVERHEAD LIGHT 7 8 4 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B63A	16	DKBL	1661226C1
3	B63B	18	DKBL	1661224C1
4-6	-	-	-	-
7	B62-GA	18	WH	1661224C1
8	B62A	18	DKBL	1661224C1
9-10	-	-	-	-

Connector 11646: CONNECTOR 3530563C1 RED DRIVERS DOME LIGHT DROP B A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B63B	18	DKBL	1661262C1
B	B63-GA	16	WH	1661262C1

Legend: & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK

Connector 11647: CONNECTOR 1661260C1 BODY LOCK 1661264C1 THEFT MATE YEL DOT 1 2 3 4 5

Table: AND N/0508108 - NOT FUSE BLOCK

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B101	18	TN	3761061C1
1#	B125AD	18	GY	3761061C1
2	B125AE	18	GY	3761061C1
3	B125AF	18	GY	3761061C1
4	B70D	18	RD	3761061C1
5&	B63A	18	DKBL	3761061C1
5%	B125N	18	GY	3761061C1

Legend: ! W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/THEFTMATE PREWIRE W/SNOOZE ; # W/THEFT MATE PREWIRE ; % W/CCM/TM W/9,W/EMER ACT DOMES ; & W/STOP/TAIL/TURN LT W/CHK W/9 W/THEFT

Connector 11648: THEFT MATE SIG VIO DOT 1 2 3

CAV	CIRCUIT	GA	COLOR	TERMINAL
1*	B12A	18	LTBL	3761061C1
1#	B125C	18	GY	3761061C1
2%	B125CMD	18	GY	3761061C1
2*	B130MD	18	GY	3761061C1
3&	B125H	18	GY	3761061C1
3#	B125AH	20	GY	3761061C1

Legend: ! W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK ; AND N/0508108 - NOT FUSE BLOCK ; * W/THEFTMATE PREWIRE W/SNOOZE ; # W/THEFT MATE PREWIRE ; & W/CCM/TM W/SNOOZE W/LIFT ; % W/THEFT MATE PREWIRE PLUS 9 ; REV REFERENCE DRAWN ; 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS ; RELEASE NO. DATE

26.70. CONNECTOR COMPOSITES &11653, &11654, &11760, &11770, P. 69 | Figure 1415 CONNECTOR COMPOSITES &11653, &11654, &11760, &11770 | printed page 1415

Connector 11653: INC. SEON POWER 3 1
Table: SEON POWER &(11653)

FUSE	CAV	CIRCUIT	GA	COLOR	TERMINAL
1 3	1	B14	16	RD	3545087C1
1 3	2	B11	16	WH	3545087C1
	3	-	-	-	-
	4	B13	18	PK	3902785C1

Legend: & W/0508108 - MTA FUSE BLOCK ; CONNECTOR 3544980C1 ; SEON SIGNALS ; &(11654) ; NEAR TO FUSE BLOCK IN ELECTRICAL PANEL)

Connector 11654: & CONNECTOR 3544980C1 SEON SIGNALS

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B56LA	18	YL	1661539C1
2	B119	18	GY	1661539C1
3	B70C	18	RD	1661539C1
4	B57RA	18	LTGN	1661539C1

Connector 11760: CONNECTOR 2206661C1 AMBER CANCEL 7 8 4 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	-	-	-	-
2	B123-GB	18	WH	1661224C1
3	B123-GC	18	WH	1661224C1
4	-	-	-	-
5	B11-G	18	WH	1661224C1
6	B11-GA	18	WH	1661224C1
7*	B62-G	18	WH	1661224C1
7#	B62-GA	18	WH	1661224C1
8*	B62	18	DKBL	1661224C1
8#	B62A	18	DKBL	1661224C1

Legend: * W/MSTR,RRX,AMB CNCL W/2 POSN TOGGLE ; # W/3 POSN TOGGLE & W/AMBER CANCEL ; FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; - NOT FUSE BLOCK

Connector 11770: & N/0508108 3 POSN TOGGLE W/AMBER CANCEL A
Table: TOGGLE W/AMBER CANCEL &(11770)

FUSE	CAV	CIRCUIT	GA	COLOR	TERMINAL
A	A*	B123-GB	18	WH	0879632R1
A	A*	B123-GD	18	WH	0879632R1
A	B	B120-G	18	WH	0879630R1
A	C	-	-	-	-
E B	D	B9D	18	GY	0879630R1
E B	E	B9A	18	GY	0879630R1

Legend: * W/3 POSN TOGGLE & W/AMBER CANCEL ; D C ; & W/COMMON FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; N/0508108 - NOT FUSE BLOCK ; CONNECTOR 0491058C1

26.71. CONNECTOR COMPOSITES !11653, P. 69A
Figure 1416 CONNECTOR COMPOSITES !11653

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.71. CONNECTOR COMPOSITES !11653, P. 69A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, RELEASE NO. PART AE08090677 NO. 96183U 21JUL21 / CHAPTER 26 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / SEON POWER !(11653) (LOCATED NEAR TO FUSE BLOCK IN ELECTRICAL PANEL) 1 3 / CONNECTOR 3544980C1 / ! N/0508108 - NOT MTA FUSE BLOCK / 2 4 / CAVITY CIRCUIT GA COLOR TERMINAL 1 B14 16 RD 3545087C1 2 B11 16 WH 3545087C1 3 - - - - 4 B13 18 PK 3902785C1 / Figure 1416 / CONNECTOR COMPOSITES !11653

Connector 11653: SEON POWER IN ELECTRICAL PANEL) 3 1

CIRCUIT	GA	COLOR	TERMINAL
B14	16	RD	3545087C1
B11	16	WH	3545087C1
-	-	-	-
B13	18	PK	3902785C1

26.72. CONNECTOR COMPOSITES &14510, &14510A, &14601, P. 70 | Figure 1417 CONNECTOR COMPOSITES &14510, &14510A, &14601 | printed page 1417

Connector 14510: WEBASTO SMARTEMP 3 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B74B	16	LTGN	3545087C1
2	B74-GA	16	WH	3545087C1
3	B74C	18	LTGN	3902785C1
4	B74D	18	LTGN	3902785C1

Legend: FOR VEHICLE W/0508108 - MTA FUSE BLOCK AND ; - NOT FUSE BLOCK

Connector 14510A: WEBASTO SMART TEMP TIMER 3 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B74M	16	LTGN	3545087C1
2	B74-G	16	WH	3545087C1
3	B74E	16	LTGN	3545087C1
4	B74L	18	LTGN	3902785C1

Connector 14601: PTI ACTIVE INDICATOR LIGHT 1B 1A

CAV	CIRCUIT	GA	COLOR	TERMINAL
1A	B125	18	GY	1661224C1
1B	B25-G	18	WH	1661224C1

Legend: - MTA FUSE BLOCK

26.73. CONNECTOR COMPOSITES %14520, %14521, %14600, *14602, P. 70A | Figure 1418 CONNECTOR COMPOSITES %14520, %14521, %14600, *14602 | printed page 1418

Connector 14520:

CAV	CIRCUIT	GA	COLOR	TERMINAL
A	B137B	16	LTBL	3544876C1
B	B137-GB	16	WH	3544876C1
C	B137D	16	LTBL	3544876C1
D	B137C	18	LTBL	3544876C1

Legend: % N/0508108 - NOT MTA FUSE BLOCK

Connector 14521: TO DISTRIBUTOR UNIT POWER AND GROUND 1 5

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B137-GK	16	WH	3545087C1
2	B137K	16	LTBL	3545087C1

Connector 14600: CONNECTOR 4122449C1 FUEL DOOR OPEN INDICATOR 1A 1B

CAV	CIRCUIT	GA	COLOR	TERMINAL
1A	B171	18	GY	1661224C1
1B	B171-GD	18	WH	1661224C1
2A	-	-	-	-
2B	-	-	-	-

Connector 14602: LYTX CAMERA PREWIRE 1B 1A

CAV	CIRCUIT	GA	COLOR	TERMINAL
A#	B14AJ	16	RD	1661261C1
A%	B14AH	16	RD	1661261C1
B#	B13F	18	PK	1661261C1
B%	B13K	18	PK	1661261C1
C#	B11-GL	16	WH	1661261C1
C%	B11-GZ	16	WH	1661261C1

Legend: * W/COMMON FOR VEHICLE W/0508108 - MTA FUSE ; BLOCK AND N/0508108 - NOT MTA FUSE BLOCK ; % N/0508108 - NOT MTA FUSE BLOCK ; # W/0508108 - MTA FUSE BLOCK

26.74. CONNECTOR COMPOSITES @83174, @84273, @84331, P. 71
Figure 1419 CONNECTOR COMPOSITES @83174, @84273, @84331

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.74. CONNECTOR COMPOSITES @83174, @84273, @84331, P. 71 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / 23112202 CIRCUIT DIAGRAM, BE,CE BUS MODELS PART AE08090677 NO. RELEASE NO. 95504E 02MAR20 / CHAPTER 26 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 ADDED NOTE FOR FUSE BLOCK. / INPOWER DIMMER OUTPUT 1 @(84273) (LOCATED IN ELECTRICAL PANEL) / CONNECTOR 1669030C1 / REAR ROW EMER DOME LT @(84331) (LOCATED IN ELECTRICAL PANEL) / CONNECTOR 1669030C1 / CONNECTOR 3866308C1 BODY LOCK 1684263C1 / INPOWER DIMMER OUTPUT 2 @(83174) (LOCATED IN ELECTRICAL PANEL) / @ W/0508108 - MTA FUSE BLOCK / @ N/0508108 - NOT MTA FUSE BLOCK / @ N/0508108 - NOT MTA FUSE BLOCK / CAV CIRCUIT GA COLOR TERMINAL 1 B63A 16 DKBL 1680205C1 2 B63C 16 DKBL 1680205C1 / CAV CIRCUIT GA COLOR TERMINAL 1 B63-G 14 WH 1680205C1 2 B63-GA 14 WH 1680205C1 / CAV CIRCUIT GA COLOR TERMINAL 1 B63B 16 DKBL 1680205C1 2 B63D 16 DKBL 1680205C1 / Figure 1419 / CONNECTOR COMPOSITES @83174, @84273, @84331

Connector 83174: INPOWER DIMMER OUTPUT 2 CAV

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B63B	16	DKBL	1680205C1
2	B63D	16	DKBL	1680205C1

Connector 84273: INPOWER DIMMER OUTPUT 1 CAV 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B63A	16	DKBL	1680205C1
2	B63C	16	DKBL	1680205C1

Connector 84331: @ REAR ROW EMER DOME LT CAV 1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	B63-G	14	WH	1680205C1
2	B63-GA	14	WH	1680205C1

26.75. CONNECTOR COMPOSITES !83174, !84273, !84331, P. 71A
Figure 1420 CONNECTOR COMPOSITES !83174, !84273, !84331

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 26.75. CONNECTOR COMPOSITES !83174, !84273, !84331, P. 71A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / MJV1085 CIRCUIT DIAGRAM, BE,CE BUS MODELS, RELEASE NO. PART AE08090677 NO. 96183U 21JUL21 / CHAPTER 26 CONNECTOR BODY COMPOSITE MATING VIEW SHOWN / MJV0488 13SEP21 INITIAL PRODUCTION RELEASE. / INPOWER DIMMER OUTPUT 2 !(83174) (LOCATED IN ELECTRICAL PANEL) / CONNECTOR 1669030C1 / ! N/0508108 - NOT MTA FUSE BLOCK / 1 2 / ! W/0508108 - MTA FUSE BLOCK / CONNECTOR 3866308C1 BODY LOCK 1684263C1 / REAR ROW EMER DOME LT !(84331) (LOCATED IN ELECTRICAL PANEL) / INPOWER DIMMER OUTPUT 2 !(84273) (LOCATED IN ELECTRICAL PANEL) / CONNECTOR 3866308C1 BODY LOCK 1684263C1 / ! W/0508108 - MTA FUSE BLOCK / CAVITY CIRCUIT GA COLOR TERMINAL 1 B63B 16 DK BL 1661538C1 2 B63D 16 DK BL 1661538C1 / CAVITY CIRCUIT GA COLOR TERMINAL 1 B63AR 16 DKBL 1680205C1 2 B63CB 16 DKBL 1680205C1 / CAVITY CIRCUIT GA COLOR TERMINAL 1 SW63-GD 14 WH 2034787C1 2 SW63-GA 14 WH 2034787C1 / Figure 1420 / CONNECTOR COMPOSITES !83174, !84273, !84331

Connector 83174: INPOWER DIMMER OUTPUT 2 1

CIRCUIT	GA	COLOR	TERMINAL
B63B	16	DK BL	1661538C1
B63D	16	DK BL	1661538C1

Legend: ! N/0508108 - NOT MTA FUSE BLOCK

Connector 84273: INPOWER DIMMER OUTPUT 2

CIRCUIT	GA	COLOR	TERMINAL
B63AR	16	DKBL	1680205C1
B63CB	16	DKBL	1680205C1

Connector 84331: REAR ROW EMER DOME LT

CIRCUIT	GA	COLOR	TERMINAL
SW63-GD	14	WH	2034787C1
SW63-GA	14	WH	2034787C1

Figure 1421 BATTERY FEED WITH PB10E00

Components: BUS BAR (2501); FUSE (4041); STUD (1000); V BATTERY (1201)
Wires (circuit gauge+color): A14 4RD; K14D 10RD
See also sheets: CH13_22, CH3_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / ELECTRIC VEHICLE (EV) SYSTEMS (CHAPTER 27) / 27.1. BATTERY FEED WITH PB10E00, P. 1 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 / BATTERY FEED W/PB10E00 / MJV0488 10FEB22 12V MASTER DISCONNECT B SWITCH WAS MASTER SWITCH. / (4000) (4000) MEGA-FUSE MEGA-FUSE 175A 175A (2600) / BRAKE SYSTEM FUSE (4041) CH13_22 / K14D K14D 10RD 10RD / BATTERY FEED STUD (1000) CH3_01 / + 12V BATTERY (1201) / (1200) 12V MASTER DISCONNECT SWITCH / A14 4RD / 14K 4/0 RD / UNDER-HOOD BUS BAR (2501) / 14L 2RD / 14A 4/0 RD / Figure 1421 / BATTERY FEED WITH PB10E00

27.2. BATTERY FEED PDM1 WITH PB10E00, P. 2
Figure 1422 BATTERY FEED PDM1 WITH PB10E00

Components: AIR DRYER RELAY (6015); BUS BAR (1401); CABIN HEAT ENABLE RELAY (4215); CABIN HEAT PUMP (6071); F1C (6082); VCU/CHASSIS (6091/6091)
Wires (circuit gauge+color): K14W 16RD; K14X 16RD; K14Z 12RD; K74B 12RD
See also sheets: CH27_17, CH27_32, CH27_42, CH27_47, CH27_49
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.2. BATTERY FEED PDM1 WITH PB10E00, P. 2 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 BATTERY FEED PDM1 W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / F2E 30A / CABIN HEAT PUMP (6071) CH27_49 / (6082) 1 K74B 12RD / (6081) 7 K14X 16RD VCU/CHASSIS (6091/6091) F K14W 16RD / F3D 10A / CABIN HEAT ENABLE RELAY (4215) CH27_47 / BMS/S-BOX CH27_17 / F3E 10A / POWER FEED #1 (2700) / F2C 25A / AIR DRYER RELAY (6015) CH27_42 / (6082) 3 K14Z 12RD / 1/0 RD / F1C 150A / RADIATOR FAN CH27_32 / AUX STUD #3 (2701) POWER FEED #2 (1400) / 14M 6RD / 14M 6RD / 14H 2/0 RD / UNDER-HOOD BUS BAR (1401) / Figure 1422 / BATTERY FEED PDM1 WITH PB10E00

27.3. BATTERY FEED PDM2 WITH PB10E00, P. 3
Figure 1423 BATTERY FEED PDM2 WITH PB10E00

Components: BTMS (6059A); COOLANT PUMP (6073); F1C (6084); GLOBAL A RELAY (4220); GLOBAL B RELAY (4221); HVAC RELAY (4222); HVDU (6050); SCU (6030); VCU (6025)
Wires (circuit gauge+color): K14A 4RD; K14AA 12RD; K14AE 18RD; K14AF 16RD; K14B 16RD; K14M 18RD; K14P 16RD; K14Q 16RD; K14R 16RD; K14S 16RD; K14T 10RD; K14U 12RD; K74C 12LTGN
See also sheets: CH27_14, CH27_19, CH27_21, CH27_28, CH27_29, CH27_30, CH27_31, CH27_33, CH27_37, CH27_38, CH27_64
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.3. BATTERY FEED PDM2 WITH PB10E00, P. 3 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 BATTERY FEED PDM2 W/PB10E00 / MJV0488 10FEB22 POWER ELECTRONICS B 96429Y COOLANT PUMP WAS MEDIUM TEMP PUMP. / F2E 30A / VCU (6025) CH27_28 / (6084) 1 K14T 10RD / (6083) 7 K14S 16RD / F3D 20A / HVDU (6050) CH27_14 / SCU (6030) CH27_29 K14AG HVAC RELAY (4222) CH27_64 16 RD K14AE GLOBAL A RELAY 18RD (4220) CH27_30 / F3E 10A / K14R 16RD / POWER FEED #1 (2700) / F2D 25A / OCI (6091) CH27_21 / (6084) 2 K14U 12RD / K14A 4RD / F1C 125A / BTMS (6059A) CH27_33 / AUX STUD #3 (2701) POWER FEED #2 / 14M 6RD / 14M 6RD / 2/0 RD / UNDER-HOOD BUS BAR / F3F 20A / K14Q 16RD / DISC SW CH27_19 / K14M 18RD / K14B 16RD / K14AF 16RD / GLOBAL B RELAY (4221) CH27_31 / F2C 30A / POWER ELECTRONICS COOLANT PUMP (6073) CH27_37 / K74C 12LTGN / K14P 16RD / K14AA 12RD / TPIM (6094) CH27_38 / Figure 1423 / BATTERY FEED PDM2 WITH PB10E00

27.4. IGNITION FEED WITH PB10E00, P. 4
Figure 1424 IGNITION FEED WITH PB10E00

Components: CHASSIS/OCI JUMPER (6055); FUSE A3-K (1016); OCI MODULE (7875); PLATFORM/VCU (1701); VCU (6025); VCU IGN DIODE (6036); VCU/CHASSIS (6091)
See also sheets: CH3_005
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.4. IGNITION FEED WITH PB10E00, P. 4 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 / IGNITION FEED W/PB10E00 / MJV0488 22SEP21 INITIAL PRODCUTION RELEASE. / VCU IGN DIODE (6036) / VCU (6025) / OCI MODULE (7875) / K13HH 18 PK / PLATFORM/VCU (1701) 21 / FUSE A3-K (1016) CH3_005 / K97H 18 PK / CHASSIS/OCI JUMPER (6055) 4 / P13 18 PK / VCU/CHASSIS (6091) K / N13E 18 PK / K13D 18 PK / K13H 22 PK / A97UA 18 VT / *K13D 18 PK / * W/FRONT CHARGE PORT / Figure 1424 / IGNITION FEED WITH PB10E00

27.5. J1939 POWERTRAIN WITH 500K AND PB10E00, P. 5
Figure 1425 J1939 POWERTRAIN WITH 500K AND PB10E00

Components: ELEC PANEL/ PLATFORM (1703); EV SHIFTER GSM (1855); K BAUD (1651); PLATFORM/FWD CHASSIS (1700); PLATFORM/VCU (1701); RESISTOR (1657); RESISTOR (6028); VCU (6025)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.5. J1939 POWERTRAIN WITH 500K AND PB10E00, P. 5 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 J1939 POWERTRAIN W/500K W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / A5MA(-) 18 GN A5M(A+) 18 YL PLATFORM/VCU (1701) 45 A5R(+) 18 YL A5R(-) 18 GN / DIAGNOSTIC J1939 - CONNECTOR D D 500K BAUD (1651) C C J1939 + / K5B(+) 18 YL K5B(-) 18 GN / J6-18 WAY BODY CONTROLLER (1606) / A5H(+) 18 YL A5H(-) 18 GN A5J(-) A5J(+) GN YL 18 18 / PLATFORM/FWD CHASSIS (1700) 30 / M5A(+) 18YL M5A(-) 18GN / J1939 TERMINATING RESISTOR (1657) A / OHMS 120 / VCU (6025) / K5GA(-) 22 GN K5GA(+) 22 YL / J1939 TERMINATING RESISTOR (6028) B / OHMS 120 / K5AQ(-) 18 GN K5AQ(+) 18 YL / EV SHIFTER GSM (1855) / A5D(+) 18 YL A5D(-) 18 GN / A5CA(+) 20 YL A5A(-) 20 GN / A5BA(+) 29 20 YL / A5A(+) 12 20 YL / A5BA(-) 28 20 GN / A5CA(-) 38 20 GN / INSTRUMENT CLUSTER (1507) / A5S(+) 18 YL A5S(-) 18 GN A5E(-) 18 GN A5E(+) 18YL / A5K(+) 18 YL A5K(-) 18 GN / A5V(+) YL A5V(-) 18 GN 18 / A5G(+) YL 18 A5G(-) GN 18 / Figure 1425 / J1939 POWERTRAIN WITH 500K AND PB10E00

27.6. J1939 CAN_HVCTRLS NETWORK WITH PB10E00, P. 6
Figure 1426 J1939 CAN_HVCTRLS NETWORK WITH PB10E00

Components: CABIN HEAT PUMP (6072); CHASSIS JUMPER/VCU (6090); DC/DC 1 (6085); DC/DC 2 (6084); FAN CONTROL MODULE (6057); IN-1 INVERTER (6035); PLATFORM/VCU (1701); RESISTOR (1653A); RESISTOR (6086); TPIM (6094); VCU (6025)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.6. J1939 CAN_HVCTRLS NETWORK WITH PB10E00, P. 6 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS PART AE08093713 NO. RELEASE NO. 96275E 07JUL21 / CHAPTER 27 J1939 CAN_HVCTRLS NETWORK W/PB10E00 / MJV0488 10FEB22 UPDATED DESCRIPTION FOR R/D'S 14519 AND 6074. / 2 K5AS(-) 18 K5AS(+) GN 18 YL / FAN CONTROL MODULE (6057) / EV DIAGNOSTIC CONNECTOR (1652) / 2-IN-1 INVERTER (6035) / POWER ELECTRONICS COOLANT PUMP (6074) / CABIN HEAT PUMP (6072) / J1939 TERMINATING RESISTOR (6086) A / OHMS OHMS 120 120 / N5J(-) 18 GN TPIM N5L(+) YL (6094) 18 N5L(-) GN 18 / N5P(-) 18 GN DC/DC 1 N5E(+) YL (6085) 18 N5E(-) GN 18 / DC/DC 2 (6084) / PLATFORM/VCU (1701) 39 K5BA(+) 18 YL 40 K5BA(-) 18 GN / A5TA(-) 18 GN EV HVAC CHASSIS JUMPER/VCU (6090) CONTROLS RESISTOR B (1653A) N5A(-) 18 GN A A N5A(+) 18 YL / K5K(+) 18 YL K5K(-) 18 GN / K5U(-) 18 GN K5U(+) 18 YL / K5E(-) 18 GN K5E(+) 18 YL K5AV(-) 18 GN K5AV(+) 18 YL / K5AB(-) GN 18 / K5AB(+) YL 18 / A5TB(+) 18 YL A5TB(-) 18 GN / K5Y(+) YL K5Y(-) GN 18 18 / K5L(-) 18 GN K5L(+) 18 YL / K5P(-) 18 GN K5P(+) 18 YL / N5R(+) 18 YL / N5R(-) 18 GN / N5P(+) 18 YL / N5J(+) 18 YL / N5D(-) GN 18 N5D(+) YL 18 / K5EB(-) 22 K5EA(+) 22 GN YL / VCU (6025) / A5T(+) 18 YL A5T(-) 18 GN / OHMS OHMS 120 120 / A5TA(+) 18 YL / *B5AF(-) GN 18 / *B5AF(+) YL 18 / EV HVAC CONTROLLER 3 (14517) 2 / *A5T(+) YL 18 *A5T(-) GN 18 / *B5AH(-) GN *B5AH(+) *B5AG(-) *B5AG(+) 18 YL GN YL 18 18 18 4 2 3 1 *A5TAA(+) YL *A5TAA(-) 18 GN 18 / *W/ 48CXZ BODY A/C / W/BODY A/C ONLY / CAN_HVCTRLS (14519) / K5W(+) 18 YL K5W(-) 18 GN / Figure 1426 / J1939 CAN_HVCTRLS NETWORK WITH PB10E00

27.7. J1939 CAN_HVPWR NETWORK WITH PB10E00, P. 7
Figure 1427 J1939 CAN_HVPWR NETWORK WITH PB10E00

Components: BMS S-BOX (6081); BTMS (6058); CHARGE CONTROL (6055); CHASSIS JUMPER/VCU (6090); CHASSISJUMPER/OCI (6055); CONNECTOR (1652); HVDM (6092); OBC1 (6041); OBC2 (6042); OCI (7875); PLATFORM/VCU (1701); RESISTOR (6027); RESISTOR (8000); SCU (6030); VCU (6025)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.7. J1939 CAN_HVPWR NETWORK WITH PB10E00, P. 7 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS PART AE08093713 NO. RELEASE NO. 96275E 07JUL21 / CHAPTER 27 J1939 CAN_HVPWR NETWORK W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / OHMS OHMS 120 120 / J1939 TERMINATING RESISTOR (6027) A / 88 K5DA(+) 22 YL K5DB(-) 22 GN / VCU (6025) / SCU (6030) / K5M(+) 18 YL K5M(-) 18 GN EV DIAGNOSTIC CONNECTOR (1652) / OBC2 (6042) / OBC1 (6041) / J1939 TERMINATING RESISTOR (8000) A / 120 120 OHMS OHMS / OCI (7875) / N5M(-) 18 GN #N5S(+) YL 18 CHASSISJUMPER/OCI #N5S(-) GN (6055) 1 2E P5(+) 18 18 YL P5(-) 18 GN / N5T(-) 18 GN N5F(+) BMS S-BOX YL (6081) 18 N5F(-) GN 18 / HVDM (6092) / K5AU(+) 18 YL K5AU(-) 18 GN / K5JA(-) 22 GN K5JB(+) 22 YL OCI (7875) / K5AA(-) 18 GN K5AA(+) 18 YL K5AC(-) GN OCI CHARGE CONTROL (6055) 18 2 *K5S(-) 18 GN *K5S(+) 18 YL / K5Z(+) YL 18 K5Z(-) GN 18 K5J(-) 20 GN K5J(+) 20 YL / K5AC(+) YL 18 / K5N(-) 18 GN K5N(+) 18 YL / K5C(+) 18 YL K5C(-) 18 GN / K5AD(+) 18 YL K5AD(-) 18 GN / K5AY(+) YL K5AY(-) 18 GN PLATFORM/VCU 18 (1701) K5AX(-) 38 18 GN K5AX(+) 18 YL / CHASSIS JUMPER/VCU (6090) S N5C(-) K5R(-) 18 GN 18 GN N5C(+) R K5R(+) 18 YL 18 YL / N5N(+) 18 YL / N5N(-) 18 GN / N5T(+) 18 YL / N5M(+) 18 YL / N5H(-) GN 18 N5H(+) YL 18 / A5PA(-) 18 GN A5PA(+) 18 YL / BTMS (6058) / K5D(+) 18 YL K5D(-) 18 GN / *W/FRONT CHARGE PORT ONLY #W/REAR CHARGE PORT ONLY / P5(-) 18 GN P5(+) 18 YL / Figure 1427 / J1939 CAN_HVPWR NETWORK WITH PB10E00

27.8. J1939 CAN_BMS-C NETWORK WITH PB10E00, P. 8
Figure 1428 J1939 CAN_BMS-C NETWORK WITH PB10E00

Components: BMS S-BOX (6081); SCU (6030); VCU/CHASSIS JUMPER (6090)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.8. J1939 CAN_BMS-C NETWORK WITH PB10E00, P. 8 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS PART AE08093713 NO. RELEASE NO. 96275E 07JUL21 / CHAPTER 27 / J1939 CAN_BMS-C NETWORK W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / SCU (6030) / K5H(+) 20 YL K5H(-) 20 GN / VCU/CHASSIS JUMPER (6090) E / N5B(+) 18 YL N5B(-) 18 GN / BMS S-BOX (6081) / K5HA(+) 22 YL K5HA(-) 22 GN / Figure 1428 / J1939 CAN_BMS-C NETWORK WITH PB10E00

27.9. J1939 CAN_BMS-C NETWORK WITH PB10E00 (6030), (6090), P. 8A
Figure 1473 J1939 CAN_BMS-C NETWORK WITH PB10E00 (6030), (6090)

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.9. J1939 CAN_BMS-C NETWORK WITH PB10E00 (6030), (6090), P. 8A / Figure 1473 / J1939 CAN_BMS-C NETWORK WITH PB10E00 (6030), (6090)

27.9. J1939 CAN_0 VCU DIAGNOSTIC NETWORK WITH PB10E00, P. 9
Figure 1429 J1939 CAN_0 VCU DIAGNOSTIC NETWORK WITH PB10E00

Components: CONNECTOR (1652); RESISTOR (1653); VCU (6025); VCU/PLATFORM (1701)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.9. J1939 CAN_0 VCU DIAGNOSTIC NETWORK WITH PB10E00, P. 9 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS PART AE08093713 NO. RELEASE NO. 96275E 07JUL21 / CHAPTER 27 / J1939 CAN_0 VCU DIAGNOSTIC NETWORK W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / A A / VCU (6025) / K5X(+) 18 YL K5X(-) 18 GN / VCU/PLATFORM (1701) 30 / A5VA(+) 18 YL A5VA(-) 18 GN / J1939 TERMINATING RESISTOR (1653) A / OHMS 120 / A5VB(-) 18 GN A5VB(+) 18 YL / A5VC(+) 18 YL A5VC(-) 18 GN / EV DIAGNOSTIC CONNECTOR (1652) / K5XA(+) 22 YL K5XB(-) 22 GN / Figure 1429 / J1939 CAN_0 VCU DIAGNOSTIC NETWORK WITH PB10E00

27.10. CLEAN GROUND WITH PB10E00, P. 10
Figure 1430 CLEAN GROUND WITH PB10E00

Components: BTMS (6058); CLEAN GROUND (9260); CONTROLLER (14517); FAN CONTROL MODULE (6057); OCI INLINE (6055); SCU (6030); VCU (6025); VCU/CHASSIS JUMPER (6091); VCU/PLATFORM (1701)
See also sheets: CH27_36, CH27_37, CH27_40, CH27_41, CH27_65
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.10. CLEAN GROUND WITH PB10E00, P. 10 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 / CLEAN GROUND W/PB10E00 / MJV0488 10FEB22 GROUND WAS 9260 DESCRIPTION UPDATED. / K10C 10 WH K10D 10 WH / VCU/CHASSIS JUMPER (6091) J / CLEAN GROUND (9260) / K10K 20 WH K10L 16 WH K10M 20 WH K10N 16 WH / K10F 16 WH K10G 16 WH K10H 16 WH K10S 20 WH K10J 20 WH K10P 20 WH / VCU (6025) CH27_36 / SCU (6030) CH27_37 / K10A 18 WH / #K10Q 16 WH VCU/PLATFORM (1701) 53 / K10E 18 WH / K10R 18 WH / #N10A 16 WH / OCI INLINE (6055) 3 / FAN CONTROL MODULE (6057) CH27_40 / BTMS (6058) CH27_41 / A10E 18 WH / EV HVAC CONTROLLER (14517) CH27_65 / *K10Q 16 WH / OCI INLINE (6055) 3 / *W/FRONT CHARGE PORT #W/REAR CHARGE PORT / Figure 1430 / CLEAN GROUND WITH PB10E00

27.11. EV DIAGNOSTIC CONNECTOR WITH PB10E00, P. 11
Figure 1431 EV DIAGNOSTIC CONNECTOR WITH PB10E00

Components: CONNECTOR (1652); FUSE A3-P (1016); FUSE A6-K (1014); GROUND (4037A)
Wires (circuit gauge+color): A11-GZ 8WH; A98-GA 18WH
See also sheets: CH27_06, CH27_07, CH27_09, CH3_02, CH3_06, CH3_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.11. EV DIAGNOSTIC CONNECTOR WITH PB10E00, P. 11 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 / EV DIAGNOSTIC CONNECTOR W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / A A A / A98-GA 18WH A98-GB 18WH / EV DIAGNOSTIC CONNECTOR (1652) / A5PA(+) 18 YL A5PA(-) 18 GN A5TB(+) 18 YL A5TB(-) 18 GN / A98-G 16WH / A11-GZ 8WH / CAN_HVPWR J1939 CH27_07 / GROUND (4037A) CH3_32 / CAN_HVCTRL J1939 CH27_06 / A5VB(+) 18 YL A5VB(-) 18 GN / CANO_VCU DIAGNOSTIC J1939 CH27_09 / A28AB 18 TN A98C 18 VT / FUSE A3-P (1016) CH3_06 FUSE A6-K (1014) CH3_02 / A28A 18TN A98A 18 VT / Figure 1431 / EV DIAGNOSTIC CONNECTOR WITH PB10E00

27.12. BODY GROUND WITH PB10E00, P. 12
Figure 1432 BODY GROUND WITH PB10E00

Components: CITY HORN (8310E); GROUND (2801); GROUND (4037A); HOOD (8003E); STUD (2800)
Wires (circuit gauge+color): K11 4WH; M11-GC 14WH; M59H-G 2WH
See also sheets: CH13_05, CH27_13, CH27_33, CH3_32, CH3_51, CH7_51, CH7_59
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.12. BODY GROUND WITH PB10E00, P. 12 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 / BODY GROUND W/PB10E00 / MJV0488 10FEB22 CITY HORN WAS EV HORN. / A11-GZ 8WH GROUND (4037A) / CHASSIS UPPER DASH LOWER DASH /2GA/2GG / PLATFORM HARNESS CH3_32 / (2G/3G) BODY GROUND STUD (2800) / CITY HORN (8310E) CH13_?? / AIR SOLENOID 4_PACK (9736) CH13_05 / GROUND SPLICE (6740E) CH3_51 / M11-GA 10 WH / M11-GC 12 WH / M59H-G 14WH / K11 2WH K11A 4WH / M85-GA 16 WH / VCU HARNESS GROUND FEED CH27_13 BTMS GROUND STUD CH27_33 / FRAME GROUND (2801)/(1901) / BK 11-GG 1/0 / 12V BATTERY / M11-GE 4 WH / M11-GD 12 WH / RADIATOR GROUND (9737E) CH3_51 / M11-GB 12 WH / HOOD (8003E) CH7_59 CH7_51 / 11-GD 4/0 BK / Figure 1432 / BODY GROUND WITH PB10E00

27.13. BODY GROUND - EV SYSTEMS WITH PB10E00, P. 13
Figure 1433 BODY GROUND - EV SYSTEMS WITH PB10E00

Components: COOLANT PUMP (6073); HVDU (6050); IN-1 INVERTER (6035); MODULE (6057); OBC1 (6041); OBC2 (6042); PULL-DOWN RESISTOR (6023A); PULL-DOWN RESISTOR (6023B); PULL-DOWN RESISTOR (6037); PULL-DOWN RESISTOR (6038); PUMP (6071); RELAY (4015)
Wires (circuit gauge+color): K11AA 18WH; K11AB 18WH; K11AZ 16WH; K11B 18WH; K11C 16WH; K11D 18WH; K11E 18WH; K11F 18WH; K11G 18WH; K11J 18WH; K11K 18WH; K11L 18WH; K11M 18WH; K11P 14WH; K11Q 12WH; K11R 8WH; K11S 18BK; K11T 18WH; K11V 8WH; K11W 12WH; K11Y 16WH; K11Z 16WH; K39A-G 18WH; N11M 14WH
See also sheets: CH27_14, CH27_15, CH27_32, CH27_37, CH27_41, CH27_42, CH27_49, CH27_64
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.13. BODY GROUND - EV SYSTEMS WITH PB10E00, P. 13 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 BODY GROUND - EV SYSTEMS W/PB10E00 / MJV0488 10FEB22 UPDATED DESCRIPTION B 96429Y FOR R/D'S 6023A,6023B AND 6073. / 2-IN-1 INVERTER (6035) CH27_41 / AIR DRYER RELAY (4015) CH27_42 / CABIN HT PUMP PULL-DOWN RESISTOR (6023A) CH27_49 CABIN HT PUMP PULL-DOWN RESISTOR (6023B) CH27_49 / VCU/CHASSIS JUMPER (6091) R N11M 14WH / K11 2WH / CAB GROUND STUD (2G) / POSITIVE SENSE PULL-DOWN RESISTOR (6037) CH27_14 NEGATIVE SENSE PULL-DOWN RESISTOR (6038) CH27_14 HVDU (6050) CH27_14 / CHASSIS JUMPER HARNESS CH27_VARIOUS / K11U 8WH / K11AA 18WH / K11AB 18WH / K74A-G 12WH / CABIN HT PUMP (6071) CH27_49 / K74B-G 12WH / POWER ELECTRONICS COOLANT PUMP (6073) CH27_37 K11T 18WH / K11R 8WH / K11Q 12WH / K11P 12WH / N11A 14WH / K11X 12WH / K11W 12WH / K11V 8WH / K11Y 16WH / K39A-G 18WH / K11AZ 16WH / K11S 18BK / K11Z 16WH / K11B 18WH / K11C 18WH / K11D 16WH / K11J 18WH K11K 18WH K11L 18WH K11M 18WH / K11E 18WH K11F 18WH K11G 18WH K11H 18WH / OBC2 (6042) CH27_15 / FAN CONTROL MODULE (6057) CH27_32 / OBC1 (6041) CH27_15 / HVAC RELAY(4222) CH27_64 / K11N 16 WH / Figure 1433 / BODY GROUND - EV SYSTEMS WITH PB10E00

27.14. HVDU WITH PB10E00, P. 14
Figure 1434 HVDU WITH PB10E00

Components: FUSE F3D (6083); HVDU (6050); RESISTOR (6037); SCU (6030)
Wires (circuit gauge+color): K11B 18WH; K11C 18WH; K11D 16WH; K11Y 16WH; K14M 18RD; K97R 16PK
See also sheets: CH27_03, CH27_13
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.14. HVDU WITH PB10E00, P. 14 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 / HVDU W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / A A / SCU (6030) / NEGATIVE SENSE PULL-DOWN RESISTOR OHMS 715 (6038) / POSITIVE SENSE PULL-DOWN RESISTOR (6037) / K11Y 16WH / FUSE F3D (6083) CH27_03 / CAB GROUND CONNECTION CH27_13 / OHMS 715 / K11D 16WH / HVDU (6050) / K14M 18RD / K97F 20VT / K97P 18VT / K97N 18VT / K97T 20VT / K97Q 18VT / K97M 18VT / K97R 16PK / K11C 18WH / K11B 18WH / Figure 1434 / HVDU WITH PB10E00

27.15. ON-BOARD CHARGERS WITH PB10E00, P. 15
Figure 1435 ON-BOARD CHARGERS WITH PB10E00

Components: B RELAY (4221); OBC1 (6041); OBC2 (6042)
Wires (circuit gauge+color): K11AZ 16WH; K11E 18WH; K11F 18WH; K11G 18WH; K11H 18WH; K11J 18WH; K11K 18WH; K11M 18WH; K11X 12WH; K11Z 16WH; K13N 18PK; K13P 18PK; K13Q 18PK; K13S 18PK; K13Y 16PK; K98C 18BK; K98D 18BK
See also sheets: CH27_13, CH27_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.15. ON-BOARD CHARGERS WITH PB10E00, P. 15 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 ON BOARD CHARGERS W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / A A A / OBC2 (6042) / K11M 18WH K11J 18WH K11K 18WH K11L 18W K13N 18PK K13S 18PK / K11AZ 16WH / K98D 18BK / CAB GROUND CONNECTION CH27_13 / OBC1 (6041) / GLOBAL POWER B RELAY (4221) CH27_31 / K13Y 16PK / K13P 18PK K13Q 18PK K11E 18WH K11F 18WH K11G 18WH K11H 18WH / K11Z 16WH / K98C 18BK / K11X 12WH / Figure 1435 / ON-BOARD CHARGERS WITH PB10E00

27.16. HIGH VOLTAGE DISTRIBUTION MODULE (HVDM) WITH PB10E00, P. 16
Figure 1436 HIGH VOLTAGE DISTRIBUTION MODULE (HVDM) WITH PB10E00

Components: A RELAY (4220); CHASSIS JUMPER/VCU (6090); CHASSIS JUMPER/VCU (6091); HVDM (6092); RESISTOR A (6096A); RESISTOR B (6096B); SCU (6030); VCU (6025); VCU/CHASSIS JUMPER (6091)
Wires (circuit gauge+color): K11P 12WH; K11Q 12WH; K13K 18PK; K97K 16PK; N11A 14WH; N11F 18WH; N11J 18WH; N11M 14WH; N11N 18WH; N13A 18PK; N13F 18PK
See also sheets: CH27_13, CH27_30
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.16. HIGH VOLTAGE DISTRIBUTION MODULE (HVDM) WITH PB10E00, P. 16 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS PART AE08093713 NO. RELEASE NO. 96275E 07JUL21 / CHAPTER 27 / HVDM W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / A A A / N11N 18WH / GLOBAL POWER A RELAY (4220)CH27_30 / K13K 18PK / R1 ENABLE RESISTOR A (6096A) / SCU (6030) / N11J 18WH / HVDM (6092) / OHMS 715 / N97E 18VT / N97A 18VT / N97M 18VT / K97G 22VT / OHMS 715 / N13F 18PK / CHASSIS JUMPER/VCU (6091) H / K11P 12WH / CAB GROUND CONNECTION CH27_13 / N97N 18VT / K97W 18VT / N13A 18PK / K97K 16PK / N97D 18VT / N11F 18WH / N97G 18VT / K97GG 20VT / K97J 16VT / N11M 14WH / CHASSIS JUMPER/VCU (6090) M / VCU (6025) / VCU/CHASSIS JUMPER (6091) / R1 ENABLE RESISTOR B (6096B) / K11Q 12WH / N11A 14WH / Figure 1436 / HIGH VOLTAGE DISTRIBUTION MODULE (HVDM) WITH PB10E00

27.18. HIGH VOLTAGE DISTRIBUTION MODULE (HVDM) WITH PB10E00 (4220), (6025),
Figure 1482 HIGH VOLTAGE DISTRIBUTION MODULE (HVDM) WITH PB10E00 (4220), (6025), (6081), (6090),

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.18. HIGH VOLTAGE DISTRIBUTION MODULE (HVDM) WITH PB10E00 (4220), (6025), (6081), (6090), (6091), (6092), (6096A), (6096B), P. 16A / Figure 1482 HIGH VOLTAGE DISTRIBUTION MODULE (HVDM) WITH PB10E00 (4220), (6025), (6081), (6090), (6091), (6092), (6096A), (6096B)

27.17. BATTERY MANAGEMENT SYSTEM (BMS) S-BOX WITH PB10E00, P. 17
Figure 1437 BATTERY MANAGEMENT SYSTEM (BMS) S-BOX WITH PB10E00

Components: FUSE F3E (6081); RESISTOR (6098); S-BOX (6081); SCU (6030); VCU (6025)
See also sheets: CH27_02, CH27_13
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.17. BATTERY MANAGEMENT SYSTEM (BMS) S-BOX WITH PB10E00, P. 17 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS PART AE08093713 NO. RELEASE NO. 96275E 07JUL21 / CHAPTER 27 / BMS S-BOX W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / A A A / 10 11 / VCU (6025) / N14D 18 RD N14E 18 RD / BMS S-BOX (6081) / FUSE F3E (6081) CH27_02 / N11D 18 BK N11E 18 BK / CAB GROUND CONNECTION CH27_13 / R3 ENABLE RESISTOR (6098) A / OHMS 715 B / N11K 18 WH / N97K 18 VT / K97U 20 VT / K97L 20 PK / SCU (6030) / N11M 14 WH / K11P 12 WH / CAB GROUND CONNECTION CH27_13 / VCU/CHASSIS JUMPER (6091) R / CHASSIS JUMPER/VCU (6091) F / N14B 16 RD / K14W 16 RD / N11A 14 WH / K11Q 12 WH / N97H 18 PK / K97S 18 VT / CHASSIS JUMPER/VCU (6090) J / N97B 18 VT / GND GND / Figure 1437 / BATTERY MANAGEMENT SYSTEM (BMS) S-BOX WITH PB10E00

27.18. BMS HV BATTERY VENDOR SUPPLIED CABLES WITH PB10E00, P. 17A
Figure 1438 BMS HV BATTERY VENDOR SUPPLIED CABLES WITH PB10E00

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.18. BMS HV BATTERY VENDOR SUPPLIED CABLES WITH PB10E00, P. 17A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 BMS HV BATTERY VENDOR SUPPLIED CABLES W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / A A A / BMS S-BOX TP_OUT / 20VT LV INPUT 5 / LV OUTPUT 1 / 20VT 20PK 20VT 20PK / 20VT 20PK 20VT 20PK / W/1 HV BATTERY STACK ASSY / W/3 HV BATTERY STACK ASSY / 20VT 20PK 20VT 20PK / Figure 1438 / BMS HV BATTERY VENDOR SUPPLIED CABLES WITH PB10E00

27.19. DC / DC CONVERTERS WITH PB10E00, P. 18
Figure 1439 DC / DC CONVERTERS WITH PB10E00

Components: B RELAY (4221); CHASSIS JUMPER/VCU (6090); CHASSIS JUMPER/VCU (6091); DC/DC1 (6085); DC/DC2 (6084); V BATTERY (6100)
Wires (circuit gauge+color): K11Q 12WH; K13J 18PK; N11A 14WH; N11B 18WH; N11C 18WH; N13B 18PK; N13C 18PK; N13D 18PK; N27A 18TN; N27A-G 18WH; N27B 18TN; N27B-G 18WH; N27C 18TN; N27C-G 18WH
See also sheets: CH27_13, CH27_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.19. DC / DC CONVERTERS WITH PB10E00, P. 18 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 DC/DC CONVERTERS W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / A A A / 12V BATTERY (6100) (6101) / CHASSIS JUMPER/VCU (6091) S / CAB GROUND CONNECTION CH27_13 / POS SENSE 7 NEG SENSE 8 / DC/DC1 (6085) / ADDRESS 3 POS SENSE 7 NEG SENSE 8 / DC/DC2 (6084) / GLOBAL POWER B RELAY (4221) CH27_31 / K13J 18PK / N13D 18PK / CHASSIS JUMPER/VCU (6090) L / N27B 18TN / N11C 18WH / N27B-G 18WH N27C-G 18WH / N13C 18PK N11A 14WH / N27A-G 18WH / N11B 18WH / N27A 18TN / N13B 18PK / N27C 18TN / K11Q 12WH / 12V MASTER DISCONNECT / BATTERY FRAME GROUND / 2/0 RD / 2/0 BK / RD 2/0 / 2/0 BK / Figure 1439 / DC / DC CONVERTERS WITH PB10E00

27.20. 12V DISCONNECT OF HV SYSTEM WITH PB10E00, P. 19
Figure 1440 12V DISCONNECT OF HV SYSTEM WITH PB10E00

Components: B14HVA (10290A); FUSE F3D (6083); HVDC BY-PASS (14518); PLATFORM/VCU (1701)
See also sheets: CH27_03
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.20. 12V DISCONNECT OF HV SYSTEM WITH PB10E00, P. 19 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 12V DISCONNECT OF HV SYSTEM W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / A A A / BATT 1 / VCU/CHASSIS JUMPER (6091) G / K14S 16 RD / K14B 16 RD / HVDC BY-PASS (14518) 1 A14HD 18 RD A14HV 18 RD / B14HVA 18 RD / B14HD 18 RD / FUSE F3D (6083) CH27_03 / PLATFORM/VCU (1701) 42 / 12V DISCONNECT SW FOR HV SYSTEM / K14C 16 RD / HVDM (6092) / N14C 16 RD / Figure 1440 / 12V DISCONNECT OF HV SYSTEM WITH PB10E00

27.21. VCU HVIL WITH PB10E00, P. 20
Figure 1441 VCU HVIL WITH PB10E00

Components: FRONT (1100MA); HVDM (6092); HVDU (6050); INLINE (1100M); MSD1 (6093); MSD2 (6094); REAR (1100MB); TPIM (6094); VCU (6025)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.21. VCU HVIL WITH PB10E00, P. 20 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 / VCU HVIL W/PB10E00 / MJV0488 10FEB22 UPDATED MSD RELAY NAME. / DC SENSE 36 / QX SENSE 57 / HVIL RETURN 52 / TPIM SENSE 60 HVIL SOURCE 70 / K19B 22 GY / K19D 22 GY / VCU/CHASSIS JUMPER (6090) C K193E 18 GY N K19C 22 GY K19E 22 GY TPIM (6094) / K19BB 18 GY / HVDM (6092) / N19B 18 GY / N6D 18 GY / N19A 18 GY N6C / K193C 18 GY / K19DD 18 GY K6D 18 GY / VCU (6025) / HVDU (6050) / N6A 18 GY / 18 K193 GY MANUAL SERVICE DISCONNECT (MSD1) MSD1 (6093) LID SW 1 2 / 1 2 / MSD INLINE (1100M)/(1100F) / SHUNT CAP / 18 K193A GY MANUAL SERVICE DISCONNECT (MSD2) MSD2 (6094) LID SW 1 2 / * W/08TLD HV BATTERY STACK ASSY ONLY / MSD MANUAL SERVICE FRONT DISCONNECT (MSD3) (1100MA) LID SW 1 *N193BCA *N193BD 10 GY 16 GY 2 *N193BE 16 GY / MSD MANUAL SERVICE DISCONNECT (MSD4) REAR (1100MB) LID SW 1 *N193BF 16 GY 2 *N193CD 16 GY / VCU/CHASSIS JUMPER (6091) M K193B N193B 18 GY 16 GY K193C N193C 16 GY 18 GY / N193BA 10 GY N193CA 10 GY / N193BB GY 16 / N193CB GY 16 / *N193BEA GY 10 / *N193CC GY 16 / *N193BC GY 16 / *N193CDA GY 10 / Figure 1441 / VCU HVIL WITH PB10E00

27.22. ONBOARDING CHARGING INTERFACE MODULE (OCI) WITH PB10E00, P. 21
Figure 1442 ONBOARDING CHARGING INTERFACE MODULE (OCI) WITH PB10E00

Components: DIODE (6036); FUSE F2D (6084); IGNITION DIODE (6036); MODULE (7875)
See also sheets: CH27_03, CH27_04, CH27_07, CH27_10, CH27_13
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.22. ONBOARDING CHARGING INTERFACE MODULE (OCI) WITH PB10E00, P. 21 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS PART AE08093713 NO. RELEASE NO. 96275E 07JUL21 / CHAPTER 27 ONBOARD CHARGING INTERFACE MODULE (OCI) W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / A A A / P5(+) 18 YL / SPARE CIRCUIT / CAB GROUND CONNECTION CH27_13 FUSE F2D (6084) CH27_03 / *W/REAR CHARGE PORT #W/FRONT CHARGE PORT / K14U 12 RD IGNITION DIODE (6036) CH27_04 CLEAN GROUND K10D CONNECTION 10 WH CH27_10 / OCI JUMPER/CHASSIS JUMPER INLINE (6055) #K5S(+) 18 YL 1 *N5S(+) 18 YL #K5S(-) 18 GN *N5S(-) 18 GN #K10Q 16 WH / OCI MODULE (7875) / P5(-) 18 GN / P13 18 PK / P14 18 RD / SPARE CIRUIT / N11A 14 WH *N14HA 14 RD *N13E 18 PK *N10A 16 WH / VCU/CHASSIS JUMPER (6091) S / K11Q 12 WH *K14P 16 RD *K13D 18 PK / *K10Q 16 WH / *N11Q 18 WH / CAB GROUND CONNECTION CH27_13 / #K14P 16 RD *N14H 16 RD / #K13D 18 PK / #OCI_CHSS_GND 18 WH / CAN_HVPWR NETWORK CH27_07 / CLEAN GROUND CONNECTION CH27_10 / IGNITION DIODE (6036) CH27_04 / FUSE F2D (6084) CH27_03 / Figure 1442 / ONBOARDING CHARGING INTERFACE MODULE (OCI) WITH PB10E00

27.23. CHARGE PORT INLET 12V SIGNALS WITH PB10E00, P. 22
Figure 1443 CHARGE PORT INLET 12V SIGNALS WITH PB10E00

Components: INLINE (7850); OCI MODULE (7875)
Wires (circuit gauge+color): M2 18GY; P97F 18WH; P9A 18GY; P9C 18GY; P9D 18GY; P9E 18GY; P9F 18GY; P9G 18GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.23. CHARGE PORT INLET 12V SIGNALS WITH PB10E00, P. 22 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 CHARGE PORT INLET 12V SIGNALS W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / CHARGE PORT INLET J1 J1 PE PE / CP CP / 4YL/GN 4YL/GN / 2BK CHARGE PORT INLET INLINE (7850) 12 12 P10 P10 18GY 18GY 11 11 2 2 3 3 / 18WH 18WH 16WH 16WH / 20WH 20WH / 20WH/BL 20WH/BL / 12V 12V BATTERY BATTERY FRAME FRAME GROUND GROUND / M2 L2 J2 K2 / P97F P97F 18VT 18VT / TEMP TEMP LEADS LEADS A/C+ A/C+ D/C+ D/C+ / A/C- A/C- / D/C- D/C- / 1 1 4 4 9 9 5 5 / 20VT 20VT / 20YL 20YL / 20VT/BN 20VT/BN / 20VL/BN 20VL/BN LOCK LOCK ACTUATOR ACTUATOR 3 3 1 1 / 2 2 / 4 4 / 10 10 6 6 8 8 7 7 / 20 20 BL/YL BL/YL / 20BL/GN 20BL/GN / 20BL/RD 20BL/RD / 20BN/BL 20BN/BL LED LED BUTTON BUTTON INLINE INLINE (7852) (7852) 1 1 2 2 3 3 4 4 5 5 6 6 / OCI OCI MODULE MODULE (7875) (7875) / P11 P11 16WH 16WH / P97B P97B 18VT 18VT / P97C P97C 18VT 18VT / P9D P9D 18GY 18GY / P97D P97D 18VT 18VT / P97A P97A 18VT 18VT / A2 A3 / P9B P9B 18GY 18GY P9A P9A 18GY 18GY / P97H P97H 18VT 18VT / P97E P97E 18VT 18VT / P9C P9C 18GY 18GY / LED LED RING RING PUSH PUSH BUTTON BUTTON / 3 3 4 4 5 5 6 6 7 7 8 8 / L3 B4 M3 / 18GY 18BK / C4 D4 F4 G4 H4 E4 / P9E 18GY P9F 18GY P97J 18VT P97K 18VT P97L 18VT P9G 18GY / Figure 1443 / CHARGE PORT INLET 12V SIGNALS WITH PB10E00

27.24. INSTRUMENT GAUGE CLUSTER WITH PB10E00, P. 23
Figure 1444 INSTRUMENT GAUGE CLUSTER WITH PB10E00

Components: FUSE A3-P (1016); FUSE A6-D (1014); GROUND (4037A)
Wires (circuit gauge+color): A11-GZ 8WH; A28 20TN
See also sheets: CH27_5, CH3_01, CH3_06, CH3_32
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.24. INSTRUMENT GAUGE CLUSTER WITH PB10E00, P. 23 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 INSTRUMENT GAUGE CLUSTER W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / A28-G 20WH FUSE A6-D (1014) CH3_01 A28A 18TN / EV INSTRUMENT CLUSTER (1507) / GROUND FUSE A3-P (4037A) CH3_32 (1016) CH3_06 / PT_CAN J1939 CH27_5 / A28 20TN A28AA 20TN / A5A(+) 20YL A5BA(+) 20YL A5CA(+) 20YL / A5A(-) 20GN A5BA(-) 20GN A5CA(-) 20GN / A11-GZ 8WH / A5D(+) 18YL A5D(-) 18GN / Figure 1444 / INSTRUMENT GAUGE CLUSTER WITH PB10E00

27.25. DIESEL FUEL GAUGE WITH AUX HEATER AND PB10E00, P. 24
Figure 1445 DIESEL FUEL GAUGE WITH AUX HEATER AND PB10E00

Components: BODY CNTROLLER (1602); BODY CONTROLLER (1600); CHASSIS (1700E); INTERCONNECT EV (9513E); LEVEL SENSOR (9101E)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.25. DIESEL FUEL GAUGE WITH AUX HEATER AND PB10E00, P. 24 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 DIESEL FUEL GAUGE W/AUX HEATER W/ PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / ZERO VOLT E3 (1) / J3-RED BODY CONTROLLER (1600) / A36 18 TN / A9AAP 18 GY / M36 18 TN / M9 18 GY / PLATFORM/FORWARD CHASSIS (1700E) 58 / J5-TAN BODY CNTROLLER (1602) / FUEL LEVEL SENSOR INPUT / ABS FORWARD INTERCONNECT EV (9513E)/9513FE) 14 / R36 16 BK / R9 16 WH / AUX FUEL LEVEL SENSOR (9101E) / Figure 1445 / DIESEL FUEL GAUGE WITH AUX HEATER AND PB10E00

27.26. HEAD / PARK LAMP SWITCH WITH PB10E00, P. 25
Figure 1446 HEAD / PARK LAMP SWITCH WITH PB10E00

Components: FUSE A6-E (1014); GROUND SPLICE (1003A); HEAD/ PARK LAMP SWITCH (1142); J5-TAN (1602); J7 CONNECTOR (1607); PANEL LIGHTS SPLICE (1002A); REFERENCE SPLICE (1005)
Wires (circuit gauge+color): A14HB 18RD; A62-G 18WH; A62-GB 18WH; A62FA 18DKBL; A62HA 18DKBL; A9KA 18GY; A9LA 18GY; A9PA 18GY
See also sheets: CH3_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.26. HEAD / PARK LAMP SWITCH WITH PB10E00, P. 25 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 HEAD/PARK LAMP SWITCH W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / HEAD/ PARK LAMP SWITCH (1142) / PARKLAMP B6 ENABLE / BCM J7 CONNECTOR (1607) / A50 18YL A14HB 18RD / A62HA 18DKBL A62-G 18WH / A9PA 18GY ZERO VOLT SPLICE (1005) / A9KA 18GY / A62FA 18DKBL A62-GB 18WH / BCM J5-TAN (1602) / HEADLIGHT ENABLE / FUSE A6-E (1014) CH3_01 / PANEL LIGHTS SPLICE (1002A) / GROUND SPLICE (1003A) K / A9LA 18GY / Figure 1446 / HEAD / PARK LAMP SWITCH WITH PB10E00

27.27. VCU BACKUP LIGHTS SIGNAL WITH PB10E00, P. 26
Figure 1447 VCU BACKUP LIGHTS SIGNAL WITH PB10E00

Components: ALARM (9545E); ALARM/NOISE GEN (11548); BACK-UP LIGHT (11539A); BLOCK (11507); FUSE A3-M (1016); INTER EV (9513E); LT RELAY (1010-R6); VCU (6025)
Wires (circuit gauge+color): A71 16OR; A71A 18OR; A71AA 18TN; A71D 16LTBL; A71H 16LTBL; B71AH 16LTBL; B71D 16LTBL; K71AA 18OR; M71A 16LTBL; R71A 16WH; R71AA 16LTBL; R71AB 16LTBL; R71B 16WH; Y71B 16WH
See also sheets: CH3_06, CH7_01
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.27. VCU BACKUP LIGHTS SIGNAL WITH PB10E00, P. 26 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 VCU BACKUP LIGHTS SIGNAL W/ PB10E00 / MJV0488 10FEB22 BACK-UP LIGHT WAS REAR ILLUM LT. / VCU (6025) / K71A 22PK / VCU/PLATFORM (1701) 22 A71AA 18TN / BACKUP LT RELAY (1010-R6) / K71AA 18PK / A71B A71 18OR 16OR A71A 18OR / FUSE A3-M (1016) CH3_06 / A71BB 16LTBL / A71D 16LTBL / EV BACK-UP ALARM/NOISE GEN (11548)/(9513EA) 3 / ELECT PANEL/PLATFORM (1703) A11 B71D 16LTBL / B71AH 16LTBL ABS FWD/REAR INTER EV (9513E)/(9513FE) 19 / ADDITIONAL LIGHTING FEATURES CH7_01,05,06 / ELECT PANEL/ SEALED ENGINE (11500) D7 / A71H 16LTBL / Y71A 16LTBL / Y71B 16WH / M71B 16WH BACK-UP ALARM GROUND SPLICE (9545E) BLOCK (11507) 2 / M71A 16LTBL / R71A 16LTBL R71B 16WH / R71BA 16WH R71AA 16LTBL / BACK-UP LIGHT (11539A) R71BB 2 16WH R71AB 16LTBL / Figure 1447 / VCU BACKUP LIGHTS SIGNAL WITH PB10E00

27.28. PANEL LIGHTS SWITCH WITH PB10E00, P. 27
Figure 1448 PANEL LIGHTS SWITCH WITH PB10E00

Components: FUSE A3-X (1016); GROUND SPLICE (1003A); J6-18WAY (1606); J7 CONNECTOR (1607); PANEL LIGHTS SPLICE (1002A); REFERENCE SPLICE (1005); SPLICE (1002A); SWITCH (1144)
Wires (circuit gauge+color): A62 16DKBL; A62-G 18WH; A62-GA 18WH; A62EA 18DKBL; A62HA 18DKBL; A62Z 16DKBL; A62ZA 16DKBL; A9JA 18GY; A9LA 18GY; A9MA 18GY; A9NA 18GY
See also sheets: CH8_25
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.28. PANEL LIGHTS SWITCH WITH PB10E00, P. 27 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 PANEL LIGHTS SWITCH W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / BCM J7 CONNECTOR (1607) / A62EA 18DKBL / A62Z 16DKBL / A9MA 18GY / A9LA 18GY / A62-GA 18WH / FUSE A3-X (1016) 40 36 / DIM J OUTPUT / BCM J6-18WAY (1606) / A62 16DKBL / PANEL DIMMER SWITCH (1144) 8 / A9NA 18GY / DIM UP / DIM DN / A9JA 18GY / ZERO VOLT SPLICE (1005) / GROUND SPLICE (1003A) / A62-G 18WH / PANEL LIGHTS SPLICE (1002A) / A62HA 18DKBL / PANEL LTS SPLICE (1002A) CH8_25 / A62ZA 16DKBL / Figure 1448 / PANEL LIGHTS SWITCH WITH PB10E00

27.29. VEHICLE CONTROL UNIT (VCU) WITH PB10E00, P. 28
Figure 1449 VEHICLE CONTROL UNIT (VCU) WITH PB10E00

Components: CABIN HT ENABLE RELAY (4215); CABIN HT SURGE TANK (6020); FUSE F2E (6084); GLOBAL POWER A RELAY (4220); GLOBAL POWER B RELAY (4221); GLOBAL RELAY A (4220); GLOBAL RELAY B (4221); MT COOLANT SURGE TANK (6076); VCU (6025)
Wires (circuit gauge+color): K10F 16WH; K10G 16WH; K10H 16WH; K13L 18PK; K13M 18PK; K13R 18PK; K13V 18PK; K13X 18PK; K14E 16RD; K14F 16RD; K14G 16RD; K14T 10RD
See also sheets: CH27_03, CH27_10, CH27_30, CH27_31, CH27_36, CH27_47
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.29. VEHICLE CONTROL UNIT (VCU) WITH PB10E00, P. 28 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS PART AE08093713 NO. RELEASE NO. 96275E 07JUL21 / CHAPTER 27 VEHICLE CONTROL UNIT (VCU) W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / VCU (6025) / K14E 16RD K14F 16RD K14G 16RD K10F 16WH K10G 16WH K10H 16WH / K14T 10RD / K97AF 18VT K97AG 22VT / CLEAN GROUND CONNECTION CH27_10 / GLOBAL RELAY A (4220)_ CH27_30 GLOBAL RELAY B (4221) CH27_31 K13V 18PK K13X 18PK K13R 18PK / FUSE F2E (6084) CH27_03 / K97AJ 18VT / K13M 18PK K13L 18PK / 12V SUPPLY / Figure 1449 / VEHICLE CONTROL UNIT (VCU) WITH PB10E00

27.30. SCU MODULE WITH PB10E00, P. 29
Figure 1450 SCU MODULE WITH PB10E00

Components: FUSE F3E (6083); SCU (6030)
Wires (circuit gauge+color): K10J 20WH; K10K 20WH; K10L 16WH; K10M 20WH; K10N 16WH; K10P 20WH; K10S 20WH; K14H 20PK; K14J 20PK; K14K 20PK; K14L 20PK; K14R 16RD
See also sheets: CH27_03, CH27_10
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.30. SCU MODULE WITH PB10E00, P. 29 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 / SCU MODULE W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / SCU (6030) / K14H 20PK K14J 20PK K14K 20PK K14L 20PK K10S 20WH K10J 20WH / K14R 16RD / K10P 20WH K10K 20WH K10L 16WH / CLEAN GROUND CONNECTION CH27_10 / FUSE F3E (6083) CH27_03 / K10M 20WH K10N 16WH / Figure 1450 / SCU MODULE WITH PB10E00

27.31. GLOBAL POWER A RELAY WITH PB10E00, P. 30
Figure 1451 GLOBAL POWER A RELAY WITH PB10E00

Components: COIL POWER (6025); FUSE F3F (6083); IN-1 INVERTER (6035); VCU GLOBAL A (6025)
Wires (circuit gauge+color): K13AC 18PK; K13K 18PK; K13V 18PK; K13W 18PK; K14AE 18RD; N13A 18PK
See also sheets: CH27_03, CH27_16, CH27_28, CH27_41
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.31. GLOBAL POWER A RELAY WITH PB10E00, P. 30 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 GLOBAL POWER A RELAY W/ PB10E00 / MJV0488 10FEB22 ADDED NOTE FOR GLOBAL POWER RELAY A. / 85 2 / 1 86 / 3 30 GLOBAL POWER A RELAY (4220) / K14AE 18RD / FUSE F3F (6083) CH27_03 / K97AFF 16VT / VCU GLOBAL A (6025) CH27_28 / COIL POWER (6025) CH27_28 / K13V 18PK / K13AC 2-IN-1 INVERTER 18PK (6035) CH27_41 VCU/ CHASSIS JUMPER (6090) H N13A 18PK / HVDM (6092) CH27_16 / K13K 18PK / K13W 18PK / NOTE - GLOBAL POWER REALY A IS USED FOR QX, INVERTER, HVDM CONNECTIONS. / Figure 1451 / GLOBAL POWER A RELAY WITH PB10E00

27.32. GLOBAL POWER B RELAY WITH PB10E00, P. 31
Figure 1452 GLOBAL POWER B RELAY WITH PB10E00

Components: BTMS (6058); COIL POWER (6025); COOLANT PUMP (6073); FAN CONTROL MODULE (6057); FUSE F3F (6083); OBC1 AND OBC2 (6041); VCU GLOBAL B (6025)
Wires (circuit gauge+color): K13A 18PK; K13AB 18PK; K13J 18PK; K13N 18PK; K13P 18PK; K13Q 18PK; K13S 18PK; K13X 18PK; K13Y 16PK; K14AF 16RD; K74D 14PK; N13B 18PK
See also sheets: CH27_03, CH27_15, CH27_28, CH27_32, CH27_33, CH27_37
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.32. GLOBAL POWER B RELAY WITH PB10E00, P. 31 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 GLOBAL POWER B RELAY W/ PB10E00 / MJV0488 10FEB22 POWER ELECTRONICS B 96429Y COOLANT PUMP WAS MT COOLANT PUMP. / 85 2 / 1 86 / 3 30 GLOBAL POWER B RELAY (4221) / K14AF 16RD / FUSE F3F (6083) CH27_03 / K97AGG 16VT / VCU GLOBAL B (6025) CH27_28 / COIL POWER (6025) CH27_28 / K13X 18PK / HV COMPONENTS CH27_VARIOUS / K13Q 18PK K13N 18PK K13S 18PK L K13J N13B 18PK 18PK VCU/ CHASSIS JUMPER (6090) / OBC1 AND OBC2 (6041) (6042) CH27_15 / K13A 18PK K13P 18PK / K13AB 18PK K74D 14PK / FAN CONTROL MODULE (6057) CH27_32 POWER ELECTRONICS COOLANT PUMP (6073) CH27_37 BTMS (6058) CH27_33 / K13Y 16PK / NOTE - GLOBAL POWER REALY B IS USED FOR RADIATOR FAN, OBC1, OBC 2, BTMS,EPM, MT COOLING PUMP,DC/DC1 & DC/DC2. / Figure 1452 / GLOBAL POWER B RELAY WITH PB10E00

27.33. FAN CONTROL MODULE WITH PB10E00, P. 32
Figure 1453 FAN CONTROL MODULE WITH PB10E00

Components: GLOBAL RELAY B (4221); MODULE (6057)
See also sheets: CH27_02, CH27_10, CH27_13, CH27_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.33. FAN CONTROL MODULE WITH PB10E00, P. 32 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 08JUL21 / CHAPTER 27 FAN CONTROL MODULE W/ PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / FAN CONTROL MODULE (6057) / GLOBAL RELAY B (4221) CH27_31 CLEAN GROUND CONNECTION CH27_10 CAB GROUND CH27_13 / K13AB 18 PK K10R 18 WH K11S 18 BK / RADIATOR POSITIVE POST / RADIATOR NEGATIVE POST / 1/0 RD / 1/0 BK / FUSE F1C CH27_02 / BATTERY FRAME GROUND / Figure 1453 / FAN CONTROL MODULE WITH PB10E00

27.34. BATTERY THERMAL MANAGEMENT SYSTEM (BTMS) WITH PB10E00, P. 33
Figure 1454 BATTERY THERMAL MANAGEMENT SYSTEM (BTMS) WITH PB10E00

Components: BTMS (6058); GLOBAL POWER B RELAY (4221); GROUND STUD (6059B); POWER STUD (6059A)
See also sheets: CH27_03, CH27_13, CH27_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.34. BATTERY THERMAL MANAGEMENT SYSTEM (BTMS) WITH PB10E00, P. 33 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS PART AE08093713 NO. RELEASE NO. 96275E 08JUL21 / CHAPTER 27 BATTERY THERMAL MANAGEMENT SYSTEM (BTMS) W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / K13A 18 PK K10A 18 WH / BTMS (6058) / GLOBAL POWER B RELAY (4221) CH27_31 / CLEAN GROUND CONNECTION CH27_13 / BTMS LV POWER STUD (6059A) / BTMS LV GROUND STUD (6059B) / K14A 4 RD / K11A 4 WH / CAB GROUND STUD (3G) / FUSE F1C CH27_03 / Figure 1454 / BATTERY THERMAL MANAGEMENT SYSTEM (BTMS) WITH PB10E00

27.35. VCU AMBIENT TEMP SENSOR WITH PB10E00, P. 34
Figure 1455 VCU AMBIENT TEMP SENSOR WITH PB10E00

Components: SENSOR (6075); VCU (6025)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.35. VCU AMBIENT TEMP SENSOR WITH PB10E00, P. 34 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 08JUL21 / CHAPTER 27 VCU AMBIENT TEMP SENSOR W/ PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / AMBIENT TEMP SENSOR (6075) / SIG 19 SOURCE / VCU (6025) / K6G 22 GY K41A 22 TN / K6B 18 GY K41AA 18 TN / Figure 1455 / VCU AMBIENT TEMP SENSOR WITH PB10E00

27.36. COOLANT TEMP SENSORS WITH PB10E00, P. 35
Figure 1456 COOLANT TEMP SENSORS WITH PB10E00

Components: COOLANT TEMP SENSOR (6078); INLET TEMP (6079); OUTLET TEMP (6022); VCU (6025)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.36. COOLANT TEMP SENSORS WITH PB10E00, P. 35 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / CHAPTER 27 COOLANT TEMP SENSORS W/ PB10E00 / CABIN HEAT INLET TEMP (6079) / CABIN HEAT OUTLET TEMP (6022) / POWER ELECTRONICS COOLANT TEMP SENSOR (6078) / VCU (6025) / K29A 22 TN K6G 22 GY / K29E 22 TN / K29B 22 TN / K29AA 18 TN K6A 18 GY / K6L 18 GY K29EE 18 TN / K6C 18 GY K29BB 18 TN / SIG SOURCE / Figure 1456 / COOLANT TEMP SENSORS WITH PB10E00

27.37. SURGE TANK SENSORS WITH PB10E00, P. 36
Figure 1457 SURGE TANK SENSORS WITH PB10E00

Components: SURGE TANK (6020); TANK SENSOR (6076); VCU (6025)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.37. SURGE TANK SENSORS WITH PB10E00, P. 36 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 08JUL21 / CHAPTER 27 SURGE TANK SENSORS W/ PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / VCU (6025) / B C D / B C D / CABIN HEAT SURGE TANK (6020) / MT SURGE TANK SENSOR (6076) / K36AA 22 TN K9FF 22 GY K36BB 22 TN / K97AJ 18 VT / K34AA 22 GY K9GG 22 GY K34BB 22 TN / K34A 18 TN K9G 18 GY K13M 18 PK / K34B 18 TN / K36A 18 TN K9F 18 GY / K36B 18 TN / K13L 18 PK / 12V SUPPLY / Figure 1457 / SURGE TANK SENSORS WITH PB10E00

27.38. MEDIUM TEMP (MT) COOLANT PUMP WITH PB10E00, P. 37
Figure 1458 MEDIUM TEMP (MT) COOLANT PUMP WITH PB10E00

Components: B RELAY (4221); COOLANT PUMP (6073); FUSE F2C (6084)
Wires (circuit gauge+color): K11U 8WH; K74B-G 12WH; K74C 12LTGN; K74D 14PK
See also sheets: CH27_13, CH27_3, CH27_31
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.38. MEDIUM TEMP (MT) COOLANT PUMP WITH PB10E00, P. 37 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS PART AE08093713 NO. RELEASE NO. 96275E 08JUL21 / CHAPTER 27 POWER ELECTRONICS COOLANT PUMP W/PB10E00 / MJV0488 10FEB22 POWER ELECTRONICS B 96429Y COOLANT PUMP WAS MT COOLANT PUMP. / FUSE F2C (6084) CH27_3 / CAB GROUND CONECTION CH27_13 / GLOBAL POWER B RELAY (4221) CH27_31 / POWER ELECTRONICS COOLANT PUMP (6073) / K74D 14PK / K74C 12LTGN / K74B-G 12WH / K11U 8WH / Figure 1458 / MEDIUM TEMP (MT) COOLANT PUMP WITH PB10E00

27.39. TRACTION POWER INVERTER MODULE (TPIM) WITH PB10E00, P. 38
Figure 1459 TRACTION POWER INVERTER MODULE (TPIM) WITH PB10E00

Components: CHASSIS JUMPER/VCU (6090); CHASSIS JUMPER/VCU (6091); FUSE F2D (6084); RESISTOR A (6097A); RESISTOR B (6097B); TPIM (6094); VCU (6025)
Wires (circuit gauge+color): K11H 18WH; K11P 12WH; K14AA 12RD; K14U 12RD; N11G 18WH; N11L 18WH; N11M 14WH; N11P 18WH; N14A 16RD; N14F 18RD; N14G 18RD
See also sheets: CH27_13, CH27_3
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.39. TRACTION POWER INVERTER MODULE (TPIM) WITH PB10E00, P. 38 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS PART AE08093713 NO. RELEASE NO. 96275E 08JUL21 / CHAPTER 27 TRACTION POWER INVERTER MODULE (TPIM) W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / N11L 18WH / R2 ENABLE RESISTOR A (6097A) / TPIM (6094) / OHMS 715 / 715 OHMS / CHASSIS JUMPER/VCU (6090) K / VCU (6025) / R2 ENABLE RESISTOR B (6097B) / N14G 18RD / K14AA 12RD / N14F 18RD / N14A 16RD / CHASSIS JUMPER/VCU (6091) E / CAB GROUND CONNECTION CH27_13 / N11M 14WH / N11G 18WH / K11P 12WH / K11H 18WH / FUSE F2D (6084) CH27_3 / K14U 12RD / K97AE 22VT / N97C 18VT / N97J 18VT / N97P 18VT / N97L 18VT / N11P 18WH / Figure 1459 / TRACTION POWER INVERTER MODULE (TPIM) WITH PB10E00

27.40. TPIM VENDOR MOTOR CONTROL CABLE WITH PB10E00, P. 38A
Figure 1460 TPIM VENDOR MOTOR CONTROL CABLE WITH PB10E00

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.40. TPIM VENDOR MOTOR CONTROL CABLE WITH PB10E00, P. 38A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 08JUL21 / CHAPTER 27 TPIM VENDOR MOTOR CONTROL CABLE W/ PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / TPIM DRIVE SIDE / 1 WIRE GND S / TEMP A(+) F / TEMP A(-) E / S 1 WIRE GND / R 1 WIRE OUT / MOTOR SIDE / E TEMP A(-) / F TEMP A(+) / HVIL TO H MOTOR HVIL FROM K MOTOR / HVIL TO MOTOR HVIL FROM K MOTOR / TEMP B(-) C / C TEMP B(-) / A TEMP C(-) / TEMP B(+) D / TEMP B(+) D / TEMP C(+) B / R 1 WIRE OUT / TEMP C(-) A / TEMP C(+) B / 18 GN / 18 WH / 18 RD / 18 BK / 18 YL / 18 BU / 18 RD / 18 BK / 18 RD / 18 WH / 18 WH / 18 GN / 18 BK / 18 WH / 18 PU / 18 OR / Figure 1460 / TPIM VENDOR MOTOR CONTROL CABLE WITH PB10E00

27.41. ACCELERATOR POSITION SENSOR WITH PB10E00, P. 39
Figure 1461 ACCELERATOR POSITION SENSOR WITH PB10E00

Components: POSITION SENSOR (1804); VCU (6025); VCU/PLATFORM (1701/1701)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.41. ACCELERATOR POSITION SENSOR WITH PB10E00, P. 39 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 20AUG21 / CHAPTER 27 ACCELERATOR POSITION SENSOR W/ PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / VCU (6025) / K97C 22VT K99A 22VT K97B 22VT K97E 22VT K99B 22VT K97D 22VT / VCU/PLATFORM (1701/1701) 47 A97R 18VT A99A 18VT A97C 18VT A97WC 18VT A99F 18VT A99D 18VT / ACCELERATOR POSITION SENSOR (1804) / K97CC 18VT K99AA 18VT K97BB 18VT K97EE 18VT K97BB 18VT K97DD 18VT / Figure 1461 / ACCELERATOR POSITION SENSOR WITH PB10E00

27.42. EV SHIFT SELECTOR (RNDL PUSH BUTTON TYPE) WITH PB10E00, P. 40
Figure 1462 EV SHIFT SELECTOR (RNDL PUSH BUTTON TYPE) WITH PB10E00

Components: FUSE A3-E (1016); FUSE A6-M (1014); GROUND SPLICE (1003A); PANNEL LIGHTS (1002A); PLATFORM/VCU (1701); VCU (6025)
Wires (circuit gauge+color): A62J 18DKBL; A92-G 18WH; A92A 18TN; A92B 18TN; A92C 18TN; K92A 22TN; K92AA 18TN
See also sheets: CH27_05, CH3_2, CH3_5
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.42. EV SHIFT SELECTOR (RNDL PUSH BUTTON TYPE) WITH PB10E00, P. 40 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS PART AE08093713 NO. RELEASE NO. 96275E 08JUL21 / CHAPTER 27 EV SHIFT SELECTOR (RNDL PUSHBUTTON TYPE) W/PB10E00 / MJV0488 10FEB22 DRIVE MODE SELECTOR WAS EV SHIFTER GSM. / DRIVE MODE SELECTOR (1855) / PLATFORM/VCU (1701) 51 / VCU (6025) / A5K(+) 18YL / A5K(-) 18GN / A92A 18TN / A62J 18DKBL / PT_CAN J1939 CH27_05 / K92AA 18TN / K92A 22TN / A92C 18TN A92B 18TN / A92-G 18WH / PANNEL LIGHTS (1002A) / GROUND SPLICE (1003A) / FUSE A3-E (1016) CH3_5 FUSE A6-M (1014) CH3_2 / Figure 1462 / EV SHIFT SELECTOR (RNDL PUSH BUTTON TYPE) WITH PB10E00

27.43. 2-IN-ONE INVERTER WITH PB10E00, P. 41
Figure 1463 2-IN-ONE INVERTER WITH PB10E00

Components: GLOBAL POWER A RELAY (4220); INVERTER (6035)
See also sheets: CH27_13, CH27_30
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.43. 2-IN-ONE INVERTER WITH PB10E00, P. 41 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 08JUL21 / CHAPTER 27 2-IN-ONE INVERTER W/ PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / K13AC 18 PK K11T 18 WH / 2-IN-1 INVERTER (6035) / GLOBAL POWER A RELAY (4220) CH27_30 / CAB GROUND CONNECTION CH27_13 / Figure 1463 / 2-IN-ONE INVERTER WITH PB10E00

27.44. 2-IN-1 INVERTER VENDOR SUPPLIED CABLES WITH PB10E00, P. 41A
Figure 1464 2-IN-1 INVERTER VENDOR SUPPLIED CABLES WITH PB10E00

Components: INLINE (6035); INLINE (9000); TEMP SENSOR (9001)
Wires (circuit gauge+color): M77 18RD
See also sheets: CH27_41, CH27_6
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.44. 2-IN-1 INVERTER VENDOR SUPPLIED CABLES WITH PB10E00, P. 41A / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 08JUL21 / CHAPTER 27 2-IN-1 INVERTER VENDOR SUPPLIED CABLES W/ PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / 2-IN-1 CONTROL CABLE CONNECTOR / EMPTY HV AIR COMPRESSOR D ENABLE / 2-IN-1 INVERTER INLINE (6035) 1 / EMPTY HV POWER STEERING ENABLE 12V(+) H / HV AIR COMPRESSOR TEMP SENSOR (9001) / K5AV(+) 18YL K5AV(-) 18GN / HV AIR COMPRESSOR INLINE (9000) 2 / SPARE CIRCUIT K13AC 18PK K11T 18WH / M77-G 18LTGN M77 18RD / 12V(-) HV AIR COMPRESSOR G TEMP(-) HV AIR COMPRESSOR K TEMP(+) EMPTY / SPARE CIRCUIT / VCU HARNESS CH27_41 / CAN_HVCTRL CH27_6 / Figure 1464 / 2-IN-1 INVERTER VENDOR SUPPLIED CABLES WITH PB10E00

27.45. AIR DRYER WITH PB10E00, P. 42
Figure 1465 AIR DRYER WITH PB10E00

Components: AIR DRAIN VALVE (9526E); FUSE A3-N (1016); FUSE F2C (6082); HEATER (9257E); INTERCONN (9513); PLATFORM (1700); PLATFORM/VCU (1701); SPLICE (6740E); VCU/PLATFORM (1701)
Wires (circuit gauge+color): A13FD 18PK; A39DE 14WH; A39E 14BK; A39F 14BK; K11W 12WH; K13F 18PK; K14Z 12RD; K39A-G 18WH; K39D 18GY; M39C 14WH; M39D 14WH; M39D-G 14BK
See also sheets: CH27_13, CH27_2, CH3_6
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.45. AIR DRYER WITH PB10E00, P. 42 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 AIR DRYER W/PB10E00 / MJV0488 10FEB22 UPDATE DESCRIPTION OF R/D 9526E & 9557E. / CAB GROUND CONNECTION CH27_13 AIR DRAIN VALVE (9526E) / 3 AIR DRYER 30 RELAY (4015) / PLATFORM/VCU (1701) / VCU/PLATFORM (1701) 28 / K11W 12WH / K39A-G 18WH / 85 2 / 87A 5 / 1 86 / A39F 14BK / K14Z 12RD / K13F 18PK / FUSE F2C (6082) CH27_2 / A39E 14BK / FUSE A3-N (1016) CH3_6 / A13FD 18PK / K39D 18GY / R39C 14BK / FWD CHASSIS /PLATFORM (1700) 28 / EV GROUND F SPLICE (6740E) / A39DE 14BK / R39C-G 14WH / M39C 14BK EV/FWD/REAR INTERCONN (9513)/(9513FE) 15 / M39D 14BK / M39D-G 14WH / M39C-G 14WH / AIR DRYER HEATER (9257E) / Figure 1465 / AIR DRYER WITH PB10E00

27.46. HV AIR COMPRESSOR PURGE VALVE WITH PB10E00, P. 43
Figure 1466 HV AIR COMPRESSOR PURGE VALVE WITH PB10E00

Components: PURGE VALVE (6095); VCU (6025); VCU/CHASSIS JUMPER (6091)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.46. HV AIR COMPRESSOR PURGE VALVE WITH PB10E00, P. 43 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 HV AIR COMPRESSOR PURGE VALVE W/ PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE / K9D 22 GY K39E 22 GY / SW RTN 31 / 79 SW SIG / VCU (6025) / VCU/CHASSIS JUMPER (6091) C / HV AIR COMP PURGE VALVE (6095) / K9B 18 GY / N97F 18 GY N39A 18 GY / Figure 1466 / HV AIR COMPRESSOR PURGE VALVE WITH PB10E00

27.47. AIR PARK BRAKE INTERLOCK WITH PB10E00, P. 44
Figure 1467 AIR PARK BRAKE INTERLOCK WITH PB10E00

Components: BRAKE SOLENOID (4905); FUSE A3-A (1016); PLATFORM/VCU (1701); SPLICE (1003B)
Wires (circuit gauge+color): A44C-G 18WH; K44 18GY; K44C 18GY
See also sheets: CH3_05, CH3_33
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.47. AIR PARK BRAKE INTERLOCK WITH PB10E00, P. 44 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 AIR PARK BRAKE INTERLOCK W/ PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE / K44 18GY / AIR PARK BRAKE SOLENOID (4905) / K44C 18GY / PLATFORM/VCU (1701) / A44C-G 18WH / W/PARK BRAKE INTERLOCK / FUSE A3-A (1016) CH3_05 / GROUND SPLICE (1003B) CH3_33 / A44AB 16VT / Figure 1467 / AIR PARK BRAKE INTERLOCK WITH PB10E00

27.48. VCU STOP LIGHT PRESSURE SWITCHES WITH PB10E00, P. 45
Figure 1468 VCU STOP LIGHT PRESSURE SWITCHES WITH PB10E00

Components: PRESSURE SWITCH (1825); PRESSURE SWITCH (1826); VCU (6025); VCU/PLATFORM (1701)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.48. VCU STOP LIGHT PRESSURE SWITCHES WITH PB10E00, P. 45 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 VCU STOP LIGHT PRESSURE SWITCHES W/ PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE / K101A 22 GY / A9BA 18 GY / A101BB 18 TN / VCU (6025) / K101BB 18 GY / SW SIG 79 / K101B 22 GY / VCU/PLATFORM (1701) 24 A101AA 18 TN / A9AAA 18 GY / K9D 22 GY / VCU STOP LT 2 PRESSURE SWITCH (1826) / K9A 18 PK / A9CAA 18 GY / K101AA 18 GY / VCU STOP LT 1 PRESSURE SWITCH (1825) / Figure 1468 / VCU STOP LIGHT PRESSURE SWITCHES WITH PB10E00

27.49. HV ELECTRIC WATER HEATER WITH PB10E00, P. 46
Figure 1469 HV ELECTRIC WATER HEATER WITH PB10E00

Components: HVDU (6050); SWITCH (6060)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.49. HV ELECTRIC WATER HEATER WITH PB10E00, P. 46 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 HV ELECTRIC WATER HEATER W/ PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE / HV WATER HEATER THERMAL SWITCH (6060) / HVDU (6050) / K29D 18 TN K29C 18 TN / Figure 1469 / HV ELECTRIC WATER HEATER WITH PB10E00

27.50. HIGH VOLTAGE CABIN HEAT ENABLE WITH PB10E00, P. 47
Figure 1470 HIGH VOLTAGE CABIN HEAT ENABLE WITH PB10E00

Components: ENABLE RELAY (4215); FUSE F3D (6081); HVDU (6050); VCU (6025)
Wires (circuit gauge+color): K13B 18PK; K13R 18PK; K14X 16RD
See also sheets: CH27_2, CH27_28
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.50. HIGH VOLTAGE CABIN HEAT ENABLE WITH PB10E00, P. 47 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 HIGH VOLTAGE CABIN HEAT ENABLE W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE / VCU (6025) / 3 30 HV CABIN HT ENABLE RELAY (4215) / VCU (6025) CH27_28 / HVDU (6050) / K97AL 22VT / K97ALL 16VT / 85 2 / 1 86 / K13B 18PK / K14X 16RD / K13R 18PK / FUSE F3D (6081) CH27_2 / HT ENABLE / Figure 1470 / HIGH VOLTAGE CABIN HEAT ENABLE WITH PB10E00

27.51. HIGH VOLTAGE CABIN HEAT ENABLE WITH PB10E00 (CONT.), P. 48
Figure 1471 HIGH VOLTAGE CABIN HEAT ENABLE WITH PB10E00 (CONT.)

Components: CONNECTOR (1607); HEATER SWITCH (10244C); PLATFORM/PANNEL (1702); SPLICE PACK (10331); ZVR ADAPTER (10350B)
Wires (circuit gauge+color): A9FAA 18GY; B62D 18DKBL; B9FA 18GY; B9KA 18GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.51. HIGH VOLTAGE CABIN HEAT ENABLE WITH PB10E00 (CONT.), P. 48 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS PART AE08093713 NO. RELEASE NO. 96275E 08JUL21 / CHAPTER 27 HV CABIN HEAT ENABLE(CONTINUED) W/PB10E00 / MJV0488 10FEB22 COOLANT HEATER SWITCH B WAS WATER HEATER SWITCH. / EV COOLANT HEATER SWITCH (10244C) 2 / SWITCH ILLUMINATION SPLICE PACK (10331) / B62D 18DKBL B62-GD 18 WH / PLATFORM/PANNEL (1702) 63 / B9FA 18GY / ZVR ADAPTER (10350B) / B9KA 18GY / A9FAA 18GY / HT SW B4 INPUT / BCM J7 CONNECTOR (1607) / Figure 1471 / HIGH VOLTAGE CABIN HEAT ENABLE WITH PB10E00 (CONT.)

27.52. EV BOOSTER (CABIN HEAT) PUMP WITH PB10E00, P. 49
Figure 1472 EV BOOSTER (CABIN HEAT) PUMP WITH PB10E00

Components: FUSE F2E (6082); RESISTOR A (6023A); RESISTOR B (6023B); VCU (6025)
See also sheets: CH27_13, CH27_2
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.52. EV BOOSTER (CABIN HEAT) PUMP WITH PB10E00, P. 49 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS PART AE08093713 NO. RELEASE NO. 96275E 08JUL21 / CHAPTER 27 EV BOOSTER (CABIN HEAT) PUMP W/ PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE / 2 4 / CABIN HT PUMP 6-WAY (6072) / K98A 14 BK / CABIN HT PUMP 4-WAY (6071) / K74B 12 RD / FUSE F2E (6082) CH27_2 / K74A-G 12 WH / K11AA 18 WH / VCU (6025) / K74A 14 PK / K97V 22 VT / OHMS 715 A / CAB GROUND CONNECTION CH27_13 HEAT PUMP PULL-DOWN RESISTOR A (6023A) B / HEAT PUMP PULL-DOWN RESISTOR B (6023B) B / 715 OHMS A / K97Y 18 PK / K97Z 18 PK / K11AB 18 WH / K98AB 18 BK / K11U 8 WH / K97VV 16 VT / Figure 1472 / EV BOOSTER (CABIN HEAT) PUMP WITH PB10E00

27.53. EV BOOSTER (CABIN HEAT) PUMP WITH PB10E00 (CONT.), P. 50
Figure 1473 EV BOOSTER (CABIN HEAT) PUMP WITH PB10E00 (CONT.)

Components: CONNECTOR (1607); PLATFORM/PANNEL (1702); PUMP SWITCH (10255A); SPLICE PACK (10331); ZVR ADAPTER (10350B)
Wires (circuit gauge+color): A9HAA 18GY; B62CA 18DKBL; B9HA 18GY; B9JA 18GY
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.53. EV BOOSTER (CABIN HEAT) PUMP WITH PB10E00 (CONT.), P. 50 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS PART AE08093713 NO. RELEASE NO. 96275E 08JUL21 / CHAPTER 27 EV BOOSTER PUMP (CONTINUED) W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE / EV BOOSTER PUMP SWITCH (10255A) 2 / SWITCH ILLUMINATION SPLICE PACK (10331) / B62CA 18DKBL B62GC 18 WH / PLATFORM/PANNEL (1702) 31 / B9HA 18GY / ZVR ADAPTER (10350B) / B9JA 18GY / A9HAA 18GY / BOOST B5 INPUT / BCM J7 CONNECTOR (1607) / Figure 1473 / EV BOOSTER (CABIN HEAT) PUMP WITH PB10E00 (CONT.)

27.54. AUX HEATER WITH PB10E00, P. 51
Figure 1474 AUX HEATER WITH PB10E00

Components: FUSE B6-B (10303); SWITCH (10245C)
Wires (circuit gauge+color): B13JA 18PK; B13KA 18PK; B74A-GAA 12WH; B74AD 12RD; B74BD 16LTGN; B74CZ 18LTGN; B74DB 18LTGN
See also sheets: CH3_9
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.54. AUX HEATER WITH PB10E00, P. 51 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 08JUL21 / CHAPTER 27 AUX HEATER W/ PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE / WEBASTO SMARTEMP (14510B) / GROUND STUD 1 GROUND (36) / AUX HTR SWITCH (10245C) 2 / 2 1 3 / B74BD 16LTGN B74DB 18LTGN B74AD 12RD B74A-GAA 12WH / 5 6 / FUSE B6-B (10303) CH3_9 B74-GAA 16WH / 3 1 4 / WEBASTO HEATER (10101) / A13J 18PK / PLATFORM/PANEL (1702) 32 / B13JA 18PK / IGNITION SPLICE PACK (1014A) / EV AUX HTR DIODE(14511) 1 / B74CC 18LTGN / B74CZ 18LTGN / SWITCH ILLUMINATION SPLICE PACK (10331) / B62EA 18DKBL / B62GEA 18WH / B13KA 18PK / Figure 1474 / AUX HEATER WITH PB10E00

27.55. ABS FORWARD / REAR CHASSIS INTERCONNECT WITH PB10E00, P. 52
Figure 1475 ABS FORWARD / REAR CHASSIS INTERCONNECT WITH PB10E00

Components: ATC EV (9522E); BENDIX RL WSS (9501E); BENDIX RR WSS (9503E); MODULATOR (9518E); MODULATOR (9519E); REAR INTERCONN (9513E)
Wires (circuit gauge+color): M152A 16GY; M152B 16GY; M94A 16GY; M94C 16GY; M94D 16GY; M94E 14GY; M94H 14GY; M94J 14GY; M94K 14GY; M94L 14GY; R152A 14GY; R152B 16GY; R94B 16GY; R94D 16GY; R94H 14GY; R94J 14GY; R94L 16GY
See also sheets: CH13_43
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.55. ABS FORWARD / REAR CHASSIS INTERCONNECT WITH PB10E00, P. 52 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 08JUL21 / CHAPTER 27 ABS FORWARD/REAR CHASSIS INTERCONNECT W/ PB10E00 / MJV0488 22SEP21 INITIAL RODUCTION RELEASE / BENDIX RL WSS (9501E) CH13_43 / ABS FWD/ REAR INTERCONN (9513E)/(9513FE) / R94A 16GY R94B 16GY R94C 16GY R94D 16GY R94E 14GY R94F 14GY R94H 14GY R94J 14GY R94K 14GY R94L 14GY R152A 16GY R152B 16GY / M94A 16GY M94B 16GY M94C 16GY M94D 16GY M94E 14GY M94F 14GY M94H 14GY M94J 14GY M94K 14GY M94L 14GY M152A 16GY M152B 16GY / PLATFORM/FWD CHASSIS (1700E) CH13_43 / BENDIX RR WSS (9503E) CH13_43 / BENDIX ABS LR MODULATOR (9518E) CH13_43 / ATC EV (9522E) CH13_43 / BENDIX ABS RR MODULATOR (9519E) CH13_43 / Figure 1475 / ABS FORWARD / REAR CHASSIS INTERCONNECT WITH PB10E00

27.56. HV DC FAST BATTERY CHARGE WITH PB10E00, P. 53
Figure 1476 HV DC FAST BATTERY CHARGE WITH PB10E00

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.56. HV DC FAST BATTERY CHARGE WITH PB10E00, P. 53 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 07JUL21 / CHAPTER 27 HV DC FAST BATTERY CHARGE W/ PB10E00 / - UPDATED HV CABLE FOR LINE THICKNESS. / POS 2/0 OR / CHARGE PORT INLET J1 / POS 2/0 OR / NEG 2/0 OR / NEG 2/0 OR / Figure 1476 / HV DC FAST BATTERY CHARGE WITH PB10E00

27.57. HV AC BATTERY CHARGE WITH PB10E00, P. 54
Figure 1477 HV AC BATTERY CHARGE WITH PB10E00

Wires (circuit gauge+color): L1 4BN
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.57. HV AC BATTERY CHARGE WITH PB10E00, P. 54 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 05AUG21 / CHAPTER 27 HV AC BATTERY CHARGE W/ PB10E00 / - UPDATED HV CABLE FOR LINE THICKNESS. / 6 OR / OBC TOP J1 A / PORT INLET J1 L1 / 6 OR / 4 12BK 6 12BK / 5 12BK 2 12BK / 1 12BK 3 12BK / 5 12BK 2 12BK / 1 12BK 3 12BK / OBC BOTTOM J1 A / 4 12BK 6 12BK / FRAME GROUND / Figure 1477 / HV AC BATTERY CHARGE WITH PB10E00

27.58. HV BATTERY CHARGE DISTRIBUTION WITH PB10E00, P. 55
Figure 1478 HV BATTERY CHARGE DISTRIBUTION WITH PB10E00

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.58. HV BATTERY CHARGE DISTRIBUTION WITH PB10E00, P. 55 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 08JUL21 / CHAPTER 27 HV BATTERY CHARGE DISTRIBUTION W/PB10E00 / - UPDATED HV CABLE FOR LINE THICKNESS. / BMS S-BOX / NEG1 1 / NEG 2/0 OR / NEG2 1 / POS1 1 / POS2 1 / NEG1 1 / NEG2 1 / POS1 1 / POS2 1 / NEG 2/0 OR / POS 2/0 OR / POS 2/0 OR / OBC2 J3 1 / OBC1 J3 1 / POS 12RD NEG 12BL / POS 12RD NEG 12BL / PDE HVDU / PDE DC / HVDU B / OBC1 2 / OBC2 2 1 / HVDM B / POS 4 OR / NEG 4 OR / Figure 1478 / HV BATTERY CHARGE DISTRIBUTION WITH PB10E00

27.59. HV BATTERY BMS SWITCH BOX WITH PB10E00, P. 56
Figure 1479 HV BATTERY BMS SWITCH BOX WITH PB10E00

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.59. HV BATTERY BMS SWITCH BOX WITH PB10E00, P. 56 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 08JUL21 / CHAPTER 27 HV BATTERY BMS SWITCH BOX W/PB10E00 / - UPDATED HV CABLE FOR LINE THICKNESS. / W/2-BATTERY STACK ASSY B HV BATT 4 NEG / NEG1 1 / POS 630A POS 3/0 OR / NEG2 1 / POS1 1 / POS2 1 / BAT2- 1 / BAT1- 1 / BAT1+ 1 POS 3/0 OR BAT2+ 1 / OR 3/0 / BMS S-BOX / 630A POS / HV BATT 5 NEG / HV BATT 6 NEG / OR 3/0 / W/1-BATTERY STACK ASSY A HV BATT 1 NEG / HV BATT 2 NEG / OR 3/0 / OR 3/0 / EXTERNAL MSD 2 IN OUT / HV BATT 3 NEG / NEG 3/0 OR / EXTERNAL MSD 1 IN OUT / NEG 3/0 OR / BAT3+ 1 / BAT3- 1 / EXTERNAL MSD 3 / HV BATT 8 NEG / OR 3/0 EXTERNAL IN 4 MSD OUT / HV BATT 7 NEG / HV BATT 9 NEG / OR 3/0 / POS 3/0 OR / POS 3/0 OR / POS 3/0 OR / OR 3/0 / NEG 3/0 OR / W/3-BATTERY STACK ASSY C / POS 3/0 OR / POS 630A / 630A POS / 630A POS / POS 630A / 630A POS / POS 630A / 630A POS / Figure 1479 / HV BATTERY BMS SWITCH BOX WITH PB10E00

Figure 1480 HV DC/DC CONVERTERS WITH PB10E00

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.60. HV DC/DC CONVERTERS WITH PB10E00, P. 57 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 08JUL21 / CHAPTER 27 HV DC/DC CONVERTERS W/PB10E00 / - UPDATED HV CABLE FOR LINE THICKNESS. / DC/DC CONVERTER 1 INPUT 1 POS / DCDC1 1 POS 12RD NEG 12BL / 2 NEG / DCDC2 1 POS 12RD NEG 12BL / DC/DC CONVERTER 2 INPUT MULTI-CORE 1 POS / HVDM B / 2 NEG / Figure 1480 / HV DC/DC CONVERTERS WITH PB10E00

Figure 1481 HV ELECTRIC COOLANT HEATER WITH PB10E00

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.61. HV ELECTRIC COOLANT HEATER WITH PB10E00, P. 58 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 08JUL21 / CHAPTER 27 HV ELECTRIC COOLANT HEATER W/PB10E00 / - UPDATED HV CABLE FOR LINE THICKNESS. / NEG 6 OR POS 6 OR / HVDM B / COOLANT HEATER / HV ELECTRIC COOLANT HEATER / Figure 1481 / HV ELECTRIC COOLANT HEATER WITH PB10E00

Figure 1482 HV 2-IN-ONE INVERTER WITH PB10E00

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.62. HV 2-IN-ONE INVERTER WITH PB10E00, P. 59 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 08JUL21 / CHAPTER 27 HV 2-IN-ONE INVERTER W/PB10E00 / - UPDATED HV CABLE FOR LINE THICKNESS. / HV AIR AC COMPRESSOR INPUT 1 2 3 HV POWER AC STEERING PUMP INPUT 3 2 1 / QX 2 / 2-IN-1 INVERTER AC OUT CPRSR U 1 14 2 V 14 W 3 14 / HVDM B / HV INPUT / NEG 12BL POS 12RD / AC OUT PWR STRG U 1 14 V 2 14 W 3 14 / Figure 1482 / HV 2-IN-ONE INVERTER WITH PB10E00

27.63. HV BATTERY THERMAL MANAGEMENT SYSTEM WITH PB10E00, P. 60
Figure 1483 HV BATTERY THERMAL MANAGEMENT SYSTEM WITH PB10E00

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.63. HV BATTERY THERMAL MANAGEMENT SYSTEM WITH PB10E00, P. 60 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 08JUL21 / CHAPTER 27 HV BATTERY THERMAL MANAGEMENT SYSTEM W/PB10E00 / - UPDATED HV CABLE FOR LINE THICKNESS. / BTMS 1 / HVDU B / HV1 MULTI-CORE POS 10RD NEG 10BK / PDE HVDU / Figure 1483 / HV BATTERY THERMAL MANAGEMENT SYSTEM WITH PB10E00

27.64. HV TPIM DRIVE MOTOR WITH PB10E00, P. 61
Figure 1484 HV TPIM DRIVE MOTOR WITH PB10E00

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.64. HV TPIM DRIVE MOTOR WITH PB10E00, P. 61 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 08JUL21 / CHAPTER 27 HV TPIM DRIVE MOTOR W/PB10E00 / - UPDATED HV CABLE FOR LINE THICKNESS. / TPIM+ 1 / TPIM- 1 / NEG1 1 / TPIM - / SCE TPIM / POS 2/0 OR / NEG 2/0 OR / POS1 1 / DRIVE MOTOR / 1 OR / 1 OR / 1 OR / 1 OR / 1 OR / 1 OR / Figure 1484 / HV TPIM DRIVE MOTOR WITH PB10E00

27.65. HVDU HVIL CIRCUIT WITH PB10E00, P. 62
Figure 1485 HVDU HVIL CIRCUIT WITH PB10E00

Components: OBC2 (6042); SCU (6030); VCU (6025)
Wires (circuit gauge+color): K19BB 18GY; K19DD 18GY; K97R 16PK; K98C 18BK; K98D 18BK
See also sheets: CH27_14, CH27_20
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.65. HVDU HVIL CIRCUIT WITH PB10E00, P. 62 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 08JUL21 / CHAPTER 27 HVDU HVIL CIRCUIT W/PB10E00 / - UPDATED HV CABLE FOR LINE THICKNESS. / 2-IN-1 3 / DCDC1 MULTI-CORE 3 HVIL+ 20BK HVIL- 20BK / DCDC2 MULTI-CORE 3 HVIL+ 20BK HVIL- 20BK / OBC1 J3 MULTI-CORE 3 3 HVIL+ 20BK HVIL- 20BK / (6041) 11 K98C 18BK / OBC2 J3 MULTI-CORE 3 3 HVIL+ 20BK HVIL- 20BK / (6042) 11 K98D 18BK 12 / (6050) K193D 1 18GY 3 K19DD 18GY 4 K19BB 18GY 7 K97R 16PK / SCU (6030) CH27_14 / VCU (6025) CH27_20 / LID SW / CNTCR AC CH+ / Figure 1485 / HVDU HVIL CIRCUIT WITH PB10E00

27.66. HVDM HVIL CIRCUIT WITH PB10E00, P. 63
Figure 1486 HVDM HVIL CIRCUIT WITH PB10E00

Components: POS1 (6092); SCU (6030); VCU (6025)
Wires (circuit gauge+color): N13A 18PK; N14C 16RD; N6C 18GY
See also sheets: CH27_16, CH27_19, CH27_20
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.66. HVDM HVIL CIRCUIT WITH PB10E00, P. 63 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 08JUL21 / CHAPTER 27 HVDM HVIL CIRCUIT W/PB10E00 / - UPDATED HV CABLE FOR LINE THICKNESS. / (6092) 3 N19A 18GY N6C 12 18GY 1 N14C 16RD N97M 18VT N13A 18PK N97D 18VT / VCU (6025) CH27_16 / VCU (6025) CH27_20 HV DISCONNECT (10290B) CH27_19 / LID SW / SCU (6030) CH27_16 / SCE TPIM / BTMS 3 / SCE HVAC - REAR / SCE DCFC / PDE HVDU / SCE HVAC - FRONT / HVAC-F 3 / HVAC-R 3 / Figure 1486 / HVDM HVIL CIRCUIT WITH PB10E00

27.67. BODY AIR CONDITIONING ENABLE WITH PB10E00, P. 64
Figure 1487 BODY AIR CONDITIONING ENABLE WITH PB10E00

Components: A/C DIODE (4210); FUSE F3F (6083); RELAY (4222); SOLENOID (4212); VCU (6025); VCU/ PLATFORM (1701)
Wires (circuit gauge+color): K14AG 16RD
See also sheets: CH27_13, CH27_3
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.67. BODY AIR CONDITIONING ENABLE WITH PB10E00, P. 64 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 22JUL21 / CHAPTER 27 BODY AIR CONDITIONING ENABLE W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / VCU (6025) / CAB GROUND CH27_13 / K97V 22VT / K97ALM 16VT / K77A 16 PK / K14AG 16RD / K11N 16 WH / FUSE F3F (6083) CH27_3 / 85 2 / 3 HVAC 30 RELAY (4222) / 1 86 / GROUND SPLICE #1 (1003B) / BODY A/C SOLENOID (4212) / VCU/ PLATFORM (1701) / A/C DIODE (4210) / A77-G 18 WH / A77B 18 PK A77-GA 18 WH / A77A 16 PK / Figure 1487 / BODY AIR CONDITIONING ENABLE WITH PB10E00

27.68. BODY AIR CONDITIONING HMI WITH 48CXZ & PB10E00, P. 65
Figure 1488 BODY AIR CONDITIONING HMI WITH 48CXZ & PB10E00

Components: CONTROLLER (14517); HVCTRLS (14519); PLATFORM/PANEL (1702); RESISTOR (1653A); VCU/PLATFORM (1701)
Wires (circuit gauge+color): A10E 18WH; K10E 18WH
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.68. BODY AIR CONDITIONING HMI WITH 48CXZ & PB10E00, P. 65 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 22JUL21 / CHAPTER 27 BODY AIR CONDITIONING HMI W/48CXZ & W/ PB10E00 / MJV0488 10FEB22 CAN_HVCTRLS WAS HVAC CAN. / EV HVAC CONTROLLER (14517) 1 / 120 120 OHMS OHMS / EV HVAC CONTROLS RESISTOR (1653A) A / A5TA(+) 18 YL / A5TA(-) 18 GN / A5TAA(+) 18 YL / A5TAA(-) 18 GN / CAN_HVCTRLS (14519) / B5AF(-) 18 GN B5AF(+) 18 YL / B5AG(-) 18 GN B5AH(-) 18 GN B5AG(+) 18 YL B5AH(+) 18 YL / A5T(-) 18 GN / K10D 10WH / PLATFORM/PANEL (1702) 34 / VCU/PLATFORM (1701) 53 / A5T(+) 18 YL / K10E 18WH / A10E 18WH / B11A 18WH / CLEAN GROUND CONNECTION CH 27_10 / K5BA(+) 18 YL K5BA(-) 18 GN / CAN_HVCTRLS CH 27_6 / Figure 1488 / BODY AIR CONDITIONING HMI WITH 48CXZ & PB10E00

27.69. BODY AIR CONDITIONING 12V POWER FEED WITH 48CXZ & PB10E00, P. 66
Figure 1489 BODY AIR CONDITIONING 12V POWER FEED WITH 48CXZ & PB10E00

Wires (circuit gauge+color): AA10A 4WH
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.69. BODY AIR CONDITIONING 12V POWER FEED WITH 48CXZ & PB10E00, P. 66 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 22JUL21 / CHAPTER 27 BODY AIR CONDITIONING 12V POWER FEED W/48CXZ & W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / AA10A 4WH / FRONT A/C POWER PANEL GROUND (102) / AA10A 4WH / REAR A/C POWER PANEL GROUND (102) / FRAME GROUND (101) / FRONT A/C POWER PANEL POSITIVE FEED / CUBE FUSE 150A / REAR A/C POWER PANEL POSITIVE FEED / (VENDOR SUPPLIED CABLE) / (VENDOR SUPPLIED CABLE) / EXTERIOR COWL STUD / A/C POWER PANEL SOLENOID / 12V BATTERY / Figure 1489 / BODY AIR CONDITIONING 12V POWER FEED WITH 48CXZ & PB10E00

27.70. ADJUSTABLE PEDALS WITH PB10E00, P. 67
Figure 1490 ADJUSTABLE PEDALS WITH PB10E00

Components: BCM J4 (1601); MOTOR (9551); SPLICE PACK (1014A)
Wires (circuit gauge+color): A99-G 16WH; A99-GA 16TN; A99-GC 16WH; A99-GD 16WH; A99HA 16TN; A99HB 16TN; A99J 16TN; A99L 16TN; A99M 16WH
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.70. ADJUSTABLE PEDALS WITH PB10E00, P. 67 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 30JUL21 / CHAPTER 27 ADJUSTABLE PEDALS W/ PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE / GROUND SPLICE PACK #4 (1003) / PEDAL FORWARD RELAY (1010-R2) / A99-GA 16WH / A99K 16TN A99M 16TN / IGNITION SPLICE PACK (1014A) G / A99-GC 16WH / A99-GB 16WH / A99-G 16WH / A99-GD 16WH / PEDAL MOTOR (9551) / A99L 16TN / A99H 16TN / A99J 16TN / A99HA 16TN / BCM J4 (1601) / A99HB 16TN / PEDAL REARWARD RELAY (1010-R3) / Figure 1490 / ADJUSTABLE PEDALS WITH PB10E00

27.71. EV NOISE GENERATOR WITH PB10E00, P. 68
Figure 1491 EV NOISE GENERATOR WITH PB10E00

Components: ALARM/NOISE GEN (11548); INTERCONNECT EV (9513FE)
See also sheets: CH27_05, CH3_19
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.71. EV NOISE GENERATOR WITH PB10E00, P. 68 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 09AUG21 / CHAPTER 27 / EV NOISE GENERATOR W/PB10E00 / MJV0488 22SEP21 INITIAL PRODUCTION RELEASE. / A A / B13AZ 18 PK / B86FR2 18 LTGN B86FR1 18 LTGN B86RR2 18 LTGN B86RR1 18 LTGN / CAN HI 7 / B5AD(+) 18 YL B5AE(+) 18 YL B5AD(-) 18 GN B5AE(-) 18 GN ELEC PANEL/ SEALED ENGINE (11500) C8 / NOISE GENERATOR MODULE (14516) / FUSE B12-M (10301) CH3_19 / A5NB(+) 18 YL A5NA(+) 18 YL A5NB(-) 18 GN A5NA(-) 18 GN NOISE GENERATOR SPEAKER FRT (11549) 2 1 / CAN LO 1 / IGN 12 / PANEL/PLATFORM (1703) B12 / EV BACKUP ALARM/NOISE GEN (11548)/(9513EA) 2 / ABS FWD/REAR INTERCONNECT EV (9513FE)/(9513E) 17 / B11AA 18 WH / CAN_PT J1939 CH27_05 / R86DA 18 LTGN / NOISE GENERATOR REAR SPEAKER (9555E) / GROUND SPLICE (10337) / B5AC(+) 18 YL B5AC(-) 18 GN / Y86FR2 18 LTGN Y86FR1 18 LTGN Y86RR2 18 LTGN / Y86RR1 18 LTGN / R86CA 18 LTGN / M86DA 18 LTGN / M86CA 18 LTGN / Figure 1491 / EV NOISE GENERATOR WITH PB10E00

Figure 1492 HV BODY AIR CONDITIONING WITH 48CXZ AND PB10E00

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 27.72. HV BODY AIR CONDITIONING WITH 48CXZ AND PB10E00, P. 69 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10432 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093713 NO. 96275E 10AUG21 / CHAPTER 27 HV BODY AIR CONDITIONING W/48CXZ AND W/ PB10E00 / - UPDATED HV CABLE FOR LINE THICKNESS. / HVAC-R 1 / NEG 12BK / VFD FWD HV IN MULTI-CORE POS 12RD / VFD REAR HV IN MULTI-CORE POS 12RD / HVAC-F 1 / SCE HVAC-REAR / SCE HVAC-FRONT / NEG 12BK / POS 2 / POS 1 / NEG 2 / NEG 1 / Figure 1492 / HV BODY AIR CONDITIONING WITH 48CXZ AND PB10E00

Figure 1493 CONNECTOR COMPOSITE 1100F, 1100M, 110MA, 110MB

Components: FRONT MSD 3 (1100MA); MSD INLINE (1100F); MSD INLINE (1100M); REAR MSD 4 (1100MB)
Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / CONNECTOR COMPOSITE (1100F-14159) EV SYSTEMS CHAPTER 28 / 28.1. CONNECTOR COMPOSITE 1100F, 1100M, 110MA, 110MB, P. 1 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093712 NO. 96275D 26AUG21 / CHAPTER 28 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / CAV CIRCUIT 1 N193BD 2 N193BE / CONNECTOR 4110039C1 GAUGE COLOR TERMINAL SEAL/SLEEVE 16 GY 3830798C1 3509903C1 16 GY 3830798C1 3509903C1 / CAV CIRCUIT 1 N193BF 2 N193CD / GAUGE COLOR TERMINAL SEAL/SLEEVE 16 GY 3830798C1 3509903C1 16 GY 3830798C1 3509903C1 / CONNECTOR 3757488C1 CAV CIRCUIT GAUGE COLOR TERMINAL 1 N193BB 16 GY 382181C1 2 N193CB 16 GY 382181C1 / CONNECTOR 3757487C1 CAV CIRCUIT GAUGE COLOR TERMINAL 1 N193BB 16 GY 382181C1 2 N193CB 16 GY 382181C1 / MJV0488 10FEB22 UPDATED MSD NAMES. / MSD INLINE (1100F) (LOCATED ON MSD JUMPER HARNESS NEAR BMS S-BOX) / FRONT MSD 3 (1100MA) (LOCATED AT MSD MOUNTED OUTSIDE RIGHT FRAME RAIL) / REAR MSD 4 (1100MB) (LOCATED AT MSD MOUNTED OUTSIDE RIGHT FRAME RAIL) / CONNECTOR 4110039C1 / MSD INLINE (1100M) (LOCATED ON CHASSIS JUMPER HARNESS NEAR BMS S-BOX) / Figure 1493 / CONNECTOR COMPOSITE 1100F, 1100M, 110MA, 110MB

Table: CONNECTOR 3757487C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	N193BB	16	GY	382181C1
2	N193CB	16	GY	382181C1

Table: CONNECTOR 3757488C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	N193BB	16	GY	382181C1
2	N193CB	16	GY	382181C1

Table: CONNECTOR 4110039C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	N193BD	16	GY	3830798C1
2	N193BE	16	GY	3830798C1

Table: CONNECTOR 4110039C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	N193BF	16	GY	3830798C1
2	N193CD	16	GY	3830798C1

28.2. CONNECTOR COMPOSITE 1142, 1144, 1507, P. 2 | Figure 1494 CONNECTOR COMPOSITE 1142, 1144, 1507 | printed page 1494

Table: CONNECTOR 4062808C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	A28-G	20	WH	4062808C1
2	-	-	-	-
3	-	-	-	-
4	-	-	-	-
5	-	-	-	-
6	-	-	-	-
7	-	-	-	-
8	-	-	-	-
9	-	-	-	-
10	-	-	-	-
11	A5BA(-)	20	GN	4062808C1
12	A5BA(+)	20	YL	4062808C1
13	-	-	-	-
14	-	-	-	-
15	-	-	-	-
16	-	-	-	-
17	-	-	-	-
18	-	-	-	-
19	-	-	-	-
20	-	-	-	-
21	A28	20	TN	4062808C1
22	-	-	-	-
23	-	-	-	-
24	-	-	-	-
25	-	-	-	-
26	-	-	-	-
27	-	-	-	-
28	A5BA(-)	20	GN	4062808C1
29	A5BA(+)	20	YL	4062808C1
30	-	-	-	-
31	-	-	-	-
32	-	-	-	-
33	-	-	-	-
34	-	-	-	-
35	-	-	-	-
36	-	-	-	-
37	A28AA	20	TN	4062808C1
38	A5CA(-)	20	GN	4062808C1
39	A5CA(+)	20	YL	4062808C1
40	-	-	-	-

Table: CONNECTOR 3530563C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	-	-	-	-
2	A9KA	18	GY	1661224C1
3	A9PA	18	GY	1661224C1
4	-	-	-	-
5	A14HB	18	RD	1661224C1
6	A50	18	YL	1661224C1
7	A62-GB	18	WH	1661224C1
8	A62-FA	18	DKBL	1661224C1
9	-	-	-	-
10	-	-	-	-

Table: CONNECTOR 3530563C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	A9MA	18	GY	1661224C1
2	A9JA	18	GY	1661224C1
3	A9NA	18	GY	1661224C1
4	-	-	-	-
5	-	-	-	-
6	-	-	-	-
7	A62-GA	18	WH	1661224C1
8	A62-EA	18	DKBL	1661224C1
9	-	-	-	-
10	-	-	-	-

28.3. CONNECTOR COMPOSITE 1607, 1652, P. 3 | Figure 1495 CONNECTOR COMPOSITE 1607, 1652 | printed page 1495

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A1	-	-	-	-
A2	-	-	-	-
A3	A9NA	18	GY	3539904C1
A4	A9MA	18	GY	3539904C1
A5	-	-	-	-
A6	-	-	-	-
A7	-	-	-	-
A8	-	-	-	-
A9	-	-	-	-
A10	-	-	-	-
A11	-	-	-	-
A12	-	-	-	-
B1	-	-	-	-
B2	-	-	-	-
B3	-	-	-	-
B4	A9FAA	18	GY	3539904C1
B5	A9HAA	18	GY	3539904C1
B6	A9PA	18	GY	3539904C1
B7	-	-	-	-
B8	-	-	-	-
B10	-	-	-	-
B11	-	-	-	-
B12	-	-	-	-

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	A5PA(+)	18	YL	3544886C1
B	F5TB(+)	18	YL	3544886C1
C	A5VB(+)	18	YL	3544886C1
D	A98-GA	18	WH	3544886C1
E	A98-GB	18	WH	3544886C1
F	A5PA(-)	18	GN	3544886C1
G	A5TB(-)	18	GN	3544886C1
H	A5VB(-)	18	GN	3544886C1
J	A28AB	18	TN	3544886C1
K	A98C	18	VT	3544886C1

28.4. CONNECTOR COMPOSITE 1653, 1653A, P. 4
Figure 1496 CONNECTOR COMPOSITE 1653, 1653A

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 28.4. CONNECTOR COMPOSITE 1653, 1653A, P. 4 / THIS PRINT IS PROVIDED ON A RESTRICTED BASIS AND IS NOT TO BE USED IN ANY WAY DETRIMENTAL TO THE INTEREST OF NAVISTAR, INC. / ND10433 CIRCUIT DIAGRAM, BE,CE BUS RELEASE NO. PART AE08093712 NO. 96275D 26AUG21 / CHAPTER 28 CONNECTOR BODY COMPOSITE - MATING VIEW SHOWN / CAV CIRCUIT A A5VC(+) B PLUG C A5VC(-) / GAUGE COLOR TERMINAL SEAL/SLEEVE 18 YL 1667741C1 3568570C1 1687788C1 1667741C1 3568570C1 / CAV CIRCUIT A A5TA(+) B PLUG C A5TA(-) / CONNECTOR 1667741C1 GAUGE COLOR TERMINAL SEAL/SLEEVE 18 YL 1667741C1 3568570C1 1687788C1 1667741C1 3568570C1 / MJV0488 10FEB22 UPDATED DESCRIPTION FOR R/D'S 1653 AND 1653A. / C B A / EV TERMINATING RESISTOR (1653) (LOCATED IN INSTRUMENT PANEL NEAR DIAGNOSTIC CONN) / C B A / CONNECTOR 1667741C1 / EV HVCTRLS TERMINATING RESISTOR (1653A) (LOCATED IN INSTRUMENT PANEL NEAR DIAGNOSTIC CONN) / Figure 1496 / CONNECTOR COMPOSITE 1653, 1653A

Table: CONNECTOR 1667741C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	A5TA(+)	18	YL	1667741C1
B	PLUG			1687788C1
C	A5TA(-)	18	GN	1667741C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	A5VC(+)	18	YL	1667741C1
B	PLUG			1687788C1
C	A5VC(-)	18	GN	1667741C1

28.5. CONNECTOR COMPOSITE 1700E, P. 5 | Figure 1497 CONNECTOR COMPOSITE 1700E | printed page 1497

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	M64	14	YL	3549416C1
2	M52A	12	YL	3549415C1
3	M52B	12	YL	3549415C1
4	M53A	12	YL	3549415C1
5	M53B	12	YL	3549415C1
6	M56A	14	OR	3549416C1
7	M57A	14	OR	3549416C1
8	M58AA	14	BN	3549416C1
9	PLUG			3598922C1
10	PLUG			3598922C1
11	M152G	16	GY	3549416C1
12	M152H	16	GY	3549416C1
13	PLUG			3598922C1
14	M152A	16	GY	3549417C1
15	PLUG			3598921C1
16	M85A	16	GY	3549417C1
17	PLUG			3598921C1
18	M152B	16	GY	3549417C1
19	M59J	18	GY	3549418C1
20	M59K	18	GY	3549418C1
21	M59L	18	GY	3549418C1
22	M59M	18	GY	3549418C1
23	PLUG			3598921C1
24	M39C	14	BK	3549417C1
25	M87A	18	GY	3549418C1
26	PLUG			3598922C1
27	M87-G	18	GY	3549418C1
28	M39D	14	BK	3549417C1
29	M94E	14	GY	3549417C1
30	M5(+)	18	YL	3549418C1
31	M5(-)	18	GN	3549418C1
32	PLUG			3598921C1
33	M94LA	16	GY	3549417C1
34	M94LB	16	GY	3549417C1
35	M94RA	16	GY	3549417C1
36	M94RB	16	GY	3549417C1
37	PLUG			3598921C1
38	PLUG			3598921C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
39	M94BA	14	GY	3549417C1
40	M94BB	14	GY	3549417C1
41	M94BC	14	GY	3549417C1
42	M94BD	14	GY	3549417C1
43	M94BE	14	GY	3549417C1
44	M94BF	14	GY	3549417C1
45	M94A	16	GY	3549417C1
46	M94B	16	GY	3549417C1
47	M94C	16	GY	3549417C1
48	M94D	16	GY	3549417C1
49	PLUG			3598921C1
50	PLUG			3598921C1
51	PLUG			3598922C1
52	M94F	14	GY	3549417C1
53	M9	18	GY	3549418C1
54	M94H	14	GY	3549417C1
55	M94J	14	GY	3549417C1
56	M94K	14	GY	3549417C1
57	M94L	14	GY	3549417C1
58	M36	18	TN	3549418C1
59	M152C	18	RD	3549418C1
60	M152D	18	BK	3549418C1
61	M152(+)	18	YL	3549418C1
62	M152(-)	18	GN	3549418C1
63	M119A	16	VT	3549417C1
64	PLUG			3598922C1
65	PLUG			3598922C1
66	M119	16	VT	3549416C1
67	PLUG			3598922C1
68	PLUG			3598922C1
69	PLUG			3598922C1
70	PLUG			3598922C1
71	PLUG			3598922C1
72	PLUG			3598922C1
73	PLUG			3598922C1
74	PLUG			3598922C1
75	PLUG			3598922C1
76	PLUG			3598922C1

28.6. CONNECTOR COMPOSITE 1701, P. 6 | Figure 1498 CONNECTOR COMPOSITE 1701 | printed page 1498

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	PLUG			3598922C1
2	PLUG			3598922C1
3	PLUG			3598922C1
4	PLUG			3598922C1
5	PLUG			3598922C1
6	PLUG			3598922C1
7	PLUG			3598922C1
8	PLUG			3598922C1
9	PLUG			3598922C1
10	PLUG			3598922C1
11	K94B	10	GY	3549415C1
12	PLUG			3598922C1
13	PLUG			3598922C1
14	PLUG			3598921C1
15	PLUG			3598921C1
16	PLUG			3598921C1
17	PLUG			3598921C1
18	K77A	16	PK	3549417C1
19	PLUG			3598921C1
20	PLUG			3598921C1
21	K97H	18	PK	3549418C1
22	K71AA	18	PK	3549418C1
23	PLUG			3598921C1
24	K101AA	18	GY	3549418C1
25	PLUG			3598921C1
26	PLUG			3598922C1
27	K44	18	GY	3549418C1
28	K39D	18	GY	3549418C1
29	PLUG			3598921C1
30	K5X(+)	18	YL	3549418C1
31	K5X(-)	18	GN	3549418C1
32	PLUG			3598921C1
33	K13F	18	PK	3549418C1
34	PLUG			3598921C1
35	PLUG			3598921C1
36	PLUG			3598921C1
37	K5AX(+)	18	YL	3549418C1
38	K5AX(-)	18	GN	3549418C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
39	K5BA(+)	18	YL	3549418C1
40	K5BA(-)	18	GN	3549418C1
41	PLUG			3598921C1
42	K14B	16	RD	3549417C1
43	PLUG			3598921C1
44	PLUG			3598921C1
45	K5B(+)	18	YL	3549418C1
46	K5B(-)	18	GN	3549418C1
47	K97CC	18	VT	3549418C1
48	K97BB	18	VT	3549418C1
49	K99AA	18	VT	3549418C1
50	PLUG			3598921C1
51	K92AA	18	TN	3574277C1
52	K44C	18	GY	3549418C1
53	K10E	18	WH	3549418C1
54	K9A	18	PK	3549418C1
55	PLUG			3598921C1
56	PLUG			3598921C1
57	PLUG			3598921C1
58	PLUG			3598921C1
59	K97EE	18	VT	3549418C1
60	K14C	16	RD	3549417C1
61	PLUG			3598921C1
62	K97DD	18	VT	3549418C1
63	K99BB	18	VT	3549418C1
64	K101BB	18	GY	3574277C1
65	PLUG			3598922C1
66	PLUG			3598922C1
67	PLUG			3598922C1
68	PLUG			3598922C1
69	PLUG			3598922C1
70	PLUG			3598922C1
71	PLUG			3598922C1
72	PLUG			3598922C1
73	PLUG			3598922C1
74	PLUG			3598922C1
75	PLUG			3598922C1
76	PLUG			3598922C1

28.7. CONNECTOR COMPOSITE 1825, 1826, 1855, P. 7 | Figure 1499 CONNECTOR COMPOSITE 1825, 1826, 1855 | printed page 1499

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
C	A101AA	18	TN	1661777C1
D	A9BA	18	GY	1661777C1

Table: CONNECTOR 1661777C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
C	A101BB	18	TN	1661777C1
D	A9CAA	18	GY	1661777C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	A5K(-)	18	GN	3599009C1
2	A5K(+)	18	YL	3599009C1
3	PLUG			3518314C1
4	A92A	18	TN	3599009C1
5	A62J	18	DKBL	3599009C1
6	PLUG			3518314C1
7	PLUG			3518314C1
8	PLUG			3518314C1
9	A92-G	18	WH	3599009C1
10	PLUG			3518314C1
11	PLUG			3518314C1
12	PLUG			3518314C1
13	PLUG			3518314C1
14	PLUG			3518314C1
15	PLUG			3518314C1
16	PLUG			3518314C1
17	A92C	18	TN	3599009C1
18	PLUG			3518314C1
19	PLUG			3518314C1
20	PLUG			3518314C1
21	A92B	18	TN	3599009C1
22	PLUG			3518314C1
23	PLUG			3518314C1
24	PLUG			3518314C1

Legend: DRAWN ; ND10432 CIRCUIT DIAGRAM, BE,CE BUS ; RELEASE NO. DATE ; 96275D 09JUL21 AE08093712 007

28.8. CONNECTOR COMPOSITE 4015, 4041, 4210, 4212, 4215, P. 8
Figure 1500 CONNECTOR COMPOSITE 4015, 4041, 4210, 4212, 4215

Components: AIR ABS MAXI-FUSE (4041); AIR DRYER RELAY (4015); CABIN HT ENABLE RELAY (4215)

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
30	K14Z	12	RD	3519803C1
85	K39A-G	18	WH	4201397C1
86	K13F	18	PK	4201397C1
87	K39D	18	GY	4201397C1
87A	-	-	-	-

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	K14D	10	RD	3515522C1
B	K94B	10	GN	3515522C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	A77-GA	18	WH	872291R1
A	A77-G	18	WH	872291R1
B	A77A	16	PK	872291R1
B	A77B	18	PK	872291R1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	A77B	18	PK	4307694C1
2	A77-GA	18	WH	4307694C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
30	K14X	16	RD	3830798C1
85	K97ALL	16	VT	382182C1
86	K13R	18	PK	4201397C1
87	K13B	18	PK	1651988C1
87A	-	-	-	-

Figure 1501 CONNECTOR COMPOSITE 4220, 4221, 4222, 4905

Components: GLOBAL SWITCHED POWER A RELAY (4220); GLOBAL SWITCHED POWER B RELAY (4221); HVAC RELAY (4222); SOLENOID (4905)

Table: CONNECTOR 4243370C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
30	K14AE	18	RD	4201397C1
85	K97AFF	16	VT	382182C1
86	K13V	18	PK	4201397C1
87	K13W	18	PK	4201397C1
87A	-	-	-	-

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
30	K14AG	16	RD	3535326C1
85	K11N	16	WH	3535326C1
86	K97ALM	16	VT	3535326C1
87	K77A	16	PK	3535326C1
87A	-	-	-	-

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
30	K14AF	16	RD	3535326C1
85	K97AGG	16	VT	3535326C1
86	K13X	18	PK	4201397C1
87	K13Y	16	PK	3535326C1
87A	-	-	-	-

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	K44	18	GY	587578C1
B	K44C	18	GY	587578C1

28.10. CONNECTOR COMPOSITE 6020, 6022, 6023A, 6023B, P. 10
Figure 1502 CONNECTOR COMPOSITE 6020, 6022, 6023A, 6023B

Components: CABIN HEAT COOLANT LEVEL SENSOR (6020); HEAT PUMP PULL-DOWN RESISTOR (6023A); HEAT PUMP PULL-DOWN RESISTOR (6023B); OUTLET SENSOR (6022)

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	K34A	18	TN	1661875C1
B	K9G	18	GY	1661875C1
C	K13M	18	PK	1661875C1
D	K34B	18	TN	1661875C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	K97Y	18	PK	3535303C1
B	K11AA	18	WH	3535303C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	K6L	18	GY	4177728C1
2	K29EE	18	TN	4177728C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	K97Y	18	PK	3535303C1
B	K11AA	18	WH	3535303C1

28.11. CONNECTOR COMPOSITE 6025, P. 11 | Figure 1503 CONNECTOR COMPOSITE 6025 | printed page 1503

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	K14E	16	RD	3624234C1
2	K10F	16	WH	3624234C1
3	K14F	16	RD	3624234C1
4	K10G	16	WH	3624234C1
5	K14G	16	RD	3624234C1
6	K10H	16	WH	3624234C1
7	K97W	18	VT	3590745C1
8	K97AE	22	VT	4241465C1
9	K97V	22	VT	4241465C1
10	PLUG			4241462C1
11	PLUG			4241462C1
12	PLUG			4241462C1
13	PLUG			4241462C1
14	PLUG			4241462C1
15	PLUG			4241462C1
16	PLUG			4241462C1
17	PLUG			4241462C1
18	K97E	22	VT	4241465C1
19	K6G	22	GY	4241465C1
20	PLUG			4241462C1
21	PLUG			4241462C1
22	PLUG			4241462C1
23	K9FF	22	GY	4241465C1
24	K13H	22	PK	4241465C1
25	PLUG			4241462C1
26	PLUG			4241462C1
27	PLUG			4241462C1
28	PLUG			4241462C1
29	K97AJ	18	VT	3590745C1
30	PLUG			4241462C1
31	K39E	22	GY	4241465C1
32	PLUG			4241462C1
33	PLUG			4241462C1
34	PLUG			4241462C1
35	K101A	22	GY	4241465C1
36	K19B	22	GY	4241465C1
37	K29A	22	TN	4241465C1
38	K41A	22	TN	4241465C1
39	K29E	22	TN	4241465C1
40	K32A	22	TN	4241465C1
41	PLUG			4241462C1
42	K36BB	22	TN	4241465C1
43	K34AA	22	GY	4241465C1
44	PLUG			4241462C1
45	K36AA	22	TN	4241465C1
46	K9GG	22	GY	4241465C1
47	K97C	22	VT	4241465C1

Table: 4241464C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
48	PLUG			4241462C1
49	PLUG			4241462C1
50	PLUG			4241462C1
51	K97AF	18	VT	3590745C1
52	K19C	22	GY	4241465C1
53	PLUG			4241462C1
54	PLUG			4241462C1
55	PLUG			4241462C1
56	PLUG			4241462C1
57	K19D	22	GY	4241465C1
58	PLUG			4241462C1
59	PLUG			4241462C1
60	K19E	22	GY	4241465C1
61	PLUG			4241462C1
62	PLUG			4241462C1
63	K34BB	22	TN	4241465C1
64	K29B	22	TN	4241465C1
65	K101B	22	GY	4241465C1
66	K5DB(-)	22	LTGN	4241465C1
67	K5EB(-)	22	LTGN	4241465C1
68	K5XB(-)	22	LTGN	4241465C1
69	K5GB(-)	22	LTGN	4241465C1
70	K6J	22	GY	4241465C1
71	PLUG			4241462C1
72	K97B	22	VT	4241465C1
73	K97U	20	VT	3590743C1
74	PLUG			4241462C1
75	PLUG			4241462C1
76	K92A	22	TN	4241465C1
77	K99B	22	VT	4241465C1
78	K99A	22	VT	4241465C1
79	K9D	22	GY	4241465C1
80	PLUG			4241462C1
81	K97AG	22	VT	4241465C1
82	PLUG			4241462C1
83	K97AL	22	VT	4241465C1
84	PLUG			4241462C1
85	PLUG			4241462C1
86	K71A	22	PK	4241465C1
87	PLUG			4241462C1
88	K5DA(+)	22	YL	4241465C1
89	K5EA(+)	22	YL	4241465C1
90	K5XA(+)	22	YL	4241465C1
91	K5GA(+)	22	YL	4241465C1
92	PLUG			4241462C1
93	PLUG			4241462C1
94	K97D	22	VT	4241465C1

Labels: ELECTRICAL CIRCUIT DIAGRAM MANUAL / 28.12. CONNECTOR COMPOSITE 6027, 6028, 6030, P. 12 / Figure 1550 / CONNECTOR COMPOSITE 6027, 6028, 6030

28.12. CONNECTOR COMPOSITE 6027, 6028, 6030, P. 12
Figure 1550 CONNECTOR COMPOSITE 6027, 6028, 6030

28.13. CONNECTOR COMPOSITE 6035, 6036, 6038, 6041, P. 13
Figure 1505 CONNECTOR COMPOSITE 6035, 6036, 6038, 6041

Components: IN-1 INVERTER (6035); OBC1 BOTTOM (6041); RESISTOR (6037); RESISTOR (6038); VCU IGNITION DIODE (6036)

Table: CONNECTOR 3572899C1
CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	K5AV(+)	18	YL	1651988C1
2	K5AV(-)	18	GN	1651988C1
3	K13AC	18	PK	1651988C1
4	K11T	18	WH	1651988C1
5	PLUG			3527276C1
6	PLUG			3527276C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	PLUG			1688285C1
2	PLUG			1688285C1
3	PLUG			1688285C1
4	K13P	18	PK	2005483C1
5	PLUG			1688285C1
6	PLUG			1688285C1
7	K13Q	18	PK	2005483C1
8	K11E	18	WH	2005483C1
9	PLUG			1688285C1
10	PLUG			1688285C1
11	K98C	18	BK	2005483C1
12	K98C	18	BK	2005483C1
13	K11F	18	WH	2005483C1
14	K11G	18	WH	2005483C1
15	K11H	18	WH	2005483C1
16	PLUG			1688285C1
17	PLUG			1688285C1
18	PLUG			1688285C1
19	PLUG			1688285C1
20	PLUG			1688285C1
21	PLUG			1688285C1
22	K5M(-)	18	GN	2005483C1
23	K5M(+)	18	YL	2005483C1

Table: CONNECTOR 3991593C1
CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	PLUG			3527276C1
2	K13D	18	PK	1651988C1
3	K97H	18	PK	1651988C1
4	K13HH	18	PK	1651988C1

Table: CONNECTOR 4173578C1
CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	K97M	18	VT	3535303C1
B	K11B	18	WH	3535303C1

Table: CONNECTOR 4173578C1
CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	K97N	18	VT	3535303C1
B	K11C	18	WH	3535303C1

Figure 1506 CONNECTOR COMPOSITE 6042, 6050, 6055

Components: HVDU FRONT (6050); OBC2 TOP (6042)

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	*N5S(+)	18	YL	3727971C1
1	#K5S(+)	18	YL	3727971C1
2	*N5S(-)	18	GN	3727971C1
2	#K5S(-)	18	GN	3727971C1
3	*N10A	16	WH	3518963C1
3	#K10Q	16	WH	3518963C1
4	*N13E	18	PK	3727971C1
4	#K13D	18	PK	3727971C1
5	*N14H	16	RD	3518963C1
5	#K14P	16	RD	3518963C1
6	*N11Q	18	WH	3727971C1
6	#OCI_CHSS_GND	18	WH	3727971C1
7	PLUG			3527276C1
8	PLUG			3527276C1

Table: CONNECTOR 3677559C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	PLUG			1688285C1
2	PLUG			1688285C1
3	PLUG			1688285C1
4	K13N	18	PK	2005483C1
5	PLUG			1688285C1
6	PLUG			1688285C1
7	K13S	18	PK	2005483C1
8	K11M	18	WH	2005483C1
9	PLUG			1688285C1
10	PLUG			1688285C1
11	K98D	18	BK	2005483C1
12	K98D	18	BK	2005483C1
13	K11J	18	WH	2005483C1
14	K11K	18	WH	2005483C1
15	K11L	18	WH	2005483C1
16	PLUG			1688285C1
17	PLUG			1688285C1
18	PLUG			1688285C1
19	PLUG			1688285C1
20	PLUG			1688285C1
21	PLUG			1688285C1
22	K5N(-)	18	GN	2005483C1
23	K5N(+)	18	YL	2005483C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K193D	18	GY	1651988C1
2	K11D	16	WH	1651988C1
3	K19DD	18	GY	1651988C1
4	K19BB	18	GY	1651988C1
5	PLUG			3527276C1
6	K13B	18	PK	1651988C1
7	K97R	16	PK	1651988C1
8	K29D	18	TN	1651988C1
9	K29C	18	TN	1651988C1
10	K14M	18	RD	1651988C1
11	K97Q	18	VT	1651988C1
12	K97P	18	VT	1651988C1

28.15. CONNECTOR COMPOSITE 6055, 6057, 6058, 6060, P. 15
Figure 1507 CONNECTOR COMPOSITE 6055, 6057, 6058, 6060

Components: BTMS LV CONN (6058); COOLANT HEATER THERMAL SWITCH (6060); RADIATOR FAN MODULE (6057)

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	P5(+)	18	YL	3518961C1
2	P5(-)	18	GN	3518961C1
3	PLUG			3527276C1
4	P13	18	PK	3518961C1
5	P14	18	RD	3518961C1
6	PLUG			3527276C1
7	PLUG			3527276C1
8	PLUG			3527276C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K5AS(+)	18	YL	3693147C1
2	K5AS(-)	18	GN	3693147C1
3	PLUG			3577744C1
4	K13AB	18	PK	3693147C1
5	PLUG			3577744C1
6	PLUG			3577744C1
7	K10R	18	WH	3693147C1
8	K11S	18	BK	3693147C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	PLUG			3577744C1
2	K13A	18	PK	4086472C1
3	K5C(+)	18	YL	4086472C1
4	K5C(-)	18	GN	4086472C1
5	PLUG			3577744C1
6	K10A	18	WH	4086472C1
7	PLUG			3577744C1
8	PLUG			3577744C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	K29C	18	TN	1680205C1
2	K29D	18	TN	1680205C1

28.16. CONNECTOR COMPOSITE 6071, 6072, 6073, 6074, P. 16
Figure 1508 CONNECTOR COMPOSITE 6071, 6072, 6073, 6074

Components: CABIN HEAT PUMP 4-WAY (6071); CABIN HEAT PUMP 6-WAY (6072); PUMP 4-WAY (6073); PUMP 6-WAY (6074)

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	K98A	14	BK	500398C1
2	K74A-G	12	WH	500398C1
3	K74B	12	RD	500398C1
4	K74A	14	PK	500398C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	K5L(+)	18	YL	3727971C1
2	PLUG			3527276C1
3	K98AB	18	BK	3727971C1
4	PLUG			3527276C1
5	PLUG			3527276C1
6	K5L(-)	18	GN	3727971C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	PLUG			453133C1
2	K74B-G	12	WH	3841699C1
3	K74C	12	LTGN	3841699C1
4	K74D	14	PK	3841699C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	K5K(+)	18	YL	3727971C1
2	PLUG			3527276C1
3	PLUG			3527276C1
4	PLUG			3527276C1
5	PLUG			3527276C1
6	K5K(-)	18	GN	3727971C1

28.17. CONNECTOR COMPOSITE 6075, 6076, 6078, 6079, P. 17
Figure 1509 CONNECTOR COMPOSITE 6075, 6076, 6078, 6079

Components: CABIN HEAT INLET TEMP SENSOR (6079); POWER ELECTRONICS COOLA (6078); POWER ELECTRONICS COOLANT LEVEL SENSO (6076); SENSOR (6075)

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	K6B	18	GY	1661875C1
B	K41AA	18	TN	1661875C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	K36A	18	TN	1661875C1
B	K9F	18	GY	1661875C1
C	K13L	18	PK	1661875C1
D	K36B	18	TN	1661875C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	K6C	18	GY	4177728C1
2	K29BB	18	TN	4177728C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	K6A	18	GY	4177728C1
2	K29AA	18	TN	4177728C1

Figure 1510 CONNECTOR COMPOSITE 6075, 6076, 6078, 6079

Components: BMS S-BOX (6081)

Table: CONNECTOR 6113341C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	PLUG			3532129C1
2	PLUG			3532129C1
3	PLUG			3532129C1
4	K14W	16	RD	3830798C1
5	PLUG			3532129C1
6	PLUG			3532129C1
7	K14X	16	RD	3830798C1
8	PLUG			3532129C1
9	PLUG			3532129C1
10	PLUG			3532129C1
11	PLUG			3532129C1
12	PLUG			3532129C1
13	PLUG			3532129C1
14	PLUG			3532129C1
15	PLUG			3532129C1

Table: CONNECTOR 6113338C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	K74B	12	RD	6113343C1
2	PLUG			6113348C1
3	K14Z	12	RD	6113343C1
4	PLUG			6113348C1

Table: CONNECTOR 6132204C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	N14D	18	RD	4086472C1
2	N14E	18	RD	4086472C1
3	PLUG			3577744C1
4	N5F(+)	18	YL	4086472C1
5	N5F(-)	18	GN	4086472C1
6	PLUG			3577744C1
7	N5B(+)	18	YL	4086472C1
8	N5B(-)	18	GN	4086472C1
9	PLUG			3577744C1
10	N11D	18	BK	4086472C1
11	N11E	18	BK	4086472C1
12	PLUG			3577744C1
13	N97H	18	PK	4086472C1
14	PLUG			3577744C1
15	PLUG			3577744C1
16	PLUG			3577744C1
17	PLUG			3577744C1
18	PLUG			3577744C1

Table: CONNECTOR 6113341C1

CAV	CIRCUIT	GA	COLOR	TERMINAL
1	K14Q	12	RD	3830799C1
2	PLUG			3532129C1
3	PLUG			3532129C1
4	K14R	16	RD	3830798C1
5	PLUG			3532129C1
6	PLUG			3532129C1
7	K14S	16	RD	3830798C1
8	PLUG			3532129C1
9	PLUG			3532129C1
10	PLUG			3532129C1
11	PLUG			3532129C1
12	PLUG			3532129C1
13	PLUG			3532129C1
14	PLUG			3532129C1
15	PLUG			3532129C1

Legend: DRAWN ; ND10433 CIRCUIT DIAGRAM, BE, CE BUS ; RELEASE NO. DATE ; 96275D 27AUG21 AE08093712 018

28.19. CONNECTOR COMPOSITE 6084, 6085, 6086, P. 19
Figure 1511 CONNECTOR COMPOSITE 6084, 6085, 6086

Components: PDM2 MAXI-FUSE (6084)

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	K14T	10	RD	3752553C1
2	K14U	12	RD	6113343C1
3	K74C	12	LTGN	6113343C1
4	PLUG			6113348C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	N13C	18	PK	2005483C1
2	N11B	18	WH	2005483C1
3	N11C	18	WH	2005483C1
4	PLUG			1688285C1
5	N5D(+)	18	YL	2005483C1
6	N5D(-)	18	GN	2005483C1
7	N27A	18	TN	2005483C1
8	N27A-G	18	WH	2005483C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	N13D	18	PK	2005483C1
2	PLUG			1688285C1
3	PLUG			1688285C1
4	PLUG			1688285C1
5	N5E(+)	18	YL	2005483C1
6	N5E(-)	18	GN	2005483C1
7	N27B	18	TN	2005483C1
8	N27B-G	18	WH	2005483C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	N5J(+)	18	YL	3535303C1
B	N5J(-)	18	GN	3535303C1

28.20. CONNECTOR COMPOSITE 6090, 6091, P. 20
Figure 1512 CONNECTOR COMPOSITE 6090, 6091

Components: CHASSIS JUMPER INLINE 1 (6090); CHASSIS JUMPER INLINE 2 (6091)

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	K5P(+)	18	YL	3534162C1
B	K5P(-)	18	GN	3534162C1
C	K193E	18	GY	3534162C1
D	K32A	22	TN	3535299C1
E	K5H(+)	20	YL	3535299C1
F	K5H(-)	20	GN	3535299C1
G	K97W	18	VT	3534162C1
H	K13K	18	PK	3534162C1
J	K97S	18	VT	3534162C1
K	K97AE	22	VT	3535299C1
L	K13J	18	PK	3534162C1
M	K97K	16	PK	3534162C1
N	K19C	22	GY	3535299C1
P	K19E	22	GY	3535299C1
R	K5R(+)	18	YL	3534162C1
S	K5R(-)	18	GN	3534162C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	N5A(+)	18	YL	3534160C1
B	N5A(-)	18	GN	3534160C1
C	N6A	18	GY	3534160C1
D	PLUG			3535430C1
E	N5B(+)	18	YL	3534160C1
F	N5B(-)	18	GN	3534160C1
G	N97A	18	VT	3534160C1
H	N13A	18	PK	3534160C1
J	N97B	18	VT	3534160C1
K	N97C	18	VT	3534160C1
L	N13B	18	PK	3534160C1
M	N97D	18	VT	3534160C1
N	N19A	18	GY	3534160C1
P	N19B	18	GY	3534160C1
R	N5C(+)	18	YL	3534160C1
S	N5C(-)	18	GN	3534160C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	K6E	18	GY	3534160C1
B	K97J	16	VT	3534160C1
C	K9B	18	GY	3534160C1
D	K39E	22	GY	3535301C1
E	K14AA	12	RD	3534161C1
F	K14W	16	RD	3534160C1
G	K14C	16	RD	3534160C1
H	K97G	22	VT	3535301C1
J	K10Q	16	WH	3534160C1
K	K13D	18	PK	3534160C1
L	K14P	16	RD	3534160C1
M	K193B	18	GY	3534160C1
N	K193C	18	GY	3534160C1
P	PLUG			3535430C1
R	K11P	12	WH	3534161C1
S	K11Q	12	WH	3534161C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	PLUG			3535430C1
B	N97E	18	VT	3534162C1
C	N97F	18	GY	3534162C1
D	N39A	18	GY	3534162C1
E	N14A	16	RD	3534162C1
F	N14B	16	RD	3534162C1
G	N14C	16	RD	3534162C1
H	N97G	18	VT	3534162C1
J	N10A	16	WH	3534162C1
K	N13E	18	PK	3534162C1
L	N14HA	14	RD	3534162C1
M	N193B	16	GY	3534162C1
N	N193C	16	GY	3534162C1
P	PLUG			3535430C1
R	N11M	14	WH	3534163C1
S	N11A	14	WH	3534163C1

28.21. CONNECTOR COMPOSITE 6092, 6093, 6094, P. 21
Figure 1513 CONNECTOR COMPOSITE 6092, 6093, 6094

Components: MSD 1 (6093); MSD 2 (6094)

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	N14C	16	RD	3534162C1
2	N11F	18	WH	1680205C1
3	N19A	18	GY	3534160C1
4	N97G	18	VT	3534162C1
5	N97E	18	VT	3534162C1
6	N97D	18	VT	3534160C1
7	N13A	18	PK	3534160C1
8	N97M	18	VT	1680205C1
9	PLUG			3527276C1
10	N5H(+)	18	YL	3757932C1
11	N5H(-)	18	GN	3757932C1
12	N6C	18	GY	1680205C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	K193	18	GY	3830792C1
2	K193A	18	GY	3830792C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	K193A	18	GY	3830792C1
2	K193B	18	GY	3830792C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	PLUG			4243354C1
B	PLUG			4243354C1
C	N5L(-)	18	GN	4243353C1
D	N5L(+)	18	YL	4243353C1
E	N14F	18	RD	4243353C1
F	N14G	18	RD	4243353C1
G	N97J	18	VT	4243353C1
H	PLUG			4243354C1
J	N6D	18	GY	4243353C1
K	N19B	18	GY	3534160C1
L	N11G	18	WH	4243353C1
M	N11H	18	WH	4243353C1

28.22. CONNECTOR COMPOSITE 6095, 6096A, 6096B, 6097A, 6097B, P. 22 | Figure 1514 CONNECTOR COMPOSITE 6095, 6096A, 6096B, 6097A, 6097B | printed page 1514

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
C	N39A	18	GY	3534162C1
D	N97F	18	GY	3534162C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	N13F	18	PK	3535303C1
B	N11J	18	WH	3535303C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	N97N	18	VT	3535303C1
B	N11N	18	WH	3535303C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	N97L	18	VT	3535303C1
B	N11L	18	WH	3535303C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	N97P	18	VT	3535303C1
B	N11P	18	WH	3535303C1

28.23. CONNECTOR COMPOSITE 6098, 6740E, 7850, 7852, P. 23 | Figure 1515 CONNECTOR COMPOSITE 6098, 6740E, 7850, 7852 | printed page 1515

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	N97K	18	VT	3535303C1
B	N11K	18	WH	3535303C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	M11-GA	10	WH	1687847C1
B	M89-G	16	WH	2033819C1
C	PLUG			587579C1
D	M64-G	14	WH	2033816C1
E	M39C-G	14	WH	2033816C1
F	M39D-G	14	WH	2033816C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	P97A	18	VT	3518961C1
2	P97B	18	VT	3518961C1
3	P97C	18	VT	3518961C1
4	P97D	18	VT	3518961C1
5	P9A	18	GY	3518961C1
6	P97E	18	VT	3518961C1
7	P97F	18	VT	3518961C1
8	P97H	18	VT	3518961C1
9	P9B	18	GY	3518961C1
10	P9C	18	GY	3518961C1
11	P11	16	WH	3518961C1
12	P10	18	GY	3518961C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	P9E	18	GY	3518961C1
2	P9F	18	GY	3518961C1
3	P97J	18	VT	3518961C1
4	P97K	18	VT	3518961C1
5	P97L	18	VT	3518961C1
6	P9G	18	GY	3518961C1

Figure 1516 CONNECTOR COMPOSITE 7875, 8000, 9000, 9001

Components: OC1 MODULE (7875)

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A1	PLUG			4258267C1
A2	P97A	18	VT	4258264C1
A3	P97D	18	VT	4258264C1
A4	PLUG			4258267C1
B1	PLUG			4258267C1
B2	PLUG			4258267C1
B3	P9D	18	GY	4258264C1
B4	P97H	18	VT	4258264C1
C1	PLUG			4258267C1
C2	PLUG			4258267C1
C3	PLUG			4258267C1
C4	P9E	18	GY	4258264C1
D1	PLUG			4258267C1
D2	PLUG			4258267C1
D3	PLUG			4258267C1
D4	P9F	18	GY	4258264C1
E1	PLUG			4258267C1
E2	P5(+)	18	YL	4258264C1
E3	PLUG			4258267C1
E4	P9G	18	GY	4258264C1
F1	PLUG			4258267C1
F2	P5(-)	18	GN	4258264C1
F3	PLUG			4258267C1
F4	P97J	18	VT	4258264C1
G1	PLUG			4258267C1
G2	PLUG			4258267C1
G3	PLUG			4258267C1
G4	P97K	18	VT	4258264C1
H1	PLUG			4258267C1
H2	PLUG			4258267C1
H3	PLUG			4258267C1
H4	P97L	18	VT	4258264C1
J1	PLUG			4258267C1
J2	P97B	18	VT	4258264C1
J3	P13	18	PK	4258264C1
J4	PLUG			4258267C1
K1	PLUG			4258267C1
K2	P97C	18	VT	4258264C1
K3	PLUG			4258267C1
K4	PLUG			4258267C1
L1	PLUG			4258267C1
L2	P11	16	WH	4258266C1
L3	P97E	18	VT	4258265C1
L4	PLUG			4258268C1
M1	PLUG			4258267C1
M2	P10	18	GY	4258265C1
M3	P97F	18	VT	4258265C1
M4	P14	18	RD	4258265C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	N5M(+)	18	YL	3535303C1
B	N5M(-)	18	GN	3535303C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	M77	18	RD	2206584C1
2	M77-G	18	LTGN	2206584C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	M77	18	RD	3522190C1
2	M77-G	18	LTGN	3522190C1

28.25. CONNECTOR COMPOSITE 9101E, 9513E, P. 25
Figure 1517 CONNECTOR COMPOSITE 9101E, 9513E,

28.25. CONNECTOR COMPOSITE 9101E, 9513E, P. 25 | Figure 1517 CONNECTOR COMPOSITE 9101E, 9513E, | printed page 1517

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	R36	16	BK	3559037C1
B	R9	16	WH	3559037C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	M94A	16	GY	3559035C1
2	M94B	16	GY	3559035C1
3	M94C	16	GY	3559035C1
4	M94D	16	GY	3559035C1
5	M94E	14	GY	3559035C1
6	M94F	14	GY	3559035C1
7	M94H	14	GY	3559035C1
8	M94J	14	GY	3559035C1
9	M94K	14	GY	3559035C1
10	M94L	14	GY	3559035C1
11	M152A	16	GY	3559035C1
12	M152B	16	GY	3559035C1
13	M9	18	GY	3509874C1
14	M36	18	TN	3509874C1
15	M39C	14	BK	3559035C1
16	M39C-G	14	WH	3559035C1
17	M86CA	18	LT GN	3509874C1
18	M86DA	18	LT GN	3509874C1
19	M71A	16	LT BL	3559035C1
20	M71B	16	WH	3559035C1
21	PLUG			3532129C1
22	PLUG			3532129C1
23	PLUG			3532129C1
24	PLUG			3532129C1

28.26. CONNECTOR COMPOSITE 9513FE, 9545E, 9551, 9551, 9555E, 1010, P. 26 | Figure 1518 CONNECTOR COMPOSITE 9513FE, 9545E, 9551, 9551, 9555E | printed page 1518

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	R94A	16	GY	3559037C1
2	R94B	16	GY	3559037C1
3	R94C	16	GY	3559037C1
4	R94D	16	GY	3559037C1
5	R94E	14	GY	3559037C1
6	R94F	14	GY	3559037C1
7	R94H	14	GY	3559037C1
8	R94J	14	GY	3559037C1
9	R94K	14	GY	3559037C1
10	R94L	14	GY	3559037C1
11	R152A	16	GY	3559037C1
12	R152B	16	GY	3559037C1
13	R9	16	WH	3559037C1
14	R36	16	BK	3559037C1
15	R39C	14	BK	3559037C1
16	R39C-G	14	WH	3559037C1
17	R86CA	18	LT GN	3559036C1
18	R86DA	18	LT GN	3559036C1
19	R71A	16	LT BL	3559037C1
20	R71B	16	WH	3559037C1
21	PLUG			3532129C1
22	PLUG			3532129C1
23	PLUG			3532129C1
24	PLUG			3532129C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	R71AA	16	LT BL	2206584C1
2	R71BA	16	WH	2206584C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
A	A99J	16	TN	3925787C1
B	A99L	16	TN	3925787C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	R86CA	18	LT GN	382181C1
2	R86DA	18	LT GN	382181C1

Connector 10101: CONNECTOR 2206588C1 WEBASTO AUX HEATER CAV 1 1 4

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	B74BD	16	LTGN	1661539C1
2	B74CC	18	LTGN	1661539C2
3	B74DB	18	LTGN	1661539C3
4	-	-	-	-
5	B74AD	12	RD	2030386C1
6	B74A-GAA	12	WH	2030386C1

28.27. CONNECTOR COMPOSITE 10244C, 10245C, 10255A, 11548, P. 27 | Figure 1519 CONNECTOR COMPOSITE 10244C, 10245C, 10255A, 11548 | printed page 1519

Connector 10244C: EV WATER HEATER SWITCH 8 7 1 4
Table: CONNECTOR 3530563C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	-	-	-	-
2	B9KA	18	GY	1661224C1
3	B9FA	18	GY	1661224C1
4	-	-	-	-
5	-	-	-	-
6	-	-	-	-
7	B62GD	18	WH	1661224C1
8	B62D	18	DKBL	1661224C1
9	-	-	-	-
10	-	-	-	-

Connector 10255A: EV BOOSTER PUMP SWITCH 7 4 8 1
Table: CONNECTOR 3530563C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	-	-	-	-
2	B62GF	18	GY	1661224C1
3	-	-	-	-
4	-	-	-	-
5	B9JA	18	GY	1661224C1
6	B9HA	18	GY	1661224C1
7	B62GC	18	WH	1661224C1
8	B62CA	18	DKBL	1661224C1
9	-	-	-	-
10	-	-	-	-

Connector 10245C: 10 - - - - EV AUX COOLANT HEATER SWITCH 7 4 8 1
Table: CONNECTOR 3530563C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	-	-	-	-
2	B13JA	18	PK	1661224C1
3	B13KA	18	PK	1661224C1
4	-	-	-	-
5	-	-	-	-
6	-	-	-	-
7	B62GEA	18	WH	1661224C1
8	B62EA	18	DKBL	1661224C1
9	-	-	-	-
10	-	-	-	-

Connector 11548: EV BACKUP/NOISE GEN TO FWD CHASSIS
Table: CONNECTOR 3820176C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	Y86RR1	18	LT GN	3613771C1
2	Y86RR2	18	LT GN	3613771C1
3	Y71A	16	LT BL	3613770C1
4	Y71B	16	WH	3613770C1

28.28. CONNECTOR COMPOSITE 11549, 14510B, 14511, 14516, P. 28
Figure 1520 CONNECTOR COMPOSITE 11549, 14510B, 14511, 14516

Components: SPEAKER UNDERHOOD (11549)

Connector 11549: NOISE GENERATOR 1 SPEAKER UNDERHOOD HOOD SPEAKER)

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	Y86FR1	18	LT GN	3522190C1
2	Y86FR2	18	LT GN	3522190C1

Connector 14511: WEBASTO TIMER DIODE

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	B13KA	18	PK	1661538C1
2	B74CC	18	LTGN	1661538C1
3	B74CZ	18	LTGN	1661538C1

Connector 14510B: EV WEBASTO SMARTTEMP COMPARTMENT) 1 3

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	B74BD	16	LTGN	3545087C1
2	B74-GAA	16	WH	3545087C1
3	BP74CZ	18	LTGN	3902785C1
4	B74DB	18	LTGN	3902785C1

Connector 14516: NOISE GENERATOR MODULE
Table: CONNECTOR 4276424C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	B5AC(-)	18	GN	6721902C1
2	PLUG			6721904C1
3	B86FR2	18	LTGN	6721902C1
4	B86RR2	18	LTGN	6721902C1
5	PLUG			6721904C1
6	B11AA	18	WH	6721902C1
7	B5AC(+)	18	YL	6721902C1
8	PLUG			6721904C1
9	B86FR1	18	LTGN	6721902C1
10	B86RR1	18	LTGN	6721902C1
11	PLUG			6721904C1
12	B13AZ	18	PK	6721902C1

28.29. CONNECTOR COMPOSITE 14517, 14518, 14519, P. 29 | Figure 1521 CONNECTOR COMPOSITE 14517, 14518, 14519 | printed page 1521

Connector 14517: EV HVAC CONTROLLER

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	B11A	18	WH	4281719C1
2	B5AF(-)	18	GN	4281719C1
3	B5AF(+)	18	YL	4281719C1

Connector 14518: HVDC BY-PASS ELECTRICAL PANEL HARNESSES)

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	B14HD	18	RD	3573077C1
2	B14HVA	18	RD	3573077C1
3	-	-	-	-
4	-	-	-	-

Connector 14518: HVDC BY-PASS ELECTRICAL PANEL HARNESSES)
Table: CONNECTOR 4124472C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	A14HD	18	RD	3626441C1
2	A14HV	18	RD	3626441C1
3	-	-	-	-
4	-	-	-	-

Connector 14519: HVCNTRLS INTERCONNECT ELECTRICAL PANEL HARNESSES)

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	B5AG(+)	18	YL	3573077C1
2	B5AH(+)	18	YL	3573077C1
3	B5AG(-)	18	GN	3573077C1
4	B5AH(-)	18	GN	3573077C1

Connector 14519: HVCNTRLS INTERCONNECT ELECTRICAL PANEL HARNESSES)
Table: CONNECTOR 4124472C1

CAV	CIRCUIT	GAUGE	COLOR	TERMINAL
1	A5T(+)	18	YL	3626441C1
2	A5TAA(+)	18	YL	3626441C1
3	A5T(-)	18	GN	3626441C1
4	A5TAA(-)	18	GN	3626441C1