Action	Cable plugged in
Message Type	Port Status
Port StatusMessage Type	PORT_MOD
Port Config	all 0
Port Current	only 1000 full mode is 1, medium support,
	auto negotiation and pause support are 1
Port Advertised	mode are all 1 except 1000 half, pause support
	is 1,all other flags are 0
Port Supported	mode are all 1 except 1000 half, pause support,
	autoneg, asymmetric pause are 1, medium are
	all 0
Port Peer	mode are all 1 except 1000 half, pause support
	is 1, all other flags are 0

Action	Cable pulled out
Message Type	Port Status
Port Status	PORT_MOD
Port Config	all 0
Port State	No physical link
Port Current	mode are all 0, medium support, auto
	negotiation and pause support are 1
Port Advertised	the same as the message in (1)
Port Supported	the same as the message in (1)
Port Peer	all 0
notes	when the cable is pulled out, all changes to the
	port on switch do not trigger any message

Action	While cable is plugged in, change settings at the host end: set	
	autoneg to off, speed changed from 1000 to 100, duplex	
	changed from full to half	
Message#	Message 1	Message2
Message Type	Port Status	Port Status
Port Status	PORT_MOD	PORT_MOD
Port Config	all 0	all 0
Port State	No physical link	
Port Current	mode are all 0, medium	only mode 100 half is 1,
	support, auto negotiation and	medium support and autoneg
	pause support are 1	are 1
Port Advertised	the same as the message in (1)	the same as the message in (1)
Port Supported	the same as the message in (1)	the same as the message in (1)
Port Peer	all 0	mode has 10 half and 100 half
		and 1000 full be 1,all other
		flags are 0

notes	The first message has exactly the same flags as when cable is	
	pulled out, changing settings on host will cause link to go	
	down and up again.	

Action	While cable is plugged in, char	While cable is plugged in, change settings at the host end: set	
	autoneg back to on , speed o	autoneg back to on , speed changed back to 1000, duplex	
	changed back to full		
Message#	Message1	Message2	
Message Type	Port Status	Port Status	
Port Status	PORT_MOD	PORT_MOD	
Port Config	all 0	all 0	
Port State	No physical link		
Port Current	mode are all 0, medium	only mode 1000 full is 1,	
	support, auto negotiation are 1,	medium support, autoneg and	
		pause support are 1	
Port Advertised	the same as the message in (1)	the same as the message in (1)	
Port Supported	the same as the message in (1)	the same as the message in (1)	
Port Peer	all 0	mode has 10 half and 100 half	
		and 1000 full be 1,all other	
		flags are 0,pause support is 1	
notes	From these two actions, we can see that when a message coming and reports that a port is down, all flags are the same as it is up, only except that all current modes are set to		
	0.		

Action	While cable is plugged in, change settings on
	the switch, set autoneg to off
Message Type	Port Status
Port Status	PORT_MOD
Port Config	all 0
Port State	No physical link
Port Current	mode only has the current mode set, medium
	support, pause support are 1, autoneg is 0
Port Advertised	the same as the message in (1)
Port Supported	the same as the message in (1)
Port Peer	all 0
notes	Disable the autoneg will simply make the
	port down, then other changes do not
	trigger messages, until autoneg is reset.
	Changing speed causes the autoneg to
	become 0 as well and then becomes the same
	situation. When the autoneg is reset to 1, the
	following message is created

## 21697 23727

Action	set autoneg on swith port to 1
Message Type	Port Status
Port Status	PORT_MOD
Port Config	all 0
Port State	
Port Current	mode only has the current mode set, medium
	support, pause support and autoneg are 1
Port Advertised	the same as the message in (1)
Port Supported	the same as the message in (1)
Port Peer	mode has 10 half and 100 half and 1000 full be
	1,all other flags are 0,pause support is 1

Action	set the port on the host to down(using ifconfig down)	
Message#	Message1	Message2
Message Type	Port Status	Port Status
Port Status	PORT_MOD	PORT_MOD
Port Config	all 0	all 0
Port State	No physical link	
Port Current	mode are all 0, medium	only mode 1000 full is 1,
	support, auto negotiation and	medium support, autoneg and
	pause support are 1	pause support are 1
Port Advertised	the same as the message in (1)	the same as the message in (1)
Port Supported	the same as the message in (1)	the same as the message in (1)
Port Peer	all 0	mode has 10 half and 100 half
		and 1000 full be 1,all other
		flags are 0,pause support is 1

Action	disable the port on the switch
Message Type	Port Status
Port Status	PORT_MOD
Port Config	admin down is 1, all others are 0
Port State	
Port Current	mode only has the current mode set, medium
	support, pause support and autoneg are 1
Port Advertised	the same as the message in (1)
Port Supported	the same as the message in (1)
Port Peer	mode has 10 half and 100 half and 1000 full be
	1, all other flags are 0, pause support is 1
notes	When the port is enabled again, 1 message is
	generated, the only difference between
	messages about disabling and enabling the

## port is administratively down flag.

Action	disable the port on the switch
Message Type	Port Status
Port Status	PORT_MOD
Port Config	all are 0
Port State	No physical link
Port Current	all modes are 0, medium support, pause support
	and autoneg are 1
Port Advertised	the same as the message in (1)
Port Supported	the same as the message in (1)
Port Peer	all are 0

Action	change mtu on switch port
No message is created at all	