Soway 0-500PSI Pressure Transducer Wiring Instructions for 4-pin Hirschmann Connector

This instruction guide is provided for situations where the sensor was received un-wired, as a replacement for a broken sensor, or when the customer wishes to modify the length of a sensor cable.

Step 1: Disassemble the Connector

- Remove the central screw with a philips screwdriver
- Pull the connector housing off of the sensor
- Extract the screw terminal block from the housing



Step 2: Insert the 3-wire Cable


- Feed the cable through the cord grip
- Strip approximately 1.5 inches off of the outer cable jacket
- Strip approximately ¼ inch off of each of the three stranded wires



Step 3: Connect the wires to the screw terminals

- If your cable has Red/Black/White wires:
 - Connect the Red wire to Pin 1
 - Connect the Black wire to Pin 2
 - Connect the White wire to Pin 3
- If your cable has Black/Blue/Brown wires:
 - Connect the Black wire to Pin 1
 - Connect the Blue wire to Pin 2
 - Connect the Brown wire to Pin 3

Optional: apply dielectric grease to screw terminals to prevent corrosion in wet environments.



Step 4: Close and Tighten Connector Housing

- Insert the terminal block into the connector housing. The terminal block is keyed to fit in a specific orientation in the housing. Do not force it!
- Seat the terminal block and gasket onto the sensor, paying attention to the pin alignment.
- Thread and tighten the central screw through the assembly and tighten for a snug fit. Do not overtighten!
- Tighten the cord grip around the cable.

