

Left Steering Wheel Button
Audi 4F C6
Pin Assignments

White 9-pin connector directly on the button housing
Viewed from the outside
PCB is on the bottom, connector is on the right

Pin	Side	Function
1	Left	Incremental Encoder A
2		? Possibly LED ?
3		Incremental Encoder B
4		? Possibly LED ?
5		MODE Button
6		Incremental Encoder COM
7		? Possibly LED ?
8		? Possibly LED ?
9	Right	Incremental Encoder Button