Singing Bowl Components Connections



Uln2003 Motor Driver



Servo

		IN1	IN2	IN3	IN4	5V	Gnd	Signal	5V	Gnd
os D1	5V					X			Х	
	Gnd						Х			X
	D1	X								
	D2		Х							
	D3			Х						
	D4				X					



D5