



Product Contents

Verify that your DGE-550SX PCI-X 1000Base-SX Network A package contains the following items. If any items are missing, ple contact your reseller.

- D-Link DGE-550SX PCI-X 1000Base-SX Network Adapte
- Drivers, Manual, and Warranty on CD

System Requirements

Before installing the DGE-550SX, check your system for the following configuration requirements.

- Windows ® XP SP2, 2000 SP4, Vista [™], or 2003*
- CD-ROM Drive
- 20MB of Hard Disk Space
- 32-bit PCI Slot



Introduction

The D-Link DGE-550SX is a high-bandwidth network adapter, provided to 2000Mbps full-duplex bandwidth capacity to support high-end so this adapter delivers added performance to the network while wo with the existing LAN infrastructure. In addition, with advanced full like VLAN filtering and hardware-based Chip-Level IP (CLIP) paperocessing, the adapter provides added performance, flexible configurant secure networking to users in a standards-based environment. It is compact form, the DGE-550SX network adapter holds a Gigabit Ethe controller and a standard-based PCI/PCI-X interface with a fiber SC connector. Its front panel includes LEDs to indicate linkage and adstates.

The DGE-550SX network adapter can be installed in (short) 32-bit o (64-bit) PCI/PCI-X slots at 33MHz, 100MHz, or 133MHz. Best perfor however, is reached with a 64-bit/133MHz bus.

No pre-installation is required to setup the DGE-550SX network a simply insert it into the PCI/PCI-X slot. For more detailed informabout the network adapter and technical specifications, please rether manual located on the Autorun CD.



Step 1 - Driver Installation

Turn on your computer and insert the D-Link DGE-550SX Autorun Cl the CD-ROM drive.

Note: Do not install the adapter until you install the drivers.

If the Autorun CD function does not automatically start on your comp go to Start > Run. In the run command box type "D:\Autorun.exe" (w D: represents the drive letter of your CD-ROM drive).

When the autorun screen appears, click Install Drivers.

Drivers for non-Windows ® operating systems are located on the CD, and can be accessed via the View Other Drivers button.

Please see the section "Alternate Driver Installation" in the manual for detailed description on installing drivers for a specific operating sy



Step 2 - Hardware Installation

- A. Shut down the computer and unplug the power cord.
- B. Remove the chassis cover. If you are installing a network adapted a tower computer, we recommend to put the computer on its start order to be able to apply the correct force to insert the adapter into PCI/PCI-X slot.
- C. Locate an empty PCI or PCI-X slot on the motherboard.

Note: This adapter can be installed in (short) 32-bit or (long) 64 PCI/PCI-X slots at 33 MHz, 66 MHz, 100 MHz, or 133 MHz. performance, however, is reached with a 64-bit/133 MHz bus.

- D. Insert the network adapter into the PCI/PCI-X slot and push it of vertically into the slot until it is firmly seated.
- E. Install the bracket screw to secure the network adapter to the con chassis.
- F. Replace the computer chassis cover.
- G. Reconnect the power and switch the computer power on. If the B section of your computer's boot program is plug-and-play com then at power-up the BIOS will automatically configure any installed DGE-550SX Network Adapter.

Step 3 - Connecting the Network Ca

1000Base-SX Gigabit Ethernet enables operation over 50.0mm or 6 multimode fiber-optic cabling systems. With 62.5mm multimode fi cabling link lengths are limited to 275 m (max distance), 50.0mm multim fiber-optic cabling allows for link lengths of 550 m (max distance).



Notes



Notes



Technical Support

D-Link's website contains the latest user documentation an software updates for D-Link products.

U.S. and Canadian customers can contact D-Link Technica Support through our website or by phone.

United States

Telephone (877) 453-5465

World Wide Web http://support.dlink.com

Canada

Telephone (800) 361-5265

World Wide Web http://support.dlink.com