

# 18ECC204J DIGITAL SIGNAL PROCESSING- WEEK 2



### Syllabus Overview

- Learning Unit / Module 1: Signals and Waveforms
- Learning Unit / Module 2: Frequency Transformations
- Learning Unit / Module 3: FIR Filters
- Learning Unit / Module 4: IIR Filters
- Learning Unit / Module 5: Multirate signal Processing




### Learning Unit / Module 1: Signals and Waveforms

- Basic Elements of DSP , Advantages and applications of DSP
- Continuous Time vs Discrete time signals, Continuous valued vs discrete valued signals.
- Concepts of frequency in analog signals , Continuous and discrete time sinusoidal signals ,
- Sampling of analog signals Sampling theorem
- Aliasing Quantization of continuous amplitude signals,
- Analog to digital conversion Sample and hold, Quantization and coding
- Oversampling A/D converters , Digital to analog conversion Sample and hold
- Oversampling D/A converters, Quantization noise
- Errors due to truncation, Probability of error
- Errors due to rounding




### **Block Diagram of DSP**






### Illustration of Aliasing Effects





### A/D & D/A Conversion





### Analog to Digital (A/D) Conversion

Most signals of practical interest are analog in nature
 Examples: Voice, Video, RADAR signals,

 Transducer/Sensor output, Biological signals etc


 So in order to utilize those benefits, we need to convert our analog signals into digital

This process is called A/D conversion



### Analog to Digital Conversion

A/D conversion can be viewed as a three step process





### Analog to Digital Conversion

#### A/D conversion can be viewed as a three step process

- Sampling
  - Conversion from continuous-time, continuous valued signal to discrete-time, continuous-valued signal
- Quantization
  - Conversion from discrete-time, continuous valued signal to discrete-time, discrete-valued signal
- Coding
  - Conversion from a discrete-time, discrete-valued signal to an efficient digital data format



### Analog to Digital Conversion Sample & Hold (Sampler)

- Analog signal is continuous in time and continuous in amplitude.
- It means that it carries infinite information of time and infinite information of amplitude.
- Analog (continuous-time) signal has some value defined at every time instant, so it has infinite number of sample points.



### Analog to Digital Conversion Sample & Hold (Sampler)

- It is impossible to digitize an infinite number of points.
- The infinite points cannot be processed by the digital signal (DS) processor or computer, since they require an infinite amount of memory and infinite amount of processing power for computations.
- Sampling is the process to reduce the time information or sample points.



### Analog to Digital Conversion

#### Sample & Hold (Sampler)

- The first essential step in analog-to-digital (A/D) conversion is to sample an analog signal.
- This step is performed by a sample and hold circuit, which samples at regular intervals called sampling intervals.
- Sampling can take samples at a fixed time interval.
- The length of the sampling interval is the same as the sampling period, and the reciprocal of the sampling period is the sampling frequency fs.




### Analog to Digital Conversion

#### Sample & Hold (Sampler)

- After a brief acquisition time, during which a sample is acquired, the sample and hold circuit holds the sample steady for the remainder of the sampling interval.
- The hold time is needed to allow time for an A/D converter to generate a digital code that best corresponds to the analog sample.
- If x(t) is the input to the sampler, the output is x(nT), where T is called the sampling interval or sampling period.
- After the sampling, the signal is called "discrete time continuous signal" which is discrete in time and continuous in amplitude.



## Analog to Digital Conversion Sample & Hold (Sampler)






### Analog to Digital Conversion

### Sample & Hold (Sampler)


Figure below shows an analog (continuoustime) signal (solid line) defined at every point over the time axis (horizontal line) and





### Analog to Digital Conversion Sample & Hold (Sampler)

- Each sample maintains its voltage level during the sampling interval *T* to give the ADC enough time to convert it.
- This process is called sample and hold.





The sampling theorem guarantees that an analogue signal can be perfectly recovered as long as the sampling rate is at least twice as large as the highest-frequency component of the analogue signal to  $F_{s} \ge 2F_{\max}$  led.

 $\Box$  For a given sampling interval T, which is defined as the time span between two sample points, the sampling rate is therefore given by

$$f_s = \frac{1}{T}$$
 samples per second (Hz)

- □ Example
  - If a sampling period is  $T = 125 \,\mu s$ , the sampling rate is  $f_s = 1/125 \,\mu s = 8,000 \,\text{samples per second (Hz)}$ .



#### **Examples**

□ In order to sample a voice signal containing frequencies up to 4 KHz, we need a sampling rate of 2\*4000 = 8000 samples/second

Similarly for sampling of sound with frequencies up to 20 KHz, we need a sampling frequency of 2\*20000 = 40000 samples/second



Example: For the following analog signal, find the Nyquist sampling rate, also determine the digital signal frequency and the digital signal

The maximum frequency component is x(t) is

$$F_{\text{max}} = \frac{70\pi}{2\pi} = 35 \text{ Hz}$$

Therefore according to Nyquist, we need a sampling rate of

$$F_{\rm s} = 2F_{\rm max} = 70 \ Hz$$

The digital signal would have a frequency

$$w = 2\pi \frac{35}{70} = \pi$$


The digital signal can be represented as

$$x[n] = 3\cos(\pi n)$$



#### Example: Find the sampling frequency of the following signal.

$$s(t) = 3 \cdot \cos(50 \pi t) + 10 \cdot \sin(300 \pi t) - \cos(100 \pi t)$$



So sampling frequency should be

 $f_{\rm S}$  > 300 Hz



#### **Exercise**

### Determine the Nyquist sampling rate of a signal

 $x(t) = 3\sin(5000\pi t + 17^{\circ})$ 



How fast must we sample \*a continuous signal to preserve its info content?

Ex: train wheels in a movie.

25 frames (=samples) per second.

Train starts wheels 'go' clockwise.

Train accelerates wheels 'go' counter-clockwise.



Frequency misidentification due to low sampling frequency.





#### How many hertz can the human eye see?

Most don't notice unless it is under 50 or 60 Hz.


- Generally, people notice when the frame-rate is less than the refresh rate of the display.
- Depending on the type of CRT, you couldn't see flicker at 30
   Hz or you could still see it at 120 Hz.



- When the minimum sampling rate is not respected, distortion called aliasing occurs.
- Aliasing causes high frequency signals to appear as lower frequency signals.
- To be sure aliasing will not occur, sampling is always preceded by low pass filtering.
- The low pass filter, called the anti-aliasing filter, removes all frequencies above half the selected sampling rate.




- Figure illustrates sampling a 40 Hz sinusoid
- The sampling interval between sample points is T = 0.01 second, and the sampling rate is thus fs = 100 Hz.





- Figure illustrates sampling a 90 Hz sinusoid
- The sampling interval between sample points is T = 0.01 second, and the sampling rate is thus fs = 100 Hz.






### Aliasina

- Based on the sample amplitudes labeled with the circles in the second plot
  - We cannot tell whether the sampled signal comes from sampling a 90-Hz sine wave (plotted using the solid line) or from sampling a 10-Hz sine wave (plotted using the dot-dash line).
  - They are not distinguishable.
  - Thus they are aliases of each other.
  - We call the 10-Hz sine wave the aliasing noise in this case, since the sampled amplitudes actually come from sampling the 90-Hz sine wave.


#### Sampling condition is not satisfied





Sampling Effect in Time Domain


Example of Aliasing in the time domain of various sinusoidal signals ranging from 10 kHz to 80 kHz with a sampling frequency Fs = 40 kHz.






### Time & Frequency Domains There are two complementary signal descriptions.


- Signals seen as projected onto time or frequency domains.






### Signal & Spectrum





(b) One-Sided Spectrum of Signal



(c) Two-Sided Spectrum of Signal



### Frequency Range of Analog & Digital Signals

For analog signals, the frequency range is from -∞ Hz to
 ∞ Hz

 For digital signals, the frequency range is from 0 Hz to Fs/2 Hz



### Sampling Effect in Frequency Domain

 Sampling causes images of a signal's spectrum to appear at every multiple of the sampling frequency fs.

• For a signal with frequency f, the sampled spectrum has frequency components at  $kfs \pm f$ 



- Anti Aliasing Filter

  A signal with no frequency component above a certain maximum frequency is knówn as a band-limited signal.
  - In our case we want to have a signal band-limited to ½ Fs.
  - Some times higher frequency components (both harmonics and noise) are added to the analog signal (practical signals are not band-limited).
  - · In order to keep analog signal band-limited, we need a filter, usually a low pass that stops all frequencies above ½ Fs.
  - This is called an "Anti-Aliasing" filter.



### Anti Aliasing Filter

Anti-aliasing filters are analog filters.

They process the signal before it is sampled.

 In most cases, they are also low-pass filters unless bandpass sampling techniques are used.



### **Under Sampling**

If the sampling rate is lower than the required Nyquist rate, that is  $f_S < 2W$ , it is called *under sampling*.

 In under sampling images of high frequency signals erroneously appear in the baseband (or Nyquist range) due to aliasing.



# Sampling of Band Limited Signals

Signals whose frequencies are restricted to a narrow band of high frequencies can be sampled at a rate similar to twice the Bandwidth (BW) instead of twice the maximum frequency.

Fs ≥ BW



# Sampling of Band Limited Signals White this under-sampling is normally avoided, it can be exploited.


- For example, in the case of band limited signals all of the important signal characteristics can be deduced from the copy of the spectrum that appears in the baseband through sampling.
- Depending on the relationship between the signal frequencies and the sampling rate, spectral inversion may cause the shape of the spectrum in the baseband to be inverted from the true s

100

200 f, kHz



## Sampling of Band Limited Signals





# Over Sampling


• Oversampling is defined as sampling above the minimum Nyquist rate, that is,  $f_s > 2f_{max}$ .

 Oversampling is useful because it creates space in the spectrum that can reduce the demands on the analog anti-aliasing filter.




- Over Sampling

   In the example below, 2x oversampling means that a low order analog filter is adequate to keep important signal information intact after sampling.
  - After sampling, higher order digital filter can be used to extract the information



(a) Analog Filtering Before Sampling



(b) Digital Filtering After Sampling



- Over Sampling
  The ideal filter has a flat pass-band and the cutoff is very sharp, since the cut-off frequency of this filter is half of that of the sampling frequency, the resulting replicated spectrum of the sampled signal do not overlap each other. Thus no aliasing occurs.
  - Practical low-pass filters cannot achieve the ideal characteristics.
  - Firstly, this would mean that we have to sample the filtered signals at a rate that is higher than the Nyquist rate to compensate for the transition bar Lowpass filter



Spectra of Sampled signals






Figure: Signal 's Spectra


- (i) Over sampled
- (ii) Nyquest Rate
- (iii) Under Sampled








### Sampling Low Pass Signals



(a) Band-limited signal: frequencies in [-B, B] (f<sub>MAX</sub> = B).

 $f_S > 2 B \implies$  no aliasing.



(c)  $f_S \le 2B \implies aliasing!$ 

Aliasing: signal ambiguity in frequency domain



### Exercise

Exercise-1: If the 20 kHz signal is under-sampled at 30 kHz, find the aliased frequency of the signal.

Exercise-2: A voice signal is sampled at 8000 samples per second.

- i. What is the time between samples?
- ii. What is the maximum frequency that will be recovered from the signal?

Exercise-3: An analog Electromyogram (EMG) signal contains useful frequencies up to 3000 Hz.

- i. Determine the minimum required sampling rate to avoid aliasing.
- ii. Suppose that we sample this signal at a rate of 6500 samples/s. what is the highest frequency that can be represented uniquely at this sampling rate?



# Analog to Digital Conversion Quantizer

- After the sampling, the discrete time continuous signal still carry infinite information (can take any value) in terms of amplitude.
- Quantization is the process to reduce infinite information of the amplitude.
- Quantizer do the conversion of discrete time continuous valued signal into a discrete-time discretevalue signal.
- The value of each signal sample is represented by a value selected from a finite set of possible values.



# Analog to Digital Conversion Quantizer

 The A/D converter chooses a quantization level for each analog sample.

- Number of levels of quantizer is equal to L = 2<sup>N</sup>
- An N-bit converter chooses among 2<sup>N</sup> possible quantization levels.

 So 3 bit converter has 8 quantization levels, and 4 bit converter has 8 quantization levels.



## Analog to Digital Conversion

The quantization step size or resolution is calculated as:

$$\Delta = Q = R/2^N$$

where


**R** is the full scale range of the analog signal (i.e.  $Y_{max} - Y_{min}$ ) **N** is the number of bits used by the converter

- Resolution of a quantizer is the distance between two successive quantization levels
- More quantization levels, a better resolution!
- What's the downside of more quantization levels?

The strength of the signal compared to that of the quantization errors is measured by dynamic range and signal-to-noise ratio.




# Analog to Digital Conversion 4-bit Quantizer





# Analog to Digital Conversion 4-bit Quantizer





### **Quantization Error**

 The error caused by representing a continuous-valued signal (infinite set) by a finite set of discrete-valued levels.

- The larger the number of quantization levels, the smaller the quantization errors.
- The quantization error is calculated as the difference between the quantized level and the true sample level.
- Most quantization errors are limited in size to half a quantization step Q or  $\Delta$  .



### **Quantization Error**

 Suppose a quantizer operation given by Q(.) is performed on continuous-valued samples x[n] is given by Q(x[n]), then the quantization error is given by


$$e_q[n] = x[n] - x_q[n]$$



### Analog to Digital Conversion

Lets consider the signal which is to be quantized.

$$x[n] = \begin{cases} 0.9^n & n \ge 0 \\ 0 & n < 0 \end{cases}$$



In the figure, we can see that there is a difference between the original signal (Blue Line) and the quantized signal (Red Lines). This is the error produced while quantization



# Analog to Digital Conversion Quantization error can be reduced, however,

Quantization error can be reduced, however, if the number of quantization levels is

increase 4 3-bit ADC Quant. error 8-bit ADC Quant. error




# Analog to Digital Conversion Quantization of unipolar data (maximum

error = full step)

#### Unipolar Quantizer


unipolar quantizer with deals analog signals ranging from 0 volt to positive reference voltage.





# Analog to Digital Conversion Quantization of unipolar data (maximum

error = half step)






Analog to Digital Conversion Example: Analog pressures are recorded using a pressure

Example: Analog pressures are recorded using a pressure transducer as voltages between 0 and 3 V. The signal must be quantized using a 3-bit digital code. Indicate how the analog voltages will be covered to digital values.

The quantization step size is

$$Q = 3 V/2^3 = 0.375 V$$

The half of quantization step is 0.1875 V






# Analog to Digital Conversion Quantization of bipolar data (maximum error

= half step)


Bipolar Quantizer

A bipolar quantizer deals with analog signals ranging from a negative reference to a positive reference





# Three-bit A/D Conversion





## Dynamic Range

- Quantization errors can be determined by the quantization step.
- Quantization errors can be reduced by increasing the number of bits used to represent each sample.
- Unfortunately these errors can not be entirely eliminated and their combined effect is called quantization noise.
- The dynamic range of the quantizer is the number of levels it can distinguish in noise.
- It is a function of the range of signal values and the range of error values, and is expressed in decibels, dB.
- Dynamic Range =  $20log_2\left(\frac{R}{Q}\right)$



## Signal-to-Quantization-Noise Ratio

 Provides the ratio of the signal power to the quantization noise (or quantization error)

$$Pq = \frac{1}{N} \sum_{n=0}^{N-1} (e_q[n])^2 = \frac{1}{N} \sum_{n=0}^{N-1} (x[n] - x_q[n])^2$$

Mathematically,


$$SQNR_{dB} = 10\log_{10}\left(\frac{P_x}{P_q}\right)$$

#### where

- $P_x$ = Power of the signal 'x' (before quantization)
- $P_q$ = Power of the error signal ' $x_q$ '




# Analog to Digital Conversion






## Digital-to-Analog (D/A) Conversion

#### **Block Diagram of D/A Conversion**







# Digital-to-Analog (D/A) Conversion

- Once digital signal processing is complete, digital-toanalog (D/A) conversion must occur.
- This process begins by converting each digital code into an analog voltage that is proportional in size to the number represented by the code.
- This voltage is held steady through zero order hold until the next code is available, one sampling interval later.
- This creates a staircase-like signal that contains frequencies above W Hz.
- These signals are removed with a smoothing analog low pass filter, the last step in D/A conversion.




## Digital-to-Analog (D/A) Conversion

- In the frequency domain, the high frequency elements present in the zero order hold signal appear as images, copies of the original signal spectrum situated around integer multiples of the sampling frequency.
- The smoothing analog filter removes these images and so is given the name of Anti-Imaging Filter.
- Only the frequencies in the baseband, between 0 and f<sub>S</sub>/2 Hz, remain.




# Digital-to-Analog (D/A) Conversion Three bit D/A Conversion






### Comparing Signals in the A/D & D/A Chain




(a) Original Signal with Reconstructed Signal in Background




(b) Sample-and-Hold Signal with Original Signal in Background



### Comparing Signals in the A/D & D/A Chain



(c) Zero Order Hold Signal with Sample-and-Hold Signal in Background



(d) Reconstructed Signal with Zero Order Hold Signal in Background



## Summary

- An analog signal is continuous in both time and amplitude. Analog signals in the real world include current, voltage, temperature, pressure, light intensity, and so on. The digital signal contains the digital values converted from the analog signal at the specified time instants.
- Analog-to-digital signal conversion requires an ADC unit (hardware) and a lowpass filter attached ahead of the ADC unit to block the high-frequency components that ADC cannot handle.
- The digital signal can be manipulated using arithmetic. The manipulations may include digital filtering, calculation of signal frequency content, and so on.



## Summary

- The digital signal can be converted back to an analog signal by sending the digital values to DAC to produce the corresponding voltage levels and applying a smooth filter (reconstruction filter) to the DAC voltage steps.
- Digital signal processing finds many applications in the areas of digital speech and audio, digital and cellular telephones, automobile controls, vibration signal analysis, communications, biomedical imaging, image/video processing, and multimedia.




### **Review Questions**

- a. What is Aliasing
- b. Compare undersampling and oversampling




### ANSWERS Sampling Low Pass Signals



(a) Band-limited signal: frequencies in [-B, B] (f<sub>MAX</sub> = B).

 $f_S > 2 B \implies$  no aliasing.



(c)  $f_S \le 2B \implies aliasing!$ 

Aliasing: signal ambiguity in frequency domain



#### References:

- https://wiki.seg.org/wiki/Frequency\_aliasing
- https://sciencing.com/calculate-alias-frequency-8619254.html#:~:text=Aliasing%20is%20an%20undesired %20effect,of%20a%20much%20higher%20frequency.
- National Instruments; Bandwidth, Sample Rate, and Nyquist Theorem; Sep 6, 2006
- Sound on Sound: Q. What is 'Aliasing' and What's the Cause of It?