

Install Arduino Drivers on Windows 8


If you are reading this article you have probably already discovered that installing the drivers for an Arduino on Windows 8 is not straight forward. If you follow through the instructions on Arduino's official website (http://arduino.cc/en/Guide/windows) you will receive the error message "The driver is not digitally signed". Surely this is a warning? No, Microsoft thinks differently.



In order to install the driver you will need to disable driver signature enforcement. To do this, open the charms bar and click **Change PC Settings**. Then go to **General** and under **Advanced Startup and** click **Restart Now.** This will obviously restart your computer so make sure you have saved any work.



When the computer starts up click **Troubleshoot**












Then Advanced Options



From the next menu select Startup Settings and then Restart



The screen displayed allows you to "Disable driver signature enforcement" by pressing key 7.










What are the different AWS Services?






great instructions. We even learned stuff along the way...like Windows 8 is even more terrible that we originally

thought. Thanks!

In Flag Share

MichaelFrancisAyapana Thanks!



Like Reply

PRIVACY POLICY COMMENT POLICY LEGAL TERMS OF USE

×









© 2011 - 2014 Wheal Media Limited - All Rights Reserved

"MyTechBlog" is a registered trademark of Wheal Media Limited