CSE3421 Computer Architecture

Performance metrics

Xiaodong Zhang

What is Performance?

- Three ways to measure a computer system
 - Response time: the time between the start and completion of a task (often measured by a user)
 - In economics: completion time for a product (e.g. the assembly line of Ford in 1913)
 - Throughput: number of tasks completed in a time unit
 - In economics: productivity (related to efficiency)
 - Resource consumption: resource used to complete task
 - For example, a kernel context switch uses 1348 CPU cycles on a 2.86GHz P4 processor
 - In economics: cost or expense of production (related to investment)



Performance Metrics

- Provide a basis for comparison and a metric for evaluation
- Purchasing perspective
 - □ given a collection of machines, which has the
 - best performance?
 - least cost?
 - best cost/performance?
- Design perspective
 - ☐ faced with design options, which has the
 - best performance improvement?
 - best cost/performance?
 - A planning question: Should Intel design chips with 32 "wimpy" (500 MHz) cores or 4 "beefy" (3GHz) cores?
- □Our goal is to understand what factors in the architecture contribute to overall system performance and the relative importance (and cost) of these factors

Performance questions

- How do the following changes affect response time, throughput, and power consumption?
 - Increasing the processor clock rate by 2X for an application that calculates derivatives
 - CPU Throughput and Power up, Response time down
 - Adding an additional processor for the derivative calculator
 - CPU Response time, Throughput and Power up
 - Implementing a faster algorithm to compute derivatives
 - Throughput up, CPU Power and Response time down
 - Adding an additional processor for a web crawler
 - Response Time and Throughput and CPU Power up
 - Efficient algorithms design is most powerful
- Why additional resources degrade performance?
 - Cost of process coordination, context switch, low parallelism...

Defining (Speed) Performance

■Maximizing performance => to minimize execution time

If X is n times faster than Y, then

Decreasing response time almost always improves throughput

A Relative Performance Example

□ If computer A runs a program in 10 seconds and computer B runs the same program in 15 seconds, how much faster is A than B?

A Relative Performance Example

□ If computer A runs a program in 10 seconds and computer B runs the same program in 15 seconds, how much faster is A than B?

We know that A is n times faster than B if

The performance ratio is
$$\begin{array}{r} 15 \\ ---- \\ 10 \end{array} = 1.5$$

So A is 1.5 times faster than B

Time units and data size units

- ☐ Time units in the computing world
 - 1 millisecond (ms) = 10⁻³ second
 - 1 microsecond (us) = 10⁻⁶ second
 - 1 nanosecond (ns) = 10⁻⁹ second
 - 1 picosecond (ps) = 10⁻¹² second
 - 1 femtosecond (fs) = 10⁻¹⁵ second
 - 1 attosecond (as) = 10⁻¹⁸ second
- Data size units in the computing world
 - 1 kilobyte (KB) = 10³ bytes
 - 1 megabytes (MB) = 10⁶ bytes
 - 1 gigabytes (GB) = 10⁹ bytes
 - 1 terabytes (TB) = 10¹² bytes
 - 1 petabytes (PB) = 10¹⁵ bytes
 - 1 exabytes (EB) = 10^{18} bytes
 - 1 zettabyte (ZB) = 10²¹ bytes

cse 3421 • 1 yottabyte (YB) =10²⁴ bytes

Basic Computing Unit: Clock Rate and Cycle Time

□Clock rate (clock cycles per second in MHz or GHz) is inverse of clock cycle time (clock period)

Increasing the number of transistors on chip, reducing the cycle time, Why?

CSE 3421 the higher transistor density, the lower interconnection delay Slide:

The Core Model of CPU Execution Time

- □CPU execution time (or CPU time): time the CPU spends working on a task
 - □ Does not include time waiting for I/O or running other programs

or

□Can improve performance by reducing either the length of the clock cycle or the number of clock cycles required for a program

Improving Performance Example

□ A program runs on computer A with a 2 GHz clock in 10 seconds. What clock rate must computer B run at to run this program in 6 seconds? Unfortunately, to accomplish this, computer B will require an additional 1.2 times as many clock cycles.

$$CPU time_{A} = \frac{\# CPU clock cycles_{A}}{clock rate_{A}}$$

$$\# CPU clock cycles_{A} = 10 sec x 2 x 10^{9} cycles/sec$$

$$= 20 x 10^{9} cycles$$

$$CPU time_{B} = \frac{1.2 \times 20 \times 10^{9} cycles}{clock rate_{B}}$$

$$clock rate_{B} = \frac{1.2 \times 20 \times 10^{9} cycles}{6 seconds} = 4 GHz$$

Why Computer B needs more cycles?

Slide: 11

Improving Performance Example

□Computer C has a clock rate of 3 GHz and will require only 1.05 as many clock cycles as computer A. How long will the program take?

$$CPU time_{A} = \frac{\# CPU clock cycles_{A}}{clock rate_{A}}$$

$$\# CPU clock cycles_{A} = 10 sec \times 2 \times 10^{9} cycles/sec$$

$$= 20 \times 10^{9} cycles$$

$$CPU time_{C} = \frac{1.05 \times 20 \times 10^{9} cycles}{clock rate_{C}}$$

$$= \frac{21 \times 10^{9} cycles}{3 \times 10^{9} cycles/sec} = 7 seconds$$

Extending the Model: Clock Cycles per Instruction

- ■Not all instructions take the same amount of time to execute
 - One way to think about execution time is that it equals the number of instructions executed multiplied by the average time per instruction

CPU clock cycles = # Instructions x Average clock cycles for a program = for a program x per instruction

- □Clock cycles per instruction (CPI) the average number of clock cycles each instruction takes to execute
 - ☐ A way to compare two different implementations of the same ISA

	CPI for this instruction class			
	A	В	O	
CPI (#cycles)	1	2	3	

Slide: 13

Effective (Average) CPI

Computing the overall effective CPI is done by looking at the different types of instructions and their individual cycle counts and averaging

Overall effective CPI =
$$\sum_{i=1}^{n} (CPI_i \times IC_i)$$

- ☐ Where IC_i is the percentage of instructions of class i executed
- □ CPI_i is the (average) number of clock cycles per instruction for that instruction class
- □ n is the number of instruction classes
- □ The overall effective CPI varies by instruction mix a measure of the dynamic frequency of instructions across one or many programs

What similar formula do you use all the time?

$$GPA = \sum_{i=1}^{n} (Grade_i \times %CH_i)$$

Slide: 14

Comparing CPI

- Performance analysis rule: Conclusive experiments vary according to only 1 factor: CPI is machine dependent.
 - Can we compare the CPI of loading Firefox on Intel P4 Northwood to loading Firefox on a Sun Niagara? What does it tell us?
 - No, we cannot compare CPIs between architectures
 - Can we compare the CPI of loading Firefox to the CPI of loading Internet Explorer on the same machine?
 Yes.

Comparing CPI in the same architecture

□Computers A and B share the same architecture design. Computer A has a clock cycle time of 250 ps (picosecond, 10⁻¹²) and an effective CPI of 2.0 for a program and computer B has a clock cycle time of 500 ps and an effective CPI of 1.2 for the same program. Which computer is faster and by how much?

Each computer executes the same number of instructions, *I*, so

CPU time_A =
$$I \times 2.0 \times 250 \text{ ps} = 500 \times I \text{ ps}$$

CPU time_B = $I \times 1.2 \times 500 \text{ ps} = 600 \times I \text{ ps}$

Clearly, A is faster ... by the ratio of execution times

The Performance Equation

□Our basic performance equation is then

- ☐ These equations separate the three key factors that affect performance
 - ☐ Can measure the CPU execution time by running the program
 - ☐ The clock rate is usually given
 - ☐ Can measure overall instruction count by using profilers/ simulators without knowing all of the implementation details
 - □ CPI varies by instruction type and hardware design for which we must know the implementation details

Compiler Benefits in Today's Processor

- Comparing performance for bubble (exchange) sort
 - ☐ To sort 100,000 words with the array initialized to random values on a Pentium 4 with a 3.06 GHz clock rate, with 2 GB DRAM memory, using Linux version 2.4.20

gcc opt	Relative performance	Clock cycles (M)	Instr count (M)	CPI
None	1.00	158,615	114,938	1.38
O1 (medium)	2.37	66,990	37,470	1.79
O2 (full)	2.38	66,521	39,993	1.66
O3 (proc mig)	2.41	65,747	44,993	1.46

☐ The unoptimized code has the best CPI, the O1 version has the lowest instruction count, but the O3 version offers the best mix, O2 is ranked second.

CSE 3421 The execution time represents the final performance Slide: 18

What does a compiler do for optimization?

- Eliminate redundant instructions
- Reordering the sequence of instructions
- Selecting effective instructions (not necessarily low CPIs)
- Grouping data accesses to reuse the cache

• ...

Determinates of CPU Performance

CPU time = Instruction_count x CPI x cycle_time

	Instruction _count	CPI	clock_cycle
Algorithm	X	X	
Programming language	X	X	
Compiler	X	X	
Instruction Set	X	X	
Organization (pipeline, etc.)		X	X
Chip technology			X

A Simple Example

Ор	Freq	CPI _i	Freq x CPI _i
ALU	50%	1	
Load	20%	5	
Store	10%	3	
Branch	20%	2	
			$\Sigma =$

How much faster would the machine be if a better data cache reduced the average load time to 2 cycles?

How does this compare with using branch prediction to shave a cycle off the branch time?

What if two ALU instructions could be executed at once?

A Simple Example

Ор	Freq	CPI _i	Freq x	(CPI _i			
ALU	50%	1		.5	.5	.5	.25
Load	20%	5		1.0	.4	1.0	1.0
Store	10%	3		.3	.3	.3	.3
Branch	20%	2		.4	.4	.2	.4
	•		$\Sigma =$	2.2	1.6	2.0	1.95

How much faster would the machine be if a better data cache reduced the average load time to 2 cycles?

CPU time new = $1.6 \times IC \times CC$ so $2.2/1.6 \times IC \times CC$ means 37.5% faster

How does this compare with using branch prediction to shave a cycle off the branch time?

CPU time new = $2.0 \times IC \times CC$ so $2.2/2.0 \times IC \times CC$

What if two ALU instructions could be executed at once?

CPU time new = 1.95 x IC x CC so 2.2/1.95 means 12.8% faster


Power

Intel 80386 (1985) 12-40 MHz, consumed ~ 2 W

3.3 GHz Intel Core i7 consumed 130 W 2009

Heat must be dissipated from chips

This is the limit of what can be cooled by air



Reducing Power and/or Energy

Techniques for reducing power:

Dynamic Voltage-Frequency Scaling (adjustment)

Low power state for DRAM, disks (sleeping mode)

Over-clocking – increasing clock rate of a computing unit, but turning off other computing units (cores) for low power and high efficiency

Performance beyond formulas

Linear (proportional) relationships on the same CPU running the same number of instructions:

- Overall effective CPI and execution time (the lower CPI, the lower execution time)
- # instructions / second and the execution performance (the higher #I/s, the higher perf)
- Execution time is determined by weights (percentages) of different classes of instructions, such as data-intensive (high percentages of Load/Store instructions), computing-intensive (high percentages of ALU instructions)