4.6 HALLCDWRITESTRINGVALUEVALUE() 6
4.6.1 Description 6
4.6.2 Prototype 6
4.6.3 Parameter Details 6
4.6.4 Return 6
4.7 HALLCDDISPLAYPERCENTBAR() 7
4.7.1 Description 7
4.7.2 Prototype 7
4.7.3 Parameter Details 7
4.7.4 Return .....
4.8 CONSTANTS .....
4.8.1 Options 7

LED SERVICE .....

5.1 HALLEDINIT 7
5.1.1 Description 7
5.1.2 Prototype 7
5.1.3 Parameter Details 8
5.1.4 Return .....

6.2.1 Description *10*
6.2.2 Prototype *11*
6.2.3 Parameter Details *11*
6.2.4 Return *11*
6.3 HALKEYREAD() 11
6.3.1 Description *11*
6.3.2 Prototype *11*
6.3.3 Parameter Details *11*
6.3.4 Return *11*
6.4 HALKEYENTERSLEEP() 11

9.5.1 Description *22*

```
void HalTimerInit (void)
```

8.4.3 Parameter Details

None.

8.4.4 Return

None.

8.5 HalTimerConfig()

8.5.1 Description

This function allows the channels to be configured in different modes.

8.5.2 Prototype

```
halTimerStatus_t HalTimerConfig ( uint8 timerId,
                                  uint8 opModem(is fu)T1
```

8.9 HalTimerInterruptEnable()

8.9.1 Description

This function will enable or isable timer interrupt of e timerId and ch nelMode.

8.9.2 Prototype

```
uint8 HalTimerInterruptEnable ( uint8 timerId,
                                uint8 channelMode,
                                bool enable );
```

8.9.3 Parameter Details

`timerId` – HAL_TIMER_X, identification of the timer. Di processorsupport different numbers of timers. (See TimerId Table)

channelMode - The channel mode, Input Capture Mode, Output Comp

8.10.3 Channel Modes

Channel Mode

HAL_TIMER_16_TC_EXT

```
uint16 maxBufSize;
```

hol

9.3.4 Return

None.

9.4 HalUARTRead ()

9.4.1 Description

This function reads a buffer from the UART. The number of bytes to be read is determined by the application. If the requested length is larger than the Rx Buffer, then the requested length will be adjusted to the Rx buffer length and e whole Rx buffer is returned together with the adju length. If the requested length is smaller than the Rx buffer length, then only requested length buffer is sent back. The Rx buffer will be updated after the requested buffer is sent back. The function returns the length of the data if it is successful

9.6 HalUARTPoll()

9.9.2 Prototype

```
void Hal_UART_FlowControlSet  (uint8 port,
                               uint8 status);
```

9.9.3 Parameter Details

port - specified serial port, for which flo

11.1 Hal12CInit ()