# 14.Electronic password lock

## **ABOUT THIS PROJECT:**

## You will learn:

How to make a electronic password lock

1. Things used in this project:

1. Things used in this project:		
Hardware components	Picture	Quantity
V-1 board Breadboard		1 PCS
Dicadoodid	‡ <u></u> ‡	
Battery button (you need to buy 9V battery yourself)		1 PCS
Breadboard power module		1 PCS
Male to Male DuPont Cable		12 PCS
30 CM USB Cable		1 PCS
SS8050 Transistor		1 PCS
IN4148 diode		1 PCS
Active buzzer		1 PCS
4*4 membrane button		1 PCS
F3 Red LED Light		1 PCS
220R Resistance	(11111)	2 PCS

1

#### 2.Overview

This experiment is an extension of Lesson 13, adding resistors and LED lights, and its circuitry is a bit more complicated. In the experiment, if you enter the correct password in the 4\*4 matrix keyboard, the LED in the circuit will light up.

\*: Re-enter password

#:confirm password

For example, the initial setting password is 123456. After entering the 123456 password on the 4\*4 matrix keyboard, press the # key again and the LED will light.

## 3. Experiment of electronic password lock


Copy the keypad library file to the libraries folder in the IDE installation directory.

#### 3.1 Sketch


```
#include <Keypad.h>
#define buzzer 11
#define led 10
const byte ROWS = 4; //four rows
const byte COLS = 4; //four columns
//define the cymbols on the buttons of the keypads
char hexaKeys[ROWS][COLS] = {
  {'1','2','3','A'},
  {'4','5','6','B'},
  {'7','8','9','C'},
  \{'*','0','\#','D'\}
byte rowPins[ROWS] = \{2, 3, 4, 5\}; //connect to the row pinouts of the keypad
byte colPins[COLS] = \{6, 7, 8, 9\}; //connect to the column pinouts of the keypad
//initialize an instance of class NewKeypad
Keypad customKeypad = Keypad( makeKeymap(hexaKeys), rowPins, colPins, ROWS, COLS);
char passWord[7]="123456";
char temp password[7]="
int count=0;
void setup(){
  Serial.begin(9600);
  pinMode(led,OUTPUT);
  setPwmFrequency(11, 8);
void loop(){
  char customKey = customKeypad.getKey();
  if (customKey){
    analogWrite(buzzer,30);
    if(count<=5 && customKey!='#' && customKey!='*')
       temp password[count]=customKey;
    count++;
    if(count \ge 100)
        count=100;
    delay(100);
    analogWrite(buzzer,0);
    Serial.println(customKey);
  if(customKey=='#'){
                           //confirm password
    int a=0:
```

```
for(int b=0;b<6;b++){
       if(temp password[b]==passWord[b])
         a=a+1;
  if(a==6)
    digitalWrite(led,HIGH);
  count=0;
  if(customKey=='*'){
                         //reset password
    for(int c=0;c<6;c++){
       temp password[c]=' ';
    count=0;
    digitalWrite(led,LOW);
void setPwmFrequency(int pin, int divisor) {
  byte mode;
  if(pin == 5 || pin == 6 || pin == 9 || pin == 10) 
    switch(divisor) {
       case 1: mode = 0x01; break;
       case 8: mode = 0x02; break;
       case 64: mode = 0x03; break;
       case 256: mode = 0x04; break;
       case 1024: mode = 0x05; break;
       default: return;
    if(pin == 5 || pin == 6) {
       TCCR0B = TCCR0B & 0b11111000 | mode;
       TCCR1B = TCCR1B & 0b111111000 | mode;
  \} else if(pin == 3 || pin == 11) {
    switch(divisor) {
       case 1: mode = 0x01; break;
       case 8: mode = 0x02; break;
       case 32: mode = 0x03; break;
       case 64: mode = 0x04; break;
       case 128: mode = 0x05; break;
       case 256: mode = 0x06; break;
       case 1024: mode = 0x7; break;
       default: return;
    TCCR2B = TCCR2B & 0b11111000 | mode;
```

#### 3.2 Wiring Diagram




#### **Detail enlargement**




## **3.3 Step**


3.3.1 Connect the computer and V-1 board with a USB cable and copy the above sample code to the Arduino IDE as shown below:



#### 3.3.2 Select board type




#### 3.3.3 Select port



#### 3.3.4 Compiling

```
coded lock | Arduino 1.8.5
                                                                                 X
File Edit Sketch Tools Help
          oded_lock
#Include (Keypad. h)
#define buzzer 11
#define led 10
const byte ROWS = 4; //four rows
const byte COLS = 4; //four columns
//define the cymbols on the buttons of the keypads
char hexaKeys[ROWS][COLS] = {
  {'1', '2', '3', 'A'},
  {'4', '5', '6', 'B'},
  {'7','8','9','C'},
  {'*','0','#','D'}
}:
byte rowPins[ROWS] = {2, 3, 4, 5}; //connect to the row pinouts of the keypad
byte colPins[COLS] = {6, 7, 8, 9}; //connect to the column pinouts of the keypad
//initialize an instance of class NewKeypad
Keypad customKeypad = Keypad ( makeKeymap (hexaKeys), rowPins, colPins, ROWS, COLS);
char passWord[7]="123456";
char temp_password[7]="
int count=0;
  -13 ----- (\)
Done compiling.
ketch uses 3590 bytes (11%) of program storage space. Maximum is 32256 bytes
Global variables use 349 bytes (17%) of dynamic memory, leaving 1699 bytes for local variable
```

#### 3.3.5 Upload the sketch



#### 3.3.6 Result

Unplug the USB cable from the V-1 board, connect the power module to the external power supply, and then turn on the switch of the power module on the breadboard. entering the 123456 password on the 4\*4 matrix keyboard, press the # key again and the LED will light.

