

How to restart the router

SOP-003: Restart the router

This guide provides users with steps on how to restore an internet connection by restarting the router.

Please ensure you have gone through this guide intended for non-technical users before contacting IT Support.

1. Issue

Internet connection is unavailable or unstable, and devices cannot access the network.

2. Solution

1. Locate the router power cable connected to the electrical outlet.
2. Unplug the router power cable from the wall outlet.



2.a)

3. Wait 30 seconds before reconnecting the power cable.
4. Plug the router power cable back into the wall outlet.

5. Allow the router several minutes to fully restart.

6. Wait until the router status light changes:

Orange – Router is starting up and not yet connected.

White – Router is fully connected and ready to use.



6.a)

7. **Verify** that the issue is resolved:

- Router status light is white
- Internet connection is restored
- Websites load successfully on a connected device

3. Prevention Best Practices

- Keep the router plugged into a reliable power source.
- Avoid unplugging the router unless instructed by IT Support or while troubleshooting.
- Place the router in a well-ventilated area to prevent overheating.
- Do not place objects on top of the router, as they may block airflow.

Contact IT Support if:

- Router status light does not turn white after 5 minutes.
- The router repeatedly loses connection.
- Physical damage to the router or cables is visible.

Version	Date	Author	Changes
1.0	June 2026	Coleton Vowles	Initial release