Introduction to QAM and OFM

Colin P . Chaney

Amplitude Modulation Model




Figure 1: Symbol model of amplitude modulation

- $ullet f_{BB}(t)$: Base-band Signal (low frequency user input)
- $f_c(t)$: Carrier Signal (high frequency carrier)

$$f_{out}(t) = f_{BB}(t) \cdot f_c(t)$$

Equation 1: Mathematical model of amplitude modulation

Amplitude Modulation – Time Domain Example

