

User Manual

EMO AI Desktop Pet

living.ai

Introduction of EMO

Meet EMO, your new desk buddy built-in with multiple sensors and cutting-edge technology to bring a vibrant personality to your workspace. This sleek, stylish desk robot is designed to engage and entertain with over 1,000 unique expressions and movements.

EMO is here to cheer you up with music, dance and games. And he can do more-Like waking you up in the morning, taking photos and answering your questions. It's like having a lifelike pet right on your desk.

EMO features a striking design with a chic purple and indigo-blue finish inspired by pop culture, giving him a fashionable edge that complements any setting.

Experience the perfect blend of technology and personality with EMO-where your desk gets a touch of life.

Get to know EMO



Speech recognition far field mic-array

Stroke and touch sensor

AI face recognition camera

Stroke and touch sensor

ToF LiDAR scanner

4 smart digital servos to move

4 optical drop sensors

5W wireless charger

What's included



EMO X 1



Adapter X 1



Smart Light X 1




User Manual X 1



Wireless Charger X 1

Preparation for EMO's arrival

1. A tidy and spacious table, Light colors are better than dark ones.



Tables with rounded edges are not recommended.



2. A 2.4G WIFI (5G is not supported) connected to the internet.



3. Install EMO app from App Store or Google Play.



EMO in his new home



Power EMO up. (Align EMO's feet with the charging coil by magnetic force).



Connect EMO with the APP and config the network for EMO.



EMO explores his new home.




Let EMO have a rest.

Some interactions with EMO




1 Pick EMO up.



2 Touch EMO's head.



3 Shake EMO to dizziness.



4 Carefully push EMO to
the edge of the table.



5 Get in the way of EMO.



6 Let EMO lay down.

Call EMO his name

Try to call "EMO" correctly to wake up EMO, it's "EE" + "moh"(2 syllables).

Try to wake him up while he's charging, wandering or sleeping, at least 10 times. Gradually master the skill of waking up him until he responds every time you call him "EMO".



Ask EMO to show skills



EMO, what's the weather!



EMO, it's my birthday.



EMO, play by yourself.



EMO, take a photo.



EMO, set a ten second timer.



EMO, go to sleep.

Introduce yourself to EMO

You can build a relationship with EMO by saying hello.

You can say:

"EMO, nice to meet you".

After the first greeting, if EMO is ready to know you, he will ask your name. You can answer like this:

"EMO, my name is Andy".

If EMO is not ready to know you, don't worry, you can spend more time playing with him.



Enjoy music with EMO

EMO is a super singer and dancer.

He can sing and dance by himself, or dance to external music.

You can say:

EMO, music!

EMO, dance for me!



You can also say:


EMO, listen to the music.

EMO will sing and dance by himself.


Then you can play the music on your phone.
EMO will dance follow the beat.

Play games with EMO

Connect to the App and unlock interactive games designed for EMO on your phone.



Angry EMO



Dance repeat

The number and types of games will increase over time.



Drop the beat



Treasure hunt

EMO Smart Light

Insert the light into the socket.
Touch the panel to control the light
switch.



Support up to 4 lights, RGB colors.

Touch for 5 seconds to enter pairing
mode. EMO will connect the smart
light automatically.



Support manual touch mode.

Important Tips:

- Keep EMO dry and clean.
- Do not forcibly rotate EMO's servos.
- EMO contains delicate parts, please handle it with care.
- Keep EMO away from heat sources, fire, and direct sunlight.
- Avoid squeezing, dropping, or subjecting EMO to violent collisions.

Problems	Possible Causes	Solution
Can not connect to WiFi or WiFi connection not stable.	1. Your WiFi is 5G WiFi, EMO only support 2.4G WiFi for now. 2. Your WiFi has no password. EMO doesn't support WiFi without password for security concerns. 3. Your WiFi password is too complicated.	1. Connect EMO to 2.4G WiFi. 2. Set a simple password for your WiFi.
EMO speaks intermittently.	Unstable WiFi connection.	Try to connect EMO to a stable WiFi or use your phone's hotspot.
EMO has no reaction when I touch it.	Insufficient contact area or too little touch pressure.	Please try to increase the contact area and add more pressure when touching EMO.

Get more help at living.ai/support/ or contact us at service@living.ai

EMOPET

Product name: EMO Desk Robot

Product model: EMO 1

Product dimensions: 95x67x118mm

Manufacturer: Living Technology Co., Ltd.

Made in China