WELCOME

Thank you for choosing MythToy. The Slate is designed for minimalist pleasure, combining powerful vibrations with a discreet, architectural form.

PRODUCT ANATOMY

- Precision Head: Fixed silicone tip for targeted play.
- Power Button: Integrated control.
- Charging Port: Pinhole DC port (on the base/back).

QUICK START

CHARGE

(1) Connect: Insert the pin-style charging cable into the small port.
(2) Status: The LED light flashes while charging and turns solid when full. (Approx. 60 mins)
(3) Note: Please handle the cable with care.

ACTIVATE

Press and hold the Power Button for 3 seconds to turn on.

EXPLORE

Short press the button to cycle through 10 vibration patterns.

POWER OFF

Press and hold for 3 seconds.

CARE & MAINTENANCE

- Water Resistance: The Slate is Splash-proof (IPX6). It can be cleaned with a damp cloth or rinsed quickly under water. Do not submerge.
- Cleaning: Wash with warm water and mild soap.
- Storage: Keep in the velvet pouch to protect the matte finish.

SPECIFICATIONS

Product Name: The Slate
Material: ABS + Silicone Tip
Size: 118 x 26 mm
Net Weight: 63g
Battery: Li-ion Polymer
Charging Time: 60 Minutes
Run Time: Up to 70 Minutes
Max Noise: < 40dB

WARRANTY

1-Year MythToy Warranty.
Support: support@mythtoy.com