> POWER SOURCE 12 V DC, 3A

> RELAY 1A 30V DC

PIN	Description
1	Wiegand Data0
2	Wiegand Data1
3	Wiegand GND
4	INT BAT GND
5	INT BAT +5V
6	Not Connected
7	Door Relay NO
8	Door Relay NC
9	Door Relay COM
10	Fault Relay NO
11	Fault Relay NC
12	Fault Relay COM
13	Not Connected
14	GND
15	Inactive (Fire) (NO)
16	GND
17	PIR (NC)
18	GND
19	Exit Button (NO)
20	GND
21	CM (NC)
22	- 12V
23	+12V

Cable

Color Description Position Wiegand Data0 R1 R2 Wiegand Data1 Wiegand GND R3 R4 - 12V R5 +12V R6 **Not Connected** R7 Door Relay NO R8 Door Relay NC R9 Door Relay COM R10 Fault Relay NO Fault Relay NC **R11** Fault Relay COM R12 **Not Connected** R13 GND1 verde R14 Inactive / Fire (NO) R15 a-verde albastru R16 GND2 R17 PIR (NC) a-albastru R18 GND3 maro R19 Exit Button (NO) a-maro R20 GND4 portocaliu R21 Magnetic Contact (NC) a-porto R22 **TAMPER** R23 **TAMPER** R24 **GROUND**