MALE STATIC v2 / CONTINUOUS WIRING

Revision D reading copy | Same circuit and physical pin numbers | No label-based connections

Shared supply rails

J7 / RACK

DA-15 connector

Pins grouped

by function

DXL DATA

12 V

+5 V

GND

SHELL / PAD 0

PHOTOSENSOR A

PHOTOSENSOR B

PHOTOSENSOR C

PHOTOSENSOR D

MICROPHONE

BODY NEOPIXEL DATA

BAR NEOPIXEL DATA

STATE LED

LINE IN

AUDIO RETURN

Unused pin 8

C1 220uF / 10V

C2 100nF

Local amplifier decoupling; C1 value provisional

READING THE DRAWING

Dots join wires. Crossings without dots are separate.

X marks an unused pin. Pin numbers match the PCB.

Connector pins are grouped by function, not physical position.

Four sensor channels, body/bar lights and state LED are independent.

No components or electrical connections added in this copy.

LOCAL AUDIO AMPLIFIER

R1 22K

R2 3K3

M1 / GF1002

1 x 11 plug-in socket

5 V ONLY

R_IN

INPUT_G

VDD

SUPPLY_GND

ROUT_P_VERIFY

ROUT_N_VERIFY

L_IN_NC

GAP_NC

GAP_NC

LOUT_A_NC

LOUT_B_NC

ROUT+ / verify

ROUT- / verify

M1 unused: 3 = L input; 4/7 = gaps; 8/9 = L outputs.

J2 BODY SERVO — DATA, 12V, GND

J9 PHOTOSENSOR A — OUT, 5V, GND

J8 PHOTOSENSOR B — OUT, 5V, GND

J1 PHOTOSENSOR C — OUT, 5V, GND

J4 PHOTOSENSOR D — OUT, 5V, GND

J3 MICROPHONE — OUT, 5V, GND

J5 BODY NEOPIXELS — DATA, 5V, GND

J11 BAR NEOPIXELS — DATA, 5V, GND

J10 STATE LED — SIGNAL, GND

J6 SPEAKER — 1, 2

AUDIO_RETURN and GND stay separate on this PCB.

Confirm their expected bond inside the actual module.

Insulating supports / nominal 11 mm

H1 H2

Rack J7.14/J7.7: line-level audio / return only.

Disconnect the old remote speaker output first.

Neither output goes to GND.

Reading copy — existing circuit unchanged; see comparison.md

Colloquy of Mobiles

Sheet: /

File: male-static-v2-wired.kicad_sch

Title: Male static v2 / continuous wiring / revision D

Size: A2	Date: 2026-10-20	**Rev: D wired**
KiCad E.D.A. 9.0.7		Id: 1/1