IMPORTANT!!
If you plan to plug the pico into your computer, make sure you disconnect it from the 5-volt power first.
Failure to do so may result in your laptop shorting.



Mines Robotics Club
Space Grant Team

TITLE: wiring_diagram

Document Number:

REV:

Date: 11/11/2023 1:24 PM

Sheet: 1/1