JIANT FM · CONTROLS

every button, knob, layer, combo and page

firmware v0.6.14 · M-VAVE FM-1 · juanjiant-bit.github.io/JIANT

THE PANEL

KNOBS AND TRANSPORT

MASTER	Master volume.
SELECT	HOME and GLOBAL: the tempo. Any other page: **rolls the sound's dice**. Macros open (LFO held or latched): new random routes. GLO held: the tempo.
PRESETS	Browses the sounds (factory and user). On step, list and song pages: the cursor / the row. **Hold a page button + PRESETS: jump through its pages.**
ALGORITHM	Selects the track, T1–T6, from any page.
KNOB 1–4	The four columns on screen. Fast sweeps the whole range, slow fine-tunes. With a layer held: the layer's.
OCT– · OCT+	The keyboard's octave (both together: back to 0). On action pages and dialogs: back / confirm.
PLAY	Start / stop. GLO + PLAY: restart from the top.
REC	Arms live recording on the selected track (notes and knob moves, overdub).
HOME	Tap: the ecosystem. **Hold: the MENU.**
KEYS	27 keys play the selected track in its scale; with a layer held they become that layer's.

PAGE BUTTONS

BUTTON	TAP: ITS PAGES, ONE PER TAP	HOLD
ENV	ENV · ENV DEST	—
LFO	LFO · LFO DEST · MOD · MSEQ · MSEQ 2	MACROS M1–M4 (stay latched)
FX	FX · DIST · AUTOPAN · SLICER · SL BUS · SL BUS 2 · SL PITCH · DLY · DLY 2 · REVERB · REVERB 2 · CHORUS · MASTER	PUNCH-IN FX
SCL	SCL · SCL 2	ROOT by key
EDIT	EDIT 1 · EDIT 2 · FILTER · VOICE (FM6: OPERATOR · OP ENV · OPERATOR 2; DRUM: LANES · LANES 2 · SOUND 1–3 · X-MOD)	INIT · RECALL · sound mutes
GLO	MIXER · GLOBAL · SYSTEM	MUTE · SOLO · LEVEL · TAP
SAVE	PRESETS · USER · PROJECT · ARRANGE · TOOLS	SONG layer
ARP	ARP · ARP 2	—
SEQ	STEP · PATTERN · SHIFT · PHRASES · SONG · CHANCE · AUTOMATION · AUTO LIST	SEQ TOOLS
REC	(transport)	CLEAR · CLICK

BUTTON + PRESETS jumps straight to a page (no wrap); let go and you stay there.

LAYERS · HOLD A BUTTON

FX · PUNCH-IN EFFECTS



Act while held, in on the next 1/16. Black 1–6 mute T1–T6, A#4 picks which tracks the MIDI ones touch (all · synths · drums). With REC armed and playing they record into the section's lane; G5 erases it.

KNOBS

FILTER	CRUSH	THROW	DEPTH

GLO · MIX



Black 1–6 mute T1–T6 (latched), 7–10 the DRUM-X groups. White: solo while held, E4 unmutes all, F4 tap tempo. SELECT: the tempo. PLAY: restart.

KNOBS

LEVEL T1	LEVEL T2	LEVEL T3	LEVEL T4

T5 or T6 selected: the knobs are T3–T6.

SAVE · SONG



PLAY A–D on the next bar (several in one hold: a quick chain), STORE the section into A–D. OCT+ stores the playing section, OCT– recalls it. On the SONG page KNOB 4 stores a scene.

KNOBS

SONG 1–8	-	-	-

EDIT · SOUND



INIT: the factory sound (DRUM: the kit too). RECALL: the sound stored in the section. On a DRUM track black 1–8 mute each DRUM-X sound.

KNOBS

EDIT 1	EDIT 2	EDIT 3	EDIT 4

LFO · MACROS

Knobs M1–M4; they stay latched when let go (LFO again: off). F3 rolls new routes, G3 clears them, SELECT rolls too (only tracks that sound).

KNOBS

M1	M2	M3	M4

SCL · SCALE

Any key sets the ROOT. ROOT and SCALE are every melodic track's (and RESO's).

KNOBS

ROOT	SCL	OFS	PIT

SEQ · TOOLS

On the SEQ pages: F3 CLEAR · G3 REVERSE · A3 B3 SHIFT · C4 RANDOM · D4 COOK · E4 BEAT · F4 CLR AUTO (the automation).

KNOBS

LEN	DIV	SWING	GATE

REC · RECORD

F3 CLEAR the track (asks first), G3 the metronome CLICK.

KNOBS

CLICK	-	-	-

COMBOS

BUTTONS TOGETHER

PAGE BUTTON + PRESETS	Jump through that button's pages.
REC + FX EDIT ENV LFO SCL ARP GLO	Clear that part's automation on the selected track (FX: the punch-in lane too).
SEQ + REC	CLEAR ALL SEQUENCES? (OCT+ confirms).
SAVE + OCT+ / OCT–	Store / recall the playing section.
GLO + PLAY	Restart from the top.
GLO + SELECT	Tempo (from any page).
STEP HELD + KNOB	A parameter lock on that step (roll, grid).
HOME held	MENU: knob accel, FX latch, hold time, USB level, palettes, animation...

EVERY PAGE · KNOB 1 – 4

ENV

ENV	ATK	DEC	SUS	REL
ENV DEST	FLT	PIT	SHP	LOOP

LFO

LFO	RATE	WAVE	PHS	FADE
LFO DEST	PIT	FLT	SHP	AMP
MOD	SLOT	SRC	DST	AMT
MSEQ	STEP	LVL	LEN	SLEW
MSEQ 2	DIV	-	-	-

SCL · ARP

SCL	ROOT	SCL	QNT	TRN
SCL 2	STRN	-	-	-
ARP	MODE	RATE	OCT	GATE
ARP 2	SWG	PROB	HOLD	ORD

FX

FX	DST	CHO	DLY	REV
DIST	DST	TYPE	TONE	-
AUTOPAN	DPTH	RATE	SYNC	WAVE
SLICER	SLCR	PAT	RATE	DEPTH
SL BUS	T1	T2	T3	T4
SL BUS 2	T5	T6	FX	-
SL PITCH	STEP	PIT	LEN	QNT
DLY	TIME	FDBK	TONE	MIX
DLY 2	WIDE	PITCH	SPRY	-
REVERB	TYPE	SIZE	DAMP	PRE/AIR
REVERB 2	MOD	RATE	FILT	WIDE
CHORUS	RATE	DEPTH	STER	-
MASTER	CLIP	PNCH	DUCK	REL

EDIT

EDIT 1	E1	E2	E3	E4
EDIT 2	E5	E6	E7	E8
RETRIG	RTRG	-	-	-
OPERATOR	OP	RATIO	FINE	LEVEL
OP ENV	OP	STAGE	RATE	LEVEL
OPERATOR 2	OP	MODE	DTUN	VEL
FILTER	TYPE	CUT	RES	DRV
VOICE	VCE	GLD	GLMOD	PRIO
LANES	KICK	SNARE	CLAP	HATCL
LANES 2	HATOP	TOM	RIM	BELL
SOUND	LANE	SIDE	PTCH	PMOD
SOUND 2	DCAY	NOIS	COLR	MODE
SOUND 3	LANE	PMOD	DRV	WAVE
X-MOD	RATE	DPTH	SHPE	RAND

SEQ

STEP	STEP	NOTE	TIME	FLAG
STEP · DRUM	STEP	LANE	HIT	ACC
PATTERN	LEN	DIV	SWG	GATE
SHIFT	OFS	PIT	-	-
PHRASES	PAT	LOAD	-	-
SONG	ROW	SECT	BARS	SCENE
CHANCE	STEP	CHANCE	RATCH	-
AUTOMATION	PLAY	EVENT	LOCK	CLEAR
AUTO LIST	ROW	STEP	PARAM	VALUE

GLO · SAVE

MIXER	LEVEL	PAN	REV	MUTE
GLOBAL	BPM	SWG	CLK	TUNE
SYSTEM	MIDI	-	ROUT	-
PRESETS	No.	ENG	FAV	LIST
USER	SLOT	LOAD	ERASE	SAVE
PROJECT	PROJ	SECT	LOAD	SAVE
ARRANGE	ROW	SECT	BARS	SCENE
TOOLS	CLRSQ	INIT	-	-

GPL-3.0 · fork of Felucca (Hügelton Instruments) · song mode from SLOOP