Valores MIPS

Instrucciones:

- 1. LWU R1,8{R2}
- 2. J8
- 3. HALT

ValoresMIPS / Instrucciones	LWU R1, 8{R2}	J 8	NOP (AND R1, R1, R1)	HALT
PC	1	2	8	9
CC	1	2	3	4
PC + 1	2	3	9	10
Instrucción fetch	9C410008	08000008	00210824	FFFFFFF
Branch	-	000A	0408	002D
Data A	-	00000000	00000000	00000000
Data B	-	00000000	00000000	00000000
Valor inmediato con extensión de signo	-	00000008	00000008	0824
Registros	-	0820	0000	0421
Señales de control	-	0742	0016	0C20