





The generic hardware platform

The Arduino Pro Mini

The Arduino Pro Mini is a compact form factor Arduino board based on the ATmega328P microcontroller
Use the **3.3v and 8MHz version** of the Arduino Pro Mini for lower power consumption



You can get the original board designed by Sparkfun or get one of the various clones available mainly from Chinese manufacturer. The last solution is very cost-effective as the Pro Mini board can be purchased for a bit more than 1€ a piece.

Depending on how many sensors you want to connect, the number of ground (GND) pins may be limited. You can extend a GND pin with a header pin where all pins are soldered together.

The LoRa radio module

There are various LoRa radio modules that are all based on the Semtech SX1272/1276 chips family



Fully tested LoRa radio modules



HopeRF RFM92W/95W




Liberium LoRa



Modtronix inAir4/9/9B


NiceRF





NiceRF LoRa1276

Most of SPI-based LoRa radio modules are supported. The Modtronix inAir model can come with header pins ready to be connected with Dupont wires, simplifying the procedure.

The RFM95W can be found assembled (Adafruit for instance) otherwise there are some breakout boards available.



Connect the LoRa radio module



Connect the corresponding SPI pins of the radio module to the SPI pins on the Pro Mini board. MOSI (blue) is pin 11, MISO (green) is pin 12, CS (white) is pin 10 and CLK (orange) is pin 13 (right picture). Then connect also the VCC (red) and the GND (black) of the radio module to the VCC and the GND of the board (right picture). The VCC of the Pro Mini board gets 3.3v from the on-board voltage regulator.


Connecting a sensor

Use a simple temperature sensor: LM35DZ

Connect sensor's VCC pin Pro Mini's digital pin 8 to power the sensor

Connect sensor's Analog OUT to Pro Mini's analog pin A0 to read value from sensor

Connect sensor's GND pin to one of Pro Mini's GND pin



Uploading our temperature template code

Get the Arduino libraries and code templates

Get the entire ZIP archive of the **LowCostLoRaGw** github repository at <https://github.com/CongducPham/LowCostLoRaGw>


Unzip the archive and copy the content of the **Arduino** folder in your Arduino IDE sketch folder

If you already have a **libraries** folder in your sketch folder, copy the content of the new libraries folder in your libraries folder

Open the **Arduino_LoRa_Simple_temp** sketch and select the Arduino Pro Mini board in its 3.3V & 8MHz version

Connect the Arduino Pro Mini to an FTDI breakout USB cable (in 3.3v version). Check the VCC pin and make it to correspond to the VCC pin of the FTDI breakout

Connect the USB end to your computer and the USB port should be detected in the Arduino IDE. Select the serial port for your device. Then click on the « upload » button



Use the Serial Monitor to check the device output

The template will cycle through **measure-transmit-sleep(10min)-wake up** with low-power mode

```


Capture Fichier Édition Capture Fenêtre Aide
Arduino_LoRa_temp | Arduino 1.6.6
Serial Monitor /dev/cu.usbmodem1427817
Arduino_LoRa_temp
/*
temperature sensor on analog 8 to test the LoRa gateway
Copyright (C) 2015 Congduc Pham, University of Pau, France
This program is free software; you can redistribute it and/or modify
it under the terms of the GNU General Public License as published by
the Free Software Foundation, either version 3 of the License, or
(at your option) any later version.

This program is distributed in the hope that it will be useful,
but WITHOUT ANY WARRANTY; without even the implied warranty of
MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
GNU General Public License for more details.

You should have received a copy of the GNU General Public License
along with the program. If not, see <http://www.gnu.org/licenses/>.
*/
// Include the SX1272
#include "SX1272.h"

// IMPORTANT
// please uncomment only 1 choice
*/

```



Sending LoRa messages

Device default configuration

Default configuration uses BW=125kHz, CR=4/5, SF=12 i.e. LoRa mode 1

This configuration allows for the longest range

The default gateway radio configuration is similar

LoRa mode	BW	CR	SF
1	125	4/5	12
2	250	4/5	12
3	125	4/5	10
4	500	4/5	12
5	250	4/5	10
6	500	4/5	11
7	250	4/5	9
8	500	4/5	9
9	500	4/5	8
10	500	4/5	7


ch	F(MHz)	ch	F(MHz)	ch	F(MHz)
04	863.2*	00	903.08	00	433.3*
05	863.5*	01	905.24	01	433.6*
06	863.8*	02	907.40	02	433.9*
07	864.1*	03	909.56	03	434.3*
08	864.4*	04	911.72	-	-
09	864.7*	05	913.88	-	-
10	865.2	06	916.04	-	-
11	865.5	07	918.20	-	-
12	865.8	08	920.36	-	-
13	866.1	09	922.52	-	-
14	866.4	10	924.68	-	-
15	867.7	11	926.84	-	-
16	867.0	12	915.00	-	-
17	868.0	-	-	-	-
18	868.1*	-	-	-	-

The default frequency at the end-device depends on the selected band. Using the default configuration (865.2 MHz) allows for out-of-the-box reception at the gateway

Achieving ultra low power consumption


Run on battery

You can use 4 AA batteries to provide $4 \times 1.5v = 6v$. This will be injected into the RAW pin of the board, using the on-board voltage regulator to get 3.3v. Remove the power led to greatly reduce power consumption: in sleep mode, the board draws about 5uA and can run for more than 2 years on the basis of 1 measure/hour



Ultra low power


Remove the voltage regulator and directly inject 3.1v – 3.6v to the VCC pin of the board



By removing the voltage regulator, you can use a single 3.6v Lithium-based battery or 2 regular AA batteries that provides about 3.1v

You can use the VCC pin on the programming header to power the board, as the other VCC pin is needed for the radio module

In sleep mode, the board now draws about 12uA, allowing for much longer lifetime



Additional resources & tutorials

The general github repository <https://github.com/CongducPham/LowCostLoRaGw>


The WAZIUP github <https://github.com/Waziup>

IoT device video https://www.youtube.com/watch?v=YsKbJeeav_M

Gateway video <https://www.youtube.com/watch?v=peHkDhiH3IE>

Examples of integration into production device

Simple temperature device





Multiple-level soil moisture device



Collar for cattle rustling applications

When connecting the male connector MC to the female connector FC 1, the board will be powered and will start sending periodic beacons



Beacon's RSSI will be used to approximate collar distance


Using other platforms

Platforms with integrated LoRa radio modules

There are many boards that integrate a LoRa radio, mostly the HopeRF RFM95W radio module

These boards are often based on the ATmega328P (similar to the Arduino Pro Mini) or the ATmega32U4 where compatibility with the Arduino IDE is provided. They provide easier LoRa integration but are generally much more expensive than a Pro Mini + inAir radio module combination


We tested many of them and verified that our template code is working fine, including the low-power mode. Note that the Pro Mini with both power led and voltage regulator removed shows the lowest power consumption in sleep mode: 12uA.



Ideetron Nexus
ATmega328P



Wisen WhisperNode
ATmega328P



LowPowerLab Moteino
ATmega328P




Adafruit Feather32U4
ATmega32U4

Using PCB design for easier integration

Simple PCB for easier integration

A simple PCB can be designed to just facilitate the integration of the Arduino Pro Mini board and an RFM95W radio module

Here, the designed open-source PCB from Fabien Ferrero of University of Nice, France, with an integrated antenna to avoid external fragile part when deploying the device



https://github.com/FabienFerrero/UCA_Board

More integrated PCB

A more advanced PCB integration project can use the ATmega328P microcontroller to provide a customized solution: 2 soil moisture sensors per device for the Nestlé's WaterSense project using WAZIUP software

Here, the new project from Zahoor Ahmad of LUMS University, Pakistan, integrates the ATmega328P and provides header for easy connection of the inAir Lora module. The new board uses a single 3.6v battery

