# Below are the pins exposed @ the EK-TM4C123GXL BoosterPack connector.

Also shown are functions that map with the BoosterPack pinout standard.

** Some LaunchPads do not comply with this GPIO pin. De-prioritize this pin when making a BoosterPack.

(!) Denotes I/O pins that are interrupt-capable.

**BoosterPack Standard**

**EK-TM4C123GXL Pinout**

**EK-TM4C123GXL Pinout**

**BoosterPack Standard**



EK-TM4C123GXL BoosterPack connector pinout diagram