

H1
H2
H3
H4
SW1
SW2
RESET
BOOT
UP
DOWN
SW4
SW5
J4
J3
! NO USB WHILE 24VAC IS WIRED
(unless via USB isolator)
! NO USB
WITH 24VAC