



- Shift into Park.
 Hold down both scroll buttons on the steering yoke until the touchscreen turns black.



3. After a few seconds, the Tesla logo appears. Wait approximately 30 seconds for the touchscreen to restart. If the touchscreen is still unresponsive or demonstrating unusual behavior after a few minutes, try power cycling the vehicle (if possible). See Power Cycling the Vehicle.

Note Restarting the touchscreen also activates the drive mode selector on the center console.





Note

Restarting the touchscreen using the scroll buttons does not power Model S off and on.



Do It Yourself General Information Restarting and Powercycling Wheels, Tires, and Brakes Wipers and Washers Climate Components Front and Rear Trunk Calibrate Cameras Low Voltage Battery Charging © Tesla 2022