

Calling Simulink drone model with adaptive PID parameters

```
Kp=20
```

```
Kp =  
20
```

```
Ki=17
```

```
Ki =  
17
```

```
Kd=3.505
```

```
Kd =  
3.5050
```

Calling Simulink model named "drone" presented in Figure 2.1

```
model = sim(drone)
```

```
model =  
    Simulink.SimulationOutput:  
  
        time: [400x1 double]  
        tout: [400x1 double]  
    yaw_angle: [400x1 double]  
  
    SimulationMetadata: [1x1 Simulink.SimulationMetadata]  
    ErrorMessage: [0x0 char]
```

Plotting the system response (yaw angle)

```
plot(model.time,model.yaw_angle);  
grid;  
xlabel('Time [s]');  
ylabel('Yaw Angle [deg]')
```

