

OCTOBER 2, 2014



Associate Technical Director



PRESENTATION OVERVIEW



Basics

- Reference software stack and unified release
- Simple app
- Audio/video decode, graphics, DVR

Architecture

Synchronization, interfaces, drivers, Linux user/kernel mode


Multi-Process

- Proxy mechanism
- Resource tracking and garbage collection
- Virtualization, dynamic allocation and new client-server interfaces
- NxClient

Advanced Usage


- Transcode, 3DTV, packet blit, power management
- AppLibs integration including DirectFB, WebKit, DLNA, Flash





REFERENCE SOFTWARE STACK





WHAT IS NEXUS?



Nexus is a modular, high-level API for Broadcom set-top boxes

Easy to use API

- Based on customer usage, not internal implementation
- Mapped to a variety of middleware
- Designed for backward-compatible API changes

Robust internal architecture

- Automatic synchronization that is safe and efficient
- Multi-process proxy


Flexible modular design

- Abstractions for multiple OS's
- Internal modularity makes updates easier
- Platform-specific code is isolated, making updates easier

UNIFIED RELEASE MODEL



- All platforms released concurrently using common codebase
- Easy to understand quarterly release schedule
 - URSR 14.1 = Q1 of 2014
- Phase 0.5 engineering release for new silicon still independent



SIMPLE NEXUS APP



Display

Video

Window

Video

Learn Nexus by reading and running example code.


```
int main() {
  NEXUS_Platform_Init();

display = NEXUS_Display_Open(0, &openDisplaySettings);
  window = NEXUS_VideoWindow_Open(display, 0);

decoder = NEXUS_VideoDecoder_Open(0, &openSettings);
  NEXUS_VideoWindow_AddInput(window, GetConnector(decoder));
```


LIVE AUDIO/VIDEO DECODE








nexus/examples/video/pip.c




Nexus apps can model complex usage modes by creating and connecting more interfaces.













DVR (DIGITAL VIDEO RECORDING)






MEDIA FRAMEWORK FOR DVR CONTAINER SUPPORT









ARCHITECTURE


PERL-GENERATED THUNK FOR SYNC & MULTI-PROCESS



Example synchronization thunk code:

```
NEXUS_Error NEXUS_Message_GetStatus(hndl, pSettings)
{
   NEXUS_Error rc;
   NEXUS_LockModule();
   rc = NEXUS_Message_GetStatus_impl(hndl, pSettings);
   NEXUS_UnlockModule();
   return rc;
}
```

- "Thunking" gives Nexus elements of a 4GL language without the overhead.
- Thunk for ioctls to kernel mode driver
- Thunk for sockets to user mode server.
- Thunk for enforcing power management standby mode



MODULES AND INTERFACES



How can the system be safe and efficient?

- If each module automatically locks, how do we avoid deadlocks?
- If each module automatically locks, how do we avoid fast modules waiting on slow modules?


Modules arranged in a tree

- Fast modules can't call slow modules, making the system efficient.
- Deadlock is impossible, making the system safe.

Modules distributed between client & server

The application's view of Nexus is interconnected Interfaces

- The application doesn't have to know the module tree. It sees a flat collection of interfaces.
- Nexus encapsulates internal connections. This makes your application easier to code.



CALLBACKS




How can we safely call back into the application?

- If we don't unlock, we risk deadlock.
- If we unlock, we have to code for re-entrancy in every Nexus module.

Nexus Base provides prioritized asynchronous callbacks

- Nexus Base runs one thread per module priority. Keeps slow and fast modules segregated.
- Standard callback mechanism works across kernel and process boundaries.
- One context switch is required going from kernel → user mode.
- Nexus can fire callback directly from ISR context.
- Application can make almost any call from inside a callback with no reentrancy in Nexus modules.
- Nexus close functions automatically synchronize with an interfaces callbacks.
 This eliminates very tricky race conditions.



CODING CONVENTION



Consistent naming convention

- "NEXUS_" prefix establishes a namespace
- CamelCase for consistency
- Interface name included in every member of the interface (e.g. NEXUS_VideoDecoder_Open)

Interface patterns

- Open/Close, Create/Destroy
- GetDefaultSettings/GetSettings/SetSettings
- GetBuffer/ReadComplete
- AddInput/RemoveInput

Restrictions

- No function pointers (synchronization)
- No pointers to structs inside structs (no deep copy)

Advantages

- Easy to understand
- Future proof API techniques (increased chances of backward compatibility on re-compile)
- Thunkable

```
NEXUS_SurfaceHandle NEXUS_Surface_Crea
const NEXUS_SurfaceCreateSettings
);

void NEXUS_Surface_Destroy(
    NEXUS_SurfaceHandle surface
);

NEXUS_Error NEXUS_Surface_SetSettings(
    NEXUS_SurfaceHandle surface,
    const NEXUS_SurfaceSettings *pSett
);


void NEXUS_Surface_GetSettings(
    NEXUS_SurfaceHandle surface,
```

See "Coding Conventions" in nexus/docs/Nexus_Development.pdf

NEXUS PLATFORM



- Nexus Platform allows customer- and board-specific code to be separated from chip-specific code
 - Maximizes code reuse
 - Allows full customization
- Typical features include
 - OS driver code
 - Pin-muxing
 - L1 interrupt mapping from OS
 - Build system
 - Frontend configuration
 - DAC/ADC mapping



OS ABSTRACTION



OS abstraction provided in layers

- Only provide the minimum required at each point for the architecture
- Nexus currently supported on Linux, VxWorks, Nucleus, uC-OS, and WinCE

Nexus Platform

- Memory mapping
- L1 interrupt mapping
- OS driver(s)

Nexus File


DVR file I/O

Nexus Base

threads, timers, event callbacks

Magnum KNI

events, mutexes, critical section





LINUX USER MODE/KERNEL MODE SUPPORT



Thunk provides seamless support for user and kernel mode


- Automatic kernel mode proxy
- Same libnexus.so binary interface

Kernel mode advantages


 Lower interrupt latencies for connected products using Ethernet, USB, etc.

User mode advantages

Easier development & debug



Application App calls Nexus Interfaces directly libnexus.so (proxy) (Auto-generated proxy ioctl's)



MIPS AND ARM SUPPORT



Nexus supports both seamlessly

- Same Nexus API.
- All Broadcom app and library development runs on both.

Changes the user will notice

- Different kernel and toolchain. Require Linux 3.3 and beyond.
- Moved from CFE to BOLT bootloader. Makes use of device tree for better configuration.
- Set NEXUS_PLATFORM=97xxx, B_REFSW_ARCH=arm-linux, then compile.

Internal differences that may not be noticed

- MIPS uses proprietary BMEM system to carve out device memory; ARM uses standard CMA. Nexus heaps map
 to both.
- MIPS uses 2/2 user/kernel space split; ARM uses 3/1. Less virtual memory in the kernel, more in user space.
- MIPS Linux had standard cache flush syscall; ARM Linux does not. Nexus provides one.

POWER MANAGEMENT



Dynamic Power Management

- Implicitly power down unused resources. No special API required.
 - NEXUS_VideoDecoder_Stop powers down the video decoder
 - NEXUS_Display_RemoveOutput powers down the DAC's
- Linux support for dynamic power down of peripherals includes USB, SATA, Ethernet, etc.

Active and Passive Standby

- Active Standby leaves CPU running along with a subset of modules, typically frontend and transport
- Passive Standby powers down all devices (except wake-up devices) and puts the CPU to sleep
- Variety of wake-up devices: IR, front panel, UHF, HDMI CEC, Wakeup-on-LAN, USB, GPIO, timer

Government Regulations and Standards

- Energy Star (US)
- European regulation for Simple STBs
- European VIA (Voluntary Industry Agreement) for Complex STBs



POWER STATES AND SAMPLE MEASUREMENTS




ACPI Power State	Nexus Standby Mode	Functionality	Sample power level (7425)	Sample wake up time (7425, local DVR, no SATA spin down)
S0	eOn	Full operation	4.4 W	N/A
S1	eActive	Frontend, transport and CPU active for DVR record, network messages and EPG data.	1.1 W	2.5 sec
S2	ePassive	All wake-up devices are available. All other hardware is clock gated for faster wake-up. DDR in self-refresh.	0.53 W	2.95 sec
S 3	eDeepSleep	Only wake-up devices are active using Always On (AON) block: IR, timer, CEC, GPIO and keypad. All other hardware is power gated for minimal power. DDR in self-refresh.	0.013 W	3.63 sec

LEARNING MORE ABOUT NEXUS




Every Broadcom reference software release contains what you need to learn about Nexus

- Nexus Documentation
 - nexus/docs
- Nexus Example Applications
 - nexus/examples
- Nexus API header files
 - nexus/modules/*/include/*.h







MULTI-PROCESS


Broadcom Proprietary and Confidential. © 2012 Broadcom Corporation. All rights reserved.

KERNEL MODE MULTI-PROCESS



Auto-generated ioctl calls

```
NEXUS_MessageHandle NEXUS_Message_Open(unsigned index,
    pSettings)
{
    MessageOpenIoctl data;
    data.index = index;
    data.pSettings = pSettings;
    ioctl(fd, IOCTL_MESSAGE_OPEN, &data);
    return data.returnCode;
}
```




USER MODE MULTI-PROCESS



Auto-generated socket calls

```
NEXUS Message Handle NEXUS Message Open (unsigned index,
    pSettings)
    MessageOpenData *data = LockBuffer(connection);
    MessageOpenOutParams outparams;
    data->index = index;
    data->settings = *pSettings;
    SendMessage (connection, data, &outparams);
    return outparams.returnCode;
```




Driver

RESOURCE TRACKING IN THE PROXY



Store handle/type/client on every Open/Create call

```
NEXUS_MessageHandle NEXUS_Message_Open(unsigned index, pSettings)
{
    NEXUS_MessageHandle msg;
    msg = NEXUS_Message_Open_impl(index, pSettings);
    if (msg) {
        b_objdb_insert(msg, MESSAGE, b_client());
    }
    return msg;
}
```




PROTECTING THE SERVER



Validate handle/type/client on every other call

```
int NEXUS_Message_Start(NEXUS_MessageHandle msg,
    pSettings)
{
    if (!b_objdb_verify(msg, MESSAGE, b_client()) {
        return NEXUS_INVALID_PARAM;
    }
    return NEXUS_Message_Start_impl(msg, pSettings);
}
```





Client starts up...

```
--- 08.132 b_objdb: insert NEXUS_SurfaceClient:0x74d668 client=0x66800c
--- 08.132 b_objdb: acquire NEXUS_SurfaceClient:0x74d668 client=0x74c550
--- 08.134 b_objdb: insert NEXUS_Graphics2D:0x7524b8 client=0x74c550
--- 08.135 b_objdb: insert NEXUS_Surface:0x753c40 client=0x74c550
--- 08.161 b_objdb: insert NEXUS_Surface:0x753e00 client=0x74c550
```

...then crashes

```
--- 09.964 b_objdb: auto-release: [order 1] NEXUS_SurfaceClient:0x74d668 client=0x74c550
--- 09.964 b_objdb: remove NEXUS_Surface:0x753e00 client=0x74c550
--- 09.965 b_objdb: auto-remove: [order 1] NEXUS_Graphics2D:0x7524b8 client=0x74c550
--- 09.965 b_objdb: auto-remove: [order 5] NEXUS_Surface:0x753c40 client=0x74c550
--- 09.965 b_objdb: remove NEXUS_SurfaceClient:0x74d668 client=0x66800c
```



Reference counting dependencies

```
int NEXUS_Message_Start_impl(NEXUS_MessageHandle msg,
    pSettings)
{
    if (!pSettings->pidChannel) {
        return NEXUS_INVALID_PARAMETER;
    }
    NEXUS_OBJECT_ACQUIRE (pSettings->pidChannel);
    ConfigPidChannel (pSettings->pidChannel->index);
    ConfigMessageFilter (msg->index);
    return NEXUS_SUCCESS;
}
```

SECURE MEMORY MANAGEMENT





CLIENT MODES



Feature	Verified Mode	Protected Mode	Untrusted Mode
API	Full	Full	Limited
Handle verification	Partial (skip owner test)	Yes	Yes
Garbage collection	Yes	Yes	Yes
Heaps	Only what is granted	Only what is granted	Only what is granted
Use Case	Server, Status clients	In-house clients	Third-party clients

SAFELY SHARING RESOURCES WITH CLIENTS



Abstraction for resource sharing

- An abstraction is a higher-level representation which hides implementation details
- Solve a problem in one spot instead of spreading it to all spots

Multiple abstractions are useful


- Virtualization
- Dynamic allocation
- Higher-level client/server API's

SOLUTION #1 - VIRTUALIZATION




 Rework implementation so each process thinks it owns the resource, then multiplex in software.

- Example
 - 2D graphics blitter



SOLUTION #1 – VIRTUALIZATION (CONT.)





SOLUTION #2 - DYNAMIC ALLOCATION



- Provide dynamic allocators for plentiful and orthogonal resources
- Examples
 - Pid channels, message filters, playbacks, records, parser bands

```
p = NEXUS_Playpump_Open(2, &openSettings);
NEXUS_Playpump_Close(p);
```



```
p = NEXUS_Playpump_Open(NEXUS_ANY_ID, &openSettings);
NEXUS_Playpump_Close(p);
```

SOLUTION #2 - DYNAMIC ALLOCATION (CONT.)



Pitfall

- Some API's used enumerated types for hardware resources
- Constructor/destructor needed for dynamic allocation

```
NEXUS_ParserBand_SetSettings(NEXUS_ParserBand_e0, &settings);
```




```
NEXUS_ParserBand pb;
pb = NEXUS_ParserBand_Open(NEXUS_ANY_ID);
NEXUS_ParserBand_SetSettings(pb, &settings);
NEXUS_ParserBand_Close(pb);
```

SOLUTION #3 – HIGHER-LEVEL CLIENT/SERVER API'S




- Multiplexing video and graphics to the display
- Multiplexing audio and sound effects to outputs




SINGLE PROCESS GRAPHICS






MULTI-PROCESS GRAPHICS WITH SURFACE COMPOSITOR






SINGLE PROCESS DECODE






MULTI-PROCESS DECODE WITH SIMPLE DECODER







NEXUS MULTI-PROCESS SYSTEM











NXCLIENT



- Thin library above Nexus Multi-Process to make it easier to allocate and connect resources and set global settings.
 - Not a wrapper for Nexus; just some helpful IPC utility code.
- Connects to a reusable server which integrates graphics, video and audio.


Minimal API

- NxClient_Join connect to the server and to Nexus
- NxClient_Alloc ask the server to create resources which can be acquired
- NxClient_Connect ask the server to connect video and audio decoders

Code

- nexus/nxclient/include
- nexus/nxclient/server
- nexus/nxclient/apps
- nexus/nxclient/docs





NXCLIENT MULTI-SESSION












- Server runs multiple sessions with separate graphics/video/audio presentation
- Decode and encode resources are shared
- Remote sessions can be streamed via Miracast or other standard
- Server can be headed or headless





ADVANCED USAGE

ADVANCED USAGE




- Audio/video transcode
- Packet blit
- Fast channel change
- 3DTV support
- 3D graphics using OpenGL-ES 2.0
- Large memory systems
- AppLibs

AUDIO/VIDEO TRANSCODE




- Video transcode through video decode (AVD) and video encode (VICE)
 - MPEG/VC1/AVC/MPEG4, up to 1080p30
- Audio transcode through audio decode and encode (Raaga)



2D PACKET BLIT




- High-performance 2D blitting with Nexus Packet Blit API
 - Alternative to function-based blit API
- Use data-driven technique to pipeline blits, minimize CPU overhead



- Ideal for multi-threaded applications (each thread gets a SW fifo context)
- Ideal for multi-process applications (IPC only the SW fifo pointers)

FAST CHANNEL CHANGE






3DTV (STEREOSCOPIC TV)



- Integrated 3DTV support starting with 40nm silicon
 - 65nm silicon has subset of functionality, more application code required
- Full-res decode 1080p24 or 720p60 for each eye
- Multi-view Video coding (MVC) decode can be used for 3DTV streams
- Integrated L/R graphics support
- HDMI VSI, AVC SEI signaling support





3D GRAPHICS



- 3D graphics through Video Core IV (VC4) core
- Broadcom's 3D graphics API is OpenGL-ES
 - Nexus has no underlying 3D graphics API

Specifications

- 12M rendered vertices/sec
- 180M pixels/sec with single bi-linear texturing, simple shading, 4x multisampling
- Supports 16x coverage mask anti-aliasing for 2D rendering at full pixel rate
- 720p standard resolution with 4x multisampling
- Fully supports OpenGL-ES 1.1/2.0 and OpenVG 1.1







LARGE MEMORY SYSTEMS



Limited virtual address space in 32 bits

- Kernel/user split is 2G/2G for MIPS; 1G/3G for ARM. Yet we deploy 2-3 GB systems.
- Must map memory according to use case.

Nexus provides full heap control

- Minimal mapping of each memory region
- Default heaps provided; fully customizable

NEXUS_MemoryType	Memory Mapping
NEXUS_MemoryType_eApplication	User mode CPU access
NEXUS_MemoryType_eFull	Full kernel and user mode CPU access
NEXUS_MemoryType_eDeviceOnly	No mapping. No CPU access required.
NEXUS_MemoryType_eSecure	No mapping. Limited device access.

APPLIBS INTEGRATION



- Provide suite of integrated libraries and applications on top of Nexus
 - Provided as reference code
 - Can also be used directly
- Standard open source libraries
 - DirectFB
 - WebKit
 - DLNA
 - OpenGL-ES
- Third party plug-ins
 - Adobe Flash 10













Q&A