


Hall-sensor breakout for the scanner head's +X wall

The A3144 sits in its pocket in the wall; its leads pass through the wall's slot and this board.
C1 decouples the sensor at the end of its cable. The output pull-up (10k to 3.3 V) is on the controller.
J1 pin 1 = 5 V, 2 = GND, 3 = OUT, the same order as the controller's J4.



github.com/CoraBeanz/linescan-hyperspectral-splatting
A3144 home sensor on the scanner head's +X wall
CoraBeanz

Sheet: /
File: hall_breakout.kicad_sch

Title: Hall-sensor breakout

Size: A4 Date: 2026-10-08

KiCad E.D.A. 10.0.6

Rev: A

Id: 1/1