DATA ITEM DESCRIPTION

Form Approved
OMB No. 0704-0188
Exp Date. Jun 30, 1986

1 TITLE	2 IDENTIFICATION NUMBER
AIRFRAME AND ENGINE TRACKED COMPONENTS AND RELATED EQUIPMENT TRACKING DATA	DI-ILSS-80223

3 DESCRIPTION/PURPOSE

3.1 This Data Item Description (DID) describes the data required to track the status of items installed, removed, and repaired, reworked or acquired including spares.
3.2 The tracked items include airframes, engines, including marine shipboard gas turbine engines, and components thereof, related equipment and spares.
(Continued on Page 2)

4 APPROVAL DATE (YYMMDD)	5 OFFICE OF PRIMARY RESPONSIBILITY (OPR)	6a DTIC REQUIRED	6b GIDEP REQUIRED
860825	N/AIR-411		

7 APPLICATION/INTERRELATIONSHIP

7.1 This DID contains the format and content preparation instructions for the data product generated by the specific and discrete task requirements for this data included in the contract.
7.2 This DID is applicable to the acquisition and service and contractor maintenance of tracked items including airframes, engines, and components thereof which are tracked using the Aircraft Engine Management System (AEMS), Engine Composition
(Continued on Page 2)

8 APPROVAL LIMITATION	9a APPLICABLE FORMS	9b AMSC NUMBER
		N3938

10. PREPARATION INSTRUCTIONS

10.1 Contract. This data item is generated by the contract which contains a specific and discrete work task to develop this data product.

10.2 Aircraft Engine Management System (AEMS).

10.2.1 Aircraft Engine Transaction Reports (ETR) - Reports shall be in Naval message or commercial telegram format. Aircraft engine transaction reports shall be numbered consecutively by each reporting activity through each calendar year beginning with 1 January, for example 1-85, 2-85, 3-85, etc. Include only the lines of data that are applicable to the transaction, do not use "N/A" or "Zeros" to fill data elements.

10.2.2 Identification of data elements. Engine Transaction Report (ETR) data elements for aircraft engines are identified in Figure 1. The format for the report is also provided in Figure 1.

10.2.3 Definition of data elements for aircraft engines. The word engine will be used interchangeably with assembly.

10.2.3.1 Engine serial number - A seven (7) digit number which identifies each engine-module. Field is right justified and preceded by zeros.

10.2.3.2 Date - Year and Julian date that the transaction actually occured (e.g., 15 Dec 1985 shall be 85349).

10.2.3.3 Status star code - For aircraft engine reporting use four (4) digits.

Source: https://assist.dla.mil -- Downloaded: 202610-26T10:35Z
Check the source to verify that this is the current version before use.

3. Description/Purpose (cont'd)

3.3 This data is also required for use in computing requirements for spare aircraft engines , marine shipboard gas turbine engines, spare parts for these end items and spare dynamic components of airframes.

---

7. Application/Interrelationship (cont'd)

Tracking (ECOMTRAK), Airframe Composition Tracking (ACOMTRAK), and Navy Marine Gas Turbine Engine Item Accounting/Inventory Control Systems.

7.3 This DID supersedes DI-L-2183

---

10. Preparation Instructions (cont'd)

Codes for aircraft engine use are identified in Figure 2. A dash between the status and star codes in Figure 2. is used to assist in distinguishing between the two. Do not include a dash when reporting status star codes.

10.2.3.4 Status code - A two (2) digit number which describes the condition of engines, the purpose for which they are being used, or the stage of progress that unserviceable engines have reached in the maintenance cycle.

10.2.3.5 Star code - A two (2) digit number which describes or gives reasons for transactions such as strikes, transfers, acquisitions, or remarks concerning engines and amplifies or qualifies a status code.

10.2.3.6 Engine - module type - model - A seven (7) character alphanumeric field with no spaces between characters which identifies the type model of the engines-modules. The field shall be left justified and unused spaces left blank.

10.2.3.7 Engine - module series - A seven (7) character alphanumeric field with no spaces between which identifies the current series-dash of an engine module.

10.2.3.8 Reporting Custodian - A five (5) character alphanumeric Unit Identification Code (UIC) of the activity which is reporting the transaction.

10.2.3.9 Controlling Custodian - A five (5) character alphanumeric UIC of the Controlling Custodian.

10.2.3.10 Aircraft model - For aircraft, a six (6) character alphanumeric field with no spaces between characters which identifies the applicable model of aircraft.

10.2.3.11 Hours since Overhaul (OVHL) - A five (5) digit number used to identify the operating hours of the engine-module since the last overhaul-depot repair. Shall be only whole hours, no fractions. Zero (0) operating hours shall be shown as one (1) hour. The field shall be right justified and preceded by zeros.

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

10.3.3.12 Hours since new - A five (5) digit number which identifies the operating hours of the engine-module since new. Shall be only whole hours, no fractions. Zero(0) operating hours shall be shown as one (1) hour. The field shall be right justified and preceded by zeros.

10.2.3.13 Number of OVHLS since new - A one (1) digit field which identifies the number of depot visits, including OVHLS, that have been performed on an engine-module. Shall be zero if no overhauls-repairs have been performed.

10.2.3.14 Number of first degree repairs since depot - A one (1) digit field which identifies the number of first degree repairs that have been performed on an engine-module since the last overhaul-repair.

10.2.3.15 Reporting Custodian received from-transfer to - The five (5) character alphanumeric UIC of the activity that the Reporting Custodian has received the engine-module from or transferred the engine-module to.

10.2.3.16 New Controlling Custodian transfer to - The five (5) character alphanumeric UIC of the Controlling Custodian that the engine-module is being transferred to.

10.2.3.17 Aircraft Bureau Number (BUNO) - The six (6) digit field of the aircraft the engine-module is being installed on or removed from.

10.2.3.18 Engine-module position number - The one (1) digit field designating the position in which the engine is-was installed on an aircraft (numbered from the wing on pilot's left to wing on pilot's right). On aircraft that have only one engine, the digit "1" must be entered.

10.2.3.19 Reason for removal - The two (2) character alphanumeric code, identified in Figure 3, giving the reason for the removal of an engine-module.

10.2.3.20 Remarks - Fifty (50) spaces for any pertinent amplifying information.

10.3 Navy Marine Gas Turbine Engine Item Accounting/Inventory Control System

10.3.1 Marine Shipboard Gas Turbine Engine Transaction Reports (ETR) - Marine shipboard gas turbine ETRs shall be in message format for each reporting activity, and shall be numbered consecutively through each calendar year beginning with 1 January, for example 1-85, 2-85, 3-85, etc. Include only the lines of data that are applicable to the transaction, do not use "N/A" or "Zeros" to fill data elements. The format for the report is shown in Figure 4.

10.3.2 Identification of data elements. ETR data elements for marine shipboard gas turbines are identified in Figure 4.

10.3.3 Definition of data elements for marine shipboard gas turbine engines.

10.3.3.1 Status code - A two (2) digit field which describes the condition of engines, the purpose for which they are being used, or the stage of progress that unserviceable

Source: https://assist.dla.mil -- Downloaded: 202610-26T10:35Z
Check the source to verify that this is the currentversion before use.

10. Preparation Instructions (cont'd)

engines have reached in the maintenance cycle. Codes for marine shipboard gas turbine engines are identified in Figure 5.

10.3.3.2 Date - Year and Julian date that the transaction actually occured (i.e., 15 Dec 1985 shall be 85349).

10.3.3.3 Engine designation - A seven (7) character alphanumeric field with no spaces between characters which identifies the type-model of the engines-modules. The field shall be left justified and unused spaces left blank.

10.3.3.4 Series (dash number) - A seven (7) character alphanumeric field with no spaces between which identifies the current series (dash-number) of an engine-module. Star code 52 shows series has been changed since last report. The field shall be left justified and unused spaces left blank.

10.3.3.5 Serial number - A seven (7) digit field which identifies each engine-module. Field is right justified and preceded by zeros.

10.3.3.6 Designated stocking activity - The five (5) digit UIC of the designated stocking activity. The field shall be right justified and preceded by zeros.

10.3.3.7 Designated repair point - A five (5) digit UIC of the designated repair point. The field shall be right justified and preceeded by zeros.

10.3.3..8 Ship - The five (5) digit UIC of the ship which the engine is assigned to, installed in, removed from or shipped from.

10.3.3..9 Hull number - The five (5) character alphanumeric field which identifies the hull of the ship which the engine has been assigned to, installed in, or removed from. Dashes (-), slashes (/), or other characters shall not be used to separate the elements of the hull number. The field shall be left justified with remaining spaces being blank.

10.3.3..10 Operating hours since repair - A five (5) digit field used to identify the operating hours of the engine-module since the last overhaul/depot repair. Shall be only whole hours, no fractions. Zero (0) operating hours shall be shown as one (1) hour. The field shall be right justified and preceded by zeros.

10.3.3.11 Hours since new - A five (5) digit field which identifies the operating hours of the engine-module since new. Shall be only whole hours, no fractions. Zero(0) operating hours shall be shown as one (1) hour. The field shall be right justified and preceded by zeros.

10.3.3.12 Depot repair action since new - A one (1) digit field which identifies the number of depot visits including overhauls that have been performed on an engine-module. Shall be zero if no overhauls-repairs have been performed.

10.3.3.13 Star code - A two (2) digit field which describes or gives reasons for transactions such as strikes, transfers, acquisitions, or remarks of engines and

Source: https://assist.dla.mil -- Downloaded: 202640-26T10:35Z
Check the source to verify that this is the currenversion before use.

10. Preparation Instructions (cont'd)

amplifies or qualifies a status code.Codes for marine shipboard gas turbine engines are identified in Figure 5.

10.3.3.14 Activity transfered to - The five (5) digit UIC of the Controlling Custodian that the engine-module is being transferred to.

10.4 Engine and Airframe Composition Tracking (ECOMTRAK AND ACOMTRAK) Systems

10.4.1 Newly Manufactured Items - Data elements required to be reported are identified in Figure 6. Report to be rendered in the format shown in Figure 6.

10.4.2 Items Which Were Removed, Reworked, Scrapped, or Installed - Data elements required to be reported are identified in Figure 7. Report to be rendered in the format shown in Figure 7.

10.4.3 Reporting Procedures - The addressee and method of transmission for data item reports, see 10.4.1 and 10.4.2 above, shall be as described in the CDRL, DD 1423.

10.4.4 Detailed definition, Where necessary, the definition of each data element required to be included in the reports specified in 10.4.1 and 10.4.2 above is provided.

10.4.4.1 Contract no. or task no. - Self explanatory.

10.4.4.2 Nomenclature - Name designation of the item being reported on.

10.4.4.3 Manufacture date - The calendar date on which the manufacturing process for a component was completed.

10.4.4.4 Part number - A number used to identify an item of production, or a range of items of production, by the manufacturer controlling the design, characteristics, and production of the item by means of its engineering drawings, specifications, and inspection requirements.

10.4.4.5 Engine serial number or airframe BUNO - A seven (7) digit numerical field which identifies each engine or airframe. Field is right justified and preceded by zeros.

10.4.4.6 Component serial number - A ten (10) character alphanumeric field which uniquely identifies each component within a Work Unit Code (WUC). Field is left justified and zero filled.

10.4.4.7 Manufacturer code - A five digit numerical field which uniquely identifies a specific manufacturer. A listing of these unique identifiers is contained in GSA-FSS H4-2.

10.4.4.8 Work Unit Code(WUC) - A seven (7) character alphanumeric field which identifies a system or components, parts, etc. of a system. Shall be left justified and

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

zero filled. Necessary WUC are provided as a part of the specific and discrete work task contained in the contract to develop this data product.

10.4.4.9 Type Equipment Code(TEC) - A four (4) character alphanumeric field which identifies either the end item or category of equipment on which work is performed. Necessary TEC are provided as a part of the specific and discrete work task contained in the contract to develop this data product.

10.4.4.10 Action date - The Julian date on which a maintenance form is completed by a work center (i.e., 15 Dec. 1985 shall be 85349)

10.4.4.11 Cycle counts since new (1) - A five (5) digit numerical field which identifies the cycle counts of the component since new. Counts shall be only whole counts, no fractions. The most generally used "cycle" is one (1) hour of operating time. However, for a tracked component of a landing gear, an appropriate "cycle" is one (1) landing. For some engines the cycle is considered to be a Life Used Index (LUI), etc. Zero (0) counts shall be shown as one (1) count. The field shall be right justified and preceded by zeros.

10.4.4.12 Cycle counts since overhaul-rework or repair - A five (5) digit numerical field used to identify the cycle counts of the component since the last overhaul-rework or repair. Shall be only whole counts, no fractions. Zero (0) counts shall be shown as one (1) count. The field shall be right justified and preceded by zeros.

10.4.4.13 Action taken codes - These codes are identified in Figure 8.

10.4.4.14 Part number of next higher assembly - The part number (see 10.4.4.4 above) of the component of which, in the hierarchical structure listing of work unit codes, the subcomponent being worked on is a part.

10.4.4.15 Serial number of the next higher assembly - The serial number (see 10.4.4.6 above) of the component which, in the hierarchical structure listing of work unit codes, the subcomponent being worked on is a part.

Source: https://assist.dla.mil -- Downloaded: 202610-26T10:35Z
Check the source to verify that this is the currentversion before use.

10. Preparation Instructions (cont'd)

AIRCRAFT ENGINE TRANSACTION REPORT (ETR) FORMAT

Fr
To COMNAVAIRSYSCOM, Washington, DC

UNCLAS//N13700//

A/C ENG-MODULE TRANS REPT _____, REPORT SYMBOL NAVAIR 13700-2

	ELEMENT	CHARACTER LENGTH
1.	Engine Serial Number	(7)
2.	Date	(5)
3.	Status-Star Code	(4)
4.	Engine-Module Type-Model	(7)
5.	Engine-Module Series - Dash	(7)
6.	Reporting Custodian	(5)
7.	Controlling Custodian	(5)
8.	Aircraft Model	(6)
9.	Hours Since Overhaul	(5)
10.	Hours Since New	(5)
11.	Number of OVHLs Since New	(1)
12.	Number of First Degree Repairs Since Depot	(1)
13.	Reporting Cust. Recd Fr Tran To	(5)
14.	New Controlling Cust. Tran To	(5)
15.	Aircraft Bureau Number	(6)
16.	Engine-Module Position Number	(1)
17.	Reason for Removal	(2)
18.	Remarks	(50)

FIGURE 1. Aircraft engine transaction report (ETR) format

Source: https://assist.dla.mil -- Downloaded: 202640-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

EXPLANATION OF STATUS STAR CODES
FOR AIRCRAFT ETR

Updated Status to be Applied to the File	Required ETR Format Elements	Explanation of Status Being Applied	Last Reported Status Now in File
11-bb (1)	1-8 15,16	Reporting Custodian reports installation of an engine-module in an aircraft.	21-XX(2) 23-XX 46-61
11-50	1-13, 15, 16, 21	Gain to the file of an installed engine-module received from a manufacturer.	No previous ETR Necessary
11-51	1-13, 15, 16, 21	Gain to the file of an installed engine-module received from another government agency - (USAF-ARMY-COAST GUARD, etc.)	No Previous ETR Necessary
11-52	1-9, 15, 16, 21	Reporting Custodian reports a change in the engine-module series while the engine-module remains in an installed status.	11-XX
11-60	1-8, 13-16, 21	Reporting Custodians reports transfer of an installed engine-module from one Controlling Custodian to another.	11-XX
11-61	1-13, 15, 16	Reporting Custodian reports receipt of an installed engine-module from another Controlling Custodian.	11-60 47-60
11-62	1-9, 13, 15, 16	Reporting Custodian reports receipt of an installed engine-module from within a Controlling Custodian.	11-63
11-63	1-9, 13, 15, 16	Reporting Custodian reports transfer of an installed engine-module within a Controlling Custodian.	11-XX

NOTES:
(1) A "bb" following a status code indicates a "blank star code".
(2) An "xx" following a status code indicates "any star code" unless denoted by an asterisk restricting certain STAR codes.

FIGURE 2. Explanation of status star codes for aircraft ETR

Source: https://assist.dla.mil -- Downloaded: 202610-26T10:35Z
Check the source to verify that this is the currentversion before use.

10. Preparation Instructions (cont'd)

11-70	1-9, 15, 16	Used to indicate a change in aircraft model. Engine-module remains installed in same Bureau Number (BUNO).	11-xx
11-90	1-9, 15, 16	End-of-Quarter (EOQ) report on installed engines-modules, reflecting hours flown since new. (Must be equal to or greater than previously reported).	11-xx
11-99	1-9, 15, 16	Reporting Custodian reports a change of location for installed engines. (AIRLANT and AIRPAC use for deploying squadrons or detachments.)	11-xx
13-13	1-7, 9, 10, 21, 22	Reporting Custodian reports attachment of module to assembly.	21xx 23xx
13-50	1-7, 9, 10, 21, 22	Gain to the file of a new module and attachment to new assembly.	No previous ETR necessary
21-bb	1-7	Serviceable spare engine-modules returned to a Ready for Issue (RFI) status when only a series change or Power Plant Bulletin (PPB) was incorporated by the repair activity and no other repair accomplished. Also used to report test cell correlation engines-modules status changed to an RFI status when no longer required for correlation use.	21-xx
21-50	1-7, 9-12, 21	Gain to the file of a new engine-module from a manufacturer by a Controlling Custodian.	No Previous ETR Necessary
21-51	1-7, 1-12	Gain to the file of an RFI engine-module received from another government agency.	No Previous ETR Necessary

FIGURE 2. Explanation of status star codes for aircraft ETR-continued

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

21-52	1-7	Change in engine-module series designation on an RFI engine-module.	21-xx* *except 60
21-60	1-7, 13, 14, 21	Transfer of an RFI engine-module from one Controlling Custodian to another Controlling Custodian. Transfer of an RFI engine from a Designated Rework Point (DRP) to a Supply Officer (SUPO) upon completion of repairs.(3)	21-xx 23-xx
21-61	1-7, 9-13, 21	Receipt of an RFI engine-module received from another Controlling Custodian or Field Service (FS) Custodian.	21-60 23-60 46-60
21-62	1-7, 9-13, 21	An RFI engine-module received from another Reporting Custodian within a Controlling Custodian.	21-63
21-63	1-7, 13, 14, 21	An RFI engine-module transferred to another Reporting Custodian within a Controlling Custodian.	21-xx 42-bb
21-74	1-9, 15-17, 21	Removal of an engine-module and a change of status from installed (Code 11) to RFI (Code 21). This code is used to show cannibalization or BUNO swaps of engines-modules.	11-XX* *Except 60 or 63
21-91	1-9	An RFI engine returned to RFI status after completion of a 1st degree repair by the repair activity.	24-52 24-93 24-99

Notes:
(3) DRP will be used throughout Figure 2 to mean a Naval Air Rework Facility (NARF), USAF depot or a contractor maintenance facility as may be appropriate in each ETR.

FIGURE 2. Explanation of status star codes for aircraft ETR-continued

Source: https://assist.dla.mil -- Downloaded: 202610-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

21-95	1-9, 21	Completion of Hourly Engine Maintenance Program (HEMP)	24-52 24-93
21-96	1-9, 21	An engine returned to RFI status after undergoing test.	24-62
21-97	1-9, 21	An engine returned to RFI status after completion of a 2nd degree repair by the repair activity.	24-52 24-93 24-99
21-98	1-9, 21	An engine returned to RFI status after completion of a 3rd degree repair by the repair activity.	24-52 24-93 24-99
23-bb	1-7, 9-11, 21	RFI engine after series change or PPB was incorporated and no other repair or RFI after correlation use. DRP and SUPO use.	23-xx 40-xx 41-bb
23-01	1-7, 9-11	Completion of overhaul-repair.	34-52 34-93 34-96 38-bb
23-50	1-7, 9,10,21	Gain to file of new engine-module from a manufacturer by a Controlling Custodian. DRP and SUPO use.	No previous ETR necessary
23-51	1-7, 9,10, 13, 14, 21	Gain to file of RFI engine received from another government agency. DRP and SUPO use.	No previous ETR necessary
23-52	1-7	Change in engine-module series designation on an RFI engine-module. Series must be different than previously reported, i.e., 8B to 8c, 20A to 420, etc. DRP and SUPO use.	23-xx* *Except 60 or 63
23-60	1-7, 13, 14, 21	Transfer of an RFI engine-module from one Controlling Custodian to another Controlling Custodian or transfer from	23-xx 46-61

FIGURE 2. Explanation of status star codes for aircraft ETR-continued

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

		DRP to SUPO. DRP and SUPO use.	
23-61	1-7, 9-13, 21	Receipt of an RFI engine received from another Controlling Custodian. DRP and SUPO use.	21-60 23-60 46-60
23-62	1-7, 9-13, 21	An RFI engine-module received from another Reporting Custodian within a Controlling Custodian. DRP AND SUPO use.	23-63
23-63	1-7, 13, 14, 21	An RFI engine-module transferred between two engine Reporting Custodians within a Controlling Custodian. DRP and SUPO use.	21-61 21-62 23-xx 46-61
23-74	1-9, 15, 17, 21	Removal of an engine-module and a change of status from installed (Code 11) to RFI (Code 23). This code is used to show cannibalization or BUNO swaps of engines-modules. DRP AND SUPO use.	11-xx* *Except 60 or 63
23-92	1-7	1st degree repair completion of an engine-module	36-52 36-93 36-96 38-bb
23-97	1-7	2nd degree repair completion of an engine -module.	36-52 36-93 36-96 38-bb
23-98	1-7	3rd degree repair completion of an engine-module.	36-52 36-93 36-96
31-bb	1-9, 9-12	Unserviceable engine awaiting shipment or reporting installation of an unserviceable status code 31 engine for weight and balance purposes,	31-xx* *Except 60 or 63

FIGURE 2. Explanation of status star codes for aircraft ETR-continued

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

		etc. This transaction requires authorization by the Controlling Custodian prior to submission.	
31-51	1-7, 9-12	Gain of an unserviceable engine-module from another government agency.	No Previous ETR Necessary
31-60	1-7, 9-12, 14, 21	Transfer of an unserviceable engine-module to another Controlling Custodian.	31-51 31-61 31-62 31-72 31-73 31-74 31-99 41-bb
31-61	1-7, 9-12	Receipt of an unserviceable engine-module from another Controlling Custodian.	31-60
31-62	1-7, 9-13	Reporting receipt of an unserviceable engine-module from another Reporting Custodian within a Controlling Custodian.	31-63
31-63	1-7, 9-13	Reporting transfer of an unserviceable engine-module from one Reporting Custodian to another within a Controlling Custodian.	31-xx
31-72	1-9, 15-17	Engine-module downgrade of uninstalled serviceable and determined to be unserviceable and removed by administrative decision	21-xx* 24-xx* *Except 60 or 63.
31-73	1-9, 15-17, 21	Reporting removal of a failed engine-module awaiting shipment to the DRP.	11-xx* 47-xx *Except 60-63

FIGURE 2. Explanation of status star codes for aircraft ETR-continued

Source: https://assist.dla.mil -- Downloaded: 202640-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

31-74	1-9, 15-17	Engine determined to be unserviceable and removed by administrative decision.	11-xx
31-99	1-9, 15, 16	Reporting Custodian reports a change of location for an unserviceable engine. (AIRLANT and AIRPAC use to deploy ships, squadrons, detachments, or engines.	31-xx
32-60	1-7, 13, 14	Reporting an unserviceable engine-module shipped to the DRP.	31-51 31-61 31-62 31-72 31-73 41-bb
33-51	1-9, 13, 14, & 21	Gain of an unserviceable engine from another activity.	No previous ETR necessary
33-60	1-7, 13, 14, 21	Transfer of an awaiting depot repair engine-module from one SUPO or DRP.	33-xx 37-bb 48-xx* *Except 60 or 63
33-61	1-7, 13	Receipt at a DRP or SUPO of an unserviceable engine-module awaiting depot overhaul-repair.	32-60 33-60
33-62	1-7, 13	Receipt at a DRP or SUPO of an unserviceable engine awaiting depot overhaul-repair from within a Controlling Custodian.	33-63 34-63 36-63
33-63	1-7, 13	Transfer of an unserviceable engine located at a SUPO or DRP and awaiting depot overhaul-repair from within a Controlling Custodian.	33-xx 36-bb 37-bb 48-xx
33-72	1-7, 13	Engine reported as unserviceable due to an administrative decision at a Field Service (FS) Custodian (other than	11-xx* 23-xx 40-61

FIGURE 2. Explanation of status star codes for aircraft ETR-continued

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

		NARF) which will also repair the engine or downgrade of an engine previously removed as RFI.	42-bb 48-xx* *Except 60 or 63
33-73	1-7, 13	Engine reported as unserviceable due to a failure at an FS Custodian (other than NARF)	11-xx 47-xx
33-78	1-7, 10, 17, 21, 22	Removal of an attached unserviceable module from an assembly.	13-xx
33-92	1-7, 13	Receipt at the SUPO or DRP of parts for an unserviceable engine awaiting overhaul-repair.	33-94 37-bb 38-bb
33-94	1-7, 13	Parts shortage at the SUPO or DRP on unserviceable engine awaiting overhaul/repair.	33-61 33-62 33-92
34-bb	1-7, 9, 13	Allocation of an awaiting overhaul-repair engine-module for repair at a DRP.	33-xx
34-52	1-7	Change of series on an engine-module during overhaul-repair.	34-93
34-62	1-7, 13	Receipt of an awaiting depot overhaul-repair engine-module at a DRP.	33-63
34-63	1-7, 13, 21	Transfer of an awaiting depot overhaul-repair engine-module from the SUPO to a DRP for overhaul-repair.	34-xx
34-92	1-7	Awaiting Maintenance (AWM) at a DRP.	34-93 34-94 37-bb

FIGURE 2. Explanation of status star codes for aircraft ETR-continued

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

34-93	1-7	Induction of an engine-module for overhaul-repair on re-induction of engine-module after receipt of spare parts.	34-bb 34-62 34-92 34-93 34-94 36-93 37-bb
34-94	1-7, 21	Work stoppage on overhaul of an engine-module due to spare parts shortage.	34-52 34-92 34-93
34-96	1-7, 11, 21	Overhauled-repaired engine-module that has pased test cell performance by use of slave parts-components.	34-52 34-93
36-bb	1-7, 9	Allocation of an unserviceable engine-module for repair at FS Custodian (other than NARF) or a DPR.	33-xx
36-52	1-7	Change of series on an engine-module during repair.	36-93
36-62	1-7, 9, 13	Receipt of an unserviceable engine-module awaiting repair from SUPO to a DRP for repair.	33-63
36-63	1-7, 9, 13	Transfer of an unserviceable engine-module awaiting repair from SUPO or a DRP for repair.	36-xx
36-92	1-7	Awaiting Maintenance (AWM) at a DRP.	36-93 36-94 37-bb
36-93	1-7	Induction of an engine-module for repair or re-induction of engine-module after receipt of spare parts.	34-93 36-bb 36-62 36-92 36-93 36-94 37-bb

FIGURE 2. Explanation of status star codes for aircraft ETR-continued

Source: https://assist.dla.mil -- Downloaded: 202610-26T10:35Z
Check the source to verify that this is the currentversion before use.

10. Preparation Instructions (cont'd)

36-94	1-7, 21	Work stoppage of repair of an engine-module due to spare parts shortage.	36-92 36-93
36-96	1-7, 12	Engine-module that has completed repair, and has passed test cell performance by use of slave parts-components.	36-52 36-93
37-bb	1-7	Engines waiting repair-overhaul not being processed due to monetary constraints.	33-xx 34-xx 36-xx
38-bb	1-7, 21	RFI engine awaiting resolution of engineering problems or a safety of flight power plant bulletin.	34-93 34-96 36-93 36-96 38-xx
40-bb	1-7	Designation of a test cell correlation engine-module at a DRP.	21-xx* 23-xx* *Except 60
40-60	1-7, 13, 21	Reporting transfer of test cell correlation engine-module from one Controlling Custodian to another Controlling Custodian.	23-50 40-xx
40-61	1-7, 13	Reporting receipt of a test cell correlation engine-module from another Controlling Custodian.	21-60 40-60
40-62	1-7, 13, 14, 21	Reporting receipt of a test cell correlation engine-module within a Controlling Custodian.	40-63
40-63	1-7, 13	Transfer of a test cell correlation engine-module within a Controlling Custodian.	40-62

FIGURE 2. Explanation of status star codes for aircraft ETR-continued

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

41-bb	1-7, 21	Reporting an engine-module for which disposition instructions have been requested or has been designated for special testing.	11-xx* 21-xx* 23-xx* 24-xx* 31-xx* 33-xx* 34-xx* 36-xx* 40-xx* 41-bb *Except 60 or 63
42-bb	1-7, 21	Reporting an engine-module which is held in excess of Navy requirements.	11-xx* 21-xx* 23-xx* 24-xx* 31-xx* 33-xx* 34-xx* 36-xx* 40-xx* 41-bb 42-bb *Except 60 or 63
46-60	1-7, 9, 13, 14, 21.	Reporting transfer of uninstalled engine-module bailed to a contractor or loaned to another government agency.	21-xx* 23-xx* 24-xx* 31-xx* 46-61 46-74 *Except 60 or 63
46-61	1-7, 9, 13	Reporting receipt of an uninstalled engine-module from bailed status.	23-60 23-63 46-60
46-62	1-7, 9, 10, 13, 14, 21	Receipt of an uninstalled bailed or loaned engine from within a Controlling Custodian.	23-63 46-63

FIGURE 2. Explanation of status star codes for aircraft ETR-continued

Source: https://assist.dla.mil -- Downloaded: 202610-26T10:35Z
Check the source to verify that this is the currentversion before use.

10. Preparation Instructions (cont'd)

46-63	1-7, 10, 13, 14, 21	Transfer of uninstalled bailed or loaned engine within a Controlling Custodian.	23-61 23-62 46-61 46-62
46-74	1-9, 15-17, 21	Reporting removal of a bailed or loaned engine-module.	47-xx
47-bb	1-9, 15, 16	Reporting installation of a bailed engine-module.	21-74 23-xx* 46-xx *Except 60 or 63
47-60	1-9, 13-16, 21	Reporting transfer of an installed engine-module bailed to a contractor or loaned to a government agency.	11-xx* 47-xx *Except 61 or 62
47-61	1-9, 12, 15	Reporting receipt of an installed bailed or loaned engine-module.	11-60 47-60
47-62	1-10, 13-16, 21	Receipt of an installed engine bailed or loaned within a Controlling Custodian.	11-63 47-63
47-63	1-10, 13-16, 21	Transfer of an installed engine bailed or loaned within a Controlling Custodian.	11-61 47-xx
48-60	1-7, 9-14,21	Reporting transfer of training engine-module from another Controlling Custodian to the Naval Air Maintenance Training Group (NAMTRAGRU), Memphis.	21-xx 23-xx 24-xx 31-xx 33-xx 34-xx 36-xx 40-xx* 41-bb 42-bb 46-xx 47-xx *Except 61 or 62

FIGURE 2. Explanation of status star codes for aircraft ETR-continued

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

48-61	1-7, 9, 10, 13, 14 21	Receipt of an engine by NAMTRAGRU Memphis from another Controlling Custodian.	48-60
48-62	1-7, 9, 10, 13, 14,	Receipt of an engine by NAMTRAGRU Memphis from within a Controlling Custodian.	48-63
48-63	1-7, 9, 10, 13, 14 21	Engine transferred to NAMTRAGRU from within a Controlling Custodian.	48-61 48-62
49-60	1-7, 9-13	Engine-module stricken from the Navy inventory and transferred to another Controlling Custodian.	49-xx
49-61	1-7, 9-13	Engine-module stricken from the Navy inventory and received from another Controlling Custodian.	49-60
49-62	1-7, 9-13	Engine-module stricken from the Navy inventory and received within a Controlling Custodian.	49-63
49-63	1-7, 9-13	Engine-module stricken from the Navy inventory and transferred within a Controlling Custodian.	49-61 49-62
49-80	1-7, 21	Engine-module striken from the Navy inventory and transferred to the Property Disposal Officer (PDO).	Note (4)
49-81	1-7, 14, 21	Engine-module stricken from the Navy inventory and transferred to another government agency.	Note (4)
49-82	1-10	Engine-module stricken from the Navy inventory due to crash of the aircraft.	11-xx

NOTES:
(4) May follow any status and star codes except 32-60.

FIGURE 2. Explanation of status star codes for aircraft ETR-continued

Source: https://assist.dla.mil -- Downloaded: 202610-26T10:35Z
Check the source to verify that this is the currentversion before use.

10. Preparation Instructions (cont'd)

49-83	1-7, 21	Engine-module stricken from the Navy inventory and transferred to the International Logistics Program (ILP).	Note (5)
49-84	1-7, 21	Engine-module stricken from the Navy inventory due to an intentional loss; i.e., prevent capture by an enemy, shot down by test missile, etc.	Note (5)
49-85	1-7, 21	Engine-module stricken from the Navy inventory and transferred to technical training (not NAMTRAGRU Memphis).	Note (5)
49-86	1-7, 21	Engine-module stricken from the Navy inventory for any reason not covered by other star codes. (Explain in Remarks.)	Note (5)
49-87	1-7, 21	Engine stricken from the Navy inventory awaiting Reclamation in Lieu of Procurement (RILOP).	Note (5)
49-88	1-7, 21	Engine stricken from Navy inventory RILOP commenced.	49-87
49-89	1-7, 21	Engine-module stricken from the Navy inventory, completed.	Note (5)

NOTES:
(5) May follow any status and star codes except 32-60.

FIGURE 2. Explanation of status star codes for aircraft ETR-continued

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

REASON FOR REMOVAL CODE

AUXILLIARY SYSTEM MALFUNCTION	6S
AB BLOWOUT	9V
AB NO LIGHT/MISLIGHT	1Z
AB MALFUNCTION	8S
ACCIDENT/INCIDENT DAMAGE	4B
BACKFIRE IN FLIGHT	1E
BEARING FAILURE	8P
BLOWBY OR DETONATION (RECIP ONLY)	2Z
CAN'T TRIM	3A
CRACKED OR WARPED INLET GUIDE	3C
CRACKED DEFUSER CASE	2E
COMPRESSOR CASE CRACKED	6P
COMPRESSOR DAMAGE DUE TO MATERIAL FAILURE OR SEIZED	9Q
COMPRESSOR EROSION/CORROSION	6R
COMPRESSOR RUB	6L
COMPRESSOR STALLS	6Q
CORROSION	2Q
COMBUSTION CASE BURN HOT SPOT	8E
COMBUSTION DAMAGE	9E
COMPRESSOR ROTOR CHANGE (OTHER THAN FOD)	5Z
CYLINDER FAILURE	2U
CONTAMINATED FUEL	8D
DAMAGED/CRACKED TURBINE FRAME/CASE BURNED THROUGH	1L
DAMAGED FAILED BUCKETS	3L
DAMAGED IN TRANSIT	4L
DIRECTED REMOVAL	4D
ENGINE SEIZURE	4P
EXCESSIVE MAINTENANCE	3B
EXHAUST DUCT FAILURE	4R
EXHAUST NOZZLE CONTROL MALFUNCTION	4S
EXCESSIVE STALLS	2K
EXCEEDING QUALITY CHECK TEMP LIMIT	8J
EXCESSIVE OIL FROM BREATHER OR HIGH SUMP PRESSURE	8A
EXCESSIVE VIBRATING OR ROUGH OPERATIONS	9A
EXCESSIVE FUEL CONSUMPTION	9M
EQUIPMENT OIL ANALYSIS	2W
ENGINE OR AFTERBURNER FIRE DAMAGE	7L
ENGINE TO A/C MOUNT FAILURE	8L
ENGINE DECOUPLED (TURBOPROP)	5U
FAULTY HANDLING (DROPPED)	3E
FIRE	5B
FLAME OUT	1A
FOD-COMPRESSOR	5C
FOD-TURBINE	5D
FUEL LEAKAGE	5W
FUEL FROM OVERBOARD DRAIN	3X

FIGURE 3. Reason for removal codes

Source: https://assist.dla.mil -- Downloaded: 202640-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

1ST STAGE FAN DAMAGE	9Z
2ND STAGE FAN DAMAGE	2C
FROZEN FAN	1Q
GEARBOX MALFUNCTION	1G
HIGH EGT	1K
HIGH OIL PRESSURE	5Q
HIGH TIME	5G
HOT STARTS	1B
HIGH BREATHER PRESSURE	9J
INABILITY TO ACCELERATE	3M
INABILITY TO START ENGINE	3P
INDUCTION SYSTEM CONTAMINATED WITH METAL FROM TURBO	4H
INLET CASE CRACK	2A
INLET GUIDE VANES CRACKED/BROKEN	6W
INTERNAL FAILURE	3Q
IMPELLER OR INDUCER DAMAGE	1H
INTERGRAL REDUCTION GEAR FAILURE	7P
INABILITY TO ADJUST TO LIMITS	1W
AIR LEAKAGE	7J
OIL LEAKAGE	7K
LOW EPR	5X
LOW OIL PRESSURE	5W
LOW POWER OR THRUST	3R
LOW COMPRESSION (RECIP ONLY)	9W
LOSS OF TORQUE (RECIP ONLY)	6Z
LOW MANIFOLD PRESSURE (RECIP ONLY)	3Z
METAL IN OIL CONTAMINATION	2N
METAL-TAIL PIPE	2T
MODIFICATION INC TDC	6A
METAL IN SUMP/SCREEN OR ON MAG PLUG	7W
MANIFOLD PRESSURE BEYOND LIMITS, OVER BOOST (RECIP ONLY)	9U
NOISE-ENGINE	1T
NOSE CASE CRACKED	6X
OIL CONSUMPTION	3T
OIL STARVATION	6E
OIL IN INTAKE	8U
OIL IN TAILPIPE	1X
OIL FROM BREATHER SYSTEM	2X
OVERBOOST	2G
OVER SPEEDING	2F
OVER TEMPERATURE	6F
OIL INDUCTION SYSTEM OR COMPRESSOR SECTION (RECIP ONLY)	4Z
PROPELLER BRAKE FAILURE	8R
PRECAUTIONARY REMOVAL	9T
PRESSURE BLEED VALVE FAILURE	8N
REAR CASE CRACKED	7A
REMOVED FROM CONNIBALIZATION	3W
REMOVED HIGH TIME COMPONENT (TURBINE, COMPRESSOR, ETC.)	7H

FIGURE 3. Reason for removal code - Continued

Source: https://assist.dla.mil -- Downloaded: 202640-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

REMOVAL-HEMP	7E
REDUCTION GEARBOX FAILURE (TURBOPROP)	1R
SCAVENGER PUMP FAILURE (INCLUDES TURBOPROP GEARBOX)	4V
SERVICING WITH IMPROPER GRADE OF FUEL OR OIL	8W
SLIPPED BLOWER CLUTCH (RECIP ONLY)	5P
SPECTRUM OIL ANALYSIS PROGRAM	8F
SUDDEN STOPAGE	4J
SPARKS FROM TAILPIPE	4X
START WET	7T
START HUNG	7X
SURGES/FLUCTUATIONS	3J
SUPER CHARGER CASE CRACKED	5E
TEMPERATURE MONITOR LIMITS EXCEEDED	2H
TORQUE METER FAILURE (TURBOPROP)	3S
TURBO SUPER CHARGER FAILURE	3H
THROWN BUCKETS	2L
TURBINE FAILURE	8C
TURBINE NOZZLE FAILURE	6T
UNSTABLE/SURGING	3U
VIBRATION	3D
VARIABLE INLET GUIDE VANE DAMAGE/WEAR	7U
WILL NOT CARRY LOAD (APU)	7Z
PART OF MATCH SET (RMVD WITH ASSOCIATED ENGINE FAILURE-RFI MODULE USED ON T56A, T400, AND OTHER MODULAR ENGINE SECTION REMOVED AS RESULT OF FAILURE IN AN ASSOCIATED MODULE.)	4A

FIGURE 3. Reason for removal code - Continued

Source: https://assist.dla.mil -- Downloaded: 202610-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

MARINE SHIPBOARD GAS TURBINE ETR FORMAT

FM:

TO: COMNAVSEASYSCOM WASHINGTON, DC

UNCLAS //N04442//

SUBJ: ENG TRANS RPT_____

1. NAVSEA for 56XF

A Status Code

B Date

C Engine Designation

D Series (Dash Number)

E Serial Number

F Designated Stocking Activity

G Designated Repair Point

S Ship

H Hull Number

I Operating Hours Since Repair

J Operating Hours Since New

K Depot Repair Actions Since New

M Star Code

O Activity Transferred To

FIGURE 4. Marine shipboard gas turbine ETR format

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

DETAILED EXPLANATION OF STATUS CODES AND STAR CODES FOR MARINE SHIPBOARD GAS TURBINE ETR

1. Definition of Status Codes. Status codes are two (2) digit numbers that describe the condition of engines, the purpose for which they are being used, or the stage of progress that unserviceable engines have reached in the maintenance cycle.

2. Listing of Status Codes

2.1 Installed

11 - Installed in a Ship. This status commences as of the date an engine is installed in a ship

2.2 Serviceable Uninstalled

21 - Serviceable Spare Engine. This status code applies to any uninstalled RFI condition engine that can be installed and operated without any requirement for repair or modification by a designated repair point. In the case of an engine that has completed repair or modification at a designated repair point, status code 21 begins at the time the testing, preservation and packaging have been completed. Use of this status code by Industrial Activities and Forces Afloat will be at the direction of the Engine Inventory Manager.

22 - Serviceable Spare Engine in Transit. This status code is applicable to a RFI engine in transit between a designated repair point and a designated stocking activity, between designated stocking activities, or between a designated stocking activity and end use. Use of this status code to reflect movement other than those described above is restricted to the Engine Inventory Manager.

24 - Spare Engine Temporarily Out of Service. This status code pertains to any uninstalled spare engine that has arrived at an end use destination and is awaiting installation. This status code commences when a serviceable engine physically arrives at its end use destination and terminates as of the date the engine is transferred to status code 11, 21 or 22.

2.3 Unserviceable

31 - Unserviceable Engine Awaiting Shipment. This status code pertains to an engine that has been determined to be unserviceable and requiring repair or modification by a designated repair point. This status commences on the date the engine is determined to be unserviceable and continues until the date the engine is shipped to a designated stocking activity or designated repair point, as applicable.

FIGURE 5. Detailed explanation of status codes and star codes for marine shipboard gas turbine ETR

Source: https://assist.dla.mil -- Downloaded: 202610-26T10:35Z
Check the source to verify that this is the currentversion before use.

10. Preparation Instructions (cont'd)

32 - Unserviceable Engine In Transit. This status code describes an unserviceable engine meeting the same criteria prescribed for status code 31, but applies to the period during which the engine is physically in transit to the designated stocking activity or designated repair point. This period commences the date the engine is physically shipped by the activity preparing the bill of lading, and terminates on the date the engine physically arrives at its destination.

33 - Unserviceable Engine Awaiting Repair Or Modification. This status code applies to an unserviceable engine awaiting repair or modification. This status code commences when an unserviceable engine physically arrives at a designated stocking activity or designated repair point, as applicable, and terminates as of the date the engine is transferred to status code 36, 37, or 38.

36 - Unserviceable Engine In Process Of Repair Or Modification. This status code describes an unserviceable engine in process of being repaired or modified. Status code 36 commences on the date the engine is inducted and terminates on the date the repair or modification has been completed and the engine has been tested, preserved, and packaged. The designated stocking activity should be notified immediately that the engine is available.

37 - Engine Awaiting Disposition Intructions. This status code applies to an unserviceable engine that is being held at a designated repair point awaiting Inventory Manager determination either to strike it from the engine inventory or to retain it in the inventory or to retain it in the inventory and effect repair.

38 - Unserviceable Engine That Is No Longer Suitable For Retention. This status code describes an unserviceable engine which the Inventory Manager has determined to be no longer suitable for retention in the engine inventory and which is awaiting strike action to be taken and the engine to be transferred to status code 49.

2.4 Other

40 - Calibration/Correlation or Special Test Engine. This status code applies to an RFI engine to be used as a calibration or correlation engine.

41 - Unserviceable Test Engine. This status code applies to an unserviceable engine that has been designated for special testing. The use of this status code will be restricted to the Inventory Manager's direction.

42 - Engine Held in Excess. This status code applies to serviceable or unserviceable engine-module which is held in excess of Navy requirements. The use of this status code will be restricted to the Inventory Manager's direction.

FIGURE 5. Detailed explanation of status codes and star codes for marine shipboard gas turbine ETR - Continued

Source: https://assist.dla.mil -- Downloaded: 202610-26T10:35Z
Check the source to verify that this is the currentversion before use.

10. Preparation Instructions (cont'd)

46 - Loaned Engine Uninstalled. This status code applies to uninstalled engines that have been loaned to commercial contractors or other government agencies. The use of this status code will be restricted to the Inventory Manager's direction. This status code commences on the date the engine is loaned and terminates when the engine has been: returned to the Navy; stricken from the active engine inventory; or transferred to status code 47.

47 - Loaned Engine Installed. This status code applies to engines loaned to commercial contractors or other government agencies which have been installed in a ship or test platform. Status code 47 commences on the date the loaned engined is installed and terminates when the engine is removed and returned to status code 46. The use of this status code will be restricted to the Inventory Manager's direction.

48 - Training Engine. This status code applies to engines designated for use in naval training. The use of this status code will be restricted to the Inventory Manager's direction.

49 - Stricken. This status code applies when an engine is stricken from the Navy engine inventory.

3. Definition. Star codes describe or give reasons for transactions such as strikes, transfers, acquisitions, or remarks of engines. A status code is often used without a star code, but a star code must never be used except in conjunction with a status code. A star code merely amplifies or qualifies the status code.

4. Listing of Star Codes.

4.1 Acquisitions

50 - New Engine Accepted From Manufacturer. This code is used to report the initial receipt from the manufacturer of a new engine being accepted into the Navy inventory.

51 - Engine Accepted From Another Government Source, a Foreign Government or to Add an Engine For Any Other Reason. This code is used to report the receipt of an engine not currently in inventory from another government source, from a foreign government, or to add an engine to the inventory for any other reason, except a new engine received from the manufacturer.

52 - Engine Converted to a New Series (Dash) Number. This code is used to report a conversion of an engine from one series to another series.

FIGURE 5. Detailed explanation of status codes and star codes for marine shipboard gas turbine ETR - Continued

Source: https://assist.dla.mil -- Downloaded: 202610-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

4.2 Transfers and Receipts

61 - Acknowledgement of Receipt of Spare Parts. This code is used to report receipt of repair parts which were delaying repair of engines in status code 36 for which star code 94 had previously been reported.

4.3 Miscellaneous

94 - Report of Repair Part/Component Shortage. This code reports an engine which cannot be processed to a serviceable status for lack of part(s) or component(s). This code will only be used after appropriate action has been taken to acquire such part(s)-component(s) through proper supply channels. star code 94 is used in conjunction with status codes 24, 35 or 36. The use of Star code 94 does not constitute authority to cannibalize.

FIGURE 5. Detailed explanation of status codes and star codes for marine shipboard gas turbines - Continued

Source: https://assist.dla.mil -- Downloaded: 202610-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

NEWLY MANUFACTURED ITEMS REPORT FORMAT

FM:

TO:

1. Contract No. or Task No.

2. Data Elements.

   a. Nomenclature

   b. Manufacture Date

   c. Part Number

   d. Engine Serial Number or BUNO, or

   e. Component Serial Number

   f. Manufacturer Code

   g. Work Unit Code

   h. Type Equipment Code

FIGURE 6. Newly manufactured items report format

Source: https://assist.dla.mil -- Downloaded: 202640-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

REMOVED, REPAIRED, REWORKED, SCRAPPED, OR INSTALLED ITEMS REPORT FORMAT

FM:

TO:

1. Contract No. or Task No.
2. Data Elements.
   a. Nomenclature
   b. Action Date
   c. Part Number
   d. Serial Number
   e. Manufacturer Code
   f. Work Unit Code
   g. Type Equipment Code
   h. Cycle Counts Since New
   i. Cycle Counts Since Overhaul-Rework-Repair
   j. Action Taken Code
   k. Part Number next higher assembly (complete engine and airframes are exempted)
   l. Serial Number next higher assembly (complete engine and airframes are exempted)

FIGURE 7. Removed, repaired, reworked, scrapped or installed items report format

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T10:35Z
Check the source to verify that this is the current version before use.

10. Preparation Instructions (cont'd)

ACTION TAKEN CODES

All codes listed below may be used for both on-equipment or off-equipment work unless otherwise noted.

Code	Explanation

A. Items of Repairable Material or Weapon/Support System Discrepancy Checked No Repair Required. This code is used for all discrepancies which are checked and found that either the reported deficiency cannot be duplicated, or the equipment is operating within allowable tolerances. Adjustments may be made under this code if the purpose of the adjustment is to peak or optimize performance. If the purpose of the adjustment is to bring the equipment within allowable tolerances, action taken code C should be used.

B. Repair or replacement of attaching units, seals, gaskets, packing, tubing, hose, fittings, etc., that are not integral parts of work unit coded items or components. These parts are not identified by work unit codes (WUCs) and are normally a connecting or attaching link between two or more components that do have WUCs assigned. Therefore, when items of this nature are repaired or replaced, this action taken code is used. In case of doubt regarding which component to identify, the WUC of the component serviced will be used.

C. Repair. This code is entered when a repairable item of material which is identified by WUC is repaired. Repair includes cleaning, disassembly, inspection, reassembly, lubrication, and replacement of integral parts; adjustments are included in this definition if the purpose of the adjustment is to bring the equipment within allowable tolerances. This code also applies to the correction of a discrepancy on a weapon/support system, when appropriate.

P. Removed. This code is entered when an item of material is removed and only the removal is to be accounted for.

Q. Installed. This code is entered when an item is installed and only the installation action is to be accounted for.

R. Remove and Replace. This code is entered when an item of material is removed due to a suspected malfunction and the same or a like item is reinstalled. (1)

T. Removed and Replaced for Cannibalization. This code is used when an item of material is removed and replaced as a cannibalization action.

FIGURE 8. Action taken codes

Source: https://assist.dla.mil -- Downloaded: 202640-26T10:35Z
Check the source to verify that this is the current version before use.