FF-I-00535a(GSA-FSS)
June 15, 1966
SUPERSEDING
FF-I-00535(GSA-FSS)
October 19, 1964, and
FF-I-00530(GSA-FSS)
October 20, 1964

INTERIM FEDERAL SPECIFICATION

INCINERATOR, STATIONARY, CLASSIFIED WASTE (SECURITY)

This Interim Federal Specification was developed by Standardization Division, Federal Supply Service, General Services Administration, Washington, D. C., 20406, based upon currently available technical information. It is recommended that Federal agencies use this document in procurement and forward any recommendations for changes to the preparing activity at the address shown above.

1. SCOPE AND CLASSIFICATION

1.1 Scope. This specification covers incinerators in two sizes which are designed to meet the document destruction criteria for classified material set forth in Executive Order 10501, as amended, "Safeguarding Official Information in the Interest of the Defense of the United States." The incinerators are intended for use in the destruction of classified documents and related paper products including film, negatives, and those products of combustible nature manufactured of cellulose base materials. The incinerators are not designed to burn wood, wood products, or refuse.

1.2 Classification.

1.2.1 Size. The incinerators furnished under this specification shall be of the following sizes, as specified (see 6.1).

Size-1 - Burning capacity 250 to 450 pounds of material an hour.
Size-2 - Burning capacity 95 to 120 pounds of material an hour.

2. APPLICABLE DOCUMENTS

2.1 Specifications and standards. The following specifications and standards, of the issues in effect on the date of invitation for bids, or request for proposal form a part of this specification to the extent specified herein.

Federal Specifications:

CC-M-641 - Motor, Alternating Current, Integral Horsepower.
TT-C-490 - Cleaning Methods and Pretreatment of Ferrous Surfaces for Organic Coating.
TT-P-28 - Paint, Aluminum, Heat Resisting, Silicon.
WW-C-440 - Clamp, Hose.
PPP-B-601 - Boxes, Wood, Cleated-Plywood.
PPP-B-621 - Boxes, Wood, Nailed and Lock-Corner.
PPP-B-636 - Boxes, Fiberboard.
PPP-C-650 - Crates, Wood, Open and Covered.
PPP-C-843 - Cushioning Material, Cellulose.

Federal Standard:

Fed. Std. No. 123 - Marking for Domestic Shipment (Civil Agencies).

FSC 4540

Source: https://assist.dla.mil -- Downloaded: 202640-26T11:47Z
Check the source to verify that this is the currentversion before use.

(Activities outside the Federal Government may obtain copies of Federal Specifications, Standards, and Handbooks as outlined under General Information in the Index of Federal Specifications and Standards and at the prices indicated in the Index. The Index, which includes cumulative monthly supplements as issued, is for sale on a subscription basis by the Superintendent of Documents, U.S. Government Printing Office, Washington, D.C., 20402.

(Single copies of this specification and other product specifications required by activities outside the Federal Government for bidding purposes are available without charge at the General Services Administration Regional Offices in Boston, New York, Washington, D.C., Atlanta, Chicago, Kansas City, Mo., Dallas, Denver, San Francisco, Los Angeles, and Seattle, Wash.

(Federal Government activities may obtain copies of Federal Specifications, Standards, and Handbooks and the Index of Federal Specifications and Standards from established distribution points in their agencies.)

Military Specifications:

MIL-A-1154 - Adhesive, Bonding, Vulcanized, Synthetic, Rubber to Steel.
MIL-P-116 - Preservation, Methods of.
MIL-S-45180 - Sealing Compound, Gasket, Hydrocarbon, Fluid, Water Resistant.

Military Standard:

MIL-STD-129 - Marking for Shipment and Storage.

(Copies of Military Specifications and Standards required by contractors in connection with specific procurement functions should be obtained from the procuring activity or as directed by the contracting officer.)

2.2 Other publications. The following document forms a part of this specification to the extent specified herein. Unless otherwise indicated, the issues in effect on date of invitation for bids or request for proposal shall apply.

National Board of Fire Underwriters:
Electrical Wiring Apparatus,
Phamphlet No. 70.

(Application for copies should be addressed to the National Board of Fire Underwriters, 85 John Street, New York 38, New York).

3. REQUIREMENTS

3.1 Preproduction sample. Before production is commenced, a sample of the finished commodity shall be submitted or made ready for approval of the contracting officer or his authorized representative for inspection and tests to determine compliance with this specification. The contractor shall notify the designated Regional Quality Control Division set forth in the notice of award of the availability of the sample. The approval of the preproduction sample authorizes the commencement of production, but does not relieve the contractor of responsibility for compliance with all other applicable provisions of this specification. Production units shall not vary from the approved preproduction sample in design or construction without written approval of the contracting officer.

3.2 Material. Material used in the fabrication of the incinerators shall be as indicated in the specification drawings (see 6.2). Materials not definitely specified shall be of good commercial quality, suitable in every respect for the purpose intended.

3.2.1 Protective coating. When material are used in the fabrication of the incinerators that are subject to deterioration when exposed to climatic and environmental conditions likely to be encountered during service usage, they shall be protected against such deterioration in a manner which will in no way prevent compliance with the performance requirements of this specification. The use of any protective coating which will crack, chip, or scale with age or extremes of climate and environmental conditions shall be advoided.

Source: https://assist.dla.mil -- Downloaded: 202640-26T11:47Z
Check the source to verify that this is the current version before use.

3.3 Construction.

3.3.1 Fabrication, and assembly. Component parts of the incinerator shall be fabricated and assembled in accordance with the specification drawing (see 6.2). Regardless of the drawing, the fabricator shall be responsible that the respective parts fit together properly for the intended use. Completely assembled incinerators shall comply with the test requirements in 4.5.

3.3.2 Construction precautions. The fabricator shall pay particular attention to the following points during construction of the size-1 and -2 incinerators:

For size-1 (see specification drawing No. 254):

(a) Insure that all louvers open in the proper direction and are free from burrs, and rough edges.

(b) During welding processes care must be taken not to warp the Liner Upper Cone nor to allow gaps to occur between the Basket Top Band and the Liner Upper Cone.

(c) Care must be taken not to warp the Base Plate during welding processes.

(d) Care must be taken not to burn holes in the Radiation Shield during welding processes.

(e) The proper angularily of the Nozzles is critical and it is essential that the Nozzles be aligned as shown in the assembly drawing.

(f) The Reflector Assembly must be collapsed enough to pass by the Firing Door inward projection when the Reflector Assembly is inserted into the Outer Shell Middle Assembly.

(g) The end of the Damper Housing Assembly should be used as a form when the two parts of the Flexible Duct are cemented together.

(h) The notch in the Central Cone Base Ring on the Liner Bottom Section Assembly should be aligned with the proper end of the Stiffener on the Outer Shell Bottom Assembly when the complete Inner Liner Assembly is inserted into the Outer Shell Assembly with the Reflector Assembly installed as shown in the Incinerator Assembly drawing.

(i) The Inner Liner Assembly drawings and the Outer Shell Assembly drawings are marked with assembly reference lines to facilitate proper orientation during reassembly.

(j) To avoid damage to the Seal Strip and to minimize difficulty during final assembly, tape may be used to hold the Seal Strip in place.

(k) To prevent slippage between the Damper Shaft and the hub of the Damper Handle Assembly, the hub and shaft must be drilled and taper reamed to take a small taper pin (A Number 0 x 1-1/4 steel taper pin is recommended). With the damper forcibly held in the off position the taper pin should be driven in place, any excess length cut off, and the small diameter end of the pin peened over.

(l) A Sector Stop must be provided to be clamped over the Sector Stop with set screws.

(m) A one inch curved reinforcing strip (same type and gage as the Liner) must be welded on the inside of the Liner across the bottom of the door opening.

Source: https://assist.dla.mil -- Downloaded: 202640-26T11:47Z
Check the source to verify that this is the current version before use.

For size-2 (see specification drawing No. 362):

(a) Insure that all louvers open in the proper direction and that the louvers are free from burrs and rough edges.

(b) During welding processes care must be taken not to warp the Liner Upper Cone nor to allow gaps to occur between the Basket Top Band the Liner Top Cone.

(c) Care must be taken not to warp the Bottom Plate during welding processes.

(d) Care must be taken not to burn holes in the Radiation Shield and in the Door Shield during welding processes.

(e) The proper angularity of the Nozzles' is critical and important to the proper air flow and it is essential that they be aligned as shown in the assembly drawings.

(f) The notch in the Liner Central Base Cone Ring must be aligned with the proper end of the Stiffener when the complete Inner Liner Assembly is inserted into the Outer Shell Assembly with the Radiation Shield installed as shown in the Incinerator Assembly drawing.

(g) The Inner Liner Assembly drawings and the Outer Shell Assembly drawings are marked with reference lines to facilitate proper orientation during assembly.

(h) During final assembly care must be taken to avoid damage to the Seal Strip attached to the Liner Top Cone Assembly.

(i) Installation of the Door Latch Assembly in the Incinerator Assembly requires that the Screws be inserted from the bottom so that the Jam Nuts are on top (This will provide maximum clearance between the Damper Handle Assembly and the head of the Screw during operation of the Handle Assembly under service conditions).

(j) Care must be taken not to damage the Sound Insulation during assembly process.

(k) Insure the proper fit between Blower Assembly and the Vibration pads which secure the Blower Assembly in the side-to-side position. The front-to-back position is determined by placing the separate parts of the Plenum Chamber Plate Assembly in position in the Outer Shell Bottom Assembly after the Blower Assembly is installed. The alignment is then checked by examining the fit of the Gasket around the part of the Blower Assembly which protrudes upward through the Plenum Chamber Plate Assembly. To insure that the Gasket fits properly, the Blower Assembly should be shifted forward or backward as needed.

(l) The Blower Cross Bar shall be placed on the angle iron feet at the rear of the Blower Assembly, and positioned directly under the Rear Bracket Cover Assembly. The Vertical Vibration Pad should be inserted between the Blower Cross Bar and the Rear Bracket Cover Assembly. The Nuts on the Rear Bracket Cover Assembly should be slightly tightened, to take up slack. The Front Bracket Cover Assembly and the Front Vibration Pad should then be installed and the Nuts tightened to take up slack. The position of the Blower Assembly should be rechecked by examining the Gasket. Insure that there is no metal-to-metal contact between the Blower Assembly and any part of the Outer Shell Bottom Assembly that might defeat the purpose of the Vibration Pads. When the position is correct, the Blower Cross Bar should be welded to the

Source: https://assist.dla.mil -- Downloaded: 202640-26T11:47Z
Check the source to verify that this is the current version before use.

angle iron feet of the Blower Assembly. During the welding process care must be taken not to overheat the portions of the Blower Pads adjacent to the welds. The Nuts on the Rear Bracket Cover Assembly and on the Front Bracket Cover Assembly should then be tightened equally until reasonable pressure is exerted on the Pads.

(m) When the Damper Handle Assembly is attached to the Shaft of the Blower and Base Assembly, it is important that the damper blade inside the Blower Assembly be securely in the OFF position when the Latch of the Handle Assembly is seated in the large notch (corresponding to the OFF position of the Sector Plate.) To accomplish this, both set screws in the Coupling should be tightened; then, the Shaft should be grasped near the Coupling with a vise grip type pliers and torque should be applied in the clockwise direction until the damper blade is held forcible in the OFF position. Both set screws in the Hub of the Handle Weldment should be securely tightened. The position should be rechecked by operating the Handle Assembly; a slight amount of spring action should be evident when the Handle Assembly is latched in the OFF position so as to insure that the damper blade is forced into its OFF position. As a precaution against any subsequent slipping of the set screws in the Hub, and Shaft, the Hub and Shaft should be drilled and taper reamed to take a small taper pin (A No. 0 x 1-1/4 steel taper pin is recommended.) The pin should be driven in place, any excess length cut off, and the small diameter end of the pin peened over.

(n) A one inch curved reinforcing strip (same type and gage as the liner) must be welded on the inside of the Liner across the bottom of the door opening.

(o) The Sector Plate must be case hardened to a hardness of Rockwell 45 to 50 C.

(p) The bottom slide on the Handle Weldment must be positioned so as to clear the Sector Plate.

(q) The holes in the Gasket must be of a dimension so as to provide for maximum adjustment around the blower outlet.

(r) The Thermocouple circuit should be checked after it is connected by holding a lighted match or other small flame at the small end or bead of the thermocouple, to insure that an increase of temperature is indicated on the temperature control. The temperature control needle should move to the right to indicate a proper connection.

3.4 Incinerator blower assembly. The blower and frame assemblies shall be welded heavy gage steel construction; all parts shall be properly protected against corrosion; bearings shall be lubed at the factory and shall not require any further lube for approximately five years.

3.4.1 Size-1 blower assembly. The blower assembly for the size-1 incinerator shall be in accordance with the following specifications.

Type: Shaft mounted, rotary, squirrel-cage blower, bottom horizontal discharge, clockwise rotation.

Outlet: 8-3/8 x 10-1/8 inches outside dimensions; centerline of outlet located 10-3/8 inches from horizontal centerline of main shaft and extends 12-7/8 inches from the vertical centerline of the main shaft.

Power: Shaft connected electric motor; blower frame shall provide mounting for standard NEMA motor frame No. 215.

Source: https://assist.dla.mil -- Downloaded: 202640-26T11:47Z
Check the source to verify that this is the current version before use.

Envelope Dimensions: Blower, including motor, shall be of the following envelope dimensions, ± 1/2-inch:

Height 30 inches.
Depth 28-1/4 inches.
Width 26-3/8 inches.

Rating: 2400 C. F. M. ; 12 S. P. ; 3500 R. P. M.

3.4.2 Size-2 blower assembly. The blower assembly for the size-2 incinerator shall be in accordance with the following specifications.

Type: Shaft mounted, rotary, squirrel-cage blower, vertical discharge, counter clockwise rotation.

Outlet: 7-1/4 x 6 inches outside dimension; centerline of outlet located 7-3/16 inches from vertical centerline of main shaft and 18-3/4 inches (plus or minus 1/16 inch) from base.

Control: Manually operated damper; 5/8 inch diameter damper shaft located on horizontal plane through main blower shaft and to extend 4-9/16 inches from centerline of housing assembly.

Power: Shaft connected electric motor; blower frame shall provide mounting for standard NEMA motor frame No. 184.

Envelope Dimensions: Blower, including motor shall be of the following envelope dimensions, ± 1/16-inch:

Height: 18-3/4 inches
Depth: 20 inches
Width: 21 inches

Rating: 860 C. M. F. ; 8.6 S. P. ; 3500 R. P. M.

3.5 Blower motor. The blower motor for incerators shall conform to the applicable requirements of CC-M-641, and shall be in accordance with the standards of the National Electrical Manufacturers Association. Motors for use in overseas installation shall be supplied for electrical characteristics and ratings specified by the procuring activity (see 6.1). Unless otherwise specified, the motor shall be a self cooled, dripproof, 3 phase, 60 cycle, 220/440 volt squirrel cage induction motor. All motors shall be capable of developing sufficient power to maintain continuous full load output without exceeding the temperature requirements specified in CC-M-641.

3.5.1 Motor starter. The motor starter shall be a general purpose starter for alternating current motors of the type normally used by the contractor for the particular application intended.

3.6 Electrical wiring. Exterior wiring shall be done in rigid metallic conduit securely mounted. The AC control voltage shall be obtained from a transformer with an isolated secondary winding. The control start-stop switch shall be securely mounted, wired and installed in a position convenient to the operator. Both power and control wiring shall comply with the Electrical Standards of the National Board of Fire Underwriters' Pamphlet No. 70.

3.7 Incinerator stack. The incinerator stacks shall be of double wall design and shall be fabricated of not less than 16 gage (0.063 inch) AISI 310 stainless steel. The outer wall of the stack shall be separated from the inner pipe by not less than one inch air space. The stacks for size-1 incinerators shall provide a minimum of 200 square inches of cross sectional exhaust area. Stacks for size-2

Source: https://assist.dla.mil -- Downloaded: 202610-26T11:47Z
Check the source to verify that this is the current version before use.

incinerators shall provide a minimum of 64 inches of cross sectional exhaust area. All stack joining shall be of butt-welded construction, including the joint where fabricated stacking joins the vent pipe. Where one or both materials are stainless steel, the welding process shall be of either inert gas, heliarc, or arc welding type. An adjustable wall thimble of 14 gage steel, zinc coated shall be provided with each incinerator unit. The stack shall not be painted because of high temperatures involved.

3.7.1 Stack precautions. Incinerator stacking shall pass to the outside at a minimum of eight feet above ground level in a vertical manner. The system shall not be tied into any chimney which provides functions to any other applicance or heating device or which does not have a fire-resisting flue.

3.8 Finish.

3.8.1 Cleaning methods. Prior to painting, all exterior ferrous metal surfaces shall be cleaned in accordance with applicable methods or types specified in TT-C-490.

3.8.2 Painting. Painting shall not be performed until all testing is completed. The exterior shall then be painted with a heat resisting aluminum paint conforming to TT-P-28.

3.9 Markings. Each incinerator shall have stenciled across the front and above the door in easily read lettering not less than 1 inch in height the following:

"CLOSE DAMPER BEFORE OPENING DOOR"

The words "ON" and "OFF" shall be stenciled in proper position on the top of the air duct beside the handle. The lettering shall be easily read and not less than 1 inch in height. Mating components shall have a red paint indicator to assure proper remating during assembly.

3.10 Workmanship. The incinerators, including all parts and accessories shall be fabricated and finished in a workmanlike manner. Incinerators shall be free from blemishes, burrs, and sharp edges. Dimensions, radi of fillets, and marking of parts and assemblies shall be accurate. Soldering, welding, brazing, painting, reveting, and wiring shall be thorough and secure. Lockwashers, cotter pins, clips, retainers, or other features shall be used to prevent loosening of screws, nuts, and bolts.

3.11 Instruction and assembly manuals. Instruction manuals for the use of personnel responible for the assembly, operation, and maintenance of the incinerator shall be furnished by the manufacturer to provide all instructions necessary for proper assembly and operation of the unit.

3.12 Spare parts kit. The following listed spare parts shall be packaged and furnished with the incinerators.

For the size-1:

Description	Drawing Number	Each
"V" Band Assembly	354-110	1
Basket Assembly	111	1
Clamp Band Assembly	217	2
Wedge	329	4
Door Gasket	347	2
Door Gasket	348	2
Cotter Pin	350	8
Screw	357	24
Flange Gasket	396	45 ft.
Cap Screw	397	24
Sight Glass	398	2
Gasket	399	4
Nut	403	24
Lockwasher	404	24

Source: https://assist.dla.mil -- Downloaded: 20261010-26T11:47Z
Check the source to verify that this is the current version before use.

Description	Drawing Number	Each
Flexible Duct	434	1
Duct Flange Gasket	438	1
Nut	447	24
Lockwasher	448	24
Thermocouple Assembly	454	1

In addition, one 3 ounce tube of Sealing Compound conforming to MIL-S-45180A, shall be provided for use in cementing the Door Gasket to the Door Assembly.

For the Size-2:

Description	Drawing Number	Each
Basket Assembly	362-105	1
"V" Band Clamp Assembly	208	1
Wedge	349	4
Door Gasket	359	2
Door Gasket	360	2
Sight Glass	370	2
Gasket	372	4
Item # 130	000	4
143	000	8
144	000	4
145	000	8
146	000	12 ft.
148	000	4
Thermocouple Assembly	378	
	380	1

In addition, one 3 ounce tube of Sealing Compound conforming to MIL-S-45180, and one 3 ounce tube of Adhesive conforming to MIL-A-1154, shall be provided as part of the spare parts kit.

4. QUALITY ASSURANCE PROVISIONS

4.1 Responsibility for inspection. Unless otherwise specified in the contract or purchase order, the supplier is responsible for the performance of all inspection requirements as specified herein. Except as otherwise specified, the supplier may utilize his own facilities or any commercial laboratory acceptable to the Government. The Government reserves the right to perform any of the inspections set forth in the specification where such inspections are deemed necessary to assure that supplies and services conform to prescribed requirements.

4.2 Preproduction sample inspection. Examination and testing of the preproduction sample shall be made on a completely fabricated item for all provisions of this specification before regular production is started.

4.2.1. Component and material inspection. In accordance with 4.1, the supplier is responsible for insuring that components and materials used are manufactured, tested and inspected in accordance with the requirements of referenced subsidiary specifications and standards to the extent specified, or, if none, in accordance with this specification.

4.3 Inspection lot. A lot shall consist of the incinerators produced at one time by one manufacturer, from the same materials, under the identical fabricating conditions. The inspection lot for non-destructive inspection shall be designated by the Government inspector.

4.4 Inspection of preparation for delivery requirements. An inspection shall be made to determine that the preservation, packaging, packing, and marking requirements comply with section 5 of this specification.

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T11:47Z
Check the source to verify that this is the current version before use.

4.5 Tests.

4.5.1 General. The preproduction sample (see 3.1), and each incinerator offered for acceptance shall comply with the tests specified in 4.5.2. Proper functioning of one incinerator shall not constitute a basis for acceptance of an entire lot. Rejection of an incinerator offered for acceptance shall not preclude the manufacturer from correcting the condition which forms the basis for rejection, and from reworking a rejected part to remedy such defect for resubmission to inspections and tests. However, all units and parts so reworked shall be so indicated to the inspector.

4.5.2 Test methods.

4.5.2.1 Size-1. The size-1 incinerator shall be subjected to the tests specified hereunder.

4.5.2.1.1 Cold air flow test. The incinerator, with blower, shall be connected to an appropriate electrical source. The manometer shall be filled with water (with or without dye) connected by the Rubber Tubing to the Pressure Tap Fitting attached to the Bottom Assembly Outer Shell. The cold air-flow tests shall be made while the incinerator assembly is empty, in order (1) to check for leaks at the gasketed joints, and (2) to measure the plenum-chamber pressure, which is an indication of the overall satisfactory condition of the air flow passages such as the louvers in the Top Liner Assembly, the Liner Middle Section Assembly and the Liner Bottom Section Assembly; the Nozzles and the Flexible Duct and the damper, comprised of the Damper Housing Assembly, the Butterfly Assembly and the Damper Shaft.

To check for leaks, the Blower shall be turned on and the damper opened by moving the Handle Assembly to the "Operating" position on the Control Plate. A check shall then be made for air leaks at each of the gasketed joints of the Incinerator Assembly.

Leakage shall be judged excessive if the flame from a lighted "paper book" match is extinguished when held within a 1-inch distance of the source of leakage. Excessive leakage of air at any of the gasketed joints shall be corrected by appropriate measures before the cold air-flow testing is continued.

To measure the plenum-chamber pressure, the Blower shall be turned on and the damper set at the "Operating" position as described above. Under these conditions, the internal air pressure in the lower plenum-chamber, as indicated by the Manometer, shall be between 6.0 and 7.0 inches of water. If the pressure is not within this range, an examination shall be made of all air-flow passages, as described above, to determine the cause. Any errors or defects stemming from the manufacture of the Incinerator Assembly that contribute to internal pressures outside the range of 6.0 to 7.0 inches of water shall be corrected by the manufacturer. The measurement of the plenum-chamber pressure shall then be re-run before proceeding with the paper-burning test.

4.5.2.1.2 Paper-Burning Test. The paper-burning test shall consist of burning 500 pounds of selected paper during a period of 2 hours. Prior to the burning test, the Thermocouple shall be inserted into the fitting on the stack; the head of the Thermocouple shall be located at the center of the stack. The Temperature-Indicating Instrument shall then be properly connected to the Thermocouple with the Extension Lead Wire.

A supply of reasonably dry paper shall be obtained and used for the burning test. Typical paper from discarded office files, such as bond and onionskin typing paper, file cards, and file folders (excluding newspapers or telephone books) shall be considered suitable.

At the beginning of the burning test, the Door Assembly shall be opened and 50 pounds of mixed papers shall be loaded into the Incinerator Assembly. A few crumpled sheets of paper shall be ignited and scattered over the paper charged; the Door Assembly shall be closed and the Blower turned on. During the first 3 to 5 minutes the Handle Assembly shall be advanced gradually from the "Closed" to the "Operating" position on the Control Plate while observing the progress of ignition. When ignition is well established, intermittent feeding of 15-pound batches of paper shall be started. Each of thirty 15-pound batches shall be fed by (1) quickly moving the Handle Assembly to the "Closed" position; (2) opening the Door Assembly; (3) charging the paper; (4) closing the Door Assembly; and (5) moving the Handle Assembly quickly to the "1/2 Open" position (third notch), and then gradually to the "Operating" position (fifth notch), so as to avoid suddenly reaching excessive stack-gas temperatures above 1800 F. Successive batches shall be fed at intervals of about 3 minutes, or less, depending on the rate of burning; the pile of paper in the incinerator shall not be allowed to decrease below the initial level (corresponding to the

Source: https://assist.dla.mil -- Downloaded: 202640-26T11:47Z
Check the source to verify that this is the current version before use.

first 50 pounds) or to increase above a level approximately 6 inches below the bottom of the loading opening in the Liner Middle Section Assembly.

Near the end of the burning test, the slow burning residue shall be stirred once by manual poking, to obtain more rapid and complete burnout. If observation indicates that burning has stopped, any unburned paper or char shall be re-ignited once and the burning continued at low air flow (with the Handle Assembly at the "1/4 Open" or "1/2 Open" position) for final burnout.

Results of the burning test shall be considered satisfactory if the following conditions are achieved:

(a) Incineration of not less than 500 pounds of paper shall be completed in two hours.
(b) The residual charred paper, excluding the ash which remains at the end of the test period, shall not exceed 1-1/2 pounds in weight.
(c) Any piece of charred paper or raw paper carried out in the stack gases shall be no larger than that which would pass freely through the mesh opening of the Basket Assembly.
(d) All movable parts associated with the loading door shall function properly, as intended.

4.5.2.2 Size-2. The size-2 incinerator shall be subjected to the tests specified hereunder.

4.5.2.2.1 Cold air flow test. The incinerator, with blower, shall be connected to an appropriate electrical source. A manometer and a length of rubber tubing and a brass fitting shall be provided for measurement of the plenum chamber pressure. The cold air flow test shall be made while the incinerator is empty, in order, (1) to check for leaks at the gasketed joints and (2) to measure the plenum chamber pressure, which is an indication of the overall satisfactory condition of the air flow passages such as the louvers, the nozzles, and the damper assembly. To check for leaks, the motor-blower shall be turned on and the damper opened by moving the handle assembly to the "Operating" position on the sector plate. Number 11 notch is used for 50 cycle operation and number 5 notch for 60 cycle operation. The stop on the sector plate of the damper shall be set and a check made for air leaks at each of the gasketed joints of the Incinerator Assembly. Leakage shall be judged excessive if the flame from a lighted "paper book" match is extinguished when held within a 1-inch distance of the source of leakage. Excessive leakage of air at any of the gasketed joints shall be corrected by appropriate measures before the cold air-flow testing is continued.

To measure the plenum-chamber pressure, the Blower shall be turned on and the damper set at the "Operating" position as described above. Under these conditions, the internal air pressure in the plenum-chamber, as indicated by the Manometer, shall be between 2.7 and 3.6 inches of water. If the pressure is not within this range, an examination shall be made of all air-flow passages to determine the cause. Any errors or defects stemming from the manufacture of the Incinerator Assembly that contributes to internal pressure outside of the range of 2.7 to 3.6 inches of water shall be corrected by the manufacturer. The measurement of the plenum-chamber pressure shall then be re-run before proceeding with the paper-burning test.

4.5.2.2.2 Paper-burning test. The paper burning test shall consist of burning 190 pounds of selected paper during a period of two hours. Prior to the burning test, the Thermocouple shall be inserted into the fitting on the stack; the head of the Thermocouple shall be located at the center of the stack. The Temperature-Indicating Instrument shall then be properly connected to the Thermocouple with the extension lead wire.

A supply of reasonably dry paper shall be obtained and used for the burning test. Typical paper from discarded office files, such as bond and onionskin typing paper, file cards, and file folders (excluding newspapers) shall be considered suitable.

At the beginning of the burning test, the Door Assembly shall be opened and 22 pounds of mixed papers shall be loaded into the Incinerator Assembly. A few crumpled sheets of paper shall be ignited and scattered over the paper charged; the Door Assembly shall be closed and the motor-blower turned on. During the first 3 to 5 minutes, the Handle Assembly shall be advanced gradually from the "Closed" to the "Operating" position on the Sector Plate to observe the progress of

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T11:47Z
Check the source to verify that this is the current version before use.

ignition. When ignition is well established, intermittent feeding of 6-pound batches of paper shall be started. Each of the twenty-eight 6-pound batches shall be fed by (1) quickly moving the Handle Assembly to the "Closed" position; (2) opening the Door Assembly; (3) charging the paper; (4) closing the Door Assembly; and (5) moving the Handle Assembly slowly to the "Operating" position, so as to avoid suddenly reaching excessive stack-gas temperatures above 1800 degrees F. Successive batches shall be fed at intervals of about four minutes or less, depending on the rate of burning; the pile of paper in the incinerator shall not be allowed to decrease below the initial level (corresponding to the first 22 pounds) or to increase above a level approximately 2- inches below the bottom of the loading opening.

Near the end of the burning test, the slow burning residue shall be stirred once by manual poking to obtain more rapid and complete burnout. If observation indicates that burning has stopped, any unburned paper or char shall be re-ignited once and the burning continued at low air-flow (with the Handle Assembly at a mid-open position) for final burnout.

Results of the burning test shall be considered satisfactory if the following conditions are achieved:

(a) Incineration of not less than 190 pounds of paper shall be completed in two hours.
(b) The residual charred paper, excluding the ash which remains at the end of the test period, shall not exceed 1 pound in weight.
(c) Any piece of charred paper or raw paper carried out in the stack gases shall be no larger than that which would pass freely through the mesh opening of the Basket Assembly.
(d) All movable parts associated with loading door shall function properly, as intended.

5. PREPARATION FOR DELIVERY

5.1 Packaging. Packaging shall be level A, B, or C as specified (see 6.1).

5.1.1 Level A.

5.1.1.1 Disassembly. Disassembly of the incinerator shall be the minimum necessary to safeguard parts vulnerable to damage, pilferage and loss. The blower unit shall be removed. Protruding parts that increase cubage and that can be removed and reassembled without special tools shall be removed. All bolts, nuts, and washers removed shall be placed in mating parts and secured to prevent their loss.

5.1.1.2 Unprotected surfaces. Exterior unprotected metal surfaces requiring the application of a contact preservative shall be coated with type P-1 preservative conforming to the applicable specification listed in and shall be applied in accordance with MIL-P-116.

5.1.1.3 Blower assembly. All opening in the electric motor shall be sealed with tape conforming to PPP-T-60, type II, class 1. Power supply cables shall be coiled to a minimum safe diameter and the coil secured to the blower assembly in a protected location.

5.1.1.4 Unit assembly. The hinged door shall be closed and secured to prevent accidental opening during shipment. The glass faces on recording dials shall be cushioned with material conforming to PPP-C-843. The pyrometer shall be removed and packaged in accordance with MIL-P-116, method IC-2 and the package secured to the unit.

5.1.1.5 Technical manuals. Technical manuals shall be preserved and packaged in accordance with MIL-P-116, method IC-1.

5.1.1.6 Accessory hardware. The accessory shall be packaged in a box conforming to PPP-B-636, V3c, style optional. The individual items shall be wrapped and cushioned to prevent movement within the container. The box shall be closed and waterproofed sealed in accordance with the appendix to the box specification.

5.1.2 Level B or C. The incinerator shall be preserved and packaged in accordance with the supplier's commercial practice.

Source: https://assist.dla.mil -- Downloaded: 202610-26T11:47Z
Check the source to verify that this is the current version before use.

5.2 Packing. Packing shall be level A, B, or C as specified (see 6.1)

5.2.1 Level A.

5.2.1.1 Blower assembly. The blower assembly shall be packed in a close fitting box conforming to PPP-B-621, class 2, style optional; or to PPP-B-601, overseas type. The box shall be closed and strapped in accordance with the applicable specification or appendix thereto.

5.2.1.2 Unit assembly. The unit assembly shall be packed in a crate conforming to PPP-C-650. The contents of the crate shall be blocked and braced to prevent movement during shipment. A waterproof shroud shall be placed over the contents and shall extend to the base of the crate. The shroud shall be fabricated in accordance to the appendix to the crate specification.

5.2.1.3 Technical manuals and accessory hardware. The technical manuals and accessory hardware shall be packed in a close fitting box conforming to PPP-B-621, class 2, style optional, or to PPP-B-601, overseas type, style optional. Strapping shall be in accordance to the appendix to the box specification.

5.2.2 Level B.

5.2.2.1 Blower assembly. The blower assembly shall be packed as specified in 5.2.1.1 except the boxes shall be class 1 or domestic type. Closure shall be in accordance with the appendix to the applicable box specification.

5.2.2.2 Unit assembly. The unit assembly shall be packed as specified in 5.2.1.2 except the waterproof shroud shall not be required.

5.2.2.3 Technical manuals and accessory hardware. The technical publications and accessory hardware shall be packed as specified in 5.2.1.3 except the boxes shall be class 1 or domestic type. Closure shall be in accordance with the applicable box specification.

5.2.3 Level C. The incinerator shall be packed in accordance with the supplier's commercial practice.

5.3 Marking.

5.3.1 Civil agencies. In addition to markings required by the contract or order the packages and shipping containers shall be marked in accordance with Fed. Std. No. 123.

5.3.2 Military activities. In addition to markings required by the contract or order, the packages and shipping containers shall be marked in accordance with MIL-STD-129.

6. NOTES

6.1 Ordering data. Purchaser should select the preferred options permitted herein and include the following information in procurement documents.

(a) Title, number, and date of this specification.
(b) Size required (see 1.2.1).
(c) Motor electrical characteristics required (see 3.5).
(d) Levels of preservation, packaging, packing, and marking required (see 5.1, 5.2, and 5.3).

6.2 Incinerator specification drawings. Specification drawings for incinerators covered by this specification are identified hereunder by individual part name and drawing number. The drawings are available for examination, or will be furnished at cost upon request addressed to the General Services Administration Business Service Center, Washington, D. C. 20407. Certified checks or postal money orders are to be made payable to "General Services Administration, Region 3".

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T11:47Z
Check the source to verify that this is the current version before use.

Set No. 354 for size-1 incinerators costs $38.00 per set and consists of the following listed drawings:

Description	Drawing Number
Incinerator Assembly	354-100
Outer Shell Top Assembly	101
Outer Shell Middle Assembly	102
Outer Shell Bottom Assembly	103
Top Liner Assembly	104
Liner Middle Section Assembly	105
Liner Lower Section Assembly	106
Liner Bottom Cone Assembly	107
Inner Liner Base Cone Assembly	108
Reflector Assembly	109
"V" Band Assembly	110
Basket Assembly	111
Handle Assembly	112
Bottom Liner Section Assembly	113
Door Assembly	114
Stack Ring Assembly	115a
Butterfly Assembly	202
Inspection Door Assembly	203
Door Channel Assembly	204
Door Stiffener	205
Frame	206
Frame Assembly	207
Bottom Plate Assembly	208
Damper Housing Assembly	209
Door Liner	210
Duct Assembly	211
Door Frame Assembly	212
Firing Door Front Panel Assembly	213
Inspection Door Screw Assembly	214
Latch Assembly	215
Handle Weldment	216
Clamp Band Assembly	217
Base Plate	300
Stiffener	301
Stiffener	302
Side Plate	303
Damper Housing Panel	304
Bracket	305
Control Plate	306
Duct Side	307
Duct Side	308
Duct Panel	309
Duct Panel	310
Duct Flange	311
Damper Blade	312
Damper Center Tube	313
Damper Shaft	314
Spacer	315
Collar	316
Step	317
Screw	318
Handle	319
Washer	320
Inspection Door	321
Gasket	322
Channel	323
Nut	324

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T11:47Z
Check the source to verify that this is the current version before use.

Description	Drawing Number
Shield	354-325
Basket Bottom	326
Basket Top Band	327
Hanger	328
Wedge	329
Corner Fill	330
Door Frame	331
Door Frame Top and Bottom	332
Nozzle	333
Nozzle	334
Nozzle	335
Bracket	336
Bracket	337
Washer	338
Spring Retainer	339a
Pivot Bar	340
Door Stiffener	341
Door Stiffener	342
Door Inner Liner	343
Door Liner Flange	344
Door Shield	345
Door Front	346
Door Gasket	347
Door Gasket	348
Washer	349
Cotter Pin	350
Screw	351
Nut	352
Latch Cam	353
Latch Handle	354
Pivot Block	355
Link	356
Screw	357
Washer	358
Cap Screw	359
Nut	360
Cap Screw	361
Nut	362
Hinged Pin	363
Nozzle	364
Pivot Bar	365
Bracket	366
Hinge	367
Latch Block	368
Door Frame	369
Door Frame	370
Stiffener	371
Frame	372
Frame	373
Frame	374
Handle	375
Stiffener	376
Grab Rail	377
Pivot Angle	378
Handle	379
Handle Hub	380
Ball	381
Slide	382
Slide	383
Spring	384
Jam Nut	385

Source: https://assist.dla.mil -- Downloaded: 20260-26T11:47Z
Check the source to verify that this is the current version before use.

Description	Drawing Number
Cover	354-386
Cover	387
Screw	388
Trigger Rod	389
Set Screw	390
Radiation Shield	391
Handle	392
Screw	393
Spring	394
Spring	395
Flange Gasket	396
Cap Screw	397
Sight Glass	398
Gasket	399
Sight Glass Holder	400
Sight Glass Nut	401
Latch	402
Nut	403
Lock Washer	404
Spacer	405
Control Cone Top Section	406
Seal Strip	407
Basket	408
Liner Upper Cone Lower Flange	409
Liner Upper Cone Upper Flange	410
Central Cone Mid Section	411
Central Cone Bottom Section	412
Central Cone Base Ring	413
Liner Middle Section	414
Liner Lower Section	415
Liner Bottom Cone	416
Liner Upper Cone	417
Sight Glass Nipple	418
Sight Glass Nipple	419
Vent Pipe Ring	420a
Coupling Flange	421
Outer Shell Top Ring	422
Coupling Flange	423
Top Ring Outer Shell	424
Outer Shell Flange	425
Outer Shell Top Cone	426
Mid Section Outer Shell	427
Bottom Section Outer Shell	428
Inspection Port Ring	429
Reflector Shield	430
Reflector Shield	431
Reflector Shield	432
Reflector Shield	433
Flexible Duct	434
Clamp	435
Clamp Band	436
Duct Flange Gasket	438
(VOID)	439
(VOID)	440
(VOID)	441
Clamp Block	442
Clamp Block	443
Set Screw	444

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T11:47Z
Check the source to verify that this is the current version before use.

Description	Drawing Number
Lockwasher	354-445
Lockwasher	446
Nut	447
Lockwasher	448
Screw	449
Coupling	450
Bib	451
Coupling	452
Instruments and Mounting Panel	453
Thermocouple Assembly	454
Thermocouple Extension Lead Wire	455
Rubber Tube	456
Pad	457
Pad	458
Insulation Pad	459
Bracket	460
Radiation Shield	461
Screw	462
Nut	463

Set No. 362 for size-2 incinerators costs $38.00 per set and consists of the following listed drawings:

Description	Drawing Number
List of Materials	362-000
Incinerator Assembly	100
Liner Middle Section Assembly	101
Bottom Plate Assembly	102
Liner Bottom Section Assembly	103
Liner Assembly	104
Basket Assembly	105
Liner Top Cone Assembly	106
Outer Shell Middle Section Assembly	107
Outer Shell Top Assembly	108
Modified Temperature Control	109
Temperature Control Assembly	110
Stack Assembly	111a
Door Assembly	112
Blower and Base Assembly	113
Rear Grill Assembly	114
Handle Assembly	115
Outer Bottom Plate Assembly	200
Door Stiffener Assembly	201
Door Front Panel Assembly	202
Frame Assembly	203
Frame Assembly	204
Door Frame Assembly	205
Door Liner Assembly	206
Latch Assembly	207
"V" Bend Clamp Assembly	208
Clean Out Door Cover Assembly	209
Plenum Chamber Plate Assembly	210
Rear Blower Bracket Assembly	211
Front Blower Bracket Assembly	212
Rear Bracket Cover Assembly	213
Front Bracket Cover Assembly	214

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T11:47Z
Check the source to verify that this is the current version before use.

Description	Drawing Number
U Bracket	362-215
Handle Weldment	216
Outer Shell Bottom Assembly	218
Liner Middle Section	300
Liner Bottom Cone	301
Liner Top Cone	302
Liner Top Cone Top Flange	303
Liner Center Cone Middle	304
Liner Center Cone Bottom	305
Liner Center Cone Base Ring	306
Spacer	307
Nozzle	308
Nozzle	309
Nozzle	310
Liner Center Cone Top	311
Stiffener	312
Stiffener	313
Bottom Plate	314
Radiation Shield	315
Radiation Shield	316
Door Frame Side	317
Door Frame Top and Bottom	318
Door Stiffener	319
Grab Rail	320
Door Inner Liner	321
Door Inner Liner Flange	322
Hinge Pin	323
Radiation Shield	324
Pivot Angle	325
Frame	326
Frame	327
Frame	328
Stiffener	329
Door Frame	330
Door Frame	331
Pivot Bar	332
Latch Handle	333
Latch Cam	334
Seal Strip	335
Stiffener	336
Outer Shell Middle Section	337
Outer Shell Top Cone	338
Outer Shell Top Ring	339
Radiation Shield Top Cone	340
Spacer	341
Cleanout Door Cover	342
Cleanout Door Frame	343
Door Shield	344
Basket	345
Basket Top Band	346
Basket Bottom	347
Door Front	348
Wedge	349
Hanger	350
Corner Fill	351
Bracket	352
Hinge	353
Latch Block	354

Source: https://assist.dla.mil -- Downloaded: 202610-26T11:47Z
Check the source to verify that this is the current version before use.

Description	Drawing Number
Radiation Shield	362-355
Bracket	356
Pivot Block	357
Link	358
Door Gasket	359
Door Gasket	360
Pivot Bar	361
Spring Retainer	362a
Washer	363
Bracket	364
Coupling Strip	365
Spacer	366
Flange	367
Flange	368
Sight Glass Holder	369
Sight Glass	370
Sight Glass Nut	371
Gasket	372
Bracket	373
Meter Bracket	374
Radiation Shield	375
Temperature Control, Indicating Type	376
Stack	377a
Thermocouple	378
Spring	379
Wire	380
Plate	381
Plate	382
Plate	383
Stiffener	384
Frame	385
Gasket	386
Flange	387
Stiffener	388
Stiffener	389
Rear Blower Bracket	390
Front Blower Bracket	391
Shim	392
Plate	393
Angle	394
Bar	395
Plate	396
Bar	397
Blower	398
Bottom Plate	399
Outer Shell Bottom	400
Rear Grill	402
Sector Stop	403
Plate	404
Plate	405
Plate	406
Bracket Cover	407
Sector Plate	408
Band	409
Stiffener	410
Cover	411
Handle	412

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T11:47Z
Check the source to verify that this is the current version before use.

Description	Drawing Number
Trigger Rod	362-413
Ball	414
Slide	415
Slide	416
Hub	417
Cover Plate	418
Latch	419
Cover	420
Cover	421
Spring	422
Vibration Pad	423
Vibration Pad	424
Shaft	425
Coupling	426
Cleanout Door Gasket	427
Sound Insulation	428
Gasket	429
Stiffener, Inner Liner	431
Flange Detail	432
Plenum Chamber Plate Detail	433

6.3 Supersession data. This specification includes the requirements of FF-I-00530(GSA-FSS), dated October 20, 1964.

GSA DC 66-20394

Source: https://assist.dla.mil -- Downloaded: 2026-10-26T11:47Z
Check the source to verify that this is the current version before use.