MILITARY SPECIFICATION

QUADRANT, FIRE CONTROL: ELEVATION M14E1

1. SCOPE

1.1 This specification covers one type of elevation quadrant which measures elevation angles in artillery weapons. The level vials on this quadrant are radioactively illuminated.

2. APPLICABLE DOCUMENTS

2.1 The following documents, of the issue in effect on date of invitation for bids or request for proposal, form a part of this specification to the extent specified herein.

SPECIFICATIONS

Military

MIL-F-13926	Fire Control Materiel; General Specification Governing the Manufacture and Inspection
MIL-P-14232	Parts, Equipment and Tools for Army Materiel, Packaging and Packing of
MIL-I-45607	Inspection Equipment, Supply and Maintenance of

STANDARDS

Military

MIL-STD-105	Sampling Procedures and Tables for Inspection by Attributes
MIL-STD-109	Quality Assurance Terms and Definitions

DRAWINGS

U.S. Army, Frankford Arsenal

F11730915	Quadrant, Fire Control: Elevation M14El

PACKAGING DATA SHEET

11730915	Packaging of Quadrant, Fire Control: Elevation M14E1

FSC 1290

Source: https://assist.dla.mil -- Downloaded: 2026-10-22T20:23Z
Check the source to verify that this is the current version before use.

(Copies of specifications, standards, drawings and packaging data sheets required by suppliers in connection with specific procurement functions should be obtained from the procuring activity or as directed by the contracting officer.)

2.2 Other publications.- The following document forms a part of this specification to the extent specified herein. Unless otherwise indicated, the issue in effect on date of invitation for bids or request for proposal shall apply.

DEFENSE SUPPLY AGENCY MANUAL

DSAM 4145.8	Radioactive Commodities in the DOD Supply Systems

(Copies of DSAM 4145.8 may be obtained from the Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. 20402)

3. REQUIREMENTS

3.1 Regulations Pertaining to radioactive devices.- Marking, identification, handling, and shipping of radioactive devices shall be in accordance with DSAM 4145.8.

3.2 Fabrication.- The quadrant shall be manufactured in accordance with Drawing F11730915.

3.3 General specification.- The following requirements of MIL-F-13926 shall be met:

a. Order of precedence
b. Dimensions and tolerances
c. Inorganic protective surface finishes
d. Part identification and marking
e. Workmanship

3.4 Environmental.

3.4.1 Storage temperatues.- The quadrant shall show no evidence of physical failure due to being thermally stabilized at -80° and +160° Fahrenheit (F).

3.4.2 Operating temperatures.- The quadrant shall meet the applicable requirements of 3.10 while thermally stabilized at -40° and +150°F.

3.4.3 Vibration.- The telescope shall be vibrated in a vertical plane at a constant frequency of thirty cycles per second with an amplitude of 1/16 inch (1/8 inch total excursion) for a period of five minutes plus or minus fifteen seconds. Subsequent to vibration there shall be no evidence of physical failure.

Source: https://assist.dla.mil -- Downloaded: 2026-10-22T20:23Z
Check the source to verify that this is the current version before use.

3.5 Sealing.- The quadrant shall show no evidence of water penetration within the counter area when subjected to Procedure I of the rain test of MIL-F-13926.

3.6 Orientation.- The quadrant shall be adjusted to meet the qualification procedures of Drawing F11730915 and positioned with the mounting surface of the quadrant bracket in a vertical plane with the keyway of the quadrant bracket horizontal. The elevation and correction counters shall read zero. The elevation and crosslevel vial bubbles shall be centered within the thickness of one graduation line on the vial and the gunner's quadrant pads shall be level within 0.20 roil.

3.6.1 Telescope mounting tube.- The azimuth and elevation boresight adjustments shall be actuated to position the geometric axis of the gimbal tube horizontal and parallel to the vertical plane of the quadrant mounting surface.

3.7 Accuracy.

3.7.1 Elevation counter.- With the quadrant positioned in accordance with 3.6, utilizing the elevation knob, elevation counter readings shall be obtained in 200 mil increments from 200 roils depression to 1200 roils elevation. With the quadrant repositioned until the bubble in the elevation level is centered to within the thickness of one graduation line of the vial, the angle of elevation formed by the gunner's quadrant pads shall be equivalent to the elevation mil counter reading within 0.5 roil.

3.7.2 Crosslevel vial.- The crosslevel vial bubble shall remain centered within 1/4 graduation when the elevation level vial is centered and the quadrant positioned to the requirements of 3.7.1.

3.7.3 Correction counter.- Plus values of 25 roils and 50 roils put on the correction counter shall subtract an equal number of roils within 0.2 mil from the elevation counter. Minus values of 25 roils and 50 roils put on the correction counter shall add an equal number of roils within 0.5 mil to the elevation counter.

3.7.4 Crosslevel (cant).- From the horizontal position of 3.6 with the mounting surface of the quadrant bracket vertical, rotation of the crosslevel knob shall provide a minimum travel of 34 degrees to the left and 34 degrees to the right.

3.7.5 Boresight adjustment.

3.7.5..1 Elevation adjustment.- The elevation boresight adjustment shall move the geometric axis of the gimbal tube at least 18 roils above and 18 roils below the position established in 3.6.1.

3.7.5.2 Azimuth adjustment.- The azimuth boresight adjustment shall move the geometric axis of the gimbal tube at least 18 mils to the left and 18 roils to the right of the position established in 3.6.1.

Source: https://assist.dla.mil -- Downloaded: 2026-10-22T20:23Z
Check the source to verify that this is the current version before use.

3.7.6 Backlash.

3.7.6.1 Elevation.- Backlash in the elevation mechanism shall not exceed 0.5 miL at any elevation or correction setting between 230 roils in depression and 1383 roils in elevation.

3.7.6.2 Crosslevel.- Backlash in the crosslevel mechanism shall not exceed 0.5 mil at any crosslevel setting between 34 degrees to the right and 34 degrees to the left.

3.8 Excursion range.

3.8.1 Elevation counter.- The elevation counter shall cover an excursion of at least 1383 roils in elevation and 230 roils in depression (230 roils depression will read 9770 roils on the elevation counter) when the correction counters read zero.

3.8.2 Correction counter.- The correction counter limit stops shall allow a minimum of plus 50 and minus 50 roils correction.

3.9 Counter numbers.- Variation in the alignment of the numbers in any counter shall not exceed one sixteenth inch.

3.10 Operability.- The running torque required to rotate the following controls at standard ambient temperature shall not exceed the values specified below:

Elevation knob	ten inch-pounds
Correction knob	three inch-pounds
Crosslevel knob	ten inch-pounds
Boresight adjustment screws	ten inch-pounds

The values obtained when exposed to the extreme temperatures of 3.4.2 shall not exceed the value contained at standard ambient temperature by more than one hundred percent. The toggle switch shall be operable at extreme temperatures.

3.11 Illumination.

3.11.1 Counter numerals.- The counter numerals shall be visible in all ambient light conditions.

3.11.2 Level vials.- The level vial bubbles shall each be visible in all ambient light conditions.

4. QUALITY ASSURANCE PROVISIONS

4.1 Responsibility for inspection.- Unless otherwise specified in the contract or purchase order, the supplier is responsible for the performance of-all inspection requirements as specified herein. Except as

Source: https://assist.dla.mil -- Downloaded: 2026-10-22T20:23Z
Check the source to verify that this is the current version before use.

otherwise specified, the supplier may utilize his own facilities or any other facilities suitable for the performance of the inspection requirements specified herein, unless disapproved by the Government. The Government reserves the right to perform any of the inspections set forth in the specification where such inspections are deemed necessary to assure supplies and services conform to prescribed requirements.

4.1.1 General provisions.- The component and subassembly inspection requirements of MIL-F-13926 form a part of the Quality Assurance Provisions of this specification. Definitions of inspection terms shall be as listed in MIL-STD-109.

4.2 First article (initial production) approval.- The requirement for first article approval and the responsibility (Government or contractor) for first article testing shall be as specified in the contract. The sample for first article approval tests shall consist of three (3) quadrants plus three (3) each of all items covered by SQAP. The sample shall be manufactured in the same manner, using the same materials, equipment, processes, and procedures as used in regular production. All parts and materials, including packaging and packing, shall be obtained from the same source of supply as used in regular production.

4.2.1 Government testing.- When the Government is responsible for conducting first article approval tests, the contractor, prior to submitting the sample to the Government, shall inspect the sample to insure that it conforms to all the requirements of the contract and submit a record of this inspection with the sample, including certificates of conformance for materials.

4.2.2 Contractor testing.- When the contractor is responsible for conducting first article approval tests, the sample shall be inspected by the contractor for all the requirements of the contract. The sample and a record of this inspection, including certificates of conformance for materials, shall be submitted to the Government for approval. The Government reserves the right to witness the contractor's inspection.

4.3 Inspection Provisions.

4.3.1 Submission of Product.- Unless otherwise specified by the contracting officer, inspection lot size, lot formation and presentation of lots shall be in accordance with "Submission of Product" provisions of MIL-STD-105.

4.3.2 Examination and tests.

4.3.2.1 Components and subassemblies.- All components and subassemblies shall be inspected in accordance with the inspection provisions contained in Supplementary Quality Assurance Provisions (SQAP) listed in the List of Inspection Documents (IEL), when provided with the technical data package (TDP). In the absence of SQAPs, the applicable Quality Assurance Provisions of MIL-F-13926 shall apply.

Source: https://assist.dla.mil -- Downloaded: 2026-10-22T20:23Z
Check the source to verify that this is the current version before use.

4.3.2.2 Final acceptance inspection.- Subsequent to first article approval, examination and tests related to Section 3 herein shall be performed on a single defect (individual characteristic) basis in accordance with MIL-STD-105 anti the sampling. plans specified in Table I herein. EXamination and tests for Packaging, Packing and Marking shall be in accordance with MIL-P-14232 and Section 5 herein. The tabulated classification of defects in Table I shall constitute the minimum inspection to be performed by the supplier after first article approval and prior to Government acceptor rejection by item or lot.

TABLE I - CLASSIFICATION OF DEFECTS

CLASS	CHARACTERISTIC	REQUIREMENT	TEST PROCEDURE
CRITICAL: NONE			
MAJOR:			
101.	Post vibration physical condition	3.4.3	4.6.2.1
102.	Previbration physical condition	3.4.3	4.6.2.1
103.	Accuracy of elevation counter (limits)	3.8.1	4.6.2.4
104.	Accuracy of elevation counter readings to quadrant pads	3.7.1	4.6.2.3
105.	Crosslevel vial accuracy	3.7.2	4.6.2.3
106.	Correction counter operation and accuracy	3.7.3	4.6.2.5
107.	Crosslevel cant limits	3.7.4	4.6.2.7
108.	Boresight adjustment (elevation)	3.7.5.1	4.6.2.8
109.	Boresight adjustment (azimuth)	3.7.5.2	4.6.2.9
110.	Backlash elevation mechanism	3.7.6.1	4.6.2.3
111.	Backlash crosslevel mechanism	3.7.6.2	4.6.2.7
112.	Correction counter limit stops	3.8.2	4.6.2.6
113.	Torque elevation knob	3.10	4.6.2.11
114.	Torque correction knob	3.10	4.6.2.11
115.	Torque crosslevel knob	3.10	4.6.2.11
116.	Torque boresight adjustment screws	3.10	4.6.2.11
117.	Illumination counter	3.11.1	4.6.2.12.1
118.	Illumination level vial	3.11.2	4.6.2.12.2
MINOR:			
201.	Counter digit alignment	3.9	4.6.2.10

4.4 Special sampling for environmental testing.

4.4.1 Samples shall be selected from lots at random from lots in accordance with inspection Level S-3, Table I of MIL-STD-105. Acceptance or rejection of the lot shall be in accordance with AQL 2.5 of Table II-A of MIL-STD-105. The samples shall have met a11 the requirements and tests outlined in Table I prior to being subjected to the following examination and test.

Source: https://assist.dla.mil -- Downloaded: 2026-10-22T20:23Z
Check the source to verify that this is the current version before use.

TABLE 11

	CHARACTERISTIC	REQUIREMENT	TEST PROCEDURE
301.	Regulation pertaining to radioactive devices	3.1	Certification
302.	Fabrication	3.2	Certification
303.	General specifications	3.3	Certification
304.	Temperature (storage)	3.4.1	4.6.1.1
305.	Temperature (operating)	3.4.2	4.6.1.1
306.	Sealing	3.5	4.6.1.2
307.	Torque elevation knob	3.10	4.6.2.11
308.	Torque correction knob	3.10	4.6.2.11
309.	Torque crosslevel knob	3.10	4.6.2.11
310.	Boresight adjustment screws	3.10	4.6.2.11

4.4.2 Failure of sample.- Should any one item of a special sampling fail to meet the specified test requirements, acceptance of the represented inspection lot will be suspended by the Government until necessary corrections have been made by the contractor and the resubmitted samples have been approved (see 4.3.3).

4.5 Inspection equipment.- Except as otherwise provided for by the contract, the contractor shall supply and maintain inspection equipment in accordance with the applicable requirements of MIL-I-45607.

4.5.1 Government furnished inspection equipment.- Where the contract provides for Government furnished test equipment, supply and maintenance of test equipment shall be in accordance with the applicable requirements specified in MIL-I-45607.

4.5.2.2 Contractor design.- The contractor shall design and supply inspection equipment compatible with the “Test Methods and Procedures” specified in 4.6 of this specification and with the component inspection procedures specified in “Examination" and "Test Facilities” requirements Of MIL-F-13926. Since tolerance of test equipment is normally considered to be within 10% of the product tolerance for which it is intended, this inherent error in the test equipment design must be considered as part of the prescribed product tolerance limit. Thus, concept, construction, materials, dimensions and tolerance used in the design of test equipment shall be so selected and controlled as to insure that the test equipment will reliably indicate acceptability of a product which does not exceed 90% of the prescribed tolerance limit, and permit positive rejection when non-conforming. Construction shall be such as to facilitate routine calibration of test equipment..

4.5.3 Test equipment.- In conjunction with 4.5.2.2, the following standard test equipment shall be utilized in the performance of the applicable tests as specified in 4.6 and 4.7.

Source: https://assist.dla.mil -- Downloaded: 2026-10-22T20:23Z
Check the source to verify that this is the current version before use.

NOMENCLATURE	DESCRIPTION
1. Hot and cold chamber	Standard type conforming to the accuracies outlind in test facilities specified under test facilities of MIL-F-13926.
2. Continuity checker	Standard shop type capable of providing readings accurately within 2% of specified tolerance.
3. Insulation resistance checker	Standard shop type conforming to the accuracies outlined in 4.5.2.2.
4. Power supply	O to 50 D.C. output within 2% accuracy.
5. Torque wrench and scale	Standard shop type accurate to within 10% of torque tolerances.

4.6 Test methods and procedures.

4.6.1 Environmental.

4.6.1.1 Temperature test.- The quadrant shall be subjected to Test Procedure I of MIL-F-13926; however, the temperatures specified in 3.4.1 and 3.4.2 shall apply. When the quadrant has been stabilized at the temperature specified, the result of the specified test shall conform to the limits outlined in 3.4.1 and 3.4.2 using test procedures outlined herein.

4.6.1.2 Sealing.- The quadrant shall be subjected to Test Procedure I outlined in MIL-F-13926 and inspected for water penetration within the counter area as specified in 3.5.

4.6.2 Performance.

4.6.2.1 Vibration.- Prior to performing the vibration test, determine by visual and tactile inspection techniques that the quadrant shows no evidence of loose, bent or broken components. Subject the quadrant to Vibration Procedure V of MIL-F-13926 using the frequency, duration and amplitude specified in 3.4.3. At the completion of this test, use visual and tactile inspection techniques to determine conformance with 3.4.3.

4.6.2.2 Orientation.- Orienting the quadrant may be accomplished by using a crossleveling type fixture and mounting adapter, the accuracy of which shall conform to the accuracies depicted on Drawing D6523553 and c8565834 both of which are listed on IEL 8626310. Prior to orienting the. quadrant, the test fixture and adapter shall be positioned level in all planes. Crossleveling of the fixture is accomplished by placing viewing Telescopes c5549108 in the “V” slot of the adapter and by positioning a plumb line approximately 40 feet from the viewing telescope and in coincidence with the viewing telescope optical axis. Raise and lower the line of sight by activating the elevation handwheel of the fixture. The telescope’s line

Source: https://assist.dla.mil -- Downloaded: 2026-10-22T20:23Z
Check the source to verify that this is the current version before use.

of sight shall remain parallel to the plumb line during this activation. Place a 10 second precision level over the adapter keys. Both keys shall be considered leveled when identical level readings are produced on the level vial when rotated 180° from the original position. Roll the collimating telescope in the "V" groove and coincide the plumb line and vertical reticle line. Place target lines A and B (Figure 1) in coincidence with the collimator's vertical and horizontal reticle lines. Secure the quadrant to the adapter by means provided and observe previously coincided lines. Insert a previously aligned adapter collimating Telescope c8246024 into the gimbal tube and again observe coincided lines. Aligning the adapter collimating telescope is assured after placing the adapter in a "V" block with the collimating telescope centered in the adapter. Direct the line of sight toward a clearly defined target image and roll the collimator and adapter in the "V" block. Observe coincidence between the intersecting point of the collimator reticle lines and a selected target point. Six screws are provided to facilitate this adjustment. When coincidence has been obtained, the adapter and collimator are ready for use. Set the correction counter and elevation counters to zero readings and observe level vial settings of the quadrant. They must read level within the limits specified in 3.6. Place an Inspection Aid (Gunner's Quadrant) Drawing A8658940 set to zero roils elevation over each set of machined pads of the quadrant. The inspection aid must indicate level in both planes within the limits specified in 3.6. Observe where the intersecting point of the reticle lines fall with respect to the intersecting point of target lines C and D. Any adjustments shall be made by means of the elevation and azimuth adjusting screws of the quadrant to assure conformance with 3.6.1.

4.6.2.3 Elevation counter, accuracy and backlash.- With the unit positioned as outlined in 4.6.2.2, set the unit off 200 roils in elevation as indicated by the counter reading and observe crosslevel bubble for movement. Set the inspection aid to indicate the identical roil. setting. Place the inspection aid on the proper set of pads and by means of the fixture elevation handwheel, relevel the quadrant level vial to indicate a true level setting. Do not override this setting. Observe coincidence between the quadrant level vial and the inspection aid level vial. They must coincide within the limits outlined in 3.7.1. Also observe elevation counter reading and elevation reading of the inspection aid. They must coincide within the limits of 3.7.1. During elevation or depression of the quadrant, the crosslevel bubble shall not move by more than the limits specified in 3.7.2. After recording reading and position of level vials, continue to rotate the quadrant elevation handwheel one revolution beyond the setting and return to previously recorded elevation level vial setting of the quadrant and observe elevation counter reading. Any variation between this reading and the recorded reading is considered backlash and must be within the limits specified in 3.7.6.1. Repeat this procedure every 200 roils from 200 mils depression to 1200 elevation.

4.6.2.4 Range of elevation counter.- This test may be performed during the above test. The test is performed by rotating the correction knob full clockwise and then full counterclockwise. At each maximum rotation, the counter shall produce a reading within the minimum range specified in 3.8.1.

Source: https://assist.dla.mil -- Downloaded: 2026-10-22T20:23Z
Check the source to verify that this is the current version before use.

4.6.2.5 Accuracy of correction counter .- This test can be performed using the procedure outlined in 4.6.2.3. After the accuracy of the elevation setting has been established, turn the correction counter in the plus and minus direction to indicate a 25 mil setting. The elevation counter shall rotate in an opposite direction 25 roils from the original setting of the elevation counter within the limits outlined in 3.7.3. Repeat this procedure at the 50 mil setting each side of the level position.

4.6.2.6 Range of correction counter.- This test may be performed during the previous test. The test is performed by rotating the correction knob in the maximum clockwise and counterclockwise directions. At each maximum rotation, the counter shall produce a reading within the limits outlined in 3.8.2.

4.6.2.7 Minimum cant travel and backlash.- With the quadrant positioned as outlined in 4.6.2.3, rotate the crosslevel knob full clockwise. Place the inspection aid over the crossleveling pads. Set the inspection aid to indicate level. The angle read on the inspection aid must be within the limits of 3.7.4. Repeat this procedure with the crosslevel knob in the full counterclockwise position. Backlash to be measured in at least two places each side of zero cant. Perform this test by selecting any angle of cant, scribe on index line on the crosslevel knob and another on the casting. Turn the crosslevel handwheel in the opposite direction and level the quadrant level vial. Sight through the collimator and observe coincidence between the vertical reticle line and vertical target line. This difference, if any, is backlash and shall not exceed the limits specified in 3.7.6.2.

4.6.2.8 Elevation adjustment.- With the mount and fixture set as outlined in 4.6.2.2, rotate the elevation adjustment screw maximum clockwise and counterclockwise from the leveled position while sighting through the adapter collimating telescope. The intersecting point of the reticle line must coincide with or exceed the limits of the 36 mil target block to conform to the requirement of 3.7.5.1. At the completion of the test, return line of sight to the intersecting point of target lines c and D.

4.6.2.12 Illumination.

4.6.2.12.1 Counter numbers.- Place the instrument in a dark room having a controlled light source. The observer and instrument must become dark adapted. After being adapted to the darkness, the observer shall visually examine the counter numbers. They must be clearly discernible to assure conformance with 3.11.1. Gradually raise the ambient level of light in the dark room 1 foot candle of illumination in the area of the counter. The counter numbers shall be clearly discernible to assure conformance with 3.11.1.

4.6.2.12.2 Level vial.- Place the instrument in a dark room having a controlled light source. The observer and instrument **must** become dark adapter. After being **adapted** to the darkness, the observer shall visually examine the level vial bubble and the graduation. They must be clearly

Source: https://assist.dla.mil -- Downloaded: 202610-22T20:23Z
Check the source to verify that this is the current version before use.

discernible to assure conformance with 3.11.2. Gradually raise the ambient level of light in the dark room 1 foot candle of illumination in the area of the level vial. The level vial and graduation shall be clearly discernible to assure conformance with 3.11.2.

5. PREPARATION FOR DELIVERY

5.1 Packaging, packing and marking.- Packaging, packing and marking shall be in accordance with Packaging Data Sheet 11730915. The level of protection shall be as specified in the procurement document.

6. NOTES

6.1 Intended use.- The Quadrant Fire Control M14E1 is primarily intended for laying the weapon in elevation for indirect fire. The quadrant also incorporates a mechanism (telescope mount) for mounting and boresighting the direct fire, Elbow Telescope M114E1 for direct fire. When using the Elbow Telescope M114E1 for direct fire, the elevation counter and correction counter remains at zero setting.

6.2 Ordering data.- Procurement documents should specify the following:

a. Title, number and date of this specification
b. Selection of applicable levels of preservation, packaging, and packing
c. Applicable stock number

6.3 Radioactive material.- Prospective bidders should be cognizant of the need for an Atomic Energy Commission license governing the procurement and handling of radioactive material.

custodian:

Army - MU

Preparing activity:

Army - mU

Project No. 1290-A256

Source: https://assist.dla.mil -- Downloaded: 202610-22T20:23Z
Check the source to verify that this is the current version before use.

SPECIFICATION ANALYSIS SHEET

Form Approved
Budget Bureau No. 22-R255

INSTRUCTIONS: This sheet is to be filled out by personnel, either Government or contractor, involved in the use of the specification in procurement of products for ultimate use by the Department of Defense. This sheet is provided for obtaining information on the use of this specification which will insure that suitable products can be procured with a minimum amount of delay and at the least cost. Comments and the return of this form will be appreciated. Fold on lines on reverse side, staple in corner, and send to preparing activity. Comments and suggestions submitted on this form do not constitute or imply authorization to waive any portion of the referenced document(s) or serve to amend contractual requirements.

SPECIFICATION

ORGANIZATION

CITY AND STATE | CONTRACT NUMBER

MATERIAL PROCURED UNDER A

☐ DIRECT GOVERNMENT CONTRACT ☐ SUBCONTRACT

1. HAS ANY PART OF THE SPECIFICATION CREATED PROBLEMS OR REQUIRED INTERPRETATION IN PROCUREMENT USE?

A. GIVE PARAGRAPH NUMBER AND WORDING.

B. RECOMMENDATIONS FOR CORRECTING THE DEFICIENCIES

2. COMMENTS ON ANY SPECIFICATION REQUIREMENT CONSIDERED TOO RIGID

3. IS THE SPECIFICATION RESTRICTIVE?

[ ] YES [ ] NO *(If "yes", in what way?)*

4. REMARKS *(Attach any pertinent data which may be of use in improving this specification. If there are additional papers, attach to form and place both in an envelope addressed to preparing activity)*

SUBMITTED BY *(Printed or typed name and activity - Optional)* | DATE

DD FORM 1 JAN 66 1426 REPLACES EDITION OF 1 OCT 64 WHICH MAY BE USED.

Source: https://assist.dla.mil -- Downloaded: 202610-22T20:23Z
Check the source to verify that this is the current version before use.

FOLD

Department of the Army

Frankford Arsenal
Philadelphia, Pa. 19137

OFFICIAL BUSINESS

POSTAGE AND FEES PAID
Department of the Army

Commanding Officer
Frankford Arsenal
ATTN: SMUFA-N1100
Philadelphia, Pa. 19137

FOLD

Source: https://assist.dla.mil -- Downloaded: 202610-22T20:23Z
Check the source to verify that this is the current version before use.