METRIC

MIL-C-24382A(SH)
AMENDMENT - 1
17 May 1990

MILITARY SPECIFICATION

CANISTER, OXYGEN BREATHING APPARATUS, TYPE A-4 TRAINING KIT

This amendment forms a part of MIL-C-24382A(SH), dated 27 July 1988, and is approved for use by the Naval Sea Systems Command, Department of the Navy is available for use by all Departments and Agencies of the Defense.

PAGE 3

3.2: Delete and substitute:

"3.2 Materials. The materials shall be as specified herein."

3.3.1: Line 3; Delete ", boss, ".

PAGE 4

3.3.1.3: Delete in its entirety.

3.3.1.5: Line 1; Delete "+0.005" and substitute "± 0.0005".

PAGE 5

3.3.5.1: Line 2; Delete "25" and substitute "5".

3.3.5.1: Add at the end of paragraph:

"Impurities to be analyzed shall include ammonia, barium, carbon monoxide, chlorine, hydrogen chloride (see 4.7.8.2.1)."

AMSC N/A FSC 4240

DISTRIBUTION STATEMENT A. Approved for public release; distribution is unlimited.

Source: https://assist.dla.mil -- Downloaded: 2026-10-19T21:39Z
Check the source to verify that this is the current version before use.

PAGE 9

4.7.2.1: Line 3; Delete "2 - and 4 -" and substitute "3".

4.7.2.1: Line 3; Delete "marks" and substitute "mark".

4.7.3: Line 9; Delete "pink" and substitute "pink and white".

4.7.3.1: Line 1; Delete "1" and substitute "1-1/2".

4.7.3.1: Line 2; Delete "2-1/2" and substitute "5".

4.7.5: Line 6; Delete "3.3.1.7." and substitute "3.3.2.".

PAGE 10

4.7.8.2.1: Delete last sentence and substitute:

"The sampling and analytical methods used for analysis of impurities specified in 3.3.5.1 shall be the methods suggested in NOISH Publication No. 85-114, or their equivalent.

PAGE 12


5.3.3: Line 1; Delete "apparatus" and substitute "apparatus training canister".

6.1: Delete and substitute:

"6.1 Intended use. The training canister kit covered by this specification is intended to tbe used with the type A-4 OBA."

Source: https://assist.dla.mil -- Downloaded: 202610-19T21:39Z
Check the source to verify that this is the current version before use.

FIGURE 1: Delete and substitute:




SH 9768

FIGURE 1. Training canister assembly - exploded view.

Source: https://assist.dla.mil -- Downloaded: 202610-19T21:39Z
Check the source to verify that this is the current version before use.

FIGURE 2: Delete and substitute:



SH 9769

FIGURE 2. Detail of firing mechanism assembly.


Source: https://assist.dla.mil -- Downloaded: 202610-19T21:39Z
Check the source to verify that this is the current version before use.

FIGURE 3: Delete and substitute:

TRAINING CANISTER, QUICK STARTING
FOR
NAVY OXYGEN BREATHING APPARATUS
For Charging Canister, see instructions on Candle-Storage Container

STARTING INSTRUCTIONS

1. Remove tear-off cap by placing a finger in tab hole, pulling backwards and upwards.
2. Remove the candle cover by rotating swivel plate 180 degrees. Pull swivel plate up toward center of canister, leaving the cover dangling by the lanyard. DO NOT PULL LANYARD.
3. With bail handle down, insert canister into apparatus. THIS IS THE STANDBY POSITION.
4. Don and adjust face piece and check for airtight fit.
5. Depress tabs on bail handle and rotate downward to the standby position. Test handle to ensure lock is secure.
6. Pull lanyard straight away from body to ignite candle. Ensure cotter key has detached from timing mechanism.
7. Set timer for 5 minutes by rotating dial to 60 minutes, then back to 5 minutes.



AFTER USE

1. To remove canister, depress tabs on bail handle and rotate downward to the standby position. Pull release strap. Catch canister with a suitably gloved hand.
2. See instructions on candle storage container for recharging, storage and disposal.

CAUTION


1. Canister must be charged with a candle before use.
2. Do not remove tear-off cap until ready to insert canister into apparatus.
3. Canister, when charged with fresh candle, is good for 5 minutes at rest.
4. Canister is to be discarded after forty training periods or when indicator on the canister turns blue, whichever occurs first.
5. Never allow any foreign substance to enter canister, especially OIL, WATER AND OIL, GASOLINE, GREASE, etc.
6. For storage, canister must be sealed by the metal tear-off cap on the canister neck and by the plastic storage plug and firing mechanism at the candle recess on the bottom.
7. Never store canister with a fresh or a used candle in place.

MFD. BY

FIGURE 3. Label for canister body (label A).

Source: https://assist.dla.mil -- Downloaded: 202610-19T21:39Z
Check the source to verify that this is the current version before use.

FIGURE 4: Delete and substitute:



INSTRUCTIONS FOR CHARGING OF
QUICK START TRAINING CANISTER FOR
NAVY OXYGEN BREATHING APPARATUS

CAUTION:
1. DO NOT SERVICE CANISTER NEAR OIL OR GREASE.
2. KEEP HANDS, GLOVES AND TOOLS FREE FROM OIL OR GREASE.
3. CANISTER BOTTOM IS HOT IMMEDIATELY AFTER USE SO USE GLOVES IN REMOVING FIRING MECHANISM AND CANDLE ASSEMBLE.
4. NEVER STORE CANISTER WITH A USED OR FRESH CANDLE IN PLACE.

1. IF CANISTER IS NEW OR HAS JUST BEEN REMOVED FROM STORAGE:
The canister shall be sealed at the neck by a metal tear-off cap and at the bottom by a plastic storage plug held in place by the firing mechanism. Leave the tear-off cap in place but remove the storage plug, retaining, it, however, for further storage use. Remove the cover from the cocked firing mechanism assembly and proceed to step #3 below.
2. IF CANISTER HAS JUST BEEN USED:
   (a) Position metal tear-off cap on canister neck to the hand tab points toward instruction label on the convex side of canister.
   (b) Remove firing mechanism from bottom of canister by turning counterclockwise until tongs line up with notches.
   (c) Remove used candle and discard it.
   (d) Hold firing mechanism with slotted end of frame pointing toward you. Raise firing hammer to cocked position.
   (e) While holding firing hammer in this position, insert cotter pin through the holes in the frame from the same side as the rivet head. Secure the cotter pin by bending long leg slightly.
3. INSTALL NEW CANDLE ASSEMBLY AS FOLLOW:
   (a) It is important to remove all packaging materials from candle assembly (specifically the primer or ignition cap area).
   (b) Insert candle assembly into candle recess in canister. Make sure the gasket is flat against bottom of canister.
   (c) Place firing mechanism over candle assembly with primer housing projecting through center hole and with notches lined up with tongs.
   (NOTE: Notches and tongs are positioned so that unit can only be assembled in correct position).
   (d) Rotate firing mechanism clockwise to lock candle in place. Tighten until the firing mechanism frame contacts tongs. (Do not over tighten).
4. Fold lanyard into the candle cover and secure the assembly on the firing mechanism frame. After replacing firing mechanism cover, rotate the swivel plate to its original position laying on the cover.
5. Canister is now ready for use with OBA in accordance with "Starting Instructions" on Canister Body.
6. IF CANISTER IS TO BE STORED:
Upon completion of training or for breaks in training of 1 hour or more, place a metal tear-off cap on the canister neck; remove candle, insert the plastic storage plug in the candle recess; and lock with the firing mechanism.
7. DISPOSAL: Discard used candles the same as other metallic materials. Discard unused candles by soaking in one gallon of clean water per candle for three days. Solid material will liquefy. Pour residual water, which is caustic, down a drain. Discard metal and used canisters, less candle, same as other waste.

MFD. BY

SH 13231794

FIGURE 4. Label for candle container (lable B).

Source: https://assist.dla.mil -- Downloaded: 2026-10-19T21:39Z
Check the source to verify that this is the current version before use.

Preparing activity:
NAVY-SH
(4240-N997)

Source: https://assist.dla.mil -- Downloaded: 2026-10-19T21:39Z
Check the source to verify that this is the current version before use.