BY ORDER OF THE COMMANDER
36TH WING

36th WING INSTRUCTION 21-107

28 OCTOBER 2026

Maintenance

CRASHED, DAMAGED, OR DISABLED AIRCRAFT RECOVERY (CDDAR) PROGRAM

COMPLIANCE WITH THIS PUBLICATION IS MANDATORY

ACCESSIBILITY: This publication is available for downloading or ordering on the e-Publishing website at www.e-Publishing.af.mil

RELEASABILITY: There are no releasability restrictions on this publication

---

OPR: 36MXG/MXGQ

Certified by: 36MXG/CC
(Colonel Matthew S. Drossner)

Supersedes: 36WGI21-107, 24 August 2020

Pages: 24

This publication implements 36th Wing Instruction (WGI) 21-107, required by Department of the Air Force (DAFI) 21-101, *Aircraft and Equipment Maintenance Management*, to assign specific responsibilities and procedures to implement a CDDAR program in accordance with (IAW) Technical Order (TO) 00-80C-1, *Crashed, Damaged, Disabled Aircraft Recovery Manual*. Transient Alert (TA) assumes responsibility to manage and execute aircraft crash recovery operations through Performance Work Statement (PWS) FA52024QM017 and Emergency Service (CLIN XX06) documents. It establishes recovery procedures for aircraft involved in a ground or air incident to include contingency planning considerations for 24/7/365 coverage. The instruction applies to all 36th Wing (36 WG) organizations and personnel including associate and deployed units that maintain aircraft, aircraft systems, equipment, support equipment and components regardless of Air Force Specialty Code (AFSC). This publication does not apply to Air Force Reserve Command (AFRC) and Air National Guard (ANG) Units. It will be used in conjunction with other agency policies and all applicable Technical Orders (TOs) pertaining to the disabled aircraft. It establishes policies and procedures and assigns responsibilities for CDDAR. Refer recommended changes and questions about this publication to the Office of Primary Responsibility (OPR) using the Department of the Air Force (DAF) Form 847, *Recommendation for Change of Publication*; route DAF Form 847 from the field through the appropriate functional chain of command. Ensure that all records created as a result of processes prescribed in this publication are maintained in accordance with Air Force Instruction (AFI) 33-322, *Records Management and Information Governance Program*, and disposed of IAW Air Force Records Disposition Schedule (RDS) located in the Air Force Records Information Management System (AFRIMS). The use of

the name or mark of any specific manufacturer, commercial product, commodity, or service in this publication does not imply endorsement by the Air Force.

SUMMARY OF CHANGES

This document has been revised and should be completely reviewed. Changes include **Chapter 1** OVERVIEW added a brief description of the CDDAR Program. identification of responsibility for the CDDAR capability to align with Performance Work Statement guidelines as part of the TA services contract. A margin bar (|) indicates newly revised material.

Chapter 1—OVERVIEW **4**

1.1. Overview. 4

Chapter 2—TEAM COMPOSITION **5**

2.1. Team Composition. 5

2.2. Team Duty Positions. 5

Chapter 3—ROLES AND RESPONSIBILITIES **6**

3.1. 36th Wing Safety (36 WG/SE). 6

3.2. 36th Maintenance Group Commander (36 MXG/CC). 6

3.3. 36th Mission Support Group Commander (36 MSG/CC). 6

3.4. 36th Operational Group Commander (36 OG/CC). 7

3.5. 36th Medical Group Commander (36 MDG/CC). 7

3.6. 36th Maintenance Squadron Commander (36 MXS/CC). 7

3.7. 734th Air Mobility Squadron Commander (734 AMS/CC). 8

3.8. 4th Reconnaissance Squadron Commander (4 RS/CC). 8

3.9. U.S. Navy Helicopter Sea Combat (HSC) Squadron 25 Commander (HSC-25/CDR). 8

3.10. CDDAR Team Chief (TC). 8

3.11. Transient Alert (TA). 9

Chapter 4—TRAINING **10**

4.1. Training. 10

Chapter 5—PROCEDURES **11**

5.1. Procedures. 11

5.2. Heavy Equipment Utilization. 12

5.3. Civil Aircraft Incident. 12

5.4. Off-base Recovery. 12

5.5. Underwater Salvage. 13

Chapter 6—EQUIPMENT **14**

6.1. Equipment. 14

6.2. ABDR Equipment. 14

6.3. Additional Equipment. 14

6.4. Equipment Accountability and Reporting. 14

Attachment 1—GLOSSARY OF REFERENCES AND SUPPORTING INFORMATION **16**

Attachment 2—BARRIER ENGAGEMENT CHECKLIST **19**

Attachment 3—BLOWN TIRE CHECKLIST **21**

Attachment 4—AIRCRAFT DEBOGGING **22**

Chapter 1

OVERVIEW

1.1. Overview.

1.1.1. The CDDAR program is designed to recover crashed, damaged or disabled aircraft in a minimum amount of time. Requirements will consist of opening runways for operational use, prevention of secondary damage to the aircraft, and preservation of evidence for mishap or accident safety investigation.

1.1.2. CDDAR Program Instruction. The CDDAR program instruction is procedural and will not take precedence over aircraft specific technical data in the recovery of crashed, damaged or disabled aircraft.

Chapter 2

TEAM COMPOSITION

2.1. Team Composition. Andersen AFB CDDAR is supported primarily by Transient Alert (TA) contract services, as prescribed in the Performance Work Statement (PWS), and augmented by assigned 36th Maintenance Group (36 MXG), 734th Air Mobility Squadron (734 AMS), 4th Reconnaissance Squadron (4 RS), and U.S. Navy unit Helicopter Sea Combat-25 (HSC-25) personnel, as well as deployed or TDY personnel, as applicable. The 36th Maintenance Group Commander (36 MXG/CC) will assist the Incident Commander (IC), Recovery Operations Chief (ROC), or the Interim Safety Board (ISB) President for the initial crash response support and immediate recovery/removal as required of damaged or disabled aircraft until the owning unit takes responsibility. The 36th Wing Commander (36 WG/CC) or designated representative will determine the degree of emergency and make the initial decision regarding the speed with which the runway is cleared. This decision is dictated by evaluation of alert status, number of returning aircraft, available weather alternates and other operational criteria.

2.2. Team Duty Positions.

2.2.1. **Team Chief (TC).** Responsible for the overall CDDAR Program development, implementation, and management. TC(s) will be TA contracted personnel and designated Senior Noncommissioned Officers (SNCO) by 36 MXG/CC in writing. All CDDAR operations will be coordinated through the TC who will act as the single on-scene focal point for all CDDAR operations. The TC will maintain and provide a current recall roster for the Maintenance Operations Center (MOC) and the Wing Command Post.

2.2.2. **Team Leader (TL).** TL(s) will be trained in CDDAR supervisory duties by the TC and report directly to the TC. TLs may be designated upon notification of a recovery operation. For extended recovery operations, two CDDAR TLs may be designated to cover 24-hour operations.

2.2.3. **Team Member (TM).** Works directly for, and reports to the CDDAR TL. These individuals must be formally trained by AETC Course Code J3AAR2AXXX 048B. TL trained personnel may be utilized as TMs during CDDAR operations. (Ref. DAFI 21-101 para 11.28.2.2).

2.2.4. **Members of Deployed Units.** Owning units of deployed aircraft are responsible for providing trained TLs and TMs. The 36th Maintenance Squadron’s Aviation Support Flight (36 MXS/ASF) will liaise with TA personnel to provide just-in-time, local familiarization training, as needed, to qualified deployed personnel within 30 days of arrival. A Memorandum for Record (MFR) documenting this training will be maintained by the 36 MXS/ASF.

Chapter 3

ROLES AND RESPONSIBILITIES

3.1. 36th Wing Safety (36 WG/SE).

3.1.1. Briefs all organizations directly involved in CDDAR operations on the importance of preserving evidence prior to the initial CDDAR team walkthrough of a crash or incident site.

3.1.2. Advises Incident Commander (IC) and ROC on proper documentation of incident site prior to the initial removal of any wreckage to include complete photographic coverage, notes, liquid samples, and measurements.

3.2. 36th Maintenance Group Commander (36 MXG/CC).

3.2.1. Manages the CDDAR program, ensuring at least two 36 MXG-assigned military members attend the AETC Recovery Operations formal course to liaise with TA personnel responsible for aircraft recovery operations. The contractor will manage and execute aircraft crash and recovery operations as required per the PWS. Appoint a primary and alternate contractor TC. The TA lead contractor will identify members to serve as TC and TMs. The contractor will fund, and the government will facilitate attendance to AETC CDDAR training (Course ID: J3AAR2AXXX 048A) and maintain annual refresher training IAW DAFI 21-101 and 36WGI 21-107 for TCs and TMs (Reference **para. 3**.). Oversight of contractual responsibilities will be managed by the assigned Contracting Officer Representative (COR).

3.2.2. Appoint a military TC as the focal point for the wing's CDDAR program.

3.2.2.1. Ensure the TC coordinates with base and commercial agencies to source heavy equipment not available on base but required for recovery operations.

3.2.3. Ensure recurring CDDAR training is conducted on an annual basis and is annotated on an MFR that is maintained in the CDDAR program binder. The training audience will include Andersen TA contractors, 36 MXG, 734 AMS, and 4 RS personnel, as well as deployed personnel (as applicable).

3.2.4. To the extent reasonable, provide composite response capability with assistance from the deployed maintenance units, as applicable. Additional support may include 36 MXS personnel trained in composite response.

3.3. 36th Mission Support Group Commander (36 MSG/CC).

3.3.1. Provide an Incident Commander (IC). The IC (Senior Fire Officer) will take command of the crash site and control access (for more information see DAFI 10-2501 *Emergency Management Program*). The IC will be the focal point for all base agency coordination and direct all support requests to the Emergency Operations Center (EOC).

3.3.2. Provide Explosive Ordnance Disposal (EOD) personnel on site to render safe aircraft explosive hazards and munitions as required upon request from the IC.

3.3.3. Provide emergency crash and fire response, as well as hazardous materials and spill containment capability beyond the scope of the unit through coordination with 36th Civil Engineer Squadron (36 CES).

3.3.4. Provide Security Forces personnel to secure the mishap scene and wreckage assembly point, as directed by the IC.

3.3.5. Provide tractor trailers and forklifts, as necessary, to transport CDDAR support equipment (such as pneumatic air bags and recycled plastic lumber) to the mishap site, as well as transport wreckage to the wreckage assembly point. (This may include an all-terrain forklift depending on the mishap site conditions).

3.3.5.1. In coordination with the MXG/CC determine unit vehicle/equipment requirements beyond those approved in the Authorization Standards to provide 24/7 CDDAR response and runway clearing capability.

3.3.6. Provide on-scene fuel servicing of recovery support equipment, to include Aerospace Ground Equipment (AGE) and heavy equipment as required.

3.3.7. Provide contracting support for specialized equipment as necessary to support recovery operations as necessary to support recovery operations as required not already covered under the transient alert contract.

3.3.8. Provide additional personnel, equipment, and services, as needed to augment mishap response efforts. This may include field GPS optical surveying and mapping equipment and support as required by the IC, Mortuary Affairs, and/or investigation team (AFH 10-247 v4). Personnel may need PPE for working near damaged airframe, e.g. respirator and Tyvek suit.

3.3.9. Ensure 36th Contracting Squadron (36 CONS) includes CDDAR requirements in the TA contract.

3.3.10. Provide HAZMAT personnel to assess downwind threats and hazards pertaining to scene mishaps that have a known HAZMAT component as necessary (hydrazine, etc…).

3.4. 36th Operational Group Commander (36 OG/CC).

3.4.1. Ensure notification of all in-flight emergency (IFE) aircraft inbound to Andersen AFB occurs using the secondary crash net (SCN) and land mobile “Ramp” net.

3.4.2. Establish clearances for access to the active runway and publish NOTAMs as required.

3.4.3. Reroute aircraft traffic as required.

3.5. 36th Medical Group Commander (36 MDG/CC).

3.5.1. Provide Bioenvironmental capabilities as per 36 WG Installation Emergency Management Plan (IEMP) 10-2.

3.5.2. Provide respirator fit tests for composite response as required.

3.5.3. Provide on-scene medical assistance, Flight Medicine mishap support, and transport wounded as required IAW 36WGI 91-204, *36th Wing Mishap Response Plan*.

3.6. 36th Maintenance Squadron Commander (36 MXS/CC).

3.6.1. Ensure that TA CDDAR support contract requirements are provided to 36 CONS.

3.7. 734th Air Mobility Squadron Commander (734 AMS/CC).

3.7.1. Provide Subject Matter Expertise (SME), manpower, technical data, and specialized equipment to assist in CDDAR operations for Air Mobility Command (AMC) aircraft. If available, provide personnel to augment the 36 MXG upon request for operations involving other aircraft.

3.7.2. Coordinate CDDAR equipment and maintenance recovery team (MRT) support requests with HQ AMC for incidents involving AMC aircraft. 734 AMS personnel will maintain tow qualifications on C-5 and C-17 aircraft to support the removal of aircraft from runway, or any affected locations, for crash/recovery purposes.

3.8. 4th Reconnaissance Squadron Commander (4 RS/CC).

3.8.1. Provide SME, manpower, technical data, and specialized equipment to assist in CDDAR operations for assigned RQ-4 aircraft. If available, provide personnel to augment the 36 MXG upon request for operations involving other aircraft.

3.8.2. Provide RQ-4 familiarization training to 36 MXG CDDAR members annually.

3.8.3. Provide tow vehicle and RQ-4 tow bar for crash/recovery purposes as required.

3.9. U.S. Navy Helicopter Sea Combat (HSC) Squadron 25 Commander (HSC-25/CDR).

3.9.1. Provide SME, manpower, technical data, and specialized equipment to assist in CDDAR operations for HSC-25 assigned aircraft. If available, provide personnel to augment the 36 MXG upon request for operations involving other aircraft.

3.9.2. Provide familiarization training of assigned aircraft to 36 MXG CDDAR members annually.

3.9.3. Provide aerial survey support, if available, for ISB Investigating Officer and combat camera. At a time determined by the convening authority representative, provide support for CDDAR TC and transport for CDDAR TMs if location of crash is inaccessible via roadways.

3.10. CDDAR Team Chief (TC).

3.10.1. Prior to conducting composite response activities, will consult with Bioenvironmental and Environmental Engineering to determine risks specific to the incident. All Crash Recovery Team (CRT) members shall be trained and familiar with T.O. 00-105E-9, *Emergency Rescue Information*.

3.10.2. The appointed military TC will establish a CDDAR program binder comprised of a training plan, copy of the CDDAR TC appointment letter, memorandums of agreement, as applicable, and an inventory to identify the location of all CDDAR equipment, to include any deployed equipment. (Reference **para. 2.2.1**.). TA appointed TC(s) are responsible for maintaining equipment IAW PWS para. 3.3.

3.10.2.1. The appointed military TC will liaise with 36 MXS/MXMG (AGE WRM) to ensure accountability and serviceability of assigned Aircraft Battle Damage Repair (ABDR) equipment. Note – AGE WRM is solely responsible for the ABDR-39/A trailers, while Air Force Sustainment Center (AFSC)/A4M ABDR Program Office is responsible for attached tooling and equipment.

3.10.3. Coordinate with mission partner home bases and tenant organizations to establish memorandums of agreement that establish mutual support for CDDAR operations.

3.10.4. Maintain a secondary crash phone.

3.11. Transient Alert (TA).

3.11.1. Respond to aircraft-related emergencies as directed by IC and/or TC.

3.11.2. Assist in aircraft crash and recovery operations to include removal of disabled aircraft from the runway at the request of the CDDAR team as required.

3.11.3. Establish and maintain a CDDAR initial response trailer. Transient Alert will maintain and manage the trailer IAW PWS para.3.3.

Chapter 4

TRAINING

4.1. Training.

4.1.1. The appointed military CDDAR TC(s) will:

4.1.1.1. Develop and implement a training program IAW DAFI 21-101, AFI 36-2201, and T.O. 00-80C-1 Pg.2-8 para. **2.3.2** and **2.3.2.2**. Training plans will be reviewed and updated annually.

4.1.1.2. Assign recovery duties to task-qualified 36 MXG-assigned, permanent party members within 30 days of arrival, as well as personnel deployed more than 30 days. Special equipment qualifications may be recorded in either myTraining, the Career Field Education and Training Plan (CFETP), AF IMT 797, or the Maintenance Information System (MIS) as applicable.

4.1.1.3. Provide annual training comprised of, at a minimum:

4.1.1.3.1. Basic concepts of crash or disabled recovery procedures.

4.1.1.3.2. Safety precautions include hazards associated with initial response, hazardous liquids, composite materials and potentially hazardous cargo.

4.1.1.3.3. Aircraft lifting bag and control console operations.

4.1.1.3.4. Familiarity with crash trailer equipment, location of secondary equipment, and inspection requirements.

4.1.1.3.5. Training completion will be documented via MFR and maintained in the CDDAR program binder.

Chapter 5

PROCEDURES

5.1. Procedures.

5.1.1. All accident response agencies are notified according to 36 WG IEMP 10-2.

5.1.2. 36 MXG MOC will notify TA then 36 MXS Production Superintendent of the mishap and provide type of aircraft, location, amount of fuel on board, explosives on board and known extent of aircraft damage. The MOC Controller will designate one aircraft maintenance radio net as the primary maintenance recovery operation net and direct all personnel who are not directly involved in the recovery operation to switch to an alternate net and will use Crash Net as required. The MOC will also notify a leadership representative from each 36 MXG squadron (per MOC checklists) that a crash recovery is in progress and to stand by to respond with additional personnel and equipment as directed by IC or CDDAR TC.

5.1.3. Once alerted for a recovery operation, TA will assume primary responsibility for assembling the initial recovery team and designating the initial CDDAR TL. This will be accomplished in coordination with 36 MXS/MXM to ensure proper resource allocation and initial oversight. MXG-trained and appointed CDDAR TCs will augment TA's efforts, providing support to the on-scene TL.

5.1.4. 36th Operations Support Squadron (OSS) will notify 36 WG Command Post on secondary crash net to enable proper execution of appropriate notifications and checklists.

5.1.5. An Impoundment Official will be appointed by the affected unit and implement impoundment procedures for the applicable aircraft, maintenance documentation records, tools (Consolidated Tools Kit items), and all support equipment (e.g., Aerospace Ground Equipment) that may have been used on or played a role in the mishap sequence.

5.1.6. Other MXG squadrons will provide manpower and aircraft system expertise to the CDDAR TC as required.

5.1.7. The 36 WG/CC or designated representative will notify the IC of any special considerations for wreckage removal.

5.1.8. Control of the mishap scene belongs to the IC until released to the ROC or president of the ISB/SIB.

5.1.9. Removal or crash recovery of an aircraft begins when directed by the ROC/ISB/SIB. Depending upon circumstances, considerations for CDDAR operations may include preventing further damage to equipment, EOD considerations, and mission continuation time constraints.

5.1.9.1. Coordination with the ISB President, ROC, 36 WG/SE, and 36 MXG/QA are required to determine when all photographic and cataloging documentation for the incident is complete.

5.1.10. Remove or disturbance of equipment is unauthorized unless directed by the ISB President or the IC, to accomplish recovery operations or for security reasons. TC will seek approval from the IC (ROC or ISB/SIB President, if responsibility has been transferred).

5.1.11. The IC will ensure the aircraft is fire and explosive safe (hydrazine safe if applicable) prior to any removal operations. If required, the CDDAR team will don full-face filtered mask and PPE for composite aircraft incidents based on aircraft technical data from T.O. 00-105E-9, **Chapter 3**, and input from the Bioenvironmental Engineering office.

5.1.12. Once the emergency is over and recovery starts, the IC must officially transfer control of the site to the ROC. The EOC Director selects the ROC IAW TO 00-80C-1. The appointed ROC will have working knowledge of the hazards, activities, Hazardous Material (HAZMAT), and recovery procedures specific to the incident (e.g. maintenance officer for an aircraft mishap or a medical officer for a pandemic incident).

5.1.13. Qualified 36 LRS/LGRF personnel must be present during the appropriate (Fuels/Oil/Hydro) sample draw to ensure it is gathered correctly for testing.

5.1.14. Reference T.O. 42B-1-1 for fuels testing requirements and waivers by the Safety Investigation Board President (SIB).

5.2. Heavy Equipment Utilization. The CDDAR TC will advise the ROC of the most prudent method of aircraft removal given the condition of the incident site. The CDDAR TC and ROC will identify any equipment (e.g. bulldozers, flatbed trucks, front-end loaders, cranes or forklifts) or disaster response activities, (e.g. EOD, firefighting, decontamination or rescue) required for removal operations and begin coordinating for the additional support IAW 36 WG IEMP 10-2.

5.2.1. If heavy equipment is required on the airfield, the CDDAR TC will coordinate closely with the Airfield Manager or designated representative.

5.2.2. The ROC will use all the resources necessary to safely account for the CDDAR aircraft. Under certain conditions, time may not permit the use of normal or typical sourcing methods. As needed, all 36 WG assets may be utilized for recovery operations.

5.3. Civil Aircraft Incident. Civil aircraft CDDAR is normally accomplished by the company owning the asset due to damage and liability concerns. The individual or company responsible for the affected aircraft will coordinate with Judge Advocate (36 WG/JA) to provide a recommendation to the 36 WG/CC before removal or recovery of a civil aircraft is performed by a contractor or military CDDAR team.

5.4. Off-base Recovery.

5.4.1. 36 MXG/MOC will alert the Vehicle Operations Dispatcher that the following vehicles may be required for dispatch. The dispatcher will recall from use or reserve the following vehicles.

5.4.1.1. One six-passenger, four-wheel-drive truck.

5.4.1.2. One 1.5-ton truck or equivalent.

5.4.1.3. Two 7.5-ton tractors or larger with 40-foot trailers for transporting equipment and wreckage, as needed.

5.4.2. Once the wreckage is released to the CDDAR team, augmented support will help load the wreckage for return to Andersen AFB (or designated wreckage assembly point). A facility

large enough to house wreckage will be identified and secured, allowing only essential authorized personnel access to the facility.

5.5. Underwater Salvage. 36 WG leadership will initiate requests for Navy diving or salvage operations as required.

Chapter 6

EQUIPMENT

6.1. Equipment. All initial CDDAR response equipment and Personal Protective Equipment (e.g. gloves, hard hats, reflective vests, composite material protective equipment), will be stored in the CDDAR response trailer. All equipment will have identification markings and be annotated on an equipment inventory list that is maintained in the trailer. The trailer and equipment will be inspected and inventoried at least semi-annually by the CDDAR Team and documented in TCMax.

6.1.1. The following equipment, tools, vehicles and other supplies/consumables may be required for CDDAR operations:

6.1.2. Aircraft lifting bags and control consoles.

6.1.2.1. Air compressors (MC-7) or equivalent.

6.1.2.2. Proper tow vehicle.

6.1.2.3. If adequate equipment or qualified operator(s) are available, 36 CONS will provide contractual support to aid in acquisition.

6.1.2.4. Tow bars for assigned and deployed aircraft.

6.1.2.5. Light carts as required for night recovery operations.

6.1.2.6. General purpose toolbox.

6.1.2.7. Shoring.

6.1.2.8. Semi-trailer, 40-ton minimum capacity, low bed.

6.1.2.9. Temporary runway matting and 50-ton load meters for aircraft debogging.

6.1.2.10. Disabled wheel dolly.

6.1.2.11. 36 LRS will anticipate a requirement for a 7.5-ton or larger tractor, 40-foot trailer, and 10K forklift with driver.

6.1.2.12. 36 CES will anticipate supply front-end loaders with driver.

6.2. ABDR Equipment. The military CDDAR TC will monitor status of the ABDR mobility Unit Type Code equipment requirements (HFUAS and HFUAA). AFSC/A4M will ensure equipment accountability and availability to deploy and will report any shortfalls or limiting factors to the 36 MXG/CC.

6.3. Additional Equipment. The ROC will coordinate with applicable units for additional recovery operations support as required.

6.4. Equipment Accountability and Reporting. As requested by the 36 MXG/CC, the military CDDAR TC will furnish a report comprised of the CDDAR Defense Property and Accountability System (DPAS) or equipment custodian asset report(s) detailing inventories that identify items in excess or shortage.

CHARLES D. COOLEY, Brigadier General, USAF
Commander

Attachment 1

GLOSSARY OF REFERENCES AND SUPPORTING INFORMATION

References

36 WG *Installation Emergency Management Plan (IEMP) 10-2*

DAFI 10-2501, *Air Force Emergency Management (EM) Program Planning and Operations*

AFPD 21-1, *Maintenance of Military Material*

DAFI 21-101 and CAF SUP 1, *Aerospace Equipment Maintenance Management, Documentation, Policy, and Procedures*

DAFI 21-103, *Equipment Inventory, Status and Utilization Reporting*

36 WG PLAN 91-204, *Aircraft Mishap Response Plan*

T.O. 00-105E-9, *Emergency Rescue Information*

T.O. 00-80C-1*, Crashed, Damaged, Disabled, Aircraft Recovery Manual*

Prescribed Forms

None

Adopted Forms

AF Form 847*, Recommendation for Change of Publication*

Abbreviations and Acronyms

AFMAN—Air Force Manual

AFRC—Air Force Reserve Command

AFRIMS—Air Force Records Information Management System

AGE—Aerospace Ground Equipment

ABDR—Aircraft Battle Damage Repair

CEMP—Comprehensive Emergency Management Plan

CDDAR—Crashed, Damaged, or Disabled Aircraft Recovery

CRT—Crash Recovery Team

CTK—Composite Tool Kit

EOC—Emergency Operations Center

EOD—Explosive Ordnance Disposal

HAZMAT—Hazardous Materials

HQ—Headquarters

IAW—In Accordance With

IC—Incident Commander

ICC—Installation Control Center

IEMP—Installation Emergency Management Plan

IFE—In-Flight Emergency

ISB—Interim Safety Board

JAG—Judge Advocate General

MOC—Maintenance Operations Center

MRT—Maintenance Recovery Team

NOTAM—Notice to Airmen

OPR—Office of Primary Responsibility

PPE—Personal Protective Equipment

QA—Quality Assurance

RDS—Records Disposition Schedule

REDHORSE—Rapid Engineer Deployable Heavy Operational Repair Squadron Engineer

ROC—Recovery Operations Chief

SCN—Secondary Crash Net

SIB—Safety Investigation Board

TC—Team Chief

TL—Team Lead

TO—Technical Orders

Terms

Carbon Fiber—A strong, stiff, thin fiber of nearly pure carbon, made by subjecting various organic raw materials to high temperatures, combined with synthetic resins to produce a strong, lightweight material used in construction of aircraft and spacecraft.

Debogging—Recovery of an aircraft that has sunk into a soft surface (to include asphalt).

Decontamination—The physical or chemical process of reducing and preventing the spread of contaminants from persons and equipment used at HAZMAT incident.

Emergency Operations Center (EOC)—The physical location at which the coordination of information and resources to support attack response and incident management activities normally takes place. An EOC may be a temporary facility or may be located in a more central or permanently established facility, perhaps at a higher level of organization within a jurisdiction. EOCs may be organized by major functional disciplines such as fire, security forces and medical services, by jurisdiction such as Federal, State, regional, county, city, tribal or a combination thereof.

Hydrazine—Hydrazine is highly alkaline. Hydrazine at room temperature is a clear, oily, fuming liquid with an odor similar to ammonia. It is hazardous to health in both the liquid and vapor form and is combustible and explosive. Hydrazine fuel (H-70) is a blend of 70% Hydrazine and 30% water and is used to power the Emergency Power Unit (EPU) on F-l6 series aircraft and the Emergency Start System (ESS) on U-2 series aircraft.

Incident Commander (IC)—The command function is directed by the IC, who is the person in charge at the incident and who must be fully qualified to manage the response. Major responsibilities for the IC include: performing command activities, such as establishing command; protecting life and property; controlling personnel and equipment resources; maintaining accountability for responder and public safety, as well as for task accomplishment; establishing and maintaining an effective liaison with outside agencies and organizations, including the EOC, when it is activated.

Initial Response—Resources initially committed to an incident.

Personal Protective Equipment (PPE)—Personal Protective Equipment (PPE) is equipment designed to protect individuals exposed to hazards from injury or illness in non-military unique occupational environments where OSHA or applicable AFOSH standards apply, including emergency response to CBRNE incidents in the United States.

Recovery—The development, coordination and execution of service- and site-restoration plans for impacted communities and the reconstitution of government operations and services through individual, private-sector, nongovernmental and public assistance programs that: identify needs and define resources; provide housing and promote restoration; address long-term care and treatment of affected persons; implement additional measures for community restoration; incorporate mitigation measures and techniques, as feasible; evaluate the incident to identify lessons learned; and develop initiatives to mitigate the effects of future incidents.

Recovery Operations Chief—The Recovery Operations Chief must be a subject matter expert in the hazards or activities within the incident site. If it is a HAZMAT incident, the organization or individual that assumes control of the site must be knowledgeable of the hazards and recovery procedures. The person in charge of that work should have an environmental engineering background and be familiar with HAZMAT clean-up requirements. If it is an aircraft incident, the recovery operations chief should be familiar with that aircraft or be a member of the interim aircraft mishap investigation team. The EOC Director should select the individual that will be in charge of the site.

Attachment 2

BARRIER ENGAGEMENT CHECKLIST

Table A2.1. Barrier Engagement Checklist.

NOTE: Aircraft commander and/or IC will determine if the aircraft is capable of self-extraction based on aircraft type and mechanical state. Self-extraction is only possible if the aircraft engages the BAK-12 barrier **SELF-EXTRACTION (SLINGSHOT METHOD)**			
STEP	C/W	N/A	PROCEDURE
1			Request barrier maintenance to lock cable in place
2			Marshall aircraft forward to place tension on the barrier cable. When all slack has been removed and cable appears to be taut, inform pilot to hold brakes and retard throttle to idle
3			When engine(s) is/are at idle, signal the pilot to release the brakes. If the aircraft does not roll far enough back to release the barrier cable, repeat steps 2 and 3.
4			Retract tail hook when hook is free from cable
5			Taxi aircraft to parking location.
6			Request barrier maintenance to rewind cable.
PULLING CABLE FROM TAIL HOOK (MANUAL METHOD)			
STEP	C/W	N/A	PROCEDURE
1			Establish communication with aircraft commander and brief pilot on the procedure
2			Install all safety devices
3			Attach barrier tow cable to barrier cable next to tail hook
4			Position tow vehicle in front of aircraft and attach barrier tow cable to the tow vehicle
5			Pull barrier cable far enough forward to release aircraft tail hook
6			Retract tail hook
7			Remove barrier tow cable and tow vehicle
8			Taxi aircraft to parking location
9			Request barrier maintenance to rewind cable

AIRCRAFT SHUT DOWN AND TOW (ALTERNATE METHOD)

STEP	C/W	N/A	PROCEDURE
1			Install all safety devices
2			Shut aircraft down
3			Attach tow bar to aircraft and tow vehicle
4			Push aircraft back to release barrier cable
5			Raise aircraft tail hook
6			Proceed on with normal aircraft towing procedure
7			Request barrier maintenance to rewind cable

Attachment 3

BLOWN TIRE CHECKLIST

Table A3.1. Blown Tire Checklist.

STEP	C/W	N/A	PROCEDURE
1			CONTACT OWNING AGENCY
2			PICK UP TOW VEHICLE & APPLICABLE TOW BAR
3			CALL/PICK UP WHEEL DOLLY (AGE)
4			AFTER FD RELEASES ACFT/CHECK HOT BRAKES
5			SAFE AIRCRAFT
6			SHUTDOWN AIRCRAFT
7			CALL TOWER FOR TOW CLEARANCE
8			HOOK UP TOW BAR AND TOW VEHICLE
9			PUT ACFT ON DISABLED WHEEL DOLLY
10			TOW VEHICLE TO PARKING SPOT
11			CALL TOWER TO CANCEL TOW

Attachment 4

AIRCRAFT DEBOGGING

Table A4.1. Aircraft Debogging.

Task	ITEM (Circle if Applicable)	X IF ACTION IS REQUIRED	NOTES
Stop or slow the Aircraft sinking	Reduce tire air pressure Defuel Remove cargo Remove munitions Other		
Assess extent of bog	NLG sunk to_____ Rt MLG sunk to_____ Lt MLG sunk to_____		
Assess aircraft structural integrity	Good, ready to tow Damaged, replace gear Damaged, consult engineering		
Aircraft preparation	Safety landing gear Reduce weight Jack aircraft Bag lift aircraft Other		
Tow plan	**Note**: transition NLG from soft ground to pavement on a shallow slope and straight on) Use winch Tow backward Tow forward, create ramp, then tow back Tow backward then turn before transition		

Ground preparation needed for aircraft movement	None Excavate Plywood or steel plate over Timbers Plywood Compacted gravel Pierced steel planking Cargo pallets Rapid runway material Portable Roadway material Other		Width of path: Length of path:
Additional preparation for NLG transition	None Create ramp (write desired materials here)		Width of ramp: Length of ramp:
Ground preparation for Tow Vehicle	None Sand Other (write desired materials here)		
Estimate towing force needed	Level pavement drawbar pull Multiply by additions Added resistance of soft ground_____ Estimated force on tow ropes_____		
Tow rope	Quantity_____ Length_____		

Bridging material	Rope Chain Ground stakes (Quantity)_____ Other _____		Length of bridging material (Not the length of tow rope) _____
Tow Vehicles	Type_____ Quantity _____		