

Torque quick-reference v0.99.20

Torque is safety-critical and looked up constantly — but it had no page (only buried in procedures/Work Order). New /torque surfaces it, with a unit converter.

Torque quick-reference

Converter — ft-lb · in-lb · N·m

30

ft-lb

360

in-lb

40.67

N·m

30-35 ft-lb = 360...420 in-lb · 40.67...47.45 N·m

“Tighten the alternator mounting bolts to 30-35 ft-lb in the sequence shown.”

HMMWV M998 · TM 9-2320-280-24P · p.215

[view page ↗](#)

WHAT IT DOES

Search a part / NSN / fastener → every cited torque value (from /api/torque), each with context + page citation that opens the real page in Deep-Zoom.
Live converter + per-result conversion to the other two units.
Parses '30-35 ft-lb', '18 in-lb', '45 N·m' (ranges handled).

VERIFIED / R1

- inline JS passes node --check; math verified (30 ft-lb = 40.67 N·m = 360 in-lb).
- FOUND & FIXED a parse bug: unit normalizer didn't strip the '.' in N·m → 45 N·m returned null.
- Wired: /torque in _PAGES · in palette + Tools menu · in verify_ui.py. Citations → /deepzoom.
- Additive & rollbackable: one page + one route + two menu entries. No index writes (R1/R6).