

Modal aligned to the 104th sheet header — built

v0.15.0 · 1:1 field order & labels · header fields always shown · live preview · required = Bumper# + Fault. Additive (R1).

Start a maintenance session

Header fields match the 104th sheet — what you fill is what prints.

FIND A PART · SEARCH ONLY — DOES NOT PRINT ON THE SHEET

WHAT DO YOU NEED?

gasket water pump

PARTS REQUEST SHEET HEADER · FILLS THE 104TH BLOCKS

MECHANIC'S NAME (PRINT/SIGN)

SPC R. Alvarez

BUMPER# *

B-14

FAULT *

No-start; alt not charging

TM

TM 9-2320-280-20-2

UOC

—

TECH STATUS

NMC

MOTOR SERGEANT / SENIOR MECHANIC

SFC J. Doe

LIVE SHEET-HEADER PREVIEW

104TH ECC PARTS REQUEST SHEET

(FILL OUT ALL BLOCKS)

MECHANIC'S NAME (PRINT/SIGN): SPC R. Alvarez

BUMPER#: B-14 FAULT: No-start; alt not charging

TM: TM 9-2320-280-20-2 UOC: — TECH STATUS: NMC

MOTOR SERGEANT / SENIOR MECHANIC: SFC J. Doe

Start session & search

DATA FLOW · modal field → SESSION key → sheet block

modal id	SESSION key	104th block
#m_mechanic	→ mechanic	→ MECHANIC'S NAME (PRINT/SIGN)
#m_bumper *	→ bumper	→ BUMPER#
#m_fault *	→ fault	→ FAULT
#m_tm	→ tm	→ TM
#m_uoc	→ uoc	→ UOC
#m_tech	→ tech_status	→ TECH STATUS
#m_motor	→ motor_sergeant	→ MOTOR SERGEANT / SR MECH

WHAT CHANGED

- **1:1 order & exact labels**
Modal rows now mirror the sheet (Mechanic → Bumper|Fault → TM|UOC|Tech → Motor sergeant), using the sheet's wording.
- **Header always visible**
UOC / Tech status / Motor sergeant no longer hidden in Simple view — they're header blocks ('fill all blocks'). Simple now only hides cart FEDLOG.
- **Live preview**
A paper-style header replica fills in as you type — what you enter = what prints (mirrors parts_request_pdf.py).
- **Required = Bumper# + Fault**
Unchanged; the rest are recommended. Search/express field set apart — it never prints.