




Note: Fix all off sheet designators linked to this sheet

Note: All signals above are GPIO, connect to any GPIO bank, whichever is best for routing, don't use PD2



Note: Interrupt pins, place on different pin numbers (same port okay), ease for routing

