



Note: Fix all off sheet designators linked to this sheet

Note: All signals above are GPIO, connect to any GPIO bank, whichever is best for routing




Note: Interrupt pins, place on different pin numbers (same port okay), ease for routing





Δ

- Note: Fix all off sheet designators linked to this sheet
- Note: All signals above are DS, connect to any DS input, whichever is best for routing, including the DS adc on page 10



A

R

4

C

TEMP-BATT-B IN <4B SIDE OF THE PROPERTY OF THE

Note: Fix all off sheet designators linked to this sheet

Note: All signals above are SE, connect to any SE input, whichever is best for routing

